

Control, Messaging Service Server Down Ericsson Centralized User Database

OPERATING INSTRUCTION

Copyright

© Ericsson AB 2016, 2017. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

Disclaimer

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

Trademark List

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



Contents

1	Introduction	1
1.1	Alarm Description	1
1.2	Prerequisites	2
2	Procedure	3
	Glossary	5
	Reference List	7



Control, Messaging Service Server Down



1 Introduction

This instruction concerns alarm handling for the Control, Messaging Service Server Down alarm.

1.1 Alarm Description

The alarm is issued when a Messaging Service server is down.

The possible alarm causes and the corresponding fault reasons, fault locations, and impacts are described in Table 1.

Table 1 Alarm Causes

Alarm Cause	Description	Fault Reason	Fault Location	Impact
The System Controller (SC) hosting a Messaging Service server is down.	The SC hosting a Messaging Service server instance is down.	The SC is rebooting or shut down, and cannot provide any service.	The SC holding the Messaging Service server.	Messaging Service server double redundancy is decreased, since the system is running with one less Messaging Service server instance.
A Messaging Service server goes down, or becomes unreachable.	The Messaging Service server process is not running.	The process has been stopped or killed, and cannot be started.	The Messaging Service server process running in the SC.	
A Messaging Service server does not provide any service.	The Messaging Service server process is running, but is unable to provide any service.	The Messaging Service server process is running, but in an unhealthy state.	The Messaging Service server process running in the SC.	

The alarm attributes are listed and explained in Table 2.

Table 2 Alarm Attributes

Attribute Name	Attribute Value
Auto Cease	Yes
Module	CONTROL
Error Code	7
Timestamp First	Date and time when the alarm was raised for the first time.
Repeated Counter	Number which indicates how many times the alarm was raised.
Timestamp Last	Date and time of the most recent alarm raised.
Resource ID	1.3.6.1.4.1.193.169.7.7.<IP>
Alarm Model Description	Messaging Service Server down, Control
Alarm Active Description	Control: Messaging Service Server <IP> is down, uuid: <UUID>



Attribute Name	Attribute Value
ITU Alarm Event Type	processingErrorAlarm (4)
ITU Alarm Probable Cause	softwareProgramError (546)
ITU Alarm Perceived Severity	(4) - Major
Originating Source IP	Node IP where the alarm was raised.
Sequence Number	Number which indicates the order in which alarms were raised.

In Table 2, the indicated variables are as follows:

- *<IP>* is the Internet Protocol (IP) address of the Messaging Service server that is down.
- *<UUID>* is the universally unique identifier of the computing resource (blade or VM). It is blank if it is not possible to figure out its value.

For more information about Messaging Service, refer to *CUDB High Availability*, Reference [1].

For further information about attribute descriptions, refer to *CUDB Node Fault Management Configuration Guide*, Reference [2].

1.2 Prerequisites

This section provides information on the documents, tools and conditions that apply to the procedure.

1.2.1 Documents

Before starting this procedure, ensure that you have read the following documents:

- *CUDB Node Fault Management Configuration Guide*, Reference [2], regarding alarm configuration.
- *CUDB Node Logging Events*, Reference [3], regarding logs related to the Messaging Service server.

1.2.2 Tools

Not applicable.

1.2.3 Conditions

Not applicable.



2 Procedure

In case the alarm is raised, do the following:

1. Wait for a short time for the alarm to clear. If the alarm clears, no further actions must be taken. If it is not cleared after a short period of time, continue with the next step.
2. If the SC hosting the Messaging Server down is rebooting, wait until the reboot finishes. If the alarm clears, no further actions must be taken.
3. If the SC is permanently down, alarm *SAF, CLM Cluster Node Unavailable* must be raised. Refer to *SAF, CLM Cluster Node Unavailable*, Reference [4] for further information.
4. If the SC is not down, access the SC hosting the Messaging Server down and try to restart the process manually with the following command:

`cudbManageMsgSrvServer restart`
5. If the problem is not identified, or the alarm does not cease with the measures taken, consult the next level of maintenance support. Further actions are outside the scope of this instruction.



Control, Messaging Service Server Down



Glossary

For the terms, definitions, acronyms and abbreviations used in this document, refer to *CUDB Glossary of Terms and Acronyms*, Reference [5].



Control, Messaging Service Server Down



Reference List

CUDB Documents

- [1] *CUDB High Availability*
- [2] *CUDB Node Fault Management Configuration Guide*
- [3] *CUDB Node Logging Events*
- [4] *SAF, CLM Cluster Node Unavailable*
- [5] *CUDB Glossary of Terms and Acronyms*