

# Change Target-Based Access Control

## OPERATING INSTRUCTIONS

**Copyright**

© Ericsson AB 2014, 2015. All rights reserved. No part of this document may be reproduced in any form without the written permission of the copyright owner.

**Disclaimer**

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson shall have no liability for any error or damage of any kind resulting from the use of this document.

**Trademark List**

All trademarks mentioned herein are the property of their respective owners. These are shown in the document Trademark Information.



# Contents

<b>1</b>	<b>Introduction</b>	<b>1</b>
1.1	Prerequisites	1
<b>2</b>	<b>Procedure</b>	<b>3</b>





# 1 Introduction

This document describes how to change the Target-Based Access Control (TBAC). TBAC is a selective authentication method that determines if a user is allowed to access a specific Managed Element (ME) based on the target type value.

A target type value can have been set at initial configuration. The Security Administrator needs to change the target type value when the existing settings do no longer match the operator organization needs, for example, in the following situations:

- The ME needs to become part of a different geographical domain.
- The ME needs to become part of a different functional domain.
- The ME needs to become part of a different skills domain.

## 1.1 Prerequisites

This section describes the prerequisites, which must be fulfilled before using the procedure.

### 1.1.1 Conditions

The following conditions must apply:

- The user has the System Security Administrator role.
- The user profiles are updated with tagged restrictions.
- The new target type value is known.
- An Ericsson Command-Line Interface (ECLI) session in Exec mode is in progress.
- Profile filter is set to ERICSSON\_FILTER.





## 2 Procedure

To change the TBAC:

1. Navigate to the `UserManagement` managed object, for example:

```
>dn ManagedElement=N0DE06ST,SystemFunctions=1,SecM=1,UserManagement=1
```

2. Enter Config mode:

```
(UserManagement=1)>configure
```

3. Set the target type, for example:

```
(config-UserManagement=1)>targetType="ims.kista.se"
```

The value is used when a role defined in the Lightweight Directory Access Protocol (LDAP) database is prefixed with the target type. Role definitions where the target type prefix does not match are skipped.

4. Commit the setting:

```
(config-UserManagement=1)>commit
```

5. Verify the result:

```
(UserManagement=1)>show
```

The following is an example output:

