



System Release 7.13

**ASTRO® 25
INTEGRATED VOICE AND DATA**

**GTR 8000 EXPANDABLE SITE
SUBSYSTEM**

May 2015



6871022P87-C

Copyrights

The Motorola products described in this document may include copyrighted Motorola computer programs. Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted computer programs. Accordingly, any copyrighted Motorola computer programs contained in the Motorola products described in this document may not be copied or reproduced in any manner without the express written permission of Motorola.

© 2015 Motorola Solutions, Inc. All Rights Reserved

No part of this document may be reproduced, transmitted, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without the prior written permission of Motorola Solutions, Inc.

Furthermore, the purchase of Motorola products shall not be deemed to grant either directly or by implication, estoppel or otherwise, any license under the copyrights, patents or patent applications of Motorola, except for the normal non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Disclaimer

Please note that certain features, facilities, and capabilities described in this document may not be applicable to or licensed for use on a particular system, or may be dependent upon the characteristics of a particular mobile subscriber unit or configuration of certain parameters. Please refer to your Motorola contact for further information.

Trademarks

MOTOROLA, MOTO, MOTOROLA SOLUTIONS, and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners.

European Union (EU) Waste of Electrical and Electronic Equipment (WEEE) directive



■ The European Union's WEEE directive requires that products sold into EU countries must have the crossed out trash bin label on the product (or the package in some cases).

As defined by the WEEE directive, this cross-out trash bin label means that customers and end-users in EU countries should not dispose of electronic and electrical equipment or accessories in household waste.

Customers or end-users in EU countries should contact their local equipment supplier representative or service centre for information about the waste collection system in their country.

This page intentionally left blank.

Contact Us

Motorola Solution Support Center

The Solution Support Center (SSC) is the primary Motorola Solutions support contact. Call:

- Before any software reload.
- To confirm troubleshooting results and analysis before removing and replacing a Field Replaceable Unit (FRU) and Field Replaceable Entity (FRE) to repair the system.

For...	Phone
United States Calls	800-221-7144
International Calls	302-444-9800

North America Parts Organization

For assistance in ordering replacement parts or identifying a part number, contact the Motorola Parts organization. Your first response when troubleshooting your system is to call the Motorola SSC.

For...	Phone
Phone Orders	800-422-4210 (US and Canada Orders) For help identifying an item or part number, select choice 3 from the menu.
	302-444-9842 (International Orders) Includes help for identifying an item or part number and for translation as needed.
Fax Orders	800-622-6210 (US and Canada Orders)

Comments

Send questions and comments regarding user documentation to documentation@motorolasolutions.com.

Provide the following information when reporting a documentation error:

- The document title and part number
- The page number with the error
- A description of the error

We welcome your feedback on this and other Motorola manuals. To take a short, confidential survey on Motorola Customer Documentation, go to docsurvey.motorolasolutions.com or scan the following QR code with your mobile device to access the survey.



This page intentionally left blank.

Document History

Version	Description	Date
6871022P87-A	First release of the <i>GTR 8000 Expandable Site Subsystem</i> manual.	November 2012
6871022P87-B	Second release of the <i>GTR 8000 Expandable Site Subsystem</i> manual.	July 2013
6871022P87-C	Third release of the <i>GTR 8000 Expandable Site Subsystem</i> manual. <ul style="list-style-type: none">• Revised Verifying Receiver Performance for FDMA Operation on page 306.• Added Verifying Receiver Performance in TTA Operation on page 308.	May 2015

This page intentionally left blank.

Contents

Copyrights.....	3
Contact Us.....	5
Document History.....	7
List of Figures.....	21
List of Tables.....	29
List of Processes.....	35
List of Procedures.....	37
About GTR 8000 Expandable Site Subsystem.....	39
What Is Covered In This Manual?.....	39
Helpful Background Information.....	39
Related Information.....	40
Chapter 1: GTR 8000 Expandable Site Subsystem Description.....	41
GTR 8000 Expandable Site Subsystem Overview.....	41
GTR 8000 Base Radio Components.....	42
Supported System Configurations.....	42
Supported Frequencies for Trunked IV and D.....	43
Supported Frequencies for Conventional Operation.....	43
Supported Frequencies for HPD.....	43
Overview of a GTR 8000 Expandable Site Subsystem in an ASTRO Repeater Site.....	43
Overview of a GTR 8000 Expandable Site Subsystem in an ASTRO 25 Express System.....	44
Overview of a GTR 8000 Expandable Site Subsystem in a Trunked Single-Site Repeater Configuration.....	44
Configuring The Ethernet LAN Switch.....	45
Overview of a GTR 8000 Expandable Site Subsystem in a Trunked IP Simulcast Subsystem.....	46
Overview of a GTR 8000 Expandable Site Subsystem in a High Performance Data (HPD) Site.....	46
Overview of a GTR 8000 Base Radio in Conventional Architectures.....	46
ASTRO 25 Conventional Base Radio.....	47
Analog Conventional Base Radio.....	48
Overview of a GTR 8000 Expandable Site Subsystem in a Trunked 3600 System.....	48
Power Efficiency Package.....	49
GTR 8000 Expandable Site Subsystem for Trunked IP Simulcast.....	50
GTR 8000 Expandable Site Subsystem for ASTRO 25 Repeater.....	53
GTR 8000 Expandable Site Subsystem for ASTRO 25 Express System.....	54
GTR 8000 Expandable Site Subsystem for HPD.....	56

GTR 8000 Expandable Site Subsystem for Conventional.....	57
GTR 8000 Expandable Site Subsystem for Trunked 3600 IntelliRepeater Site.....	59
GTR 8000 Expandable Site Subsystem for Trunked 3600 Simulcast Subsystem.....	60
Ordering Options.....	61
GTR 8000 Expandable Site Subsystem RFDS Transmit Path.....	61
GTR 8000 Expandable Site Subsystem RFDS Receive Path.....	62
GCP 8000 Site Controller Modules (HPD, ASTRO 25 Repeater, and ASTRO 25 Express).....	64
GPB 8000 Reference Distribution Module.....	65
Expansion Hub.....	66
GGM 8000 Gateway.....	67
GTR 8000 Expandable Site Subsystem Specifications.....	67
Specifications for GTR 8000 Expandable Site Subsystem for HPD (700/800 MHz).....	68
GTR 8000 Expandable Site Subsystem Industry Canada for HPD (700/800 MHz).....	71
Specifications for GTR 8000 Expandable Site Subsystem for Integrated Voice and Data (700/800 MHz).....	71
GTR 8000 Expandable Site Subsystem Industry Canada for Integrated Voice and Data (700/800 MHz).....	76
Specifications for GTR 8000 Expandable Site Subsystem for Integrated Voice and Data (900 MHz).....	76
GTR 8000 Expandable Site Subsystem Industry Canada for Integrated Voice and Data (900 MHz).....	80
Specifications for GTR 8000 Expandable Site Subsystem for Integrated Voice and Data (UHF R1, 380–435 MHz).....	80
GTR 8000 Expandable Site Subsystem Industry Canada for Integrated Voice and Data (UHF R1, 380–435 MHz).....	83
Specifications for GTR 8000 Expandable Site Subsystem for Integrated Voice and Data (UHF R2, 435–524 MHz).....	84
GTR 8000 Expandable Site Subsystem Industry Canada for Integrated Voice and Data (UHF R2, 435–524 MHz).....	88
Specifications for GTR 8000 Expandable Site Subsystem for Integrated Voice and Data (VHF 136–174 MHz).....	88
GTR 8000 Expandable Site Subsystem Industry Canada for Integrated Voice and Data (VHF 136–174 MHz).....	92
Specifications for the GCP 8000 Site Controller and GPB 8000 Reference Distribution Module.....	92
Specifications for the Expansion Hub.....	93
GPS Unit Cable Length Specifications.....	93
Receive Expansion Cable Length Specifications.....	93
GCP 8000 Site Controller Port Default Speed/Duplex Settings.....	93
XHub Port Default Speed/Duplex Settings.....	94
GPB 8000 Reference Distribution Module Port Default Speed/Duplex Settings.....	94
Chapter 2: GTR 8000 Expandable Site Subsystem Theory of Operations.....	97

Functions of the GTR 8000 Expandable Site Subsystem Modules.....	97
Function of the Transceiver Module.....	97
Transceiver Control Board.....	98
Transceiver RF Board	99
Transceiver External Interfaces.....	99
Function of the Power Amplifier Module.....	100
Power Amplifier Input/Output Connections.....	101
Function of the Fan Module.....	102
Function of the Power Supply.....	102
AC/DC Power Distribution.....	104
Power Supply Battery Charger.....	105
Battery Temperature Sensor Cable.....	105
ON/OFF Switch for Power Supply and Battery Charger.....	105
Power Supply Module - Backplane Connections.....	106
Function of the GCP 8000 Site Controller.....	106
Function of the GPB 8000 Reference Distribution Module (IP Simulcast with High Availability).....	107
Function of the GPB 8000 Reference Distribution Module (Trunked 3600 IntelliRepeater).....	107
Function of the Expansion Hubs.....	108
Junction Panels.....	109
AC/DC Power Distribution Module.....	112
Battery Pack Splitting.....	114
Removing the DC Bus Bars in a Power Distribution Module.....	115
Backplanes and Card Cages.....	115
RFDS Modules.....	116
RFDS - Duplexer (900 MHz).....	116
RFDS - Hybrid Combiner (900 MHz).....	117
RFDS - Site Preselector (700/800 MHz).....	122
RFDS - Site Preselector (UHF, 455–512 MHz).....	122
RFDS - (RMCs/LNAs).....	123
Site Receive Multicouplers/Low Noise Amplifiers (Site RMCs/LNAs).....	124
Cabinet Receive Multicouplers/Low Noise Amplifiers (Cabinet RMCs/LNAs)....	124
RFDS - RMC Pass Through Module.....	125
RFDS - Cavity Combiner (700/800 MHz).....	125
RFDS - Cavity Combiner (UHF).....	126
RFDS - Transmit Filter (700/800/900 MHz).....	127
RFDS - Transmit Filter (UHF, 450–509 MHz).....	128
RFDS - Diplexer (700/800 MHz).....	128
Power Monitor Unit (UHF/VHF/900 MHz).....	129

Chapter 3: GTR 8000 Expandable Site Subsystem Installation.....	131
Pre-Installation Tasks.....	131
Equipment Installation Process Overview.....	131
General Safety Precautions.....	132
GTR 8000 Base Radio Supplemental Safety Installation Requirements.....	133
DC Mains Grounding Connections.....	134
Disconnect Device Permanently Connected.....	134
Multiple Power Source.....	134
Connection to Primary Power.....	134
Replaceable Batteries.....	134
Maintenance Requiring Two People.....	134
Equipment Racks.....	134
Lifting Equipment Racks Horizontally.....	135
Lifting Equipment Racks Vertically.....	135
General Installation Standards and Guidelines.....	137
General Site Preparation Overview.....	137
General Equipment Inspection and Inventory Recommendations.....	138
General Placement and Spacing Recommendations.....	138
General Cabinet Bracing Recommendations.....	139
Mounting Cabinets or Racks to a Floor.....	139
General Bonding and Grounding Requirements.....	140
General Cabling Requirements.....	140
General Power Guidelines and Requirements.....	140
General AC Power Guidelines and Requirements.....	141
General Breaker Recommendations.....	141
General Battery Installation Recommendations.....	142
General Electrostatic Discharge Recommendations.....	142
FCC Requirements.....	142
Networking Tools.....	143
General Installation/Troubleshooting Tools.....	143
General Tools.....	143
Rack Tools.....	143
Technical Support for Installation.....	144
Site-Specific Information.....	145
GTR 8000 Expandable Site Subsystem Installation.....	145
Placement and Spacing.....	145
Floor Mounting the Cabinet Version of the GTR 8000 Expandable Site Subsystem	146
Floor Mounting the Open Rack Version of the GTR 8000 Expandable Site Subsystem.....	147

Power Connections.....	148
Power Distribution Module Power Connections.....	149
DC Power Connection Wire Gauge Calculations for Integrated Voice and Data.....	149
DC Power Connection Wire Gauge Calculations for HPD.....	150
Battery Temperature Sensor Mounting.....	151
Grounding	153
GTR 8000 Expandable Site Subsystem Grounding.....	154
Backplanes and Card Cages.....	154
GTR 8000 Expandable Site Subsystem Backplane Connections for HPD.....	155
GTR 8000 Expandable Site Subsystem Backplane Connections for an ASTRO 25 Repeater Site.....	157
GTR 8000 Expandable Site Subsystem Backplane Connections for IP Simulcast Remote Sites.....	159
GTR 8000 Expandable Site Subsystem Backplane Connections for ASTRO 25 Express System.....	161
GTR 8000 Expandable Site Subsystem Backplane Connections for a Trunked 3600 IntelliRepeater Site.....	163
GTR 8000 Expandable Site Subsystem Backplane Connections for Trunked 3600 Simulcast Remote Sites.....	165
GTR 8000 Expandable Site Subsystem Power Supply Backplane.....	167
Front Transceiver Ports.....	167
System Connector Ports (Conventional).....	169
System Connector Ports (Trunked 3600).....	172
Wireline Port Pin-Outs.....	174
Microphone Port Pin-Outs.....	175
Speaker Port Pin-Outs.....	175
V.24 Port Pin-Outs.....	176
ASYNCRS-232 Cable Pin-Outs.....	176
GTR 8000 Base Radio Part 68 Information.....	177
GCP 8000 Site Controller and GPB 8000 Reference Distribution Module Ports (Front).....	178
Expansion Hub Connections.....	180
Junction Panel Connections.....	181
Junction Panel Connections for an ASTRO 25 Repeater Site (700/800/900 MHz and UHF R2 435–524 MHz).....	181
Junction Panel Connections for an ASTRO 25 Repeater Site (UHF R1 380– 435 MHz and VHF 136–174 MHz).....	187
Junction Panel Connections for a Trunked IP Simulcast Site (700/800/900 MHz and UHF R2 435–524 MHz) (Standard Configuration).....	191
Junction Panel Connections for a Trunked IP Simulcast Site (UHF R1 380– 435 MHz and VHF 136–174 MHz) (Standard Configuration).....	194
Junction Panel Connections for HPD (700/800 MHz).....	195

Junction Panel Connections for an ASTRO 25 Express System (700/800/900 MHz and UHF R2 435–524 MHz).....	198
Junction Panel Connections for an ASTRO 25 Express System (UHF R1 380–435 MHz and VHF 136–174 MHz).....	201
Junction Panel Connections for a Trunked IP Simulcast (High Availability Configuration).....	205
Junction Panel Connections for a Trunked IP Simulcast Site (700/800/900 MHz and UHF R2 435–524 MHz) (High Availability).....	205
Junction Panel Connections for a Trunked IP Simulcast Site (UHF R1 380–435 MHz and VHF 136–174 MHz) (High Availability).....	211
Junction Panel Connections for a Conventional Simulcast Cabinet Within a Trunked IP Simulcast High Availability Site.....	215
Junction Panel Connections for a Conventional Simulcast Cabinet within a Trunked IP Simulcast High Availability Site (700/800/900 MHz and UHF R2 435–524 MHz).....	215
Junction Panel Connections for a Conventional Simulcast Cabinet within a Trunked IP Simulcast High Availability Site (UHF R1 380–435 MHz and VHF 136–174 MHz).....	217
Junction Panel Connections for a Conventional Cabinet Within a Conventional Site.....	219
Junction Panel Connections for a Conventional Cabinet within a Conventional Site (700/800/900 MHz and UHF R2 435–524 MHz).....	220
Junction Panel Connections for a Conventional Cabinet within a Conventional Site (UHF R1 380–435 MHz and VHF 136–174 MHz).....	222
Junction Panel Connections for a Trunked 3600 IntelliRepeater Site.....	224
Junction Panel Connections for a Trunked 3600 IntelliRepeater Site (800/900 MHz and UHF R2 435–524 MHz).....	225
Junction Panel Connections for a Trunked 3600 IntelliRepeater Site (UHF R1 380–435 MHz and VHF 136–174 MHz).....	229
Junction Panel Connections for a Trunked 3600 Simulcast Subsystem.....	233
Junction Panel Connections – GTR 8000 Expandable Site Subsystem for a Trunked 3600 Simulcast Subsystem (800/900 MHz and UHF R2 435–524 MHz).....	233
Junction Panel Connections – GTR 8000 Expandable Site Subsystem for a Trunked 3600 Simulcast Subsystem (UHF R1 380–435 MHz and VHF 136–174 MHz).....	236
Expansion to Net AUX Conversion Cables.....	237
GPS Unit Installation for a High Availability Configuration.....	238
Installing the GPS Units.....	239
GPS Equipment.....	239
Alarm Indication (No Lock on GPS Signal).....	240
GPS Lightning Arrestor.....	240
Installation/Troubleshooting Tools.....	242
Quick Connect RF Coaxial Adapters for GTR 8000 Base Radio Support.....	243
Installing Device Software Prerequisites.....	243
Software Download.....	245

Installing Devices in the UNC.....	246
Discovering a Device in the UNC.....	247
Loading Device OS Images to the UNC.....	248
Loading Software to a Device.....	249
Enabling FTP Service.....	249
Transferring and Installing the OS Image.....	249
Inspecting Device Properties for Transferred and Installed Software.....	252
Disabling FTP Service.....	253
Chapter 4: GTR 8000 Expandable Site Subsystem Configuration.....	255
Configuration Software.....	255
Discovering a Device in the UNC.....	255
Security/Authentication Services.....	256
Device Configuration in CSS.....	257
Initially Configuring a Device in CSS.....	257
Connecting Through a Serial Port Link.....	258
Serial Connection Configurations.....	259
Setting the Device IP Address and Pairing Number in CSS.....	260
Pairing To a Comparator.....	260
Serial Security Services in CSS.....	261
Resetting SNMPv3 User Credentials to Factory Defaults in CSS.....	262
Connecting Through an Ethernet Port Link.....	262
Ethernet Connection Configurations.....	265
Setting the BR/CM Pairing Number in CSS.....	265
Setting the Date and Time in CSS.....	265
Changing SNMPv3 Configuration and User Credentials in CSS.....	265
Customizing the Login Banner in CSS.....	269
Setting the SWDL Transfer Mode in CSS.....	269
Manager IP Address Settings in CSS.....	270
NTP Server Settings in CSS.....	270
Setting the Local Password Configuration in CSS.....	271
Configuring the Parameters for the GTR 8000 Base Radio (Trunked Simulcast).....	272
Configuring the Parameters for the GTR 8000 Base Radio (Trunked Repeater).....	273
Configuring the Parameters for the GTR 8000 Base Radio (HPD).....	274
Configuring the Parameters for a GTR 8000 Base Radio (Conventional).....	274
Configuring the Parameters for a GTR 8000 Base Radio (Express).....	275
Configuring the Parameters for a GPB 8000 Reference Distribution Module.....	276
Configuring the Parameters for a GCP 8000 Site Controller.....	277
Configuring Tx Power Values and Battery Type.....	277
RMC Attenuation.....	278

RMC Attenuator DIP Switch Settings.....	280
RMC Attenuator Settings for Site with Two or More Cabinets (700/800/900 MHz).....	281
RMC Attenuator Settings for Single Cabinet Sites with No Site RMC (700/800/900 MHz).....	282
RMC Attenuator Settings for Site with Two or More Cabinets (UHF R2, 435–524 MHz).....	283
RMC Attenuator Settings for Single Cabinet Sites with No Site RMC (UHF R2, 435–524 MHz).....	283
RMC System Gain.....	284
Setting RMC System Gain.....	285
Inline Attenuator Value for a GTR 8000 Expandable Site Subsystem with a TTA for UHF R2 and 700/800/900 MHz.....	286
Calculating Inline Attenuator When a TTA is Installed.....	286
Configuring Centralized Authentication on Devices in VoyenceControl.....	287
1PPS Reference Synchronization.....	287
GPS Unit Cable Length Delay Offset Calibration.....	287
Setting the GPS Unit Cable Length Delay Offset Calibration in the CSS.....	288
Setting the GPS Unit Cable Length Delay Offset Calibration in the UNC.....	289
Chapter 5: GTR 8000 Expandable Site Subsystem Optimization.....	291
GCP 8000 Site Controller Reference Oscillator Alignment.....	291
Base Radio Internal Frequency Reference Oscillator Alignment.....	291
GTR 8000 Base Radio Time and Frequency Inputs.....	292
Cavity Combiner Tuning.....	293
Tuning the Cavity Combiner For Six Carriers.....	294
Changing Frequencies, Adding Channels, and Realigning a 700/800 MHz and UHF Cavity Combiner.....	299
Cavity Combiner Tuning for Twelve Carriers (700/800 MHz).....	300
Tuning the Cavity Combiner for up to Twelve Carriers for 700/800 MHz.....	301
Battery Equalization.....	303
ASTRO Simulcast Alignment (Trunked Operation).....	303
ASTRO/Analog Simulcast Alignment (Conventional Operation).....	303
Carrier Squelch Alignment.....	304
Tx Wireline Alignment	304
Rx Wireline Alignment.....	304
GTR 8000 Expandable Site Subsystem Performance Testing with a Service Monitor for Integrated Voice and Data.....	304
GTR 8000 Expandable Site Subsystem Performance.....	305
Deviation Standards (Digital Operation).....	305
Monitoring the Power Supply Module.....	305
Verifying Receiver Performance for FDMA Operation.....	306

Verifying Receiver Performance in TTA Operation.....	308
Verify Receiver Performance for APCO TDMA Operation.....	311
Verifying Receiver Performance (Analog Operation).....	311
Checking Receiver Sensitivity (Self-test Method) (IV and D).....	313
Monitoring the Transmitter Metering Points.....	314
Verifying Transmitter Performance (Digital Operation).....	314
Verifying Transmitter Performance (Analog Operation).....	316
GTR 8000 Expandable Site Subsystem Performance Testing with a Service Monitor for HPD.....	318
Setting Up the HPD Service Monitor for Testing the GTR 8000 Expandable Site Subsystem.....	319
Measuring HPD BR Tx Power, Frequency Accuracy, and Tx EVM.....	320
Measuring HPD BR Rx Sensitivity and Rx BER.....	323
Checking Receiver Sensitivity (Self-test Method) (HPD).....	326
Chapter 6: GTR 8000 Expandable Site Subsystem Maintenance.....	329
Fan Grill Cleaning Instructions.....	329
Base Radio Internal Frequency Reference Oscillator Alignment.....	329
GCP 8000 Site Controller Reference Oscillator Alignment.....	329
Chapter 7: GTR 8000 Expandable Site Subsystem Operation.....	331
Base Radio Operational States for Trunked Simulcast.....	331
Base Radio Operational States for Trunked Repeater and HPD.....	331
Base Radio Operational States for Conventional.....	332
Packet Data interactions with Multiple NACs.....	332
Supplementary Signaling interactions with Multiple NACs.....	332
Site Initialization for the GCP 8000 Site Controller (HPD and Repeater Sites).....	332
Site Initialization Process.....	333
GPB 8000 Reference Distribution Module Operational States.....	333
Illegal Carrier Determination Feature (Trunked).....	334
RF Channel Interference Determination Feature (Conventional).....	334
Chapter 8: GTR 8000 Expandable Site Subsystem Troubleshooting.....	335
GTR 8000 Base Radio General Troubleshooting.....	335
GCP 8000 Site Controller General Troubleshooting.....	338
GPB 8000 Reference Distribution Module General Troubleshooting.....	339
Troubleshooting Tools.....	340
Links and Components Monitoring in Unified Event Manager.....	341
Unified Event Manager Active Alarm Window Analyzation.....	341
Diagnostic Options in UEM.....	341
MOSCAD Network Fault Management.....	341
Device Troubleshooting in Unified Network Configurator.....	342

GTR 8000 Expandable Site Subsystem Troubleshooting in Configuration/Service Software (CSS).....	342
Internal Diagnostic Test Alarm Log.....	343
Local Password and SNMPv3 Passphrase Troubleshooting.....	343
Site Controller Failure Impact on GTR 8000 Base Radio for Trunked Operation.....	343
GPB 8000 Reference Distribution Module and GPS Failure Impact on GTR 8000 Base Radios.....	344
Motorola Solution Support Center.....	344
Information to Gather Before Calling Motorola.....	344
Where to Call for Service.....	344
Motorola Solution Support Center.....	345
Subcontractors.....	345
Chapter 9: GTR 8000 Expandable Site Subsystem FRU Procedures.....	347
Field Replaceable Units (FRUs) and Parts.....	347
Transceiver Hardware Generations.....	353
Transceiver Software and Feature Compatibilities.....	353
Identifying Transceiver Hardware Generation.....	354
Transceiver FRU Number Mappings.....	355
Power Amplifier Hardware Generations.....	356
Power Amplifier Software and Feature Compatibilities.....	356
Identifying Power Amplifier Hardware Generation.....	357
Power Amplifier FRU Number Mappings.....	357
Replacing a GTR 8000 Base Radio Transceiver Module.....	358
Replacing the GCP 8000 Site Controller Module.....	364
Replacing a GPB 8000 Reference Distribution Module (RDM).....	368
Replacing the Expansion Hub.....	373
Replacing the Fan Assembly.....	374
Replacing a Power Supply.....	376
Replacing a Power Supply Fan.....	377
Replacing a Power Amplifier.....	379
Replacing a GTR 8000 Expandable Site Subsystem Backplane.....	383
Replacing a GTR 8000 Expandable Site Subsystem Power Supply Backplane.....	389
Replacing a Subpanel on the GTR 8000 Expandable Site Subsystem Junction Panel.....	391
AC/DC Power Distribution Module Replacement.....	394
Replacing the AC/DC Power Distribution Module.....	396
Replacing Filters/Preselectors (700/800/900 MHz).....	398
Replacing a Site Preselector (UHF, 455–512 MHz).....	401
Replacing Transmit Filters (UHF, 450–509 MHz).....	402
Site RMC/LNA Module or Tray Replacement.....	404
Replacing a Site RMC/LNA Module or Tray.....	407

Individual Cabinet RMC/LNA Module Replacement.....	409
Replacing an Individual Cabinet RMC/LNA Module.....	412
Individual Pass Through Module Replacement.....	413
Replacing an Individual Pass Through Module.....	415
Cavity Combiner (700/800 MHz) Replacement.....	416
Replacing a Cavity Combiner (700/800 MHz).....	416
Replacing a Cavity Combiner (UHF).....	419
Replacing a Hybrid Combiner Fan Assembly.....	422
Replacing a Hybrid Combiner Module (900 MHz).....	422
Replacing a Duplexer (900 MHz).....	424
Replacing a Power Monitor Unit (PMU) (UHF/VHF/900 MHz).....	427
GGM 8000 Gateway Replacement.....	428
Chapter 10: GTR 8000 Expandable Site Subsystem Reference.....	429
LEDs.....	429
GTR 8000 Base Radio Transceiver LEDs.....	429
Transceiver Status and Alarm LEDs.....	430
Transceiver Ethernet Link Status LEDs.....	430
Transceiver Application-Controlled LEDs.....	431
Transceiver Services-Controlled LEDs.....	432
Transceiver Option Card Intercom LED.....	432
Power Amplifier LEDs.....	432
GCP 8000 Site Controller LEDs.....	433
GCP 8000 Site Controller Software and Services-Controlled LEDs	433
GCP 8000 Site Controller Status and Alarm LEDs.....	435
GCP 8000 Site Controller Active/Inactive Status LEDs.....	436
GCP 8000 Site Controller Link LEDs	437
GPB 8000 Reference Distribution Module LEDs.....	437
GPB 8000 Reference Distribution Module Software and Services-Controlled LEDs.....	437
GPB 8000 Reference Distribution Module Status and Alarm LEDs	439
GPB 8000 Reference Distribution Module Active/Inactive Status LEDs.....	440
GPB 8000 Reference Distribution Module Link LEDs	440
Expansion Hub LEDs.....	441
Fan Module LED.....	441
Hybrid Combiner Fan Module LED.....	442
Power Supply LEDs.....	442
RMC/LNA Alarm and Status LEDs.....	444
RFDS Equipment Specifications	444
GTR 8000 Expandable Site Subsystem RFDS Elevation Derating.....	444

Transmit Filter Specifications (700/800/900 MHz).....	445
Transmit Filter Specifications (UHF).....	445
Diplexer Specifications (700/800 MHz).....	446
Site Preselector Filter Specifications (700/800 MHz).....	447
Site Preselector Filter Specifications (UHF, 455–512 MHz).....	447
Cavity Combiner Specifications (700/800 MHz).....	448
Cavity Combiner Specifications (UHF).....	449
Receiver Multicoupler/Low Noise Amplifier (RMC/LNA) Specifications (700/800/900 MHz).....	450
Receiver Multicoupler/Low Noise Amplifier (RMC/LNA) Specifications (UHF).....	451
Cabinet RMC Pass Through Module Specifications.....	452
Power Monitor Unit (PMU) Specifications (UHF/VHF/900 MHz).....	453
Hybrid Module Specifications (900 MHz).....	453
Hybrid Combiner Specifications (900 MHz).....	454
Duplexer Specifications (900 MHz).....	454
Chapter 11: GTR 8000 Expandable Site Subsystem Disaster Recovery.....	457
Recovering the GTR 8000 Base Radio.....	457
Recovering the GPB 8000 Reference Distribution Module.....	457
Recovering the GCP 8000 Site Controller.....	457
Performing a Site Download.....	458

List of Figures

Figure 1: Single-Site Repeater Configuration 1.....	44
Figure 2: Single Site Repeater Configuration 2.....	45
Figure 3: GTR 8000 Expandable Site Subsystem for Trunked IP Simulcast – Standard Configuration.....	51
Figure 4: GTR 8000 Expandable Site Subsystem for Trunked IP Simulcast — High Availability Configuration.....	52
Figure 5: GTR 8000 Expandable Site Subsystem for Repeater Site Module Configuration.....	53
Figure 6: GTR 8000 Expandable Site Subsystem for ASTRO 25 Express System – Module Configuration.....	55
Figure 7: GTR 8000 Expandable Site Subsystem for HPD Module Configuration.....	56
Figure 8: GTR 8000 Expandable Site Subsystem – Conventional Only Configuration.....	58
Figure 9: GTR 8000 Expandable Site Subsystem — Trunked 3600 IntelliRepeater Site.....	59
Figure 10: GTR 8000 Expandable Site Subsystem – Trunked 3600 Simulcast Subsystem.....	60
Figure 11: GTR 8000 Expandable Site Subsystem for Transmit Path (700/800/900 MHz/UHF R2).....	62
Figure 12: GTR 8000 Expandable Site Subsystem for Receive Path (700/800/900 MHz/UHF R2)	63
Figure 13: GTR 8000 Expandable Site Subsystem for HPD Receive Path.....	63
Figure 14: GTR 8000 Expandable Site Subsystem for Receive Path (VHF or UHF R1).....	64
Figure 15: GCP 8000 Site Controller Module	64
Figure 16: GPB 8000 Reference Distribution Module.....	65
Figure 17: Expansion Hub	66
Figure 18: Transceiver Module (Front View).....	97
Figure 19: Transceiver Control Board Information Flow.....	98
Figure 20: Transceiver RESET Switch (viewable through the drop-down door).....	99
Figure 21: Transceiver Option Card Intercom Button (behind the fan module).....	100
Figure 22: Transceiver Module (Backplane Connections)	100
Figure 23: Power Amplifier Module.....	101
Figure 24: Power Amplifier (Backplane Connections).....	101
Figure 25: Fan Module	102
Figure 26: Power Supply	103
Figure 27: AC and DC Power Distribution in the GTR 8000 Expandable Site Subsystem.....	104
Figure 28: Power Supply Connections (Rear).....	106
Figure 29: Junction Panel with Primary Subpanel #1.....	109
Figure 30: Network Expansion Subpanel.....	110
Figure 31: Primary Subpanel #2.....	110
Figure 32: Rx Expansion Subpanel.....	110
Figure 33: Expansion Subpanel #1.....	111
Figure 34: Circuit Audio Subpanel.....	111

Figure 35: Six Receiver Input Subpanel.....	111
Figure 36: Six Transmit Output Subpanel.....	112
Figure 37: 3600 Simulcast Subpanel.....	112
Figure 38: AC/DC Power Distribution Module in GTR 8000 Expandable Site Subsystem (Cabinet Version - Side View).....	113
Figure 39: AC/DC Power Distribution Module in GTR 8000 Expandable Site Subsystem (Cabinet Version - Top View).....	113
Figure 40: AC/DC Power Distribution Module (Access Panel Removed)	113
Figure 41: Power Distribution Module–AC Distribution Block Diagram.....	114
Figure 42: AC/DC Power Distribution Module with Jumper Bars in Place.....	115
Figure 43: Duplexer (900 MHz) (Standalone Shown).....	116
Figure 44: Hybrid Combiner Fan Module Connections.....	118
Figure 45: Hybrid Combiner Modules.....	119
Figure 46: Single 6-Way Hybrid Combiner.....	119
Figure 47: Single 5-Way Hybrid Combiner.....	120
Figure 48: Single 4-Way Hybrid Combiner.....	120
Figure 49: Single 3-Way Hybrid Combiner.....	120
Figure 50: Single 2-Way Hybrid Combiner.....	121
Figure 51: Dual 3-Way Hybrid Combiner.....	121
Figure 52: Dual 2-Way Hybrid Combiner.....	121
Figure 53: Hybrid Combiner Fan Module.....	122
Figure 54: Site Preselector Filter (700/800 MHz).....	122
Figure 55: Site Preselector (UHF, 450–512 MHz).....	123
Figure 56: Site RMC Tray With Two RMC/LNA Modules (Front View).....	124
Figure 57: Site RMC Tray (Rear View).....	124
Figure 58: Cabinet RMC/LNA Module (Front View).....	125
Figure 59: RMC Pass Through Module.....	125
Figure 60: Cavity Combiner (700/800 MHz).....	126
Figure 61: Cavity Combiner (UHF).....	127
Figure 62: Transmit Filter (700/800/900 MHz).....	127
Figure 63: Transmit Filter (UHF, 450–509 MHz).....	128
Figure 64: Diplexer (700/800 MHz).....	129
Figure 65: Power Monitor Unit (PMU) (UHF/VHF/900 MHz).....	129
Figure 66: Warning Label on Hot Modules.....	133
Figure 67: Lengths and Angles for Lifting Using the Eyenuts.....	136
Figure 68: Proper Alignment of the Eyenuts.....	137
Figure 69: GTR 8000 Expandable Site Subsystem (Cabinet Version) - Floor Mounting Detail.....	146
Figure 70: GTR 8000 Expandable Site Subsystem (Open Rack Version) - Floor Mounting Detail.....	147
Figure 71: GTR 8000 Expandable Site Subsystem (7.5 Open Rack Shown) - Side View.....	148
Figure 72: Wire Gauge and Distance Guide.....	150

Figure 73: Battery Temperature Sensor Example 1.....	152
Figure 74: Battery Temperature Sensor Example 2.....	153
Figure 75: Rack Grounding.....	154
Figure 76: GTR 8000 Expandable Site Subsystem Backplane for HPD.....	155
Figure 77: GTR 8000 Expandable Site Subsystem Backplane for a Repeater Site.....	157
Figure 78: GTR 8000 Expandable Site Subsystem Backplane for an IP Simulcast Remote Site.....	159
Figure 79: GTR 8000 Expandable Site Subsystem Backplane for ASTRO 25 Express System.....	161
Figure 80: GTR 8000 Expandable Site Subsystem Backplane for a Trunked 3600 IntelliRepeater Site.....	163
Figure 81: GTR 8000 Expandable Site Subsystem Backplane for a Trunked 3600 Simulcast Remote Site.....	165
Figure 82: GTR 8000 Expandable Site Subsystem Power Supply Backplane.....	167
Figure 83: Transceiver Ports – Front.....	168
Figure 84: 50–Pin System Connector Pin-Outs (Conventional).....	171
Figure 85: 50–Pin System Connector Pin-Outs (Trunked 3600).....	174
Figure 86: Wireline Port Pin-Outs.....	175
Figure 87: Microphone Port Pin-Outs.....	175
Figure 88: Speaker Port Pin-Outs.....	176
Figure 89: Site Controller and RDM Ports – Front.....	179
Figure 90: Expansion Hub Connections	181
Figure 91: Junction Panel for the GTR 8000 Expandable Site Subsystem Prime Cabinet for an ASTRO 25 Repeater Site (700/800/900 MHz and UHF R2 435–524 MHz).....	182
Figure 92: Junction Panel for the GTR 8000 Expandable Site Subsystem Expansion Cabinet for an ASTRO 25 Repeater Site (700/800/900/UHF R2 435–524 MHz)	185
Figure 93: Junction Panel for the GTR 8000 Expandable Site Subsystem Prime Cabinet for an ASTRO 25 Repeater Site (UHF R1 380–435 MHz and VHF 136–174 MHz).....	187
Figure 94: Junction Panel for the GTR 8000 Expandable Site Subsystem Expansion Cabinet for an ASTRO 25 Repeater Site (UHF R1 380–435 MHz and VHF 136–174 MHz).....	190
Figure 95: Junction Panel for the GTR 8000 Expandable Site Subsystem for a Trunked IP Simulcast Site Standard Configuration (700/800/900 MHz and UHF R2 435–524 MHz).....	192
Figure 96: Junction Panel for the GTR 8000 Expandable Site Subsystem for a Trunked IP Simulcast Site Standard Configuration (UHF R1 380–435 MHz and VHF 136–174 MHz).....	194
Figure 97: Junction Panel for the GTR 8000 Expandable Site Subsystem for HPD (700/800 MHz)...	196
Figure 98: Junction Panel for the GTR 8000 Expandable Site Subsystem Prime Cabinet for an ASTRO 25 Express System (700/800/900 MHz and UHF R2 435–524 MHz).....	198
Figure 99: Junction Panel for the GTR 8000 Expandable Site Subsystem Expansion Cabinet for an ASTRO 25 Express System (700/800/900 MHz and UHF R2 435–524 MHz).....	200
Figure 100: Junction Panel for the GTR 8000 Expandable Site Subsystem Prime Cabinet for an ASTRO 25 Express System (UHF R1 380–435 MHz and VHF 136–174 MHz).....	202
Figure 101: Junction Panel for the GTR 8000 Expandable Site Subsystem Expansion Cabinet for an ASTRO 25 Express System (UHF R1 380–435 MHz and VHF 136–174 MHz).....	204
Figure 102: Junction Panel for the GTR 8000 Expandable Site Subsystem Prime Cabinet for a Trunked IP Simulcast Site High Availability (700/800/900 MHz and UHF R2 435–524 MHz).....	206

Figure 103: Junction Panel for the GTR 8000 Expandable Site Subsystem Expansion Cabinet for a Trunked IP Simulcast Site High Availability (700/800/900 MHz and UHF R2 435–524 MHz).....	209
Figure 104: Junction Panel for the GTR 8000 Expandable Site Subsystem Prime Cabinet for Trunked IP Simulcast Site High Availability (UHF R1 380–435 MHz and VHF 136–174 MHz).....	211
Figure 105: Junction Panel for the GTR 8000 Expandable Site Subsystem Expansion Cabinet for Trunked IP Simulcast Site High Availability (UHF R1 380–435 MHz and VHF 136–174 MHz).....	213
Figure 106: Junction Panel for a Simulcast Conventional GTR 8000 Expandable Site Subsystem Cabinet within a Trunked IP Simulcast High Availability Site (700/800/900/UHF R2 435–524 MHz)	216
Figure 107: Junction Panel for a Conventional Simulcast GTR 8000 Expandable Site Subsystem Cabinet within a Trunked IP Simulcast High Availability Site (UHF R1 380–435 MHz and VHF 136–174 MHz).....	218
Figure 108: Junction Panel for a Conventional GTR 8000 Expandable Site Subsystem Cabinet within a Conventional Site (700/800/900 MHz and UHF R2 435–524 MHz).....	220
Figure 109: Junction Panel for a Conventional GTR 8000 Expandable Site Subsystem Cabinet within a Conventional Site (UHF R1 380–435 MHz and VHF 136–174 MHz).....	223
Figure 110: Junction Panel for the GTR 8000 Expandable Site Subsystem Prime Cabinet for a Trunked 3600 IntelliRepeater Site (800/900 MHz and UHF R2 435–524 MHz).....	225
Figure 111: Junction Panel for the GTR 8000 Expandable Site Subsystem Expansion Cabinet for a Trunked 3600 IntelliRepeater Site (800/900 MHz and UHF R2 435–524 MHz).....	228
Figure 112: Junction Panel for the GTR 8000 Expandable Site Subsystem Prime Cabinet for a Trunked 3600 IntelliRepeater Site (UHF R1 380–435 MHz and VHF 136–174 MHz).....	230
Figure 113: Junction Panel for the GTR 8000 Expandable Site Subsystem Expansion Cabinet for a Trunked 3600 IntelliRepeater Site (UHF R1 380–435 MHz and VHF 136–174 MHz).....	232
Figure 114: Junction Panel for the GTR 8000 Expandable Site Subsystem for a Trunked 3600 Simulcast Subsystem (800/900 MHz and UHF R2 435–524 MHz).....	234
Figure 115: Junction Panel for the GTR 8000 Expandable Site Subsystem for a Trunked 3600 Simulcast Subsystem (UHF R1 380–435 MHz and VHF 136–174 MHz).....	236
Figure 116: Lightning Arrestor – System Connections.....	240
Figure 117: GPS Lightning Arrestor DS109–0129H-A Model Wiring.....	241
Figure 118: GPS Lightning Arrestor DS-IX-2L1M1DC48–IG Model Wiring.....	242
Figure 119: VoyenceControl Welcome Page.....	250
Figure 120: VoyenceControl Login Window.....	250
Figure 121: VoyenceControl Dashboard.....	251
Figure 122: SNMPv3 Security Level Option Prompt.....	256
Figure 123: CSS Login Banner.....	257
Figure 124: CSS Login Banner.....	259
Figure 125: SNMPv3 Passphrase Prompt.....	264
Figure 126: Remote Access Configuration Tab.....	270
Figure 127: Password Configuration Window.....	271
Figure 128: Cabinet RMC/LNA Module (Front View).....	278
Figure 129: RMC DIP Switch Example: 0 dB.....	279
Figure 130: RMC DIP Switch Example: 12 dB.....	279
Figure 131: CSS RMC Configuration Tab with GTR 8000 Expandable Site Subsystem Selected.....	285

Figure 132: GTR 8000 Expandable Site Subsystem Cavity Combiner for 700/800 MHz.....	293
Figure 133: GTR 8000 Expandable Site Subsystem Cavity Combiner for UHF.....	294
Figure 134: Cavity Combiner Tuning - Equipment Setup for 700/800 MHz and UHF.....	296
Figure 135: Six-Carrier ORL Response Curve — Untuned.....	297
Figure 136: Six-Carrier ORL Response Curve — Tuned.....	297
Figure 137: Six-Carrier ORL Response Curve — Tuned and Balanced.....	298
Figure 138: Phasing Harness.....	300
Figure 139: Phasing Harness.....	301
Figure 140: Twelve-Carrier ORL Response Curve — Untuned.....	302
Figure 141: Twelve-Carrier ORL Response Curve — Tuned.....	302
Figure 142: Twelve-Carrier ORL Response Curve — Tuned and Balanced.....	303
Figure 143: Metering Screen Window.....	306
Figure 144: Configuration for Modulation Fidelity Measurement (Aeroflex 2975 Series Service Monitor or Equivalent Analyzer).....	316
Figure 145: Configuration for Modulation Fidelity Measurement (Aeroflex 2975 Series Service Monitor or Equivalent).....	318
Figure 146: HPD Service Monitor Test Screen.....	319
Figure 147: HPD Service Monitor - RF Control Settings Window.....	321
Figure 148: CSS Test and Measurement Screen.....	322
Figure 149: HPD Service Monitor - Rx Meter Subscreen, Reset Soft Keys.....	322
Figure 150: HPD Service Monitor - RF Control Settings Window.....	324
Figure 151: CSS Test and Measurement Screen.....	325
Figure 152: HPD Service Monitor - Rx Meter Subscreen and Soft Keys.....	325
Figure 153: CSS Test And Measurement Screen.....	327
Figure 154: Site Initialization.....	333
Figure 155: MOSCAD Network Fault Management – Example.....	342
Figure 156: GEN 1 Transceiver Module.....	355
Figure 157: GEN 2 Transceiver Module.....	355
Figure 158: GEN 1 Power Amplifier Module.....	357
Figure 159: GEN 2 Power Amplifier Module.....	357
Figure 160: GTR 8000 Base Radio Transceiver Module.....	358
Figure 161: GTR 8000 Expandable Site Subsystem (repeater shown).....	359
Figure 162: GCP 8000 Site Controller FRU Module.....	364
Figure 163: GPB 8000 Reference Distribution Module.....	368
Figure 164: GTR 8000 Expandable Site Subsystem (trunked IP simulcast high availability shown)...	369
Figure 165: Expansion Hub FRU	374
Figure 166: Fan Assembly	375
Figure 167: Power Supply	376
Figure 168: Power Supply Fan.....	378
Figure 169: Power Amplifier Module.....	380

Figure 170: GTR 8000 Expandable Site Subsystem (repeater shown).....	381
Figure 171: Power Amplifier RF Cable (Front).....	382
Figure 172: GTR 8000 Expandable Site Subsystem Backplane Diagram.....	384
Figure 173: GTR 8000 Expandable Site Subsystem (repeater shown).....	385
Figure 174: Power Amplifier RF Cable (Front).....	386
Figure 175: GTR 8000 Expandable Site Subsystem Power Supply Backplane Diagram.....	389
Figure 176: Example of a GTR 8000 Expandable Site Subsystem Subpanels.....	392
Figure 177: AC/DC Distribution Module for the GTR 8000 Expandable Site Subsystem (Cabinet Version, Side View).....	394
Figure 178: AC/DC Power Distribution Module (Access Panel Removed)	395
Figure 179: Power Distribution Module- AC Distribution Block Diagram.....	395
Figure 180: Site Preselector Filter (700/800 MHz).....	398
Figure 181: Transmit Filter (700/800/900 MHz).....	399
Figure 182: Site Preselector Filter (UHF).....	401
Figure 183: GTR 8000 Transmit Filter (UHF, 450–509 MHz).....	402
Figure 184: Site RMC/LNA Modules in GTR 8000 Expandable Site Subsystem for HPD or TDMA....	405
Figure 185: Site RMC/LNA Modules in GTR 8000 Expandable Site Subsystem for Repeater Site....	406
Figure 186: Site RMC/LNA Module (Front View).....	406
Figure 187: GTR 8000 Site RMC Tray (Rear View).....	407
Figure 188: Cabinet RMC/LNA Modules in GTR 8000 Expandable Site Subsystem for HPD or TDMA.....	410
Figure 189: Cabinet RMC/LNA Modules in GTR 8000 Expandable Site Subsystem for Repeater Site.....	411
Figure 190: Individual Cabinet RMC/LNA Module (Front View).....	411
Figure 191: Pass Through Module.....	414
Figure 192: Individual Pass Through Module (Front View).....	414
Figure 193: Cavity Combiner (700/800 MHz).....	416
Figure 194: Cavity Combiner (700/800 MHz).....	417
Figure 195: Cavity Combiner (UHF).....	419
Figure 196: Hybrid Combiner Fan Assembly (Front View).....	422
Figure 197: Hybrid Combiner Modules (900 MHz).....	423
Figure 198: Duplexer Module (900 MHz).....	425
Figure 199: GTR 8000 Power Monitor Unit (PMU) (UHF/VHF/900 MHz).....	427
Figure 200: Transceiver LEDs (viewable through a drop-down door).....	429
Figure 201: Transceiver Option Card Intercom LED (viewable behind the fan module).....	432
Figure 202: Power Amplifier LEDs, viewable through a drop-down door.....	432
Figure 203: GCP 8000 Site Controller – Software and Services-Controlled LEDs	434
Figure 204: RDM Software and Services-Controlled LEDs	438
Figure 205: Expansion Hub LEDs.....	441
Figure 206: Fan Module-Alarm LED (lower right corner).....	442

Figure 207: Fan Module-Alarm LED (in the lower left corner).....	442
Figure 208: Power Supply Module.....	443
Figure 209: Cabinet RMC/LNA Module.....	444

This page intentionally left blank.

List of Tables

Table 1: Base Radio Modules and Function.....	42
Table 2: Standby Power Consumption.....	50
Table 3: General Specifications for GTR 8000 Expandable Site Subsystem for HPD (700/800 MHz)	68
Table 4: Transmitter (Cabinet Output)** Specifications for GTR 8000 Expandable Site Subsystem for HPD (700/800 MHz)	69
Table 5: Transmitter RF Distribution System for GTR 8000 Expandable Site Subsystem for HPD (700/800 MHz).....	69
Table 6: Receiver Specifications (Top of Cabinet) for GTR 8000 Expandable Site Subsystem for HPD (700/800 MHz)	70
Table 7: Receiver RF Distribution System for GTR 8000 Expandable Site Subsystem for HPD (700/800 MHz).....	71
Table 8: FCC Identification for GTR 8000 Expandable Site Subsystem for HPD (700/800 MHz)	71
Table 9: Industry Canada for GTR 8000 Expandable Site Subsystem for HPD (700/800 MHz).....	71
Table 10: General Specifications for GTR 8000 Expandable Site Subsystem for IV&D (700/800 MHz)	71
Table 11: Transmitter (Cabinet Output)** Specifications for GTR 8000 Expandable Site Subsystem for IV&D (700/800 MHz)	73
Table 12: Transmitter RF Distribution System for GTR 8000 Expandable Site Subsystem for IV&D (700/800 MHz).....	74
Table 13: Receiver (Top of Cabinet) Specifications for GTR 8000 Expandable Site Subsystem for IV&D (700/800 MHz)	74
Table 14: Receiver RF Distribution System for GTR 8000 Expandable Site Subsystem for IV&D (700/800 MHz).....	75
Table 15: FCC Identification for GTR 8000 Expandable Site Subsystem for IV&D (700/800 MHz)	75
Table 16: Industry Canada for GTR 8000 Expandable Site Subsystem for IV&D (700/800 MHz).....	76
Table 17: General Specifications for GTR 8000 Expandable Site Subsystem for IV&D (900 MHz)	76
Table 18: Transmitter (Cabinet Output)** Specifications for GTR 8000 Expandable Site Subsystem for IV&D (900 MHz)	78
Table 19: Transmitter RF Distribution System for GTR 8000 Expandable Site Subsystem for IV&D (900 MHz).....	78
Table 20: Receiver (Top of Cabinet) Specifications for GTR 8000 Expandable Site Subsystem for IV&D (900 MHz)	78
Table 21: Receiver RF Distribution System for GTR 8000 Expandable Site Subsystem for IV&D (900 MHz).....	79
Table 22: FCC Identification for GTR 8000 Expandable Site Subsystem for IV&D (900 MHz)	79
Table 23: Industry Canada for GTR 8000 Expandable Site Subsystem for IV&D (900 MHz).....	80
Table 24: General Specifications for GTR 8000 Expandable Site Subsystem for IV&D (UHF R1, 380–435 MHz).....	80
Table 25: Transmitter (Cabinet Output) Specifications for GTR 8000 Expandable Site Subsystem for IV&D (UHF R1, 380–435 MHz).....	82

Table 26: Receiver (Top Cabinet) Specifications for GTR 8000 Expandable Site Subsystem for IV&D (UHF R1, 380–435 MHz).....	82
Table 27: FCC Identification for GTR 8000 Expandable Site Subsystem for IV&D (UHF R1, 380–435 MHz).....	83
Table 28: Industry Canada for GTR 8000 Expandable Site Subsystem for IV&D (UHF R1 380–435 MHz).....	83
Table 29: General Specifications for GTR 8000 Expandable Site Subsystem for IV&D (UHF R2, 435–524 MHz).....	84
Table 30: Transmitter (Cabinet Output)** Specifications for GTR 8000 Expandable Site Subsystem for IV&D (UHF 450–512 MHz) Including RFDS.....	86
Table 31: Transmitter RF Distribution System for GTR 8000 Expandable Site Subsystem for IV&D (UHF 450–512 MHz).....	86
Table 32: Receiver (Top of Cabinet) Specifications for GTR 8000 Expandable Site Subsystem for IV&D (UHF 450–512 MHz) Including RFDS.....	86
Table 33: Receiver RF Distribution System for GTR 8000 Expandable Site Subsystem for IV&D (UHF 450–512 MHz).....	87
Table 34: FCC Identification for GTR 8000 Expandable Site Subsystem for IV&D (UHF R2, 435–524 MHz).....	88
Table 35: Industry Canada for GTR 8000 Expandable Site Subsystem for IV&D (UHF R2, 435–524 MHz).....	88
Table 36: General Specifications for GTR 8000 Expandable Site Subsystem for IV&D (VHF, 136–174 MHz).....	88
Table 37: Transmitter Specifications for GTR 8000 Expandable Site Subsystem for IV&D (VHF, 136–174 MHz).....	90
Table 38: Receiver Specifications for GTR 8000 Expandable Site Subsystem for IV&D (VHF, 136–174 MHz).....	91
Table 39: FCC Identification for GTR 8000 Expandable Site Subsystem for IV&D (VHF, 136–174 MHz).....	92
Table 40: Industry Canada for GTR 8000 Expandable Site Subsystem for IV&D (VHF 136–174 MHz).....	92
Table 41: GCP 8000 Site Controller and GPB 8000 Reference Distribution Module Technical and Environmental Specifications.....	92
Table 42: Expansion Hub Technical and Environmental Specifications.....	93
Table 43: GTR 8000 Receive Expansion Cable Length Specifications.....	93
Table 44: GCP 8000 Site Controller Port Default Speed/Duplex Settings.....	93
Table 45: XHub Port Default Speed/Duplex.....	94
Table 46: GPB 8000 Reference Distribution Module Port Default Speed/Duplex Settings.....	94
Table 47: Transceiver Front RESET Switch Functions.....	99
Table 48: ON/OFF Switch - States for Power Supply and Battery Charger.....	105
Table 49: GTR 8000 Power Supply Module Backplane Connections.....	106
Table 50: 900 MHz Duplexer Module Descriptions.....	117
Table 51: Hybrid Combiner Module Descriptions.....	117
Table 52: Receive Multicoupler (RMC) Internal Components.....	123
Table 53: Activities for Site Preparation.....	137

Table 54: Heavy Gauge Wire Resistance Examples.....	142
Table 55: DC Power Connection Wire Gauge Maximum Distances for an IV&D Site.....	149
Table 56: Power Connection Wire Gauge Maximum Distances for HPD.....	151
Table 57: GTR 8000 Expandable Site Subsystem Rear Backplane Connections for HPD.....	155
Table 58: GTR 8000 Expandable Site Subsystem Backplane Internal Connections for HPD.....	156
Table 59: GTR 8000 Expandable Site Subsystem Rear Backplane Connections for a Repeater Site.....	157
Table 60: GTR 8000 Expandable Site Subsystem Backplane Internal Connections for an ASTRO 25 Repeater Site.....	158
Table 61: GTR 8000 Expandable Site Subsystem Rear Backplane Connections for an IP Simulcast Remote Site.....	159
Table 62: GTR 8000 Expandable Site Subsystem Backplane Internal Connections for an IP Simulcast Remote Site (Standard Configuration).....	160
Table 63: GTR 8000 Expandable Site Subsystem Backplane Internal Connections for an IP Simulcast Remote Site (High Availability Configuration).....	160
Table 64: GTR 8000 Expandable Site Subsystem Rear Backplane Connections for ASTRO 25 Express System.....	161
Table 65: GTR 8000 Expandable Site Subsystem Backplane Internal Connections for an ASTRO 25 Express System.....	162
Table 66: GTR 8000 Expandable Site Subsystem Rear Backplane Connections for a Trunked 3600 IntelliRepeater Site.....	163
Table 67: GTR 8000 Expandable Site Subsystem Backplane Internal Connections for a Trunked 3600 IntelliRepeater Site.....	164
Table 68: GTR 8000 Expandable Site Subsystem Rear Backplane Connections for a Trunked 3600 Simulcast Remote Site.....	165
Table 69: GTR 8000 Expandable Site Subsystem Backplane Internal Connections for a Trunked 3600 Simulcast Remote Site.....	166
Table 70: GTR 8000 Expandable Site Subsystem Power Supply Backplane Connections.....	167
Table 71: Transceiver Connections - Front.....	168
Table 72: 50–Pin System Connector Pin-Outs (Conventional).....	169
Table 73: 50–Pin System Connector Pin-Outs (Trunked 3600).....	172
Table 74: Wireline Port Pin-Outs.....	174
Table 75: Microphone Port Pin-Outs.....	175
Table 76: Speaker Port Pin-Outs.....	176
Table 77: V.24 Port Pin-Outs.....	176
Table 78: ASYNC RS-232 Port Pin-Outs.....	177
Table 79: Site Controller and RDM Connections – Front.....	179
Table 80: Expansion Hub Connections (Front View)	181
Table 81: GTR 8000 Expandable Site Subsystem Prime Cabinet Junction Panel Connections for an ASTRO 25 Repeater Site (700/800/900 MHz and UHF R2 435–524 MHz).....	182
Table 82: GTR 8000 Expandable Site Subsystem Expansion Junction Panel Connections for an ASTRO 25 Repeater Site (700/800/900/UHF R2 435–524 MHz).....	185

Table 83: GTR 8000 Expandable Site Subsystem Prime Cabinet Junction Panel Connections for an ASTRO 25 Repeater Site (UHF R1 380–435 MHz and VHF 136–174 MHz).....	188
Table 84: GTR 8000 Expandable Site Subsystem Expansion Junction Panel Connections for a Repeater Site (UHF R1 380–435 MHz and VHF 136–174 MHz).....	190
Table 85: GTR 8000 Expandable Site Subsystem Junction Panel Connections for Trunked IP Simulcast Sites Standard Configuration (700/800/900 MHz and UHF R2 435–524 MHz).....	192
Table 86: GTR 8000 Expandable Site Subsystem Junction Panel Connections for a Trunked IP Simulcast Site Standard Configuration (UHF R1 380–435 MHz and VHF 136–174 MHz).....	194
Table 87: GTR 8000 Expandable Site Subsystem Junction Panel Connections for HPD (700/800 MHz).....	196
Table 88: GTR 8000 Expandable Site Subsystem Prime Cabinet Junction Panel Connections for an ASTRO 25 Express System (700/800/900 MHz and UHF R2 435–524 MHz).....	198
Table 89: GTR 8000 Expandable Site Subsystem Expansion Cabinet Junction Panel Connections for an ASTRO 25 Express System (700/800/900 MHz and UHF R2 435–524 MHz).....	200
Table 90: GTR 8000 Expandable Site Subsystem Prime Cabinet Junction Panel Connections for an ASTRO 25 Express System (UHF R1 380–435 MHz and VHF 136–174 MHz).....	202
Table 91: GTR 8000 Expandable Site Subsystem Expansion Cabinet Junction Panel Connections for an ASTRO 25 Express System (UHF R1 380–435 MHz and VHF 136–174 MHz).....	204
Table 92: GTR 8000 Expandable Site Subsystem Prime Cabinet Junction Panel Connections for Trunked IP Simulcast Site High Availability (700/800/900 MHz and UHF R2 435–524 MHz).....	206
Table 93: GTR 8000 Expandable Site Subsystem Expansion Cabinet Junction Panel Connections for Trunked IP Simulcast Site High Availability (700/800/900 MHz and UHF R2 435–524 MHz) ..	209
Table 94: GTR 8000 Expandable Site Subsystem Prime Cabinet Junction Panel Connections for Trunked IP Simulcast Site High Availability (UHF R1 380–435 MHz and VHF 136–174 MHz).....	211
Table 95: GTR 8000 Expandable Site Subsystem Expansion Cabinet Junction Panel Connections for Trunked IP Simulcast Site High Availability (UHF R1 380–435 MHz and VHF 136–174 MHz). 214	
Table 96: Simulcast Conventional GTR 8000 Expandable Site Subsystem Junction Panel Connections within a Trunked IP Simulcast High Availability Site (700/800/900/UHF R2 435–524 MHz).....	216
Table 97: Conventional Simulcast GTR 8000 Expandable Site Subsystem Junction Panel Connections within a Trunked IP Simulcast High Availability Site (UHF R1 380–435 MHz and VHF 136–174 MHz).....	218
Table 98: Conventional GTR 8000 Expandable Site Subsystem Junction Panel Connections within a Conventional Site (700/800/900 MHz and UHF R2 435–524 MHz).....	220
Table 99: Conventional GTR 8000 Expandable Site Subsystem Junction Panel Connections within a Conventional Site (UHF R1 380–435 MHz and VHF 136–174 MHz).....	223
Table 100: GTR 8000 Expandable Site Subsystem Prime Cabinet Junction Panel Connections for a Trunked 3600 IntelliRepeater Site (800/900 MHz and UHF R2 435–524 MHz).....	225
Table 101: GTR 8000 Expandable Site Subsystem Expansion Cabinet Junction Panel Connections for a Trunked 3600 IntelliRepeater Site (800/900 MHz and UHF R2 435–524 MHz)	228
Table 102: GTR 8000 Expandable Site Subsystem Prime Cabinet Junction Panel Connections for a Trunked 3600 IntelliRepeater Site (UHF R1 380–435 MHz and VHF 136–174 MHz).....	230
Table 103: GTR 8000 Expandable Site Subsystem Expansion Cabinet Junction Panel Connections for a Trunked 3600 IntelliRepeater Site (UHF R1 380–435 MHz and VHF 136–174 MHz).....	232

Table 104: GTR 8000 Expandable Site Subsystem Junction Panel Connections for a Trunked 3600 Simulcast Subsystem (800/900 MHz and UHF R2 435–524 MHz).....	234
Table 105: GTR 8000 Expandable Site Subsystem Junction Panel Connections for a Trunked 3600 Simulcast Subsystem (UHF R1 380–435 MHz and VHF 136–174 MHz).....	236
Table 106: Quick-Connect RF Coaxial Adapters for GTR 8000 Base Radio Support.....	243
Table 107: RMC Attenuator DIP Switch Settings.....	280
Table 108: RMC Attenuator Settings for Site with Two or More Cabinets (700/800/900 MHz).....	281
Table 109: RMC Attenuator Settings for Single Cabinet Sites with No Site RMC (700/800/900 MHz).....	282
Table 110: RMC Attenuator Settings for Site with Two or More Cabinets (UHF R2, 435–524 MHz)...	283
Table 111: RMC Attenuator Settings for Single Cabinet Sites with No Site RMC (UHF R2, 435–524 MHz).....	283
Table 112: RMC System Gain for GTR 8000 Expandable Site Subsystem Configurations.....	284
Table 113: RMC Attenuator Settings.....	286
Table 114: GPS Cable Length Delay Offset Value.....	288
Table 115: Time and Frequency Inputs.....	292
Table 116: Deviation Standards for ASTRO 25 System Test Patterns.....	305
Table 117: Illegal Carrier Determination.....	334
Table 118: GTR 8000 Base Radio General Troubleshooting.....	335
Table 119: GCP 8000 Site Controller - General Troubleshooting.....	338
Table 120: GPB 8000 Reference Distribution Module General Troubleshooting.....	339
Table 121: Device Diagnostic Options in UEM.....	341
Table 122: Local Password and SNMPv3 Passphrase Troubleshooting.....	343
Table 123: GTR 8000 Expandable Site Subsystem Field Replaceable Units.....	347
Table 124: GTR 8000 Expandable Site Subsystem RFDS Field Replaceable Parts.....	349
Table 125: System Feature Exceptions.....	353
Table 126: Minimum Software Download Version Requirements.....	354
Table 127: Transceiver FRU Number Mappings.....	355
Table 128: Power Amplifier FRU Number Mappings.....	357
Table 129: Transceiver Status and Alarm LEDs.....	430
Table 130: Transceiver Ethernet Link Status LEDs.....	430
Table 131: Transceiver Application-Controlled LEDs.....	431
Table 132: Transceiver Services-Controlled LEDs.....	432
Table 133: Power Amplifier LEDs.....	433
Table 134: Trunked GCP 8000 Site Controller Software-Controlled LEDs.....	434
Table 135: Conventional GCP 8000 Site Controller Software-Controlled LEDs.....	435
Table 136: GCP 8000 Site Controller Services-Controlled LEDs.....	435
Table 137: GCP 8000 Site Controller Status and Alarm LED Assignment.....	435
Table 138: GCP 8000 Site Controller Status/Alarm LEDs Definitions.....	436
Table 139: GCP 8000 Site Controller Active/Inactive Status LEDs.....	436

Table 140: GCP 8000 Site Controller Active/Inactive LEDs	437
Table 141: GCP 8000 Site Controller Link LEDs	437
Table 142: RDM Software-Controlled LEDs.....	438
Table 143: RDM Services-Controlled LEDs.....	439
Table 144: RDM Status and Alarm LED Assignment.....	439
Table 145: RDM Status Definitions for the Status/Alarm LEDs.....	439
Table 146: RDM Active/Inactive Status LEDs.....	440
Table 147: RDM Active/Inactive LEDs	440
Table 148: RDM Link LEDs.....	440
Table 149: Expansion Hub LEDs with Description.....	441
Table 150: Expansion Hub Status/Alarm LED Assignment	441
Table 151: Power Supply LEDs.....	443
Table 152: RMC/LNA Module LED States.....	444
Table 153: Transmit Filter Specifications (700/800/900 MHz).....	445
Table 154: Transmit Filter Specifications (UHF).....	445
Table 155: Diplexer Specifications.....	446
Table 156: Site Preselector Filter Specifications (700/800 MHz).....	447
Table 157: Site Preselector Filter Specifications (UHF 455–512 MHz).....	447
Table 158: Cavity Combiner Specifications (700/800 MHz).....	448
Table 159: Cavity Combiner Specifications (UHF).....	449
Table 160: Site Receiver Multicoupler/Low Noise Amplifier (RMC/LNA) Specifications (700/800/900 MHz).....	450
Table 161: Cabinet Receiver Multicoupler/Low Noise Amplifier (RMC/LNA) Specifications (700/800/900 MHz).....	450
Table 162: Site Receiver Multicoupler/Low Noise Amplifier (RMC/LNA) Specifications (UHF).....	451
Table 163: Cabinet Receiver Multicoupler/Low Noise Amplifier (RMC/LNA) Specifications (UHF).....	452
Table 164: Cabinet RMC Pass Through Module Specifications.....	452
Table 165: PMU (UHF/VHF/900 MHz).....	453
Table 166: Hybrid Module Specifications (900 MHz).....	453
Table 167: Hybrid Combiner Specifications (900 MHz).....	454
Table 168: Duplexer Specifications (900 MHz).....	454

List of Processes

Equipment Installation Process Overview	131
Installing the GPS Units	239
Installing Device Software Prerequisites	243
Installing Devices in the UNC	246
Discovering a Device in the UNC	255
Initially Configuring a Device in CSS	257
Configuring the Parameters for the GTR 8000 Base Radio (Trunked Simulcast)	272
Configuring the Parameters for the GTR 8000 Base Radio (Trunked Repeater)	273
Configuring the Parameters for the GTR 8000 Base Radio (HPD)	274
Configuring the Parameters for a GTR 8000 Base Radio (Conventional)	274
Configuring the Parameters for a GTR 8000 Base Radio (Express)	275
Configuring the Parameters for a GPB 8000 Reference Distribution Module	276
Configuring Centralized Authentication on Devices in VoyenceControl	287
Site Initialization Process	333
Recovering the GTR 8000 Base Radio	457
Recovering the GPB 8000 Reference Distribution Module	457
Recovering the GCP 8000 Site Controller	457

This page intentionally left blank.

List of Procedures

Configuring The Ethernet LAN Switch	45
Removing the DC Bus Bars in a Power Distribution Module	115
Mounting Cabinets or Racks to a Floor	139
Discovering a Device in the UNC	247
Loading Device OS Images to the UNC	248
Enabling FTP Service	249
Transferring and Installing the OS Image	249
Inspecting Device Properties for Transferred and Installed Software	252
Disabling FTP Service	253
Connecting Through a Serial Port Link	258
Setting the Device IP Address and Pairing Number in CSS	260
Setting the Serial Security Services in CSS	261
Resetting SNMPv3 User Credentials to Factory Defaults in CSS	262
Connecting Through an Ethernet Port Link	262
Setting the BR/CM Pairing Number in CSS	265
Setting the Date and Time in CSS	265
Changing SNMPv3 Configuration and User Credentials in CSS	265
Adding or Modifying an SNMPv3 User in CSS	268
Performing an SNMPv3 Connection Verification in CSS	268
Customizing the Login Banner in CSS	269
Setting the SWDL Transfer Mode in CSS	269
Setting the Local Password Configuration in CSS	271
Configuring Tx Power Values and Battery Type	277
Setting RMC System Gain	285
Calculating Inline Attenuator When a TTA is Installed	286
Setting the GPS Unit Cable Length Delay Offset Calibration in the CSS	288
Setting the GPS Unit Cable Length Delay Offset Calibration in the UNC	289
Tuning the Cavity Combiner For Six Carriers	294
Changing Frequencies, Adding Channels, and Realigning a 700/800 MHz and UHF Cavity Combiner	299
Tuning the Cavity Combiner for up to Twelve Carriers for 700/800 MHz	301
Monitoring the Power Supply Module	305
Verifying Receiver Performance for FDMA Operation	306
Verifying Receiver Performance in TTA Operation	308
Verifying Receiver Performance (Analog Operation)	311
Checking Receiver Sensitivity (Self-test Method) (IV and D)	313

Monitoring the Transmitter Metering Points	314
Verifying Transmitter Performance (Digital Operation)	314
Verifying Transmitter Performance (Analog Operation)	316
Setting Up the HPD Service Monitor for Testing the GTR 8000 Expandable Site Subsystem	319
Measuring HPD BR Tx Power, Frequency Accuracy, and Tx EVM	320
Measuring HPD BR Rx Sensitivity and Rx BER	323
Checking Receiver Sensitivity (Self-test Method) (HPD)	326
Replacing a GTR 8000 Base Radio Transceiver Module	358
Replacing the GCP 8000 Site Controller Module	364
Replacing a GPB 8000 Reference Distribution Module (RDM)	368
Replacing the Expansion Hub	373
Replacing the Fan Assembly	374
Replacing a Power Supply	376
Replacing a Power Supply Fan	377
Replacing a Power Amplifier	379
Replacing a GTR 8000 Expandable Site Subsystem Backplane	383
Replacing a GTR 8000 Expandable Site Subsystem Power Supply Backplane	389
Replacing a Subpanel on the GTR 8000 Expandable Site Subsystem Junction Panel	391
Replacing the AC/DC Power Distribution Module	396
Replacing Filters/Preselectors (700/800/900 MHz)	398
Replacing a Site Preselector (UHF, 455–512 MHz)	401
Replacing Transmit Filters (UHF, 450–509 MHz)	402
Replacing a Site RMC/LNA Module or Tray	407
Replacing an Individual Cabinet RMC/LNA Module	412
Replacing an Individual Pass Through Module	415
Replacing a Cavity Combiner (700/800 MHz)	416
Replacing a Cavity Combiner (UHF)	419
Replacing a Hybrid Combiner Fan Assembly	422
Replacing a Hybrid Combiner Module (900 MHz)	422
Replacing a Duplexer (900 MHz)	424
Replacing a Power Monitor Unit (PMU) (UHF/VHF/900 MHz)	427
Performing a Site Download	458

About GTR 8000 Expandable Site Subsystem

This manual provides descriptive and procedural information on the GTR 8000 Expandable Site Subsystem. Included in the manual are descriptions of the components of the GTR 8000 Expandable Site Subsystem and their function, specifications for the various configurations, and procedures on installation, configuration, optimization, operation, troubleshooting, and FRU/FRE replacement. Finally a reference section provides information on LED indicators and RFDS equipment specifications.

This manual is intended for technicians and system operators as a resource for understanding and installing the GTR 8000 Expandable Site Subsystem. The manual should be used with the ASTRO® 25 system documentation and the Motorola *Standards and Guidelines for Communication Sites* manual.

What Is Covered In This Manual?

This manual contains the following chapters:

- [GTR 8000 Expandable Site Subsystem Description on page 41](#) provides a high-level description of the GTR 8000 Expandable Site Subsystem and the function it serves on your system.
- [GTR 8000 Expandable Site Subsystem Theory of Operations on page 97](#) explains how the GTR 8000 Expandable Site Subsystem works in the context of your system.
- [GTR 8000 Expandable Site Subsystem Installation on page 131](#) details installation procedures relating to the GTR 8000 Expandable Site Subsystem.
- [GTR 8000 Expandable Site Subsystem Configuration on page 255](#) details configuration procedures relating to the GTR 8000 Expandable Site Subsystem.
- [GTR 8000 Expandable Site Subsystem Optimization on page 291](#) contains optimization procedures and recommended settings relating to the GTR 8000 Expandable Site Subsystem.
- [GTR 8000 Expandable Site Subsystem Maintenance on page 329](#) describes periodic maintenance procedures relating to the GTR 8000 Expandable Site Subsystem.
- [GTR 8000 Expandable Site Subsystem Operation on page 331](#) details how the GTR 8000 Expandable Site Subsystem operates once it is installed and operational on your system.
- [GTR 8000 Expandable Site Subsystem Troubleshooting on page 335](#) provides fault management and troubleshooting information relating to the GTR 8000 Expandable Site Subsystem.
- [GTR 8000 Expandable Site Subsystem FRU Procedures on page 347](#) lists the Field Replaceable Units (FRUs) and Field Replaceable Entities (FREs) and includes replacement procedures applicable to the GTR 8000 Expandable Site Subsystem.
- [GTR 8000 Expandable Site Subsystem Reference on page 429](#) contains supplemental reference information relating to the GTR 8000 Expandable Site Subsystem.
- [GTR 8000 Expandable Site Subsystem Disaster Recovery on page 457](#) provides references and information that enable you to recover a GTR 8000 Base Radio, GCP 8000 Site Controller, or GPB 8000 Reference Distribution Module in the event of a failure.

Helpful Background Information

Motorola offers various courses designed to assist in learning about the system. For information, go to <http://www.motorolasolutions.com/training> to view the current course offerings and technology paths.

Related Information

In addition to the information in the following table, see the Related Information Guide.

Related Information	Purpose
<i>Standards and Guidelines for Communication Sites</i>	Provides standards and guidelines that should be followed when setting up a Motorola communications site. This may be purchased on CD 9880384V83, by calling the North American Parts Organization at 800–422–4210 or the international number at 302–444–9842.
<i>System Documentation Overview</i>	For an overview of the ASTRO [®] 25 system documentation, open the graphical user interface for the ASTRO [®] 25 system documentation set and select the System Documentation Overview link. This opens a file that includes: <ul style="list-style-type: none">• ASTRO[®] 25 system release documentation descriptions• ASTRO[®] 25 system diagrams• ASTRO[®] 25 system glossary For an additional overview of the system, review the architecture and descriptive information in the manuals that apply to your system configuration.
<i>Dynamic System Resilience</i>	Provides all the information required to understand, operate, maintain, and troubleshoot the Dynamic System Resilience feature.
<i>GTR 8000 Base Radio</i>	Provides all the information required to understand and operate the standalone GTR 8000 Base Radio.
<i>System Gateways – GGM 8000</i>	Provides all the information required to understand and operate the GGM 8000 Gateway.
<i>Quick Guide for Implementing MLC 8000s</i>	Provides the information required to understand and operate the analog conventional MLC 8000 Comparator in a conventional analog IP-based simulcast overlay at an ASTRO [®] 25 trunked site.
<i>Trunked IP Simulcast Subsystem Remote Site</i> <i>HPD Standalone System – Infrastructure</i> <i>ASTRO 25 Repeater Site – Infrastructure</i> <i>ASTRO 25 Express Standalone – Infrastructure</i>	Provides the information required to understand and operate the GTR 8000 Expandable Site Subsystem in an ASTRO [®] 25 site.
<i>Conventional Operations</i>	Provides the information required to understand and operate the GTR 8000 Expandable Site Subsystem in a conventional architecture.
<i>Quick Guide for Replacing a Trunked 3600 QUANTAR with a GTR 8000 Base Radio</i>	Provides the information required to understand and operate the trunked GTR 8000 Base Radio in a 3600 bps system.

Chapter 1

GTR 8000 Expandable Site Subsystem Description

This chapter provides a high-level description of the GTR 8000 Expandable Site Subsystem and its components within the prime and expansion cabinets or racks and the function they serve in your system. For information on the site the GTR 8000 Expandable Site Subsystem resides in, see the following manuals.

- *Trunked IP Simulcast Subsystem Remote Site*
- *HPD Standalone System - Infrastructure*
- *ASTRO 25 Repeater Site - Infrastructure*
- *ASTRO 25 Express Standalone – Infrastructure*
- *Conventional Operations*

GTR 8000 Expandable Site Subsystem Overview

Throughout this manual, the term “base radio” is used to denote the transceiver module, power amplifier module, fan module, and power supply module to be one physical base radio. As viewed in these applications, one “base radio” is one of several in a GTR 8000 Expandable Site Subsystem configuration.



NOTICE: RFDS information provided in this documentation pertains to the RFDS equipment included in the GTR 8000 Expandable Site Subsystem.

The GTR 8000 Expandable Site Subsystem is an integrated open rack or cabinet that consists of GTR 8000 Base Radios (transceiver module, power amplifier module, fan module, and power supply module for each transmission channel). The GTR 8000 Expandable Site Subsystem may also contain GCP 8000 Site Controller modules or GPB 8000 Reference Distribution Modules (RDMs), XHub modules, GGM 8000 Gateways, and optional RFDS equipment. This configuration provides a major advantage in terms of reduced site cabling and costs. All the required connections between the base radios and the site controllers, XHubs, or RDMs are contained in the backplane; whereas individual units mounted in a 19-inch rack or cabinet require external cabling. Also, the site controller, XHub, RDM, or gateways in a GTR 8000 Expandable Site Subsystem do not have a power supply of their own, but draw power from the base radio power supply modules.

Each GTR 8000 Expandable Site Subsystem cabinet contains a maximum of either five or six base radios, depending upon the system configuration. Additional GTR 8000 Expandable Site Subsystem racks or cabinets can be added to increase the number of channels at a site. The base radios transceiver module includes the functionality for the exciter, receiver, and station control with an optional transceiver option card. The base radio software, configuration, and network management, as well as inbound/outbound traffic handling, are performed through the control section of the base radios transceiver module. On-board serial and Ethernet ports are on the transceivers module for local servicing through Configuration/Service Software (CSS) and the Unified Network Configurator (UNC). The power amplifier module amplifies the low-level modulated RF signal from the transceiver module and delivers the amplified signal on the path to the transmit antenna. The power supply module supports the transceiver and power amplifier modules. Radio Frequency Distribution System (RFDS) provides the interface between the transceivers and the site antennas and between the power amplifier and the site antennas. Each transceiver has an Ethernet connection to the site controller, XHub, or RDM modules.

Various messaging and signaling across the backplane includes inbound/outbound traffic flow, frequency reference and synchronization signaling, network management traffic, and status failover related messaging. A bank of power supplies along the bottom of the cabinet/ rack supply power to the modules. The cabinet/rack is supplied with up to five or six AC power connections. DC power or backup batteries can also be connected. The cabinet/rack can run on a combination of AC power and backup battery power, while continuing to charge the backup batteries. Installation and replacement for all the modules in the cabinet/rack is accessible through the front of the cabinet/rack.

For detailed information on the functionality, configuration, and operation of the site controller in the GTR 8000 Expandable Site Subsystem in a repeater or HPD configuration, see the *GCP 8000 Site Controller* manual.

GTR 8000 Base Radio Components

Table 1: Base Radio Modules and Function

Base Radio	Description
Power Supply	Operates from either an AC or DC input and provides the DC operating voltage for the base radio. Also provides a separate battery charger to maintain the charge on a 48 VDC nominal system, positive or negative ground.
Power Amplifier (PA)	Accepts a low-level modulated RF signal from the transceiver module and amplifies it for transmission through the site transmit antenna. Also provides a low-level RF feedback signal to the transceiver module to achieve the required transmitter linearity. Also performs functions related to the fan module.
Transceiver (XCVR)	Provides the control, exciter, and receiver functions for the base radio.
Transceiver Option Card	<p>An optional board that attaches to the control board of the transceiver. Provides an internal 10 MHz frequency reference. For conventional base radio operation, it also provides the analog interfaces and WildCard I/Os. The transceiver option card is available in two categories:</p> <ul style="list-style-type: none"> OCXO (Oven Controlled Crystal Oscillator) TCXO (Temperature Compensated Crystal Oscillator) <p> NOTICE: The OCXO board when initially powered on takes a few minutes to reach its operational temperature. During the warm-up period, if the base radio is configured to use the OCXO frequency reference, the base radio may report a frequency reference failure. This alarm condition automatically clears once the OCXO board has warmed up sufficiently to provide a stable reference.</p>
Fan	Provides intermittent forced air cooling for the power amplifier and transceiver modules.

Supported System Configurations

The GTR 8000 Expandable Site Subsystem is available in the following system configurations:

- High Performance Data (HPD) Site
- ASTRO® 25 Repeater Site
- ASTRO® 25 Express System Configuration
- Trunked IP Simulcast Subsystems
- Trunked Single-Site Repeater Configuration
- Centralized Conventional Architecture
- Trunked 3600 SmartZone® Systems

Supported Frequencies for Trunked IV and D

The GTR 8000 Expandable Site Subsystem is available in the following frequency bands:

- 700, 800 MHz
- 900 MHz
- UHF R1 (380–435 MHz)
- UHF R2 (435–524 MHz)
- VHF (136–174 MHz)

Supported Frequencies for Conventional Operation

The GTR 8000 Expandable Site Subsystem is available in the following frequency bands:

- 700, 800 MHz (700 MHz analog conventional is not available within the U.S.A. or Canada)
- UHF R1 (380–435 MHz)
- UHF R2 (435–524 MHz)
- VHF (136–174 MHz)

Supported Frequencies for HPD

The GTR 8000 Expandable Site Subsystem is available for 25 kHz operation in the following frequency bands:

- 700 MHz
- 800 MHz

Overview of a GTR 8000 Expandable Site Subsystem in an ASTRO Repeater Site

The GTR 8000 Expandable Site Subsystem in an ASTRO® 25 repeater site is set up in a single trunked site, with one active control channel and a number of voice channels at the site, with a total of 28 channels at the site. If packet data services are supported at the site, a number of voice channels can be configured with packet data channel capability. Voice traffic is routed from each of the base radios to the system for distribution to other sites and is repeated by the base radios to support other local subscribers. However, data traffic is routed to the GCP 8000 Site Controller. The site controller routes these packets upstream to the zone core for further processing and routing.

Overview of a GTR 8000 Expandable Site Subsystem in an ASTRO 25 Express System

The GTR 8000 Expandable Site Subsystem in an ASTRO[®] 25 Express System is a trunked single-site repeater site configuration that supports up to three cabinets or racks and 18 channels with one active control channel and up to 17 voice channels. The GCP 8000 Site Controller manages the resources for the ASTRO[®] 25 Express System. There is no connection to a zone core.

Overview of a GTR 8000 Expandable Site Subsystem in a Trunked Single-Site Repeater Configuration


This configuration consists of GTR 8000 Base Radios and GCP 8000 Site Controllers in a single-site repeater configuration. The base radios may be collocated with the site controllers within the GTR 8000 Expandable Site Subsystem cabinet, or be separated (standalone, non-colocated) from the site controllers.

 **NOTICE:** This configuration can only be used in non-voting configurations.

Support is provided only for FDMA when the base radios are physically separated from and not collocated with the site controllers. TDMA requires the use of a frequency reference and timing reference that can only be provided through the site controller CP3 links, which cannot be extended to non-colocated base radios when the distance exceeds the noted limits.

An Ethernet cable is used to extend the site controller signal to the first non-colocated base radio from the Network Aux A port on the junction panel to the SC-A port on the base radio. The site controller Net AUX port must be enabled and configured using the CSS for 100/FULL (speed and duplex). When the distance between the site controller and the first non-colocated base radio exceeds 328 ft (100 m), an external HP 2620 24-port Ethernet LAN switch must be used to extend the site controller signal. When there are additional non-colocated base radios and those base radios are more than 328 ft from the previous non-colocated base radio, additional Ethernet LAN switches are required to continue to extend the site controller signal. See [Figure 1: Single-Site Repeater Configuration 1 on page 44](#).

Figure 1: Single-Site Repeater Configuration 1




Single_site_rptr_conf_1_A

If the distance between the first non-colocated base radio and subsequent non-colocated base radios is less than 328 ft (100 m), a single Ethernet LAN switch can be used to distribute the site controller call control signaling to those non-colocated base radios. The stated distance limit for a shielded

twisted pair Ethernet cable (CAT5) is 328 ft (100 m) before the signal degrades too much to be used. See [Figure 2: Single Site Repeater Configuration 2 on page 45](#).

Figure 2: Single Site Repeater Configuration 2



Single_site_rptr_conf_2_A

Once the site controller link is extended, the control plane could be open to access from elements other than the base radios. Each Ethernet LAN switch must be manually configured to provide MAC Port lockdown to make sure that only the proper devices can communicate with each other. MAC Port lockdown may also be applied on any unused Expansion Ports on the site controller. See the *MAC Port Lockdown* manual to lock down the site controller. The switch ports may be enabled or disabled according to specific security guidelines. See “Enabling/Disabling Ports on HP Switches Using Local Access” in the *System LAN Switches* manual.

Each non-colocated base radio is equipped with a transceiver option card, which provides an internal 10 MHz frequency reference. See the “Reference Oscillator Alignment Procedures” of the base radio Alignment Screens in the *Configuration/Service Software (CSS) Online Help* for alignment details. The base radios that are colocated with the site controllers do not require the transceiver option card.

See the “Installation” chapter in the *GTR 8000 Base Radio* manual for rack mounting and cabling connections for the non-colocated standalone base radios.

When the Ethernet LAN switch is used in a configuration that does not include centralized network management, the switch must be programmed manually. See the *System LAN Switches* manual.

Configuring The Ethernet LAN Switch

When and where to use: Use this procedure to configure either an HP 2620 LAN switch for a Trunked Single-Site Repeater Configuration.

Procedure:

- 1 Enter the following commands at the prompt: `ProCurve Switch 2620-24#`
- 2 `ProCurve Switch 2620-24#erase startup-config`
(This command removes any existing switch configuration)
- 3 `ProCurve Switch 2620-24#config`
(This command puts the switch into configuration mode)

- 4 `ProCurve Switch 2620-24(config)#int X`
(Using Port X as an example)
- 5 `ProCurve Switch 2620-24(eth-X)#speed-duplex 100-Full`
(This command sets the interface X to 100MB/Full Duplex)
- 6 `ProCurve Switch 2620-24(eth-X)#write memory`
(This command saves the configuration changes to persistent memory)

Overview of a GTR 8000 Expandable Site Subsystem in a Trunked IP Simulcast Subsystem

The base radio captures inbound signals through external receive (Rx) antennas from the subscriber/mobile radios and then amplifies, filters, and demodulates the signals into voice packets which are forwarded to a comparator. The comparator processes the received voice packets for a particular call and forwards the best quality voice packets to the zone core, which routes them to the associated base radio at each remote site. At a predetermined time, all base radios transmit the voice packets simultaneously on the same frequency to complete the communication.

A maximum of 30 base radios can be installed per remote site. Each base radio has an Ethernet connection to a switch at the site for the Network Management interface.

There are two types of simulcast remote site configurations for the GTR 8000 Expandable Site Subsystem:

- **Standard configuration**
- **High availability configuration**

See [GTR 8000 Expandable Site Subsystem for Trunked IP Simulcast on page 50](#) for details.

Overview of a GTR 8000 Expandable Site Subsystem in a High Performance Data (HPD) Site

The GTR 8000 Expandable Site Subsystem in an HPD site is set up in a single HPD site. The GTR 8000 Expandable Site Subsystem amplifies, filters, and demodulates the signals into data packets which are forwarded to the GCP 8000 Site Controller. The site controller routes these packets upstream to a base site zone controller for further processing and routing.

Overview of a GTR 8000 Base Radio in Conventional Architectures

Throughout this manual, the term “conventional” addresses either an analog only base radio or an ASTRO[®] 25 Conventional base radio that operates in either digital mode or mixed (analog/digital) mode. The conventional base radios within a GTR 8000 Expandable Site Subsystem operate within a Centralized Conventional Architecture. Each conventional base radio uses either:

- a 2- or 4-wire TRC or 4-wire E&M interface in an analog infrastructure
- a V.24 interface for digital voice and data traffic to either a Channel Bank, Digital Interface Unit, CCGW, MLC 8000, or ASTRO-TAC 3000 Comparator and an optional 4-wire link for analog voice in a mixed mode configuration
- an IP interface for digital voice and data traffic to a CCGW or GCM 8000 Comparator.

Up to a maximum of four conventional base radios can be installed in a trunked GTR 8000 Expandable Site Subsystem cabinet/rack. The conventional base radios do not operate in trunked mode. All base radios must be in the same frequency band.

Up to a maximum of six conventional base radios can be installed in a conventional only GTR 8000 Expandable Site Subsystem cabinet/rack. The cabinet/rack can be either within a trunked site or within a conventional site. All base radios must be in the same frequency band.



NOTICE: For an overview of connecting to an ASTRO® 3.1 Conventional System, see the *Conventional Operations* manual. The base radio can be IP managed while using the 4-wire/V.24 interface for channel traffic.

ASTRO 25 Conventional Base Radio

ASTRO® 25 Conventional base radio features include:

- Separate Tx and Rx network access code
- Console or repeat priority
- Repeater set-up knockdown from the console
- Voice and data
- Control Messages (TSBK)
- Standalone repeater
- Control station
- Receive-only station
- Voting
- Multicast
- Simulcast
- Console Control
 - Monitor Mode
 - Repeat Control
 - Frequency Select
 - Scan Control (supported for the Gold Elite console)
 - Receive Qualifier Control (supported for the Gold Elite console)
- WildCard Operation
- Multi-Channel – up to 16 channels with base station or repeater functionality
- Multiple Network Access Code (Multi-NAC) Operation
- Scan Operation
- Analog Phone Patch

A GTR 8000 Expandable Site Subsystem with ASTRO® 25 Conventional base radios can be used in the following architectures:

- ASTRO® 25 Trunked Repeater Site with Conventional Channels
- Trunked IP Simulcast Remote Site with Conventional Channels
- HPD Site with Conventional Channels
- Zone Core with Colocated Conventional Channels
- Dispatch Console Site with Colocated Conventional Channels
- Conventional-Only Remote Site

Analog Conventional Base Radio

Analog conventional base radio features include:

- 12.5 kHz analog channel operation with HearClear settings (800 MHz)
- Repeater Access Control
- Multi-Channel – up to 16 channel with base station or repeater functionality
- Alarm tones over-the-air and over-the-wireline
- Transmit Antenna Relay Control and Simplex Operation
- WildCard Operation
- E&M Interface; Ext PTT keying and COR receiver I/O
- Analog simulcast support using Gen Tx and PL Analog inputs and Ext PTT and Ext PTT keying
- Multi-PL receive operation
- RA/RT configuration with analog 4-wire connections
- Analog Wireline Automatic Level Control (ALC)
- Wideband Receiver Operation
- Telephone Interconnect
- PL/DPL
- Tone Remote Control (TRC)
- Fall Back In-Cabinet Repeat (Automatic Mode)*
- In-Cabinet Repeater (External Mode)*
- Control Station
- Interfaces for local microphone and speaker
- Simplex operation
- Scan Operation
- Voting
- Multicast
- Simulcast

* For detailed information on the differences between the automatic **Fallback In-Cabinet Repeat** and the externally wired **In-Cabinet Repeat** functions, see the *Conventional Operations* manual.

An analog conventional base radio can be used in the following architectures:

- Zone Core with Colocated Conventional Channels
- ASTRO® 25 Trunked Repeater Site with Conventional Channels
- Trunked IP Simulcast Remote Site with Conventional Channels
- Dispatch Console Site with Colocated Conventional Channels
- Conventional-Only Remote Site

Overview of a GTR 8000 Expandable Site Subsystem in a Trunked 3600 System

In a trunked 3600 system, the GTR 8000 Expandable Site Subsystem control channel runs at 3600 bps, and the voice channels can be configured for analog or ASTRO® 25 voice operation.

The GTR 8000 Expandable Site Subsystem can be used in the following trunked 3600 SmartZone[®] systems:

- Trunked SmartX – 6809/MTC 3600 Site Controller Simulcast Subsystem
- Trunked SmartX – IntelliRepeater System

Depending on the system capabilities, each base radio can be configured for analog voice (4-wire interface), digital voice (V.24 interface) or mixed-mode (4-wire and V.24 interfaces). These interfaces connect to either a channel bank or ASTRO-TAC 3000 Comparator.

The GTR 8000 Expandable Site Subsystem is available in the following frequency bands:

- 800 MHz
- 900 MHz (analog only)
- UHF R1 (380–435 MHz)
- UHF R2 (435–524 MHz)
- VHF (136–174 MHz)



NOTICE: A GTR 8000 Expandable Site Subsystem can be implemented as a QUANTAR[®] station replacement within a trunked 3600 SmartZone[®] system. The implementation details can be found in the *Quick Guide for Replacing a Trunked 3600 QUANTAR with a GTR 8000 Base Radio* manual.

Power Efficiency Package

The GTR 8000 Base Radio is available in a Power Efficiency Package, which provides low standby power consumption (see [Table 2: Standby Power Consumption on page 50](#)) functionality for ASTRO[®] 25 Conventional base radios and trunked base radios operating in the UHF-R1 and UHF-R2 frequency bands. The Power Efficiency Package optimizes the power consumption for supported base radios and allows for the use of power generated from alternate energy sources such as solar or wind.

The Power Efficiency Package hardware includes a modified transceiver, power amplifier, power supply, fan, an optional transceiver option card (internal reference) along with additional software configurations through CSS.

The following conditions must be met to obtain a power consumption of less than or equal to 35 W:

- DC source only
- Speaker turned OFF (if equipped with a transceiver option card)
- No activation of Aux Out Relays (if equipped with a transceiver option card)
- No 29 V AUX loads. For example: site controllers, XHubs, GPB 8000 Reference Distribution Modules, and RMC)
- CSS configured for applications not requiring receiver diversity
- CSS Fan Holdover configured to “short” (length of time the base radio fan stays ON after transmission)
- Ambient temperature of 104 °F (40 °C) or less
- Transceiver, power amplifier, power supply, fan, and optional TCXO transceiver option card (internal reference) are all power efficiency package versions



NOTICE: The TCXO transceiver option card is available only for non-simulcast conventional systems. The OCXO transceiver option card is available for trunked or simulcast systems, but does not guarantee 35 W.

Table 2: Standby Power Consumption


	Conventional Non-Simulcast	Conventional Simulcast	Trunked Non- Simulcast	Trunked Si- mulcast
Internal Reference Ca- pable	35 W	40 W	35 W	40 W
Not Internal Reference Capable	35 W	35 W	35 W	35 W

GTR 8000 Expandable Site Subsystem for Trunked IP Simulcast

Standard Configuration

The GTR 8000 Expandable Site Subsystem in a standard configuration is an integrated cabinet or open cabinet/rack with XHubs and RFDS equipment available for most frequency bands. A standard configuration supports IP links. [Figure 3: GTR 8000 Expandable Site Subsystem for Trunked IP Simulcast – Standard Configuration on page 51](#) shows an example of the RFDS equipment configured for a one branch RMC.

Figure 3: GTR 8000 Expandable Site Subsystem for Trunked IP Simulcast – Standard Configuration



A25_Simul_expandable_subsystem_config_A

For trunked IP simulcast operation, the cabinet/rack includes the following components:


- XHub modules
- Up to six trunked transceiver modules
- Up to four conventional transceiver modules
- Up to six power amplifier modules
- Up to six power supply modules
- RFDS equipment for the transmit (Tx) and receive (Rx) paths
- Junction panel, for connection to other devices at the site, such as site gateway(s), Rx and Tx antennas, and optional MOSCAD Network Fault Management.

The XHubs, transceiver modules, and power amplifier modules are arranged in the slots of the subsystem. Each transceiver, power amplifier, and power supply represents a channel in the subsystem. The GTR 8000 Expandable Site Subsystem supports up to 30 channels. Therefore, a maximum of six transceivers, power amplifiers, and power supplies may be installed in the cabinet/rack with a maximum of six cabinets/racks.

High Availability Configuration

The GTR 8000 Expandable Site Subsystem in a trunked IP simulcast high availability configuration is an integrated cabinet or open cabinet/rack with GPB 8000 Reference Distribution Modules (RDMs), gateways, and RFDS equipment available for most frequency bands. The high availability configuration is designed so that the failure of any one item at a site limits the loss to system availability to one base radio. Each base radio receives frequency and time reference information and Ethernet access independently from each RDM and its associated XHubs. A high availability configuration supports IP links. [Figure 4: GTR 8000 Expandable Site Subsystem for Trunked IP Simulcast — High Availability Configuration on page 52](#) shows an example of the RFDS equipment configured for a one branch RMC.

Figure 4: GTR 8000 Expandable Site Subsystem for Trunked IP Simulcast — High Availability Configuration



GTR_8000_RDM_expandable_subsystem_IP_Sim_B

For trunked IP simulcast high availability operation, the cabinet/rack includes the following components:

- GPB 8000 Reference Distribution Modules (RDMs)
- Up to six trunked transceiver modules
- Up to four conventional transceiver modules
- Up to six power amplifier modules
- Up to six power supply modules
- RFDS equipment for the transmit (Tx) and receive (Rx) paths

- GGM 8000 Gateways
- Junction panel, for connection to other devices at the site, such as site gateways(s), GPS units, Rx and Tx antennas, and optional MOSCAD Network Fault Management.


The RDMs, transceiver modules, and power amplifier modules are arranged in the slots of the subsystem. Each transceiver, power amplifier, and power supply represents a channel in the subsystem. The GTR 8000 Expandable Site Subsystem supports up to 30 channels. Therefore, a maximum of six transceivers, power amplifiers, and power supplies may be installed in the cabinet/rack with a maximum of six cabinets/racks. Any expansion cabinets/racks attached to the prime cabinet/rack use XHubs instead of RDMs.

Both RDMs provide integrated Ethernet LAN switching and redundant integrated site reference distribution over the backplane of the GTR 8000 Expandable Site Subsystem.

GTR 8000 Expandable Site Subsystem for ASTRO 25 Repeater

The GTR 8000 Expandable Site Subsystem is an integrated cabinet or open rack with site controllers, channel equipment, and RFDS equipment available for most frequency bands. [Figure 5: GTR 8000 Expandable Site Subsystem for Repeater Site Module Configuration on page 53](#) shows an example of the RFDS equipment configured for a one branch RMC.

Figure 5: GTR 8000 Expandable Site Subsystem for Repeater Site Module Configuration



A25_expandable_subsystem_config_A

For repeater site operation, the cabinet/rack includes the following components:

- Redundant site controller modules

- Up to six trunked transceiver modules
- Up to four conventional transceiver modules
- Up to six power amplifier modules
- Up to six power supply modules
- RFDS equipment for the transmit (Tx) and receive (Rx) paths
- GGM 8000 Gateways (optional)
- Junction panel, for connection to other devices at the site, such as site gateway(s), Rx and Tx antennas, and optional MOSCAD Network Fault Management.

The site controller modules, transceiver modules, and power amplifier modules are arranged in the slots of the cabinet/rack as illustrated in the diagram. Each transceiver, power amplifier, and power supply represents a channel in the subsystem. The GTR 8000 Expandable Site Subsystem supports up to 28 channels. Therefore, a maximum of six transceivers, power amplifiers, and power supplies may be installed in the cabinet/rack with a maximum of six cabinets/racks. Any expansion cabinets/racks attached to the primary cabinet/rack use XHubs instead of site controllers.

The active site controller module communicates with the channels and sends status messages over the backplane of the GTR 8000 Expandable Site Subsystem chassis. The standby site controller module passively monitors status messages on the backplane to determine whether the active site controller is still operational.

The GTR 8000 Expandable Site Subsystem can be ordered in a cabinet (Option CA00293AA) or 7.5 ft open rack (Option X882AH) or 7 ft open rack (Option CA01402AA).

The Site RMC (LNA) module displayed in the upper half of [Figure 5: GTR 8000 Expandable Site Subsystem for Repeater Site Module Configuration on page 53](#) may not be present in your installation, depending on the options purchased from Motorola.

The following options are only valid for 700/800/900 MHz and UHF R2 (435–524 MHz):


- **Option CA00862AA** includes the one Site RMC module, which provides expansion of up to 24 channels on a single Rx antenna.
- **Option CA00861AA** does not include Site RMCs. It provides basic RMC functionality that is limited to a single cabinet or rack.
- **Option CA00877AA** does not include Site RMCs. It is intended for use in expansion cabinets that are wired to the primary Rx cabinet through the junction panel, and in other configurations using RMC equipment outside the cabinet.
- **Option CA01943AA** includes two Site RMC modules for Phase 2 TDMA operation, dual branch receive diversity. See “Appendix B” in the *Dynamic Dual Mode for TDMA Operation* manual.

GTR 8000 Expandable Site Subsystem for ASTRO 25 Express System

The GTR 8000 Expandable Site Subsystem is an integrated cabinet or open rack with site controllers, channel equipment, and RFDS equipment available for most frequency bands.

The site controller modules, transceiver modules, and power amplifier modules are arranged in the slots of the subsystem as shown in [Figure 6: GTR 8000 Expandable Site Subsystem for ASTRO 25 Express System – Module Configuration on page 55](#).

Figure 6: GTR 8000 Expandable Site Subsystem for ASTRO 25 Express System – Module Configuration



EXP_expandable_subsystem_config_3_racks_A

For an ASTRO[®] 25 Express System single-site configuration, the cabinet/rack includes the following components:

- Redundant site controller modules
- Up to six transceiver modules
- Up to six power amplifier modules
- Up to six power supply modules
- RFDS equipment for the transmit (Tx) and receive (Rx) paths
- Junction panel

Each transceiver, power amplifier, and power supply represent a channel in the subsystem. A maximum of six channels may be installed in each cabinet/rack. The ASTRO[®] 25 Express System single-site configuration supports up to three racks, or 18 channels. Any expansion cabinets/racks attached to the prime cabinet/rack use X Hubs instead of site controllers.

A bank of power supplies along the bottom of the cabinet/rack supplies power to the modules. The cabinet/rack is supplied with up to six AC power connections. DC power or backup batteries can also be connected. The rack can run on a combination of AC power and backup battery power, while

continuing to charge the backup batteries. Installation and replacement for all the modules in the rack is accessible through the front of the cabinet/rack.




NOTICE: The GTR 8000 Expandable Site Subsystem open rack is Option X882AH. The Site RMC (LNA) module displayed in the upper half of [Figure 6: GTR 8000 Expandable Site Subsystem for ASTRO 25 Express System – Module Configuration on page 55](#) may not be present in your installation, depending on the options purchased from Motorola. See [RFDS Modules on page 116](#) for more information on these options.

GTR 8000 Expandable Site Subsystem for HPD

The GTR 8000 Expandable Site Subsystem is an integrated cabinet or open rack with site controller, base radio equipment, and RFDS equipment. [Figure 7: GTR 8000 Expandable Site Subsystem for HPD Module Configuration on page 56](#) shows an example of the RFDS equipment configured for a two branch RMC.

Figure 7: GTR 8000 Expandable Site Subsystem for HPD Module Configuration



HPD_expandable_subsystem_config_A

For HPD operation, the rack includes the following components:

- Redundant site controller modules
- Up to five trunked transceiver modules
- Up to four conventional transceiver modules
- Up to five power amplifier modules

- Up to five power supply modules
- RFDS equipment for the transmit (Tx) and receive (Rx) paths
- GGM 8000 Gateways (optional)
- Junction panel, for connection to other devices at the site, such as site gateway(s), GPS units, Rx and Tx antennas, and optional MOSCAD Network Fault Management.


The site controller modules, transceiver modules, and power amplifier modules are arranged in the slots of the subsystem. Each transceiver, power amplifier, and power supply represents a base radio in the subsystem. The GTR 8000 Expandable Site Subsystem supports up to five base radios. Therefore, a maximum of five transceivers, power amplifiers, and power supplies may be installed in the subsystem rack.

The active site controller module communicates with the channels and sends status messages over the backplane of the GTR 8000 Expandable Site Subsystem. The standby site controller module passively monitors status messages over the backplane to determine whether the active site controller is still operational.

GTR 8000 Expandable Site Subsystem for Conventional

The GTR 8000 Expandable Site Subsystem in a conventional only configuration is an integrated cabinet or open cabinet/rack with XHubs, gateways, and RFDS equipment available for most frequency bands. A conventional only configuration supports IP, V.24, 2-wire, or 4-wire links. [Figure 8: GTR 8000 Expandable Site Subsystem – Conventional Only Configuration on page 58](#) shows an example of the RFDS equipment configured for a one branch RMC.

Figure 8: GTR 8000 Expandable Site Subsystem – Conventional Only Configuration



A25_Simul_expandable_subsystem_config_A

For conventional only operation, the cabinet/rack includes the following components:


- XHub modules
- Up to six conventional mixed mode and/or analog transceiver modules
- Up to six power amplifier modules
- Up to six power supply modules
- RFDS equipment for the transmit (Tx) and receive (Rx) paths
- GGM 8000 Gateway
- Junction panel, for connection to other devices at the site, such as site gateways(s), GPS units, Rx and Tx antennas, and optional MOSCAD Network Fault Management.

The XHubs, transceiver modules, and power amplifier modules are arranged in the slots of the cabinet/rack. Each transceiver, power amplifier, and power supply represents a base radio in the cabinet/rack. The GTR 8000 Expandable Site Subsystem cabinets/racks support up to 40 channels. Therefore, a maximum of six transceivers, power amplifiers, and power supplies may be installed in the cabinet/rack with a maximum of seven cabinets/racks.

GTR 8000 Expandable Site Subsystem for Trunked 3600 IntelliRepeater Site

The GTR 8000 Expandable Site Subsystem in a trunked 3600 IntelliRepeater site configuration is an integrated cabinet or open rack with GPB 8000 Reference Distribution Modules (RDMs), channel equipment, and RFDS equipment available for most frequency bands. [Figure 9: GTR 8000 Expandable Site Subsystem — Trunked 3600 IntelliRepeater Site on page 59](#) shows an example of the RFDS equipment configured for a one branch RMC. Each base radio receives frequency and time reference information and Ethernet access independently from each RDM and its associated XHubs in the expansion cabinets/racks.

Figure 9: GTR 8000 Expandable Site Subsystem — Trunked 3600 IntelliRepeater Site



GTR_8000_expandable_subsystem_3600_IntelliRepeater

For a trunked 3600 IntelliRepeater site, the cabinet/rack includes the following components:

- Redundant GPB 8000 Reference Distribution Modules (RDMs)
- Up to six trunked transceiver modules
- Up to six power amplifier modules
- Up to six power supply modules
- RFDS equipment for the transmit (Tx) and receive (Rx) paths
- GGM 8000 Gateways
- Junction panel, for connection to other devices at the site, such as site gateway(s) and Rx/Tx antennas.


The RDMs, transceiver modules, and power amplifier modules are arranged in the slots of the subsystem. Each transceiver, power amplifier, and power supply represents a base radio in the cabinet/rack. The GTR 8000 Expandable Site Subsystem cabinets/racks support up to 28 channels. Therefore, a maximum of six transceivers, power amplifiers, and power supplies may be installed in the cabinet/rack with a maximum of six cabinets/racks. Any expansion cabinets/racks attached to the prime cabinet/rack use XHubs instead of the RDMs.

Both RDMs in the prime cabinet provide integrated Ethernet LAN switching and redundant integrated site reference distribution over the backplane of the GTR 8000 Expandable Site Subsystem.

GTR 8000 Expandable Site Subsystem for Trunked 3600 Simulcast Subsystem

The GTR 8000 Expandable Site Subsystem in a 3600 simulcast subsystem configuration is an integrated cabinet or open rack with XHubs and RFDS equipment available for most frequency bands. [Figure 10: GTR 8000 Expandable Site Subsystem – Trunked 3600 Simulcast Subsystem on page 60](#) shows an example of the RFDS equipment configured for a one branch RMC.

Figure 10: GTR 8000 Expandable Site Subsystem – Trunked 3600 Simulcast Subsystem



A25_Simul_expandable_subsystem_config_A

For a trunked 3600 simulcast subsystem, the cabinet/rack includes the following components:

- XHub modules
- Up to six trunked transceiver modules
- Up to six power amplifier modules

- Up to six power supply modules
- RFDS equipment for the transmit (Tx) and receive (Rx) paths
- Junction panel, for connection to other devices at the site, such as site gateway(s) and Rx/Tx antennas.

The XHubs, transceiver modules, and power amplifier modules are arranged in the slots of the subsystem. Each transceiver, power amplifier, and power supply represents a channel in the subsystem. The GTR 8000 Expandable Site Subsystem supports up to 28 channels. Therefore, a maximum of six transceivers, power amplifiers, and power supplies may be installed in the cabinet/rack with a maximum of six cabinets/racks.

Ordering Options

The GTR 8000 Expandable Site Subsystem can be ordered in a cabinet (Option CA00293AA) or 7.5 ft open rack (Option X882AH) or 7 ft open rack (Option CA01402AA).

The Site RMC (LNA) module may not be present in your installation, depending on the options purchased from Motorola. The following options are only valid for 700/800/900 MHz and UHF R2 (435–524 MHz).

- **Option CA00862AA** includes two Site RMC modules, which provide support for expansion of up to 24 radios on a single Rx antenna (HPD only supports five base radios, the remaining ports are available for other receivers at the site.)
- **Option CA00861AA** does not include Site RMCs. It provides basic RMC functionality that is limited to a single cabinet or rack.
- **Option CA00877AA** does not include Site RMCs. It is intended for use in expansion cabinets that are wired to the primary Rx cabinet through the junction panel, and in other configurations using RMC equipment outside the cabinet.
- **Option CA01943AA** includes two Site RMC modules for Phase 2 TDMA operation, dual branch receive diversity. See “Appendix B” in the *Dynamic Dual Mode for TDMA Operation* manual.

The integrated GGM 8000 Gateway options are available for all GTR 8000 Expandable Site Subsystem configurations, except UHF R2. Consult your Motorola sales representative for details.

- **Option CA01536AA** includes two RDMs
- **Option CA00885AA** includes high availability XHubs for expansion cabinets/racks.
- **Option CA01706AA** includes the GGM 8000 Gateway
- **Option CA01707AA** includes the GGM 8000 Gateway and analog/V.24 interface
- **Option CA01708AA** includes the GGM 8000 Gateway and encryption
- **Option CA01709AA** includes the GGM 8000 Gateway, analog/V.24, and encryption

GTR 8000 Expandable Site Subsystem RFDS Transmit Path

The transmit part of the RFDS includes the following equipment:

- **Cavity Combiner:** Includes an isolator at each input port (700/800 MHz and UHF R2 435–524 MHz)
- **Hybrid Combiner:** Modular; 2–6 channels, 1 or 2 antennas (900 MHz)
- **Transmit filter:** (700/800/900 MHz and UHF R2 435–524 MHz)
- **Power Monitor Unit (PMU):** (900 MHz, VHF 136–174 MHz, UHF R1 380–435 MHz, and UHF R2 435–524 MHz)




NOTICE: The PMU is not supported and is reserved for future use.

The combiner aggregates all the transmit signals to a common line for the transmit antenna. It includes integrated isolators to protect the transceivers from reflected signaling and to improve intermodulation performance. The transmit filter removes any remaining noise in the receive sub-band. It includes a power monitor to measure forward and reverse power on the transmit line. The output is sent to the transmit antenna port.

If 700/800 MHz channels at the site are in different cabinets, then a diplexer is used in place of the Transmit filter.

Figure 11: GTR 8000 Expandable Site Subsystem for Transmit Path (700/800/900 MHz/UHF R2)



A25_expandable_site_subsystem_tx_path

GTR 8000 Expandable Site Subsystem RFDS Receive Path

The receive part of the RFDS includes the following equipment for 700/800/900 MHz and UHF R2 (435–524 MHz):

- **Cabinet Receive Multicouplers/low noise amplifiers:** Provide a low noise amplifier with a 6-way splitter used to distribute inbound signaling to the base radios over the backplane to complete the receive path. Two Cabinet RMC modules are used for Phase 2 TDMA operation, dual branch receive diversity. See “Appendix B” in the *Dynamic Dual Mode for TDMA Operation* manual.
- **Site Preselector:** Provides signal filtering for the inbound signal. RF input and output connectors on the front of the device are connected to the junction panel and a receive multicoupler. An input port for injecting test signals is also provided.
- **Site Receive Multicouplers/Low Noise Amplifiers:** If option CA00862AA is purchased, each receive path includes a receive multicoupler/low noise amplifier (RMC/LNA) with a balanced amplifier and a 4-way splitter that can be used to distribute inbound signaling to multiple expansion racks. RF input and output connectors on the front of the device are connected to the preselector, junction panel, and the cabinet RMC/LNA. If Option CA01943AA is purchased, it includes two Site RMC modules for Phase 2 TDMA operation, dual branch receive diversity. See “Appendix B” in the *Dynamic Dual Mode for TDMA Operation* manual.

System connections are made through the junction panel on the top of the rack. This panel includes the inputs for RF antennas and outputs for expansion cabinets.

Tower Top Amplifiers (TTAs) are only present if supplied by your organization.

Figure 12: GTR 8000 Expandable Site Subsystem for Receive Path (700/800/900 MHz/UHF R2)






Figure 13: GTR 8000 Expandable Site Subsystem for HPD Receive Path



The receive part of the RFDS includes the following equipment for VHF (136–174 MHz) or UHF R1 (380–435 MHz):

- **RMC Pass Through Module:** For VHF or UHF R1, the receive path always includes an RMC Pass Through module. Six RF input connectors on the front of the device are connected to the junction panel. This module routes the Rx signals to the backplane for distribution to the six base radios. There are no active components, splitters, or combiners on this module.

Figure 14: GTR 8000 Expandable Site Subsystem for Receive Path (VHF or UHF R1)



GTR_8000_expandable_site_subsystem_rx_path_VHF

GCP 8000 Site Controller Modules (HPD, ASTRO 25 Repeater, and ASTRO 25 Express)

The GTR 8000 Expandable Site Subsystem for an HPD, ASTRO[®] 25 repeater site, or ASTRO[®] 25 Express system is designed to work with the GCP 8000 Site Controller modules. The site controller modules provide integrated Ethernet LAN switching, eliminating external HP LAN switches at the site. The site controller manages the site and the channels, administers broadcast, and provides a time and frequency reference signal to the base radios. For HPD and repeater sites, the site controller also handles mobile subscriber unit (MSU) mobility messaging to/from the zone controller, and handles data messaging to/from the Radio Network Gateway (RNG).

One site controller module acts as the active module and the second module as the standby. The redundancy ensures that any single point of failure at the site does not reduce overall functionality.

Figure 15: GCP 8000 Site Controller Module



GCP_site_controller_GPB_RDM_FRU

GCP 8000 Site controller modules share the same card cage, backplane, and junction panel as the transceivers and XHubs.

The site controller software download and configuration is performed through serial and Ethernet ports on the module for local servicing using Configuration/Service Software (CSS). For HPD and repeater sites, network management is performed using Unified Network Configurator (UNC).

For details on the GCP 8000 Site Controller modules and configuration, see the *GCP 8000 Site Controller* manual.

GPB 8000 Reference Distribution Module

The GPB 8000 Reference Distribution Module (RDM) is supported in a trunked IP simulcast remote site with high availability and in a trunked 3600 IntelliRepeater site.

Figure 16: GPB 8000 Reference Distribution Module



GCP_site_controller_GPB_RDM_FRU

The RDMs provide integrated Ethernet LAN switching, eliminating external HP LAN switches.

XHubs allow the RDMs to support additional GTR 8000 Expandable Site Subsystem cabinets with channels beyond what the RDMs can support on their own. One RDM supports up to five XHubs with each XHub supporting up to six base radios.

The RDMs software download and configuration is performed through serial and Ethernet ports on the module for local servicing using Configuration/Service Software (CSS).

Trunked IP Simulcast Remote Site With High Availability

The RDMs provide redundant integrated site reference distribution through two GPS units as timing reference sources to all the base radios at the site, eliminating the need for the TRAK 9100 Simulcast Site Reference at the site.

The RDMs are also capable of monitoring RFDS equipment for failures and provide the interface to the MOSCAD Network Fault Management. Configuration of the RDMs is performed using CSS and Unified Network Configurator (UNC).



NOTICE: The RDMs do not provide site reference to base radios located outside of the GTR 8000 Expandable Site Subsystem cabinets or racks. A TRAK SSR is required at the site to provide for the external base radios. If there are no available Ethernet ports in the RDMs for the external base radios, an external Ethernet LAN switch is required at the site.

Trunked 3600 IntelliRepeater Site

The RDMs provide redundant integrated site reference distribution through the internal oscillator to all the base radios at the site.

Expansion Hub

The Expansion Hub (XHub) is a switching and interface module that operates in the following systems:

- Trunked IP simulcast remote site (all cabinet/racks)
- Trunked IP simulcast remote site configured with high availability (expansion cabinets/racks)
- Conventional only site (expansion cabinets/racks)
- ASTRO® 25 Repeater Site (expansion cabinets/racks)
- ASTRO® 25 Express System (expansion cabinets/racks)
- Trunked Single-Site Repeater Configuration (expansion cabinets/racks)
- Trunked 3600 IntelliRepeater Site (expansion cabinets/racks)
- Trunked 3600 Simulcast Subsystem (all cabinets/racks)

Figure 17: Expansion Hub



X-Hub2

Function in an ASTRO 25 Repeater Site, ASTRO 25 Express Site, Trunked Single-Site Repeater Site

The XHubs connect to the GCP 8000 Site Controller and allow the site controller to support additional GTR 8000 Expandable Site Subsystem cabinets/racks with channels beyond what the site controller can support on its own. One site controller supports up to five XHubs with each XHub supporting up to six base radios.

The Expansion Hub provides the following functions at the site:

- Switches Ethernet traffic between the attached base radios and the site controller
- Distributes time and frequency references from the site controller to the base radios
- Monitors base radios and RF distribution equipment
- Routes redundant Ethernet paths

Function in a Trunked IP Simulcast Remote Site (Standard Configuration), Trunked 3600 Simulcast Remote Site, or Conventional Site

The XHub provides an Ethernet pathway between the site switch and the base radios. Also provides signal buffering for the time and frequency necessary for the base radios.

Function in a Trunked IP Simulcast Remote Site (High Availability Configuration) or Trunked 3600 IntelliRepeater Site

The XHubs connect to the GPB 8000 Reference Distribution Modules (RDMs) and allow the RDMs to support additional GTR 8000 Expandable Site Subsystem cabinets/racks with channels beyond what

the RDMs can support on their own. One RDM supports up to five Expansion Hubs with each XHub supporting up to six base radios.

The Expansion Hub provides the following functions at the site:

- Switches Ethernet traffic between the attached base radios and the RDMs
- Distributes time and frequency references from the RDMs to the base radios
- Routes redundant Ethernet paths

GGM 8000 Gateway

A GGM 8000 Gateway handles traffic between a remote site network and is the link to either a prime site or master site. The gateway distributes network management traffic between the equipment in the site network.

The Conventional Channel Gateway (GGM 8000 with analog/V.24 interface kit) in an ASTRO® 25 conventional base radio site supports:

- Up to four channels using an analog interface.
- Up to four channels using a V.24 interface.
- Up to ten IP conventional channels.

The GGM 8000 with the Enhanced Low Density Conventional Gateway in an ASTRO® 25 conventional base radio site supports:

- Up to four channels using an analog interface.
- Up to four channels using a V.24 interface.
- Up to 16 IP conventional channels.

For detailed information on the GGM 8000 Gateway and the systems and interfaces it supports, see the *System Gateways – GGM 8000* manual.

GTR 8000 Expandable Site Subsystem Specifications

The following [G-Series Product Specifications](#) reference the TIA specifications for the base radio, including the following Methods and Performance recommendations:

Phase 1 (includes Linear Simulcast):

- Methods: TIA-102.CAAA-C, “Digital C4FM/CQPSK Transceiver Measurements Methods” September 2008
- Performance: TIA-102.CAB-C, “Land Mobile Radio Transceiver Performance Recommendations, Project 25 – Digital Radio Technology, C4FM/CQPSK Modulation” January 2010

Phase 2:

- Methods: TIA-102.CCAA, “Two-Slot Time Division Multiple Access Transceiver Measurement Methods” August 2011
- Performance: TIA 102.CCAB, “Two-Slot Time Division Multiple Access Transceiver Performance Recommendations” October 2011



IMPORTANT: Specifications are subject to change without notice.

Specifications for GTR 8000 Expandable Site Subsystem for HPD (700/800 MHz)

Table 3: General Specifications for GTR 8000 Expandable Site Subsystem for HPD (700/800 MHz)

General Specifications	
Model Number	T7054A or SQM01SUM7054A
Maximum Number of Channels	5
Height	
Cabinet Version (Option CA00293AA):	84.8 in. (215 cm) 43 Rack Units
7.5 ft. Open Rack Version (Option X882AH):	90.4 in. (230 cm) 48 Rack Units
7 ft. Open Rack Version (Option CA01402AA):	84.3 in. (214 cm) 44 Rack Units
Footprint (W x D)	
Cabinet Version (Option CA00293AA):	23.6 x 23.6 (60 x 60 cm)
Open Rack Version (Option X882AH CA01402AA):	20.5 x 23.5 in. (52 x 60 cm)
Weight (fully configured without gateways)	
Cabinet Version (Option CA00293AA):	526 lbs (240 kg)
Open Rack Version (Option X882AH CA01402AA):	475 lbs (215 kg)
Weight (fully configured with gateways)	
Cabinet Version (Option CA00293AA):	571 lbs (260 kg)
Open Rack Version (Option X882AH CA01402AA):	520 lbs (235 kg)
Temperature Range, Operating*	
Open Rack:	-22 to 140 °F (-30 to 60 °C)
Cabinet without Doors:	-22 to 140 °F (-30 to 60 °C)
Cabinet with Doors:	-22 to 131 °F (-30 to 55 °C)
Temperature Range, Storage	-40 to 185 °F (-40 to 85 °C)
Operating Altitude	Up to 1800 meters (5900 ft.) above mean sea level Above 1800 meters (5900 ft.), the derating is 1.5 °C/km (0.8 °F/1000 feet) Maximum operational altitude is 5000 meters (16900 ft.)
Power Supply Input	AC: 90-264 VAC, 47-63 Hz DC: 43.2–60 VDC
Power Consumption (without gateways)**	AC: 2410 W max. DC: 2130 W max.
Power Consumption (with gateways)**	AC: 2490 W max. DC: 2210 W max.
Power Supply Type	Switching
Battery Revert	Included

Table continued...

General Specifications	
Input/Output Impedance	50 Ohms
Antenna Connector Types	
	Tx: 7/16 Female
	Rx: N female
Channel Spacing	25 kHz
Transmit Combiner Spacing	150 kHz
Frequency Stability	GPS Synthesized

* = If the cabinet or rack includes a site gateway for Analog/V.24 conventional channel interfaces, the maximum operating temperature is 122 °F (50 °C) for an open rack and 113 °F (45 °C) for a cabinet with doors.

** = AC power consumption values increase by 1000 W when the batteries are being charged.

Table 4: Transmitter (Cabinet Output) Specifications for GTR 8000 Expandable Site Subsystem for HPD (700/800 MHz)**

Transmitter Specifications: Including RFDS	
Frequency Range	769-775, 775-776, 851–870 MHz
Average power output per channel*	1-20 W
Error Vector Magnitude	10%
Spurious and Harmonic Emissions Attenuation	90 dB
Modulation	64 QAM, 16 QAM, QPSK
Emissions Designators	17K7D7D
Adjacent Channel Power Ratio	
	25 kHz offset, 22 kHz BW: 58 dB
	37.5 kHz offset, 25 kHz BW: 65 dB
Intermodulation Attenuation	80 dB

* Full transmitter output power is available during battery revert at the junction panel.

** Includes Transmitter RF Distribution System.

Table 5: Transmitter RF Distribution System for GTR 8000 Expandable Site Subsystem for HPD (700/800 MHz)

Transmitter RF Distribution System Specifications	
Frequency Range	769-775, 775-776, 851–870 MHz
Insertion Loss (150 kHz spacing)	3.1 dB typ
Tx-Tx Insolation (150 kHz spacing)	32 dB

Table 6: Receiver Specifications (Top of Cabinet) for GTR 8000 Expandable Site Subsystem for HPD (700/800 MHz)

Receiver Specifications, including RFDS	
Frequency Range	792–825 MHz
Modulation	64 QAM, 16 QAM, QPSK
Digital Sensitivity 1% Bit Error Rate Static (BER)	
	64 QAM: -101 dBm
	16 QAM: -108 dBm
	QPSK: -115 dBm
Faded Sensitivity 1% Bit Error Rate TU50 (BER)	
	64 QAM: -93 dBm
	16 QAM: -99 dBm
	QPSK: -104 dBm
Faded Sensitivity 5% Bit Error Rate HT200 (BER)	
	64 QAM: -93 dBm
Faded Sensitivity 2% Bit Error Rate HT200 (BER)	
	16 QAM: -97 dBm
Faded Sensitivity 1% Bit Error Rate HT200 (BER)	
	QPSK: -101 dBm
Intermodulation Rejection*	75 dB
Spurious and Image Response Rejection*	90 dB
Intermediate Frequencies	
	1st: 73.35 MHz
	2nd: 2.16 MHz
Digital Adjacent Channel Rejection*	50 dB
Electronic Bandwidth	Full Bandwidth
Blocking Immunity*	90 dB
Conducted Spurious	-57 dBm
Bit Error Rate Floor	0.01%
Co-Channel Rejection QPSK	11 dB
RF Input Connector Type	N female
RF Impedance	50 Ohms

* Reference signal is QPSK

Table 7: Receiver RF Distribution System for GTR 8000 Expandable Site Subsystem for HPD (700/800 MHz)

Receiver RF Distribution System Specifications		
Frequency Range	792–825 MHz	
	Typical	Limit
Noise Figure	3.8 dB	5 dB
Gain	13 dB	-16 to 24 dB adjustable
3rd Order Output Intercept	21 dB	
Amplifier Intercept	35 dBm	
Preselector Bandwidth	792–825 MHz	
RF Input Connector Type	N	
RF Output Connector Type	BNC	

Table 8: FCC Identification for GTR 8000 Expandable Site Subsystem for HPD (700/800 MHz)

FCC Identification			
Frequency Range	Type	Power Output	Type Acceptance Number
769-775, 775-776 MHz	Transmitter	2–50 W	ABZ89FC5812B
851-870 MHz	Transmitter	2–50 W	ABZ89FC5810B
792-825 MHz	Receiver	N/A	ABZ89FR5811B

GTR 8000 Expandable Site Subsystem Industry Canada for HPD (700/800 MHz)

Table 9: Industry Canada for GTR 8000 Expandable Site Subsystem for HPD (700/800 MHz)

IC Approval Number	Frequency Range	Type	Power Output	IC Model Number
109AB-5810B	Tx 851–866 MHz, Rx 806–866 MHz	HPD	Variable 2-50 Watts (average)	T7039–800B
109AB-5812B	Tx 768–776 MHz, Rx 798–806 MHz	HPD	Variable 2-50 Watts (average)	T7039–700B

Specifications for GTR 8000 Expandable Site Subsystem for Integrated Voice and Data (700/800 MHz)

Table 10: General Specifications for GTR 8000 Expandable Site Subsystem for IV&D (700/800 MHz)

General Specifications	
Model Number	T7054A or SQM01SUM7054A
Maximum Number of Channels	6
Height	
Cabinet Version (Option CA00293AA):	84.8 in. (215 cm) 43 Rack Units

Table continued...

General Specifications	
7.5 ft. Open Rack Version (Option X882AH):	90.4 in. (230 cm) 48 Rack Units
7 ft. Open Rack Version (Option CA01402AA):	84.3 in. (214 cm) 44 Rack Units
Footprint (W x D)	
Cabinet Version (Option CA00293AA):	23.6 x 23.6 (60 x 60 cm)
Open Rack Version (Option X882AH CA01402AA):	20.5 x 23.5 in. (52 x 60 cm)
Weight (fully configured without gateways)	
Cabinet Version (Option CA00293AA):	526 lbs (240 kg)
Open Rack Version (Option X882AH CA01402AA):	475 lbs (215 kg)
Weight (fully configured with gateways)	
Cabinet Version (Option CA00293AA):	571 lbs (260 kg)
Open Rack Version (Option X882AH CA01402AA):	520 lbs (235 kg)
Temperature Range, Operating*	
Open Rack:	-22 to 140 °F (-30 to 60 °C)
Cabinet without Doors:	-22 to 140 °F (-30 to 60 °C)
Cabinet with Doors:	-22 to 131 °F (-30 to 55 °C)
Temperature Range, Storage	
	-40 to 185 °F (-40 to 85 °C)
Operating Altitude	
	Up to 1800 meters (5900 ft.) above mean sea level
	Above 1800 meters (5900 ft.), the derating is 1.5 °C/km (0.8 °F/1000 feet)
	Maximum operational altitude is 5000 meters (16900 ft.)
Power Supply Input	
	AC: 90-264 VAC, 47-63 Hz
	DC: 43.2–60 VDC
Power Consumption (without gateways)**	
AC:	C4FM, FM: 2890 W max. H-DQPSK, LSM: 3250 W max.
DC:	C4FM, FM: 2650 W max. H-DQPSK, LSM: 3010 W max.
Power Consumption (with gateways)**	
AC:	C4FM, FM: 3010 W max. H-DQPSK, LSM: 3370 W max.
DC:	C4FM, FM: 2770 W max. H-DQPSK, LSM: 3130 W max.
Power Supply Type	
	Switching
Battery Revert	
	Included
Input/Output Impedance	
	50 Ohms

Table continued...

General Specifications	
Antenna Connector Types	Tx: 7/16 Female Rx: N female
Channel Spacing	12.5/25 kHz
Transmit Combiner Spacing	150 kHz
Frequency Stability (High Availability configuration)	GPS locked or Aging: 30 ppb/yr 100 ppb/5yr Temperature: 40 ppb
Frequency Stability Internal Reference (transceiver option card)	Aging: 30 ppb/yr 100 ppb/5yr Temperature: 40 ppb
Frequency Stability External Reference	TRAK
Frequency Generation	Synthesized

* = If the cabinet or rack includes a site gateway for Analog/V.24 conventional channel interfaces, the maximum operating temperature is 122 °F (50 °C) for an open rack and 113 °F (45 °C) for a cabinet with doors.

** = AC power consumption values increase by 1200 W when the batteries are being charged.

Table 11: Transmitter (Cabinet Output) Specifications for GTR 8000 Expandable Site Subsystem for IV&D (700/800 MHz)**

Transmitter Specifications: Including RFDS	
Frequency Range	769-775, 775-776, 851-870 MHz
Average power output per channel*	1-40 W
Modulation Fidelity	5%
Spurious and Harmonic Emissions Attenuation	90 dB
Modulation	C4FM, LSM, H-DQPSK, FM
Analog FM Hum and Noise	
	12.5 kHz 45 dB
	25 kHz 50 dB
Analog Audio Distortion	Less than 2% at 1000 Hz
Emissions Designators	8K70D1E, 8K70D1D, 8K70D1W 8K10F1E, 8K10F1D, 8K10F1W 9K80D7E, 9K80D7D, 9K80D7W 10K0F1E, 10K0F1D, 800 W only: 10K0F1W, 16K0F1D, 16K0F3E, 11K0F3E, 14K0F1D, 14K0F3E
Adjacent Channel Power Ratio	

Table continued...

Transmitter Specifications: Including RFDS

12.5 kHz offset, 6 kHz BW:	67 dB
Intermodulation Attenuation	80 dB

* Full transmitter output power is available during battery revert at the junction panel.

** Includes Transmitter RF Distribution System.

Table 12: Transmitter RF Distribution System for GTR 8000 Expandable Site Subsystem for IV&D (700/800 MHz)

Transmitter RF Distribution System Specifications

Frequency Range	769-775, 775-776, 851-870 MHz
Insertion Loss (150 kHz spacing)	3.1 dB typ
Tx-Tx Insolation (150 kHz spacing)	32 dB

Table 13: Receiver (Top of Cabinet) Specifications for GTR 8000 Expandable Site Subsystem for IV&D (700/800 MHz)

Receiver Specifications, including RFDS

Frequency Range	792-825 MHz
Modulation	C4FM, H-CPM, FM
Analog Sensitivity (12 dB SINAD)	
	12.5 kHz -123 dBm
	25 kHz -122 dBm
Digital Sensitivity 5% Bit Error Rate Static (BER)	
	C4FM: -123 dBm
	H-CPM: -121 dBm
Faded Sensitivity 5% Bit Error Rate (BER)	
	C4FM: -115 dBm
Intermodulation Rejection	80 dB
Digital Adjacent Channel Rejection	60 dB
Analog Adjacent Channel Rejection (EIA603) Analog 12.5 kHz	75 dB
Analog Adjacent Channel Rejection (TIA603D)	
	Analog 12.5 kHz 50 or 60 dB (adjustable)
	Analog 25 kHz 80 dB
Spurious and Image Response Rejection	100 dB
Analog Audio Response	+1, -3 dB from 6 dB per octave de-emphasis; 300-3000 Hz referenced to 1000 Hz at line output
Analog Audio Distortion	3% or 5% (adjustable)
Analog FM Hum and Noise	

Table continued...

Receiver Specifications, including RFDS	
	12.5 kHz 45 dB
	25 kHz 50 dB
Blocking Immunity	100 dB
Signal Displacement Bandwidth	1 kHz
Intermediate Frequencies	
	1st: 73.35 MHz
	2nd: 2.16 MHz
Electronic Bandwidth	Full Bandwidth
Conducted Spurious	-57 dBm
Bit Error Rate Floor	0.01%

Table 14: Receiver RF Distribution System for GTR 8000 Expandable Site Subsystem for IV&D (700/800 MHz)

Receiver RF Distribution System Specifications		
Frequency Range	792–825 MHz	
	Typical	Limit
Noise Figure	3.8 dB	5 dB
Gain	13 dB	-16 to 24 dB adjustable
3rd Order Output Intercept	21 dB	
Amplifier Intercept		35 dBm
Preselector Bandwidth	792–825 MHz	
RF Input Connector Type	N	
RF Output Connector Type	BNC	

Table 15: FCC Identification for GTR 8000 Expandable Site Subsystem for IV&D (700/800 MHz)

FCC Identification			
Frequency Range	Type	Power Output	Type Acceptance Number
769-775, 775-776 MHz	Transmitter	2-100 W	ABZ89FC5812B
851–870 MHz	Transmitter	2-100 W	ABZ89FC5810B
792–825 MHz	Receiver	N/A	ABZ89FR5811B

GTR 8000 Expandable Site Subsystem Industry Canada for Integrated Voice and Data (700/800 MHz)

Table 16: Industry Canada for GTR 8000 Expandable Site Subsystem for IV&D (700/800 MHz)

IC Approval Number	Frequency Range	Type	Power Output	IC Model Number
109AB-5810B	Tx 851–869 MHz, Rx 806–824 MHz	LSM	Variable 2-100 Watts (average)	T7039–800B
109AB-5810B	Tx 851–869 MHz, Rx 806–824 MHz	C4FM, FM	Variable 2-100 Watts	T7039–800B
109AB-5812B	Tx 768–776 MHz, Rx 798–806 MHz	LSM	Variable 2-100 Watts (average)	T7039–700B
109AB-5812B	Tx 768–776 MHz, Rx 798–806 MHz	C4FM, FM	Variable 2-100 Watts	T7039–700B

Specifications for GTR 8000 Expandable Site Subsystem for Integrated Voice and Data (900 MHz)

Table 17: General Specifications for GTR 8000 Expandable Site Subsystem for IV&D (900 MHz)

General Specifications	
Model Number	T7054A or SQM01SUM7054A
Maximum Number of Channels	6
Height	
Cabinet Version (Option CA00293AA):	84.8 in. (215 cm) 43 Rack Units
7.5 ft. Open Rack Version (Option X882AH):	90.4 in. (230 cm) 48 Rack Units
7 ft. Open Rack Version (Option CA01402AA):	84.3 in. (214 cm) 44 Rack Units
Footprint (W x D)	
Cabinet Version (Option CA00293AA):	23.6 x 23.6 in. (60 x 60 cm)
Open Rack Version (Option X882AH CA01402AA):	20.5 x 23.5 in. (52 x 60 cm)
Weight (fully configured without gateways)	
Cabinet Version (Option CA00293AA):	550 lbs (250 kg)
Open Rack Version (Option X882AH CA01402AA):	495 lbs (225 kg)
Weight (fully configured with gateways)	
Cabinet Version (Option CA00293AA):	595 lbs (270 kg)
Open Rack Version (Option X882AH CA01402AA):	540 lbs (245 kg)
Temperature Range, Operating	
Open Rack:	-22 to 140 °F (-30 to 60 °C)
Cabinet without Doors:	-22 to 140 °F (-30 to 60 °C)
Cabinet with Doors:	-22 to 122 °F (-30 to 50 °C)

Table continued...

General Specifications	
Temperature Range, Storage	-40 to 185 °F (-40 to 85 °C)
Operating Altitude	Up to 1800 meters (5900 ft.) above mean sea level Above 1800 meters (5900 ft.), the derating is 1.5 °C/km (0.8 °F/1000 feet) Maximum operational altitude is 5000 meters (16900 ft.)
Power Supply Input	AC: 90-264 VAC, 47-63 Hz DC: 43.2–60 VDC
Power Consumption*	AC: C4FM: 3700 W max. LSM: 4100 W max. DC: C4FM: 3400 W max. LSM: 3700 W max.
Channel Spacing	12.5 kHz
Transmit Combiner Spacing	12.5 kHz (hybrid) 150 kHz (cavity)
Power Supply Type	Switching
Battery Revert	Included
Input/Output Impedance	50 Ohms
Antenna Connector Types	Tx: 7/16 Female (with cavity combiner) Tx: N female (with hybrid combiner) Rx: N female
Frequency Stability (High Availability configuration)	GPS locked or Aging: 30 ppb/yr 100 ppb/5yr Temperature: 40 ppb
Frequency Stability Internal Reference (transceiver option card)	Aging: 30 ppb/yr 100 ppb/5yr Temperature: 40 ppb
Frequency Stability External Reference	TRAK
Frequency Generation	Synthesized

* = AC power consumption values increase by 1200 W when the batteries are being charged.

Table 18: Transmitter (Cabinet Output) Specifications for GTR 8000 Expandable Site Subsystem for IV&D (900 MHz)**

Transmitter Specifications: Including RFDS	
Frequency Range	935–941 MHz
Average power output per channel*	
Single PA Output, no combining:	2-80 W
Hybrid Single Output 2-way:	1-37 W
Hybrid Single Output 3-way:	1-22 W
Hybrid Single Output 4-way:	1-17 W
Hybrid Single Output 5-way:	1-12 W
Hybrid Single Output 6-way:	1-10 W
Hybrid Dual Output 2-way:	1-37 W
Hybrid Dual Output 3-way:	1-22 W
Modulation Fidelity	5%
Spurious and Harmonic Emissions Attenuation	90 dB
Modulation	H-DQPSK, FM
Emissions Designators	8K70D1W, 8K10F1E, 8K10F1D, 9K80D7W
Adjacent Channel Power Ratio	
12.5 kHz offset, 6 kHz BW:	67 dB
Intermodulation Attenuation	80 dB

* Full transmitter output power is available during battery revert at the junction panel.

** Includes Transmitter RF Distribution System.

Table 19: Transmitter RF Distribution System for GTR 8000 Expandable Site Subsystem for IV&D (900 MHz)

Transmitter RF Distribution System Specifications	
Frequency Range	935–941 MHz
Insertion Loss (150 kHz spacing)	2-way loss: 4.4 dB typ 3-way loss: 6.3 dB typ 4-way loss: 7.6 dB typ 5-way loss: 8.8 dB typ 6-way loss: 9.7 dB typ
Tx-Tx Insolation (150 kHz spacing)	20 dB

Table 20: Receiver (Top of Cabinet) Specifications for GTR 8000 Expandable Site Subsystem for IV&D (900 MHz)

Receiver Specifications, including RFDS	
Frequency Range	896–902 MHz
Modulation	C4FM

Table continued...

Receiver Specifications, including RFDS	
Digital Sensitivity 5% Bit Error Rate Static (BER)	
C4FM:	-123 dBm
Faded Sensitivity 5% Bit Error Rate (BER)	
C4FM:	-115 dBm
Intermodulation Rejection	80 dB
Digital Adjacent Channel Rejection	60 dB
Spurious and Image Response Rejection	100 dB
Blocking Immunity	100 dB
Signal Displacement Bandwidth	1 kHz
Intermediate Frequencies	
1st:	73.35 MHz
2nd:	2.16 MHz
Electronic Bandwidth	Full Bandwidth
Conducted Spurious	-57 dBm
Bit Error Rate Floor	0.01%

Table 21: Receiver RF Distribution System for GTR 8000 Expandable Site Subsystem for IV&D (900 MHz)

Receiver RF Distribution System Specifications		
Frequency Range	896–902 MHz	
	Typical	Limit
Noise Figure	3.8 dB	5 dB
Gain	13 dB	-16 to 24 dB adjustable
3rd Order Output Intercept	21 dB	
Amplifier Intercept		35 dBm
Preselector Bandwidth	896–902 MHz	
RF Input Connector Type	N	
RF Output Connector Type	BNC	

Table 22: FCC Identification for GTR 8000 Expandable Site Subsystem for IV&D (900 MHz)

FCC Identification			
Frequency Range	Type	Power Output	Type Acceptance Number
935–941 MHz	Transmitter	2-120 W	ABZ89FC5823B
896–902 MHz	Receiver	N/A	ABZ89FR5824B

GTR 8000 Expandable Site Subsystem Industry Canada for Integrated Voice and Data (900 MHz)

Table 23: Industry Canada for GTR 8000 Expandable Site Subsystem for IV&D (900 MHz)

IC Approval Number	Frequency Range	Type	Power Output	IC Model Number
109AB-5824B	Tx 935–940 MHz, Rx 896–901 MHz	H-DQPSK, FM	Variable 2-120 Watts (average)	T7039–900B

Specifications for GTR 8000 Expandable Site Subsystem for Integrated Voice and Data (UHF R1, 380–435 MHz)

Table 24: General Specifications for GTR 8000 Expandable Site Subsystem for IV&D (UHF R1, 380–435 MHz)

General Specifications	
Model Number	T7054A or SQM01SUM7054A
Maximum Number of Channels	6
Height	
Cabinet Version (Option CA00293AA):	84.8 in. (215 cm) 43 Rack Units
7.5 ft. Open Rack Version (Option X882AH):	90.4 in. (230 cm) 48 Rack Units
7 ft. Open Rack Version (Option CA01402AA):	84.3 in. (214 cm) 44 Rack Units
Footprint (W x D)	
Cabinet Version (Option CA00293AA):	23.6 x 23.6 in. (60 x 60 cm)
Open Rack Version (Option X882AH CA01402AA):	20.5 x 23.5 in. (52 x 60 cm)
Weight (fully configured without gateways)	
Cabinet Version (Option CA00293AA):	495 lbs (225 kg)
Open Rack Version (Option X882AH CA01402AA):	430 lbs (195 kg)
Weight (fully configured with gateways)	
Cabinet Version (Option CA00293AA):	540 lbs (245 kg)
Open Rack Version (Option X882AH CA01402AA):	475 lbs (215 kg)
Temperature Range*	
Open Rack:	-22 to 140 °F (-30 to 60 °C)
Cabinet without Doors:	-22 to 140 °F (-30 to 60 °C)
Cabinet with Doors:	-22 to 131 °F (-30 to 55 °C)
Temperature Range, Storage	-40 to 185 °F (-40 to 85 °C)
Operating Altitude	Up to 1800 meters (5900 ft.) above mean sea level Above 1800 meters (5900 ft.), the derating is 1.5 °C/km (0.8 °F/1000 feet)

Table continued...

General Specifications	
	Maximum operational altitude is 5000 meters (16900 ft.)
Power Supply Input	AC: 90-264 VAC, 47-63 Hz DC: 43.2–60 VDC
Power Consumption (without gateways)**	
	AC: C4FM, FM: 3070 W max H-DQPSK, LSM: 3370 W max
	DC: C4FM, FM: 2830 W max. H-DQPSK, LSM: 3130 W max.
Power Consumption (with gateways)**	
	AC: C4FM, FM: 3190 W max. H-DQPSK, LSM: 3490 W max.
	DC: C4FM, FM: 2950 W max. H-DQPSK, LSM: 3250 W max.
Power Supply Type	Switching
Battery Revert	Included
Input/Output Impedance	50 Ohms
Antenna Connector Types	Tx: six N female Rx: six BNC female
Channel Spacing	12.5/25 kHz
Frequency Stability (High Availability configuration)	GPS locked or Aging: 30 ppb/yr 100 ppb/5yr Temperature: 40 ppb
Frequency Stability Internal Reference (OCXO transceiver option card)	Aging: 30 ppb/yr 100 ppb/5yr Temperature: 40 ppb
Frequency Stability Internal Reference (TCXO transceiver option card)	Aging: 1000 ppb/yr Temperature: 500 ppb
Frequency Stability External Reference	TRAK
Frequency Generation	Synthesized

* = If the cabinet or rack includes a site gateway for Analog/V.24 conventional channel interfaces, the maximum operating temperature is 122 °F (50 °C) for an open rack and 113 °F (45 °C) for a cabinet with doors.

** = AC power consumption values increase by 1200 W when the batteries are being charged.

Table 25: Transmitter (Cabinet Output) Specifications for GTR 8000 Expandable Site Subsystem for IV&D (UHF R1, 380–435 MHz)

Transmitter Specifications	
Frequency Range	380–435 MHz
Average power output per channel*	2-110 W C4FM, FM 2-100 W LSM, H-DQPSK
Modulation Fidelity	5%
Spurious and Harmonic Emissions Attenuation	90 dB
Analog FM Hum and Noise	
	12.5 kHz: 45 dB
	25 kHz: 50 dB
Analog Audio Distortion	Less than 2% (1% typical) at 1000 Hz
Modulation	C4FM, LSM, H-DQPSK, FM
Emissions Designators	8K70D1W, 8K70D1E, 8K70D1D, 8K10F1W, 8K10F1E, 8K10F1D, 9K80D7W, 9K80D7E, 9K80D7D, 16K0F3E, 11K0F3E, 16K0F1D, 10K0F1D
Adjacent Channel Power Ratio	
	12.5 kHz offset, 6 kHz BW: 67 dB
Intermodulation Attenuation	65 dB

* Full transmitter output power is available during battery revert at the junction panel.

Table 26: Receiver (Top Cabinet) Specifications for GTR 8000 Expandable Site Subsystem for IV&D (UHF R1, 380–435 MHz)

Receiver Specifications	
Frequency Range	380–435 MHz
Modulation	C4FM, H-CPM, FM
Analog Sensitivity (12 dB SINAD)	
	12.5 kHz: -117 dBm
	25 kHz: -116 dBm
Digital Sensitivity 5% Bit Error Rate Static (BER)	
	C4FM: -117 dBm
	H-CPM: -115 dBm
Faded Sensitivity 5% Bit Error Rate (BER)	
	C4FM: -109 dBm
Intermodulation Rejection	85 dB
Digital Adjacent Channel Rejection	60 dB
Analog Adjacent Channel Rejection (EIA603) Analog 12.5 kHz	75 dB

Table continued...

Receiver Specifications	
Analog Adjacent Channel Rejection (TIA603D)	
Analog 12.5 kHz:	50 or 60 dB (adjustable)
Analog 25 kHz:	80 dB
Spurious and Image Response Rejection	85 dB
Analog Audio Response	+1, -3 dB from 6 dB per octave de-emphasis; 300–3000 Hz referenced to 1000 Hz at line output
Analog Audio Distortion	3% or 5% (adjustable)
Analog FM Hum and Noise	
12.5 kHz:	45 dB
25 kHz:	50 dB
Blocking Immunity	100 dB
Signal Displacement Bandwidth	1 kHz
Intermediate Frequencies	
1st:	73.35 MHz
2nd:	2.16 MHz
Electronic Bandwidth	Full Bandwidth
Conducted Spurious	-57 dBm
Bit Error Rate Floor	0.01%

Table 27: FCC Identification for GTR 8000 Expandable Site Subsystem for IV&D (UHF R1, 380–435 MHz)

FCC Identification			
Frequency Range	Type	Power Output	Type Acceptance Number
406.1–435 MHz	Transmitter	2-110 W C4FM, FM 2-100 W LSM, H-DQPSK	ABZ89FC4821B
380–435 MHz	Receiver	N/A	ABZ89FR4822B

GTR 8000 Expandable Site Subsystem Industry Canada for Integrated Voice and Data (UHF R1, 380–435 MHz)

Table 28: Industry Canada for GTR 8000 Expandable Site Subsystem for IV&D (UHF R1 380–435 MHz)

IC Approval Number	Frequency Range	Type	Power Output	IC Model Number
109AB-4821B	Tx 406.1–430 MHz, Rx 406.1–430 MHz	C4FM, FM	Variable 2-110 Watts	T7039-UHFR1B
109AB-4821B	Tx 406.1–430 MHz, Rx 406.1–430 MHz	LSM, H-DQPSK	Variable 2-100 Watts	T7039-UHFR1B

Specifications for GTR 8000 Expandable Site Subsystem for Integrated Voice and Data (UHF R2, 435–524 MHz)

Table 29: General Specifications for GTR 8000 Expandable Site Subsystem for IV&D (UHF R2, 435–524 MHz)

General Specifications	
Model Number	T7054A or SQM01SUM7054A
Maximum Number of Channels	6
Height	
Cabinet Version (Option CA00293AA):	84.8 in. (215 cm) 43 Rack Units
7.5 ft. Open Rack Version (Option X882AH):	90.4 in. (230 cm) 48 Rack Units
7 ft. Open Rack Version (Option CA01402AA):	84.3 in. (214 cm) 44 Rack Units
Footprint (W x D)	
Cabinet Version (Option CA00293AA):	23.6 x 23.6 in. (60 x 60 cm)
Open Rack Version (Option X882AH CA01402AA):	20.5 x 23.5 in. (52 x 60 cm)
Weight (fully configured with cavity combiner, no gateways)	
Cabinet Version (Option CA00293AA):	610 lbs (280 kg)
Open Rack Version (Option X882AH CA01402AA):	565 lbs (260 kg)
Weight (fully configured with gateways, no cavity combiner)	
Cabinet Version (Option CA00293AA):	540 lbs (245 kg)
Open Rack Version (Option X882AH CA01402AA):	475 lbs (215 kg)
Temperature Range*	
Open Rack:	-22 to 140 °F (-30 to 60 °C)
Cabinet without Doors:	-22 to 140 °F (-30 to 60 °C)
Cabinet with Doors:	-22 to 131 °F (-30 to 55 °C)
Temperature Range, Storage	-40 to 185 °F (-40 to 85 °C)
Operating Altitude	Up to 1800 meters (5900 ft.) above mean sea level Above 1800 meters (5900 ft.), the derating is 1.5 °C/km (0.8 °F/1000 feet) Above 3,000 meters (9,800 feet), the peak power derating for the Tx filter is 1dB/1km (0.3dB/1,000 ft.) Maximum operational altitude is 5000 meters (16900 ft.)
Power Supply Input	AC: 90-264 VAC, 47-63 Hz DC: 43.2–60 VDC

Table continued...

General Specifications	
Power Consumption (with cavity combiner, no gateways)**	
AC:	C4FM, FM: 2830 W max. H-DQPSK, LSM: 3130 W max.
DC:	C4FM, FM: 2590 W max. H-DQPSK, LSM: 2890 W max.
Power Consumption (with gateways, no cavity combiner)**	
AC:	C4FM, FM: 2950 W max. H-DQPSK, LSM: 3250 W max.
DC:	C4FM, FM: 2710 W max. H-DQPSK, LSM: 3010 W max.
Power Supply Type	Switching
Battery Revert	Included
Input/Output Impedance	50 Ohms
Antenna Connector Types	
	Tx: 7/16 Female
	Rx: N female
Channel Spacing	12.5/25 kHz
Transmit Combiner Spacing	150 kHz
Frequency Stability (High Availability configuration)	GPS locked or Aging: 30 ppb/yr 100 ppb/5yr Temperature: 40 ppb
Frequency Stability Internal Reference (OCXO transceiver option card)	Aging: 30 ppb/yr 100 ppb/5yr Temperature: 40 ppb
Frequency Stability Internal Reference (TCXO transceiver option card)	Aging: 1000 ppb/yr Temperature: 500 ppb
Frequency Stability External Reference	TRAK
Frequency Generation	Synthesized

* = If the cabinet or rack includes a site gateway for Analog/V.24 conventional channel interfaces, the maximum operating temperature is 122 °F (50 °C) for an open rack and 113 °F (45 °C) for a cabinet with doors.

** = AC power consumption values increase by 1200 W when the batteries are being charged.

Table 30: Transmitter (Cabinet Output)** Specifications for GTR 8000 Expandable Site Subsystem for IV&D (UHF 450–512 MHz) Including RFDS

Transmitter Specifications: Including RFDS	
Frequency Range	450–512 MHz
Average power output per channel*	
	C4FM, FM: 1-33 W
	H-DQPSK, LSM: 1-30 W
Modulation Fidelity	5%
Spurious and Harmonic Emissions Attenuation	90 dB
Modulation	C4FM, LSM, H-DQPSK, FM
Analog FM Hum and Noise	
	12.5 kHz: 45 dB
	25 kHz: 50 dB
Analog Audio Distortion	Less than 2% (1% typical) at 1000 Hz
Emissions Designators	8K70D1W, 8K70D1E, 8K70D1D, 8K10F1W, 8K10F1E, 8K10F1D, 9K80D7W, 9K80D7E, 9K80D7D, 16K0F3E, 11K0F3E, 16K0F1D, 10K0F1D
Adjacent Channel Power Ratio	
	12.5 kHz offset, 6 kHz BW: 67 dB
Intermodulation Attenuation	80 dB

* Full transmitter output power is available during battery revert at the junction panel.

** Includes Transmitter RF Distribution System.

Table 31: Transmitter RF Distribution System for GTR 8000 Expandable Site Subsystem for IV&D (UHF 450–512 MHz)

Transmitter RF Distribution System Specifications	
Frequency Range	450–512 MHz
Insertion Loss (150 kHz spacing)	4.5 dB typ
Tx-Tx Insolation (150 kHz spacing)	32 dB

Table 32: Receiver (Top of Cabinet) Specifications for GTR 8000 Expandable Site Subsystem for IV&D (UHF 450–512 MHz) Including RFDS

Receiver Specifications, including RFDS	
Frequency Range	450–512 MHz
Modulation	C4FM, H-CPM, FM
Analog Sensitivity (12 dB SINAD)	
	12.5 kHz: -121.5 dBm
	25 kHz: -120.5 dBm

Table continued...

Receiver Specifications, including RFDS	
Digital Sensitivity 5% Bit Error Rate Static (BER)	
C4FM:	-121.5 dBm
H-CPM:	-119.5 dBm
Faded Sensitivity 5% Bit Error Rate (BER)	
C4FM:	-113.5 dBm
Intermodulation Rejection	80 dB
Digital Adjacent Channel Rejection	60 dB
Analog Adjacent Channel Rejection (EIA603) Analog 12.5 kHz	75 dB
Analog Adjacent Channel Rejection (TIA603D)	
Analog 12.5 kHz:	50 or 60 dB (adjustable)
Analog 25 kHz:	80 dB
Spurious and Image Response Rejection	100 dB
Analog Audio Response	+1, -3 dB from 6 dB per octave de-emphasis; 300–3000 Hz referenced to 1000 Hz at line output
Analog Audio Distortion	3% or 5% (adjustable)
Analog FM Hum and Noise	
12.5 kHz:	45 dB
25 kHz:	50 dB
Blocking Immunity	100 dB
Signal Displacement Bandwidth	1 kHz
Intermediate Frequencies	
1st:	73.35 MHz
2nd:	2.16 MHz
Electronic Bandwidth	2.0 or 3.5 MHz
Conducted Spurious	-57 dBm
Bit Error Rate Floor	0.01%

Table 33: Receiver RF Distribution System for GTR 8000 Expandable Site Subsystem for IV&D (UHF 450–512 MHz)

Receiver RF Distribution System Specifications		
Frequency Range	450–512 MHz	
	Typical	Limit
Noise Figure	4.6 dB	5.5 dB
Gain	10 dB	–16 to 24 dB adjustable
3rd Order Output Intercept	19 dB	
Amplifier Intercept		40 dBm

Table continued...

Receiver RF Distribution System Specifications	
Preselector Bandwidth	2 or 3.5 MHz
RF Input Connector Type	N
RF Output Connector Type	BNC

Table 34: FCC Identification for GTR 8000 Expandable Site Subsystem for IV&D (UHF R2, 435–524 MHz)

FCC Identification			
Frequency Range	Type	Power Output	Type Acceptance Number
435–512 MHz	Transmitter	2-110 W C4FM, FM 2-100 W LSM, H-DQPSK	ABZ89FC4819B
435–524 MHz	Receiver	N/A	ABZ89FR4820B

GTR 8000 Expandable Site Subsystem Industry Canada for Integrated Voice and Data (UHF R2, 435–524 MHz)

Table 35: Industry Canada for GTR 8000 Expandable Site Subsystem for IV&D (UHF R2, 435–524 MHz)

IC Approval Number	Frequency Range	Type	Power Output	IC Model Number
109AB-4819B	Tx 450–470 MHz, Rx 450–470 MHz	C4FM, FM	Variable 2-110 Watts (average)	T7039-UHFR2B
109AB-4819B	Tx 450–470 MHz, Rx 450–470 MHz	LSM, H-DQPSK	Variable 2-100 Watts	T7039-UHFR2B

Specifications for GTR 8000 Expandable Site Subsystem for Integrated Voice and Data (VHF 136–174 MHz)

Table 36: General Specifications for GTR 8000 Expandable Site Subsystem for IV&D (VHF, 136–174 MHz)

General Specifications	
Model Number	T7054A or SQM01SUM7054A
Maximum Number of Channels	6
Height	
Cabinet Version (Option CA00293AA):	84.8 in. (215 cm) 43 Rack Units
7.5 ft. Open Rack Version (Option X882AH):	90.4 in. (230 cm) 48 Rack Units
7 ft. Open Rack Version (Option CA01402AA):	84.3 in. (214 cm) 44 Rack Units
Footprint (W x D)	
Cabinet Version (Option CA00293AA):	23.6 x 23.6 in. (60 x 60 cm)

Table continued...

General Specifications	
Open Rack Version (Option X882AH CA01402AA):	20.5 x 23.5 in. (52 x 60 cm)
Weight (fully configured without gateways)	
Cabinet Version (Option CA00293AA):	495 lbs (255 kg)
Open Rack Version (Option X882AH CA01402AA):	430 lbs (195 kg)
Weight (fully configured with gateways)	
Cabinet Version (Option CA00293AA):	540 lbs (275 kg)
Open Rack Version (Option X882AH CA01402AA):	475 lbs (215 kg)
Temperature Range*	
Open Rack:	-22 to 140 °F (-30 to 60 °C)
Cabinet without Doors:	-22 to 140 °F (-30 to 60 °C)
Cabinet with Doors:	-22 to 131 °F (-30 to 55 °C)
Temperature Range, Storage	-40 to 185 °F (-40 to 85 °C)
Operating Altitude	Up to 1800 meters (5900 ft.) above mean sea level Above 1800 meters (5900 ft.), the derating is 1.5 °C/km (0.8 °F/1000 ft.) Maximum operational altitude is 5000 meters (16900 ft.)
Power Supply Input	AC: 90-264 VAC, 47-63 Hz DC: 43.2–60 VDC
Power Consumption (without gateways)**	
AC:	C4FM, FM: 3070 W max. H-DQPSK, LSM: 2530 W max.
DC:	C4FM, FM: 2830 W max. H-DQPSK, LSM: 2230 W max.
Power Consumption (with gateways)**	
AC:	C4FM, FM: 3190 W max. H-DQPSK, LSM: 2650 W max.
DC:	C4FM, FM: 2950 W max. H-DQPSK, LSM: 2350 W max.
Power Supply Type	Switching
Battery Revert	Included
Input/Output Impedance	50 Ohms
Antenna Connector Types	Tx: six N female Rx: six BNC female
Channel Spacing	12.5/15/25/30 kHz
Frequency Stability (High Availability configuration)	GPS locked or Aging:

Table continued...

General Specifications	
	30 ppb/yr 100 ppb/5yr Temperature: 40 ppb
Frequency Stability Internal Reference (transceiver option card)	Aging: 30 ppb/yr 100 ppb/5yr Temperature: 40 ppb
Frequency Stability External Reference	TRAK
Frequency Generation	Synthesized

* = If the cabinet or rack includes a site gateway for Analog/V.24 conventional channel interfaces, the maximum operating temperature is 122 °F (50 °C) for an open rack and 113 °F (45 °C) for a cabinet with doors.

** = AC power consumption values increase by 1200 W when the batteries are being charged.

Table 37: Transmitter Specifications for GTR 8000 Expandable Site Subsystem for IV&D (VHF, 136–174 MHz)

Transmitter Specifications	
Frequency Range	136–174 MHz
Average power output per channel*	2-100 W C4FM, FM 2-60 W H-DQPSK, LSM
Modulation Fidelity	5%
Spurious and Harmonic Emissions Attenuation	90 dB
Modulation	C4FM, LSM, H-DQPSK, FM
Analog FM Hum and Noise	
	12.5 kHz: 45 dB
	25 kHz: 50 dB
Analog Audio Distortion	Less than 2% (1% typical) at 1000 Hz
Emissions Designators	8K70D1W, 8K70D1E, 8K70D1D, 8K10F1W, 8K10F1E, 8K10F1D, 9K80D7W, 9K80D7E, 9K80D7D, 16K0F3E, 11K0F3E, 16K0F1D, 10K0F1D
Adjacent Channel Power Ratio	
	12.5 kHz offset, 6 kHz BW: 67 dB
Intermodulation Attenuation	55 dB

* Full transmitter output power is available during battery revert at the junction panel.

Table 38: Receiver Specifications for GTR 8000 Expandable Site Subsystem for IV&D (VHF, 136–174 MHz)

Receiver Specifications	
Frequency Range	136–174 MHz
Modulation	C4FM, H-CPM, FM
Analog Sensitivity (12 dB SINAD)	
12.5/15 kHz:	-118 dBm
25/30 kHz:	-117 dBm
Digital Sensitivity 5% Bit Error Rate Static (BER)	
C4FM:	-118 dBm
H-CPM:	-116 dBm
Faded Sensitivity 5% Bit Error Rate (BER)	
C4FM:	-110 dBm
Intermodulation Rejection	85 dB
Digital Adjacent Channel Rejection	60 dB
Analog Adjacent Channel Rejection (EIA603) Analog 12.5 kHz	75 dB
Analog Adjacent Channel Rejection (TIA603D)	
Analog 12.5 kHz:	50 or 60 dB (adjustable)
Analog 25 kHz:	80 dB
Spurious and Image Response Rejection	90 dB
Analog Audio Response	+1, -3 dB from 6 dB per octave de-emphasis; 300–3000 Hz referenced to 1000 Hz at line output
Analog Audio Distortion	3% or 5% (adjustable)
Analog FM Hum and Noise	
12.5 kHz:	45 dB
25 kHz:	50 dB
Blocking Immunity	100 dB
Signal Displacement Bandwidth	1 kHz
Intermediate Frequencies	
1st:	44.85 MHz
2nd:	2.16 MHz
Electronic Bandwidth	Full Bandwidth
Conducted Spurious	-57 dBm
Bit Error Rate Floor	0.01%

Table 39: FCC Identification for GTR 8000 Expandable Site Subsystem for IV&D (VHF, 136–174 MHz)

FCC Identification			
Frequency Range	Type	Power Output	Type Acceptance Number
136–174 MHz	Transmitter	2-100 W C4FM, FM 2-60 W LSM, H-DQPSK	ABZ89FC3790B
136–174 MHz	Receiver	N/A	ABZ89FR3791B

GTR 8000 Expandable Site Subsystem Industry Canada for Integrated Voice and Data (VHF 136–174 MHz)

Table 40: Industry Canada for GTR 8000 Expandable Site Subsystem for IV&D (VHF 136–174 MHz)

IC Approval Number	Frequency Range	Type	Power Output	IC Model Number
109AB-3790B	Tx 138–174 MHz, Rx 138–174 MHz	C4FM, FM	Variable 2–100 Watts	T7039–VHFB
109AB-3790B	Tx 138–174 MHz, Rx 138–174 MHz	LSM, H-DQPSK	Variable 2–60 Watts	T7039–VHFB

Specifications for the GCP 8000 Site Controller and GPB 8000 Reference Distribution Module

Table 41: GCP 8000 Site Controller and GPB 8000 Reference Distribution Module Technical and Environmental Specifications

General Specifications	
Temperature	
Operating temperature:	-30 to 60 °C (-22 to 140 °F)
Storage temperature:	-40 to 85 °C (-40 to 185 °F)
Relative humidity	90% relative humidity at 50 °C non-condensing
Input supply voltage	See the individual frequency bands for the GTR 8000 Expandable Site Subsystem specifications
Power consumption	See the individual frequency bands for the GTR 8000 Expandable Site Subsystem specifications
Operating altitude	Up to 5,000 m (16,400 ft) above mean sea level
Frequency Stability	GPS locked or Aging: 30 ppb/yr 100 ppb/5yr Temperature: 40 ppb

Specifications for the Expansion Hub

Table 42: Expansion Hub Technical and Environmental Specifications

XHubs	Specifications
Temperature	
Operating temperature:	-30 to 60 °C (-22 to 140 °F)
Storage temperature:	-40 to 85 °C (-40 to 185 °F)
Relative Humidity:	90% relative humidity at 50 °C (122 °F) non-condensing
Input Supply Voltage:	See the individual frequency bands for the GTR 8000 Expandable Site Subsystem specifications
Power Consumption:	See the individual frequency bands for the GTR 8000 Expandable Site Subsystem specifications
Operating Altitude:	Up to 5,000 m (16,400 ft) above mean sea level

GPS Unit Cable Length Specifications

The GPS units used with the GPB 8000 Reference Distribution Modules in the high availability configuration includes the antenna and a receiver/modem. The actual receiver is integrated with the antenna and the connection between the GPS unit and the RDM is a 6-pair twisted pair cable.

See [GPS Unit Cable Length Delay Offset Calibration on page 287](#) for determining the delay offset to be programmed in the GPS unit.

Receive Expansion Cable Length Specifications

The receive expansion cables connect the Expansion Cabinets and are **not** provided. Cable length is not critical; however, maintain the lengths within $\pm 50\%$ of the values listed in the table to achieve a good balance between all receivers. A nominal loss of 1 dB is recommended.

Table 43: GTR 8000 Receive Expansion Cable Length Specifications

Cable Type	Length (ft)	Length (m)
EnviroFlex™ EF142	6.6	2
1/4" Superflex or equivalent	19	5.8
3/8" Superflex or equivalent	28	8.5
1/2" Superflex or equivalent	31	9.5

GCP 8000 Site Controller Port Default Speed/Duplex Settings

Table 44: GCP 8000 Site Controller Port Default Speed/Duplex Settings

Switch Port	Speed/Duplex
Net/Aux	Auto-Negotiate
Site Controller Expansion 1	100BaseT/Full Duplex
Site Controller Expansion 2	100BaseT/Full Duplex

Table continued...

Switch Port	Speed/Duplex
Site Controller Expansion 3	100BaseT/Full Duplex
Site Controller Expansion 4	100BaseT/Full Duplex
Site Controller Expansion 5	100BaseT/Full Duplex
Service Port	Auto-Negotiate
Gateway Port	100BaseT/Full Duplex
SC to Base Radio 1	100BaseT/Full Duplex
SC to Base Radio 2	100BaseT/Full Duplex
SC to Base Radio 3	100BaseT/Full Duplex
SC to Base Radio 4	100BaseT/Full Duplex
SC to Base Radio 5	100BaseT/Full Duplex
SC to Base Radio 6	100BaseT/Full Duplex
Alarm	Auto-Negotiate

XHub Port Default Speed/Duplex Settings

Table 45: XHub Port Default Speed/Duplex

Switch Port	Speed/Duplex
Base Radio 1	100BaseT/Full Duplex
Base Radio 2	100BaseT/Full Duplex
Base Radio 3	100BaseT/Full Duplex
Base Radio 4	100BaseT/Full Duplex
Base Radio 5	100BaseT/Full Duplex
Base Radio 6	100BaseT/Full Duplex
Alarm	Auto-Negotiate
Site Controller Expansion	100BaseT/Full Duplex
Net Aux	Auto-Negotiate

GPB 8000 Reference Distribution Module Port Default Speed/Duplex Settings

Table 46: GPB 8000 Reference Distribution Module Port Default Speed/Duplex Settings

RDM Port	Speed/Duplex
Net/Aux	Auto-Negotiate
RDM Expansion 1	100BaseT/Full Duplex
RDM Expansion 2	100BaseT/Full Duplex
RDM Expansion 3	100BaseT/Full Duplex

Table continued...

RDM Port	Speed/Duplex
RDM Expansion 4	100BaseT/Full Duplex
RDM Expansion 5	100BaseT/Full Duplex
Service Port	Auto-Negotiate
Router	100BaseT/Full Duplex
Base Radio 1	100BaseT/Full Duplex
Base Radio 2	100BaseT/Full Duplex
Base Radio 3	100BaseT/Full Duplex
Base Radio 4	100BaseT/Full Duplex
Base Radio 5	100BaseT/Full Duplex
Base Radio 6	100BaseT/Full Duplex
Alarm	Auto-Negotiate

This page intentionally left blank.

Chapter 2

GTR 8000 Expandable Site Subsystem Theory of Operations

This chapter explains how the GTR 8000 Expandable Site Subsystem works in the context of your system.

For an understanding of the way the GTR 8000 Expandable Site Subsystem components contribute to a system, review the modules that provide the GTR 8000 Expandable Site Subsystem functionality, the modules that provide RF distribution functionality (RFDS), and the modules that connect GTR 8000 Expandable Site Subsystems to the rest of the site (backplanes and junction panels).

Functions of the GTR 8000 Expandable Site Subsystem Modules

The following lists the GTR 8000 Expandable Site Subsystem modules:

- GTR 8000 Base Radio Transceiver (XCVR) module (with or without a transceiver option card)
- Power amplifier module
- Fan module
- Power supply module
- RFDS (transmit and receive) modules
- GCP 8000 Site Controller Module (ASTRO[®] repeater, ASTRO[®] 25 Express, or HPD site)
- Expansion Hub Module
- GPB 8000 Reference Distribution Module
- GGM 8000 Gateway

Function of the Transceiver Module

The transceiver module provides the control, exciter, receiver, and optional transceiver option card for the base radio.

Figure 18: Transceiver Module (Front View)



GTR8000_XCVR_wsac

The transceiver generates the station reference, which typically must be locked on to one of many possible external sources. The external source can be either the site controller TDM clocks or the external reference operating at 5 MHz or 10 MHz.

The transceiver SPI bus allows communication with its receiver and exciter circuitry, as well as the power supply module and power amplifier module.

Two or three circuit boards in the transceiver are:

Transceiver Control Board

Performs the control management, digital signal processing, and transmit and receive data formatting for the base radio.

Transceiver RF Board

Contains DC power conversion/regulation and performs receiver and exciter functions.

Transceiver Option Card

An optional board that attaches to the control board. Provides an internal 10 MHz frequency reference. For conventional operation, it also provides the analog interfaces and WildCard I/Os. The transceiver option card requires an internal frequency reference oscillator alignment at different intervals mandated by its category and frequency band. See Base Radio Service Help > Service Screens > Alignment Screens in the *CSS Online Help* for the alignment procedures and mandated intervals.

The transceiver option card is available in two categories:

- **OCCO (Oven Controlled Crystal Oscillator)** – operates at 0.1 ppm and is inclusive to temperature and aging. The OCCO Transceiver Option Card is available in 700/800 MHz, UHF R1/R2, and VHF frequency bands.
- **TCXO (Temperature Compensated Crystal Oscillator)** – operates at 1.5 ppm, of which 0.5 ppm is allocated to temperature, and 1.0 ppm is allocated to aging. Reference precision with the TCXO is traded for lower power consumption. The TCXO mandates shorter maintenance intervals. The TCXO transceiver option card is available in UHF R1/R2 frequency bands. The TXCO is only available for non-simulcast conventional systems.


Transceiver Control Board

The main operating software for the base radio is loaded in the XCVRs control section. As the main manager for the base radio, the XCVR control board provides operational control over the other station modules. It handles three types of information flow, in the following ways:

- Serves as a gateway between the network and RF functionality, by distributing the RF payload to and from the network.
- Supports operational and diagnostic functions with digital control data (for example: site information, channel assignments, and identification numbers for call processing).
- Ensures the flow of other network management configuration information.

Figure 19: Transceiver Control Board Information Flow on page 98 shows the information flow through the transceiver control and RF sections for trunked and conventional operation.

Figure 19: Transceiver Control Board Information Flow



GTR8000_RF_Ethernet_Flow

Transceiver RF Board

In addition to DC power conversion/regulation, the XCVR RF board provides circuitry for the following exciter and receiver functions.

Exciter

The exciter on the XCVR RF board provides the transmitter functions for the base radio. The exciter circuitry generates a low-level, modulated RF signal that passes to the power amplifier. It supports various modulation types as well as bandwidths up to 25 kHz, through software programming.

The exciter also provides a controlled output power level to the power amplifier.

Receiver

The receiver provides either single receiver input or dual (HPD or TDMA) receiver inputs for dual diversity. The receiver also provides enhanced diagnostic capabilities using an on board noise source generator. It includes a wide tuning range (electronic varactor-tuned) preselector. The preselector is electronically tuned to the desired receive frequency anywhere between 792–825 MHz, 896–902 MHz, UHF R1 380–435 MHz, UHF R2 435–524 MHz, or VHF 136–174 MHz.

Transceiver External Interfaces

The transceiver external interfaces include seven external ports, a switch, and LEDs. If a transceiver option card is part of the transceiver, there are four additional external ports. See [Front Transceiver Ports on page 167](#) for the port connections. See [LEDs on page 429](#) for information on the LEDs.

Transceiver Switch

The multifunction RESET switch on the front of the transceiver module is accessible through the drop-down door to the left of the fans. The RESET switch has two functions:

Figure 20: Transceiver RESET Switch (viewable through the drop-down door)





Table 47: Transceiver Front RESET Switch Functions

User Action	Result
Press switch for less than 1 second	Toggles between Tx Inhibit and Tx Enable (LED 3 blinks amber)
Press switch for more than 3 seconds, then release	Transceiver Control Module Reset

Transceiver Option Card Intercom Button

The intercom button on the front of the transceiver option card is accessible behind the fan module. Pressing the intercom button toggles the intercom function between the ON and OFF states.

Figure 21: Transceiver Option Card Intercom Button (behind the fan module)




Transceiver Ports (Rear)

The transceiver interconnects to the backplane using a 120-pin HVDML digital connector and 8-pack RF connector, as shown in the figure. These connections handle multiple signals including power supply communications, power amplifier communications, fan interface, and peripheral interface. The digital connection receives alarm data and the site controller or RDM Time Division Multiplexing (TDM) signals, which are used to pass reference and control data to the base radio.

The site controllers, RDMs, XHubs, and transceivers connect directly through a common backplane. The backplane connects the transceiver RF inputs with the associated receive multicouplers (Cabinet RMCs/LNAs).

Figure 22: Transceiver Module (Backplane Connections)




Function of the Power Amplifier Module

The Power Amplifier (PA) is a forced convection-cooled RF power amplifier. It accepts a low-level modulated RF signal from the transceiver module, and amplifies it for transmission through the site transmit antenna. To complete the Cartesian correction loop (linearization method), the PA provides a low-level RF feedback signal to the transceiver module to achieve the required transmitter linearity.

Transmit power output is set using Configuration/Service Software (CSS). See [Configuring Tx Power Values and Battery Type on page 277](#) in the Configuration chapter.

The power amplifier also performs functions related to the fan module, including reporting of the fan module status and supplying power to the fan power bus.

Figure 23: Power Amplifier Module


The power amplifier is comprised of six internal modules:

- Core Board
- Converter Board
- Driver Amplifier Board
- Final Amplifier Board
- Distribution Board
- Output Circuitry

Power Amplifier Input/Output Connections

There are three electrical connection assemblies on the power amplifier:

- RF output (front QN quick-N connector) on the front of the power amplifier module, which is cabled to the RFDS combiner transmit connector.
- DC power supply/control signal (backplane connection)
- RF input/feedback (backplane connection).

Figure 24: Power Amplifier (Backplane Connections)

Function of the Fan Module

The fan module provides intermittent forced air cooling for the power amplifier, transceiver, site controller, or RDM modules. The fan module houses two 119 mm axial fans which deliver a total of approximately 160 cubic feet per minute of airflow. Nominal fan speed is 4100 revolutions per minute. A thermostat behind the fan module controls each fan. If the fan speed for either fan falls below 30% of the rated speed, a built-in speed sensor on each fan turns on the red Fan Alarm LED. In addition, the power amplifiers always turn on the fan during any transmission.


If the fan module is used for the Power Efficiency Package, the fan holdover time (length of time the base radio fan stays ON after transmission) can be configured in the CSS.

The fan module connects to the power amplifiers, transceivers, site controllers, or RDMs through a 4-pin port.



NOTICE: The power supply module has its own fan which provides independent airflow.

Figure 25: Fan Module



Function of the Power Supply

The power supply operates from either an AC or DC input and provides the DC operating voltage for the equipment in the cabinet/rack. However the power supply prioritizes an AC source (if present) over a DC source.

Figure 26: Power Supply

G_series_power_supply_A



NOTICE: If the power supply module is used for the Power Efficiency Package, the power supply must be used in DC only mode.

When operating from an AC source (90 to 264 VAC, 47-63 Hz), the supply generates two DC output voltages of 29 V with respect to output ground. The power supply automatically adjusts to AC input ranges and supplies a steady output.

In AC mode, the power supply provides a separate battery charger which can be used to maintain the charge on a 48 VDC nominal system, positive or negative ground, if installed. The supply generates two DC output voltages of 29 V with respect to output ground, when operating from a DC source (43.2 VDC to 60 VDC maximum, positive or negative ground). This voltage limit includes consideration of the battery charging "float voltage" associated with the intended supply system, regardless of the marked power rating of the equipment. Whether in AC, Battery Revert, or DC Only mode, at a voltage of 42 V or lower, the power supply shuts down in order to not damage any connected battery bank. Once this condition occurs, the power supply starts only after the applied voltage exceeds 45 V.

The battery charger is not usable when operating from a DC input power source. This DC source must be located in the same building as the base radio / repeater, and it must meet the requirements of a SELV circuit.

The power supply contains several switching-type power supply circuits as follows:

- Power factor correction circuitry
- Battery charging circuitry
- Diagnostics and monitoring circuitry

The battery charger outputs of the power supply are bussed together so that up to six power supplies can provide charging services to a single battery bank.

The power supply controls its own continuously running fan, changing its speed to fast, or slow as needed.




NOTICE: If the power supply module is used for the Power Efficiency Package, the power supply fan does not run below a 40 °C air inlet temperature in DC mode with the transmitter in a de-keyed state.

AC/DC Power Distribution

As with the power supply, the power distribution prioritizes an AC source (if present) over a DC source. The main DC output from each power supply feeds a power amplifier/transceiver (PA/transceiver) combination. The Auxiliary outputs of up to three Power Supplies are bussed together to provide an Aux DC bus, used as a redundant power source for site critical components (including site controllers). This auxiliary power bus ensures that the site controllers can continue to operate if a power supply fails or is removed and replaced.

Figure 27: AC and DC Power Distribution in the GTR 8000 Expandable Site Subsystem



For additional information about power distribution in the GTR 8000 Expandable Site Subsystem, see the following sections:

- [AC/DC Power Distribution Module on page 112](#)
- [Backplanes and Card Cages on page 115](#)

Power Supply Battery Charger

The power supply includes an integrated battery charger. The battery charger is controlled entirely through software on the associated base radio. Software contains the information on supported battery types and obtains user-specific information pertaining to the particular site. The base radio software receives battery bus voltage and battery temperature information from the power supply and uses these variables with supported battery charging profiles to return a signal which sets the charger output voltage appropriately. The battery charge and temperature conditions may be viewed through Configuration/Service Software (CSS) or through alarms to Unified Event Manager.

The maximum charging current available from the integrated charger is 3A (48 VDC nominal system). Motorola recommends that a battery with a capacity of no larger than 60A-hr is connected to a single charger to ensure that the charger maintains an adequate state-of-charge on the backup battery, and that the backup battery is restored to full capacity within a reasonable amount of time following operation on battery backup power.

In addition to standard sealed lead-acid batteries (valve-regulated lead acid or gel cells), the GTR 8000 Expandable Site Subsystem supports charging of vented lead-acid and NiCd batteries.

In the Expandable Site Subsystem, up to six power supplies operate from a single battery backup system. The combined battery charger outputs enable the system to maintain the state of charge on a larger battery bank than a single charger could maintain (300A-hr for five combined battery charger outputs or 360A-hr for six combined battery charger outputs).

Battery Temperature Sensor Cable

The integrated charger in the power supply performs temperature compensated battery charging when a temperature sensor is connected. If the sensor is disconnected, the charger continues to operate as an uncompensated charger with the charging profile following the minimum charger voltage specified by the battery manufacturer.

Included is a 40 ft battery temperature sensor cable, which attaches to a battery pack, supplied by your organization, and to the backplane of the device. This three-wire cable carries a voltage signal to the power supply from the sensor element, which must be mounted close to the storage battery. Voltage is proportional to the battery temperature, and the diagnostic circuitry in the power supply module. This cable is extended to a total length of 190 ft using 50 ft extensions. See [Battery Temperature Sensor Mounting on page 151](#).



IMPORTANT: Continuous operation with a disconnected sensor is not recommended.

ON/OFF Switch for Power Supply and Battery Charger

This table identifies the switch states for the power supply and battery charger.

Table 48: ON/OFF Switch - States for Power Supply and Battery Charger

Switch Position	Power Supply State	Battery Charger State
ON (1)	<ul style="list-style-type: none"> Power Factor Correction (PFC) section is active (AC input only) Main DC converter runs to create the MAIN and AUX DC outputs 	Can be started if desired (AC input only)

Table continued...


Switch Position	Power Supply State	Battery Charger State
OFF (0)	<ul style="list-style-type: none"> Main DC converter is turned OFF and the MAIN and AUX DC outputs become 0.0 VDC 	Disabled (AC input only)

Power Supply Module - Backplane Connections

Table 49: GTR 8000 Power Supply Module Backplane Connections

Port/Type	Description
AC	Input only
Battery / DC Power and Control Signal	<p>48 VDC:</p> <ul style="list-style-type: none"> Provides the DC input to the power supply when operating from a DC source. Connects the charger output to the standby battery when operating from an AC input with a standby DC battery. <p>29 VDC:</p> <ul style="list-style-type: none"> Provides the Main outputs of the power supply for use by the power amplifier and transceiver. Provides the Aux DC outputs of the power supply for use by site controller, XHub, RDM, integrated site gateway, Rx multicoupler, power monitor unit (PMU), and hybrid combiner fan module. <p>Other signals handled by this connector include control interface and battery temperature interface.</p>

Figure 28: Power Supply Connections (Rear)



G_Series_PS_Rear1

Function of the GCP 8000 Site Controller

See “GCP 8000 Site Controller Functions” in the *GCP 8000 Site Controller* manual for functions of the site controller used in a GTR 8000 Expandable Site Subsystem at an HPD, ASTRO[®] 25 repeater site, or ASTRO[®] 25 Express site.

Function of the GPB 8000 Reference Distribution Module (IP Simulcast with High Availability)

Each GPB 8000 Reference Distribution Module (RDM) provides integrated Ethernet LAN switching and integrated site reference distribution to the base radios, ensuring that a single point of failure in the reference or switch does not cause the loss of any channels at the site.

Integrated Ethernet LAN Switches

Both RDMs maintain a built-in Ethernet LAN switch providing each base radio at the site with two Ethernet LAN switch connections. The base radios determine which switch to use based on the condition of the RDMs.

Network Time Protocol Sources

Network Time Protocol (NTP) provides a clock synchronization mechanism to the RDMs and other NTP clients at the site. In a high-availability configuration, the NTP clients must use the TRAK 9100 Simulcast Site Reference (SSR), at the prime site, as the primary time source; and an ntp02.zoneN device at a zone core as the secondary time source. The RDMs at the site also act as an NTP time source. The base radios use RDM A as the primary NTP time source, and use RDM B as the secondary NTP time source.

Dual GPS Unit Function

Each RDM has a connected GPS unit that provides the necessary references to either of the RDMs. A high-stability ovenized crystal oscillator within the RDMs train to the GPS units. The RDMs then generate the output time reference to the base radios. Both GPS units are active and provide protection against a single GPS unit failure/interference at the site.

The CSS indicates whether the GPS capability is configured. The RDMs indicate the alarms for GPS service to Unified Event Manager (UEM) and MOSCAD Network Fault Management (NFM).

Time Synchronization and Frequency Reference Function

The RDMs provide a 1PPS and 10 MHz reference signaling to the base radios. The time reference synchronizes the transmissions from the base radios, and the high-stability frequency reference provides a reference for both the transmit and receive frequency synthesizers in the base radios. The time and frequency reference is supplied from a high-stability ovenized crystal oscillator within the RDMs to the base radios through the backplanes of the GTR 8000 Expandable Site Subsystem.

Function of the GPB 8000 Reference Distribution Module (Trunked 3600 IntelliRepeater)

Each GPB 8000 Reference Distribution Module (RDM) provides integrated Ethernet LAN switching and integrated site reference distribution to the base radios, ensuring that a single point of failure in the reference or switch does not cause the loss of any channels at the site.

Integrated Ethernet LAN Switches

Both RDMs maintain a built-in Ethernet LAN switch providing each base radio at the site with two Ethernet LAN switch connections. The base radios determine which switch to use based on the condition of the RDMs.

Network Time Protocol (NTP) Sources

The RDMs at the site act as the Network Time Protocol (NTP) time source for time-stamping FM events. The base radios use RDM A as the primary NTP time source, and use RDM B as the

secondary NTP time source. The IP addresses of the RDMs are used as the primary and secondary NTP server, and are configured into the base radios.

Time Synchronization and Frequency Reference Function

The RDMs provide a 1PPS and 10 MHz reference signaling to the base radios. The time reference synchronizes the transmissions from the base radios, and the high stability frequency reference provides a reference for both the transmit and receive frequency synthesizers in the base radios. The time and frequency reference is supplied from a high-stability ovenized crystal oscillator within the RDMs to the base radios through the backplanes of the GTR 8000 Expandable Site Subsystem.

Function of the Expansion Hubs

The XHub has three modes of operation:

Normal Mode

The XHub extends the switching and interface capabilities of the GCP 8000 Site Controllers or GPB 8000 Reference Distribution Modules (RDMs) in an expansion cabinet/rack. In normal mode, the site controller or RDM configures the Ethernet switch.

Impaired Normal Mode

Occurs when one of the links between the site controller or RDM and the XHub is lost. The other XHub remains active to pass the traffic.

Standalone Mode

Requires External 5 MHz and 1PPS, either as separate signals or as one combined 5 MHz/1PPS signal. 1PPS generates the 5 MHz frequency reference for the base radios even if it is not used by the base radio. For example: Analog Simulcast.

The XHubs at a repeater site are redundant and are required to support system expansion in configurations with redundant site controllers. Redundant XHubs within each expansion cabinet/rack share many common external interfaces. A hardware mechanism ensures that only one XHub drives these interfaces at a given time.

The XHubs at a simulcast subsystem are both active and are required to support system expansion with or without RDMs. Both XHubs within each expansion cabinet/rack drive the common external interfaces.

The XHub supports these features:


- XHub Control circuitry:
 - Six circuit links to base radios (backplane)
 - One circuit link to the front panel of the site controller or RDM
 - Power Supply monitoring and control through the remote SPI bus (backplane)
 - Fan detection, control, and alarm
 - Front-panel LEDs
- A 10/100/1000 Base-T Ethernet switch supporting the following LAN interfaces:
 - Six 10/100Base-T Packet base radio interfaces (backplane)
 - One 10/100Base-T Packet site controller or RDM interface (front panel)
 - One 10/100/1000 Base-T interface (front panel)
 - One 10/100Base-T interface for future use (backplane)
- Integrated Alarm Circuitry supports the following alarm interfaces:
 - Fifteen Single-ended, opto-isolated, internal cabinet/rack alarm inputs
 - Nine Single-ended, opto-isolated, external customer alarm inputs

- Three Opto-isolated, external customer alarm inputs with isolated grounds
- One Opto-isolated, internal cabinet alarm input with isolated ground
- Four Analog inputs
- Two Relay outputs

Junction Panels

The junction panels for the GTR 8000 Expandable Site Subsystem provide locations for all the connections to external devices. Locations for receive (Rx) and transmit (Tx) connectors are integrated in the junction panel in the lower center position as shown in [Figure 29: Junction Panel with Primary Subpanel #1 on page 109](#).

Figure 29: Junction Panel with Primary Subpanel #1




All other connector locations are provided through additional subpanels. These subpanels include:




NOTICE: The following panels may not be included in your configuration. For details, see the site manual for your site.

- Primary Subpanel #1, shown at the top right in [Figure 29: Junction Panel with Primary Subpanel #1 on page 109](#). Included when site controllers or RDMs are installed in the cabinet/rack. Connections are Internal Alarm, Gateway, Network AUX, Remote GPS A, Remote GPS B, Battery Temp, External Frequency Reference, and 1PPS.
- Network Expansion Subpanel. Included when site controllers or RDMs are installed in the cabinet/rack. Connections are two LAN links to each of five Expansion cabinets/racks and ten RJ-45 connections.

Figure 30: Network Expansion Subpanel


GTR8000_IP_XS_Network_Expansion_Subpanel

- Primary Subpanel #2. Included when the cabinet has XHubs that are used in a trunked simulcast standard configuration, trunked 3600 simulcast subsystem, or conventional system. Connections are Internal Alarm, LAN, External Frequency Reference, 1 PPS, and Battery Temp.

Figure 31: Primary Subpanel #2

GTR8000_primary_subpanel_#2

- Rx Expansion Subpanel. This subpanel is provided only if the GTR 8000 Expandable Site Subsystem includes the CA00862AA (Site RMC) option. Connections are three RX branches to three Expansion cabinets, and nine BNC connectors. See [Site Receive Multicouplers/Low Noise Amplifiers \(Site RMCs/LNAs\) on page 124](#).


Figure 32: Rx Expansion Subpanel

GTR8000_RX_expansion_subpanel

- Expansion Subpanel #1. This subpanel is provided only if the GTR 8000 Expandable Site Subsystem includes the CA01536AA option when XHubs are installed in Expansion cabinets/racks for a repeater site, trunked IP simulcast with high availability configuration, trunked 3600


IntelliRepeater, or conventional overlay. Connections are Internal Alarm, LAN Input, Network AUX, and Battery Temp.

Figure 33: Expansion Subpanel #1




- Circuit Audio Subpanel. Included to allow the connection of V.24, analog wireline, or optional WildCard I/O when the cabinet/rack has conventional base radios or integrated CCGWs, or for a trunked 3600 system for connection of circuit audio, ASYNC RS-232 and optional I/O. Connections are thirteen RJ-45 connectors – six V.24, six wirelines, and one ASYNC.

Figure 34: Circuit Audio Subpanel



- Six Receiver Input Subpanel. The six receiver input subpanel is used on a VHF and UHF R1 cabinet/rack. VHF and UHF R1 use a Pass Through RMC module. Connections are six BNC female connectors, one for each receiver input.


Figure 35: Six Receiver Input Subpanel



- Six Transmit Output Subpanel. The six transmit output subpanel is used on a VHF and UHF R1 cabinet/rack. Also used when a cavity combiner is not included in the cabinet/rack for an 800 MHz,


900 MHz, and UHF R2 cabinet/rack. Connects from a PA output or to a Tx combiner. Connections are six N-type connectors, one for each transmit output.

Figure 36: Six Transmit Output Subpanel



- **3600 Simulcast Subpanel.** The 3600 simulcast subpanel is used for 3600 simulcast systems and has six RJ-45 connections for analog voice to the DSM and six DB-25 connections to the remote site controller.

Figure 37: 3600 Simulcast Subpanel



Cables provided by Motorola include the specific connectors required by the junction panel on one end and the subsystem equipment on the other end. For the types of connections at the junction panel, see [Junction Panel Connections on page 181](#).

AC/DC Power Distribution Module

The power distribution module located with the junction panel provides connections for customer-provided AC and DC inputs. One or two DC inputs can be connected to the DC section of the power distribution module. For each power supply, there must be a single, separate AC source with the proper power rating connected to the appropriate terminals in the AC section, where it is then fed to the corresponding AC power supply input.

The number of **outputs** from the power distribution module depends on the configuration purchased:

- **For HPD GTR 8000 Expandable Site Subsystems:** Up to five AC outputs from the AC section of the power distribution module are connected to the power supply through the power supply backplane.
- **For Trunked IV&D and Conventional GTR 8000 Expandable Site Subsystems:** Up to six AC outputs from the AC section of the power distribution module are connected to the power supply through the power supply backplane.

For additional information about power distribution in GTR 8000 Expandable Site Subsystem, see the following sections:

- [AC/DC Power Distribution on page 104](#)
- [Backplanes and Card Cages on page 115](#)

Figure 38: AC/DC Power Distribution Module in GTR 8000 Expandable Site Subsystem (Cabinet Version - Side View)




Figure 39: AC/DC Power Distribution Module in GTR 8000 Expandable Site Subsystem (Cabinet Version - Top View)





Figure 40: AC/DC Power Distribution Module (Access Panel Removed)



In the AC distribution block of the power distribution module:

- L indicates Line or Hot AC power feed.
- N indicates Neutral AC power feed.
- Input cable ground wires should be terminated to the ground bus bar.

Figure 41: Power Distribution Module–AC Distribution Block Diagram



GTR8000_JP_PowerBox_AC_DistrBlock

Battery Pack Splitting


The GTR 8000 Expandable Site Subsystem is designed to receive DC power from a single DC source. The power distribution module at the junction panel is shipped with the DC busses interconnected to ensure that the single source is available for all power supplies contained within the subsystem. Two sets of DC input terminals are provided to reduce the current supplied through any one set of DC input cables to a value within the rating of the DC cables maximum size (2 AWG).

The jumpers can be removed if you are providing two DC inputs from separate sources.



NOTICE: Each DC input termination is rated for a maximum of 108A.

If only one DC power source is connected, the jumpers must be in place to provide DC power to the entire subsystem. The power distribution module has six AC output cables, not the three as shown in this figure).

Figure 42: AC/DC Power Distribution Module with Jumper Bars in Place

GTR8000_JP_PowerBox_Jumper_ON1

Removing the DC Bus Bars in a Power Distribution Module

If operation with a split DC bus is desired, the DC jumpers can be easily removed from the bus bars by performing the following procedure:



CAUTION: Potentially hazardous voltages are present in the power distribution panel. Input power sources should be de-energized before removing access covers. If input power cannot be de-energized at the source, this procedure should only be performed by properly trained service personnel using appropriate safety precautions for working on energized equipment.



NOTICE: Your organization should consider the impacts on system availability when operating with a split DC bus.

Prerequisites:

This procedure assumes the following service access clearances:

- At least 2 ft access at the rear of the cabinet or rack, or
- At least 2 ft access on one side of the cabinet or rack, and at least 6 inches at the rear of the cabinet or rack

Procedure:

- 1 Locate the access cover on the junction panel power distribution module (accessible from the rear of the cabinet or rack, immediately below the AC power output cables).
- 2 Remove the access cover by removing the two retaining screws.
- 3 Remove the two screws that secure each jumper to the bus bars.
- 4 Carefully remove each jumper from the assembly.
- 5 Retain the jumpers and screws in a secure location in case jumper reinstallation is needed at a later date.
- 6 Reinstall the cover plate removed in step 1.

Backplanes and Card Cages

Card cages for the GTR 8000 Expandable Site Subsystem are created with a welded and riveted design. Each card cage has a backplane. The GTR 8000 Expandable Site Subsystem backplane is pre-cabled when the system is delivered. For connections, see the following:

- [GTR 8000 Expandable Site Subsystem Backplane Connections for HPD on page 155.](#)
- [GTR 8000 Expandable Site Subsystem Backplane Connections for an ASTRO 25 Repeater Site on page 157.](#)
- [GTR 8000 Expandable Site Subsystem Backplane Connections for IP Simulcast Remote Sites on page 159.](#)
- [GTR 8000 Expandable Site Subsystem Backplane Connections for ASTRO 25 Express System on page 161](#)
- [GTR 8000 Expandable Site Subsystem Backplane Connections for a Trunked 3600 IntelliRepeater Site on page 163](#)
- [GTR 8000 Expandable Site Subsystem Backplane Connections for Trunked 3600 Simulcast Remote Sites on page 165](#)


RFDS Modules

The Radio Frequency Distribution System (RFDS) equipment included in your subsystem depends on what options were purchased from Motorola. The following lists all RFDS equipment available for the GTR 8000 Expandable Site Subsystem.

RFDS - Duplexer (900 MHz)

The 900 MHz duplexer cleans up transmit signals (Tx) by removing any remaining noise in the receive (Rx) sub-band between the hybrid combiner and the (Tx/Rx) antenna.

Figure 43: Duplexer (900 MHz) (Standalone Shown)



The duplexer also provides a first level of band pass filtering for inbound RF signals (Rx). It rejects unwanted signals including the transmitter signals from over loading the receiver multi-coupler and receivers.

The duplexer is mounted on a tray which has an additional mounting location for dual duplexer applications. Dual duplexer applications can include one or two transmit and/or receive paths. Two transmit paths allow for greater outbound coverage by placing two or three hybrid-combined carriers on each path instead of all carriers on one path. Two receive paths allow for improved receiver performance via receiver diversity.

Table 50: 900 MHz Duplexer Module Descriptions

Duplexer Type	Description
Duplexer Tray	A single duplexer mounted on a tray. It is used for both Rx and Tx filtering in concert with hybrid combining and single branch receive.
Dual Duplexer	Two duplexers mounted on a tray. In some configurations, each duplexer can be used for separate Rx and Tx filtering. Other configurations can be a combination of two branch receive and/or two hybrid-combined transmit paths.
Standalone Duplexer	A single duplexer that can be used for site alterations such as the addition of a second receive branch, splitting of Rx and Tx paths, or adding a second transmit path.

RFDS - Hybrid Combiner (900 MHz)

The hybrid combiner prepares output signals from all the RF carriers in the GTR 8000 Expandable Site Subsystem for transmission on a single antenna. The hybrid combiner can be set up in one of seven combining configurations for two carriers through six carriers and/or one or two antennas. Three unique combining modules are arranged in such a manner that provides optimal performance.

Table 51: Hybrid Combiner Module Descriptions

Module	Description
Hybrid Module, 1/2 – 1/2	This symmetric module equally passes two RF inputs. It is used in all combiner configurations from 2-way through 6-way combining.
Hybrid Module, 2/3 – 1/3	This asymmetric module passes two RF inputs with one input having two times the insertion loss of the other input. It is used in 3-way, 5-way, and 6-way combining.
Hybrid Module, 3/5 – 2/5	This asymmetric module also passes two RF inputs with one input having 50% more insertion loss than the other input. It is used only in 5-way combining.
Blank Panel	Blank panels are installed to properly cool the modules in 2-way, 3-way, 4-way, and 5-way combining.

The hybrid combiner handles any permutation of valid 900 MHz transmitter frequencies. It has a continuously running fan assembly, which is driven from the auxiliary odd/even bus of each power system. Fan current draw is monitored within the assembly. If the fan current draw falls below a preset threshold, an alarm signal is set and displays an alarm LED. Presence detect is also included with the hybrid combiner fan assembly.

A blind-mate connector is installed within the hybrid combiner chassis. It is used to provide power and signaling to the fan assembly. A female RJ-45 connector is also installed in the hybrid combiner chassis and provides a fan alarm to the MOSCAD NFM.

Figure 44: Hybrid Combiner Fan Module Connections




Figure 45: Hybrid Combiner Modules



Figure 46: Single 6-Way Hybrid Combiner




Figure 47: Single 5-Way Hybrid Combiner




Figure 48: Single 4-Way Hybrid Combiner




Figure 49: Single 3-Way Hybrid Combiner




Figure 50: Single 2-Way Hybrid Combiner




Figure 51: Dual 3-Way Hybrid Combiner




Figure 52: Dual 2-Way Hybrid Combiner





Figure 53: Hybrid Combiner Fan Module

Fan Alarm LED

RFDS - Site Preselector (700/800 MHz)

The site preselector provides a first level of band pass filtering for inbound RF signals. The site preselector rejects unwanted signals including the transmitter signals from over loading the receiver multicoupler and receivers. RF input and output connectors on the front of the device are cabled to the junction panel and a receive multicoupler.

Figure 54: Site Preselector Filter (700/800 MHz)

GTR8000_RFDS_Preselector_Front_2

The site preselector also has a built-in 30 dB coupler attached to a BNC connector on the front of the filter. The coupler port can be used for diagnostics and test purposes. For instance, a test signal can be injected on that port without having to disconnect the site from the antenna.

A single 700/800 MHz Site Preselector covers the 792-825 MHz frequency range.

RFDS - Site Preselector (UHF, 455–512 MHz)


The site preselector provides a first level of band pass filtering for inbound RF signals. The site preselector rejects unwanted signals including the transmitter signals from over loading the receiver multicoupler and receivers. RF input and output connectors on the front of the device are cabled to the junction panel and a receive multicoupler.

The site preselector also has a built-in 30 dB coupler attached to a BNC connector on the front of the filter. The coupler port can be used for diagnostics and test purposes. For instance, a test signal can be injected on that port without having to disconnect the site from the antenna.

Site preselectors are pre-tuned to one of 18 subbands. The filters for the lower 4 subbands (below 470 MHz) have 3.5 MHz bandwidth. The remaining 14 filters (above 470 MHz) have 2 MHz bandwidth. These filters cannot be retuned in the field. No other frequency subbands are available. If you need the

filters to work on a different frequency, you must order a different filter. See [Field Replaceable Units \(FRUs\) and Parts on page 347](#) for a part number list for more information. Also see [Motorola Solution Support Center on page 344](#).

Figure 55: Site Preselector (UHF, 450–512 MHz)



RFDS - (RMCs/LNAs)

Depending on your RFDS configuration, you may have Site RMCs/LNAs or Cabinet RMCs/LNAs or both. (RMC and LNA are used interchangeably in this documentation when referring to the receive multicoupler/low noise amplifier modules.) [Table 52: Receive Multicoupler \(RMC\) Internal Components on page 123](#) describes components that are common to both Site RMCs/LNAs and Cabinet RMCs/LNAs.

Table 52: Receive Multicoupler (RMC) Internal Components

Circuit	Description
Balanced Amplifier	A balanced amplifier design has been chosen, in order to achieve redundancy, improved intercept point, and improved input matching. It splits the receive signal into two identical branches. Each branch contains a low noise amplifier, a programmable attenuator, and a driver. At the output, the two branches are combined.
Splitter	The splitter provides multiple outputs. Each output is isolated from the others to prevent unwanted interactions between the receivers. The programmable step attenuator used to adjust output level is at the input of the splitter.
Alarm Circuit	Measured current is compared to a threshold. If the threshold is exceeded an alarm signal is set. The digital circuit block controls the status and alarm LED.
Power Supply	Each amplifier branch has its own 5 V regulator for redundancy reasons. A separate 5 V regulator feeds the alarm circuitry.

The following are additional features that are common to both Site RMCs/LNAs and Cabinet RMCs/LNAs:

- Each RMC/LNA has a built-in 29 V to 7.5 V DC/DC converter.
- For HPD only, power sharing between the RMC/LNAs provides PSU redundancy.
- A green and a red LED visible from the front of the module indicate power supply and alarm states.

Site Receive Multicouplers/Low Noise Amplifiers (Site RMCs/LNAs)


Each site RMC/LNA module serves as a balanced amplifier and a four-way splitter. It includes a built-in adjustable 30 dB output attenuator, which is controlled through a DIP switch on the front of the module. You can adjust overall RFDS receive (Rx) gain to the actual site configuration by selecting your configuration on the RMC Attenuation tab of the Configuration Window in Configuration/Service Software (CSS), then setting the DIP switches to the positions shown.

An RF input connector on the front of the RMC/LNA module is cabled to the preselector for the associated Rx path. Four Rx output connectors are on the front of each Site RMC/LNA module. One Rx output goes to the cabinet RMC/LNA module in the main card cage, and the other three can serve as outputs to multiple expansion rack cabinet RMCs/LNAs in configurations with additional cabinets.

 **NOTICE:** If your GTR 8000 Expandable Site Subsystem includes the CA00862AA (Site RMC) option, it provides support for up to three colocated expansion RMCs.

Figure 56: Site RMC Tray With Two RMC/LNA Modules (Front View) on page 124 shows the two Site RMC/LNA modules (A and B) on the RMC Tray for HPD or TDMA with dual diversity. For trunked IV&D, only one Site RMC/LNA module is used. The connector ports are labeled for the module on the left.

Figure 56: Site RMC Tray With Two RMC/LNA Modules (Front View)



GTR8000_RFDS_RMC_Site_Front1

The two Site RMC/LNA modules are connected to a backplane on a Site RMC tray. The backplane includes an external connector labeled RMC that receives power from and sends alarm signals to the site controller RFDS connection on the main backplane.


Figure 57: Site RMC Tray (Rear View)



GTR8000_RFDS_RMC_Site_Rear_CableOFF1

Cabinet Receive Multicouplers/Low Noise Amplifiers (Cabinet RMCs/LNAs)


The Cabinet RMC/LNA module employs a balanced amplifier, selectable attenuators, and a balanced divider to route Rx signals to each of the base radios in the cabinet. The Cabinet RMC/LNA six-way splitter sends output to up to five base radios (in the HPD GTR 8000 Expandable Site Subsystem) and up to six base radios (in the GTR 8000 Expandable Site Subsystem for trunked IV&D).

Figure 58: Cabinet RMC/LNA Module (Front View)

GTR8000_RFDS_XS_RMC_Cabinet_Front1

RFDS - RMC Pass Through Module

The RMC Pass Through module is in all VHF or UHF R1 applications on the GTR 8000 Expandable Site Subsystem. It has six inputs, which correspond to the six receiver inputs. The RMC Pass Through module has no active stages, no splitters, and no attenuators.


Figure 59: RMC Pass Through Module

RMC_pass_through_module_VHF1

RFDS - Cavity Combiner (700/800 MHz)

A six-way integrated ceramic cavity combiner prepares the output signals from all the RF carriers in the GTR 8000 Expandable Site Subsystem for transmission on a single antenna. The cavity combiner has built-in single stage circulator at each input. Each input to the combiner has a tuning and locking mechanism for each cavity to provide on-site frequency selection / tuning and to prevent unintentional detuning. Circulator loads are on the back of the combiner on a common heat sink. [Figure 60: Cavity Combiner \(700/800 MHz\) on page 126](#) shows the combiner set-up for six channels. The RF input cable, built in circulator, and tuning knob have been identified for one of the six cavities. With the optional phasing harness (700/800 MHz only), two combiners can provide 12-way combining on to a single transmit antenna.


Figure 60: Cavity Combiner (700/800 MHz)



GTR8000_expandable_site_subsystem_combiner2

RFDS - Cavity Combiner (UHF)

A six-way integrated ceramic cavity combiner prepares the output signals from all the RF carriers in the GTR 8000 Expandable Site Subsystem for transmission on a single antenna. The cavity combiner has built-in single stage circulators at each input. Each input to the combiner has a tuning and locking mechanism for each cavity to provide on-site frequency selection / tuning and to prevent unintentional detuning. Circulator loads are on the back of the combiner on a common heat sink. Minimum transmitter frequency spacing is 150 kHz. The combiner is optional on the GTR 8000 Expandable Site Subsystem. Frequency subbands for the UHF cavity combiners are 450–465 MHz, 470–491 MHz, and 494–509 MHz. 12-way combining is not available for UHF. The RF input cable, built in circulator, and tuning knob have been identified for one of the cavities.

Figure 61: Cavity Combiner (UHF)

RFDS - Transmit Filter (700/800/900 MHz)


The transmit filter removes any remaining noise in the receive sub-band between the combiner and the transmit antenna. The output is sent to the transmit antenna port at the junction panel.

The transmit band pass filter has a built-in power monitor on the output for monitoring the antenna system voltage standing wave ratio (VSWR). The power monitor converts the forward and reverse RF signals to proportional 0-5 V analog signals. VSWR alarms are routed to the infrastructure as they occur.



NOTICE: The integrated Power Monitor Unit (PMU) connector on the front of the filter that routes analog signals received by the integrated alarm function in the site controller is not supported and is reserved for future use.

The transmit filter is either 764–776 MHz, 851–870 MHz, or 935–941 MHz.

Figure 62: Transmit Filter (700/800/900 MHz)

GTR8000_RFDS_XS_TXFilter_Front1

RFDS - Transmit Filter (UHF, 450–509 MHz)

The transmit filter removes any remaining noise in the receive sub-band between the combiner and the transmit antenna. The output is sent to the transmit antenna port at the junction panel.


The transmit band pass filter has a built-in power monitor on the output for monitoring the antenna system voltage standing wave ratio (VSWR). The power monitor converts the forward and reverse RF signals to proportional 0-5 V analog signals. VSWR alarms are routed to the infrastructure as they occur.



NOTICE: The integrated Power Monitor Unit (PMU) connector on the front of the filter that routes analog signals received by the integrated alarm function in the site controller is not supported and is reserved for future use.


The transmit filter is optional on the GTR 8000 Expandable Site Subsystem. The transmit filter is pre-tuned to one of 18 subbands. The filters for the lower 4 subbands (below 470 MHz) have 3.5 MHz bandwidth. The remaining 14 filters (above 470 MHz) have 2 MHz bandwidth. These filters cannot be retuned in the field. No other frequency subbands are available. See [Field Replaceable Units \(FRUs\) and Parts on page 347](#) for a part number list for more information. Also see [Motorola Solution Support Center on page 344](#).

Figure 63: Transmit Filter (UHF, 450–509 MHz)



RFDS - Diplexer (700/800 MHz)

The diplexer is used to combine the outputs of a 700 MHz cavity combiner in one rack with the output of an 800 MHz cavity combiner in another rack. The diplexer provides the same noise filtering function as the Tx filter. The diplexer can be located either in the cabinet with the 700 MHz radios or the cabinet with the 800 MHz radios. It is mounted on a tray with the preselector similar to the Tx filter. The cabinet without the diplexer must be ordered with a diplexer extension cable.

Figure 64: Diplexer (700/800 MHz)


Power Monitor Unit (UHF/VHF/900 MHz)



NOTICE: The Power Monitor Unit (PMU) is not supported and is reserved for future use.

The Power Monitor Unit (PMU) is used to monitor the combined transmitter forward and reflected power. Analog voltages proportional to power are provided to the site controller.

The PMU circuitry is included in all transmit filters and diplexers. For sites without a transmit filter or diplexer, a standalone PMU can be used.

Figure 65: Power Monitor Unit (PMU) (UHF/VHF/900 MHz)

This page intentionally left blank.

Chapter 3

GTR 8000 Expandable Site Subsystem Installation

This chapter details installation procedures relating to the GTR 8000 Expandable Site Subsystem.

Pre-Installation Tasks

Follow this process to perform the installation tasks. Ensure that you have the following:

- Appropriate cables
- Access to Software Download (SWDL), Configuration/Service Software (CSS), and the Unified Network Configurator (UNC)
- IP/DNS information
- Login and password information

Equipment Installation Process Overview

Process:

- 1 Prepare the site to comply with the Motorola requirements and specifications for the equipment, as listed in the Motorola *Standards and Guidelines for Communication Sites* manual. The base radio may be installed in a suitable, restricted access, indoor enclosure in any location suitable for electronic communications equipment. Other codes and guidelines that may apply to the location must also be met. See [General Safety Precautions on page 132](#).
- 2 Inspect and inventory all racks, cabinets, cables, and other equipment with a Motorola representative to ensure that the order is complete. See [General Installation Standards and Guidelines on page 137](#).
- 3 Various tools are used to install and service the equipment. If information is needed regarding where to obtain any of the equipment and tools listed, contact the Motorola Solution Support Center (SSC). See [General Installation/Troubleshooting Tools on page 143](#) for a list of general recommended tools for installing and servicing the hardware.
- 4 Install all equipment using the site drawings and other documents provided by the Field Engineer. Use the installation standards and guidelines for placing and installing equipment.
- 5 Properly ground all the racks and cabinets to protect against ground faults, electrical surges, and lightning. See [GTR 8000 Expandable Site Subsystem Installation on page 145](#).
- 6 Connect all necessary cables within a rack and between the racks for system interconnection. See [Junction Panel Connections on page 181](#).
- 7 Run a preliminary check of a site before applying power.
- 8 See [Installing Device Software Prerequisites on page 243](#) for a list of items you need access to before installing the software.
- 9 See [Installing Devices in the UNC on page 246](#) to discover the base radio and to load OS software images from the UNC.
- 10 See [Device Configuration in CSS on page 257](#) to program the configurations into the base radio using CSS.

- 11 See [Configuring Centralized Authentication on Devices in VoyenceControl on page 287](#) to program the base radio using UNC.

General Safety Precautions



WARNING: Compliance with FCC guidelines for human exposure to Electromagnetic Energy (EME) at Transmitter Antenna sites generally requires that personnel working at a site must be aware of the potential for exposure to EME, and can exercise control of exposure by appropriate means, such as adhering to warning sign instructions, using standard operating procedures (work practices), wearing personal protective equipment, or limiting the duration of exposure. For more details and specific guidelines, see “Appendix A” of the *Motorola Standards and Guidelines for Communications Sites* manual.

Observe the following general safety precautions during all phases of operation, service, and repair of the equipment described in this manual. Follow the safety precautions listed and all other warnings and cautions necessary for the safe operation of all equipment. See the appropriate section of the product service manual for additional pertinent safety information. Due to the danger of introducing additional hazards, do not install substitute parts or perform any unauthorized modifications of equipment.



NOTICE: The installation process requires preparation and knowledge of the site before installation begins. Review installation procedures and precautions in the *Motorola Standards and Guidelines for Communications Sites* manual before performing any site or component installation.

Always follow all applicable safety procedures, such as Occupational Safety and Health Administration (OSHA) requirements, National Electrical Code (NEC) requirements, local code requirements, and safe working practices. Also, all personnel must practice good judgment. General safety precautions include the following:


- Read and follow all warning notices and instructions marked on the product or included in this manual before installing, servicing, or operating the equipment. Retain these safety instructions for future reference.
- If troubleshooting the equipment while power is on, be aware of the live circuits.
- Do not operate the radio transmitters unless all RF connectors are secure and all connectors are properly terminated.
- Ground all equipment properly in accordance with the *Motorola Standards and Guidelines for Communications Sites* manual and specified installation instructions for safe operation.
- Slots and openings in the cabinet are provided for ventilation. Do not block or cover openings that protect the devices from overheating.
- Only a qualified technician familiar with similar electronic equipment should service equipment.
- Some equipment components can become hot during operation. Turn off all power to the equipment and wait until sufficiently cool before touching.
- Maintain emergency first aid kits at the site.
- Direct personnel to call in with their travel routes to help ensure their safety while traveling between remote sites.
- Institute a communications routine during certain higher risk procedures where the on-site technician continually updates management or safety personnel of the progress so that help can be dispatched if needed.
- Never store combustible materials in or near equipment racks. The combination of combustible material, heat, and electrical energy increases the risk of a fire safety hazard.
- Equipment installed at the site meeting the requirements of a "restricted access location," per UL60950-1, is defined as follows: "Access can only be gained by service persons or by a user who has been warned about the possible burn hazard on equipment metal housing. Access to the

equipment is by using a tool or lock and key, or other means of security, and is controlled by the authority responsible for the location."



WARNING: Burn hazard. The metal housing of the product may become extremely hot. Use caution when working around the equipment.

Figure 66: Warning Label on Hot Modules



warning_hot



WARNING: DC input voltage must be no higher than 60 VDC. This maximum voltage includes consideration of the battery charging "float voltage" associated with the intended supply system, regardless of the marked power rating of the equipment. Failure to follow this guideline may result in electric shock.

RF energy burn hazard: disconnect power in the cabinet to prevent injury while disconnecting and connecting antennas.



CAUTION: All Tx and Rx RF cables outer shields must be grounded per Motorola *Standards and Guidelines for Communications Sites* manual requirements.

All Tx and Rx RF cables must be connected to a surge protection device according to the Motorola *Standards and Guidelines for Communications Sites* manual. Do not connect Tx and Rx RF cables directly to an outside antenna.



IMPORTANT: All equipment must be serviced by Motorola-trained personnel.

GTR 8000 Base Radio Supplemental Safety Installation Requirements

The Supplemental Safety and Installation Requirements include the following:

- The GTR 8000 Base Radio must be installed in a suitable, in-building enclosure. A restricted access location is required when installing this equipment into the end system.
- The base radio contains a Class 1 built-in power supply component. This component is equipped with an appliance inlet for connecting to an AC input, as well as DC input terminals which meet SELV DC circuit requirements.
- When installing the equipment, all requirements of relevant standards and local electrical codes must be fulfilled.
- The maximum operating ambient temperature of this equipment is 60 °C. The maximum operating altitude is 3000 meters above sea level.
- The 28.6 VDC output from the power supply to the PA is at an energy hazard level (exceeds 240 VA). When installing into the end system, care must be taken so as not to touch the output wires.
- When the base radio is used in a DC reverting system, the DC power supply must be located in the same building as the base radio, and it must meet the requirements of a SELV circuit.

DC Mains Grounding Connections



CAUTION: This equipment is designed to permit the connection of the earthed conductor of the DC supply circuit to the earthing conductor at the equipment. If this connection is made, you must meet all following conditions:

- Connect this equipment directly to the DC supply system earthing electrode conductor or to a bonding jumper from an earthing terminal bar or bus in which the DC supply system earthing electrode conductor is connected.
- Locate this equipment in the same immediate area (such as adjacent cabinets) as any other equipment that has a connection between the earthed conductor of the same DC supply circuit and the earthing conductor (and also the point of earthing of the DC system). Do not earth the DC system elsewhere.
- Locate the DC supply source within the same premises as the equipment.
- Do not install switching or disconnecting devices in the earthed circuit conductor between the DC source and the point of connection of the earthing electrode conductor.

Disconnect Device Permanently Connected

Incorporate a readily accessible disconnect device (circuit breaker or switch) in the building installation wiring.

Multiple Power Source

This product has multiple power sources. If service requires the removal of a power source, disconnect all inputs (AC and DC powers) to remove power completely to the equipment before servicing.

Connection to Primary Power

For supply connections, use wires suitable for at least 75 °C.

Replaceable Batteries



WARNING: Risk of Explosion if you replace the battery with an incorrect type. Dispose of used batteries according to the instructions.

Maintenance Requiring Two People

Identify maintenance actions that require two people to perform the repair. Two people are required when:

- A repair has the risk of injury that would require one person to perform first aid or call for emergency support. An example is work around high-voltage sources. If an accident occurs to one person, another person may be required to remove power and call for emergency aid.
- Heavy lifting is involved. Use the National Institute of Occupational Safety and Health (NIOSH) lifting equation to determine whether one or two persons are required to lift a system component when it must be removed and replaced in its rack.

Equipment Racks

Lift equipment racks without the use of lifting equipment only when sufficient personnel are available to ensure that regulations covering health and safety are not breached. Use an appropriately powered

mechanical lifting apparatus for moving and lifting the equipment racks. In addition to these points, comply with any local regulations that govern the use of lifting equipment.



WARNING: Crush Hazard could result in death, personal injury, or equipment damage. Equipment racks can weigh up to 360 kg (800 lb). See the following instructions for proper lifting procedures.

Lifting Equipment Racks Horizontally

In some cases, equipment racks are shipped in the horizontal position. Use the appropriate lifting apparatus to lift the racks upright. Comply with all applicable health and safety regulations, and any other regulations applicable to lifting heavy equipment.



WARNING: Crush Hazard could result in death, personal injury, or equipment damage. Do not use the eyenuts mounted on the top of the rack to lift the rack upright from a horizontal position. The eyenuts are not designed to lift horizontally and could fail resulting in damage to the equipment or injury to personnel.

Lifting Equipment Racks Vertically


Some equipment racks have four M10 eyenuts mounted in the top of the rack. Use these eyenuts to lift the equipment rack vertically. Before using these eyenuts, visually check them and the rack hardware for any damage that may have occurred during shipping.



WARNING: Do not use the eyenuts if damage is apparent. Contact Motorola for replacements.

Use all four eyenuts when lifting the equipment rack. The minimum distance from each eyenut to the lifting point is 1.2 meters (47.2 in). Using a shorter length than specified could cause the eyenuts to fail. [Figure 67: Lengths and Angles for Lifting Using the Eyenuts on page 136](#) shows the minimum lengths and proper lifting angles using the eyenuts.


Figure 67: Lengths and Angles for Lifting Using the Eyenuts



If eyenuts are removed or become loose, install them properly before lifting the equipment rack. Tighten the eyenuts and bolt assembly by hand. Correct eyenut tightness and alignment are crucial to ensure that the eyenut assembly performs to its intended lifting capacity. Align the eyenuts to point towards the center lifting point of the cabinet and tightened to between 90 to 120 in-lb torque.

[Figure 68: Proper Alignment of the Eyenuts on page 137](#) shows the proper alignment of the eyenuts.

Figure 68: Proper Alignment of the Eyenuts



General Installation Standards and Guidelines

This section provides several guidelines to ensure a quality install. Review these guidelines before unpacking and installing the system. Additionally, review the installation information in the *Motorola Standards and Guidelines for Communication Sites* manual for more details, including:

- Equipment installation
- Antenna installation

Review installation information specifically for the GTR 8000 Expandable Site Subsystem. See [GTR 8000 Expandable Site Subsystem Installation on page 145](#).

General Site Preparation Overview

Perform the activities listed in this table to ensure proper site preparation. The table references specific chapters in the *Motorola Standards and Guidelines for Communication Sites* manual for more information.

Table 53: Activities for Site Preparation

Activity	Description of Activity	Chapter Reference
Review the site plan.	<ul style="list-style-type: none"> • Prevents potential on-site and off-site interference by local trunked systems. 	<ul style="list-style-type: none"> • Chapter 2 "Site Design and Development"

Table continued...

Activity	Description of Activity	Chapter Reference
	<ul style="list-style-type: none"> Minimizes cable lengths. Determines the location of tele-com equipment. 	
Determine site access and security.	Outlines of site access and security measures.	<ul style="list-style-type: none"> Chapter 2 "Site Design and Development"
Review safety considerations.	Outlines general, installation, and environmental safety guidelines and requirements and OSHA-related considerations.	<ul style="list-style-type: none"> Chapter 3 "Communications Site Building Design and Installation"
Schedule installation of telephone service.	Ensures options and functions of on-site, two-way communications for personnel safety and maintenance.	<ul style="list-style-type: none"> Chapter 3 "Communications Site Building Design and Installation"
Review grounding specifications.	Ensures that the site meets or exceeds the Quality Audit Checklist in Appendix F as well as the Power and Grounding Checklist in Appendix D.	<ul style="list-style-type: none"> Appendix D. "Grounding (Earthing) Electrode System Testing/Verification" Appendix F. "R56 Compliance Checklist"
Schedule installation of site power.	Covers grounding, power sources, and surge protection.	<ul style="list-style-type: none"> Chapter 4 "External Grounding (Earthing)" Chapter 5 "Internal Grounding (Earthing)" Chapter 6 "Power Sources" Chapter 7 "Surge Protective Devices"

General Equipment Inspection and Inventory Recommendations

Take an inventory of all equipment with a Motorola representative to ensure that the order is complete. Carefully inspect all equipment and accessories to verify that they are in good condition. Promptly report any damaged or missing items to a Motorola representative.



CAUTION: Do not tamper with factory configuration settings for these devices. These settings include software configuration, firmware release, password, and physical connections. Motorola has configured and connected these devices to meet specific performance requirements. Tampering with these devices may result in unpredictable system performance or catastrophic failure.

General Placement and Spacing Recommendations

When placing equipment at a site, perform the following:

- Place each rack on a firm, level, and stable surface, and bolt the racks together.
- Use correct mounting hardware and shims to prevent rack movement.
- Use strain relief when installing and positioning cables and cords to help ensure that no interruption of service occurs.

- Provide an appropriate amount of space around all components to allow for proper air flow, cooling, and safe access to equipment.
- Locate the site racks and other equipment with enough spacing to allow access for service.



NOTICE: Proper spacing of equipment is essential for ease of maintenance and safety of personnel. Spacing requirements have been established to meet the National Fire Protection Associations (NFPA) code, and the American Society of Heating, Refrigerating, and Air Conditioning Engineers (ASHRAE) standards. Adhere to any local regulations that apply to the installation.

- Locate the system in an area free of dust, smoke, and electrostatic discharge (ESD).
- See the Motorola *Standards and Guidelines for Communication Sites* manual for details on these space requirements.

General Cabinet Bracing Recommendations

Use all supplied bracing hardware when installing a rack or cabinet, and secure all equipment within a rack or cabinet.

If additional equipment is installed, see the system design document the field engineer provided, or consult the Motorola Field Representative.

Subsystem cabinets are self-supporting structures. In areas subject to seismic activity, additional bracing of the cabinet may be required to prevent it from tipping. However, the bracing hardware must be locally procured. No specific procedures are provided within this manual for bracing cabinets in active seismic areas. See the Motorola *Standards and Guidelines for Communication Sites* manual for details on seismic conditions.

Mounting Cabinets or Racks to a Floor

When and where to use: Perform the following steps to properly install a cabinet or open rack within a site building. Secure the cabinets and racks to the floor for optimum stability. This procedure is written so that the cabinet or rack is moved only once.

Procedure:

- 1 Carefully mark the mounting holes with a pencil, as indicated on the appropriate cabinet or rack footprint.
- 2 Drill the marked mounting holes to the appropriate depth of the mounting hardware with a hammer drill and bit.
- 3 Insert an anchor into the drilled hole. If necessary, tap the anchor into place using a hammer.
- 4 For cabinets, remove the four screws securing the bottom kick panel to the front and back of the cabinet. Remove the kick panel and set aside during installation.
- 5 Carefully move the cabinet or rack into the position indicated by the holes in the floor.



WARNING: Equipment cabinets and racks are heavy and may tip. Use extreme caution when moving. Lift from top eyelets with the appropriate apparatus, or secure the cabinet or rack from tipping if lifting from the bottom. Failure to do so could result in death or serious injury or equipment damage.

- 6 Adjust and level the cabinet or rack as necessary to position the cabinet mounting holes with the pre-drilled holes.
- 7 Secure the cabinet or rack to the site floor with the locally procured mounting hardware.



IMPORTANT: If securing the cabinet or rack to a concrete floor, use 1/2-inch grade 8 bolts with anchors.

General Bonding and Grounding Requirements

Cabinets and racks include a Rack Grounding Bar (RGB) with the capacity to terminate numerous ground wires. Attach equipment added to the cabinet or rack to the ground bar using solid or stranded 6 AWG copper wire.

The RGB uses dual-hole lugs to terminate ground wires. The minimum number of dual-hole attachments is system-dependent and specified by the customer. This bar provides electrical continuity between all bonds and ground wire with a current-carrying capacity equal to or exceeding that of a 6 AWG copper wire.

See the Motorola *Standards and Guidelines for Communication Sites* manual for more information on proper bonding and ground at a site.

General Cabling Requirements

Diagrams for cabling are typically included in the system-specific configuration documentation Motorola provides. Also see the Motorola *Standards and Guidelines for Communication Sites* manual for cabling standards.



IMPORTANT: System certification was completed using shielded cables. To prevent emission problems, use only shielded cables. Do not substitute other cable types.

- Position the equipment to avoid excessive tension on cables and connectors. Cables must be loose with absolutely no stress on the connectors. Careful cable routing and securing the cables with tie wraps (or other devices) is one way to provide this protection. Set up preventive maintenance loops .
- Dress the cables neatly using cable ties. Do not tighten the cable ties until you are sure that the required service length and bend radius requirements are met. Leave cable ties loose enough to allow adjustment.
- Verify that all cables are properly labeled to match System-specific configuration documentation Motorola provided.
- Ensure that cables do not exceed the minimum bend radius as outlined in the Motorola *Standards and Guidelines for Communication Sites* manual.



CAUTION: Use only Category 5 Shielded Twisted Pair (or higher) for cabling Ethernet connections. Motorola has engineered this system to meet specific performance requirements. Using other cabling and connectors may result in unpredictable system performance or catastrophic failure.



NOTICE: For more information on cabling guidelines, see the documentation supplied with components from each equipment manufacturer.

General Power Guidelines and Requirements

See the Motorola *Standards and Guidelines for Communication Sites* manual for information on providing electrical service, power budgeting, selecting batteries, and other topics for supplying power at the site.

Perform electrical installation work in accordance with the current edition of the NFPA 70 and local building codes. Where required, use a qualified and licensed electrician for all electrical installations.

General AC Power Guidelines and Requirements

The Motorola *Standards and Guidelines for Communication Sites* manual defines the guidelines and requirements for cabinets and racks which house equipment that requires AC power input. Some of the guidelines and requirements are as follows:

- The cabinet or rack is designed to accept 120/240 V, single-phase power with an amperage service size as required by the electronic equipment.
- Cabinets and racks powered by commercial power must be equipped with a Nationally Recognized Test Laboratory (NRTL) certified power distribution module that contains a main circuit breaker or individual circuit breakers of the correct size as required for the electronic equipment or as the customer specified.
- A decal showing an electrical schematic of the power wiring is affixed to the inside surface of the cabinet.
- All AC power equipment and electrical components must conform to National Electrical Manufacturers Association (NEMA) and National Electrical Code (NEC). The AC power equipment must also be listed by an NRTL.
- A surge arrestor, designed to protect equipment systems from a 120/240 V service and load center, is placed on the power feed ahead of all individual load center circuit breakers. This gapless arrestor must be listed by an NRTL for the purpose intended.
- Selection of a surge arrestor is based on the susceptibility of the equipment powered by the electrical service, with margin provided for locally generated disturbances. See ANSI/IEEE C62.41 (21) for more details.
- At least one 120 VAC, 15 A duplex convenience outlet equipped with Ground Fault Interrupter (GFI) protection must be provided in the electronic equipment compartment.



CAUTION: Do not use surge/transient suppressors without careful and expert power system analysis.



NOTICE: Redundant devices could be terminated on different AC main phases so that a single phase failure does not result in a power loss for both devices.

General Breaker Recommendations

To ensure that a fault which causes the breaker to open does not result in the loss of multiple transmit channels, each power supply should have its own supply breaker. The breaker recommendations for AC and DC supply breakers are as follows:

- For a 120 VAC, 60 Hz application, the AC supply breaker must be rated for a continuous current of 20 A. For a 220 VAC, 50 Hz application, the AC supply breaker must be rated for a continuous current of 10 A minimum, not to exceed 20 A.
- Individual DC breakers are not used. For information involving the sizing of cables and DC power distribution, see the *Standards and Guidelines for Communication Sites* manual.
- Site installation must include a single current interrupting device on the DC input distribution (fuse or circuit breaker) rated for the application loading, not to exceed 200 A. For each standalone device, the DC supply breaker should be rated for a continuous current of 25 A.

General Battery Installation Recommendations

The batteries and charger should be as close as possible to the rectifier system using the cables. A heavy gauge stranded cable is advised to minimize voltage drop. Examples of the resistance of some heavy gauge wire are:

Table 54: Heavy Gauge Wire Resistance Examples

Gauge	Resistance
#6 gauge	0.3951 /1000 ft
#4 gauge	0.2485 /1000 ft
#2 gauge	0.1563 /1000 ft

The maximum voltage drop can be calculated by knowing the peak current drawn by the radio system. Use the following formula:

Total Voltage drop = $[\Omega/1000 \text{ ft}] \times [\text{total loop length (ft)}] \times [I_{\text{peak}} \text{ (A)}] + [\text{connector(s) voltage drop(s)}]$

See [DC Power Connection Wire Gauge Calculations for Integrated Voice and Data on page 149](#) and [DC Power Connection Wire Gauge Calculations for HPD on page 150](#) for additional guidelines on cable sizing.

General Electrostatic Discharge Recommendations

Electronic components, such as circuit boards and memory modules, can be sensitive to Electrostatic Discharge (ESD). Use an antistatic wrist strap and a conductive foam pad when installing or upgrading the system.

If an ESD station is not available, wear an antistatic wrist strap. Wrap the strap around the wrist and attach the ground end (usually a piece of copper foil or an alligator clip) to an electrical ground. An electrical ground can be a piece of metal that literally runs into the ground (such as an unpainted metal pipe), or the metal part of a grounded electrical appliance. An appliance is grounded if it has a three-prong plug and is plugged into a three-prong grounded outlet.



NOTICE: Do not use a computer as a ground, because it is not plugged in during installation.

FCC Requirements

Radio frequency (RF) transmitters installed at sites within the US must be in compliance with the following FCC regulations:

- The station licensee is responsible for the proper operation of the station at all times and is expected to provide observations, servicing, and maintenance as often as may be necessary to ensure proper operation.
- The transmitter ERP must not exceed the maximum power specified on the current station authorization.
- The frequency of the transmitter must be checked during initial installation of the transmitter, when replacing modules, or when making adjustments that affect the carrier frequency or modulation characteristics.

This equipment has been tested and found to comply with the limits for a Class A digital device, according to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to radio communications when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy. If not installed properly and used in accordance with the instruction manuals, the equipment may cause harmful interference to radio communications. Operation of some compliant equipment in a residential area may cause harmful interference to radio communications, in which case the interference must be corrected.

Networking Tools

Use the following networking tools for installing and servicing the network:

- Fluke® OneTouch Assistant LAN tester
- NiMH rechargeable battery for Fluke
- T1/E1 or E1 test set (such as the Hewlett-Packard® HP37702A)
- Serialtest® software with the ComProbe® and SerialBERT option

General Installation/Troubleshooting Tools

If information is needed regarding where to obtain any of the equipment and tools listed, contact the Motorola Solution Support Center (SSC). See [Motorola Solution Support Center on page 344](#).

General Tools

Use the following general tools to install, optimize, and service equipment in the system:

- 150 MHz 4 Channel Digital Storage Oscilloscope
- Transmission Test Set (TIMS Set)
- Aeroflex 3900 Series Service Monitor or equivalent
- 50 Ohm Terminated Load
- Digital Multimeter (DMM)
- Terminal Emulation Software
- DB-9 Straight through serial cable
- RS-232 Cables with Connectors
- Punch Block Impact Tool
- MODAPT – RJ-45 Breakout Box
- Remote RJ-11/ RJ-45 Cable Tester (1200 ft length maximum)
- PC Cable Tester (RG-58, 59, 62, BNC, RJ-45, RJ-11, DB-9, DB-15, DB-25, Centronics 36-pin connectors)
- ESD field service kit
- Amprobe Instruments GP-1 Earth Tester
- AEMC 3730 Clamp-on Ground Resistance Tester

Rack Tools

Use the following tools to install, optimize, and service the equipment:

- Service Monitor: Aeroflex 3900 Series Service Monitor with P25 Options installed (plus High Performance Data (HPD) and Time Division Multiple Access (TDMA) options as required)
- Personal Computer meeting the following specifications:

- Operating Systems:
 - + Windows XP Home Edition
 - + Windows XP Professional
 - + Windows Vista (all editions)
 - + Windows 7 (all editions)
- Hardware Requirements:
 - Processor:
 - + 1 GHz or higher Pentium grade
 - Processor Memory:
 - + 1 GB RAM recommended for Windows XP
 - + 2 GB RAM recommended for Windows Vista and Windows 7
 - Hard Disk Space:
 - + 300 MB minimum free space (for a Typical Installation, including Help Text and Software Download) or 100 MB minimum free space (for a Compact Installation)
 - Peripherals:
 - + Microsoft Windows supported mouse or trackball
 - + Microsoft Windows supported serial port for product communication
 - + Microsoft Windows supported Ethernet port for product communication
 - + Microsoft Windows supported printer port for report printing
 - + CD-ROM for software installation
- Configuration/Service Software (CSS) DLN6455
- CSS serial programming cable
- Ethernet cable
- Antenna tester
- 50 Ohm terminated load
- Rohde & Schwarz NRT-Z14 Directional Power Sensor, 25-1000 GHz, 0.1-120 W. Recommended for all uses when a service monitor is not available.

Technical Support for Installation

Technical support is available from the site-specific documents the Field Engineer or Motorola Field Representative provided for the system, one of the Motorola Solution Support Centers (SSC), or qualified subcontractors.

- SSC can help technicians and engineers resolve system problems and ensure that warranty requirements are met. Check your contract for specific warranty information. See [Motorola Solution Support Center on page 344](#).
- The Motorola System Service Subcontractor Assessment program ensures that service people contracted by Motorola meet strict minimum requirements before they can work on any system. For more information on this program, contact the Motorola representative.

Site-Specific Information

When the Motorola Center for Customer Solution Integration (CCSi) stages a system, the Field Engineer assigned to the system creates all site-specific system documentation to document how the system was staged. Site-specific information includes the following:

- Site design drawings showing the location of racks, cabinets, cable trays, and other components
- Rack drawings showing the location of the equipment in each rack
- Cable matrix in a table format that shows each cable and its connections
- Interconnect wiring diagrams to show the cable connections between devices
- Pre-programmed parameters of each site component
- Templates used to program each device
- All firmware and software revisions of each site component
- Test data from each device that requires operational verification
- Optimization requirements and settings of each electrical path
- Acceptance Test Plan for the site components



NOTICE: Maintain this site-specific information to reflect the current site configuration and layout for the system.

GTR 8000 Expandable Site Subsystem Installation

The following is information specific to the GTR 8000 Expandable Site Subsystem.

Placement and Spacing

Expansion cabinets or racks allow equipment to be added to a site. Always consider room for expansion when setting up a site. Cabinets or racks may be installed next to each other or to other equipment. However, all cabinets and racks must have sufficient floor space to permit access for installation and service.

For the GTR 8000 Expandable Site Subsystem, all service can be performed from the front of the cabinet or rack except replacement of the power distribution module, the junction panel, eyenuts, backplanes, and related cables. The following clearance is required to ensure complete service access, including access for the power distribution module, junction panel, eyenut, backplane, and related cable replacement.

Front access:


- At least 2 ft floor access in front of the cabinet or rack.

Side and rear access:

- At least 6 inches at the rear of the cabinet or rack for ventilation.
- No clearance is required on the sides of the cabinet or rack.
- No rear service access is required for the GTR 8000 Expandable Site Subsystem. Access is required to the front and one side of cabinet to secure the GTR 8000 Expandable Site Subsystem to the floor.

Floor Mounting the Cabinet Version of the GTR 8000 Expandable Site Subsystem

Figure 69: GTR 8000 Expandable Site Subsystem (Cabinet Version) - Floor Mounting Detail



GTR8000_XS_cabinet_footprint

Floor Mounting the Open Rack Version of the GTR 8000 Expandable Site Subsystem

Figure 70: GTR 8000 Expandable Site Subsystem (Open Rack Version) - Floor Mounting Detail





Figure 71: GTR 8000 Expandable Site Subsystem (7.5 Open Rack Shown) - Side View



GTR8000_XS_Rack_footprint_side

Power Connections

This section covers topics on connecting power cables to the GTR 8000 Expandable Site Subsystem and the power distribution module, calculating the length of wire for various gauges, and mounting the battery temperature sensor.

Power Distribution Module Power Connections

In GTR 8000 Expandable Site Subsystems, the AC/DC power distribution module located with the junction panel provides connections for customer-provided AC and DC inputs. One or two DC inputs can be connected to the DC section of the power distribution module. For each base radio, there must be a single, separate AC source with the proper power rating connected to the appropriate terminals in the AC section, where it is then fed to the corresponding AC power supply input.



NOTICE: Each DC input termination is rated for a maximum of 108A.

For additional information about power distribution in GTR 8000 Expandable Site Subsystems, see the following:

- [AC/DC Power Distribution on page 104](#)
- [AC/DC Power Distribution Module on page 112](#)

DC Power Connection Wire Gauge Calculations for Integrated Voice and Data

Since the power supply disconnects itself from the DC input when it senses that DC voltage has dropped to 42 VDC, it is important to minimize the voltage drop in the DC power supply loop (the total length of the 48 VDC hot wire and the DC return wire) to no more than 1 V total. Minimizing the voltage drop ensures that the maximum energy is removed from the battery before disconnecting the power supply from the DC input line.

A base radio transmitting at 100 W draws up to 10 A* current when operating from a 54 V source (nominal 48 VDC system). As the voltage decreases (due to the standby battery discharging) the current increases proportionally (since the base radio appears to be a constant power load). At the low voltage disconnect point (42 V for a nominal 48 VDC system), the current is up to 13 A*. If a single pair of 2 AWG wire is used to connect the battery to the junction panel, the maximum length of a single conductor would be 75m (245 ft). Use of smaller gauge wire would reduce this length depending on the resistance of the wire. To determine the maximum length of wire for wire other than 2 AWG, the following relationship can be used:

* = The actual current value can be calculated from the power consumption value in the specifications tables. See [GTR 8000 Expandable Site Subsystem Specifications on page 67](#).

- Length (meter/feet) = $V/I/R$

where:

- V = voltage drop in one leg of the loop (max = 0.5 V)
- I = current drawn by the base radio during DC operation
- R = resistance of the wire being considered (in Ohms per meter/foot)

For common wire sizes for an IV&D site, the maximum distances apply.

Table 55: DC Power Connection Wire Gauge Maximum Distances for an IV&D Site


AWG	Resistance (ohm/1000 ft)	Maximum Distance (for 13 A)
2	0.1563	75m (245 ft)
3	0.1970	60m (195 ft)
4	0.2485	47m (155 ft)
5	0.3133	37m (120 ft)
6	0.3951	30m (95 ft)

In some installations, local codes may require the installation of wire heavier than 2 AWG. In these situations, a local splice box can be used to reduce the incoming wire to the 2 AWG needed for connection to the input terminal box. The splice box should be as close as possible to the junction panel.

If two pairs of 2 AWG wire are used to connect the GTR 8000 Expandable Site Subsystem to the battery bank, the maximum distance from the battery to the junction panel would be 70 ft. If longer distances are required, a splice box must be included in the DC distribution. In that event, the following diagram provides guidance regarding the maximum distance permitted for various wire gages available. These values are based on a splice box located 10 ft from the junction panel. If the splice box is more than 10 ft from the junction panel, the allowable distance between the splice box and the battery bank will be shorter.

 **NOTICE:** Each DC input termination is rated for a maximum of 108 A.

Figure 72: Wire Gauge and Distance Guide



DC Power Connection Wire Gauge Calculations for HPD

Since the power supply disconnects itself from the DC input when it senses that DC voltage has dropped to 42 VDC, it is important to minimize the voltage drop in the DC power supply loop (the total length of the 48 VDC hot wire and the DC return wire) to no more than 1 V total. Minimizing the voltage drop ensures that the maximum energy is removed from the battery before disconnecting the power supply from the DC input line.

A base radio transmitting at 50 W draws up to 7.4 A current when operating from a 54 V source (nominal 48 VDC system). As the voltage decreases (due to the standby battery discharging) the current increases proportionally (since the base radio appears to be a constant power load). At the low voltage disconnect point (42 V for a nominal 48 VDC system), the current is up to 9.5 A. Use of smaller gauge wire would reduce this length depending on the resistance of the wire. To determine the maximum length of wire for wire other than 2 AWG, the following relationship can be used:

- Length (ft) = $V/I/R$

where:

- V = voltage drop in one leg of the loop (max = 0.5 V)
- I = current drawn by the base radio during DC operation (9.5A)
- R = resistance of the wire being considered (in Ohms per ft)

For common wire sizes, the maximum distances apply.

Table 56: Power Connection Wire Gauge Maximum Distances for HPD

AWG	Resistance (ohm/1000 ft)	Maximum Distance
2	0.1563	102m (335 ft)
3	0.1970	81m (265 ft)
4	0.2485	64m (210 ft)
5	0.3133	51m (165 ft)
6	0.3951	40m (130 ft)

Battery Temperature Sensor Mounting


A 40 ft battery temperature sensor cable is shipped with your device. This three-wire cable carries a voltage signal to the power supply from a sensor element which must be mounted close to the storage battery. Voltage is proportional to the battery temperature and the diagnostic circuitry in the power supply module. The 40 ft cable can be extended to a total length of 190 ft using 50 ft extensions (Motorola part number 3084827Y04. See [Motorola Solution Support Center on page 344](#)).

Mount the sensing element of the temperature sensor so that it detects the actual battery temperature (or the ambient temperature as close as possible to the batteries being charged). The two examples of mounting are as follows:

Example 1

Use cable ties to attach the sensing cable to the positive (or negative) power cable. A minimum of two cable ties should be used (spaced 6 inches apart), with one of the cable ties not more than 2 inches from the sensing element. Mount the sensing element not more than 2 inches from the battery post where the power cable connects. See [Figure 73: Battery Temperature Sensor Example 1 on page 152](#).

Figure 73: Battery Temperature Sensor Example 1



GTR8000_Battery_Temperature_Sensor_1

Example 2

Attach the sensing cable to an existing battery tray support bracket using cable ties or nylon loop straps of the proper size. Mount the sensing element not more than 2 inches from the surface of the batteries being monitored. Use a minimum of two cable ties and/or loop straps to secure the sensing cable to the bracket. Place the cable ties/ loop straps no more than 6 inches apart with one placed no more than 2 inches from the sensing element. See [Figure 74: Battery Temperature Sensor Example 2 on page 153](#).

Figure 74: Battery Temperature Sensor Example 2

Grounding

Detailed grounding information is beyond the scope of this manual. See the *Motorola Standards and Guidelines for Communication Sites* manual for detailed information about grounding and lightning protection.




IMPORTANT: Ground the battery system, either positive or negative, at the battery. The DC input (battery charger output) of the power supply is floating with respect to earth ground. The power supply can therefore be used in either positive ground or negative ground DC systems. The appropriate terminal (+ or -) of the DC system should be connected to protective earth at the battery.

These instructions assume that all telephone lines, antenna cables, and AC or DC power cables have been properly grounded and lightning-protected.

When rack installations have a primary rack and one or more expansion racks, all these racks must be connected to the same Sub System Ground Bus Bar (SSGB) (and no other rack connected to the SSGB). Grounding ensures that surge events do not produce ground potential differences that affect signals between the racks.

Figure 75: Rack Grounding



GTR 8000 Expandable Site Subsystem Grounding

In the GTR 8000 Expandable Site Subsystem, devices connected to the backplanes (transceivers, power amplifiers, fan modules, and power supplies) are grounded by contact with the card cage/backplane. Each backplane has a double lug with two lock nuts on the rear panel where the ground wire connects to the rack grounding bar.

In addition, there are grounding lugs on Radio Frequency Distribution System (RFDS) modules that connect to the rack grounding bar.

The rack grounding bar must be connected to the master ground bus bar through the junction panel.


Backplanes and Card Cages

Card cages for the GTR 8000 Expandable Site Subsystem are created with a welded and riveted design. Each card cage has a backplane. The GTR 8000 Expandable Site Subsystem backplane is pre-cabled when the system is delivered. For connections, see the following:

- [GTR 8000 Expandable Site Subsystem Backplane Connections for HPD on page 155.](#)
- [GTR 8000 Expandable Site Subsystem Backplane Connections for an ASTRO 25 Repeater Site on page 157.](#)
- [GTR 8000 Expandable Site Subsystem Backplane Connections for IP Simulcast Remote Sites on page 159.](#)
- [GTR 8000 Expandable Site Subsystem Backplane Connections for ASTRO 25 Express System on page 161](#)
- [GTR 8000 Expandable Site Subsystem Backplane Connections for a Trunked 3600 IntelliRepeater Site on page 163](#)
- [GTR 8000 Expandable Site Subsystem Backplane Connections for Trunked 3600 Simulcast Remote Sites on page 165](#)

GTR 8000 Expandable Site Subsystem Backplane Connections for HPD

Figure 76: GTR 8000 Expandable Site Subsystem Backplane for HPD



HPD_GTR8000_XS_Main_Backplane



IMPORTANT: It is not recommended that any external devices be connected to the ports accessible on the GTR 8000 Expandable Site Subsystem backplane. Connections for external equipment are on the junction panel.

Table 57: GTR 8000 Expandable Site Subsystem Rear Backplane Connections for HPD

Type of Connection	Description
RFDS	Supplies power to and receives status information signals from the receive multicouplers/low noise amplifiers (Site RMCs/LNAs) and the Power Monitor in the Tx Filter.
Remote GPS A	Connects Site Controller A to Remote GPS Unit A through the junction panel.
Remote GPS B	Connects Site Controller B to Remote GPS Unit B through the junction panel.
DC Input #1	Connects to DC Output # 1 on the GTR 8000 Expandable Site Subsystem Power Supply backplane. Provides the Main DC outputs and communication signals from power supplies 1, 2 and 3 to PAs/ transceivers 1, 2 and 3. Also carries power for the Odd Aux bus.

Table continued...


Type of Connection	Description
DC Input #2	Connects to DC Output # 2 on the GTR 8000 Expandable Site Subsystems Power Supply backplane. Provides the Main DC outputs and communication signals from power supplies 4 and 5 to PAs/ transceivers 4 and 5. Also carries power for the Even Aux bus.
Even AUX PWR Output	Auxiliary power output from the even-numbered power supplies. Reserved for connection to other system components that require a redundant AUX PWR input.
Odd AUX PWR Output	Auxiliary power output from the odd-numbered power supplies. Reserved for connection to other system components that require a redundant AUX PWR input.
GND	Two grounding lugs
Internal Alarm	Not in use. However this port is cabled to the Internal Alarm port on the junction panel.
External Alarm	Not in use
EXT FREQ REF	Not in use
1 PPS	Not in use

Table 58: GTR 8000 Expandable Site Subsystem Backplane Internal Connections for HPD

Type of Connection	Description
Internal (digital)	Connection between Site Controller module A and base radios
Internal (digital)	Connection between Site Controller module B and base radios
Internal (RF)	Receive line A between Cabinet RMC A and up to 5 HPD base radios
Internal (RF)	Receive line B between Cabinet RMC B and up to 5 HPD base radios
Internal (RF)	Transmit line between transceivers and power amplifiers

GTR 8000 Expandable Site Subsystem Backplane Connections for an ASTRO 25 Repeater Site

Figure 77: GTR 8000 Expandable Site Subsystem Backplane for a Repeater Site



HPD_GTR8000_XS_Main_Backplane



IMPORTANT: It is not recommended that any external devices be connected to the ports accessible on the GTR 8000 Expandable Site Subsystem backplane. Connections for external equipment are on the junction panel.

Table 59: GTR 8000 Expandable Site Subsystem Rear Backplane Connections for a Repeater Site

Type of Connection	Description
RFDS	Supplies power to and receives status information signals from the receive multicouplers/low noise amplifiers (Site RMCs/LNAs), the Tx Filter, the Power Monitor Unit, and the Hybrid Combiner Fan Module.
Remote GPS A	Not in use
Remote GPS B	Not in use
DC Input #1	Connects to DC Output # 1 on the GTR 8000 Expandable Site Subsystem Power Supply backplane. Provides the Main DC outputs and communication signals from power supplies 1, 2 and 3 to PAs/ transceivers 1, 2 and 3. Also carries power for the Odd Aux bus.

Table continued...


Type of Connection	Description
DC Input #2	Connects to DC Output # 2 on the GTR 8000 Expandable Site Subsystems Power Supply backplane. Provides the Main DC outputs and communication signals from power supplies 4, 5 and 6 to PAs/ transceivers 4, 5 and 6. Also carries power for the Even Aux bus.
Even AUX PWR Output	Auxiliary power output from the even-numbered power supplies. Provides power to optional GGM 8000 Gateways colocated in the rack.
Odd AUX PWR Output	Auxiliary power output from the odd-numbered power supplies. Provides power to optional GGM 8000 Gateways colocated in the rack.
GND	Two grounding lugs.
Internal Alarm	Not in use. However this port is cabled to the Internal Alarm port on the junction panel.
External Alarm	Not in use
EXT FREQ REF	Not in use
1 PPS	Not in use

Table 60: GTR 8000 Expandable Site Subsystem Backplane Internal Connections for an ASTRO 25 Repeater Site

Type of Connection	Description
Internal (digital)	Connection between site controller module A and base radios
Internal (digital)	Connection between site controller module B and base radios
Internal (RF)	Receive line A between cabinet RMC A and up to six base radios
Internal (RF)	Transmit line between transceiver modules and power amplifiers

GTR 8000 Expandable Site Subsystem Backplane Connections for IP Simulcast Remote Sites

Figure 78: GTR 8000 Expandable Site Subsystem Backplane for an IP Simulcast Remote Site



HPD_GTR8000_XS_Main_Backplane



IMPORTANT: It is not recommended that any external devices be connected to the ports accessible on the GTR 8000 Expandable Site Subsystem backplane. Connections for external equipment are on the junction panel.

Table 61: GTR 8000 Expandable Site Subsystem Rear Backplane Connections for an IP Simulcast Remote Site

Type of Connection	Description
RFDS	Supplies power to and receives status information signals from the receive multicouplers/low noise amplifiers (Site RMCs/LNAs), the Tx Filter, the Power Monitor Unit, and the Hybrid Combiner Fan Module.
Remote GPS A	Used in a trunked IP simulcast high availability configuration. Connects RDM A to Remote GPS Unit A through the junction panel.
Remote GPS B	Used in a trunked IP simulcast high availability configuration. Connects RDM B to Remote GPS Unit B through the junction panel.
DC Input #1	Connects to DC Output # 1 on the GTR 8000 Expandable Site Subsystem Power Supply backplane. Provides the Main DC outputs and com-

Table continued...

Type of Connection	Description
	munication signals from power supplies 1, 2 and 3 to PAs/ transceivers 1, 2 and 3. Also carries power for the Odd Aux bus.
DC Input #2	Connects to DC Output # 2 on the GTR 8000 Expandable Site Subsystems Power Supply backplane. Provides the Main DC outputs and communication signals from power supplies 4, 5 and 6 to PAs/ transceivers 4, 5 and 6. Also carries power for the Even Aux bus.
Even AUX PWR Output	Auxiliary power output from the even-numbered power supplies. Provides power to optional GGM 8000 Gateways colocated in the rack.
Odd AUX PWR Output	Auxiliary power output from the odd-numbered power supplies. Provides power to optional GGM 8000 Gateways colocated in the rack.
GND	Two grounding lugs
Internal Alarm	Not in use. However this port is cabled to the Internal Alarm port on the junction panel.
External Alarm	Not in use
EXT FREQ REF	Used when a TRAK is installed at the site. The EXT FREQ REF input must have a BNC "T" connected to it. A 50 Ohm termination is on one leg of the "T" and the cable to the junction panel is on the other side of the "T".
1PPS	Used when a TRAK is installed at the site. The 1PPS input must have a BNC "T" connected to it. A 50 Ohm termination is on one leg of the "T" and the cable to the junction panel is on the other side of the "T".



NOTICE: The EXT FREQ REF and 1PPS inputs on the backplane of the GTR 8000 Expandable Site Subsystem are high impedance. Use an external termination to properly terminate the cable connected to the input. A BNC "T" and a 50 Ohm BNC termination is provided.

Table 62: GTR 8000 Expandable Site Subsystem Backplane Internal Connections for an IP Simulcast Remote Site (Standard Configuration)

Type of Connection	Description
Internal (digital)	Connection between XHub module A and base radios
Internal (digital)	Connection between XHub module B and base radios
Internal (RF)	Receive line A between Cabinet RMC A and up to six base radios
Internal (RF)	Transmit line between transceiver modules and power amplifiers

Table 63: GTR 8000 Expandable Site Subsystem Backplane Internal Connections for an IP Simulcast Remote Site (High Availability Configuration)


Type of Connection	Description
Internal (digital)	Connection between RDM A and base radios
Internal (digital)	Connection between RDM B and base radios
Internal (RF)	Receive line A between Cabinet RMC A and up to 6 base radios

Table continued...

Type of Connection	Description
Internal (RF)	Transmit line between transceiver modules and power amplifiers

GTR 8000 Expandable Site Subsystem Backplane Connections for ASTRO 25 Express System

Figure 79: GTR 8000 Expandable Site Subsystem Backplane for ASTRO 25 Express System



GTR8000_XS_Main_Backplane



IMPORTANT: It is not recommended to connect any external devices to the ports accessible on the GTR 8000 Expandable Site Subsystem backplane. Connections for external equipment are on the junction panel.

Table 64: GTR 8000 Expandable Site Subsystem Rear Backplane Connections for ASTRO 25 Express System

Type of Connection	Description
RFDS	Supplies power to and receives status information signals from the receive multicouplers/low noise amplifiers (Site RMCs/LNAs), and Hybrid Combiner Fan Module.
Remote GPS A	Not in use
Remote GPS B	Not in use

Table continued...


Type of Connection	Description
DC Input #1	Connects to DC Output # 1 on the GTR 8000 Expandable Site Subsystem Power Supply backplane. Provides the Main DC outputs and communication signals from power supplies 1, 2 and 3 to PAs/ XCVRs 1, 2 and 3; also carries power for the Odd Aux bus.
DC Input #2	Connects to DC Output # 2 on the GTR 8000 Expandable Site Subsystem Power Supply backplane. Provides the Main DC outputs and communication signals from power supplies 4, 5 and 6 to PAs/ XCVRs 4, 5 and 6; also carries power for the Even Aux bus.
Even AUX PWR Output	Auxiliary power output from the even-numbered power supplies. Reserved for connection to other system components that require a redundant AUX PWR input.
Odd AUX PWR Output	Auxiliary power output from the odd-numbered power supplies. Reserved for connection to other system components that require a redundant AUX PWR input.
GND	Two grounding lugs
Internal Alarm	Not in use, however this port is cabled to the Internal Alarm port on the junction panel.
External Alarm	Not in use
EXT FREQ REF	Not in use
1 PPS	Not in use

Table 65: GTR 8000 Expandable Site Subsystem Backplane Internal Connections for an ASTRO 25 Express System

Type of Connection	Description
Internal (digital)	Connection between Site Controller module A and base radios
Internal (digital)	Connection between Site Controller module B and base radios
Internal (RF)	Receive line A between Cabinet RMC A and up to 6 base radios
Internal (RF)	Transmit line between transceiver modules and power amplifiers

GTR 8000 Expandable Site Subsystem Backplane Connections for a Trunked 3600 IntelliRepeater Site

Figure 80: GTR 8000 Expandable Site Subsystem Backplane for a Trunked 3600 IntelliRepeater Site



HPD_GTR8000_XS_Main_Backplane



IMPORTANT: It is not recommended that any external devices be connected to the ports accessible on the GTR 8000 Expandable Site Subsystem backplane. Connections for external equipment are on the junction panel.

Table 66: GTR 8000 Expandable Site Subsystem Rear Backplane Connections for a Trunked 3600 IntelliRepeater Site

Type of Connection	Description
RFDS	Supplies power to and receives status information signals from the receive multicouplers/low noise amplifiers (Site RMCs/LNAs), the Tx Filter, the Power Monitor Unit, and the Hybrid Combiner Fan Module.
Remote GPS A	Not in use
Remote GPS B	Not in use
DC Input #1	Connects to DC Output # 1 on the GTR 8000 Expandable Site Subsystem Power Supply backplane. Provides the Main DC outputs and communication signals from power supplies 1, 2 and 3 to PAs/ transceivers 1, 2 and 3. Also carries power for the Odd Aux bus.

Table continued...


Type of Connection	Description
DC Input #2	Connects to DC Output # 2 on the GTR 8000 Expandable Site Subsystems Power Supply backplane. Provides the Main DC outputs and communication signals from power supplies 4, 5 and 6 to PAs/ transceivers 4, 5 and 6. Also carries power for the Even Aux bus.
Even AUX PWR Output	Auxiliary power output from the even-numbered power supplies. Provides power to optional GGM 8000 Gateways colocated in the rack.
Odd AUX PWR Output	Auxiliary power output from the odd-numbered power supplies. Provides power to optional GGM 8000 Gateways colocated in the rack.
GND	Two grounding lugs.
Internal Alarm	Not in use. However this port is cabled to the Internal Alarm port on the junction panel.
External Alarm	Not in use
EXT FREQ REF	Not in use
1 PPS	Not in use

Table 67: GTR 8000 Expandable Site Subsystem Backplane Internal Connections for a Trunked 3600 IntelliRepeater Site

Type of Connection	Description
Internal (digital)	Connection between RDM A and base radios
Internal (digital)	Connection between RDM B and base radios
Internal (RF)	Receive line A between Cabinet RMC A and up to six base radios
Internal (RF)	Transmit line between transceiver modules and power amplifiers

GTR 8000 Expandable Site Subsystem Backplane Connections for Trunked 3600 Simulcast Remote Sites

Figure 81: GTR 8000 Expandable Site Subsystem Backplane for a Trunked 3600 Simulcast Remote Site



HPD_GTR8000_XS_Main_Backplane

IMPORTANT: It is not recommended that any external devices be connected to the ports accessible on the GTR 8000 Expandable Site Subsystem backplane. Connections for external equipment are on the junction panel.

Table 68: GTR 8000 Expandable Site Subsystem Rear Backplane Connections for a Trunked 3600 Simulcast Remote Site

Type of Connection	Description
RFDS	Supplies power to and receives status information signals from the receive multicouplers/low noise amplifiers (Site RMCs/LNAs), the Tx Filter, the Power Monitor Unit, and the Hybrid Combiner Fan Module.
Remote GPS A	Not in use
Remote GPS B	Not in use
DC Input #1	Connects to DC Output # 1 on the GTR 8000 Expandable Site Subsystem Power Supply backplane. Provides the Main DC outputs and communication signals from power supplies 1, 2 and 3 to PAs/ transceivers 1, 2 and 3. Also carries power for the Odd Aux bus.

Table continued...

Type of Connection	Description
DC Input #2	Connects to DC Output # 2 on the GTR 8000 Expandable Site Subsystems Power Supply backplane. Provides the Main DC outputs and communication signals from power supplies 4, 5 and 6 to PAs/ transceivers 4, 5 and 6. Also carries power for the Even Aux bus.
Even AUX PWR Output	Auxiliary power output from the even-numbered power supplies.
Odd AUX PWR Output	Auxiliary power output from the odd-numbered power supplies.
GND	Two grounding lugs.
Internal Alarm	Not in use. However this port is cabled to the Internal Alarm port on the junction panel.
External Alarm	Not in use
EXT FREQ REF	Used when a simulcast site reference is installed at the site. The EXT FREQ REF input must have a BNC "T" connected to it. A 50 Ohm termination is on one leg of the "T" and the cable to the junction panel is on the other side of the "T".
1 PPS	Used when a simulcast site reference is installed at the site. The 1 PPS input must have a BNC "T" connected to it. A 50 Ohm termination is on one leg of the "T" and the cable to the junction panel is on the other side of the "T".




NOTICE: The EXT FREQ REF and 1 PPS inputs on the backplane of the GTR 8000 Expandable Site Subsystem are high impedance. Use an external termination to properly terminate the cable connected to the input. A BNC "T" and a 50 Ohm BNC termination is provided.

Table 69: GTR 8000 Expandable Site Subsystem Backplane Internal Connections for a Trunked 3600 Simulcast Remote Site

Type of Connection	Description
Internal (digital)	Connection between XHub module A and base radios
Internal (digital)	Connection between XHub module B and base radios
Internal (RF)	Receive line A between Cabinet RMC A and up to six base radios
Internal (RF)	Transmit line between transceiver modules and power amplifiers

GTR 8000 Expandable Site Subsystem Power Supply Backplane

Figure 82: GTR 8000 Expandable Site Subsystem Power Supply Backplane



HPD_GTR8000_XS_PS_backplane

Table 70: GTR 8000 Expandable Site Subsystem Power Supply Backplane Connections

Type of Connection	Description
PS + Batt/DC -	These ports connect to the positive and negative DC input cables attached to the junction panel power distribution module. From these ports, the DC power feeds through the backplane to the DC connector on the associated power supply.
AC In	These ports connect to the AC input cable attached to the junction panel power distribution module. From these ports, AC power feeds through the backplane to the AC input connector on the associated power supply.
Batt Temp Sensor, 6-pin	For battery temperature sensor cable that can connect to a probe through the junction panel. Used for temperature compensated battery charging.
DC Output #1	Connects to DC Input # 1 on the GTR 8000 Expandable Site Subsystem backplane. Provides the Main DC outputs and communication signals from power supplies 1, 2 and 3 to PAs/transceivers 1, 2 and 3. Also carries power for the Odd Aux bus.
DC Output #2	Connects to DC Input # 2 on the GTR 8000 Expandable Site Subsystem backplane. Provides the Main DC outputs and communication signals from power supplies 4, 5 and 6 to PAs/transceivers 4, 5 and 6. Also carries power for the Even Aux bus.




NOTICE: Information about **internal** power connections for the GTR 8000 Expandable Site Subsystem backplane and Power Supply backplane are provided in [AC/DC Power Distribution](#) on page 104.

Front Transceiver Ports

Two service ports are accessible through a drop-down door to the top of the fans. The remaining ports are behind the fan module.

Figure 83: Transceiver Ports – Front



 **NOTICE:** The optional Transceiver Option Card is a board that attaches to the control board. The board provides an internal 10 MHz frequency reference. For conventional base radio operation, it also provides the analog interfaces and WildCard I/Os.

Table 71: Transceiver Connections - Front

Transceiver Port / Type	Connects to This Device/Port	Description
Ethernet service port, RJ-45	Service PC, LAN port	Ethernet service port for local access using Configuration/Service Software (CSS). Also may be used for localized software downloads.  NOTICE: Supports only 10 Mb half duplex operation.
Serial service port, DB-9	Service PC, RS-232 port	Serial service port for initial configuration of the base radio IP address.
Microphone port, RJ-45	Microphone, RJ-45	Used to connect to a microphone with PTT button.  NOTICE: Use microphone kit GMM4063B.
Speaker port, RJ-9	External Speaker, RJ-9	Used to connect to an amplified (DC powered) external speaker. Audio volume level is set from the CSS.  CAUTION: To prevent damage to the base radio, use speaker kit HSN1006A and cable part no. 0185180U01.
Wireline port, RJ-45	Junction Panel, RJ-45	Connection between telephone lines or analog site equipment and the analog base radio. The wireline processes and routes all wireline audio signals between the base radio and land-line equipment (such as consoles or modems).

Table continued...

Transceiver Port / Type	Connects to This Device/Port	Description
System Connector, mini SCSI	Junction Panel, RJ-45 or Punchblock 50-pin Telco	Provides the WildCard I/Os and supplementary Analog I/Os for analog simulcast and special applications. Editing of WildCard configurations is permitted only through CSS.
Asynchronous port, RS232, RJ-45	Junction Panel, RJ-45	Connection port when the base radio is part of a trunked 3600 IntelliRepeater site.
V.24 port	Junction Panel, RJ-45	Connection port when the base radio is part of a conventional or trunking circuit-based site, mixed mode or digital only.
Reference frequency input, BNC*	Service monitor	Connection port to service monitor for frequency calibration.

* See [GTR 8000 Base Radio Time and Frequency Inputs on page 292](#).

System Connector Ports (Conventional)

The system connector, a 50-pin Mini SCSI connector, is used for the WildCard inputs, outputs, and the analog audio paths not routed to their own connector.

Table 72: 50-Pin System Connector Pin-Outs (Conventional)

Pin No.	Signal	Type	Function	Note
1	Aux In 2	Input	Main Standby - External hand-shaking	Pull To Ground To Activate
2	Aux In 4	Input	Main Standby- Status of other side	Pull To Ground To Activate
3*	Aux In 6	Input	In-Cabinet Repeat	Pull To Ground To Activate
4	Aux In 8	Input	Main Standby - Connectivity other Station	Pull To Ground To Activate
5	Aux In 9 –	Input	Phone Patch - PL Strip	Opto-Isolated In - Current flow to Activate
6	Aux In 10 –	Input	Phone Patch - Monitor	Opto-Isolated In - Current flow to Activate
7	Aux In 11 –	Input		Opto-Isolated In - Current flow to Activate
8	Aux In 12 –	Input		Opto-Isolated In - Current flow to Activate
9	Aux In 13	Input	For future use	Pull To Ground To Activate
10	Aux Out 12	Output		Low Impedance to Ground When Active
11	Aux Out 2	Output	Phone Patch - Rx Carrier	Low Impedance to Ground When Active
12	Aux Out 4	Output	Main Standby - Station Status	Low Impedance to Ground When Active

Table continued...

Pin No.	Signal	Type	Function	Note
13	Aux Out 6	Output		Low Impedance to Ground When Active
14	Aux Out Relay 7 Com	Output	RD STAT - Receiver Active	Form Relay A Closed When Active
15	Aux Out Relay 8 Com	Output	Main Standby - Antenna Relay	Form Relay A Closed When Active
16	Aux Out Relay 9 Com	Output		Form Relay A Closed When Active
17	Aux Out Relay 10 Com	Output		Form Relay A Closed When Active
18	Aux Out 11	Output		Low Impedance to Ground When Active
19	External_Reset	Input	Reset	Buffered Input Pull To Ground To Activate
20	TSTAT	Output	For future use	0 Volts When Inactive / +5 Volts when Active
21	AUX RX	Output	Aux Rx	Analog Signal – Unbalanced
22	GND		GND	
23**	AUX TX	Input/Output	Aux Tx	Analog Signal – 600 Ohm Unbalanced
24	PL -	Input	PL(-) In	Analog Signal – 600 Ohm Balanced
25**	Gen TX –	Input	Gen TX Data-	Analog Signal – 600 Ohm Balanced
26	Aux In 1	Input	Phone Patch - Call Request	Pull To Ground To Activate
27	Aux In 3	Input	Tx Inhibit	Pull To Ground To Activate
28	Aux In 5	Input	External PTT	Pull To Ground To Activate
29	Aux In 7	Input	Rx Inhibit	Pull To Ground To Activate
30	Aux In 9 +	Input	Phone Patch - PL Strip	Opto-Isolated In - Current flow to Activate
31	Aux In 10 +	Input	Phone Patch - Monitor	Opto-Isolated In - Current flow to Activate
32	Aux In 11 +	Input		Opto-Isolated In - Current flow to Activate
33	Aux In 12 +	Input		Opto-Isolated In - Current flow to Activate
34	GND		GND	
35	Aux In 14	Input	For future use	Pull To Ground To Activate
36	Aux Out 1	Output	Phone Patch - Inhibit / Enable	Low Impedance to Ground When Active
37	Aux Out 3	Output		Low Impedance to Ground When Active


Table continued...

Pin No.	Signal	Type	Function	Note
38	Aux Out 5	Output		Low Impedance to Ground When Active
39	Aux Out Relay 7 N.O.	Output	RD STAT - Receiver Active	Form Relay A Closed When Active
40	Aux Out Relay 8 N.O.	Output	Main Standby - Antenna Relay	Form Relay A Closed When Active
41	Aux Out Relay 9 N.O.	Output		Form Relay A Closed When Active
42	Aux Out Relay 10 N.O.	Output		Form Relay A Closed When Active
43	GND		GND	
44	GND		GND	
45	RSTAT	Output	For future use	0 Volts When Inactive / +5 Volts when Active
46	GND		GND	
47	TX DATA +			
48	GND		GND	
49	PL +	Input	PL(+) In	Analog Signal – 600 Ohm Balanced
50**	Gen TX +	Input	Gen TX DATA +	Analog Signal – 600 Ohm Balanced

* For detailed information on the differences between the automatic **Fallback In-Cabinet Repeat** and the externally-wired **In-Cabinet Repeat** functions, see the *Conventional Operations* manual.

** It is the responsibility of the third-party vendor to ensure that the signal generated by their device is compliant with any regulatory agency limitation imposed on the channel. This signal is not filtered or limited by the GTR 8000 Base Radio.

Figure 84: 50-Pin System Connector Pin-Outs (Conventional)



System Connector Ports (Trunked 3600)

The system connector is a 50-pin Mini SCSI connector. It is used for the WildCard inputs, outputs, and the analog audio paths not routed to their own connector.

Table 73: 50-Pin System Connector Pin-Outs (Trunked 3600)

Pin #	Signal	Type	Function	Note
1	Aux In 2	Input	CCI	Pull To Ground To Activate
2	Aux In 4	Input	TPTT	Pull To Ground To Activate
3*	Aux In 6	Input	In-Cabinet Repeat	Pull To Ground To Activate
4	Aux In 8	Input		Pull To Ground To Activate
5	Aux In 9 –	Input		Opto-Isolated In - Current flow to Activate
6	Aux In 10 –	Input		Opto-Isolated In - Current flow to Activate
7	Aux In 11 –	Input		Opto-Isolated In - Current flow to Activate
8	Aux In 12 –	Input		Opto-Isolated In - Current flow to Activate
9	Aux In 13	Input	Trunking Mute	Pull To Ground To Activate
10	Aux Out 12	Output		Low Impedance to Ground When Active
11	Aux Out 2	Output		Low Impedance to Ground When Active
12	Aux Out 4	Output		Low Impedance to Ground When Active
13	Aux Out 6	Output		Low Impedance to Ground When Active
14	Aux Out Relay 7 Com	Output	RD STAT - Receiver Active	Form Relay A Closed When Active
15	Aux Out Relay 8 Com	Output		Form Relay A Closed When Active
16	Aux Out Relay 9 Com	Output		Form Relay A Closed When Active
17	Aux Out Relay 10 Com	Output		Form Relay A Closed When Active
18	Aux Out 11	Output		Low Impedance to Ground When Active
19	External_Reset	Input	Reset	Buffered Input Pull To Ground To Activate
20	TSTAT	Output	TSTAT	0 Volts When Inactive / +5 Volts when Active

Table continued...

Pin #	Signal	Type	Function	Note
21	AUX RX	Output	Aux Rx	Analog Signal – Unbalanced
22	GND		GND	
23**	AUX TX	Input/Output	Aux Tx	Analog Signal – 600 Ohm Unbalanced
24	PL -	Input	n/a	Analog Signal – 600 Ohm Balanced
25**	Gen TX –	Input	Gen TX Data-	Analog Signal – 600 Ohm Balanced
26	Aux In 1	Input	Ext Failsoft	Pull To Ground To Activate
27	Aux In 3	Input	Tx Inhibit	Pull To Ground To Activate
28	Aux In 5	Input	External PTT	Pull To Ground To Activate
29	Aux In 7	Input	Rx Inhibit	Pull To Ground To Activate
30	Aux In 9 +	Input		Opto-Isolated In - Current flow to Activate
31	Aux In 10 +	Input		Opto-Isolated In - Current flow to Activate
32	Aux In 11 +	Input		Opto-Isolated In - Current flow to Activate
33	Aux In 12 +	Input		Opto-Isolated In - Current flow to Activate
34	GND		GND	
35	Aux In 14	Input	For future use	Pull To Ground To Activate
36	Aux Out 1	Output	Failsoft Indicate	Low Impedance to Ground When Active
37	Aux Out 3	Output		Low Impedance to Ground When Active
38	Aux Out 5	Output		Low Impedance to Ground When Active
39	Aux Out Relay 7 N.O.	Output	RD STAT - Receiver Active	Form Relay A Closed When Active
40	Aux Out Relay 8 N.O.	Output		Form Relay A Closed When Active
41	Aux Out Relay 9 N.O.	Output		Form Relay A Closed When Active
42	Aux Out Relay 10 N.O.	Output		Form Relay A Closed When Active
43	GND		GND	
44	GND		GND	
45	RSTAT	Output	RSTAT	0 Volts When Inactive / +5 Volts when Active
46	GND		GND	
47	TX DATA +			


Table continued...

Pin #	Signal	Type	Function	Note
48	GND		GND	
49	PL +	Input	n/a	Analog Signal – 600 Ohm Balanced
50**	Gen TX +	Input	Gen TX DATA +	Analog Signal – 600 Ohm Balanced

* For detailed information on the differences between the automatic **Fallback In-Cabinet Repeat** and the externally-wired **In-Cabinet Repeat** functions, see the *Conventional Operations* manual.

** It is the responsibility of the third-party vendor to ensure that the signal generated by their device is compliant with any regulatory agency limitation imposed on the channel. This signal is not filtered or limited by the GTR 8000 Base Radio.

Figure 85: 50-Pin System Connector Pin-Outs (Trunked 3600)




Wireline Port Pin-Outs

The Wireline port, an RJ-45 connector, can accommodate up to eight pins.

Table 74: Wireline Port Pin-Outs

Signal Name	Pin No.	2-Wire Con- nection	4-Wire Con- nection	Auxiliary 4- Wire Con- nection
Line2_+	1	Input/Output	Output	
Line2_–	2	Input/Output	Output	
Line3_+	3			Input
Line1_–	4		Input	
Line1_+	5		Input	
Line3_–	6			Input
Line4_+	7			Output
Line4_–	8			Output

Figure 86: Wireline Port Pin-Outs




Microphone Port Pin-Outs

The Microphone port is an RJ-45 connector that provides the interface for a microphone.

Table 75: Microphone Port Pin-Outs

Signal Name	Pin No.
Reserved	1
Reserved	2
MIC_PTT	3
MIC_AUDIO	4
GND	5
Reserved	6
Reserved	7
Reserved	8

Figure 87: Microphone Port Pin-Outs



Speaker Port Pin-Outs

The Speaker port is an RJ-9 connector that provides the interface to an external speaker.




CAUTION: To prevent damage to the base radio, use the HSN1006A speaker with the 0185180U01 cable.

Table 76: Speaker Port Pin-Outs

Signal Name	Pin No.
GND	1
+12 V	2
GND	3
Speaker Out	4

Figure 88: Speaker Port Pin-Outs



V.24 Port Pin-Outs

The V.24 port is an RJ-45 connector that provides the interface to a Digital Interface Unit, Conventional Channel Interface, Conventional Channel Gateway (CCGW), ASTRO-TAC® 3000 Comparator, or Channel Bank.

Table 77: V.24 Port Pin-Outs

Signal Name	Pin No.	Type
RCLK	1	Input
Rx Line Det	2	Input
TCLK	3	Input/Output
GND	4	GND
Data Rx	5	Input
Data Tx	6	Output
CTS	7	Input
RTS	8	Output

ASYNC RS-232 Cable Pin-Outs

The ASYNC RS-232 port is an RJ-45 connector that provides the interface to the Channel Bank for connection to the zone controller.



NOTICE: The ASYNC connection is only supported for a GTR 8000 Expandable Site Subsystem used in a trunked 3600 IntelliRepeater site.

Table 78: ASYNC RS-232 Port Pin-Outs

Function	XCVR Pin-Outs	Junction Panel Pin-Outs
	RJ-45 ASYNC Pin #	Channel Bank RJ-45 Pin #
RTS	1	8
DCD/DSR	2	2
RXD	3	5
—	4	—
GND	5	4
TXD	6	6
—	7	—
CTS	8	7

GTR 8000 Base Radio Part 68 Information

This section applies when the base radio is equipped with the optional wireline interface circuitry contained on the Oven Controlled Crystal Oscillator (OCXO) Transceiver Option Card (Option CA01506AA) or Temperature Compensated Crystal Oscillator (TCXO) Transceiver Option Card (Option CA01953).



NOTICE: The TCXO Transceiver Option Card is used for the Power Efficiency Package option.

This equipment complies with Part 68 of the FCC rules and the requirements of the Administrative Counsel for Terminal Attachments (ACTA). On the rear of this equipment is a label that contains, among other information, the registration number:

- US: ABZNINANT7039

If requested, this number must be provided to the telephone company.

The connector used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements of the ACTA. A compliant connector is provided with this product. See installation instructions for details.

REN: N/A

Connector: RJ-48

Authorized Network Port: 04NO2

Service Order Code: 7.0Y

If the equipment causes harm to the telephone network, the telephone company notifies your organization in advance that temporary discontinuance of service may be required. If advance notice is not practical, the telephone company notifies your organization as soon as possible. Also, your organization is advised of the right to file a complaint with the FCC if it is necessary.

The telephone company may change its facilities, equipment, operations, or procedures that could affect the operation of the equipment. If changes happen, the telephone company provides advance notice so your organization can make necessary modifications to maintain uninterrupted service.

If your organization experiences trouble with this equipment, see [Motorola Solution Support Center on page 344](#) for repair and warranty information. If the equipment is causing harm to the telephone

network, the telephone company may request that you disconnect the equipment until the problem is resolved.

None of the circuit boards in this equipment are field repairable. For assistance in sending the boards back for repair, see [Motorola Solution Support Center on page 344](#).

This equipment cannot be used on telephone company public coin phone service. Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission, or corporation commission for information.

GCP 8000 Site Controller and GPB 8000 Reference Distribution Module Ports (Front)

The GCP 8000 Site Controller and GPB 8000 Reference Distribution Module (RDM) has ports on both the front and the back that allow it to connect to various devices, including base radios, expansion ports, and other site equipment. In a GTR 8000 Expandable Site Subsystem configuration, the Ethernet connections from the individual base radios run on the backplane and connect to the switch on the site controller or RDM. This configuration minimizes the need for Ethernet cables.

Two service ports are accessible through a drop-down door to the top of the fans. The remaining ports are behind the fan module.

Figure 89: Site Controller and RDM Ports – Front




Table 79: Site Controller and RDM Connections – Front


Port / Type	Device it connects to:	Port / Type	Description
Ethernet service port, RJ-45	Service PC	LAN port	Ethernet service port for local access using Configuration/Service Software (CSS). Also may be used for localized software downloads.

Table continued...

Port / Type	Device it connects to:	Port / Type	Description
			 NOTICE: Supports only 10 Mb half duplex operation.
Serial service port, DB-9	Service PC	RS-232 port	Serial service port for initial configuration of the IP address.
Net AUX, RJ-45			Not in use
Gateway, RJ-45	Site router or site gateway	RJ-45	Connection to Gateway port on junction panel.
Expansion 1-5, RJ-45	Junction panel	Cab #1-5 A and Cab #1-5 B ports, RJ-45	Connects the site controllers or RDMs to the XHubs in the expansion cabinets.
Reference frequency input, BNC	Service monitor	BNC	Connection port to service monitor for frequency calibration.

Expansion Hub Connections

Each Expansion Hub (XHub) is connected to its corresponding site controller or GPB 8000 Reference Distribution Module (RDM) through the sub-panels on the junction panel.

Figure 90: Expansion Hub Connections

X_Hub_connections

Table 80: Expansion Hub Connections (Front View)

Port	Connects to	Port Type	Description
NET AUX	Junction panel, NET AUX port	RJ-45	Provides connection to auxiliary devices to the LAN.
EXPSN Input (CP3)	Network Expansion sub-panel on junction panel	RJ-45	Provides connection between XHubs and junction panel. Also provides connections between site controllers or RDMs in Cabinet #1.

Junction Panel Connections

The junction panel for the GTR 8000 Expandable Site Subsystem provides locations for all the connections to external devices. Cables provided by Motorola include the specific connectors for the junction panel on one end and the subsystem equipment on the other end.



IMPORTANT: Do not remove the label from a connector location until you insert the connector.




NOTICE: For an overview of connecting to an ASTRO[®] 3.1 Conventional System (ASTRO-TAC 3000 Comparator or DIU), see the *Conventional Operations* manual. The base radio can be IP managed while using the 4-wire/V.24 interface for channel traffic.

Junction Panel Connections for an ASTRO 25 Repeater Site (700/800/900 MHz and UHF R2 435–524 MHz)

In the GTR 8000 Expandable Site Subsystem, the junction panel is the primary location of connections to external equipment. The RF connections are also illustrated in [GTR 8000 Expandable Site](#)

Subsystem RFDS Transmit Path on page 61 and GTR 8000 Expandable Site Subsystem RFDS Receive Path on page 62.

Figure 91: Junction Panel for the GTR 8000 Expandable Site Subsystem Prime Cabinet for an ASTRO 25 Repeater Site (700/800/900 MHz and UHF R2 435–524 MHz)



A25_GTR8000_JP_ESS_Prime_Conv_700_800_900_UHFR2E

NOTICE: For HPD Overlay sites, the Gateway A and B connections link directly to Site Switches A and B instead of gateways. The site switches may be inside the site controller modules if HPD is overlaid on a GTR 8000 Expandable Site Subsystem.

Table 81: GTR 8000 Expandable Site Subsystem Prime Cabinet Junction Panel Connections for an ASTRO 25 Repeater Site (700/800/900 MHz and UHF R2 435–524 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Gateway A port, RJ-45	Primary Site Gateway	LAN 1, RJ-45	Ethernet link between site controller A and the primary site gateway or primary site gateway to site link
Gateway B port, RJ-45	Secondary Site Gateway (optional)	LAN 1, RJ-45	Ethernet link between site controller B and secondary site gateway or secondary site gateway to site link (if installed).

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Network AUX A, RJ-45	MOSCAD NFM or external trunked base radio	LAN Port 1, RJ-45 SC-A, RJ-45	Ethernet link for MOSCAD NFM or connection to external trunked base radio.
Network AUX B, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site. If a site gateway (CCGW) is integrated into the prime cabinet, it connects directly to the Net AUX port on SC B.
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
Remote GPS A, DB-15			Not in use
Remote GPS B, DB-15			Not in use
V.24-1 through 6, RJ-45	External DIU, site gateway (digital CCGW), channel bank, or base radio (for conventional channels)	RJ-45	Connection of V.24 link from BR to DIU, site gateway (digital CCGW) device, or channel bank. The conventional base radio and/or site gateway (digital CCGW) can be external or integrated into the prime cabinet. This port is used to connect them when one is integrated and the other is not.
Wireline-1 through 6, RJ-45	External DIU, site gateway (analog CCGW), or analog conventional base radio	RJ-45	Connection of Wireline link from BR to DIU or site gateway (analog CCGW) device. The conventional base radio and/or site gateway (analog CCGW) can be external or integrated into the prime cabinet. This port is used to connect them when one is integrated and the other is not.
ASYNC, RJ-45			Not in use
Rx-A, N-type	Receive antenna A / tower top amplifier	TTA input port	RF coax to receive branch A.
Rx-B, N-type	Receive antenna B / tower top amplifier	TTA input port	RF coax to receive branch B. Used if diversity option for Phase 2 TDMA is needed.
Tx, 7/16	Transmit antenna for cavity combiner	Tx output port	RF coax to transmit antenna.

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Tx 1, N female (900 MHz only)	Transmit antenna for hybrid combiner	Tx output port	RF coax to transmit antenna.
Tx 2, N female (900 MHz only)	Transmit antenna for hybrid combiner (optional)	Tx output port	RF coax to transmit antenna.
Cab #1-5, A, RJ-45	Site Controller 1	Expansion Ports 1-5, RJ-45	Connection of site controller 1 to XHub A in expansion cabinets #1-5.
Cab #1-5, B, RJ-45	Site Controller 2	Expansion Ports 1-5, RJ-45	Connection of site controller 2 to XHub B in expansion cabinets #1-5.
Cab #1-3, Branch A, BNC	Expansion cabinet #1-3 Receive Input Branch 'A'.	Rx A, N	Receive path connection from the primary cabinet to the Rx Branch 'A' connector of expansion cabinets #1-3.
Cab #1-3, Branch B, BNC	Expansion cabinet #1-3 Receive Input Branch 'B'.	Rx B, N	Receive path connection from the primary cabinet to the Rx Branch 'B' connector of expansion cabinets #1-3.
Internal Alarm, DB-25			Not in use
Ext. Freq. Ref.			Not in use
1 PPS			Not in use

Figure 92: Junction Panel for the GTR 8000 Expandable Site Subsystem Expansion Cabinet for an ASTRO 25 Repeater Site (700/800/900/UHF R2 435–524 MHz)




Table 82: GTR 8000 Expandable Site Subsystem Expansion Junction Panel Connections for an ASTRO 25 Repeater Site (700/800/900/UHF R2 435–524 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Expansion Input A RJ-45	Primary cabinet, network expansion sub-panel Cab # 1-5, A	LAN 1, RJ-45	Expansion link between site controller A and XHub A in expansion cabinet (N) where N is the number of the cabinet.
Expansion Input B RJ-45	Primary cabinet, network expansion sub-panel Cab # 1-5, B	LAN 1, RJ-45	Expansion link between site controller B and XHub B in expansion cabinet (N) where N is the number of the cabinet.
Network AUX A, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site.


Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Network AUX B, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site.
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
V.24-1 through 6, RJ-45	External DIU, site gateway (digital CCGW), channel bank, or base radio (for conventional channels)	RJ-45	Connection of V.24 link from BR to DIU, site gateway (digital CCGW) device, or channel bank. The conventional base radio and/or site gateway (digital CCGW) can be external or integrated into the cabinet. This port is used to connect them when one is integrated and the other is not.
Wireline-1 through 6, RJ-45	External DIU, site gateway (analog CCGW), or analog conventional base radio	RJ-45	Connection of Wireline link from BR to DIU or site gateway (analog CCGW) device. The conventional base radio and/or site gateway (analog CCGW) can be external or integrated into the cabinet. This port is used to connect them when one is integrated and the other is not.
ASync, RJ-45			Not in use
Rx-A, N-type	Receive antenna A/tower top amplifier or Receive expansion	TTA input port	RF coax to receive branch A.
Rx-B, N-type	Receive antenna B / tower top amplifier	TTA input port	RF coax to receive branch B. Used if diversity option for Phase 2 TDMA is needed.
Tx, 7/16	Transmit antenna for cavity combiner	Tx output port	RF coax to transmit antenna.
Tx 1, N female (900 MHz only)	Transmit antenna for hybrid combiner	Tx output port	RF coax to transmit antenna.
Tx 2, N female (900 MHz only)	Transmit antenna for hybrid combiner (optional)	Tx output port	RF coax to transmit antenna.
Internal Alarm, DB-25			Not in use

Junction Panel Connections for an ASTRO 25 Repeater Site (UHF R1 380–435 MHz and VHF 136–174 MHz)

In a GTR 8000 Expandable Site Subsystem operating in the UHF R1 and VHF bands, most external equipment is connected through the junction panel. Each of the six Tx outputs is connected with a cable from a power amplifier in the GTR 8000 Expandable Site Subsystem to the junction panel that connects to the Tx RFDS. The RF connections are also illustrated in [GTR 8000 Expandable Site Subsystem RFDS Transmit Path on page 61](#) and [GTR 8000 Expandable Site Subsystem RFDS Receive Path on page 62](#).

Figure 93: Junction Panel for the GTR 8000 Expandable Site Subsystem Prime Cabinet for an ASTRO 25 Repeater Site (UHF R1 380–435 MHz and VHF 136–174 MHz)



A25_GTR8000_JP_ESS_Prime_Conv_VHF_UHFR1B



NOTICE: For HPD Overlay sites, the Gateway A and B connections link directly to Site Switches A and B instead of gateways. The site switches may be inside the site controller modules if HPD is overlaid on a GTR 8000 Expandable Site Subsystem.

Table 83: GTR 8000 Expandable Site Subsystem Prime Cabinet Junction Panel Connections for an ASTRO 25 Repeater Site (UHF R1 380–435 MHz and VHF 136–174 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Gateway A port, RJ-45	Primary Site Gateway	LAN 1, RJ-45	Ethernet link between site controller A and the primary site gateway or primary site gateway to site link.
Gateway B port, RJ-45	Secondary Site Gateway (optional)	LAN 1, RJ-45	Ethernet link between site controller B and secondary site gateway or secondary site gateway to site link (if installed).
Network AUX A, RJ-45	MOSCAD NFM or external trunked base radio	LAN 1, RJ-45 SC-A, RJ-45	Ethernet link for MOSCAD NFM or connection to external trunked base radio.
Network AUX B, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site. If a site gateway is integrated into the prime cabinet, it connects directly to the Net AUX port on SC B.
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
Remote GPS A, DB-15			Not in use
Remote GPS B, DB-15			Not in use
V.24-1 through 6, RJ-45	External DIU, site gateway (digital CCGW), channel bank, or base radio (for conventional channels)	RJ-45	Connection of V.24 link from BR to DIU, site gateway (digital CCGW) device, or channel bank. The conventional base radio and/or site gateway (digital CCGW) can be external or integrated into the prime cabinet. This port is used to connect them when one is integrated and the other is not.
Wireline-1 through 6, RJ-45	External DIU, site gateway (analog CCGW), or analog conventional base radio	RJ-45	Connection of Wireline link from BR to DIU or site gateway (analog CCGW) device. The conventional base radio and/or site gateway (analog CCGW) can be external or integrated into the prime cabinet. This

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
			port is used to connect them when one is integrated and the other is not.
ASYNC			Not in use
RX 1 through 6, BNC	External Receive Multi-coupler	RMC output Port	RF coax to receive input for each BR.
TX 1 through 6, N-type	Tx combiner	Tx input port	RF coax output from each BR to Tx combiner.
Tx, 7/16	Transmit antenna	Tx output port	RF coax to transmit antenna if PMU option is included. Tx output from external combiner must be routed directly to PMU input.
Cab #1-5, A, RJ-5	Site Controller 1	Expansion Ports 1-5, RJ-45	Connection of site controller 1 to XHub A in expansion cabinets #1-5.
Cab #1-5, B, RJ-45	Site Controller 2	Expansion Ports 1-5, RJ-45	Connection of site controller 2 to XHub B in expansion cabinets #1-5.
Internal Alarm, DB-25			Not in use
Ext. Freq. Ref.			Not in use
1 PPS			Not in use

Figure 94: Junction Panel for the GTR 8000 Expandable Site Subsystem Expansion Cabinet for an ASTRO 25 Repeater Site (UHF R1 380–435 MHz and VHF 136–174 MHz)




Table 84: GTR 8000 Expandable Site Subsystem Expansion Junction Panel Connections for a Repeater Site (UHF R1 380–435 MHz and VHF 136–174 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Expansion Input A port, RJ-45	Primary cabinet, network expansion sub-panel Cab # 1-5, A	LAN 1, RJ-45	Expansion link between site controller A and Expansion Hub A in expansion cabinet (N) where N is the number of the cabinet.
Expansion Input B port, RJ-45	Primary cabinet, network expansion sub-panel Cab # 1-5, B	LAN 1, RJ-45	Expansion link between site controller B and Expansion Hub B in expansion cabinet (N) where N is the number of the cabinet.
Network AUX A, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site.
Network AUX B, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site.


Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
V.24-1 through 6, RJ-45	External DIU, site gateway (digital CCGW), channel bank, or base radio (for conventional channels)	RJ-45	Connection of V.24 link from BR to DIU, site gateway (digital CCGW) device, or channel bank. The conventional base radio and/or site gateway (digital CCGW) can be external or integrated into the cabinet. This port is used to connect them when one is integrated and the other is not.
Wireline-1 through 6, RJ-45	External DIU, site gateway (analog CCGW), or analog conventional base radio	RJ-45	Connection of Wireline link from BR to DIU or site gateway (analog CCGW) device. The conventional base radio and/or site gateway (analog CCGW) can be external or integrated into the cabinet. This port is used to connect them when one is integrated and the other is not.
ASYNC			Not in use
RX '1' through 6 BNC	External Receive Multi-coupler	RMC output Port	RF coax to receive input for each BR.
TX 1 through 6 N-type	Tx combiner	Tx input port	RF coax output from each BR to Tx combiner.
Tx, 7/16	Transmit antenna	Tx output port	RF coax to transmit antenna if PMU option is included. Tx output from external combiner must be routed directly to PMU input.
Internal Alarm, DB-25			Not in use

Junction Panel Connections for a Trunked IP Simulcast Site (700/800/900 MHz and UHF R2 435–524 MHz) (Standard Configuration)

In the GTR 8000 Expandable Site Subsystem, the junction panel is the primary location of connections to external equipment. The RF connections are also illustrated in [GTR 8000 Expandable Site Subsystem RFDS Transmit Path on page 61](#) and [GTR 8000 Expandable Site Subsystem RFDS Receive Path on page 62](#).

Figure 95: Junction Panel for the GTR 8000 Expandable Site Subsystem for a Trunked IP Simulcast Site Standard Configuration (700/800/900 MHz and UHF R2 435–524 MHz)



IP_Sim_GTR8000_JP_ESS_Prime_Conv_700_800_900_UHFR2A

Table 85: GTR 8000 Expandable Site Subsystem Junction Panel Connections for Trunked IP Simulcast Sites Standard Configuration (700/800/900 MHz and UHF R2 435–524 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
LAN A port, RJ-45	Switch	LAN 1, RJ-45	Ethernet link to the LAN switch to remote site gateway.
LAN B port, RJ-45			Not in use
1PPS, BNC*	TRAK 9100	Timing, BNC	Connect external Site Timing Reference
Ext Freq Ref, BNC*	TRAK 9100 5 MHz frequency reference	RF, BNC	Connect external Site Frequency Reference
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
V.24-1 through 6, RJ-45	External DIU, site gateway (digital CCGW), channel bank, or base radio (for conventional channels)	RJ-45	Connection of V.24 link from BR to DIU, site gateway (digital CCGW) device, or channel bank. The conventional base radio and/or site gateway (digital CCGW) can be external or integrated into the cabinet. This port is used to connect them when one is integrated and the other is not.
Wireline-1 through 6, RJ-45	External DIU, site gateway (analog CCGW), or analog conventional base radio	RJ-45	Connection of Wireline link from BR to DIU or site gateway (analog CCGW) device. The conventional base radio and/or site gateway (analog CCGW) can be external or integrated into the cabinet. This port is used to connect them when one is integrated and the other is not.
ASYNCR			Not in use
Rx-A, N-type	Receive antenna A / tower top amplifier	TTA input port	RF coax to receive branch A.
Rx-B, N-type	Receive antenna B / tower top amplifier	TTA input port	RF coax to receive branch B. Used if diversity option for Phase 2 TDMA is required.
Tx, 7/16	Transmit antenna for cavity combiner	Tx output port	RF coax to transmit antenna.
Tx 1, N female (900 MHz only)	Transmit antenna for hybrid combiner	Tx output port	RF coax to transmit antenna.
Tx 2, N female (900 MHz only)	Transmit antenna for hybrid combiner (optional)	Tx output port	RF coax to transmit antenna.
Cab #1-3, Branch A, BNC	Expansion cabinet #1-3 Receive Input Branch 'A'.	Rx A, N	Receive path connection from the primary cabinet to the Rx Branch 'A' connector of expansion cabinets #1-3.
Cab #1-3, Branch B, BNC	Expansion cabinet #1-3 Receive Input Branch 'B'.	Rx B, N	Receive path connection from the primary cabinet to the Rx Branch 'B' connector of expansion cabinets #1-3.
Internal Alarm, DB-25			May connect MOSCAD NFM to pin-22 and 23 for contact closure. Indicates RMC failure.

* See [GTR 8000 Base Radio Time and Frequency Inputs on page 292](#) The XHubs need both Time and Frequency references that are provided with either a Composite (5 MHz +1PPS) or separate 5 MHz and 1PPS sources. For a separate 5 MHz reference, connect to the Ext Freq Ref port on each cabinet/rack. For a separate 1PPS reference, connect to the 1PPS port on each cabinet/rack. For a Composite reference, connect to the Ext Freq Ref port only on each cabinet/rack.

Both Ext Freq Ref and 1PPS inputs must have a BNC "T" connected. A 50 Ohm termination is on one leg of the "T" and the cable to the junction panel is on the other side of the "T".

Junction Panel Connections for a Trunked IP Simulcast Site (UHF R1 380–435 MHz and VHF 136–174 MHz) (Standard Configuration)

In a GTR 8000 Expandable Site Subsystem operating in the UHF R1 and VHF bands, most external equipment is connected through the junction panel. Each of the six Tx outputs is connected with a cable from a power amplifier in the GTR 8000 Expandable Site Subsystem to a jumper cable that connects to the Tx RFDS. The RF connections are also illustrated in [GTR 8000 Expandable Site Subsystem RFDS Transmit Path on page 61](#) and [GTR 8000 Expandable Site Subsystem RFDS Receive Path on page 62](#).

Figure 96: Junction Panel for the GTR 8000 Expandable Site Subsystem for a Trunked IP Simulcast Site Standard Configuration (UHF R1 380–435 MHz and VHF 136–174 MHz)




Table 86: GTR 8000 Expandable Site Subsystem Junction Panel Connections for a Trunked IP Simulcast Site Standard Configuration (UHF R1 380–435 MHz and VHF 136–174 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
LAN A port, RJ-45	Switch	LAN 1, RJ-45	Ethernet link to the LAN switch to remote site gateway.
LAN B port, RJ-45			Not in use
1PPS, BNC*	TRAK 9100	Timing	Connect external Site Timing Reference

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Freq Ref, BNC*	TRAK 9100 5 MHz frequency reference	RF, BNC	Connect external Site Frequency Reference
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
V.24-1 through 6, RJ-45	External DIU, site gateway (digital CCGW), channel bank, or base radio (for conventional channels)	RJ-45	Connection of V.24 link from BR to DIU, site gateway (digital CCGW) device, or channel bank. The conventional base radio and/or site gateway (digital CCGW) can be external or integrated into the cabinet. This port is used to connect them when one is integrated and the other is not.
Wireline-1 through 6, RJ-45	External DIU, site gateway (analog CCGW), or analog conventional base radio	RJ-45	Connection of Wireline link from BR to DIU or site gateway (analog CCGW) device. The conventional base radio and/or site gateway (analog CCGW) can be external or integrated into the cabinet. This port is used to connect them when one is integrated and the other is not.
ASYN			Not in use
RX 1 through 6, BNC	External Receive Multi-coupler	RMC output Port	RF coax to receive input for each BR.
TX 1 through 6, N-type	Tx combiner	Tx input port	RF coax output from each BR to Tx combiner.
Tx, 7/16			Not in use
Internal Alarm, DB-25			May connect MOSCAD NFM to pin-22 and 23 for contact closure. Indicates RMC failure.


* See [GTR 8000 Base Radio Time and Frequency Inputs on page 292](#). The XHubs need both Time and Frequency references that are provided with either a Composite (5 MHz + 1PPS) or separate 5 MHz and 1PPS sources. For a separate 5 MHz reference, connect to the Ext Freq Ref port on each cabinet/rack. For a separate 1PPS reference, connect to the 1PPS port on each cabinet/rack. For a Composite reference, connect to the Ext Freq Ref port only on each cabinet/rack.

Both Ext Freq Ref and 1PPS inputs must have a BNC “T” connected. A 50 Ohm termination is on one leg of the “T” and the cable to the junction panel is on the other side of the “T”.

Junction Panel Connections for HPD (700/800 MHz)

In the GTR 8000 Expandable Site Subsystem, the junction panel is the primary location of connections to external equipment. The RF connections are also illustrated in [GTR 8000 Expandable Site Subsystem RFDS Transmit Path on page 61](#) and [GTR 8000 Expandable Site Subsystem RFDS Receive Path on page 62](#).

Figure 97: Junction Panel for the GTR 8000 Expandable Site Subsystem for HPD (700/800 MHz)



HPD_GTR8000_JP_ESS_2

NOTICE: For HPD Overlay sites, the Gateway A and B connections link directly to Site Switches A and B instead of gateways.

Table 87: GTR 8000 Expandable Site Subsystem Junction Panel Connections for HPD (700/800 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Gateway A port, RJ-45	Primary Site Gateway	LAN 1, RJ-45	Ethernet link between site controller A and the primary site gateway or primary site gateway to site link.
Gateway B port, RJ-45	Secondary Site Gateway (optional)	LAN 1, RJ-45	Ethernet link between site controller B and secondary site gateway or secondary site gateway to site link (if installed).
Network AUX A, RJ-45	MOSCAD NFM	LAN Port 1, RJ-45	Ethernet link for MOSCAD NFM.
Network AUX B, RJ-45	Auxiliary site equipment such as a site gateway	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a site gateway if it is included at the site.


Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
			If a site gateway is integrated into the prime cabinet, it connects directly to the Net AUX port on SC B.
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
V7.24-1 through 6, RJ-45	External DIU, site gateway (digital CCGW), channel bank, or base radio (for conventional channels)	RJ-45	Connection of V.24 link from BR to DIU, site gateway (digital CCGW) device, or channel bank. The conventional base radio and/or site gateway (digital CCGW) can be external or integrated into the cabinet. This port is used to connect them when one is integrated and the other is not.
Wireline-1 through 6, RJ-45	External DIU, site gateway (analog CCGW), or analog conventional base radio	RJ-45	Connection of Wireline link from BR to DIU or site gateway (analog CCGW) device. The conventional base radio and/or site gateway (analog CCGW) can be external or integrated into the cabinet. This port is used to connect them when one is integrated and the other is not.
ASYNC			
Remote GPS A, DB-15	Lightning Arrestor / RGPS Unit A	Line terminals	See GPS Lightning Arrestor for terminal connection details on the lightning arrestor.
Remote GPS B, DB-15	Lightning Arrestor / RGPS Unit B	Line terminals	See GPS Lightning Arrestor for terminal connection details on the lightning arrestor.
Rx-A, N-type	Receive antenna A / tower top amplifier	TTA input port	RF coax to receive branch A.
Rx-B, N-type	Receive antenna B / tower top amplifier	TTA input port	RF coax to receive branch B.
Tx, 7/16	Transmit antenna	Tx output port	RF coax to transmit antenna.
Ext. Freq. Ref.			Not in use
1PPS			Not in use
Internal Alarm, DB-25			Not in use

Junction Panel Connections for an ASTRO 25 Express System (700/800/900 MHz and UHF R2 435–524 MHz)

In the GTR 8000 Expandable Site Subsystem, the junction panel is the primary location of connections to external equipment. The RF connections are also illustrated in [GTR 8000 Expandable Site Subsystem RFDS Transmit Path on page 61](#) and [GTR 8000 Expandable Site Subsystem RFDS Receive Path on page 62](#).

Figure 98: Junction Panel for the GTR 8000 Expandable Site Subsystem Prime Cabinet for an ASTRO 25 Express System (700/800/900 MHz and UHF R2 435–524 MHz)



A25_Express_GTR8000_JP_ESS_Prime_700_800_900_UHFR2


Table 88: GTR 8000 Expandable Site Subsystem Prime Cabinet Junction Panel Connections for an ASTRO 25 Express System (700/800/900 MHz and UHF R2 435–524 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Gateway A port, RJ-45			Not in use
Gateway B port, RJ-45			Not in use
Network AUX A, RJ-45			not in use

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Network AUX B, RJ-45			Not in use
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
Remote GPS A, DB-15			Not in use
Remote GPS B, DB-15			Not in use
Rx-A, N-type	Receive antenna A / tower top amplifier	TTA input port	RF coax to receive branch A.
Rx-B, N-type	Receive antenna B / tower top amplifier	TTA input port	RF coax to receive branch B. Used if diversity operation for Phase 2 TDMA is required.
Tx, 7/16	Transmit antenna for cavity combiner	Tx output port	RF coax to transmit antenna.
Tx 1, N female (900 MHz only)	Transmit antenna for hybrid combiner	Tx output port	RF coax to transmit antenna.
Tx 2, N female (900 MHz only)	Transmit antenna for hybrid combiner (optional)	Tx output port	RF coax to transmit antenna.
Internal Alarm, DB-25			Not in use
Cab #1-5, A, RJ-45	Site Controller 1	Expansion Ports 1–5, RJ-45	Connection of site controller 1 to XHub A in expansion cabinets #1-5.
Cab #1-5, B, RJ-45	Site Controller 2	Expansion Ports 1–5, RJ-45	Connection of site controller 2 to XHub B in expansion cabinets #1-5.
Cab #1-3, Branch A, BNC	Expansion cabinet #1-3 Receive Input Branch 'A'.	Rx A, N	Receive path connection from the primary cabinet to the Rx Branch 'A' connector of expansion cabinets #1-3.
Cab #1-3, Branch B, BNC	Expansion cabinet #1-3 Receive Input Branch 'B'.	Rx B, N	Receive path connection from the primary cabinet to the Rx Branch 'B' connector of expansion cabinets #1-3.
Ext. Freq. Ref.			Not in use
1PPS			Not in use

Figure 99: Junction Panel for the GTR 8000 Expandable Site Subsystem Expansion Cabinet for an ASTRO 25 Express System (700/800/900 MHz and UHF R2 435–524 MHz)



NOTICE: For an ASTRO® 25 Express System using Phase 2 TDMA operation, a second antenna branch may be required, see “Appendix B” in the *Dynamic Dual Mode for TDMA Operation* manual for details.

Table 89: GTR 8000 Expandable Site Subsystem Expansion Cabinet Junction Panel Connections for an ASTRO 25 Express System (700/800/900 MHz and UHF R2 435–524 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Expansion Input A port, RJ-45	Primary cabinet, network expansion sub-panel Cab #(N) A	LAN 1, RJ-45	Expansion link between site controller 1 and Expansion Hub A in expansion cabinet (N) where N is the number of the cabinet.
Expansion Input B port, RJ-45	Primary cabinet, network expansion sub-panel Cab #(N) B	LAN 1, RJ-45	Expansion link between site controller 2 and Expansion Hub B in expansion cabinet (N) where N is the number of the cabinet.
Network AUX A, RJ-45			Not in use


Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Network AUX B, RJ-45			Not in use
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
Rx-A, N-type	Receive antenna A / tower top amplifier	TTA input port	RF coax to receive branch A.
Rx-B, N-type	Receive antenna B / tower top amplifier	TTA input port	RF coax to receive branch B. Used if diversity operation for Phase 2 TDMA is required.
Tx 1, N female	Not in use	Tx output port	Not in use
Tx 2, N female	Not in use	Tx output port	Not in use
Tx, 7/16	Transmit antenna	Tx output port	RF coax to transmit antenna.
Internal Alarm, DB-25			Not in use

Junction Panel Connections for an ASTRO 25 Express System (UHF R1 380–435 MHz and VHF 136–174 MHz)

In a GTR 8000 Expandable Site Subsystem operating in the UHF R1 and VHF bands, most external equipment is connected through the junction panel. Each of the six Tx outputs is connected with a cable from a power amplifier in the GTR 8000 Expandable Site Subsystem to the junction panel. The RF connections are also illustrated in [GTR 8000 Expandable Site Subsystem RFDS Transmit Path on page 61](#) and [GTR 8000 Expandable Site Subsystem RFDS Receive Path on page 62](#).

Figure 100: Junction Panel for the GTR 8000 Expandable Site Subsystem Prime Cabinet for an ASTRO 25 Express System (UHF R1 380–435 MHz and VHF 136–174 MHz)



A25_Express_GTR8000_JP_ESS_Prime_VHF_UHFR1

Table 90: GTR 8000 Expandable Site Subsystem Prime Cabinet Junction Panel Connections for an ASTRO 25 Express System (UHF R1 380–435 MHz and VHF 136–174 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Gateway A port, RJ-45			Not in use
Gateway B port, RJ-45			Not in use
Network AUX A, RJ-45			No in use
Network AUX B, RJ-45			Not in use
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
Remote GPS A, DB-15			Not in use

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Remote GPS B, DB-15			Not in use
RX 1 through 6, BNC	External Receive Multi-coupler	RMC Output Port	RF coax to receive input for each BR.
Tx, 7/16	Transmit antenna	Tx output port	RF coax to transmit antenna if PMU option is included. Tx output from external combiner must be routed directly to PMU input.
TX 1 through 6, N-type	Tx combiner	Tx input port	RF coax output from each BR to Tx combiner
Cab #1-5, A, RJ-45	Site Controller 1	Expansion Ports 1-5, RJ-45	Connection of site controller 1 to XHub A in expansion cabinets #1-5.
Cab #1-5, B, RJ-45	Site Controller 2	Expansion Ports 1-5, RJ-45	Connection of site controller 2 to XHub B in expansion cabinets #1-5.
Internal Alarm, DB-25			Not in use
Ext Freq Ref			Not in use
1PPS			Not in use

Figure 101: Junction Panel for the GTR 8000 Expandable Site Subsystem Expansion Cabinet for an ASTRO 25 Express System (UHF R1 380–435 MHz and VHF 136–174 MHz)




Table 91: GTR 8000 Expandable Site Subsystem Expansion Cabinet Junction Panel Connections for an ASTRO 25 Express System (UHF R1 380–435 MHz and VHF 136–174 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Expansion Input A port, RJ-45	Primary cabinet, network expansion sub-panel Cab #(N) A	LAN 1, RJ-45	Expansion link between site controller 1 and expansion Hub A in expansion cabinet (N) where N is the number of the cabinet.
Expansion Input B port, RJ-45	Primary cabinet, network expansion sub-panel Cab #(N) B	LAN 1, RJ-45	Expansion link between site controller 2 and expansion Hub B in expansion cabinet (N) where N is the number of the cabinet.
Network AUX A, RJ-45			Not in use
Network AUX B, RJ-45			Not in use

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
RX 1 through 6, BNC	External Receive Multi-coupler	RMC output Port	RF coax to receive input for each BR.
TX 1 through 6, N-type	Tx combiner	Tx input port	RF coax output from each BR to Tx combiner
Tx, 7/16	Transmit antenna	Tx output port	RF coax to transmit antenna if PMU option is included. Tx output from external combiner must be routed directly to PMU input.
Internal Alarm, DB-25			Not in use

Junction Panel Connections for a Trunked IP Simulcast (High Availability Configuration)

A high availability configuration at a trunked IP simulcast remote site uses GPB 8000 Reference Distribution Modules (RDMs) instead of XHubs in the first cabinet/rack. The RDM provides integrated Ethernet LAN switching, eliminating the external HP LAN switches at the remote site. The RDM also provides redundant integrated site reference distribution through two GPS units as timing reference sources to all the base radios at the remote site, eliminating the need for the TRAK 9100 Simulcast Site Reference at the remote site.

The junction panel for the GTR 8000 Expandable Site Subsystem provides locations for all the connections to external devices. Cables provided by Motorola include the specific connectors for the junction panel on one end and the subsystem equipment on the other end.



IMPORTANT: Do not remove the label from a connector location until you insert the connector.




NOTICE: For an overview of connecting to an ASTRO® 3.1 Conventional System (ASTRO-TAC 3000 Comparator or DIU), see the *Conventional Operations* manual. The base radio can be IP managed while using the 2- or 4-wire E&M, or V.24 interface for channel traffic.

Junction Panel Connections for a Trunked IP Simulcast Site (700/800/900 MHz and UHF R2 435–524 MHz) (High Availability)

In the GTR 8000 Expandable Site Subsystem, the junction panel is the primary location of connections to external equipment. The RF connections are also illustrated in [GTR 8000 Expandable Site Subsystem RFDS Transmit Path on page 61](#) and [GTR 8000 Expandable Site Subsystem RFDS Receive Path on page 62](#).

Figure 102: Junction Panel for the GTR 8000 Expandable Site Subsystem Prime Cabinet for a Trunked IP Simulcast Site High Availability (700/800/900 MHz and UHF R2 435–524 MHz)



A25_GTR8000_JP_ESS_Prime_Conv_700_800_900_UHFR2E

NOTICE: For HPD Overlay sites, the Gateway A and B ports in the HPD rack/cabinet connect to the LAN via Network AUX ports in the trunked simulcast site and not to a Gateway directly.

Table 92: GTR 8000 Expandable Site Subsystem Prime Cabinet Junction Panel Connections for Trunked IP Simulcast Site High Availability (700/800/900 MHz and UHF R2 435–524 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Gateway A port, RJ-45	Primary Site Gateway	LAN 1, RJ-45	Ethernet link between RDM A and the primary site gateway or primary site gateway to site link.
Gateway B port, RJ-45	Secondary Site Gateway (optional)	LAN 1, RJ-45	Ethernet link between RDM B and secondary site gateway or secondary site gateway to site link (if installed).
Network AUX A, RJ-45	MOSCAD NFM	LAN Port 1, RJ-45	Ethernet link for MOSCAD NFM.

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Network AUX B, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site. If a site gateway (CCGW) is integrated into the prime cabinet, it connects directly to the Net AUX port on RDM B.
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
Remote GPS A, DB-15	Lightning Arrestor / GPS Unit A	Line terminals	See GPS Lightning Arrestor for terminal connection details on the lightning arrestor.
Remote GPS B, DB-15	Lightning Arrestor / GPS Unit B	Line terminals	See GPS Lightning Arrestor for terminal connection details on the lightning arrestor.
V.24-1 through 6, RJ-45	External DIU, site gateway (digital CCGW), channel bank, or base radio (for conventional channels)	RJ-45	Connection of V.24 link from BR to DIU, site gateway (digital CCGW) device, or channel bank. The conventional base radio and/or site gateway (digital CCGW) can be external or integrated into the prime cabinet. This port is used to connect them when one is integrated and the other is not.
Wireline-1 through 6, RJ-45	External DIU, site gateway (analog CCGW), or analog conventional base radio	RJ-45	Connection of Wireline link from BR to DIU or site gateway (analog CCGW) device. The conventional base radio and/or site gateway (analog CCGW) can be external or integrated into the prime cabinet. This port is used to connect them when one is integrated and the other is not.
ASYNC			Not in use
Rx-A, N-type	Receive antenna A / tower top amplifier	TTA input port	RF coax to receive branch A.
Rx-B, N-type	Receive antenna B / tower top amplifier	TTA input port	RF coax to receive branch B. Used if diversity operation for Phase 2 TDMA is required.
Tx, 7/16	Transmit antenna for cavity combiner	Tx output port	RF coax to transmit antenna.
Tx 1, N female (900 MHz only)	Transmit antenna for hybrid combiner	Tx output port	RF coax to transmit antenna.

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Tx 2, N female (900 MHz only)	Transmit antenna for hybrid combiner (optional)	Tx output port	RF coax to transmit antenna.
Cab #1-5, A, RJ-45	RDM A	Expansion Ports 1–5, RJ-45	Connection of RDM A to XHub A in expansion cabinets #1-5.
Cab #1-5, B, RJ-45	RDM B	Expansion Ports 1–5, RJ-45	Connection of RDM B to XHub B in expansion cabinets #1-5.
Cab #1-3, Branch A, BNC	Expansion cabinet #1-3 Receive Input Branch 'A'.	Rx A, N	Receive path connection from the primary cabinet to the Rx Branch 'A' connector of expansion cabinets #1-3.
Cab #1-3, Branch B, BNC	Expansion cabinet #1-3 Receive Input Branch 'B'.	Rx B, N	Receive path connection from the primary cabinet to the Rx Branch 'B' connector of expansion cabinets #1-3.
Internal Alarm, DB-25			Not in use
Ext. Freq. Reference			Not in use
1PPS			Not in use

*See [GTR 8000 Base Radio Time and Frequency Inputs on page 292](#).

Figure 103: Junction Panel for the GTR 8000 Expandable Site Subsystem Expansion Cabinet for a Trunked IP Simulcast Site High Availability (700/800/900 MHz and UHF R2 435–524 MHz)




Table 93: GTR 8000 Expandable Site Subsystem Expansion Cabinet Junction Panel Connections for Trunked IP Simulcast Site High Availability (700/800/900 MHz and UHF R2 435–524 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Expansion Input A RJ-45	Primary cabinet, network expansion sub-panel Cab # 1–5, A	LAN 1, RJ-45	Expansion link between RDM A and XHub A in expansion cabinet (N) where N is the number of the cabinet.
Expansion Input B RJ-45	Primary cabinet, network expansion sub-panel Cab # 1–5, B	LAN 1, RJ-45	Expansion link between RDM B and XHub B in expansion cabinet (N) where N is the number of the cabinet.
Network AUX A, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site.


Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Network AUX B, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site.
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
V.24-1 through 6, RJ-45	External DIU, site gateway (digital CCGW), channel bank, or base radio (for conventional channels)	RJ-45	Connection of V.24 link from BR to DIU, site gateway (digital CCGW) device, or channel bank. The conventional base radio and/or site gateway (digital CCGW) can be external or integrated into the cabinet. This port is used to connect them when one is integrated and the other is not.
Wireline-1 through 6, RJ-45	External DIU, site gateway (analog CCGW), or analog conventional base radio	RJ-45	Connection of Wireline link from BR to DIU or site gateway (analog CCGW) device. The conventional base radio and/or site gateway (analog CCGW) can be external or integrated into the cabinet. This port is used to connect them when one is integrated and the other is not.
ASync			Not in use
Rx-A, N-type	Receive antenna A/tower top amplifier or Receive expansion	TTA input port	RF coax to receive branch A.
Rx-B, N-type	Receive antenna B / tower top amplifier	TTA input port	RF coax to receive branch B. Used if diversity operation for Phase 2 TDMA is required.
Tx, 7/16	Transmit antenna for cavity combiner	Tx output port	RF coax to transmit antenna.
Tx 1, N female (900 MHz only)	Transmit antenna for hybrid combiner	Tx output port	RF coax to transmit antenna.
Tx 2, N female (900 MHz only)	Transmit antenna for hybrid combiner (optional)	Tx output port	RF coax to transmit antenna.
Internal Alarm, DB-25			Not in use

Junction Panel Connections for a Trunked IP Simulcast Site (UHF R1 380–435 MHz and VHF 136–174 MHz) (High Availability)

In a GTR 8000 Expandable Site Subsystem operating in the UHF R1 and VHF bands, most external equipment is connected through the junction panel. Each of the six Tx outputs is connected with a cable from a power amplifier in the GTR 8000 Expandable Site Subsystem to a jumper cable that connects to the Tx RFDS. The RF connections are also illustrated in [GTR 8000 Expandable Site Subsystem RFDS Transmit Path on page 61](#) and [GTR 8000 Expandable Site Subsystem RFDS Receive Path on page 62](#).

Figure 104: Junction Panel for the GTR 8000 Expandable Site Subsystem Prime Cabinet for Trunked IP Simulcast Site High Availability (UHF R1 380–435 MHz and VHF 136–174 MHz)



A25_GTR8000_JP_ESS_Prime_Conv_VHF_UHFR1B



NOTICE: For HPD Overlay sites, the Gateway A and B ports in the HPD rack/cabinet connect to the LAN via Network AUX ports in the trunked simulcast site and not to a Gateway directly.

Table 94: GTR 8000 Expandable Site Subsystem Prime Cabinet Junction Panel Connections for Trunked IP Simulcast Site High Availability (UHF R1 380–435 MHz and VHF 136–174 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Gateway A port, RJ-45	Primary Site Gateway	LAN 1, RJ-45	Ethernet link between RDM A and the primary site gateway or primary site gateway to link.

Table continued...


Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Gateway B port, RJ-45	Secondary Site Gateway (optional)	LAN 1, RJ-45	Ethernet link between RDM B and secondary site gateway or secondary site gateway to link (if installed).
Network AUX A, RJ-45	MOSCAD NFM	LAN Port 1, RJ-45	Ethernet link for MOSCAD NFM.
Network AUX B, RJ-45	Auxiliary site equipment such as a site gateway	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a site gateway if it is included at the site. If a site gateway is integrated into the prime cabinet, it connects directly to the Net AUX port on RDM B.
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
Remote GPS A, DB-15	Lightning Arrestor / GPS Unit A	Line terminals	See GPS Lightning Arrestor for terminal connection details on the lightning arrestor.
Remote GPS B, DB-15	Lightning Arrestor / GPS Unit B	Line terminals	See GPS Lightning Arrestor for terminal connection details on the lightning arrestor.
V.24-1 through 6, RJ-45	External DIU, site gateway (digital CCGW), channel bank, or base radio (for conventional channels)	RJ-45	Connection of V.24 link from BR to DIU, site gateway (digital CCGW) device, or channel bank. The conventional base radio and/or site gateway (digital CCGW) can be external or integrated into the prime cabinet. This port is used to connect them when one is integrated and the other is not.
Wireline-1 through 6, RJ-45	External DIU, site gateway (analog CCGW), or analog conventional base radio	RJ-45	Connection of Wireline link from BR to DIU or site gateway (analog CCGW) device. The conventional base radio and/or site gateway (analog CCGW) can be external or integrated into the prime cabinet. This port is used to connect them when one is integrated and the other is not.
ASYNCR			Not in use
RX 1 through 6, BNC	External Receive Multi-coupler	RMC output Port	RF coax to receive input for each BR.
TX 1 through 6, N-type	Tx combiner	Tx input port	RF coax output from each BR to Tx combiner.

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Tx, 7/16	Transmit antenna	Tx output port	RF coax to transmit antenna if PMU option is included. Tx output from external combiner must be routed directly to PMU input.
Cab #1-5, A, RJ-45	RDM A	Expansion Ports 1-5, RJ-45	Connection of RDM A to XHub A in expansion cabinets #1-5.
Cab #1-5, B, RJ-45	RDM B	Expansion Ports 1-5, RJ-45	Connection of RDM B to XHub B in expansion cabinets #1-5.
Internal Alarm, DB-25			Not in use
Ext. Freq. Reference			Not in use
1PPS			Not in use

*See [GTR 8000 Base Radio Time and Frequency Inputs on page 292](#).

Figure 105: Junction Panel for the GTR 8000 Expandable Site Subsystem Expansion Cabinet for Trunked IP Simulcast Site High Availability (UHF R1 380–435 MHz and VHF 136–174 MHz)



A25_GTR_8000_JP_ESS_Expansion_VHF_UHFR1B

Table 95: GTR 8000 Expandable Site Subsystem Expansion Cabinet Junction Panel Connections for Trunked IP Simulcast Site High Availability (UHF R1 380–435 MHz and VHF 136–174 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Expansion Input A RJ-45	Primary cabinet, network expansion sub-panel Cab #1-5, A	LAN 1, RJ-45	Expansion link between RDM A and XHub A in expansion cabinet (N) where N is the number of the cabinet.
Expansion Input B RJ-45	Primary cabinet, network expansion sub-panel Cab #1-5, B	LAN 1, RJ-45	Expansion link between RDM B and XHub B in expansion cabinet (N) where N is the number of the cabinet.
Network AUX A, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site.
Network AUX B, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site.
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
V.24-1 through 6, RJ-45	External DIU, site gateway (digital CCGW), channel bank, or base radio (for conventional channels)	RJ-45	Connection of V.24 link from BR to DIU, site gateway (digital CCGW) device or channel bank. The conventional base radio and/or site gateway (digital CCGW) can be external or integrated into the cabinet. This port is used to connect them when one is integrated and the other is not.
Wireline-1 through 6, RJ-45	External DIU, site gateway (analog CCGW), or analog conventional base radio	RJ-45	Connection of Wireline link from BR to DIU or site gateway (analog CCGW) device. The conventional base radio and/or site gateway (analog CCGW) can be external or integrated into the cabinet. This port is used to connect them when one is integrated and the other is not.
ASync			Not in use
RX '1' through 6, BNC	External Receive Multi-coupler	RMC output port	RF coax to receive input for each BR.
TX 1 through 6, N-type	Tx combiner	Tx input port	RF coax output from each BR to Tx combiner.

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Tx, 7/16	Transmit antenna	Tx output port	RF coax to transmit antenna if PMU option is included. Tx output from external combiner must be routed directly to PMU input.
Internal Alarm, DB-25			Not in use

Junction Panel Connections for a Conventional Simulcast Cabinet Within a Trunked IP Simulcast High Availability Site

The junction panel for the GTR 8000 Expandable Site Subsystem provides locations for many of the connections to external devices when a conventional GTR 8000 Expandable Site Subsystem cabinet resides within a trunked IP simulcast high availability site. Cables provided by Motorola include the specific connectors for the junction panel on one end and the subsystem equipment on the other end.



IMPORTANT: Do not remove the label from a connector location until you insert the connector.



NOTICE: For an overview of connecting to an ASTRO® 3.1 Conventional System (ASTRO-TAC 3000 Comparator or DIU), see the *Conventional Operations* manual. The base radio can be IP managed while using the 4-wire/V.24 interface for channel traffic.

Junction Panel Connections for a Conventional Simulcast Cabinet within a Trunked IP Simulcast High Availability Site (700/800/900 MHz and UHF R2 435–524 MHz)

In the GTR 8000 Expandable Site Subsystem, the junction panel is the primary location of connections to external equipment. The RF connections are also illustrated in [GTR 8000 Expandable Site Subsystem RFDS Transmit Path on page 61](#) and [GTR 8000 Expandable Site Subsystem RFDS Receive Path on page 62](#).

Figure 106: Junction Panel for a Simulcast Conventional GTR 8000 Expandable Site Subsystem Cabinet within a Trunked IP Simulcast High Availability Site (700/800/900/UHF R2 435–524 MHz)




Table 96: Simulcast Conventional GTR 8000 Expandable Site Subsystem Junction Panel Connections within a Trunked IP Simulcast High Availability Site (700/800/900/UHF R2 435–524 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Expansion Input A RJ-45	Primary cabinet, network expansion sub-panel Cab # 1-5, A	LAN 1, RJ-45	Expansion link between RDM A and XHub A in expansion cabinet (N) where N is the number of the cabinet.
Expansion Input B RJ-45	Primary cabinet, network expansion sub-panel Cab # 1-5, B	LAN 1, RJ-45	Expansion link between RDM B and XHub B in expansion cabinet (N) where N is the number of the cabinet.
Network AUX A, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site.

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Network AUX B, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site.
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
V.24-1 through 6, RJ-45	External DIU, site gateway (digital CCGW), or channel bank	RJ-45	Connection of V.24 link from BR to DIU, site gateway (digital CCGW) device, or channel bank. If more than six connections are required, then cables may need to be run through the access hole provided.
Wireline-1 through 6, RJ-45	External DIU, site gateway (analog CCGW), or analog comparator	RJ-45	Connection of Wireline link from BR to DIU, site gateway (analog CCGW) device, or analog comparator. If more than six connections are required, then cables may need to be run through the access hole provided.
ASync, RJ-45			Not in use
Rx-A, N-type	Receive antenna A/tower top amplifier or Receive expansion	TTA input port	RF coax to receive branch A.
Rx-B, N-type	Receive antenna B / tower top amplifier	TTA input port	RF coax to receive branch B. Used if diversity option for Phase 2 TDMA is needed.
Tx, 7/16	Transmit antenna for cavity combiner	Tx output port	RF coax to transmit antenna.
Tx 1, N female (900 MHz only)	Transmit antenna for hybrid combiner	Tx output port	RF coax to transmit antenna.
Tx 2, N female (900 MHz only)	Transmit antenna for hybrid combiner (optional)	Tx output port	RF coax to transmit antenna.
Internal Alarm, DB-25			Not in use

Junction Panel Connections for a Conventional Simulcast Cabinet within a Trunked IP Simulcast High Availability Site (UHF R1 380–435 MHz and VHF 136–174 MHz)

In a GTR 8000 Expandable Site Subsystem operating in the UHF R1 and VHF bands, most external equipment is connected through the junction panel. Each of the six Tx outputs is connected with a cable from a power amplifier in the GTR 8000 Expandable Site Subsystem to the junction panel that

connects to the Tx RFDS. The RF connections are also illustrated in [GTR 8000 Expandable Site Subsystem RFDS Transmit Path on page 61](#) and [GTR 8000 Expandable Site Subsystem RFDS Receive Path on page 62](#).

Figure 107: Junction Panel for a Conventional Simulcast GTR 8000 Expandable Site Subsystem Cabinet within a Trunked IP Simulcast High Availability Site (UHF R1 380–435 MHz and VHF 136–174 MHz)




Table 97: Conventional Simulcast GTR 8000 Expandable Site Subsystem Junction Panel Connections within a Trunked IP Simulcast High Availability Site (UHF R1 380–435 MHz and VHF 136–174 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Expansion Input A	Primary cabinet, network expansion sub-panel Cab # 1-5, A	LAN 1, RJ-45	Expansion link between RDM A and Expansion Hub A in expansion cabinet (N) where N is the number of the cabinet.
Expansion Input B	Primary cabinet, network expansion sub-panel Cab # 1-5, B	LAN 1, RJ-45	Expansion link between RDM B and Expansion Hub B in expansion cabinet (N) where N is the number of the cabinet.
V.24-1 through 6, RJ-45	External DIU, site gateway (digital CCGW), or channel bank	RJ-45	Connection of V.24 link from BR to DIU, site gateway (digital CCGW) device, or channel bank. If more than six connections are required, then cables may need to be run through the access hole provided.

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Wireline-1 through 6, RJ-45	External DIU, site gateway (analog CCGW), or analog comparator	RJ-45	Connection of Wireline link from BR to DIU, site gateway (analog CCGW) device, or analog comparator. If more than six connections are required, then cables may need to be run through the access hole provided.
ASYNCR			Not in use
Network AUX A, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site.
Network AUX B, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site.
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
RX '1' through 6 BNC	External Receive Multi-coupler	RMC output Port	RF coax to receive input for each BR.
TX 1 through 6 N-type	Tx combiner	Tx input port	RF coax output from each BR to Tx combiner.
Tx, 7/16	Transmit antenna	Tx output port	RF coax to transmit antenna if PMU option is included. Tx output from external combiner must be routed directly to PMU input.
Internal Alarm, DB-25			Not in use

Junction Panel Connections for a Conventional Cabinet Within a Conventional Site

The junction panel for the GTR 8000 Expandable Site Subsystem provides locations for all the connections to external devices when a conventional GTR 8000 Expandable Site Subsystem cabinet resides within a conventional site. Cables provided by Motorola include the specific connectors for the junction panel on one end and the subsystem equipment on the other end.



IMPORTANT: Do not remove the label from a connector location until you insert the connector.




NOTICE: For an overview of connecting to an ASTRO® 3.1 Conventional System (ASTRO-TAC 3000 Comparator or DIU), see the *Conventional Operations* manual. The base radio can be IP managed while using the 4-wire/V.24 interface for channel traffic.

Junction Panel Connections for a Conventional Cabinet within a Conventional Site (700/800/900 MHz and UHF R2 435–524 MHz)

In the GTR 8000 Expandable Site Subsystem, the junction panel is the primary location of connections to external equipment. The RF connections are also illustrated in [GTR 8000 Expandable Site Subsystem RFDS Transmit Path on page 61](#) and [GTR 8000 Expandable Site Subsystem RFDS Receive Path on page 62](#).

Figure 108: Junction Panel for a Conventional GTR 8000 Expandable Site Subsystem Cabinet within a Conventional Site (700/800/900 MHz and UHF R2 435–524 MHz)



IP_Sim_GTR8000_JP_ESS_Prime_Conv_700_800_900_UHFR2A

Table 98: Conventional GTR 8000 Expandable Site Subsystem Junction Panel Connections within a Conventional Site (700/800/900 MHz and UHF R2 435–524 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
LAN A port, RJ-45	Switch	LAN 1, RJ-45	Ethernet link to the LAN switch to remote site gateway.
LAN B port, RJ-45			Not in use

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
1PPS, BNC*	TRAK 9100	Timing, BNC	Connect external Site Timing Reference Required for simulcast
Freq Ref, BNC*	TRAK 9100 5 MHz frequency reference	RF, BNC	Connect external Site Frequency Reference Required for simulcast
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
V.24-1 through 6, RJ-45	External DIU, site gateway (digital CCGW), or channel bank	RJ-45	Connection of V.24 link from BR to DIU, site gateway (digital CCGW) device, or channel bank. If more than six connections are required, then cables may need to be run through the access hole provided.
Wireline-1 through 6, RJ-45	External DIU, site gateway (analog CCGW), or analog comparator	RJ-45	Connection of Wireline link from BR to DIU, site gateway (analog CCGW) device, or analog comparator. If more than six connections are required, then cables may need to be run through the access hole provided.
ASYN			Not in use
Rx-A, N-type	Receive antenna A / tower top amplifier	TTA input port	RF coax to receive branch A.
Rx-B, N-type	Receive antenna B / tower top amplifier	TTA input port	RF coax to receive branch B. Used if diversity option for Phase 2 TDMA is required.
Tx, 7/16	Transmit antenna for cavity combiner	Tx output port	RF coax to transmit antenna.
Tx 1, N female (900 MHz only)	Transmit antenna for hybrid combiner	Tx output port	RF coax to transmit antenna.
Tx 2, N female (900 MHz only)	Transmit antenna for hybrid combiner (optional)	Tx output port	RF coax to transmit antenna.
Cab #1-3, Branch A, BNC	Expansion cabinet #1-3 Receive Input Branch 'A'.	Rx A, N	Receive path connection from the primary cabinet to the Rx Branch 'A' connector of expansion cabinets #1-3.
Cab #1-3, Branch B, BNC	Expansion cabinet #1-3 Receive Input Branch 'B'.	Rx B, N	Receive path connection from the primary cabinet to the Rx Branch 'B' connector of expansion cabinets #1-3.
Internal Alarm, DB-25			May connect MOSCAD NFM to pin-22 and 23 for contact closure. Indicates RMC failure.

* See [GTR 8000 Base Radio Time and Frequency Inputs on page 292](#). The XHubs need both Time and Frequency references that are provided with either a Composite (5 MHz + 1PPS) or separate 5 MHz and 1PPS sources. For a separate 5 MHz reference, connect to the Ext Freq Ref port on each cabinet/rack. For a separate 1PPS reference, connect to the 1PPS port on each cabinet/rack. For a Composite reference, connect to the Ext Freq Ref port only on each cabinet/rack.

Both Ext Freq Ref and 1PPS inputs must have a BNC “T” connected. A 50 Ohm termination is on one leg of the “T” and the cable to the junction panel is on the other side of the “T”.

Junction Panel Connections for a Conventional Cabinet within a Conventional Site (UHF R1 380–435 MHz and VHF 136–174 MHz)

In a GTR 8000 Expandable Site Subsystem operating in the UHF R1 and VHF bands, most external equipment is connected through the junction panel. Each of the six Tx outputs is connected with a cable from a power amplifier in the GTR 8000 Expandable Site Subsystem to a jumper cable that connects to the Tx RFDS. The RF connections are also illustrated in [GTR 8000 Expandable Site Subsystem RFDS Transmit Path on page 61](#) and [GTR 8000 Expandable Site Subsystem RFDS Receive Path on page 62](#).

Figure 109: Junction Panel for a Conventional GTR 8000 Expandable Site Subsystem Cabinet within a Conventional Site (UHF R1 380–435 MHz and VHF 136–174 MHz)




Table 99: Conventional GTR 8000 Expandable Site Subsystem Junction Panel Connections within a Conventional Site (UHF R1 380–435 MHz and VHF 136–174 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
LAN A port, RJ-45	Switch	LAN 1, RJ-45	Ethernet link to the LAN switch to remote site gateway.
LAN B port, RJ-45			Not in use
1PPS, BNC*	TRAK 9100	Timing	Connect external Site Timing Reference Required for simulcast
Freq Ref, BNC*	TRAK 9100 5 MHz frequency reference	RF, BNC	Connect external Site Frequency Reference Required for simulcast
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
V.24-1 through 6, RJ-45	External DIU, site gateway (digital CCGW), or channel bank	RJ-45	Connection of V.24 link from BR to DIU, site gateway (digital CCGW) device or channel bank. If more than six connections are required, then cables may need to be run through the access hole provided.
Wireline-1 through 6, RJ-45	External DIU, site gateway (analog CCGW), or analog comparator	RJ-45	Connection of Wireline link from BR to DIU, site gateway (analog CCGW) device or analog comparator. If more than six connections are required, then cables may need to be run through the access hole provided.
ASYN			Not in use
RX 1 through 6, BNC	External Receive Multi-coupler	RMC output Port	RF coax to receive input for each BR.
TX 1 through 6, N-type	Tx combiner	Tx input port	RF coax output from each BR to Tx combiner.
Tx, 7/16			Not in use
Internal Alarm, DB-25			May connect MOSCAD NFM to pin-22 and 23 for contact closure. Indicates RMC failure.

* See [GTR 8000 Base Radio Time and Frequency Inputs on page 292](#). The XHubs need both Time and Frequency references that are provided with either a Composite (5 MHz + 1PPS) or separate 5 MHz and 1PPS sources. For a separate 5 MHz reference, connect to the Ext Freq Ref port on each cabinet/rack. For a separate 1PPS reference, connect to the 1PPS port on each cabinet/rack. For a Composite reference, connect to the Ext Freq Ref port only on each cabinet/rack.

Both Ext Freq Ref and 1PPS inputs must have a BNC “T” connected. A 50 Ohm termination is on one leg of the “T” and the cable to the junction panel is on the other side of the “T”.

Junction Panel Connections for a Trunked 3600 IntelliRepeater Site

A trunked 3600 IntelliRepeater site uses GPB 8000 Reference Distribution Modules (RDMs) instead of XHubs in the first cabinet/rack. The RDM provides integrated Ethernet LAN switching and redundant integrated time and frequency reference sources to all the base radios at the site.

The junction panel for the GTR 8000 Expandable Site Subsystem provides locations for all the connections to external devices. Cables provided by Motorola include the specific connectors for the junction panel on one end and the subsystem equipment on the other end.




IMPORTANT: Do not remove the label from a connector location until you insert the connector.

Junction Panel Connections for a Trunked 3600 IntelliRepeater Site (800/900 MHz and UHF R2 435–524 MHz)

In the GTR 8000 Expandable Site Subsystem, the junction panel is the primary location of connections to external equipment. The RF connections are also illustrated in [GTR 8000 Expandable Site Subsystem RFDS Transmit Path on page 61](#) and [GTR 8000 Expandable Site Subsystem RFDS Receive Path on page 62](#).

Figure 110: Junction Panel for the GTR 8000 Expandable Site Subsystem Prime Cabinet for a Trunked 3600 IntelliRepeater Site (800/900 MHz and UHF R2 435–524 MHz)



A25_GTR8000_JP_ESS_Prime_Conv_700_800_900_UHFR2E

Table 100: GTR 8000 Expandable Site Subsystem Prime Cabinet Junction Panel Connections for a Trunked 3600 IntelliRepeater Site (800/900 MHz and UHF R2 435–524 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Gateway A port, RJ-45	Primary Site Gateway	LAN 1, RJ-45	Ethernet link between RDM A and the primary site gateway or primary site gateway to site link.
Gateway B port, RJ-45	Secondary Site Gateway (optional)	LAN 1, RJ-45	Ethernet link between RDM B and secondary site gateway or secondary site gateway to site link (if installed).

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Network AUX A, RJ-45			Not in use
Network AUX B, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site. If a site gateway (CCGW) is integrated into the prime cabinet, it connects directly to the Net AUX port on RDM B.
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
Remote GPS A, DB-15			Not in use
Remote GPS B, DB-15			Not in use
V.24-1 through 6, RJ-45	Channel Bank	RJ-45	Connection of V.24 link from base radio to channel bank.
Wireline-1 through 6, RJ-45	Channel Bank	RJ-45	Connection of Wireline link from BR to channel bank.
ASYNC, RS-232, RJ-45	Channel Bank	RJ-45	ASYNC RS-232 connection to the zone controller.
Rx-A, N-type	Receive antenna A / tower top amplifier	TTA input port	RF coax to receive branch A.
Rx-B, N-type	Receive antenna B / tower top amplifier	TTA input port	RF coax to receive branch B. Used if diversity operation for Phase 2 TDMA is required.
Tx, 7/16	Transmit antenna for cavity combiner	Tx output port	RF coax to transmit antenna.
Tx 1, N female (900 MHz only)	Transmit antenna for hybrid combiner	Tx output port	RF coax to transmit antenna.
Tx 2, N female (900 MHz only)	Transmit antenna for hybrid combiner (optional)	Tx output port	RF coax to transmit antenna.

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Cab #1-5, A, RJ-45	RDM A	Expansion Ports 1–5, RJ-45	Connection of RDM A to XHub A in expansion cabinets #1-5.
Cab #1-5, B, RJ-45	RDM B	Expansion Ports 1–5, RJ-45	Connection of RDM B to XHub B in expansion cabinets #1-5.
Cab #1-3, Branch A, BNC	Expansion cabinet #1-3 Receive Input Branch 'A'.	Rx A, N	Receive path connection from the primary cabinet to the Rx Branch 'A' connector of expansion cabinets #1-3.
Cab #1-3, Branch B, BNC	Expansion cabinet #1-3 Receive Input Branch 'B'.	Rx B, N	Receive path connection from the primary cabinet to the Rx Branch 'B' connector of expansion cabinets #1-3.
Internal Alarm, DB-25			Not in use
Ext. Freq. Reference			Not in use
1PPS			Not in use

Figure 111: Junction Panel for the GTR 8000 Expandable Site Subsystem Expansion Cabinet for a Trunked 3600 IntelliRepeater Site (800/900 MHz and UHF R2 435–524 MHz)




Table 101: GTR 8000 Expandable Site Subsystem Expansion Cabinet Junction Panel Connections for a Trunked 3600 IntelliRepeater Site (800/900 MHz and UHF R2 435–524 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Expansion Input A RJ-45	Primary cabinet, network expansion sub-panel Cab # 1–5, A	LAN 1, RJ-45	Expansion link between RDM A and XHub A in expansion cabinet (N) where N is the number of the cabinet.
Expansion Input B RJ-45	Primary cabinet, network expansion sub-panel Cab # 1–5, B	LAN 1, RJ-45	Expansion link between RDM B and XHub B in expansion cabinet (N) where N is the number of the cabinet.
Network AUX A, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site.


Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Network AUX B, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site.
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
V.24-1 through 6, RJ-45	Channel Bank	RJ-45	Connection of V.24 link from base radio to channel bank.
Wireline-1 through 6, RJ-45	Channel Bank	RJ-45	Connection of Wireline link from base radio to channel bank.
ASYNCRS-232, RJ-45			Not in use
Rx-A, N-type	Receive antenna A/tower top amplifier or Receive expansion	TTA input port	RF coax to receive branch A.
Rx-B, N-type	Receive antenna B / tower top amplifier	TTA input port	RF coax to receive branch B. Used if diversity operation for Phase 2 TDMA is required.
Tx, 7/16	Transmit antenna for cavity combiner	Tx output port	RF coax to transmit antenna.
Tx 1, N female (900 MHz only)	Transmit antenna for hybrid combiner	Tx output port	RF coax to transmit antenna.
Tx 2, N female (900 MHz only)	Transmit antenna for hybrid combiner (optional)	Tx output port	RF coax to transmit antenna.
Internal Alarm, DB-25			Not in use

Junction Panel Connections for a Trunked 3600 IntelliRepeater Site (UHF R1 380–435 MHz and VHF 136–174 MHz)

In the GTR 8000 Expandable Site Subsystem, the junction panel is the primary location of connections to external equipment. The RF connections are also illustrated in [GTR 8000 Expandable Site Subsystem RFDS Transmit Path on page 61](#) and [GTR 8000 Expandable Site Subsystem RFDS Receive Path on page 62](#).

Figure 112: Junction Panel for the GTR 8000 Expandable Site Subsystem Prime Cabinet for a Trunked 3600 IntelliRepeater Site (UHF R1 380–435 MHz and VHF 136–174 MHz)



A25_GTR8000_JP_ESS_Prime_Conv_VHF_UHFR1B


Table 102: GTR 8000 Expandable Site Subsystem Prime Cabinet Junction Panel Connections for a Trunked 3600 IntelliRepeater Site (UHF R1 380–435 MHz and VHF 136–174 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Gateway A port, RJ-45	Primary Site Gateway	LAN 1, RJ-45	Ethernet link between RDM A and the primary site gateway or primary site gateway to link.
Gateway B port, RJ-45	Secondary Site Gateway (optional)	LAN 1, RJ-45	Ethernet link between RDM B and secondary site gateway or secondary site gateway to link (if installed).
Network AUX A, RJ-45			Not in use
Network AUX B, RJ-45	Auxiliary site equipment such as a site gateway	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a site gateway if it is included at the site.

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
			If a site gateway is integrated into the prime cabinet, it connects directly to the Net AUX port on RDM B.
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
Remote GPS A, DB-15			Not in use
Remote GPS B, DB-15			Not in use
V.24-1 through 6, RJ-45	Channel Bank	RJ-45	Connection of V.24 link from base radio to channel bank.
Wireline-1 through 6, RJ-45	Channel Bank	RJ-45	Connection of Wireline link from base radio to channel bank.
ASYNC, RS-232, RJ-45	Channel Bank	RJ-45	ASYNC RS-232 connection to the zone controller.
RX 1 through 6, BNC	External Receive Multi-coupler	RMC output Port	RF coax to receive input for each BR.
TX 1 through 6, N-type	Tx combiner	Tx input port	RF coax output from each BR to Tx combiner.
Tx, 7/16	Transmit antenna	Tx output port	RF coax to transmit antenna if PMU option is included. Tx output from external combiner must be routed directly to PMU input.
Cab #1-5, A, RJ-45	RDM A	Expansion Ports 1-5, RJ-45	Connection of RDM A to XHub A in expansion cabinets #1-5.
Cab #1-5, B, RJ-45	RDM B	Expansion Ports 1-5, RJ-45	Connection of RDM B to XHub B in expansion cabinets #1-5.
Internal Alarm, DB-25			Not in use
Ext. Freq. Ref.			Not in use
1PPS			Not in use

Figure 113: Junction Panel for the GTR 8000 Expandable Site Subsystem Expansion Cabinet for a Trunked 3600 IntelliRepeater Site (UHF R1 380–435 MHz and VHF 136–174 MHz)



A25_GTR_8000_JP_ESS_Expansion_VHF_UHFR1B

Table 103: GTR 8000 Expandable Site Subsystem Expansion Cabinet Junction Panel Connections for a Trunked 3600 IntelliRepeater Site (UHF R1 380–435 MHz and VHF 136–174 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Expansion Input A RJ-45	Primary cabinet, network expansion sub-panel Cab #1-5, A	LAN 1, RJ-45	Expansion link between RDM A and XHub A in expansion cabinet (N) where N is the number of the cabinet.
Expansion Input B RJ-45	Primary cabinet, network expansion sub-panel Cab #1-5, B	LAN 1, RJ-45	Expansion link between RDM B and XHub B in expansion cabinet (N) where N is the number of the cabinet.
Network AUX A, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site.
Network AUX B, RJ-45	Auxiliary site equipment such as an external site gateway (CCGW)	LAN 1, RJ-45	This port is available for devices that need to be connected to the network, including a standalone site gateway (CCGW) if it is included at the site.

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
V.24-1 through 6, RJ-45	Channel Bank	RJ-45	Connection of V.24 link from base radio to channel bank.
Wireline-1 through 6, RJ-45	Channel Bank	RJ-45	Connection of Wireline link from base radio channel bank.
ASYNCRS-232, RJ-45			Not in use
RX '1' through 6, BNC	External Receive Multi-coupler	RMC output port	RF coax to receive input for each BR.
TX 1 through 6, N-type	Tx combiner	Tx input port	RF coax output from each BR to Tx combiner.
Tx, 7/16	Transmit antenna	Tx output port	RF coax to transmit antenna if PMU option is included. Tx output from external combiner must be routed directly to PMU input.
Internal Alarm, DB-25			Not in use

Junction Panel Connections for a Trunked 3600 Simulcast Subsystem

The junction panel for the GTR 8000 Expandable Site Subsystem provides locations for all the connections to external devices when a GTR 8000 Expandable Site Subsystem cabinet resides within a trunked 3600 simulcast subsystem. Cables provided by Motorola include the specific connectors for the junction panel on one end and the subsystem equipment on the other end.




IMPORTANT: Do not remove the label from a connector location until you insert the connector.

Junction Panel Connections – GTR 8000 Expandable Site Subsystem for a Trunked 3600 Simulcast Subsystem (800/900 MHz and UHF R2 435–524 MHz)

In the GTR 8000 Expandable Site Subsystem, the junction panel is the primary location of connections to external equipment. The RF connections are also illustrated in [GTR 8000 Expandable Site Subsystem RFDS Transmit Path on page 61](#) and [GTR 8000 Expandable Site Subsystem RFDS Receive Path on page 62](#).

Figure 114: Junction Panel for the GTR 8000 Expandable Site Subsystem for a Trunked 3600 Simulcast Subsystem (800/900 MHz and UHF R2 435–524 MHz)



3600_Sim_GTR8000_JP_ESS_Prime_Conv_700_800_900_UHFR2A

Table 104: GTR 8000 Expandable Site Subsystem Junction Panel Connections for a Trunked 3600 Simulcast Subsystem (800/900 MHz and UHF R2 435–524 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
LAN A port, RJ-45	Switch	LAN 1, RJ-45	Ethernet link to the LAN switch to remote site gateway.
LAN B port, RJ-45			Not in use
1PPS, BNC*	Simulcast Site Reference	Timing, BNC	Connect external Site Timing Reference
Freq Ref, BNC*	Simulcast Site Reference, 5 MHz frequency reference	RF, BNC	Connect external Site Frequency Reference
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
V.24-1 through 6, RJ-45	Channel Bank	RJ-45	Connection of V.24 link from base radio to channel bank for mixed mode or digital systems.

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Wireline-1 through 6, RJ-45			Not in use Optional connection from Wireline port on XCVR for colocated comparator sites.
ASYNC			Not in use
Rx-A, N-type	Receive antenna A / tower top amplifier	TTA input port	RF coax to receive branch A.
Rx-B, N-type	Receive antenna B / tower top amplifier	TTA input port	RF coax to receive branch B. Used if diversity option for Phase 2 TDMA is required.
Tx, 7/16	Transmit antenna for cavity combiner	Tx output port	RF coax to transmit antenna.
Tx 1, N female (900 MHz only)	Transmit antenna for hybrid combiner	Tx output port	RF coax to transmit antenna.
Tx 2, N female (900 MHz only)	Transmit antenna for hybrid combiner (optional)	Tx output port	RF coax to transmit antenna.
Cab #1-3, Branch A, BNC	Expansion cabinet #1-3 Receive Input Branch 'A'.	Rx A, N	Receive path connection from the primary cabinet to the Rx Branch 'A' connector of expansion cabinets #1-3.
Cab #1-3, Branch B, BNC	Expansion cabinet #1-3 Receive Input Branch 'B'.	Rx B, N	Receive path connection from the primary cabinet to the Rx Branch 'B' connector of expansion cabinets #1-3.
Trunking Control-1 through 6	Remote Trunking Controller (6809 or MTC 3600)	DB-25	Control signals from base radio to external trunking controller.
DSM-1 through 6	Channel Bank	RJ-45	DSM analog audio path connection to channel bank for trunked 3600 simulcast sites.
Internal Alarm, DB-25			Not in use

* See [GTR 8000 Base Radio Time and Frequency Inputs on page 292](#).

The XHubs need both Time and Frequency references that are provided with either a Composite (5 MHz + 1PPS) or separate 5 MHz and 1PPS sources. For a separate 5 MHz reference, connect to the Ext Freq Ref port on each cabinet/rack. For a separate 1PPS reference, connect to the 1PPS port on each cabinet/rack. For a Composite reference, connect to the Ext Freq Ref port only on each cabinet/rack.

Both Ext Freq Ref and 1PPS inputs must have a BNC "T" connected. A 50 Ohm termination is on one leg of the "T" and the cable to the junction panel is on the other side of the "T".

Junction Panel Connections – GTR 8000 Expandable Site Subsystem for a Trunked 3600 Simulcast Subsystem (UHF R1 380–435 MHz and VHF 136–174 MHz)

In a GTR 8000 Expandable Site Subsystem operating in the UHF R1 and VHF bands, most external equipment is connected through the junction panel. Each of the six Tx outputs is connected with a cable from a power amplifier in the GTR 8000 Expandable Site Subsystem to a jumper cable that connects to the Tx RFDS. The RF connections are also illustrated in [GTR 8000 Expandable Site Subsystem RFDS Transmit Path on page 61](#) and [GTR 8000 Expandable Site Subsystem RFDS Receive Path on page 62](#).

Figure 115: Junction Panel for the GTR 8000 Expandable Site Subsystem for a Trunked 3600 Simulcast Subsystem (UHF R1 380–435 MHz and VHF 136–174 MHz)




Table 105: GTR 8000 Expandable Site Subsystem Junction Panel Connections for a Trunked 3600 Simulcast Subsystem (UHF R1 380–435 MHz and VHF 136–174 MHz)

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
LAN A port, RJ-45	Switch	LAN 1, RJ-45	Ethernet link to the LAN switch to remote site gateway.
LAN B port, RJ-45			Not in use
1PPS, BNC*	Simulcast Site Reference	Timing	Connect external Site Timing Reference

Table continued...

Junction Panel Port / Type	External Device This Connects To:	External Device Port / Type	Description
Freq Ref, BNC*	Simulcast Site Reference, 5 MHz frequency reference	RF, BNC	Connect external Site Frequency Reference
Battery Temp, 6-pin	Backup Battery Temperature Sensor		See battery temperature sensor instructions for connection requirements.
V.24-1 through 6, RJ-45	Channel Bank	RJ-45	Connection of V.24 link from base radio to channel bank.
Wireline-1 through 6, RJ-45			Not in use Optional connection from Wireline port on XCVR for colocated comparator sites.
ASYN			Not in use
RX 1 through 6, BNC	External Receive Multicoupler	RMC output Port	RF coax to receive input for each BR.
TX 1 through 6, N-type	Tx combiner	Tx input port	RF coax output from each BR to Tx combiner.
Trunking Control-1 through 6	Remote Trunking Controller (6809 or MTC 3600)	DB-25	Control signals from base radio to external trunking controller.
DSM-1 through 6	Channel Bank	RJ-45	DSM analog audio path connection to channel bank for trunked 3600 simulcast sites.
Tx, 7/16			Not in use
Internal Alarm, DB-25			Not in use

* See [GTR 8000 Base Radio Time and Frequency Inputs on page 292](#).

The XHubs need both Time and Frequency references that are provided with either a Composite (5 MHz + 1PPS) or separate 5 MHz and 1PPS sources. For a separate 5 MHz reference, connect to the Ext Freq Ref port on each cabinet/rack. For a separate 1PPS reference, connect to the 1PPS port on each cabinet/rack. For a Composite reference, connect to the Ext Freq Ref port only on each cabinet/rack.

Both Ext Freq Ref and 1PPS inputs must have a BNC “T” connected. A 50 Ohm termination is on one leg of the “T” and the cable to the junction panel is on the other side of the “T”.

Expansion to Net AUX Conversion Cables

To improve integration and reduce equipment at the site, the GTR 8000 Expandable Site Subsystem provides additional auxiliary network LAN ports to connect peripheral Ethernet capable devices at the site. These ports are labeled Network AUX or Net AUX at the junction panel. Examples of devices which can be connected to these Network AUX ports include: MOSCAD NFM, CCGWs, IP capable

standalone conventional radios, or connecting an HPD GTR 8000 Expandable Site Subsystem when overlaid with a repeater site or a trunked IP simulcast subsystem with high availability.

Network AUX ports are provided in cabinets/racks only for HPD, repeater, and trunked IP simulcast with high availability configurations. Two Network AUX ports are provided in the Primary Subpanel #1 contained in the prime cabinet (housing the GCP 8000 Site Controllers or GPB 8000 Reference Distribution Modules (RDM)) for each of these configuration types. In addition, two additional Network AUX ports are provided in the Expansion Subpanel #1 in each expansion cabinet added at a repeater site and a trunked IP simulcast high availability subsystem.

For systems where the quantity of peripheral devices exceeds the number of available Network AUX ports (due to no or low expansion cabinet quantities), a cable conversion kit has been created to convert the expansion link ports of the prime cabinet to standard Ethernet compliant Network AUX LAN ports. The expansion link ports in the Network Expansion subpanel, and connected to the Expansion Ports on the site controller or RDM, contain Frequency Reference and Timing Signaling in addition to LAN connectivity. These additional signals could cause adverse affects to peripheral devices connected to an expansion port. The Expansion to Net AUX conversion cable kit (CA01806AA) removes the extra signaling and provides the same 10/100 Mb Ethernet compliant interface found in other Network AUX connections. The expansion cable is blue, to differentiate it from the standard networking cables in the rack/cabinet. In addition, a blue "Net AUX" label is provided to add to the expansion panel labeling to indicate that a particular port has been converted. It is important to note that an expansion cabinet cannot be connected to a converted port. If site expansion requires the use of a converted Network AUX port, the conversion cable and label must be removed and the LAN cables provided with the expansion cabinet should be installed in their place.

Up to ten of the conversion cable kits can be added to the prime rack, though the amount is reduced by two for each expansion cabinet added to the site (the expansion cabinet has two Network AUX ports in its junction panel). These conversion cable kits are shipped bagged for installation at the site. If replacement or additional conversion kits are required they may be ordered through Motorola parts. See [GTR 8000 Expandable Site Subsystem FRU Procedures on page 347](#) for details on ordering.

GPS Unit Installation for a High Availability Configuration

Remote sites with GPB 8000 Reference Distribution Modules (RDMs) use GPS units that lock onto a GPS satellite system. The RDMs use the signals from the GPS unit to generate the time and frequency reference for the remote site. Alignment of timing is handled by each remote site independently locking to the GPS satellite system.

This section provides an overview and procedures for installing the GPS unit. In a trunked simulcast subsystem, the TRAK 9100 Simulcast Site Reference (SSR) at the prime site provides 1PPS and 5 MPPS signals to the RDMs from the GPS unit. This signal establishes timing functions for transmit and receive frequencies to the base radios.



IMPORTANT:

- Improper installation of the GPS unit (mainly reflection issues) can lead to improper position information, and is reported by the GPS unit.
- During initial startup, if the GPS unit is not locked onto at least four GPS satellites the simulcast system may not operate properly. These satellites are used to establish a three-dimensional fix (latitude, longitude, and altitude) for the site. Once the three-dimensional fix has been determined, only one GPS satellite is required to maintain proper operation.
- The RDMs can free-run for approximately four hours. However, after that period, the simulcast system will not operate properly without the GPS satellite signals. The GPS units must be properly positioned, and the cables and connectors must be properly maintained to ensure the operation of the simulcast system.
- Wait until the GPS units have locked onto the GPS satellites before verifying proper operation.

Installing the GPS Units

Follow this process to install the GPS units for a high-availability configuration.

Process:

- 1 Mount the GPS units with an unrestricted aerial down view to within ten degrees of the horizon in all directions.
- 2 Mount the GPS units high enough so they have an un-obstructed view of the sky. Adjacent structures (such as trees, buildings, and antenna towers) are considered obstructions. If an un-obstructed view is not possible, install the GPS units so they have a clear view of the appropriate sky region. Adjacent antenna towers at the RF site which protrude into the required region have a minimal effect on GPS unit reception due to their narrow, largely open profiles and are not considered obstructions.
 - For northern hemisphere installations, ensure that an un-obstructed view of the southern sky is maintained.
 - For southern hemisphere installations, ensure that an un-obstructed view of the northern sky is maintained.
- 3 Isolate the GPS units from RF interference by mounting the units at a distance of at least 3.66 m (12 ft) horizontally from the other units.
- 4 Validate the correctness of the position information (latitude, longitude, elevation) reported by the GPS unit. Proper timing operation is dependent on proper position identification.
- 5 Validate both GPB 8000 Reference Distribution Modules (RDMs) in the CSS Reference Service Screen and are within 250 nsec of each other. If not, verify the position information (latitude, longitude, elevation) reported by the GPS units on both RDMs.

GPS Equipment

The following equipment is required for an IP simulcast remote site configured for high availability. The GPS equipment should equal the number of GPB 8000 Reference Distribution Modules (RDMs) at the site with each item ordered in a quantity of two.

The following lists the equipment to install the GPS unit:

- GPS Antenna/Receiver: DS0900382701
- Mounting Kit for GPS Timing Unit: DS0900382701
- GPS Primary Surge Protector: DS0971017AA1
- GPS Antenna/Receiver to RDM Cable (125 FT): DS30C87465CO1
- GPS Antenna/Receiver to RDM Cable (350 FT): DS30C87465CO2
- GPS Antenna/Receiver to RDM Cable (500 FT): DS30C87465CO3
- GPS Antenna/Receiver to RDM Cable (1,000 FT): DS30C87465CO4

GPS Unit

The GPS unit includes the antenna and the receiver/modem. Because the actual receiver is integrated with the antenna, the connection between the GPS unit and the GPB 8000 Reference Distribution Module (RDM) is digital using a 6-pair twisted pair cable.

GPS Mounting Kit

This kit is required to mount the GPS unit. There should be one mounting kit for each GPB 8000 Reference Distribution Module (RDM) at the site.

Surge Suppression

This primary surge suppression is used at the point where the cable enters the site building. There should be one surge suppression for each GPB 8000 Reference Distribution Module (RDM) at the site. The surge suppression is installed by cutting the cable at the point where the cable enters the site building and connecting both ends to the surge suppressor.

GPS Cables

Choose the cable length required for the site configuration. One cable is required for each GPB 8000 Reference Distribution Module (RDM) at the site. These cables have a Deutsch connector at one end that connects to the GPS unit and a DB15 connector that connects to the RDM.

In a typical installation using 6-pair twisted pair cable, the recommended cable length should be 106.7 m (350 ft) or less. This cable length is sufficient for most installations. For cable lengths greater than 106.7 m (350 ft), contact Motorola Solution Support Center (SSC) for guidance on the installation and configuration.

Alarm Indication (No Lock on GPS Signal)

A system alarm indicates when the GPS signal cannot be located and that the GPS unit must be repositioned.

GPS Lightning Arrestor

A lightning arrestor must be installed between a GCP 8000 Site Controller or GPB 8000 Reference Distribution Module (RDM) and the GPS unit. One GPS unit is connected to each of the site controllers or RDMs. Each GPS unit requires its own arrestor. The lightning arrestor can be installed in an HPD or trunked IP simulcast remote site supporting a high availability configuration.

Figure 116: Lightning Arrestor – System Connections on page 240 shows the connections between the lightning arrestor and the GCP 8000 Site Controller or RDM.

Figure 116: Lightning Arrestor – System Connections




Figure 117: GPS Lightning Arrestor DS109-0129H-A Model Wiring on page 241 shows one possible configuration of the connections and terminal assignments for installing the DS109-0129H-A model lightning arrestor.

Figure 117: GPS Lightning Arrestor DS109-0129H-A Model Wiring





Figure 118: GPS Lightning Arrestor DS-IX-2L1M1DC48-IG Model Wiring on page 242 shows one possible configuration of the connections and terminal assignments for installing the DS-IX-2L1M1DC48-IG model lightning arrestor.

Figure 118: GPS Lightning Arrestor DS-IX-2L1M1DC48-IG Model Wiring



lightning_arrestor_2L1M1DC48

Installation/Troubleshooting Tools

In addition to the general tools needed for site installation activities, a service monitor is used specifically for testing the equipment.

To place an order, contact Motorola at:

Phone: 1-800-422-4210 ext. 6883

TTY Phone: 1-866-522-5210

Motorola Online users: Web: <https://businessonline.motorolasolutions.com>

Fax: 1-800-622-6210

Quick Connect RF Coaxial Adapters for GTR 8000 Base Radio Support

The GTR 8000 Base Radio employs a number of "QN" and "QMA" Quick-Connect RF connectors in its design. The following RF adapters are available from Motorola and can be used to connect test equipment to the various station devices for troubleshooting purposes.

Table 106: Quick-Connect RF Coaxial Adapters for GTR 8000 Base Radio Support

Type	Adapter / Connector description	Motorola Part Number
"N"/QN	Female "N" to Male QN	5886055Y01
"N"/QN	Female "N" to Female QN	5886055Y10
"N"/QN	Male "N" to Male "QN"	5886055Y05
QN	Right Angle Male QN cable plug for RG-400 coax	2871002H01
QN	Right Angle Male QN cable plug for RG-213 coax	2886067Y01
N/QMA	Female "N" to Male QMA	5886055Y06
N/QMA	Female "N" to Female QMA	5886055Y07
QMA/QMA	Female QMA to Female QMA	5886055Y08
QMA/QMA	Male QMA to Male QMA	5886055Y09
7/16/QN	Female 7/16 to male QN	5886055Y03
7/16/QN	Male 7/16 to Male QN	5886055Y02
7/16/QN	"Female 7/16 to female QN Intermod test adaptor"	5886055Y04
7/16/QN	"Male 7/16 to female QN Intermod test adaptor"	5886055Y11

Installing Device Software Prerequisites

When and where to use: The following tasks are required before you can complete the device software installation and begin the configuration procedures in the "Configuration" chapter.

Process:

- 1 Transfer and install new software to a device using the Software Download. See [Software Download on page 245](#).
- 2 Obtain the ASTRO® 25 system CDs and DVDs. Specifically, you need the Motorola Device OS Image CDs. See [Loading Device OS Images to the UNC on page 248](#).
- 3 Obtain user names, passwords, and procedures required to access the devices on the network. For specific user names and passwords to access devices on the network, contact your system administrator.
- 4 Set up the users in the IT Admin group in Active Directory Users and Computers. See the *Authentication Services* manual.
- 5 Obtain the following values from the system administrator:
 - Line interface number

- Zone Controller (ZC) site link path 1 IP address
- ZC site link path 2 IP address
- Host name to access the Unified Network Configurator (UNC) server application using Secure SHell (SSH) (<username> @IP address format)
- Site ID number
- IP address 1 and 2
- Primary and secondary NTP IP addresses



NOTICE: The following are applicable to systems with Authentication, Authorization, and Accounting (AAA) Servers, Domain Controllers, or Syslog Servers.

- Primary, secondary, and tertiary Domain Name Services (DNS) IP addresses
 - Requested DNS Domain Name
 - Requested DNS Host Name
 - System Name
 - Primary SYSLOG Service Name Fully Qualified Domain Name (FQDN)
 - Backup SYSLOG Service Name Fully Qualified Domain Name (FQDN)
 - Remote Authentication Dial-In User Service (RADIUS) FQDN parameter value
 - RADIUS Row Status parameter value
 - RADIUS Service Time Out (seconds) parameter value
 - RADIUS Service Retransmits Attempts parameter value
 - RADIUS Service Dead Timer (min) parameter value
 - RADIUS Specific Key parameter value
 - RADIUS Service Global Key parameter value
- 6** Obtain the default credentials (local accounts, central authentication, and SNMPv3) for the device being installed, as well as the updated passwords for those types of accounts (so that you can change the password after you install the device). Contact your system administrator, if you do not have this information. See the *SNMPv3* manual or see [Local Password and SNMPv3 Passphrase Troubleshooting on page 343](#) for more information.
- 7** Configure the device as a RADIUS client on the RADIUS server. When these devices are configured with a RADIUS key that matches a shared secret for that device in Microsoft Windows Internet Authentication Service (IAS), they become RADIUS clients. They do not join the Active Directory domain. See the *Authentication Services* manual for more information.
- 8**  **NOTICE:** This step is applicable to systems with AAA Servers, Domain Controllers, or Syslog Servers.

To use the VoyenceControl component of the Motorola centralized configuration application for any of the site device procedures, set up the UNC. Depending on your organizational policies, you may also need to implement a secure protocol between the UNC and the site device. Before performing any procedures using VoyenceControl, the device must be discovered in VoyenceControl, and the device configurations must be recently pulled to the UNC database. See the following ASTRO[®] 25 system documentation: *Unified Network Configurator* manual and *Securing Protocols with SSH* manual.

Software Download

The Software Download (SWDL) is an application that can transfer only, install only, or transfer and install new software to devices. The new software can be installed either locally at a site or on the Network Management subsystem. Individual devices not connected to the system can be downloaded using single device mode.

Software Download Security Transfer Modes

A software download can be performed using the following security transfer modes:

Clear SWDL

Transfers the software without security, based on the File-Transfer Protocol (FTP)

Secure SWDL

Transfers the software as encrypted, based on the Secure File-Transfer Protocol (SFTP)

Before initiating transfer, SWDL connects to the site in the zone to discover all devices. The transfer mode of all devices is displayed in the SWDL window. It is important that all devices have the same SWDL transfer mode. Otherwise, SWDL flags a mismatch of the SWDL transfer modes across site devices.

SWDL provisions the credentials for Secure SWDL as part of initiating the SWDL operation. No user intervention is required. For a single device, Secure or Clear SWDL is configured based on the SWDL Transfer Mode configuration within the Configuration/Service Software (CSS). The Unified Network Configurator (UNC) can be used to schedule and configure all devices in the system at once.

For information on how to configure the secure or clear SWDL transfer mode, see the *Unified Network Configurator* manual and “Device Security Configuration” in the *CSS Online Help*.

Software Download Transfer Methods

A software download can be accomplished in two ways:

Site Software Download

Allows you to transfer and install application software from any location within a network. The Software Download resides on the Network Management Client computer and a computer loaded with the CSS application. From either of the computers, you can select device types to download software. Site Software Download allows you to select the zone, site, device types, and software download operation to perform. When performing a site software download, the site controller coordinates the software transfer for all trunked base radios, receivers and/or comparators installed at the site. A site software download can only be performed on a trunked ASTRO[®] 25 system.

Single Device Software Download

Allows you to transfer and install software to a single instance of a device (such as one base radio). This feature gives the technician the ability to install different versions of software. Single device software download is done from a computer loaded with the CSS application either connected directly to the device or connected to the network.



NOTICE: Conventional devices, GPB 8000 Reference Distribution Modules, and 3600 base radios are supported only in single device software download.

Site Software Download Functionality

When SWDL is connected from a central remote location, SWDL performs a site software download to the site controllers, then to the comparators and base radios or receivers installed at the site. Both active and standby site controller modules have two flash memory banks for storing software. The device application is run from RAM, and is loaded from the active flash memory bank after a reset. One bank is active while the other bank is inactive. The transfer of the software using SWDL is a background process, without interruption of services at the site, that loads the software into the inactive bank. The site controller executes the software from one bank, while software is simultaneously

downloaded to the inactive bank. The transfer and install are done in the background. An install causes the site controller to reset and load the RAM from the bank that was installed with the new software.

SWDL communicates with the site controllers to determine the number of existing remote sites and the number of channels. SWDL considers a channel or remote site to be accessible if its status is “Not Unconfigured.” This term means that the site must be set up with a computer with CSS or a network management client before software download is performed on the site.

The system downloads software to the site controllers, comparators, base radios, or receivers as a unit. Use SWDL to transfer software to each device type, then perform an install operation. During the transfer, the operation designates a proxy for each device type at each LAN. Site controllers proxy for comparators, and base radios or receivers proxy for each other. The proxy cross-transfers the software to other devices on the LAN. Using proxies minimizes system downtime. Transfers to the LAN are done simultaneously except for the site controller and comparators.

Software installation is done on a channel-by-channel basis, starting with the highest number channel. When a channel software download occurs, the base radio or receiver which incorporates that channel is processed along with the comparator for that channel. For example, if channel 3 was being downloaded, comparator 3 and the base radios or receivers for channel 3 at each of the remote sites would be installed simultaneously.

SWDL operation can be fault managed through Unified Event Manager (UEM), syslog, local SWDL log files, user messages, and device reports.

For further information on SWDL, see the *Software Download* manual.

The operating software can also be loaded using the UNC. See the *Unified Network Configurator* manual to perform single device software downloads (ruthless download) to the devices.

See the *G-Series Equipment - System Release Configuration* manual for SWDL instructions specific to the operating characteristics of your existing system release.

Installing Devices in the UNC

When and where to use: The Unified Network Configurator (UNC) is the Network Manager used to discover a device and load Operating System images. This process lists the basic steps involved using the UNC on a device.



NOTICE: The UNC is not applicable for K core or non-networked sites.

Process:

- 1 Discover the device in the UNC. See [Discovering a Device in the UNC on page 247](#).
- 2 Log in to the UNC server application using PuTTY. See the *Securing Protocols with SSH* manual.
- 3 Load the operating system images to the UNC. See [Loading Device OS Images to the UNC on page 248](#).
- 4 Enable FTP services on the UNC. See [Enabling FTP Service on page 249](#).
- 5 Transfer and install the OS image to the device. See [Transferring and Installing the OS Image on page 249](#).
- 6 Inspect the device properties for the transferred and installed software. See [Inspecting Device Properties for Transferred and Installed Software on page 252](#).
- 7 Disable FTP services for the UNC. See [Disabling FTP Service on page 253](#).

Discovering a Device in the UNC

When and where to use:

The discovery process allows the Unified Network Configurator (UNC) to manage the site devices. Once the device is installed, configured through the Configuration/Service Software (CSS), and security parameters are enabled, follow this procedure to discover the device. The configuration information can then be updated using this configuration management application.

The UNC network management solution consists of two applications. Both the UNC Wizard and the VoyenceControl applications are used in this procedure.



NOTICE: The names EMC Smarts™ Network Configuration Manager and VoyenceControl are used interchangeably for this product.

Once the device is discovered in the UNC, the OS images and CSS configuration files can be loaded to add a device to a site, which then connects the site to the current ASTRO® 25 zone core.

Procedure:

- 1 Ensure that Domain Name Services (DNS) is functional on your system. DNS is supplied by a specific server application, which must be operational before you can discover the device.
- 2 Log on to the UNC Wizard from the Network Management (NM) client, by double-clicking the **Internet Explorer** icon on the desktop.
The Internet Explorer browser opens.
- 3 In the **Address** field, enter: `http://ucs-unc0<Y>.ucs:9443/UNCW`
where <Y> is the number of the UNC server (01 for primary core UNC server, and 02 for backup core UNC server).
The UNC Wizard launches and a login dialog box appears.
- 4 Type the administrative user name and password. Click **OK**.
The UNC Wizard appears.
- 5 From the list of available wizards on the left side, select **Subnet Discovery**.
The right side of the window is updated with the **Subnet Discovery** form.
- 6 Select **RF Site** by clicking the **Discovery Type** drop-down list.
- 7 Enter the **Zone ID** and the **Site ID**. Click **Submit**.
An auto-discovery job is created in the UNC Schedule Manager.
- 8 Log on to the UNC from the NM client by entering:
`http://ucs-unc0<Y>.ucs`
where <Y> is the number of the UNC server (01 for primary core UNC server, and 02 for backup core UNC server).
The UNC client launches and a login dialog box appears.
- 9 Type the administrative user name and password. Click **OK**.
VoyenceControl launches.



NOTICE: The names EMC Smarts™ Network Configuration Manager and VoyenceControl are used interchangeably for this product.

- 10 Press F7 (Schedule Manager).

The **Schedule Manager** window appears in the UNC with the discovery jobs.

- 11 Verify that the **Zone** and **Site** containers include any devices discovered.



IMPORTANT: No site devices should be in the **Lost and Found** folder. If any devices are in the folder, see the *Unified Network Configurator* manual for troubleshooting guidance.

- 12 In the UNC Wizard, verify the devices by selecting **Channel** under **RF Site Level Configuration**. If multiple zones exist, choose **Zone**.

The device sites are listed, which means they are available for channel configuration.

Loading Device OS Images to the UNC

Prerequisites: This procedure requires the Motorola device Operating System (OS) Image CDs. Locate the Transport OS Image media packaged with the Network Management DVDs.

When and where to use: This procedure loads the OS images for the devices for distribution through the Unified Network Configurator (UNC). Once OS images are distributed to the UNC, you can update the device Configuration/Service Software (CSS) configuration files to the UNC.

Procedure:

- 1 Launch a Secure SHell (SSH) terminal server session in PuTTY to access the UNC **Server Administration** menu. See the *Securing Protocols with SSH* manual.
- 2 From the UNC **Server Administration** menu, select **OS Images Administration**. Press ENTER.
- 3 From the **OS Images Administration** menu, select **Load new OS images**. Press ENTER.
A message appears indicating there are two methods for loading OS Images.
- 4 Insert the **Motorola Device OS Images** CD into the CD/DVD-ROM drive of the server.
The drive light starts blinking on the server.
- 5 When the drive light stops blinking, press ENTER.
The OS images load on the UNC.
- 6 From the menu, select **View OS Images**. Press ENTER.
The device software image appears.
- 7 From the menu, select **Eject CD**. Press ENTER.
The media ejects from the drive on the server.
- 8 Remove the **Motorola Device OS Images** CD from the CD/DVD-ROM drive of the server.
- 9 To log out of the server, press ENTER.
The **User Configuration Server Administration** menu appears.
- 10 Press ENTER again.
The prompt appears.

Loading Software to a Device



NOTICE: These procedures are for a single device download. For a site download, see [Software Download on page 245](#).

The following procedures describe how to load software images onto Unified Network Configurator (UNC) and download and install this software to the device. Secure protocols for software download is the preferred approach to transfer operations. However, as a backup option, FTP service can be enabled before installing the software.

Enabling FTP Service

When and where to use: Follow this procedure to enable FTP service before installing the OS software.

Procedure:

- 1 Launch a Secure SHell (SSH) terminal server session in PuTTY to access the Unified Network Configurator (UNC) **Server Administration** menu. See the *Securing Protocols with SSH* manual.
- 2 From the Server Administration menu, select **Unix Administration**. Press ENTER.
- 3 From the Unix Administration menu, select **FTP Services**. Press ENTER.
- 4 From the FTP Services menu, select **Enable FTP service**. Press ENTER.

The FTP Services are enabled and available for software transfer and install operations.

Transferring and Installing the OS Image

When and where to use: Use this procedure to download the OS from the Unified Network Configurator (UNC) to the device.

Procedure:

- 1 On the Private Network Management (PNM) client where you set up VoyenceControl, double-click the UNC shortcut on the desktop.

You can also paste the following address into an IE web browser: `http://ucs-unc0<Y>.ucs`, where <Y> is the number of the UNC server (01 for primary core UNC server, and 02 for backup core UNC server).

Internet Explorer opens to the URL of the application server, and a VoyenceControl client session launches with the welcome page.

Figure 119: VoyenceControl Welcome Page



 **NOTICE:** The names EMC Smarts™ Network Configuration Manager and VoyenceControl are used interchangeably for this product.


- 2 Click the **launch VoyenceControl™** link.
A VoyenceControl client session launches with the login window.

Figure 120: VoyenceControl Login Window



- 3 Enter the User ID and Password. Click **OK**.
The **VoyenceControl Dashboard** appears.

Figure 121: VoyenceControl Dashboard



- 4 In the left navigation pane, expand **Networks**, then select **ASTRO 25 Radio Network**, then **Views**.

The list of options expands.

- 5 From the navigation pane, double-click **Motorola <device>**.
The view opens and all currently discovered devices appear.

- 6 From the menu, select **Tools** → **OS Inventory**.
A list of the OS images appears.

- 7 Verify OS images loaded on the UNC server appear in the OS inventory.



NOTICE: These images were automatically created during the [Loading Device OS Images to the UNC on page 248](#) procedure.

- 8 Under **Networks** in the navigation pane, select one or more devices from the same device class by right-clicking the selections.
- 9 From the menu, select **Update OS Image**.

- 10 From the **Select OS Image** window, select **Software Image**. Click **Next**.

- 11 From the **Update OS Image** window, select each device that appears in the **Selected Devices** section.

This action associates a version to a device instance.



NOTICE: In most cases, the “summary of device partitions” are already set up and the values in step 11 through step 14 must be verified.

- 12 Select **nvm partition** from the **Manage Partition for Device** section.



NOTICE: Selecting **nvm partition** defines where the OS image is transferred and is the only choice for the device.

- 13 From the **Selected Image** section, select the image for this device.



NOTICE: Ignore the **Install** and **Copy** check boxes.

The **Image Info** tab is populated and informs the application which image to use.

- 14 Click **Add**.

The **Summary of Device Partitions for Device** populates and confirms the proper setup.

- 15 Select the **Device Options** section, **Software Operations**, then choose **transfer**, **install**, or **both**.

These selections indicate which operations occur when the job is executed.



NOTICE: If **transfer** is chosen, select the install option later to complete the installation. If **both** is chosen, the software is transferred and installed. There are up to two resets of the device during installation.

- 16 Click **Schedule**.

- 17 From the **Schedule Push Job** window, configure the schedule information. Click **Approve and Submit**.

The job is approved and can be viewed in the **Schedule Manager** window.



NOTICE: If only **Submit** is chosen, the job must be approved later.

- 18 Verify the job status by pressing F7 (Schedule Manager).

The **Schedule Manager** window appears in the UNC with the discovery jobs.

Inspecting Device Properties for Transferred and Installed Software

When and where to use: When the software has been transferred and installed, follow this procedure to inspect the device properties before assuming the installation was a success and disabling FTP service

Procedure:

- 1 From the **Device** view, right-click the device, select **Pull**, and then **Pull Hardware Spec**.

The current software version information is updated in the Unified Network Configurator (UNC).



NOTICE: Skip this step if a Pull All or Pull Hardware Spec has already occurred.

- 2 From the **Device** view, right-click on the device, and then choose **Properties**.

The **Device Properties** window appears.



NOTICE: Select the **Properties** icon to view the device properties appear directly within the **Device** view.

- 3 Choose the **Configuration** tab, and then the **Hardware** tab.

- 4 Double-click the **Chassis** object from the **Physical Hardware** properties.

- 5 From the **Chassis** property tree, view the following properties and their values:

- **Bnk1:**<device>: Transferred software in bank 1.
- **Bnk2:**<device>: Transferred software in bank 2.
- <device>: Installed and Running Software.



NOTICE: The Table format can be used (instead of the Diagram format) to view the Installed and Running Software in the **Device** view.

Disabling FTP Service

When and where to use: Follow this procedure to disable the FTP service after the transfer and installation of the software is completed.

Procedure:

- 1 Launch a Secure SHell (SSH) terminal server session in PuTTY to access the Unified Network Configurator (UNC) **UNC Server Administration** menu. See the *Securing Protocols with SSH* manual.
- 2 From the **UNC Server Administration** menu, select **Unix Administration**. Press ENTER.
- 3 From the Unix Administration menu, select **FTP Services**. Press ENTER.
- 4 From the **FTP Services** menu, select **Disable FTP service**. Press ENTER.
The FTP services are disabled and unavailable for software transfer and install operations.
- 5 To back out of the menus, press q three times.
- 6 At the prompt, enter: `exit` to return to the previous menu.
- 7 To log out of the application, enter: `exit`.
- 8 Close the PuTTY connection.

This page intentionally left blank.

Chapter 4

GTR 8000 Expandable Site Subsystem Configuration

This chapter details configuration procedures relating to the GTR 8000 Expandable Site Subsystem. Proper software/hardware configuration for the GTR 8000 Expandable Site Subsystem requires the following activities:

- Updating factory-installed GTR 8000 Base Radio, GCP 8000 Site Controller, and GPB 8000 Reference Distribution Module application software
- Setting parameters in a configuration file stored on the devices impact both the devices and RF Distribution System (RFDS) functionality
- Setting DIP switches on RFDS receive multicoupler/low noise amplifier (RMC/LNA) modules

Configuration Software

Configuring a device requires loading two software applications on the service computer: Configuration/Service Software (CSS) and Unified Network Configurator (UNC).

CSS

is used to configure the parameters on the device. CSS can access devices remotely over the network, or locally through an Ethernet/serial connection to the service port on the device or through a LAN switch. CSS also can be used to view status information, equalize batteries, and check internal logs of the equipment at the site. See the *CSS Online Help* for configuration details.

UNC Wizard

is a component of UNC used to configure the parameters of a site, subsite, and channel. See the *UNC Wizard Online Help* for configuration details.

VoyenceControl

is a component of UNC used to pull and push configurations and configure the parameters of the device. See the *Unified Network Configurator* manual for general information about using VoyenceControl functions.



NOTICE: While it is possible to configure a conventional device using the UNC, it is preferable to use CSS because configuration dependencies are enforced.

The UNC is not applicable for K core or non-networked sites.

All parameters are programmed locally when the site is installed but not linked to a network. Test all parameters before making the site available. The ability to locally program provides the means to test the site before making it available for system operation.

Discovering a Device in the UNC

When and where to use: Use these high-level steps to discover the devices in the Unified Network Configurator (UNC). See the *Unified Network Configurator* manual for details on discovering devices.

Process:

- 1 Use the UNC Discovery Wizard to:
 - Discover the devices.

- Upload configurations for the devices.
 - Generate changes for non-compliant devices.
- 2 Approve jobs (if any).

Security/Authentication Services

If the device supports SNMPv3 protocol, a pop-up dialog box appears displaying the SNMPv3 Password Prompt when logging in to a device through Configuration/Service Software (CSS) using an Ethernet connection. For configuration details, see the *Information Assurance Features Overview*, *Software Download*, and *SNMPv3* manuals. See [Figure 122: SNMPv3 Security Level Option Prompt on page 256](#).

Figure 122: SNMPv3 Security Level Option Prompt




The image shows a dialog box titled "SNMPv3 Passphrase Prompt". It is divided into two sections: "User Information" and "Passphrase Information".

- User Information:** Contains a "Username" field with the text "MotoCSS" and a "Security Level" dropdown menu currently set to "NoAuthNoPriv".
- Passphrase Information:** Contains two empty text input fields labeled "Authentication Passphrase" and "Encryption Passphrase".

At the bottom of the dialog are "Ok" and "Cancel" buttons. A status bar at the very bottom of the window contains the text "Select user security level."

A pop-up window appears displaying the File Transfer Access Services for CSS. Use this logon when communicating to a device through CSS using either an Ethernet or DB-9 Serial Port connection. See [Figure 123: CSS Login Banner on page 257](#).

Figure 123: CSS Login Banner



Device Configuration in CSS

This section covers configuration of a device using the Configuration/Service Software (CSS).



NOTICE: The IP address for the device is available through a serial port connection in the **Tools** → **Set IP Address** from the CSS menu.

Initially Configuring a Device in CSS

When and where to use: Use this process to initially configure a device in CSS

Process:

- 1 Perform the following configuration steps that require a serial connection. See [Connecting Through a Serial Port Link on page 258](#).
 - a Set the IP address and pairing number of the device. See [Setting the Device IP Address and Pairing Number in CSS on page 260](#).
 - b Set the serial security services. See [Setting the Serial Security Services in CSS on page 261](#).
- 2 Perform the following configuration steps that require an Ethernet connection. See [Connecting Through an Ethernet Port Link on page 262](#).
 - a Set the pairing number of the device. See [Setting the BR/CM Pairing Number in CSS on page 265](#).
 - b Set the current date and time of the device. See [Setting the Date and Time in CSS on page 265](#).
 - c Change the SNMPv3 configuration and user credentials of a device in the site. See [Changing SNMPv3 Configuration and User Credentials in CSS on page 265](#).
 - d Create, update, or delete an SNMPv3 user on a device. See [Adding or Modifying an SNMPv3 User in CSS on page 268](#).
 - e Verify the SNMPv3 credentials on a device. See [Performing an SNMPv3 Connection Verification in CSS on page 268](#).
 - f Configure DNS using the CSS. See Chapter 7, “Configuring DNS in CSS” in the Authentication Services manual.

- g Set the SWDL transfer mode. See [Setting the SWDL Transfer Mode in CSS on page 269](#).
 - h Configure for SSH. See the *Securing Protocols with SSH* manual, "Configuring SSH for RF Site Devices and VPMs in CSS" section in Chapter 4.
 - i Enable RADIUS Authentication on a device. See Chapter 7, "Configuring RADIUS Sources and Parameters in CSS" in the *Authentication Services* manual. Make sure that the devices have been added to the RADIUS servers on the domain controllers as RADIUS clients.
 - j Enable Centralized Authentication on a device. See Chapter 7, "Enabling/Disabling Centralized Authentication in CSS" in the *Authentication Services* manual.
 - k Set the Local Cache Size for Centralized Authentication on a device. See Chapter 7, "Setting the Local Cache Size for Central Authentication in CSS" in the *Authentication Services* manual.
 - l Customize the login banner text in CSS (optional). See [Customizing the Login Banner in CSS on page 269](#).
 - m Enable Centralized Event Logging on a device (optional). See Chapter 6, "Enabling/Disabling Centralized Event Logging on Devices in CSS" in the *Centralized Event Logging* manual.
 - n Set the NTP Server Settings on a device. See [NTP Server Settings in CSS on page 270](#).
- 3 Set up the local Password Configuration in the CSS (optional). See [Setting the Local Password Configuration in CSS on page 271](#).
- 4 Continue to one of the following depending on the type of device you are configuring:
- [Configuring the Parameters for the GTR 8000 Base Radio \(Trunked Simulcast\) on page 272](#).
 - [Configuring the Parameters for the GTR 8000 Base Radio \(Trunked Repeater\) on page 273](#).
 - [Configuring the Parameters for the GTR 8000 Base Radio \(HPD\) on page 274](#).
 - [Configuring the Parameters for a GTR 8000 Base Radio \(Conventional\) on page 274](#).
 - [Configuring the Parameters for a GTR 8000 Base Radio \(Express\) on page 275](#)
 - [Configuring the Parameters for a GPB 8000 Reference Distribution Module on page 276](#).

Connecting Through a Serial Port Link

Prerequisites: This procedure assumes that the Configuration/Service Software (CSS) application is loaded on your computer. See the *Private Network Management Client* manual.

When and where to use: This procedure describes the steps required to connect through a serial port link to set the IP address of the device and to set the serial security services. Perform all other device function and feature configurations through an Ethernet port connection in the CSS.


Procedure:

- 1 Connect a serial cable to a laptop or computer running CSS, and the serial connector on the device module. The serial cable is an RS232, female DB-9 to male DB-9 straight through cable. If the laptop does not have a serial port, use a USB-to-serial converter external device.
- 2 Open the CSS application.
- 3 From the menu, select **Tools** → **Connection Configuration**.
The **Connection Screen** dialog box appears.
- 4 In the **Connection Type** area, select **Serial**.
The **Serial Settings** area on the dialog box becomes enabled.

- 5 In the **Serial Port** field, select the communication port that matches the one selected on the computer.
- 6 In the **Baud Rate** field, select the baud rate with which you want to communicate with the device.
 - Baud Rate 19200
- 7 Click **Connect**.

A login/password prompt screen appears.

Figure 124: CSS Login Banner



- 8 Provide the required credentials. Perform one of the following actions:
 - If a domain controller is available on the network, enter the **Username** and **Password** for the RADIUS service user account assigned to the netwadm group in the Active Directory. (The default service user is `serviceuser`.)
 - If a domain controller is not available on the network, enter the **Username** and **Password** for the local `bts_service` account.
 - If the **Elevated Privileges Password** field is active, enter the **Elevated Privileges Password** that was set up for this device.

When accessing the device, if the default passwords do not work, the passwords may have been set to default values by a different system release of software. See "Resetting Device Passwords" in the *CSS Online Help* to reset the passwords to the current software release defaults. If Authentication Services are not enabled on a device, type any alphanumeric characters to populate the [**Username**, **Password**, and **Elevated Privileges Password**] fields, as they cannot be left blank.

- 9 To access the device and close the dialog box, click **OK**.

The blank CSS main window appears.



NOTICE: The **Service** menu is not available until you read the configuration file from the device using an Ethernet connection.

Serial Connection Configurations

The following procedures set configuration parameters in the Configuration/Service Software (CSS) using a serial connection.

Setting the Device IP Address and Pairing Number in CSS

Prerequisites: Obtain the required credentials information (local service account password and elevated privileges password) to configure the site devices before proceeding. The user credentials information includes both the current and new credentials. Without the current credentials, access to the device or to the user credentials is denied. See [Local Password and SNMPv3 Passphrase Troubleshooting on page 343](#).



NOTICE: Setting or changing the device IP Address causes the SNMPv3 configuration and user credentials to automatically reset.

Procedure:

- 1 Connect to the device using Configuration/Service Software (CSS) through a serial port link. See [Connecting Through a Serial Port Link on page 258](#).

- 2 From the menu, select **Tools** → **Set IP Address/BR_CM Pairing Number**.



NOTICE: If the device is not in a voting or simulcast IP only topology, the menu item is shown as **Set IP Address/Box Number**.

The **Set IP Address and Base Radio/Comparator Pairing Number** dialog box appears or the **Set IP Address and Box Number** dialog box appears.

- 3 In the **Device IP Address** field, enter the device IP address. Click **Set Device IP Address**.
- 4 In a voting or simulcast IP only topology, enter the device pairing number. Click **Set BR/CM Pairing Number**.
- 5 Click **OK** to close the dialog box.
- 6 Click **Reset** to initiate a hardware restart.
SNMPv3 user credentials reset to their factory default values.
- 7 Click **Close** to close the dialog box.
- 8 To reconfigure the SNMPv3 user credentials, see [Changing SNMPv3 Configuration and User Credentials in CSS on page 265](#).

Pairing To a Comparator

When operating in a voting, multicast, or IP simulcast configuration, base radios must be paired to comparators using the **BR/CM Pairing Number**. The **BR/CM Pairing Number** for the base radio and comparator is used to create an IP multicast group that allows the base radio and comparator to talk to each other. The base radio listens for messages that the comparator sends to establish an IP connection with all the paired base radios. When the base radio receives the message from the comparator, it extracts the comparator IP address from the message and uses it to send received voice and data back to the comparator.

Communication from the comparator to the paired base radio always uses a multicast IP address. Communication between the paired base radio to the comparator always uses a unicast IP address.

The multicast IP address is calculated based on the base radio and comparator pairing number and the formula as follows:

For Conventional Systems:

224.10.100.nnn, where nnn is: $(2 * \text{channel number}) - 1$ for channel number between [1, 127]

224.10.101.nnn, where nnn is: $(2 * (\text{channel number} - 127) - 1)$ for a channel number between [128, 200]

For Trunked Multi-Site Systems:

224.100.102.nnn, where nnn is: $100 + (2 * \text{channel number}) - 1$



NOTICE: The **BR/CM Pairing Number** is not used for circuit (V.24 or 4-wire/V.24 hybrid link) configurations.

See [Setting the Device IP Address and Pairing Number in CSS on page 260](#) to set the pairing number. The pairing number can also be set using an Ethernet connection. See [Setting the BR/CM Pairing Number in CSS on page 265](#).

Serial Security Services in CSS

The Serial Security Services in Configuration/Service Software (CSS) enables the secure services and changes the device password.



NOTICE: The Serial Security Services must be set before changing the SNMPv3 configuration and user credentials on a selected device in the site.

Before enabling this parameter, any login and password may be used on the File Transfer Access Services login window to access a device. After Authentication Services are enabled, the login and password provided is checked against the following authentication sources:

Stored password

RF site devices support a configurable password for the Local Service and Elevated Privileges accounts. The password is verified against the stored password for these accounts.

Built-in logins and passwords

RF site devices support built-in login/password combinations for a login by services such as the software downloads. Only certain software download login names are authenticated in this way.

Centralized Authentication

For authentication through centralized accounts instead of Local Service, Elevated Privileges, and built-in user accounts, use the **Configure the Centralized Authentication** parameter in CSS for the Challenge Handshake Authentication Protocol (CHAP). See Chapter 7, “Enabling/Disabling Centralized Authentication in CSS” in the *Authentication Services* manual. This procedure requires an Ethernet connection to the device being configured.

Setting the Serial Security Services in CSS

Prerequisites: Obtain the required credentials information (local service account password and elevated privileges password) to configure the site devices before proceeding. The user credentials information includes both the current and new credentials. Without the current credentials, you cannot access the device and cannot change the user credentials. See [Local Password and SNMPv3 Passphrase Troubleshooting on page 343](#). Changing to the incorrect user credentials may lead to not being able to access the device through Configuration/Service Software (CSS) or Secure SHell (SSH).

Procedure:

- 1 Connect to the device using CSS through a serial port link. See [Connecting Through a Serial Port Link on page 258](#).
- 2 From the menu, select **Security** → **Device Security Configuration** → **Security Services (Serial)**.
- 3 From the **Security Services Configuration** dialog box, set the **Test Application Configuration** field according to your organizational policies. The recommended secure configuration is **Disabled**.
- 4 Set the **Authentication Services** field to **Enabled**. This field enables local authentication services and must be enabled as a prerequisite for centralized authentication.

- 5 Set the **Password Reset Mechanism** field. This field allows a reset of the passwords for two built-in device accounts to their default values.
- 6 To update the password for the device, select either **Service Account** or **Elevated Privilege** from the drop-down list. Click **Update password**.
- 7 In the **Change Account Password** dialog box, enter the old password, then enter a new password, and confirm the new password before clicking **Change Password**.
- 8 To save the new password, click **OK**.
The **Change Account Password** dialog box closes.

Resetting SNMPv3 User Credentials to Factory Defaults in CSS

Prerequisites: Obtain the required credentials information (local service account password and elevated privileges password) to configure the site devices before proceeding. The user credentials information includes both the current and new credentials. Without the current credentials, you cannot access the device and cannot change the user credentials. To obtain the keys for resetting either password or SNMPv3 passphrases for the device, contact Motorola Solution Support Center (SSC). Changing to the incorrect user credentials may lead to not being able to access the device through Configuration/Service Software (CSS) or Secure SHell (SSH).

Procedure:

- 1 Connect to the device using CSS through a serial port link. See [Connecting Through a Serial Port Link on page 258](#).
- 2 From the menu, select **Security** → **SNMPv3 Configuration** → **Reset SNMPv3 Configuration (Serial)**.
The **Reset SNMPv3 Configuration** dialog box opens.
- 3 Click **Reset SMPv3 Configuration**.
The SNMPv3 configuration is reset to factory defaults in the device.
- 4 Click **Exit**.
The **Reset SNMPv3 Configuration** dialog box closes.
- 5 To reboot the device for the SNMPv3 user credentials to take effect, perform the following actions:
 - a From the menu, select **Tools** → **Set IP Address/Box Number** or **Set IP Address/BR_CM Pairing Number**.
 - b In the dialog box, click **Reset**.
The device reboots.
- 6 Proceed to [Changing SNMPv3 Configuration and User Credentials in CSS on page 265](#).

Connecting Through an Ethernet Port Link

Prerequisites: Load Configuration/Service Software (CSS) on the computer. See the *Private Network Management Client* manual if necessary or see the instructions in the CSS CD-ROM jewel box for instructions on loading the CSS on the laptop or computer.

When and where to use: Use the Ethernet port link to configure all CSS parameters for the device. For a base radio, receiver, or comparator, the 10/100Base-T LAN is not the default Ethernet port setting. To set the correct port speed and duplex, see the *CSS Online Help*.

Procedure:

- 1 Connect a computer (either laptop or desktop) to a device.
 - a Connect an Ethernet straight through cable between the Ethernet port on the computer and the appropriate LAN switch either locally at a site or remotely through the network.
 - If connecting to a base radio or receiver, set the IP address of the laptop to the 192.168.1.x subnet (where x is any number between 2 and 253).
 - If connecting to a site controller or comparator, set the IP address of the laptop to an address on the subnet of the local site, which varies depending on the site and zone numbers.
-  **NOTICE:** Normally the computer is connected to the appropriate LAN switch either locally or remotely through the network. Do not connect directly to a device unless downloading the software or configuring individually to that device.
- b Start the computer.
- 2 Open the CSS application.
 - 3 From the menu, select **Tools** → **Connection Configuration**.
 - 4 From the **Connection Screen**, in the **Connection Type** area, select **Ethernet**.
 - 5 If connected through the LAN switch, specify the IP address for the device in the **Ethernet Settings** area. Perform one of the following actions:

If...	Then...
If you know the IP address for the device,	perform the following actions: <ol style="list-style-type: none"> a In the Device IP Address field, enter the IP address for the device. b Go to step 7.
Trunked Device: If you do not know the IP address, but know the system identification of the device (the zone, site, subsite, and device ID of the device),	perform the following actions: <ol style="list-style-type: none"> a To open the DNS IP Address Calculation Screen dialog box, click Fetch DNS Entry. b From the Device list box, select the desired device type. c In the Zone, Site, Subsite, and Device ID fields, enter the proper values . <p> NOTICE: Some fields, such as Subsite, do not allow entries for some devices. Therefore, select the device first.</p> d Click OK. The Domain Name Services (DNS) information of the device automatically appears in the Device IP Address field. e Go to step 7.
Conventional Device: If you do not know the IP address,	perform the following actions: <ol style="list-style-type: none"> a Establish a serial connection to the device. See Connecting Through a Serial Port Link on page 258.

If...	Then...
	<p>b For a base radio, receiver or comparator, from the menu, select Tools → Set IP Address/BR_CM Pairing Number. For a site controller or Reference Distribution Module (RDM), select Set IP Address/Box Number.</p> <p>c In the Device IP Address field, read the IP address.</p> <p>d Re-establish an Ethernet connection and repeat steps 1 through 4.</p> <p>e In the Device IP Address field, enter the IP address for the device.</p> <p>f Go to step 7.</p>

- 6 If connected directly to the Ethernet service port of the device, click **Front Panel Ethernet**.
- 7 To make the connection, click **Connect**.

If this device is SNMPv3-capable, an **SNMPv3 Passphrase Prompt** dialog box appears.

Figure 125: SNMPv3 Passphrase Prompt



The image shows a dialog box titled "SNMPv3 Passphrase Prompt". It is divided into two sections: "User Information" and "Passphrase Information".

- User Information:**
 - Username: MotoCSS
 - Security Level: NoAuthNoPriv (selected from a dropdown menu)
- Passphrase Information:**
 - Authentication Passphrase: (empty text field)
 - Encryption Passphrase: (empty text field)

At the bottom of the dialog box, there are two buttons: "Ok" and "Cancel". A status bar at the very bottom contains the text "Select user security level."

- 8 In the **SNMPv3 Passphrase Prompt** dialog box, enter the **User Information** and **Passphrase Information**. Click **OK**. If Authentication Services are not enabled on a device, click **OK** when the dialog box appears.
- 9 From the menu, select **File** → **Read Configuration From Device**.

The parameters download from the device to the computer. When the download is complete, the CSS main window opens. Use the map on the left side of the screen to view configuration information for the device.

Ethernet Connection Configurations

The following procedures set configuration parameters in the Configuration/Service Software (CSS) using an Ethernet connection.

Setting the BR/CM Pairing Number in CSS

When and where to use:

Set the pairing number for the base radio, receiver, and comparator using Configuration/Service Software (CSS) when operating in a voting, multicast, or simulcast IP configuration using an Ethernet connection.

Procedure:

- 1 Connect to the device using Configuration/Service Software (CSS) through an Ethernet port link. See [Connecting Through an Ethernet Port Link on page 262](#).
- 2 From the menu, select **Service** → **BR/CM Pairing Number**.
- 3 Enter the pairing number. Click **OK**.
The pairing number is set.

Setting the Date and Time in CSS

This procedure provides the date and time to the device.

When and where to use: During installation, the date and time is set through an Ethernet cable connected directly to the Ethernet port of the device. After installation, this procedure may be performed remotely.



NOTICE: If a power outage occurs, the device does not retain the date and time settings.

Procedure:

- 1 Connect to the device using CSS through an Ethernet port link. See [Connecting Through an Ethernet Port Link on page 262](#).
- 2 From the menu, select **Tools** → **Set Device Date and Time**.
- 3 Enter the current date and time. Click **OK**.
The date and time are set.

Changing SNMPv3 Configuration and User Credentials in CSS

Prerequisites: Obtain the required SNMPv3 credentials information (Authentication passphrase, Encryption passphrase, and Authoritative Engine ID) to configure the device before proceeding. The user credentials information includes both the current and new credentials. Without the current credentials, you cannot access the device and cannot change the user credentials. See [Local Password and SNMPv3 Passphrase Troubleshooting on page 343](#). Changing to the incorrect user credentials may lead to not being able to access the device from the Unified Network Configurator (UNC), or for the device to be unable to send alarms to the Unified Event Manager (UEM) (for fault management).

When and where to use: This procedure changes the SNMPv3 configuration and user credentials from Configuration/Service Software (CSS) on a selected device in the site. For more information on this feature, see the *SNMPv3* manual.



NOTICE: During installation, perform this procedure through an Ethernet cable connected directly to the Ethernet port of the device. After installation, this procedure may be performed remotely from CSS.

Procedure:

- 1 Connect to the device using CSS through an Ethernet port link. See [Connecting Through an Ethernet Port Link on page 262](#).

- 2 From the menu, select **Security** → **SNMPv3 Configuration** → **Configure SNMPv3 Users (Ethernet)**.

The **SNMPv3 Passphrase Prompt** dialog box appears with **MotoAdmin** as the selected SNMPv3 user.

- 3 In the **SNMPv3 Passphrase Prompt**, enter the appropriate **Authentication** and **Encryption Passphrases** in the text fields.



NOTICE: When accessing the device for the first time, if the default passphrases do not work, the passphrases may have been set to default values by a different system release of software. See “Reset SNMPv3 Configuration (Serial)” in the *CSS Online Help* to reset the passphrases to the current software release defaults.

- 4 If connecting remotely through the network to a different device, perform one of the following actions. Otherwise, go to [step 5](#).

If...	Then...
<p>If you know the IP address for the device,</p>	<p>perform the following actions:</p> <ol style="list-style-type: none"> a In the Device IP Address field, enter the IP address for the device. b Go to step 5.
<p>If you do not know the IP address, but know the system identification of the device (the zone, site, subsite, and device ID of the device),</p>	<p>perform the following actions:</p> <ol style="list-style-type: none"> a To open the DNS IP Address Calculation Screen dialog box, click Fetch DNS Entry. b From the Device list box, select the desired device type. c In the Zone, Site, Subsite, and Device ID fields, enter the proper values. <p> NOTICE: Some fields, such as Subsite, do not allow entries for some devices. Therefore, select the device first.</p> <ol style="list-style-type: none"> d Click OK. The Domain Name Services (DNS) information of the device automatically appears in the Device IP Address field. e Go to step 5.

- 5 Click **OK**.

If the passphrases are authenticated, the **Configure SNMPv3 Users** window appears. If the connection fails, a message appears.

- 6 To update the SNMPv3 credentials for a selected user, from the **User Information** section, select a Username in the **Username** drop-down list.

The CSS retrieves the current credentials from the device for a selected user.



NOTICE: Depending on the user selected, some fields on this dialog box become read-only or disabled. Click **Cancel** at any time to discard changes made to a selected user.

- 7 To change or update the SNMPv3 security level for a selected user, from the **User Information** section, select the security level in the **Security Level** drop-down list.

The security level options are:

NoAuthNoPriv

Neither the **Authentication Passphrase** nor **Encryption Passphrase** are needed for communicating with the device.

AuthNoPriv

Authentication Passphrase is needed; but no **Encryption Passphrase** is needed for communicating with the device.

AuthPriv

Both **Authentication Passphrase** and **Encryption Passphrase** are needed for communicating with the device.

The **User Status** field reflects the current operational status of the selected SNMPv3 User. The **Status Types** include:

Active

User configured on the device; the **Update** and **Delete** options are enabled.

Not in service

User configured on the device; the **Update** and **Delete** options are enabled.

Not ready

User configured on the device; the **Update** and **Delete** options are enabled.

Not present

Not present on the device; the **Create** option is enabled.

The security level of the selected user is set.

- 8 To change the Authentication Passphrase for the selected SNMPv3 user, if applicable to the selected security level, perform the following actions:

- a From the **Authentication Passphrase** section, enter the passphrase into the **Old Passphrase** field.



NOTICE: If you do not know the passphrase, select the **I do not remember old passphrase** check box.

- b Enter the new passphrase into the **New Passphrase** field.



NOTICE: The passphrase must be between 8 and 64 characters in length and consist of upper or lowercase alphanumeric characters (excluding the @ # \$ ^ or _ characters).

- c Enter the same new passphrase into the **Confirm New Passphrase** field.

- 9 To change the encryption passphrase for the selected SNMPv3 user, if applicable to the selected security level, perform the following actions:

- a From the **Encryption Passphrase** section, enter the old passphrase into the **Old Passphrase** field.



NOTICE: If you do not know the passphrase, select the **I do not remember old passphrase** check box.

- b Enter the new passphrase into the **New Passphrase** field.

- c Enter the same new passphrase into the **Confirm New Passphrase** field.

10 To change the Authoritative Engine Identifier, applicable to MotoInformA and MotorInformB users only, perform the following actions:

- a** From the **Authoritative Engine ID** section, select the desired current engine ID from the **Current Engine ID** drop-down list.
- b** In the **New Engine ID** field, enter the new engine ID.



NOTICE: The new engine ID must be between 1 and 27 characters and comply with the Engine ID Domain Name Syntax.

11 To create, update, or delete SNMPv3 users, go to [Adding or Modifying an SNMPv3 User in CSS on page 268](#).

Adding or Modifying an SNMPv3 User in CSS

When and where to use: Use this procedure to create, update, or delete an SNMPv3 user from the **Configure SNMPv3 Users** window.

Procedure:

- 1** From the **Configure SNMPv3 Users** window, to add or modify the selected SNMPv3 user, click one of the following:
 - **Create:** Creates a user when the status is Not Present.
 - **Update:** Updates an existing user.
 - **Delete:** Removes an existing user.

A **Confirmation** dialog box appears and prompts if you want to continue.

- 2** Click **Yes**.

The **Processing Requests** dialog box appears and processes the request. A green square X indicates OK and a red square X indicates failure.

- 3** After reviewing the processing status, click **OK**.



NOTICE: If you encounter any errors, go back to the appropriate step and correct the information entered.

- 4** Repeat these steps for any SNMPv3 users you wish to create, update, or delete.
- 5** Click **Cancel** to exit the **Configure SNMPv3 Users** window.

The **Configure SNMPv3 Users** window closes, and the CSS main window returns.

Performing an SNMPv3 Connection Verification in CSS

When and where to use: When the SNMPv3 user credentials have been created, modified, or deleted, ensure that the device is properly configured for SNMPv3. Follow this procedure to verify the SNMPv3 connection.

Procedure:

- 1** Connect to the device using Configuration/Service Software (CSS) through an Ethernet port link. See [Connecting Through an Ethernet Port Link on page 262](#).
- 2** When the passphrase prompt screen opens, select the configured security level and enter the required passphrases.
- 3** If the connection was successful, click **OK**.

Customizing the Login Banner in CSS

This procedure describes how to edit the login banner security notice.

Procedure:

- 1 Connect to the device using Configuration/Service Software (CSS) through an Ethernet port link. See [Connecting Through an Ethernet Port Link on page 262](#).
- 2 From the menu, select **Security** → **Device Security Configuration** → **Remote Access/Login Banner (Ethernet)**.
- 3 From the **Remote Access/Login Banner** screen, **Remote Access Configuration** tab, click the **Login Banner** tab.
- 4 Edit the text of the banner.
- 5 Click one of the following:
 - **Refresh:** re-reads the original Login Banner text.
 - **Apply:** saves the changes and keep the screen open.
 - **OK:** saves the changes and close the screen.
 - **Cancel:** closes the screen without saving the changes.

Setting the SWDL Transfer Mode in CSS

This procedure sets the Software Download (SWDL) transfer mode.


When and where to use: Follow this procedure to set the SWDL transfer mode to Ftp (clear) or Sftp (secure) before performing a software download on the device.

Procedure:

- 1 Connect to the device using Configuration/Service Software (CSS) through an Ethernet port link. See [Connecting Through an Ethernet Port Link on page 262](#).
- 2 From the menu, select **Security** → **Device Security Configuration** → **Remote Access/Login Banner (Ethernet)**.

The **Remote Access/Login Banner** screen appears displaying the **Remote Access Configuration** tab.

Figure 126: Remote Access Configuration Tab



- 3 In the **Software Download Transfer Mode (Requested)** field, choose either **Ftp** (clear) or **Sftp** (secure). Click **OK**.

 **NOTICE:** Secure Shell Service (Requested) and Secure FTP (Requested) are automatically set to **Enabled** and grayed out when you choose **Sftp**.

Manager IP Address Settings in CSS

When IP addresses exceed the allowed total, remove the IP addresses that are no longer used at the site. This removal allows the Unified Event Manager (UEM) to be identified as the current manager and handles traps for the device.

See “Clearing Manager IP Address” in the *CSS On-line Help* for removing these IP addresses.

NTP Server Settings in CSS

Network Time Protocol (NTP) provides a clock synchronization mechanism for various Network devices and computers, and allows the NTP server to provide the date and time synchronization for a particular device. The NTP server IP address must be entered on the **Manager / NTP Definition** Screen.

Trunked ASTRO® 25 systems: For security purposes, the base radio can restrict NTP messages from only the site controller. This restriction can be accomplished by configuring two site controller IP addresses into the **NTP Server IP Address** fields on the base radio.

Trunked 3600 IntelliRepeater systems: For security purposes, the base radio can restrict NTP messages from only the GPB 8000 Reference Distribution Modules (RDMs). This restriction can be accomplished by configuring two RDM IP addresses into the **NTP Server IP Address** fields on the base radio.

For a base radio, see “Configuring the NTP Servers” or for RDMs in a trunked 3600 IntelliRepeater system, see “Configuring NTP Servers for an RDM in a Trunked 3600 IntelliRepeater Site” in the *CSS On-line Help* for defining, editing, and removing these settings.

Setting the Local Password Configuration in CSS

When and where to use: Use this procedure to set the complexity requirements and controls for the local service account password. The updated password criteria is enforced on the next password change for the device local service account. Password Configuration is an optional feature. For information, see “Password Configuration” in the *CSS Online Help*.

Procedure:

- 1 Connect to the device using Configuration/Service Software (CSS) through an Ethernet port link. See [Connecting Through an Ethernet Port Link on page 262](#).
- 2 In the navigation pane, click the **Password Configuration** element.
The **Password Configuration** window appears.

Figure 127: Password Configuration Window

The screenshot shows a window titled "Password Configuration" with two main sections: "Password Complexity" and "Password Controls".

Password Complexity:

Minimum Password Length	10
Number of Required Special Characters	1
Number of Required Numeric Characters	2
Number of Required Uppercase Characters	2
Number of Required Lowercase Characters	2
Number of Consecutive Characters	0

There is a "Set Values to Default" button at the bottom right of this section.

Password Controls:

Password Aging Time [days]	0
Change Interval Limit [days]	1

- 3 Complete the following fields:

Minimum Password Length

This field allows you to enter a value as the minimum length for the password. The minimum can be between 8 and 255 characters, with a default of 10 characters.

Number of Required Special Characters

This field allows you to enter a value for the required number of special characters which must be included in the password. The value can be between 0 and 255, with a default of 1.

Number of Required Numeric Characters

This field allows you to enter a value for the required number of numeric characters which must be included in the password. The value can be between 0 and 255, with a default of 2.

Number of Required Uppercase Characters

This field allows you to enter a value for the required number of uppercase alphabetic characters which must be included in the password. The value can be between 0 and 255, with a default of 2.

Number of Required Lowercase Characters

This field allows you to enter a value for the required number of lowercase alphabetic characters which must be included in the password. The value can be between 0 and 255, with a default of 2.

Number of Consecutive Characters

This field allows you to enter the maximum number of consecutive repeated characters permitted in the password.

Set Values to Default

This field returns all fields to their system default values.

Password Aging Time [days]

This field allows you to enter a value between 0 and 65535 for the maximum number of days a local password is valid. After the **Password Aging Time** has elapsed, the password must be changed. The default value is 0.

Change Interval Limit [days]

This field allows you to enter a value between 0 and 65535 for the number of days which must elapse before a local password can be changed. The default value is 1.

Configuring the Parameters for the GTR 8000 Base Radio (Trunked Simulcast)

When and where to use:

Before proceeding with this process, complete the initial configuration of the device in [Initially Configuring a Device in CSS on page 257](#).

For configuration parameters for a trunked simulcast GTR 8000 Expandable Site Subsystem, see the following in the *CSS Online Help*:

- **GTR 8000 Base Radios:** Multi-Site or Simulcast Subsystem
- **GCP 8000 Site Controllers:** Site Controller Configuration & Service Help > Multi-Site Controller
- **GPB 8000 Reference Distribution Modules:** Site Controller Configuration & Service Help > GPB 8000 Reference Distribution Module

Process:

- 1 Connect to the base radio through an Ethernet port link and then read the configuration file from the base radio. See [Connecting Through an Ethernet Port Link on page 262](#).
- 2 Click **System** in the System tree and enter a hexadecimal value (between 001 and FFE) in the **System Id** field.
- 3 Click **Site** in the System tree and complete the fields.
- 4 Click **Channel** in the System tree and complete the fields.
- 5 Click **Subsite** in the System tree and complete the fields.
- 6 Click **Configuration** in the System tree and complete the fields on all four tabs.



NOTICE: As part of RMC configuration, the DIP switches on the RMC/LNA modules must be set. See [RMC Attenuation on page 278](#).

- 7 Click **Network Services Configuration** in the System tree and complete the fields on the three tabs.



NOTICE: For configuration details for DNS and RADIUS Services, see the *Authentication Services* manual. For configuration details for SYSLOG Services, see the *Centralized Event Logging* manual.

- 8 Click **Password Configuration** in the System tree and complete the fields.



NOTICE: Password Configuration is only required if you have passwords entered for local accounts. Password Configuration sets the password complexity and controls. For details on password complexity and controls, see "Password Configuration" in *CSS Online Help*.

- 9 From the menu, select **File** → **Save As** to save the configuration data to a new archive file, or select **File** → **Save** to overwrite the existing archive file.



IMPORTANT: Save any configuration changes to a local or network drive in case the base radio transceiver module fails you can load the settings to a replacement base radio transceiver. If the configuration file is not saved to a local or network drive, repeat the set-up steps after replacing a transceiver module.

- From the menu, select **File** → **Write Configuration to Device** to write the configuration data to the base radio.

Configuring the Parameters for the GTR 8000 Base Radio (Trunked Repeater)

When and where to use:

Before proceeding with this process, complete the initial configuration of the device in [Initially Configuring a Device in CSS on page 257](#).

For configuration parameters for a trunked repeater GTR 8000 Expandable Site Subsystem, see the following in the *CSS Online Help*:

- **GTR 8000 Base Radios:** Repeater Site Subsystem
- **GCP 8000 Site Controllers:** Site Controller Configuration & Service Help > Repeater Site Controller > GCP 8000

Process:

- Connect to the base radio through an Ethernet port link and read the configuration file from the base radio. See [Connecting Through an Ethernet Port Link on page 262](#).
- Click **System** in the System tree and enter a hexadecimal value (between 001 and FFE) in the System Id field.
- Click **Zone** in the System tree and complete the fields.
- Click **Site** in the System tree and complete the fields.
- Click **Channel** in the System tree and complete the fields.
- Click **Configuration** in the System tree and complete the fields on all four tabs.



NOTICE: As part of RMC configuration, the DIP switches on the RMC/LNA modules must be set. See [RMC Attenuation on page 278](#).

- Click **Network Services Configuration** in the System tree and complete the fields on the three tabs.



NOTICE: For configuration details for DNS and RADIUS Services, see the *Authentication Services* manual. For configuration details for SYSLOG Services, see the *Centralized Event Logging* manual.

- Click **Password Configuration** in the System tree and complete the fields.



NOTICE: Password Configuration is only required if you have passwords entered for local accounts. Password Configuration sets the password complexity and controls. For details on password complexity and controls, see “Password Configuration” in *CSS Online Help*.

- From the menu, select **File** → **Save As** to save the configuration data to a new archive file, or select **File** → **Save** to overwrite the existing archive file.



IMPORTANT: Save any configuration changes to a local or network drive in case the base radio transceiver module fails you can load the settings to a replacement transceiver module. If the configuration file is not saved to a local or network drive, repeat the set-up steps after replacing a transceiver module.

- From the menu, select **File** → **Write Configuration to Device** to write the configuration data to the base radio.

Configuring the Parameters for the GTR 8000 Base Radio (HPD)

When and where to use:

Before proceeding with this process, complete the initial configuration of the device in [Initially Configuring a Device in CSS on page 257](#).

For configuration parameters for an HPD GTR 8000 Expandable Site Subsystem, see the following in the *CSS Online Help*:

- **GTR 8000 Base Radios:** HPD Remote/Expandable Site
- **GCP 8000 Site Controllers:** Site Controller Configuration & Service Help > HPD Site Controller

Process:

- Connect to the base radio through an Ethernet port link and read the configuration file from the base radio. See [Connecting Through an Ethernet Port Link on page 262](#).
- Click **System** in the System tree and enter a hexadecimal value (between 001 and FFE) in the System Id field.
- Click **Site** in the System tree and complete the fields.
- Click **Channel** in the System tree and complete the fields.
- Click **Configuration** in the System tree and complete the fields on all four tabs.



NOTICE: As part of RMC configuration, the DIP switches on the RMC/LNA modules must be set. See [RMC Attenuation on page 278](#).

- Click **Network Services Configuration** in the System tree and complete the fields on the three tabs.



NOTICE: For configuration details for DNS and RADIUS Services, see the *Authentication Services* manual. For configuration details for SYSLOG Services, see the *Centralized Event Logging* manual.

- Click **Password Configuration** in the System tree and complete the fields.



NOTICE: Password Configuration is only required if you have passwords entered for local accounts. Password Configuration sets the password complexity and controls. For details on password complexity and controls, see “Password Configuration” in *CSS Online Help*.

- From the menu, select **File** → **Save As** to save the configuration data to a new archive file, or select **File** → **Save** to overwrite the existing archive file.



IMPORTANT: Save any configuration changes to a local or network drive in case the base radio transceiver module fails you can load your settings to a replacement transceiver module. If the configuration file is not saved to a local or network drive, repeat the set-up steps after replacing a transceiver module.

- From the menu, select **File** → **Write Configuration to Device** to write the configuration data to the base radio.

Configuring the Parameters for a GTR 8000 Base Radio (Conventional)

When and where to use:

Before proceeding with this process, complete the initial configuration of the device in [Initially Configuring a Device in CSS on page 257](#).

For configuration parameters for a Conventional GTR 8000 Base Radio, see the following in the *CSS Online Help*:

- **Analog-only, Digital-only, or Mixed Mode GTR 8000 Base Radio:** Conventional Site - ASTRO 7.12 and Later
- **Digital-only GTR 8000 Base Radio:** Conventional Site - ASTRO 7.11 and Earlier

Process:

1 Connect to the base radio through an Ethernet port link and read the configuration file from the base radio. See [Connecting Through an Ethernet Port Link on page 262](#).

2 Click **Site** in the System tree and complete the fields.

3 Click **Hardware Configuration** in the System tree and complete the fields on the two tabs.



NOTICE: As part of RMC configuration, the DIP switches on the RMC/LNA modules must be set. See [RMC Attenuation on page 278](#).

4 Click **Options** in the System tree and complete the fields.

5 Click **Infrastructure Interface** in the System tree and complete the fields on the three tabs.

6 Click **Channel Configuration** in the System tree and complete the fields.

7 Click **Repeater Configuration** in the System tree and complete the fields.

8 Click **Receiver Scan** in the System tree and complete the fields.

9 Click **Repeater Access** in the System tree and complete the fields.

10 Click **WildCard Tables** in the System tree and complete the fields on the three tabs.

11 Click **Network Services Configuration** in the System tree and complete the fields on the three tabs.



NOTICE: For configuration details for RADIUS Services, see the *Authentication Services* manual. For configuration details for SYSLOG Services, see the *Centralized Event Logging*, manual.

12 Click **Password Configuration** in the System tree and complete the fields.



NOTICE: Password Configuration is only required if you have passwords entered for local accounts. Password Configuration sets the password complexity and controls. For details on password complexity and controls, see “Password Configuration” in *CSS Online Help*.

13 From the menu, select **File** → **Save As** to save the configuration data to a new archive file, or select **File** → **Save** to overwrite the existing archive file.



IMPORTANT: Save any configuration changes to a local or network drive in case the base radio transceiver module fails you can load your settings to a replacement base radio. If the configuration file is not saved to a local or network drive, repeat the set-up steps after replacing a base radio.

14 From the menu, select **File** → **Write Configuration to Device** to write the configuration data to the base radio.

Configuring the Parameters for a GTR 8000 Base Radio (Express)

When and where to use:

This section covers configuration for ASTRO® 25 Express System GTR 8000 Expandable Site Subsystem using the Configuration Service Software.

Before proceeding with this process, complete the initial configuration of the device in [Initially Configuring a Device in CSS on page 257](#).

For configuration parameters for an Express GTR 8000 Expandable Site Subsystem, see the following in the *CSS Online Help*:

- **GTR 8000 Base Radios:** Trunking Site > ASTRO 25 Express System
- **GCP 8000 Site Controllers:** Site Controller Configuration & Service Help > ASTRO 25 Express System

Process:

1 Connect to the base radio through an Ethernet port link and then read the configuration file from the base radio. See [Connecting Through an Ethernet Port Link on page 262](#).

2 Click **System** in the System tree and complete the fields.



NOTICE: Ensure that all base radios and site controllers have the same values for WACN ID and System ID.

3 Click **Zone** in the System tree and enter the following values:

- Set the base radios **Grant Timeout Timer (msec)** field to 1000 milliseconds (default).
- If the Phase 2 TDMA feature is present in your system, set the **Carrier Fade Timeout Timer (msec)** field to 1900 for systems that have a value less than 1900. For systems that have a value greater than 1900, use the higher value entered for the system.

4 Click **Site** in the System tree and complete the fields.

5 Click **Channel** in the System tree and complete the fields.

6 Click **Configuration** in the System tree and complete the fields on all four tabs.



NOTICE: As part of RMC configuration, the DIP switches on the RMC/LNA modules must be set. See [RMC Attenuation on page 278](#).

7 Click **Password Configuration** in the System tree and complete the fields.



NOTICE: Password Configuration is only required if you have passwords entered for local accounts. Password Configuration sets the password complexity and controls. For details on password complexity and controls, see “Password Configuration” in *CSS Online Help*.

8 From the menu, select **File** → **Save As** to save the configuration data to a new archive file, or select **File** → **Save** to overwrite the existing archive file.



IMPORTANT: Save any configuration changes to a local or network drive in case the transceiver module fails you can load your settings to a replacement transceiver. If the configuration file is not saved to a local or network drive, repeat the set-up steps after replacing a transceiver.

9 From the menu, select **File** → **Write Configuration to Device** to write the configuration data to the base radio.

Configuring the Parameters for a GPB 8000 Reference Distribution Module

Prerequisites:

Before proceeding with this process, complete the initial configuration of the device in [Device Configuration in CSS on page 257](#).

For configuration details of the GPB 8000 Reference Distribution Module, see **Site Controller Configuration & Service Help** → **GPB 8000 Reference Distribution** in the *CSS Online Help*.

Process:

- 1 Connect to the device through an Ethernet port link and read the configuration file from the device. See [Connecting Through an Ethernet Port Link on page 262](#).
- 2 Click **Site** in the System tree and complete the fields.
- 3 Click **Configuration** in the System tree and complete the fields.
- 4 Click **Network Services Configuration** in the System tree and complete the fields on the three tabs.



NOTICE: For configuration details for DNS and RADIUS Services, see the *Authentication Services* manual. For configuration details for SYSLOG Services, see the *Centralized Event Logging*, manual.

- 5 Click **Password Configuration** in the System tree and complete the fields.



NOTICE: Password Configuration is only required if you have passwords entered for local accounts. Password Configuration sets the password complexity and controls. For details on password complexity and controls, see “Password Configuration” in *CSS Online Help*.

- 6 Click **Switch Configuration** in the System tree and complete the fields.
- 7 From the menu, select **File** → **Save As** to save the configuration data to a new archive file, or select **File** → **Save** to overwrite the existing archive file.



IMPORTANT: Save any configuration changes to a local or network drive in case the device fails you can load your settings to a replacement device. If the configuration file is not saved to a local or network drive, repeat the set-up steps after replacing a device.

- 8 From the menu, select **File** → **Write Configuration to Device** to write the configuration data to the device.

Configuring the Parameters for a GCP 8000 Site Controller

For CSS configuration of the GCP 8000 Site Controllers, see the *GCP 8000 Site Controller* manual or the *CSS Online Help*.

For configuration parameters for a GCP 8000 Site Controller within a GTR 8000 Expandable Site Subsystem, see the following in the *CSS Online Help*:

- Site Controller Configuration & Service Help > HPD Site Controller
- Site Controller Configuration & Service Help > Repeater Site Controller > GCP 8000
- Site Controller Configuration & Service Help > ASTRO 25 Express System

Configuring Tx Power Values and Battery Type

When and where to use: As part of the site configuration process, the **Battery Type**, **Tx Power Level (Battery Backup)**, and **Tx Power Out** on the **Hardware Configuration** tab in Configuration/Service Software (CSS) must be configured.

Procedure:

- 1 Connect to the device through an Ethernet port link and read the configuration file from the device. See [Connecting Through an Ethernet Port Link on page 262](#).
- 2 From the navigation tree, select **Configuration**.

The **Configuration** window appears.


- 3 Select the **Hardware Configuration** tab.
- 4 In the **Tx Power Out (Watts)** field, enter a value.
- 5 In the **Tx Power Level Battery Backup (Watts)** field, enter a value.
- 6 Select the **Battery Type** (manufacturer and model, or select the generic listing for the class of battery).
- 7 From the menu, select **File** → **Save**, or select **File** → **Save As** to save the configuration to an archive on your local or network drive.
- 8 From the menu, select **File** → **Write Configuration to Device** to write the configuration to the device.

RMC Attenuation

To adjust the RF gain for different configurations, the attenuation level applied to receivers can be set from the DIP switches on the front of Cabinet RMC/LNA modules and Site RMC/LNA modules.


Figure 128: Cabinet RMC/LNA Module (Front View) on page 278 shows the DIP switches on an individual Cabinet RMC/LNA module. The location of the DIP switches is similar on a Site RMC/LNA module.

Figure 128: Cabinet RMC/LNA Module (Front View)




GTR8000_RFDS_XS_RMC_Cabinet_Front1

The following are examples of how the DIP switch positions (0 and 1) create a binary system for setting dB attenuation values.

Figure 129: RMC DIP Switch Example: 0 dB

HPD_GTR8000_RFDS_RMC_Dipswitch2

Figure 130: RMC DIP Switch Example: 12 dB

HPD_GTR8000_RFDS_RMC_Dipswitch1

To determine how to set each DIP switch for your configuration, see [RMC Attenuator DIP Switch Settings on page 280](#).

- **RMC Attenuator Settings for Single Cabinet Site with No Site RMC:** If your configuration is a Single Cabinet with No Site RMC (CA00861AA), set the DIP switches on your Cabinet RMC/LNA module to the default positions indicated in [Table 109: RMC Attenuator Settings for Single Cabinet Sites with No Site RMC \(700/800/900 MHz\) on page 282](#) for 700/800/900 MHz or [Table 111: RMC Attenuator Settings for Single Cabinet Sites with No Site RMC \(UHF R2, 435–524 MHz\) on page 283](#) for UHF R2 (450–512 MHz). HPD systems have two sets of RMC/LNA modules.
- **RMC Attenuator for All Other Configurations:** If your configuration has at least one cabinet with a Site RMC/LNA (CA00862AA), set the DIP switches on your Site and Cabinet RMC/LNA modules to the default positions indicated in [Table 108: RMC Attenuator Settings for Site with Two or More Cabinets \(700/800/900 MHz\) on page 281](#) for 700/800/900 MHz or [Table 110: RMC Attenuator Settings for Site with Two or More Cabinets \(UHF R2, 435–524 MHz\) on page 283](#) for UHF R2 (450–512 MHz). These settings also apply to the Cabinet RMC/LNA modules in any expansion cabinets (CA00877AA). HPD systems have two sets of RMC/LNA modules.



NOTICE: The default settings may not be appropriate for sites with a high antenna noise or very large in-band interfering signals. The tables provide alternate optimum settings that allow trading noise (sensitivity) for better intermodulation performance.



IMPORTANT: If your system has a customer-supplied Tower Top Amplifier (TTA), do not set the DIP switches to the dB values in the following tables. See [Inline Attenuator Value for a GTR 8000 Expandable Site Subsystem with a TTA for UHF R2 and 700/800/900 MHz on page 286](#).

RMC Attenuator DIP Switch Settings



NOTICE: Although the DIP switches on the RMC/LNA modules are numbered starting with the number 1 on the left, as shown in the RMC DIP Switch examples, this table starts with the number 5 on the left because switch 5 represents the most significant digit in the binary system that the switches provide for setting a dB value.

Table 107: RMC Attenuator DIP Switch Settings

Required Attenuation (dB)	Position 5	Position 4	Position 3	Position 2	Position 1
0dB	0	0	0	0	0
1dB	0	0	0	0	1
2dB	0	0	0	1	0
3dB	0	0	0	1	1
4dB	0	0	1	0	0
5dB	0	0	1	0	1
6dB	0	0	1	1	0
7dB	0	0	1	1	1
8dB	0	1	0	0	0
9dB	0	1	0	0	1
10dB	0	1	0	1	0
11dB	0	1	0	1	1
12dB	0	1	1	0	0
13dB	0	1	1	0	1
14dB	0	1	1	1	0
15dB	0	1	1	1	1
16dB	1	0	0	0	0
17dB	1	0	0	0	1
18dB	1	0	0	1	0
19dB	1	0	0	1	1
20dB	1	0	1	0	0
21dB	1	0	1	0	1
22dB	1	0	1	1	0
23dB	1	0	1	1	1
24dB	1	1	0	0	0
25dB	1	1	0	0	1
26dB	1	1	0	1	0
27dB	1	1	0	1	1
28dB	1	1	1	0	0

Table continued...

Required Attenuation (dB)	Position 5	Position 4	Position 3	Position 2	Position 1
29dB	1	1	1	0	1
30dB	1	1	1	1	0
31dB	1	1	1	1	1

RMC Attenuator Settings for Site with Two or More Cabinets (700/800/900 MHz)

The required attenuation dB values are also displayed on the Receive Multicoupler (RMC) Configuration tab in Configuration/Service Software (CSS), which must be used to set up system gain according to your GTR 8000 Expandable Site Subsystem configuration.

Table 108: RMC Attenuator Settings for Site with Two or More Cabinets (700/800/900 MHz)

System Noise Figure (dB)	System Input Intercept (dBm)	RFDS Gain (dB)	Site RMC Attenuator Setting (dB)	Cabinet RMC Attenuator Setting (dB)
3.4	-6.5	24	0	0
4.1	0.9	16	1	7
4.7*	3.4	13	1	10
5.0	4.4	12	2	10
6.0	6.3	10	4	10
7.1	8.2	8	6	10
8.0	9.3	7	8	9
9.2	11.0	5	9	10
10.0	11.9	4	10	10
10.9	12.7	3	11	10
12.0	13.7	2	13	9
12.9	14.5	1	14	9
13.8	15.2	0	15	9

Cabinet RMC Settings must be the same in each cabinet. These settings provide maximum possible system dynamic range.

* = Default: Recommended setting as shipped from the factory.

RMC Attenuator Settings for Single Cabinet Sites with No Site RMC (700/800/900 MHz)

The required attenuation dB values are also displayed on the Receive Multicoupler (RMC) Configuration tab in Configuration/Service Software (CSS), which must be used to set up system gain according to your GTR 8000 Expandable Site Subsystem configuration.

Table 109: RMC Attenuator Settings for Single Cabinet Sites with No Site RMC (700/800/900 MHz)

System Noise Figure (dB)	System Input Intercept (dBm)	RFDS Gain (dB)	Cabinet RMC Attenuator Setting (dB)
4.5*	4.8	13	0
4.8	5.8	12	1
5.2	6.7	11	2
5.6	7.7	10	3
6.1	8.6	9	4
6.6	9.6	8	5
7.2	10.5	7	6
7.8	11.3	6	7
8.5	12.2	5	8
9.3	13.0	4	9
10.1	13.8	3	10
10.9	14.6	2	11
11.7	15.3	1	12
12.6	15.9	0	13
13.5	16.5	-1	14
14.4	17.1	-2	15
15.4	17.6	-3	16
16.3	18.0	-4	17
17.3	18.4	-5	18
18.2	18.7	-6	19
19.2	19.0	-7	20
20.2	19.2	-8	21

* = Default: Recommended setting as shipped from the factory. Do not use these settings for Rx Expansion cabinets.

RMC Attenuator Settings for Site with Two or More Cabinets (UHF R2, 435–524 MHz)

The required attenuation dB values are also displayed on the Receive Multicoupler (RMC) Configuration tab in Configuration/Service Software (CSS), which must be used to set up system gain according to your GTR 8000 Expandable Site Subsystem configuration.

Table 110: RMC Attenuator Settings for Site with Two or More Cabinets (UHF R2, 435–524 MHz)

System Noise Figure (dB)	System Input Intercept (dBm)	RFDS Gain (dB)	Site RMC Attenuator Setting (dB)	Cabinet RMC Attenuator Setting (dB)
4.1	–3.1	16	0	13
5.1	1.4	11	2	16
5.5*	2.6	10	4	15
6.1	3.9	8	3	18
7.1	5.7	7	8	14
8.0	7.3	5	8	16
9.1	8.8	3	8	18
10.0	10.0	2	10	17
11.0	11.1	1	12	16
12.1	12.2	0	14	15
13.0	13.1	–1	15	15
14.0	13.9	–3	13	19

Cabinet RMC Settings must be the same in each cabinet. These settings provide maximum possible system dynamic range.

* = Default: Recommended setting as shipped from the factory.

RMC Attenuator Settings for Single Cabinet Sites with No Site RMC (UHF R2, 435–524 MHz)

The required attenuation dB values are also displayed on the Receive Multicoupler (RMC) Configuration tab in Configuration/Service Software (CSS), which must be used to set up system gain according to your GTR 8000 Expandable Site Subsystem configuration.

Table 111: RMC Attenuator Settings for Single Cabinet Sites with No Site RMC (UHF R2, 435–524 MHz)

System Noise Figure (dB)	System Input Intercept (dBm)	RFDS Gain (dB)	Cabinet RMC Attenuator Setting (dB)
4.6	0.0	14	0
4.7*	1.0	13	1
4.9	2.0	12	2
5.2	2.9	11	3

Table continued...

System Noise Figure (dB)	System Input Intercept (dBm)	RFDS Gain (dB)	Cabinet RMC Attenuator Setting (dB)
5.5	3.9	10	4
5.9	4.9	9	5
6.3	5.9	8	6
6.7	6.9	7	7
7.2	7.8	6	8
7.8	8.8	5	9
8.4	9.8	4	10
9.1	10.7	3	11
9.9	11.6	2	12
10.6	12.5	1	13
11.4	13.4	0	14
12.3	14.3	-1	15
13.1	15.1	-2	16
14.0	16.0	-3	17
15.0	16.7	-4	18
15.9	17.4	-5	19
16.8	18.1	-6	20

* = Default: Recommended setting as shipped from the factory. Do not use these settings for Rx Expansion cabinets.

RMC System Gain

In addition to the DIP switch settings for the Receive Multicoupler (RMC) attenuation, the RMC system gain must be set up according to your GTR 8000 Base Radio configuration.



NOTICE: System gain is used to calculate RSSI (Receiver Signal Strength Indicator) value and Illegal Carrier Detection. When system gain is properly configured, the RSSI value read by the station (displayed in CSS) corresponds to the RF level at the input of the multicoupler system. System gain is automatically calculated when you select GTR 8000 Expandable Site Subsystem as your configuration.

Table 112: RMC System Gain for GTR 8000 Expandable Site Subsystem Configurations on page 284 shows what to select on the RMC Configuration tab in Figure 131: CSS RMC Configuration Tab with GTR 8000 Expandable Site Subsystem Selected on page 285. It also displays the resulting values that CSS displays in the System Gain field and include in the RMC configuration settings.


Table 112: RMC System Gain for GTR 8000 Expandable Site Subsystem Configurations

Your Configuration	Receive Multicoupler (RMC) Configuration Tab	Resulting System Gain
Expandable Site Subsystem with Site RMCs	1 GTR 8000 Configuration field: Select GTR 8000 Expandable Site Subsystem 2 Site RMC Configuration field: select: Installed	12 dB

Table continued...

Your Configuration	Receive Multicoupler (RMC) Configuration Tab	Resulting System Gain
Expandable Site Subsystem with no Site RMCs	<ol style="list-style-type: none"> GTR 8000 Configuration field: Select GTR 8000 Expandable Site Subsystem Site RMC Configuration field: Select Not Installed 	11 dB

Figure 131: CSS RMC Configuration Tab with GTR 8000 Expandable Site Subsystem Selected



Setting RMC System Gain

Prerequisites: If you do not know the IP address for the device, it is available through a serial port connection in the **Tools** → **Set IP Address** menu.

Procedure:

- 1 Connect to the device using Configuration/Service Software (CSS) through an Ethernet port link. See [Connecting Through an Ethernet Port Link on page 262](#).
- 2 From the navigation tree in the left pane, select **Configuration**.
- 3 Select the **Receive Multicoupler (RMC) Configuration** tab in the right pane.
- 4 Select your configuration, using the fields indicated in [Table 112: RMC System Gain for GTR 8000 Expandable Site Subsystem Configurations on page 284](#). Enter the **Site RMC Configuration**, **Site RMC Attenuation**, and **Cabinet RMC Configuration**.

System gain is automatically calculated and displayed in the System Gain field.

- 5 From the menu, select **File** → **Save** or **File** → **Save As** to save your RMC configuration to an archive on your local or network drive.
- 6 From the menu, select **File** → **Write Configuration to Device** to upload to the device.

The RMCs automatically use the resulting system gain. In addition, an appropriate base radio attenuation is automatically calculated, saved in the configuration file, and used.

Inline Attenuator Value for a GTR 8000 Expandable Site Subsystem with a TTA for UHF R2 and 700/800/900 MHz



NOTICE: For calculating the Inline attenuator value for a GTR 8000 Expandable Site Subsystem with a TTA for TDMA operation, see the *Dynamic Dual Mode for TDMA Operation* manual.

Table 113: RMC Attenuator Settings

Site Type	Single Cabinet Site	Multiple Cabinet Site
RMC Option	CA00861AA	CA00862AA, CA00877AA, or CA01821AA
Site RMC Attenuator	None	8 dB
Cabinet RMC Attenuator Setting	7 dB	13 dB

Calculating Inline Attenuator When a TTA is Installed

Prerequisites:

The Rx antenna must be disconnected from all base radios when performing this procedure. This procedure drops All calls present on the site.

When and where to use: This procedure is used to calculate the inline attenuator value only in the case where a customer-supplied Tower Top Amplifier (TTA) is used. This procedure optimizes the receive gain of all the base radios in a cabinet/rack and in any expansion cabinets/racks as well. There is no need to check or test each base radio. If you do not know the IP address for the device, it is available through a serial port connection in the **Tools** → **Set IP Address** menu.

Procedure:

- 1 Connect to the device using Configuration/Service Software (CSS) through an Ethernet port link. See [Connecting Through an Ethernet Port Link on page 262](#).
- 2 From the navigation tree in the left panel, select **Configuration**.
- 3 Select the **Receive Multicoupler (RMC) Configuration** tab.
- 4 In the **GTR 8000 Configuration** field, select **GTR 8000 Expandable Site Subsystem**.
- 5 Set the DIP switches on the Site RMC/LNA modules and Cabinet RMC/LNA modules to match the dB values that result from your calculations as described in [Table 113: RMC Attenuator Settings on page 286](#). Verify that the **GTR 8000 Base Radio Configuration** and **Site RMC Configuration** settings are correct.
- 6 Connect the analyzer cable from the service monitor to the test cable of the Tower Top Amplifier.
- 7 Remove and label the cable from the Branch 1 input at the top of the cabinet (this cable comes from the TTA control unit). Connect this cable to the service monitor port.
- 8 Set up the service monitor to generate a V.52 test modulation at a frequency to equal the base radio frequency and an output level of about -40 dBm. Increase this level by the TTA test port loss and test cable loss.
- 9 Adjust the electronic attenuator in the TTA control unit until the level indicates -30 dBm on the service monitor.



NOTICE: This procedure provides 10 dB gain from the TTA input to the cabinet input.

- 10 Disconnect the cable from the analyzer.

11 Reconnect the cable to the branch 1 input at the top of the cabinet.

12 For HPD or TDMA only, repeat for Rx Branch 2, starting at [step 5](#), to apply the same attenuator adjustments to Rx Branch 2.

Configuring Centralized Authentication on Devices in VoyenceControl

When and where to use: This process provides the procedures for configuring centralized authentication on devices using the VoyenceControl component of the Unified Network Configurator (UNC) application.



NOTICE: VoyenceControl does not apply for a K core or non-networked site.

Process:

- 1 Configure Domain Name Service (DNS) on the device. See “Configuring DNS on RF Site and VPM Devices in VoyenceControl” in the *Authentication Services* manual.
- 2 Configure Authentication Sources for the device. See “Configuring Authentication Sources for RF Site and VPM Devices in VoyenceControl in the *Authentication Services* manual.
- 3 Configure RADIUS parameters for the device. See “Configuring Radius Parameters for RF Site and VPM Devices in VoyenceControl” in the *Authentication Services* manual.
- 4 Set the Local Cache Size for Centralized Authentication for the device. See “Setting the Local Cache Size for Central Authentication on RF Site and VPM Devices in VoyenceControl” in the *Authentication Services* manual.
- 5 Enable/Disable Centralized Authentication for the device. See “Enabling/Disabling Centralized Authentication on RF Site and VPM Devices in VoyenceControl” in the *Authentication Services* manual.
- 6 Enable/Disable Centralized Event Logging for the device. See “Enabling/Disabling Centralized Event Logging on RF Site Devices and VPMs in VoyenceControl” in the *Centralized Event Logging* manual.

1PPS Reference Synchronization

The GPB 8000 Reference Distribution Module (RDM) reports when the available 1PPS references are out of synchronization. This synchronization validates that all redundant 1PPS signals can be used for fallback operation. This condition could occur for, example, if there is a failure with one of the GPS units or if the delay offset applied for the GPS unit cable length is incorrect.

GPS Unit Cable Length Delay Offset Calibration

Due to varying cable lengths between the GPS unit and the RDM, an offset value must be entered to compensate for the cable delay added to the 1PPS time reference signal.

The GPS unit supports the ability to advance the 1PPS timing reference to compensate for the delay associated with the cable length. This procedure is done using CSS or UNC to allow for the most accurate time across sites irrespective of the cable lengths used so as not to impact simulcast operation. The procedure is typically performed in the following scenarios:

- Installation and configuration of a high availability site.
- Replacement of an RDM.
- Replacement of a GPS unit.

- Replacement of the cable connecting the GPS unit to the RDM.

If the offset calibration is not performed, the accuracy of time reference is impacted, which causes simulcast operation to be non-functional.



NOTICE: Maximum GPS unit cable length should not exceed 350 ft. If cable length is between 350 and 800 ft, contact the Motorola Solution Support Center (SSC).

Use [Table 114: GPS Cable Length Delay Offset Value on page 288](#) to determine the delay offset value for calibration depending on the cable length. The cable is marked every ft, which enables measuring to be done easily.

Table 114: GPS Cable Length Delay Offset Value

Cable Length	Provisioned Delay (ns)
0 to 12 ft.	119
13 to 37 ft.	168
38 to 62 ft.	232
63 to 87 ft.	297
88 to 112 ft.	362
113 to 137 ft.	426
138 to 162 ft.	476
163 to 187 ft.	526
188 to 212 ft.	576
213 to 237 ft.	626
238 to 262 ft.	676
263 to 287 ft.	726
288 to 312 ft.	775
313 to 337 ft.	825
338 to 350 ft.	863



NOTICE: The table values specified are valid only for the cables supported by Motorola as specified in the *Trunked IP Simulcast Subsystem Remote Site* manual. If the installation requires use of another vendor or gauge of cable, contact Motorola for assistance.

Setting the GPS Unit Cable Length Delay Offset Calibration in the CSS

When and where to use:

Use this procedure to configure the cable length delay offset between the GPB 8000 Reference Distribution Module (RDM) and the GPS unit for cable lengths less than 350 ft using CSS.

Procedure:

- 1 Perform the following verification steps:
 - a The GPS unit is connected to the backplane with the appropriate cable length (less than 350 ft).
 - b Latest CSS version is installed on the service computer.

- 2 Connect to the RDM using Configuration/Service Software (CSS) through an Ethernet port link. See [Connecting Through an Ethernet Port Link on page 262](#).

- 3  **NOTICE:** If the GPS unit has not been calibrated, a GPS Major Failed (Cause Code: Cable Delay Uncalibrated) Alarm is reported.

From the menu, select **Service** → **Status Report Screen**.

The **Status Report Screen** window appears and the GPS Major Failed (Cause Code: Cable Delay Uncalibrated) station log is displayed.

- 4 Enter the cable length delay offset value:
 - a From the menu, select **Service** → **GPS Information**.
 - a Verify that the GPS is tracking at least four satellites.
 - b Enter the offset value in the **GPS Receiver Cable Delay Offset**. See [Table 114: GPS Cable Length Delay Offset Value on page 288](#).
 - c Click **Set Value**.

The **GPS Information** window appears.

- 5 Calibrate the RDMs as follows:
 - a From the menu, select **Service** → **Status Report Screen**.
 - b Wait a few minutes for calibration to complete.
When calibration is successful, the **Status Report Screen** displays the GPS Enabled station logs.

 **NOTICE:** If calibration was unsuccessful, the GPS Major Failed station log remains and the GPS is not enabled. Use the **Status Report Screen** to source the cause of failure. Depending on the entered cable delay, the RDM can take up to 10 minutes to output a 1PPS reference that can be used for simulcast.

- 6 Perform steps 2 through 5 for the other RDM.
- 7 Validate that both RDMs in the **Reference Service Screen** are within 250 nsec of each other. If not, verify the position information (latitude, longitude, and elevation) reported by the GPS units on both RDMs.

Setting the GPS Unit Cable Length Delay Offset Calibration in the UNC

When and where to use:

Use this procedure to configure the cable length delay offset between the GPB 8000 Reference Distribution Module (RDM) and the GPS unit for cable lengths less than 350 ft using UNC.

Procedure:

- 1 Perform the following verification steps:
 - a The GPS unit is connected to the backplane with the appropriate cable length (less than 350 ft).
 - b The RDM has already been discovered from the UNC.
 - c UNC version A7.9 or higher is being used.
- 2 Log on to the UNC from the NM client, by double-clicking the **Internet Explorer** icon on the desktop.

The **Internet Explorer** browser opens.

- 3 Enter: `http://ucs-unc0<Y>.usc`

where <Y> is the number of the UNC server (01 for primary core UNC server, and 02 for backup core UNC server).

The **UNC client** launches and then a login dialog box appears.

- 4 Type the administrative user name and password. Click **OK**.
VoyenceControl launches.
- 5 Expand **ASTRO 25 Radio Network** in the tree view.
- 6 Expand **Sites** in the tree view.
- 7 Expand **Zone** in the tree view containing the RDMs for calibration.
- 8 Double-click **Site** containing the RDMs for calibration.
- 9 Calibrate the RDMs as follows:
 - a Right-click the RDM and select **Editor**, then **Configlet**.
The **Configlet Editor** for the RDM appears.
 - b Under **Common Configlet**, enter: `GPS 1PPS Cable Delay Offset (ns) = xyz`
where xyz is the cable delay in nanoseconds corresponding to the cable length in [Table 114: GPS Cable Length Delay Offset Value on page 288](#).
 - c Click **Schedule**.
The **Schedule** window appears.
 - d Type the name of the job. Click **Approve and Submit**.
The job is approved and submitted.
 - e Open the job that was submitted and verify that the job was successful.
 - f Repeat substeps a through e for the other RDM in the site.

Chapter 5

GTR 8000 Expandable Site Subsystem Optimization

This chapter contains optimization procedures and recommended settings relating to the GTR 8000 Expandable Site Subsystem.

Your Motorola Field Representative or Motorola Solution Support Center (SSC) can advise you on optimization activities required for your system, if any. For example, for GTR 8000 Expandable Site Subsystems, obtain advice on whether a customized cavity combiner tuning procedure is required for optimizing RF Distribution System (RFDS) performance. See [Motorola Solution Support Center on page 344](#).

GCP 8000 Site Controller Reference Oscillator Alignment



NOTICE: This alignment is for both active and standby site controllers at a repeater site only.

After an active or standby site controller is installed, the reference oscillator must be aligned.



NOTICE: The base radios must be turned on for at least one week before the reference oscillator is aligned.

The site controller reference oscillator must be aligned to within 1 ppb (parts per billion). The frequency reference used to make this alignment should be accurate to within 1 ppb. This accuracy typically requires test equipment with a double oven or a Rubidium reference oscillator.

The reference oscillator must be aligned:

- Upon installation of the site controller for all bands.
- Once every year after installation for TDMA systems for all bands.
- Once every two years after installation for FDMA, 700/800/900 MHz systems.
- Once every five years after installation for FDMA, UHF systems.
- FDMA, VHF systems do not require alignment after initial installation.

See Site Controller Configuration & Service Help > Site Controller Procedures > Aligning the Reference Oscillator in the *CSS Online Help* for the alignment procedures.

Base Radio Internal Frequency Reference Oscillator Alignment

The transceiver option card within a base radio provides an internal 10 MHz frequency reference which can be used as the primary or backup frequency reference source for the device. For conventional base radio operation, it also provides the analog interfaces and wildcard I/Os.

After a base radio is installed or after the transceiver option card is replaced, the internal frequency reference oscillator must be aligned.

The transceiver option card internal frequency reference oscillator must be aligned to within 1 ppb (parts per billion). The measuring equipment used to make this alignment should be accurate to within 1 ppb. This accuracy typically requires test equipment with a double oven or a Rubidium reference oscillator.



NOTICE: The base radio must be turned on for at least one week before the internal frequency reference oscillator is aligned.

The internal frequency reference oscillator for an OCXO transceiver option card must be aligned:

- Upon installation of the base radio for all bands.
- Once every two years after installation for 700/800/900 MHz systems.
- Once every five years after installation for UHF systems.
- VHF systems do not require alignment after initial installation.

The internal frequency reference oscillator for a TCXO transceiver option card must be aligned:

- Upon installation of the base radio for UHF.
- Every year after installation for UHF.

The internal frequency reference oscillator can be aligned using two methods: manual alignment or auto alignment.

See Base Radio Service Help > Service Screens > Alignment Screens in the *CSS Online Help* for the alignment procedures.

GTR 8000 Base Radio Time and Frequency Inputs

Various external time and frequency inputs can be provided to the base radio for normal operation or for Internal Frequency Reference Oscillator alignment. The following table provides a list of acceptable input signal types and levels for each input port.

Table 115: Time and Frequency Inputs

Input Port	Frequency	Waveform	Level	Impe- dance	Note
Ext Freq Ref	5 MHz	Sine	2.6–5.3 Vpp	100k ohms	AC coupled
Ext Freq Ref	5 MHz	Square	45–55% duty cycle	100k ohms	AC coupled
Ext Freq Ref	10 MHz	Sine	2.6–5.3 Vpp	100k ohms	AC coupled
Ext Freq Ref	10 MHz	Square	45–55% duty cycle	100k ohms	AC coupled
Ext Freq Ref	20 MHz	Sine	2.6–5.3 Vpp	100k ohms	AC coupled
Ext Freq Ref	20 MHz	Square	45–55% duty cycle	100k ohms	AC coupled
Ext Freq Ref	5 MHz/ 1PPS*	Square	2.6–5.3 Vpp	100k ohms	AC coupled; 25% modulation 1pps arrives on 75% duty cycle
1PPS	1PPS	Pulse	2.6–5.3 Vpp	100k ohms	DC coupled
Front Panel Ext Freq Ref	5 MHz	Sine	2–5 Vpp; 10–18 dBm	50 ohms	AC coupled
Front Panel Ext Freq Ref	5 MHz	Square	45–55% duty cycle	50 ohms	AC coupled
Front Panel Ext Freq Ref	10 MHz	Sine	2–5 Vpp; 10–18 dBm	50 ohms	AC coupled

Table continued...

Input Port	Frequency	Waveform	Level	Impedance	Note
Front Panel Ext Freq Ref	10 MHz	Square	45–55% duty cycle	50 ohms	AC coupled
Front Panel Ext Freq Ref	5 MHz/ 1PPS*	Square	2.6–5.3 Vpp	50 ohms	AC coupled; 25% modulation 1pps arrives on 75% duty cycle

* 25% modulation, 1PPS arrives on 75% duty cycle.




NOTICE: The Front Panel EXT FREQ REF connection is the Frequency Calibrator (BNC connector) on the transceiver module.

Cavity Combiner Tuning


Figure 132: GTR 8000 Expandable Site Subsystem Cavity Combiner for 700/800 MHz on page 293 and Figure 133: GTR 8000 Expandable Site Subsystem Cavity Combiner for UHF on page 294 show the GTR 8000 Expandable Site Subsystem cavity combiners for 700/800 MHz and UHF (450–509 MHz), with arrows to assist you in following [Tuning the Cavity Combiner For Six Carriers on page 294](#) and [Cavity Combiner Tuning for Twelve Carriers \(700/800 MHz\) on page 300](#) to tune the combiner. The RF input cable, built in circulator, and tuning knob have been identified for one of the six cavities.

Figure 132: GTR 8000 Expandable Site Subsystem Cavity Combiner for 700/800 MHz



GTR8000_expandable_site_subsystem_combiner2

Figure 133: GTR 8000 Expandable Site Subsystem Cavity Combiner for UHF



WARNING: Shock hazard. The GTR 8000 Expandable Site Subsystem contains dangerous voltages, which can cause electrical shock or damage to equipment. Set the switches on the front of the power supplies to the off (O) position when servicing this component in the Expandable Site Subsystem. Also, shut down any other racks that are connected to this GTR 8000 Expandable Subsystem.



IMPORTANT: Powering down the GTR 8000 Expandable Site Subsystem causes any affiliated subscribers to relocate to another channel at the site or another channel at an adjacent site. Place the channels in Service Mode before starting the tuning procedure, so that the system does not attribute the loss of channel to a failure. Placing a channel in Service Mode is performed using Unified Event Manager (UEM) Diagnostics or the Configuration/Service Software (CSS).

[Tuning the Cavity Combiner For Six Carriers on page 294](#) summarizes tuning for both 700/800 MHz and UHF cavity combiners. [Cavity Combiner Tuning for Twelve Carriers \(700/800 MHz\) on page 300](#) summarizes tuning for only 700/800 MHz cavity combiners. In either frequency sub-band, the tuning procedure is the same regardless of carrier sequence. In a twelve carrier application, each six channel combiner is tuned first, followed by the phasing harness installation, then retuning of both combiners to meet twelve carrier performance.



NOTICE: In all applications, initially tune the combiner to the intended operating frequency by use of a network analyzer, looking at a composite Output Return Loss (ORL) response curve as described in [Tuning the Cavity Combiner For Six Carriers on page 294](#). Afterwards, fine-tuning of the combiner can be performed by keying the base radios, one at a time, and maximizing the output power for that carrier by use of an externally connected power meter. Tuning should be accomplished first at low-power levels, approximately -10 dB to -6 dB followed by rated power.

Tuning the Cavity Combiner For Six Carriers

When and where to use: Use this procedure to tune up to six carriers for either the 700/800 MHz cavity combiner or the UHF cavity combiner. This procedure is also the basis when tuning a 7-12 carrier application for 700/800 MHz. See [Changing Frequencies, Adding Channels, and Realigning a](#)

[700/800 MHz and UHF Cavity Combiner on page 299](#) to change frequencies, add channels, and realign either the 700/800 MHz or UHF cavity combiner.

Procedure:

- 1 Wear an electrostatic discharge (ESD) strap and connect its cable to a verified good ground. This strap must be worn throughout this procedure to prevent ESD damage to any components.
- 2 Connect to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
- 3  **NOTICE:** Powering down the GTR 8000 Expandable Site Subsystem causes any affiliated subscribers to relocate to another channel at an adjacent site. Disable the site before powering down, so the system does not attribute the loss of channel to a failure.

To disable the site, perform one of the following actions:

If...	Then...
The site controllers are in the cabinet/rack,	perform the following actions: <ol style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Site Info tab. c In the User Requested Site State list box, select Site OFF.
The site controllers are at the prime site,	perform the following actions: <ol style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Subsite tab. c Click in the User Requested Site State cell of the subsite to be disabled and choose User Ignore.


The site is disabled.

- 4 Set all the switches on the front of the power supplies to the Off (O) position to power down the entire GTR 8000 Expandable Site Subsystem. Allow the combiner to cool for 15 minutes. Also shut down any other expansion cabinets/racks that are connected to the GTR 8000 Expandable Site Subsystem.
- 5 After the combiner has cooled for at least 15 minutes, disconnect and label the cabling from the front of the combiner:
 - a Remove the 7/16-inch DIN output cable.
 - b Label and remove the QN-type RF input connectors. **IMPORTANT:** Label the cavities and their associated RF input cables Ch1 through Ch6. You must know these numbers for the tuning procedure, and for reconnecting the cables.
- 6 Set up a Network Analyzer (HP/Agilent 8753B or equivalent) in the S11 (reflection) mode to cover a few hundred kHz below and above the carrier frequency range of the combiner by performing the following:
 - a Set number of points to 801.
 - b Set IF bandwidth to 3 kHz.
 - c Place a Network Analyzer marker at the desired carrier center frequency for each resonator being tuned.
 - d Store calibration in a register.

 **NOTICE:** It is not a requirement that the electrical delay is known for the type of connector and adaptors used during calibration; only $\text{mag}|S_{11}|$ is used for combiner tuning.

- 7 Connect the Network Analyzer to the 7/16 DIN output port.

Figure 134: Cavity Combiner Tuning - Equipment Setup for 700/800 MHz and UHF




GTR8000_RFDS_XS_Tuning6

- 8 Starting with combiner channel 1, loosen the locking knob. Holding the locking knob with one hand, use the other hand to tune channel 1 to the assigned carrier frequency; clockwise to decrease center frequency, counter clockwise to increase center frequency.
- 9 With channel 1 tuned and the Network Analyzer marker at an S11 minimum, lightly tighten the locking knob while continuing to hold the tuning knob.

 **NOTICE:** The tuning knob is adjusted at least once more.

- 10 Repeat [step 7](#) and [step 9](#) for all remaining combiner channels. A typical ORL response curve may look like [Figure 135: Six-Carrier ORL Response Curve — Untuned on page 297](#). Note that channels 5 and 6 ORL are much less than channels 1 and 2. Balanced is compensated for in [step 12](#). Closely spaced carriers may require repeating [step 7](#) and [step 9](#) for some channels.

Figure 135: Six-Carrier ORL Response Curve — Untuned



11 Any unused combiner channel should be tuned to a frequency at least a few hundred kHz away from any active carrier frequency assigned to a common transmit antenna. However, if an unused channel carrier frequency is known at this time, this channel can be tuned to that frequency even though a base radio is not present. This tuning simplifies the process of adding new carriers at a later date. Any unused channel’s locking knob can be securely tightened at this time.

12 Balance the ORL response by adjusting the combining manifold knobs. The knobs are labeled, “90° rotation only”. These knobs loosen and tighten the same way as the resonator tuning knobs.



CAUTION: The combining manifold tuning knobs rotate less than a quarter turn, so be careful in turning these knobs. Attempting to turn past the mechanical stop can damage the combining manifold.

13 Observing ORL response for all channels, adjust both combining manifold knobs until the ORL response curve reaches similar local minimum on all channels as best possible. See [Figure 136: Six-Carrier ORL Response Curve — Tuned on page 297](#) and [Figure 137: Six-Carrier ORL Response Curve — Tuned and Balanced on page 298](#). It is desired that all channels achieve a |dB(S11)| at least 13 dB (a goal, not a requirement). Final adjustment is made under power.



NOTICE: One or more channel center frequency may have changed tuning the manifold. This center frequency is normal and is compensated in [step 14](#).

Figure 136: Six-Carrier ORL Response Curve — Tuned





Figure 137: Six-Carrier ORL Response Curve — Tuned and Balanced



- 14 After [step 13](#) it may become necessary to re-adjust one or more channel's center frequency, as described in [step 7](#) and [step 9](#). Adjust the appropriate channels so the local minimum is at or very close to the channel's marker.
 - 15 After tuning is completed, lightly re-tighten all locking knobs. The combiner is ready for final adjustment.
 - 16 Reconnect the cabling to the front of the combiner:
 - a Reconnect the QN-type RF input connectors to the appropriate ports.
 - b Secure the 7/16-inch RF output cable to the output connector.
 - c Connect an external wattmeter to the antenna port. The output of the wattmeter should be terminated with the transmit antenna or an appropriate load.
 - 17 Set the rocker switches on the front of the power supplies to the On (I) position, to power up the GTR 8000 Expandable Site Subsystem. Also restore power to any other expansion cabinets/racks that are connected to the GTR 8000 Expandable Site Subsystem.
 - 18 Verify that the GTR 8000 Expandable Site Subsystem is operating properly using fault management software, including Unified Event Manager, and the Transmitter Metering Screen in Configuration/Service Software (CSS).
 - 19 Key up each base radio, one at a time, at a low-power level (approximately -10 dB to -6 dB of rated). The wattmeter should use averaging.
 - 20 Adjust the appropriate combiner's tuning knob until the power meter registers a maximum. Lightly secure the locking knob.
 - 21 Go to the next channel until all carriers have been re-adjusted.
 - 22 At this time, it is not essential that the combining manifold knobs be re-adjusted. However, if you choose to do so, re-apply the same low-power level to all the base radios simultaneously and adjust the tuning knobs accordingly. These locking knobs can be secured in their final position once this step is completed.
-  **CAUTION:** Be careful during this step, as adjusting the manifold can create an imbalance between two or more carriers. Since a Network Analyzer is not connected during this test, it cannot be determined which channel or channels are being adversely affected.
- 23 Repeat [step 20](#) at rated power; to all channels simultaneously. Allow system to reach equilibrium and re-adjust individual tuning knobs to maximize antenna power. Properly secure locking knobs after tuning is completed.

24 De-key all radios, remove the wattmeter, and reconnect the antenna.

25 To enable the site, perform one of the following actions:

If...	Then...
If the site controllers are in the cabinet/rack,	perform the following actions: <ul style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Site Info tab. c In the User Requested Site State list box, select Wide Trunking.
If the site controllers are at the prime site,	perform the following actions: <ul style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Subsite tab. c Click in the User Requested Site State cell of the subsite to be enabled and choose Enabled.

The site is enabled.

Changing Frequencies, Adding Channels, and Realigning a 700/800 MHz and UHF Cavity Combiner

Procedure:

- 1** Wear an electrostatic discharge (ESD) strap and connect its cable to a verified good ground. This strap must be worn throughout this procedure to prevent ESD damage to any components.
- 2** Place the base radio corresponding to the cavity being tuned in Service Mode, as follows:
 - a** Connect to the base radio using Configuration/Service Software (CSS) through an Ethernet port link. See [Connecting Through an Ethernet Port Link on page 262](#).
 - b** From the menu, select **Service** → **Test and Measurement Screen**.
The **Test and Measurement Screen** appears.
 - c** Click **Change to Service Mode**.
 - d** At the confirmation screen, click **OK**.
The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.
- 3** Open the connections between the circulator load port and the circulator load. A sampling port adaptor may or may not be used. The sampling port adaptor is available through Motorola Solution Support Center (SSC). Perform one of the following actions:

If...	Then...
If a sampling port adaptor is being used,	perform the following actions: <ul style="list-style-type: none"> a Insert the sampling port between the circulator load port and the circulator load. b Connect the output of the coupler to a power meter or a service monitor. The sampling port adaptor is a 30-40 dB coupler. An attenuator may be required on the coupled port to protect measurement equipment from excessive power.


If...	Then...
If a sampling port adaptor is Not being used,	perform the following actions: <ol style="list-style-type: none"> a Connect the output of the circulator load port to a power meter or a service monitor. b An attenuator may be required on the coupled port to protect measurement equipment from excessive power.

- 4 Re-key the radio at -10 dB to -6 dB of rated power.
- 5  **IMPORTANT:** If it is necessary to pass over a carrier frequency already in operation, that carrier will be momentarily affected. It is recommended to temporarily de-key that carrier. If this is not practical, realize there would be a few dB temporary reduction in power of the carrier already in operation.
 Tune the cavity for minimum power at the desired frequency.
- 6 Adjust the radio for full rated out power, key-up, and after five minutes re-tune the cavity for minimum power.
- 7 De-key the radio and remove test equipment, and reconnect circulator load.
- 8 Repeat [step 2](#) through [step 7](#) for any additional channels that need to be re-tuned.
- 9 If no further testing is needed, place the base radio in Normal Mode, as follows:
 - a** From the menu, select **Service** → **Test Measurement Screen**.
 The **Test and Measurement Screen** appears.
 - b** Click **Change to Normal Mode**.
 - c** At the confirmation screen, click **OK**.
 The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.

Cavity Combiner Tuning for Twelve Carriers (700/800 MHz)

Transmit expansion to 7-12 carriers requires use of a phasing harness (see [Figure 138: Phasing Harness on page 300](#)). In each case, a phasing harness consists of a combining “T” mounting bracket and two cables. One cable is labeled “primary”; the other is labeled “expansion.” The 700 MHz phasing harness must be used with the 700 MHz cavity combiner and likewise with 800 MHz.


Figure 138: Phasing Harness



[Figure 139: Phasing Harness on page 301](#) shows the use of a phasing harness in 7-12 carrier applications. The transmit expansion cabinet is allowed to be placed on either side of the primary

cabinet as long as cabinets are placed immediately next to one another (one inch or less) and the combiners are at about the same height.

Figure 139: Phasing Harness



NOTICE: The 700 MHz phasing harness must be used with a 700 MHz cavity combiner and likewise with 800 MHz.


The phasing harness arrives from the supplier with the "T" attached to the mounting bracket and cables detached. The mounting bracket arrives with four captive screws. These screws are used to secure the mounting bracket to the cavity combiner's mounting handles using a Torx driver, size T20, at a torque of about 12-15 in.-lbs. The phasing harness is always mounted to the combiner in the same rack/cabinet as the transmit antenna connection, commonly known as the transmit primary cabinet. The phasing harness output connects to the transmit filter. This is the same cable used to connect the combiner directly to the transmit filter in six-carrier (non-transmit expansion) applications.

Tuning the Cavity Combiner for up to Twelve Carriers for 700/800 MHz

Procedure:

- 1 Follow [step 7](#) through [step 11](#) of [Tuning the Cavity Combiner For Six Carriers on page 294](#) for the primary and expansion cabinet/rack cavity combiners. If the carrier frequencies are spaced in such a manner that a portion of the sub-band has a group of carriers, for instance 852-856 MHz, while another portion of the sub-band has a second group of carriers say, 864-867 MHz, calibrate the Network Analyzer for each separate group of frequencies and store each calibration in a different register. [Figure 135: Six-Carrier ORL Response Curve — Untuned on page 297](#) applies for this procedure in the same manner it did for [Tuning the Cavity Combiner For Six Carriers on page 294](#).
- 2 Connect the appropriate phasing harness to the combiners. See [Figure 139: Phasing Harness on page 301](#) and [Figure 132: GTR 8000 Expandable Site Subsystem Cavity Combiner for 700/800 MHz on page 293](#). Attach the Network Analyzer to the phasing harness output. An example of a twelve carrier response is shown in [Figure 140: Twelve-Carrier ORL Response Curve — Untuned on page 302](#).

Figure 140: Twelve-Carrier ORL Response Curve — Untuned



- 3 Repeat [step 12](#) through [step 14](#) of [Tuning the Cavity Combiner For Six Carriers on page 294](#) for the twelve carrier setup. Balancing ORL requires adjustment of the manifold tuning knobs on each combiner a few times, alternating back and forth between combiners (See [Figure 141: Twelve-Carrier ORL Response Curve — Tuned on page 302](#) and [Figure 142: Twelve-Carrier ORL Response Curve — Tuned and Balanced on page 303](#)). Note in [Figure 141: Twelve-Carrier ORL Response Curve — Tuned on page 302](#) how manifold adjustment can appear to make one carrier disappear (middle of plot). This also occurs when tuning one resonator through and past another.

Figure 141: Twelve-Carrier ORL Response Curve — Tuned





Figure 142: Twelve-Carrier ORL Response Curve — Tuned and Balanced

- Repeat [step 19](#) through [step 25](#) of [Tuning the Cavity Combiner For Six Carriers on page 294](#) for the phase-harnessed setup.



CAUTION: Care should be exercised during these steps; dealing with high-power levels. Twelve base radios at rated power results in approximately 600 W average output power and approximately 25k W Peak Envelope Power (PEP) at the antenna port.

Battery Equalization

Battery Equalization configures the power supply to set the proper charge and capacity for the storage batteries connected to the base radio. Sites equipped with storage batteries that provide power in case of primary power failure require that the battery cells be equalized periodically.

See “**Base Radio Service Help** → **Service Screens** → **Alignment Screens**” in the *CSS Online Help* for the alignment procedures.



NOTICE: Some batteries do not require equalization. See the battery manufacturer recommendations.

ASTRO Simulcast Alignment (Trunked Operation)

ASTRO[®] 25 Simulcast Alignment is used to enter a Launch Time Offset value (range 0.0 to 1000.0 usec), store the value in the base radio, and initiate a simulcast test pattern.

See “Base Radio Service Help → Service Screens → Alignment Screens” in the *CSS Online Help* for the alignment procedures.

ASTRO/Analog Simulcast Alignment (Conventional Operation)

In an ASTRO[®] 25 simulcast subsystem, all station transmitters are synchronized to a 1 pulse per second (1PPS) signal from a Global Positioning Satellite (GPS) receiver. The 1PPS signal provides a common time reference for each of the transmitters. The ASTRO[®] 25 signaling information arriving at the station transmitter includes timestamps that specify the transmit offset delay for the voice and data transmissions.

The ASTRO[®]/Analog Alignment screen allows adjustment of the overlap coverage areas, and to specify a launch time offset value, with a 0.1 μ s resolution. This value is added to the arriving launch

time value to provide an adjusted launch time. The specified ASTRO® 25 simulcast transmit offset delay value applies only to ASTRO® 25 simulcast subsystems and is considered optional. The default offset value is 0 (zero), causing no adjustment to the launch time specified by the arriving timestamp value.

For Analog Simulcast, the Transmit Offset Delay merely delays the Analog Simulcast Audio to provide the adjustment in the overlap coverage areas.

See “**Base Radio Service Help** → **Service Screens** → **Alignment Screens**” in the *CSS Online Help* for the alignment procedures.

Carrier Squelch Alignment

A Carrier Squelch (CSQ) Alignment is typically performed at an RF level which corresponds to 12 dB SINAD, or an RF level which corresponds to 20 dB quieting, or any other RF level selected.

The **CSQ Alignment** screen facilitates the measurement of 12 dB SINAD for the base radio under testing by allowing the Rx Qualifiers to be set to Open. When the Rx Qualifiers are set to Open, receive audio is gated to the WL2 wireline port or to the speaker, regardless of the RF input level. The preferred SINAD measurement port is the WL2 wireline port; however, the speaker can also be used.

When measuring SINAD, the pre-emphasis and high pass filters are set as they would be for analog voice operation. Because the channel characteristics are different, this procedure allows for CSQ Alignment and is done for both 12.5 kHz and 25 kHz channel bandwidth. If the station is configured for only one channel bandwidth, there is no need to perform a CSQ Alignment for the other bandwidth.

See “**Base Radio Service Help** → **Service Screens** → **Alignment Screens**” in the *CSS Online Help* for the alignment procedures.

Tx Wireline Alignment

Tx Wireline Alignment is used to set the levels to result in 60% system deviation for both Wireline Level Line 1(WL1) and Wireline Level Line 3 (WL3) and for setting the Wireline Squelch levels.

See “**Base Radio Service Help** → **Service Screens** → **Alignment Screens**” in the *CSS Online Help* for the alignment procedures.

Rx Wireline Alignment

Rx Wireline Alignment is used only for a base radio that processes analog receive audio and is connected with a 2- or 4-wire link to a console or a comparator in an analog only topology or an ASTRO® 25 Analog/Mixed mode topology.

See “**Base Radio Service Help** → **Service Screens** → **Alignment Screens**” in the *CSS Online Help* for the alignment procedures.

GTR 8000 Expandable Site Subsystem Performance Testing with a Service Monitor for Integrated Voice and Data

The service monitor is a diagnostic tool used with a GTR 8000 Expandable Site Subsystem or modem to test and measure the transmitter and receiver characteristics. The Service Monitor generates signaling and provides diagnostic information for received signaling.

The Service Monitor is connected to a GTR 8000 Expandable Site Subsystem to perform the diagnostic tests. These tests are designed to determine whether the equipment is operating within specification. If a GTR 8000 Expandable Site Subsystem fails to meet specification, service may be required.

GTR 8000 Expandable Site Subsystem Performance

Perform these procedures when you first set up your system and afterwards on a regular basis (for additional tests, see the service monitor manual). While these procedures are not truly configuration or optimization tasks, they are provided because you may need to perform some of these procedures to test if the radio performance is correct.

The following procedures are:

- [Deviation Standards \(Digital Operation\) on page 305](#)
- [Monitoring the Power Supply Module on page 305](#)
- [Verifying Receiver Performance for FDMA Operation on page 306](#)
- [Verifying Receiver Performance \(Analog Operation\) on page 311](#)
- [Checking Receiver Sensitivity \(Self-test Method\) \(IV and D\) on page 313](#)
- [Monitoring the Transmitter Metering Points on page 314](#)
- [Verifying Transmitter Performance \(Digital Operation\) on page 314](#)
- [Verifying Transmitter Performance \(Analog Operation\) on page 316](#)

Deviation Standards (Digital Operation)



NOTICE: These specifications allow a tolerance of $\pm 10\%$. However, because the accuracy of the service monitor is only $\pm 5\%$, the allowable tolerance in the measured deviation is $\pm 5\%$ and not $\pm 10\%$.

Table 116: Deviation Standards for ASTRO 25 System Test Patterns

Signal	Minimum Deviation	Nominal Deviation	Maximum Deviation
low signal deviation	0.84 kHz	0.93 kHz	1.02 kHz
sow signal wide pulse deviation	undetermined	1.00 kHz	undetermined
standard deviation	2.55 kHz	2.83 kHz	3.11 kHz
standard wide pulse deviation	undetermined	3.00 kHz	undetermined
V.52 deviation	2.91 kHz	3.23 kHz	3.55 kHz
V.52 wide pulse deviation	undetermined	3.00 kHz	undetermined
C4FM deviation	2.91 kHz	3.23 kHz	3.55 kHz
C4FM wide pulse deviation	undetermined	3.00 kHz	undetermined
GPS test pattern - simulcast	undetermined	3.00 kHz	undetermined
ASTRO [®] 25 system voice	3.24 kHz	3.60 kHz	3.96 kHz
ASTRO [®] 25 system wide pulse	undetermined	3.00 kHz	undetermined

Monitoring the Power Supply Module

Perform the following procedure to monitor the power supply.


Procedure:

- 1 Connect to the base radio in Configuration/Service Software (CSS) through an Ethernet connection. See [Connecting Through an Ethernet Port Link on page 262](#).

- From the menu, select **Service** → **Metering Screens**.

The **Metering Screen** window opens on the **Power Supply** tab.

Figure 143: Metering Screen Window



Item	Meter Value
DC Output Voltage (Volts)	29.0
DC Output Current (Amps)	1.1
Power Supply Ambient Air Inlet Temp ...	27.0
Power Supply Ambient Air Outlet Tem...	32.5
Battery Charger Output Voltage (Volts)	0.1
Battery Charger Output Current (Amps)	0.0

Verifying Receiver Performance for FDMA Operation

When and where to use: Use this procedure to verify receiver performance by measuring the Bit Error Rate (BER) and RSSI for the GTR 8000 Expandable Site Subsystem for ASTRO® 25 performance.

Procedure:

- Connect to the transceiver module in CSS through an Ethernet connection. See [Connecting Through an Ethernet Port Link on page 262](#).
- From the menu, select **Service** → **Test Measurement Screen**.
The **Test And Measurement Screen** appears.
- Select the **ASTRO BER RSSI Report** tab.
- Make the following connections to the GTR 8000 Expandable Site Subsystem depending on the frequency band:
 - For 700/800/900 MHz and UHF R2 (435–524 MHz) frequency bands, connect the service monitor GEN port to the Site Preselector Test Port with a BNC connector. The test port on the TTA (if present) may also be used.
 - For VHF (136–174 MHz) and UHF R1 (380–435 MHz) frequency bands, disconnect the cable from the Rx Port on the Receiver Input junction panel and connect the service monitor GEN port to the corresponding Rx Port on the Receiver Input junction panel.
- Set up the service monitor:
 - Set up to generate Project 25 test pattern.
 - Set the service analyzer to generate at the receive frequency.
 - Set the RF level depending on the frequency band:
 - For 700/800/900 MHz and UHF R2 (435–524 MHz) frequency bands, set the RF level to an initial value of -20 dBm.
 - For VHF (136–174 MHz) and UHF R1 (380–435 MHz) frequency bands, set the RF level to an initial value of -50 dBm.



NOTICE: For 700/800/900 MHz and UHF R2 (435–524 MHz) frequency bands, the levels are high since the test point coupler loss is +30 dB.

- 6** If the base radio is not already in Service Mode, place in Service Mode, as follows:
- a** Click **Change to Service Mode**.
 - b** At the confirmation screen, click **OK**.
The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.
 - c** Re-open the **Test And Measurement Screen** as described in [step 2](#).
- 7** Set up the test in CSS:
- a** From the **Pattern Type** field, select **1011 Hz (FDMA)**.
 - b** From the **Sampling Period (sec)** list box, enter the number of required seconds.
The time specifies the window over which the BER is calculated.
- 8** Measure the BER and RSSI:
- a** Click **Start BER Measurement**.
The **Test and Measurement Screen** displays the following:
 - BER results in percentage
 - RSSI results expressed in dBm

 **NOTICE:** With the initial setting of the service monitor set for a carrier level of -20 dBm (>450 MHz) or -50 dBm (<450 MHz), you should expect a BER of 0.0% and an RSSI level between -48 dBm and -52 dBm. Remember to compensate for the loss of the cable connecting the service monitor to the base radio.

 **NOTICE:** If the receiver is inhibited, RSSI displays a meaningless value.
 - b** Click **Start Log** to create a log file for the BER and RSSI measurement.
The **Log Save As** window appears.
 - c** Change the RF level and read the BER and RSSI again at the level appropriate for the base radio.
The value should be less than 5%. See [GTR 8000 Expandable Site Subsystem Specifications on page 67](#) for the appropriate value.

 **NOTICE:** Since the receive antenna and TTA, if installed, is connected during this measurement, any noise from the antenna can degrade the performance of the system.
 - d** Key the transmitter in the base radio and readjust the generator output level until 5% BER is indicated on the service analyzer. Record this level.
Less than 1 dB of degradation should occur due to the transmitters being keyed.
 - e** Dekey the transmitter.
 - f** Click **Stop BER Measurement** to stop the test.
- 9** If Rx B is used as a back and the site is not TDMA:
- a** Disconnect the test cable from the generator to Rx A at the base radio and connect it to Rx B.
 - b** Increase the generate level to -47 dBm.
 - c** Wait for Branch A to fail. Alarms may be generated during testing.
 - This can take up to two (2) minutes.

- CSS Channel tab **Time to Failure (sec)** field controls the time to fail.
- d Repeat [step 8](#).
- 10** If no further testing is needed, place the base radio in Normal Mode, as follows:
- a Click **Change to Normal Mode**.
 - b At the confirmation screen, click **OK**.
- The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.
- 11** Remove and restore the following connections to the GTR 8000 Expandable Site Subsystem depending on the frequency band:
- For 700/800/900 MHz and UHF R2 (435–524 MHz) frequency bands, remove the service monitor GEN port connection from the Site Preselector Test Port or TTA, if present.
 - For VHF (136–174 MHz) and UHF R1 (380–435 MHz) frequency bands, remove the service monitor GEN port from the Rx Port on the Receiver Input junction panel and reconnect the cable previously removed to the Rx Port on the Receiver Input junction panel.

Verifying Receiver Performance in TTA Operation

This procedure explains how to verify receiver performance in a system where a Tower Top Amplifier (TTA) is present.

Consult with any documentation that is specific to your system for the value of TTA Reserve Gain. If no information is available, use the following guidelines:

- For most situations, the TTA Reserve Gain should be in the 5 dB to 10 dB range.
- In the absence of guidance specific to your system, 7.5 dB is a useable value for TTA Reserve Gain.



NOTICE: This procedure for TTA testing is valid only for FDMA operation. An entirely different procedure for TTA testing is required for TDMA operation. Contact your system administrator for guidance, then contact your Motorola Solutions representative for assistance.

The Receive path attenuators must be configured before performing this part of the procedure. The Rx path to the Rx antenna on the tower must be complete.

When and where to use:

Use this procedure to verify receiver performance in a system where a Tower Top Amplifier (TTA) is present.

Procedure:

- 1** Perform test setup:
 - a Configure the analyzer to generate an STD1011 pattern.
 - b Connect the Analyzer Gen port (3900) or the RF Generator Out port (S412E) to the TTA Test Port using a TNC-m (3900) or N-m (S412E) to BNC-m test cable with known loss. Record the cable loss value on the T tab, Test Cable #4.
 - c Configure the TTA so that the Antenna port is terminated in a 50 Ω load. If the TTA controller has a time out feature for the termination, make sure you periodically reset the TTA termination as needed.
- 2** Connect to the transceiver module in Configuration/Service Software (CSS) through an Ethernet connection. See [Connecting Through an Ethernet Port Link on page 262](#).
- 3** If the base radio is not in service mode perform the following, otherwise go to the next step.
 - a From the CSS menu, select **Service** → **Test And Measurement Screen**.

- b** Click **Change to Service Mode**.
 - c** At the confirmation screen, click **OK**.
The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.
 - d** Re-open the **Test And Measurement Screen**.
- 4** Initiate TTA testing:
- a** On the **Test And Measurement Screen**, select the **ASTRO BER RSSI Report** tab.
 - b** In the **Pattern Type** field, select **Project 25**.
 - c** In the **Sampling Period (sec)** list box, enter 1 for the required seconds.
 - d** Set the Analyzer Generate Frequency equal to the Base Radio Rx Frequency.
- 5** Test the Rx Noise Level with the TTA terminated:
- a** Turn the analyzer generator OFF.
 - b** In CSS, click **Start RSSI Measurement**.
 - c** Record the RSSI Value in the RSSI Level Terminated field of the FDMA Chan sheet.
This Rx Noise Level is a relative value and used for future comparisons.
- 6** Test the Rx RSSI Test Port Reference Level with the TTA terminated:
- a** Turn the analyzer generator ON.
 - b** Establish an Analyzer Generate RF Level that produces an RSSI Level of -90.0 dBm.
 - c** Record the Analyzer Generate RF Level in the Gen Level Reference field of the FDMA Chan sheet.
The sheet calculates the Actual Reference Level.
 - d** In CSS, click **Stop RSSI Measurement**.
- The Actual Reference Level is a relative value used for future comparisons to assist in troubleshooting.
- This test establishes a known reference that is about 30 dB above the typical noise floor, which minimizes the contribution of noise to the measurement and is a better indicator of the gain through the receive system.
 - Testing at the sensitivity level is a function of the carrier to noise ratio. Noise has a much bigger impact when testing at the sensitivity level.
 - The goal of this test is to give you the information to determine if you have a gain issue or a noise issue when troubleshooting a receive problem.
- 7** Test the Rx Sensitivity with the TTA terminated:
- a** In CSS, click **Start BER Measurement**.
 - b** Adjust the Analyzer Generate RF Level for a $5\% \pm 0.25\%$ BER.
 - c** Record the Analyzer Generate RF Level in the Gen Level Terminated field of the FDMA Chan sheet.
 - d** In CSS, click **Stop BER Measurement**.
 - e** Click **Start RSSI Measurement**.
 - f** Record the RSSI (dBm) value in the RSSI Sensitivity field of the results sheet.

g Click **Stop RSSI Measurement**.

The Test Result Sheet calculates the Actual Sensitivity Term using Sensitivity Terminated – Test Cable Loss - TTA Test Port Cable Loss - TTA Test Port Coupling Loss. This result is the reference used to determine site degradation or de-sense in the following tests.

- 8** Test Rx De-sense for TTA Normal without other transmitters keyed. The degradation is < 2 dB @ 700/800/900 MHz, < 6 dB @ 450 MHz, or < 10 dB @ 150 MHz.



CAUTION: This test and the following Rx De-sense TTA Normal with Transmitters Keyed test cannot be performed accurately if the channel is in use within the coverage area of the site (for example, a legacy system waiting for cutover).

- a** Configure the TTA so that the antenna port is connected to the antenna (normal operation).
- b** In CSS, click **Start BER Measurement**.
- c** If needed, readjust the Analyzer Generate RF Level for $5\% \pm 0.25\%$ BER. Watch the CSS BER for about 1 minute.
- d** Record the Analyzer Generate RF Level in the Gen Lvl Desense no Tx field of the result sheet. The difference between this generator RF level and the level recorded in the Rx Sensitivity with the TTA Terminated test is the site degradation/de-sense.



NOTICE: If the BER reading is not stable, there is an external interference or a variable noise floor. Make a note on the Test Result Sheet that Channel X BER went to Y% while performing this test.

The worksheet calculates the Degradation no Tx value. The degradation should be less than specified at the beginning of this step.

- If the degradation is higher than recommended, consult with your system administrator to determine what the impact could have on talk-in coverage.
- The Gen Lvl Desense no Tx level from this test becomes the benchmark for future PM checks.

- 9** Test Rx De-sense for TTA Normal with transmitters keyed. The degradation is < 2 dB @ 700/800/900 MHz, < 6 dB @ 450 MHz, or < 10 dB @ 150 MHz. This test is optional for 700/800/900 MHz.



CAUTION: This test cannot be performed if the RF channel under test OR any of the RF channels being keyed up are in use with an operating system in the same coverage area.

- a** Key up the transmitters at the site.



WARNING: Verify that you have removed the power sensor from the Tx path before keying up multiple transmitters.

- b** If needed, readjust the Analyzer Generate RF Level for $5\% \pm 0.25\%$ BER.
- c** Record the Analyzer Generate RF Level in the Gen Lvl Desense w/Tx field of the FDMA Chan sheet.
- d** De-key the transmitters at the site.
- e** In CSS, click **Stop RSSI Measurement**.

The result sheet calculates the Degradation with Tx value. If the degradation is higher than recommended, consult with the System Engineer to determine what the impact could have on talk-in coverage.

- 10** Test the Rx Noise Level with the TTA normal. This test establishes the noise floor of the receive system:
- a** Turn the analyzer generator OFF.

- b** In CSS, click **Start RSSI Measurement**.
- c** Record the CSS RSSI Value in the RSSI Level Antenna field of the FDMA Chan sheet.
- d** Click **Stop RSSI Measurement**.

This Rx Noise Level is a relative value.

11 If no further testing is needed, place the base radio into Normal Mode, as follows:

- a** Click **Change to Normal Mode**.
- b** At the confirmation screen, click **OK**.

The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.

12 Disconnect the Analyzer from the TTA.

Effective Receiver Sensitivity

The result sheet calculates the Effective Sensitivity (ERS) as the maximum of Gen Lvl Desense no Tx or Gen Lvl Desense w/Tx, – Test Cable #4 loss - TTA Test Port Cable Loss - TTA Test Port Coupling Loss.

Be sure to discuss this actual value with your system administrator to verify that there are no impacts to the system talk-in coverage. Channel-to-channel variations should be within ± 2 dB.

If this site is utilizing two Rx antennas in a fallback (not diversity) configuration, perform all the steps in [Verifying Receiver Performance in TTA Operation on page 308](#) to verify that Rx B is functional. If using a second TTA, connect to the second TTA test port. Leave the 1st TTA test port disconnected. For a Dual Diversity TTA, disconnect the A side from the receive distribution system so that no signal is present at the Rx A connection on the rear of the GTR 8000 Base Radio or the junction panel of the GTR 8000 Expandable Site Subsystem. Fail Branch A by applying a high-level signal to Branch B and wait for Branch A to fail.

Create a second Chan Result sheet by copying the original and labeling it Chan x – x Fallback Rx. Ensure that the ERS for Rx B meets the coverage requirements too.

Verify Receiver Performance for APCO TDMA Operation

See chapter 5 in the *Dynamic Dual Mode for TDMA Operation* manual for TDMA testing using the Aeroflex service monitor.

To perform a self-test of the receiver's sensitivity, see [Checking Receiver Sensitivity \(Self-test Method\) \(IV and D\) on page 313](#).

Verifying Receiver Performance (Analog Operation)

When and where to use:

Use this procedure to verify receiver performance by measuring the receiver sensitivity (SINAD) for an analog base radio.



NOTICE: This procedure uses an internal SINAD in the base radio. If a field technician chooses to use a service monitor as an external SINAD meter, see “SINAD Measurement Procedure (measured by Service Monitor)” within Base Radio Service Help > Service Screens > Alignment Screens > Carrier Squelch Alignment Tab in the *CSS Online Help*.

Procedure:

- 1** Connect to the transceiver module in CSS through an Ethernet connection. See [Connecting Through an Ethernet Port Link on page 262](#).

- 2 From the menu, select **Service** → **Alignment Screens**.

The **Alignment Screen** appears.

- 3 If the base radio is not already in service mode perform the follows substeps, otherwise go to [step 4](#).

- a Click **Change to Service Mode**.

- b At the confirmation screen, click **OK**.

The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.

- c Re-open the **Alignment Screen** as described in [step 2](#).

- 4 Select the **Carrier Squelch Alignment** tab.

- 5 Make the following connections to the GTR 8000 Expandable Site Subsystem depending on the frequency band:

- For the 700/800/900 MHz and UHF R2 (435–524 MHz) frequency bands, connect the service monitor GEN port to the Site Preselector Test Port with a BNC connector. The test port on the TTA (if present) may also be used.
- For the VHF (136–174 MHz) and UHF R1 (380–435 MHz) frequency bands, disconnect the cable from the Rx Port on the Receiver Input junction panel and connect the service monitor GEN port to the corresponding Rx Port on the Receiver Input junction panel.

- 6 Set up the service monitor.

- a For 25 kHz channels, set the modulation to 1 kHz tone at 3 kHz deviation.

- b For 12.5 kHz channels, set the modulation to 1 kHz tone at 1.5 kHz deviation.

- c Set the service monitor to generate at the receive frequency.

- d Set the RF level depending on the frequency band:

- For 700/800/900 MHz and UHF R2 (435–524 MHz) frequency bands, set the RF level to an initial value of -50 dBm.
- For VHF (136–174 MHz) and UHF R1 (380–435 MHz) frequency bands, set the RF level to an initial value of -80 dBm.



NOTICE: For 700/800/900 MHz and UHF R2 (435–524 MHz) frequency bands, the levels are high since the test port coupler loss is +30 dB.

- 7 In the **Carrier Squelch Alignment** tab, click **25 kHz** to measure 25 kHz channel SINAD. Click **12.5 kHz**, to measure 12.5 kHz channel SINAD.

- 8 Select the **SINAD measurement** check box.

- 9 Click **Start SINAD Measurement**.

The **SINAD Measurement Value** box displays “wait”, and after 10 seconds starts to display the SINAD results in dB.



NOTICE: With the initial setting of the service monitor set for a carrier level of -80 dBm, expect a SINAD of >26 dB. Remember to compensate for the loss of the cable connecting the service monitor to the base radio. If the receiver is inhibited, SINAD displays a meaningless value.

- 10 Change the service monitors RF level and read the SINAD again until the value is 12 dB.



NOTICE: When the SINAD value is close to 12 dB, wait 10 seconds after changing the RF signal generator level. The base radio needs 10 seconds to stabilize the SINAD measurement. Remember to compensate for the loss of the cable connecting the service monitor to the base radio.

- 11 Record the signal generator RF level. Compare this value to the sensitivity specifications. See [GTR 8000 Expandable Site Subsystem Specifications on page 67](#) for the appropriate value.
 - a Key the transmitter in the base radio and readjust the generator output level until 5% BER is indicated on the service analyzer. Record this level.

Less than 1 dB of degradation should occur due to the transmitters being keyed.
 - b Dekey the transmitter.
- 12 Click **Stop SINAD measurement** to stop the measurement.
- 13 Unselect the **SINAD measurement** check box.
- 14 If no further testing is needed, place the base radio in Normal Mode, as follows.
 - a Click **Change to Normal Mode**.
 - b At the confirmation screen, click **OK**.

The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.
- 15 Remove and restore the following connections to the GTR 8000 Expandable Site Subsystem depending on the frequency band:
 - For 700/800/900 MHz and UHF R2 (435–524 MHz) frequency bands, remove the service monitor GEN port connection from the Site Preselector Test Port or TTA, if present.
 - For the VHF (136–174 MHz) and UHF R1 (380-435 MHz) frequency bands, remove the service monitor GEN port from the Rx Port on the Receiver Input junction panel and reconnect the cable previously removed to the Rx Port on the Receiver Input junction panel.

Checking Receiver Sensitivity (Self-test Method) (IV and D)

When and where to use:

Use this procedure to check the receiver sensitivity for the station without any test equipment. The receiver uses a factory calibrated low-level noise source at the receiver input to check performance. This procedure can be performed remotely.

Procedure:

- 1 Connect to the transceiver module in CSS through an Ethernet connection. See [Connecting Through an Ethernet Port Link on page 262](#).
- 2 From the menu, select **Service** → **Test Measurement Screen**.

The **Test and Measurement Screen** appears.
- 3 Select the **ASTRO BER RSSI Report** tab.
- 4 If the base radio is not already in service mode perform the follows substeps, otherwise go to [step 5](#).
 - a Click **Change to Service Mode**.
 - b At the confirmation screen, click **OK**.

The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.
 - c Re-open the **Test and Measurement Screen** as described in [step 2](#).

5 Select Start Receiver Test.

A confirmation dialog box appears indicating the test progress. After a few seconds, the test concludes with a pass or fail message.

6 Click OK.

7 If no further testing is needed, place the base radio in Normal Mode, as follows:

a Click Change to Normal Mode.

b At the confirmation screen, click OK.

The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.

Monitoring the Transmitter Metering Points

Procedure:

1 Connect to the transceiver module in Configuration/Service Software (CSS) through an Ethernet connection. See [Connecting Through an Ethernet Port Link on page 262](#).

2 From the menu, select **Service** → **Metering Screens**.

The **Metering Screen** dialog box appears.

3 Click **Transmitter Test** to briefly key up the transmitter.

The status bar on the window confirms if the transmitter is operating properly or if it has failed.

4 The **Current** column displays the values read for the following:



NOTICE: When the base radio is transmitting, the **VSWR** field on the screen displays a value of 1 or greater; when the base radio is not keyed, 1 is displayed.

Item	Measure
Current Measured Forward Power (Watts)	Forward power of the base radio
Current Measured Reflected Power (Watts)	Reflected power of the base radio
Current Measured VSWR	Voltage Standing Wave Ratio (VSWR) of the base radio
The following readings are for a conventional base radio:	
Current Stored Forward Power (Watts)	Forward power of the base radio at the last key up
Current Stored Reflected Power (Watts)	Reflected power of the base radio at the last key up
Current Stored VSWR	VSWR of the base radio at the last key up

Verifying Transmitter Performance (Digital Operation)

When and where to use:


To verify that the GTR 8000 Expandable Site Subsystem transmitter meets the ASTRO® 25 standards, the GTR 8000 Expandable Site Subsystem must be forced to transmit a V.52 standard test pattern.

Procedure:

- 1 Connect to the transceiver module in CSS through an Ethernet connection. See [Connecting Through an Ethernet Port Link on page 262](#).
- 2 From the menu, select **Service** → **Test and Measurement Screen**.
The **Test and Measurement Screen** appears.
- 3 Select the **ASTRO Test Pattern** tab.
- 4 If the base radio is not already in service mode perform the follows substeps, otherwise go to [step 5](#).
 - a Click **Change to Service Mode**.
 - b At the confirmation screen, click **OK**.
The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.
 - c Re-open the **Test and Measurement Screen**, as described in [step 2](#).
- 5 Connect the service monitor to the GTR 8000 Expandable Site Subsystem:
 - a Disconnect the Q-N Type connector cable from the input connector of the Cavity Combiner.
 - b Connect the Q-N Type connector cable (cable disconnected from step a) to the T/R port of the service monitor
- 6 Make the following settings on the service analyzer:
 - a Click **Receiver (TX Test)**.
 - b Enter the frequency to match that of the base radio TX channel selected.
 - c Click **INPUT PORT** and set to T/R.
 - d Click **ATTEN** and set to 20 dB.
 - e Click **DEMOD** and set to P25.
 - f Click **IF BW** and set to 12.5 kHz.
 - g Click **RF GEN** to turn OFF the Signal Generator Output.
- 7 On the service analyzer, click **Options**. Enable and make the following selections in the Spectrum Analyzer, EVM Data, Power Meter, and Modulation Plot, as follows:
 - a Expand the Power Meter and set to **AR** (Autorange). If necessary, change to 0. Press **Return**. Verify that Cable Loss is 0. If cable loss is anticipated, expand the Power Meter and enter the cable loss factor.
 - b Set the RF Error Meter to **AR** (Autorange).
 - c Set the Modulation Meter to **AR** (Autorange).
- 8 Set up the test in the CSS:
 - In the **Pattern Type** field, select **V.52**.
- 9 Click **Start Pattern Transmission**.
The service monitor displays:
 - The test pattern on the modulation scope.
 - The amount of deviation of the carrier.
 - The Modulation Fidelity as a percentage.

- The transmitters carrier frequency error.

Figure 144: Configuration for Modulation Fidelity Measurement (Aeroflex 2975 Series Service Monitor or Equivalent Analyzer)



- 10 Record the **BER, Modulation Fidelity Error, Symbol Deviation, and Carrier Error and FREQ** readings from the P25 Uplink Data (in the **Options** menu) for use in digital Receiver Testing.
- 11 Click **Stop Pattern Transmission** to turn off the test tone.
- 12 Disconnect the service monitor and reconnect the Q-N Type connector cable to the input connector of the Cavity Combiner.
- 13 If no further testing is needed, place the base radio in Normal Mode.
 - a Click **Change to Normal Mode**.
 - b At the confirmation screen, click **OK**.The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.

Verifying Transmitter Performance (Analog Operation)

When and where to use:

To verify that the base radio transmitter meets the ASTRO[®] 25 system standards, the base radio must be forced to transmit a 1 kHz tone.

Procedure:

- 1 Connect to the transceiver module in Configuration/Service Software (CSS) through an Ethernet connection. See [Connecting Through an Ethernet Port Link on page 262](#).
- 2 From the menu, select **Service** → **Test and Measurement Screen**.
The **Test and Measurement Screen** appears.
- 3 Select the **ASTRO Test Pattern** tab.
- 4 If the base radio is not already in service mode perform the follows substeps, otherwise go to [step 5](#).
 - a Click **Change to Service Mode**.

- b** At the confirmation screen, click **OK**.

The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.

- c** Re-open the **Test And Measurement Screen**, as described in [step 2](#)

- 5** Connect the service monitor to the base radio:

- a** Remove the N-Type connector from the Transmitter Antenna Port.
b Connect an N-to-N cable from the Transmitter Antenna Port to the T/R port of the service monitor.

- 6** Make the following settings on the service analyzer:

- a** Configure the service monitor for **Analog Duplex**.
b Enter the frequency to match that of the base radio TX channel selected.
c Click **INPUT PORT** and set to T/R.
d Click **ATTEN** and set to 20 dB.
e Click **IF BW** and set to 12.5 kHz for narrow channels. Select 25 kHz or 30 kHz for wide channels.
f Click **DEMOD** and set to FM.
g Click **RF GEN** to turn OFF the Signal Generator Output.
h For the power meter, select **W** and **BB** (Broadband).
i Select **0.3–3 kHz** for the audio filtering bandwidth.

- 7** Set up the test in CSS:


- From the **Pattern to Transmit** field, select **1 kHz Tone at 60% deviation without PL/DPL**.

- 8** Click **Start Pattern Transmission**.

The service monitor displays:

- The transmit output power (make sure to account for any cable loss).
- The amount of FM deviation of the carrier.
- The Tx SINAD (measure of Tx distortion) in dB.
- The transmitters carrier frequency error.

Figure 145: Configuration for Modulation Fidelity Measurement (Aeroflex 2975 Series Service Monitor or Equivalent)




- 9 Click **Stop Pattern Transmission** to turn off the test tone.
- 10 Disconnect the service monitor and reconnect the transmit antenna.
- 11 If no further testing is needed, place the base radio in Normal Mode, as follows:
 - a Click **Change to Normal Mode**.
 - b At the confirmation screen, click **OK**.

The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.

GTR 8000 Expandable Site Subsystem Performance Testing with a Service Monitor for HPD

The HPD Service Monitor is a diagnostic tool used with an HPD GTR 8000 Expandable Site Subsystem or HPD modem to test and measure the transmitter and receiver characteristics. The HPD Service Monitor generates HPD signaling and provides diagnostic information for received signaling.

Figure 146: HPD Service Monitor Test Screen



The HPD Service Monitor is connected with an HPD GTR 8000 Expandable Site Subsystem to perform the following diagnostic tests (for additional tests, see the HPD service monitor manual). These tests are designed to determine whether the equipment is operating within specification. If an HPD GTR 8000 Expandable Site Subsystem fails to meet specification, service may be required.

- **Measure Transmit Power:** See [Measuring HPD BR Tx Power, Frequency Accuracy, and Tx EVM on page 320](#).
- **Measure Frequency Accuracy:** See [Measuring HPD BR Tx Power, Frequency Accuracy, and Tx EVM on page 320](#).
- **Measure Error Vector Magnitude (EVM) for Transmitter:** See [Measuring HPD BR Tx Power, Frequency Accuracy, and Tx EVM on page 320](#).
- **Measure Receiver Sensitivity:** See [Measuring HPD BR Rx Sensitivity and Rx BER on page 323](#).
- **Measure Bit Error Rate (BER) for Receiver:** See [Measuring HPD BR Rx Sensitivity and Rx BER on page 323](#).

For additional information about using the service monitor, see the HPD Service Monitor manual or online help (accessed through the **Help** button on the front of the Service Monitor).

Setting Up the HPD Service Monitor for Testing the GTR 8000 Expandable Site Subsystem

Prerequisites: The following procedures assume that a USB mouse is connected. If not, for instructions to click or select you can use the **TAB** and arrow buttons on the front of the service monitor. For instructions to select a soft key on the right side of the screen, use the unlabeled buttons on the front of the service monitor, and press the button next to the soft key on the screen. The test procedures require the base radios Rx and Tx cables to be connected to the HPD Service Monitor. Any calls present on the channel associated with the base radio are dropped from that channel. Place the channel in Service Mode before performing the test procedures so that the system does not attribute the loss of channel to a failure.

When and where to use:

Use this procedure for setting up the HPD Service Monitor.

If the HPD Service Monitor runs continuously, periodic calibration is required. See the HPD Service Monitor manual for instructions.

Procedure:

- 1 Plug a power cable into the AC port at the rear of the service monitor.
- 2 Connect a USB mouse to one of the two USB ports in the rear of the Service Monitor.
- 3 Configure the Speed/Duplex setting in the PCs Ethernet interface to 10 Mb Half Duplex.
- 4 Connect to the transceiver module in CSS through an Ethernet connection. See [Connecting Through an Ethernet Port Link on page 262](#).
- 5 If the base radio being tested is not already in service mode perform the follows substeps, otherwise go to [step 6](#).
 - a From the menu, select **Service** → **Test and Measurement Screen**.
The **Test and Measurement Screen** appears.
 - b Click **Change to Service Mode**.
 - c At the confirmation screen, click **OK**.
The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.
 - d Re-open the **Test and Measurement Screen**.
- 6 Connect the service monitor to the GTR 8000 Expandable Site Subsystem:
 - a Disconnect the Q-N Type connector cable from the input connector of the Cavity Combiner.
 - b Connect the Q-N Type connector cable (cable disconnected from step 1) to the RF I/O port of the service monitor
- 7 In case you want to measure the GTR 8000 Expandable Site Subsystems receive signal (see [Measuring HPD BR Tx Power, Frequency Accuracy, and Tx EVM on page 320](#)) connect the service monitor GEN port to the Site Preselector Test Ports using a splitter.
- 8 Press the green power button on the front of the service monitor.
- 9 If the Test Screen is not displayed (see [Figure 146: HPD Service Monitor Test Screen on page 319](#)), press the **Test** button on the front of the service monitor.
- 10 Locate the specifications configuration for testing. See [GTR 8000 Expandable Site Subsystem Specifications on page 67](#).


Measuring HPD BR Tx Power, Frequency Accuracy, and Tx EVM

When and where to use:

Use this procedure for the service monitor to receive and provide readings on transmissions from the base radio.

Procedure:

- 1 Perform the service monitor setup steps in [Setting Up the HPD Service Monitor for Testing the GTR 8000 Expandable Site Subsystem on page 319](#).
- 2 Configure the service monitor T/R port to receive transmissions from the base radio as follows:
 - Click the **T/R** soft key under **RF In** on the right side of the screen on the service monitor.



- 3 Maximize the RF Control Settings window, by clicking the upper left corner of the window.


Figure 147: HPD Service Monitor - RF Control Settings Window

- 4 Set RF Receiver Frequency on the service monitor, as follows:
 - a Click the **RF Rcvr Freq** field in the upper right quadrant of the RF Control Settings window.
 - b Press the number buttons on the front of the service monitor to enter a value in the **RF Rcvr Freq** field.
 - c If **MHz** is not already displayed to the right of the RF Receiver Frequency value you entered, press the unlabeled button on the front of the service monitor next to the **MHz** soft key.

 **NOTICE:** The value you enter should be within the Frequency Range specification for the GTR 8000 Expandable Site Subsystem configuration you are testing. See [GTR 8000 Expandable Site Subsystem Specifications on page 67](#).
- 5 From the drop-down list for Pilot Sync Code (**PSC**) in the upper right quadrant of the RF Control Settings window, select **1**.
- 6 Make the following selections in the Receive (Expected) quadrant of the RF Control Settings window:
 - a From the drop-down list for **Receive Mode**, select **Manual**.
 - b From the drop-down list for **Burst Type**, select **Outbound**.
 - c From the drop-down list for **Modulation**, select **16-QAM**.
 - d From the drop-down list for **Sync Mode**, select **Free Run**.
- 7 Minimize the RF Control Settings window, by clicking the upper left corner of the window. (See [Figure 146: HPD Service Monitor Test Screen on page 319](#).) Modulation Type is not visible in the minimized RF Control Settings window but displays with Burst Type and PSC at the bottom of the screen.

The minimized RF Control Settings window is visible at the top of the screen as long as all subscreens are minimized.
- 8 On the **CSS Test and Measurement Screen**, perform the following actions:
 - a In the **Select Pattern to Transmit** field, key up the base radio for 16-QAM modulation by selecting **16-QAM**.
 - b Click **Start Pattern Transmission**.

Figure 148: CSS Test and Measurement Screen




9 Display the base radios transmission readings on the service monitors Rx Meter subscreen, as follows:

a Click the **Rx Meter** subscreen.

A panel of soft keys displays on the right side of the screen, including two **Reset** keys.

Figure 149: HPD Service Monitor - Rx Meter Subscreen, Reset Soft Keys



b Click the **Reset Acquire** soft key on the right side of the screen.

The test set with the incoming signal re-synchronizes.

c Click the **Reset Meters** soft key on the right side of the screen.

This stops, clears, and restarts the acquisition of data for the data display fields.

10 Compare the value that displays in the **Signal Power** field to the HPD Tx Power Out specification of 50 Watts.

 **NOTICE:** Account for cable loss in this comparison.

11 Note the value that displays in the **Freq. Error** field. Tolerance should be +/- 50 Hz.

12 Note the value that displays in the **EVM avg** field. The value should be less than or equal to 10%.

13 If no further testing is needed, place the base radio in Normal Mode:

- a Click **Change to Normal Mode**.
- b At the confirmation screen, click **OK**.

The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.

Measuring HPD BR Rx Sensitivity and Rx BER

When and where to use:

Use this procedure to test:

- **Rx Sensitivity:** Does the 1% Bit Error Rate (BER) meet specifications for your GTR 8000 Expandable Site Subsystem configuration?
- **Rx BER:** Does -70 dBm produce a 0.01% Bit Error Rate (BER) or better, as expected?

Procedure:

- 1 Perform the service monitor setup steps in [Setting Up the HPD Service Monitor for Testing the GTR 8000 Expandable Site Subsystem on page 319](#).
- 2 Using the soft keys on the right side of the screen, configure the service monitor GEN port to generate inbound signaling to the base radio as follows:
 - a Under **RF Gen**, click the **ON** soft key.



- b Under **RF Out**, click the **GEN** soft key.



- c Under **Transmit**, click the **ENABLE** soft key.



- 3 Maximize the **RF Control Settings** window, by clicking the upper left corner of the window. All **RF Control Settings** fields are displayed.

Figure 150: HPD Service Monitor - RF Control Settings Window

4 Select the following values in the Transmit quadrant of the **RF Control Settings** window:

- a For **Burst Type**, select **Inbound Reserved**.
- b Select a **Modulation Type**.
- c For **Sync Mode**, select **TDO**.
- d For **Pattern**, select **0.153 Std**.

 **NOTICE:** Your selection should be a modulation type from HPD Receive Sensitivity 1% BER specifications, which include:

- 64 QAM (Quadrature Amplitude Modulation)
- 16 QAM
- QPSK (Quadrature Phase Shift Keying)

See [GTR 8000 Expandable Site Subsystem Specifications on page 67](#).

5 For **Sync Mode** in the Receive (Expected) quadrant of the **RF Control Settings** window, select **Free Run**.

6 Select the following values in the upper left quadrant of the **RF Control Settings** window:

- a Click the **RF Gen Freq** field and use the number buttons on the front of the service monitor to enter a value.

 **NOTICE:** The value you enter should be within the frequency range specification for the GTR 8000 Expandable Site Subsystem configuration you are testing. See [GTR 8000 Expandable Site Subsystem Specifications on page 67](#).

- b Click the **RF Gen Level** field and enter a dBm value, depending on the length of cable between the service monitor and the base radio.

 **NOTICE:** The value you enter should match the receive sensitivity 1% BER specifications for your GTR 8000 Expandable Site Subsystem configuration, for the Modulation Type you selected. See [GTR 8000 Expandable Site Subsystem Specifications on page 67](#).

- c From the drop-down list for Pilot Sync Code (**PSC**), select **1**.

- 7 Minimize the **RF Control Settings** window, by clicking the upper left corner of the window. See [Figure 146: HPD Service Monitor Test Screen on page 319](#). Modulation Type is not visible in the minimized RF Control Settings window but displays with Burst Type and PSC at the bottom of the screen.

The minimized RF Control Settings window is visible at the top of the screen as long as all subscreens are minimized.

- 8 From the **Test and Measurement Screen**, set up to display received BER, as follows:
- Select a pattern that matches your Modulation Type selection from the **RF Control Settings** in the service monitor.



NOTICE: To match the QPSK Modulation Type on the service monitor screen, select the 4 QAM pattern in CSS.

- Click **Start Pattern Transmission**.
- Click **Start BER Measurement**.

Figure 151: CSS Test and Measurement Screen


Test And Measurement Screen			
Transmit Frequency (MHz)	851.0125		
Receiver Frequency (MHz)	806.0125		
Select Pattern to Transmit	V.52, 4 QAM	Start Pattern Transmission	
BER Rx Pattern Type	HPD generic test pattern	Start BER Measurement	
Sampling Period (sec)	1	Start RSSI Measurement	
		Start Receiver Test	
Bit Error Rate (%)	N/A		
Received Frequency Error (Hz)	0		
Received Signal Strength (dBm)	Branch 1	Branch 2	Branch 3
	-122.47	-124.74	-150.07
Start Log			
Note: When service and measurements are completed, return the station to Normal Mode.			
Change to Normal Mode			
Click the button to start the pattern transmission.			

- 9 Display the base radios transmission readings on the service monitor **Rx Meter** subscreen, as follows:

- Click the **Rx Meter** subscreen.

A panel of soft keys displays on the right side of the screen, including two **Reset** keys.

Figure 152: HPD Service Monitor - Rx Meter Subscreen and Soft Keys



- b Click the **Reset Acquire** soft key on the right side of the screen.
The test set with the incoming signal re-synchronizes.
 - c Click the **Reset Meters** soft key on the right side of the screen.
This stops, clears, and restarts the acquisition of data for the data display fields.
- 10** On the **RF Control Settings** window of the service monitor, enter lower values in the **RF Gen Level** field until 1% BER is displayed on the **CSS Test and Measurement Screen**. Compare the value in the **RF Gen Level** field to the receive sensitivity 1% BER specifications for your GTR 8000 Expandable Site Subsystem configuration. See [GTR 8000 Expandable Site Subsystem Specifications on page 67](#).
-  **NOTICE:** Be sure to take the cable and splitter loss into account, along with 30 dB for the coupling loss of the site preselectors test port.
- 11** Enter -40 dBm in the **RF Gen Level** field.
-  **NOTICE:** This should produce a 0.01% or better BER on the **Test and Measurement Screen** in CSS. If it does not, contact Motorola Solution Support Center (SSC). See [Motorola Solution Support Center on page 344](#).
- 12** When finished testing, perform the following steps in CSS on the **Test and Measurement Screen**:
- a Click **Stop BER Measurement**.
 - b Click **Stop Pattern Transmission**.
- 13** If no further testing is needed, place the base radio in Normal Mode:
- a Click **Change to Normal Mode**.
 - b At the confirmation screen, click **OK**.
- The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.

Checking Receiver Sensitivity (Self-test Method) (HPD)

When and where to use:

Use this procedure to check the High Performance Data (HPD) receiver sensitivity for the base radio without any test equipment. The base radio uses a factory calibrated low-level noise source at the receiver input to check performance. This procedure can be performed remotely.

Procedure:

- 1 Connect to the base radio in Configuration/Service Software (CSS) through an Ethernet connection. See [Connecting Through an Ethernet Port Link on page 262](#).
- 2 From the menu, select **Service** → **Test And Measurement Screen**.

Figure 153: CSS Test And Measurement Screen

The screenshot shows a software interface titled "Test And Measurement Screen". It contains several sections:

- Frequency Settings:** Transmit Frequency (MHz) is 851.0125 and Receiver Frequency (MHz) is 806.0125.
- Pattern Selection:** "Select Pattern to Transmit" is set to "V.52, 4 QAM" with a "Start Pattern Transmission" button.
- Measurement Settings:** "BER Rx Pattern Type" is "HPD generic test pattern" and "Sampling Period (sec)" is "1". There are buttons for "Start BER Measurement", "Start RSSI Measurement", and "Start Receiver Test".
- Test Results Table:**

Bit Error Rate (%)	N/A		
Received Frequency Error (Hz)	0		
Received Signal Strength (dBm)	Branch 1	Branch 2	Branch 3
	-122.47	-124.74	-150.07
- Control Buttons:** "Start Log" and "Change to Normal Mode".
- Note:** "When service and measurements are completed, return the station to Normal Mode."
- Footer:** "Click the button to start the pattern transmission."

- 3 If the base radio is not in service mode perform the follows substeps, otherwise go to [step 4](#).
 - a Click **Change to Service Mode**.
 - b At the confirmation screen, click **OK**.
The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.
 - c Re-open the **Test And Measurement Screen** as described in [step 2](#).
- 4 Select **Start Receiver Test**.
A confirmation dialog box appears indicating the test progress. After a few seconds, the test concludes with a pass or fail message.
- 5 Click **OK**.
- 6 If no further testing is needed, place the base radio in Normal Mode.
 - a Click **Change to Normal Mode**.
 - b At the confirmation screen, click **OK**.
The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.

This page intentionally left blank.

Chapter 6

GTR 8000 Expandable Site Subsystem Maintenance

This chapter describes periodic maintenance procedures relating to the GTR 8000 Expandable Site Subsystem.

Fan Grill Cleaning Instructions

If the station equipment is installed in a dusty environment, take precautions to filter the air used for a forced cooling of the station. Excessive dust drawn across and into the device circuit modules by the cooling fans can adversely affect heat dissipation and circuit operation. In such installation, be sure to clean or replace external filtering devices periodically.

If dust has accumulated on the fan grills, cleaning the fan grills is recommended. When cleaning, take care to prevent dust from being pulled into the modules. Use a damp cloth to wipe the front of the fan grills. When removing the power supply, turn off the unit before proceeding.

Base Radio Internal Frequency Reference Oscillator Alignment

The transceiver option card internal frequency reference oscillator in a base radio must be aligned:



NOTICE: The base radio must be turned on for at least one week before the internal frequency reference oscillator is aligned.

See Base Radio Service Help > Service Screens > Alignment Screens in the *CSS Online Help* for the alignment procedures.

GCP 8000 Site Controller Reference Oscillator Alignment



NOTICE: This alignment is for both the active and standby site controllers at a repeater site only.

After the GCP 8000 Site Controller is installed, the reference oscillator must be aligned.



NOTICE: The base radios must be turned on for at least one week before the reference oscillator is aligned.

The site controller reference oscillator must be aligned to within 1 ppb (parts per billion). The frequency reference used to make this alignment should be accurate to within 1 ppb. This accuracy typically requires test equipment with a double oven or a Rubidium reference oscillator.

See Site Controller Configuration Service Help > Site Controller Procedures > Aligning the Reference Oscillator in the *CSS Online Help* for the alignment procedures.

This page intentionally left blank.

Chapter 7

GTR 8000 Expandable Site Subsystem Operation

This chapter details how the GTR 8000 Expandable Site Subsystem operates once it is installed and operational on your system.

Base Radio Operational States for Trunked Simulcast

GTR 8000 Base Radio modules can be in any one of the following four operational states:

- Standby
- Idle
- Assigned
- Isolated

During initialization, the base radio powers up into the **standby** state and waits for a status packet from the comparator. When initial contact with the comparator has been made, the base radio enters **idle** mode. The base radio sends a status message back to the comparator indicating that it is ready for the assignment.

After a base radio has been **assigned**, it can begin to handle inbound/outbound traffic. In the case where the base radio fails to receive status packets from the comparator, the base radio enters **isolated** mode and dequeues. This **isolated** mode is reported in the Unified Event Manager (UEM).

If the base radio becomes operational again, and receives the status packets from the comparator, it again replies with a channel status message. The base radio returns to the **idle** state and is ready for an assignment from the comparator.

Adjacent Site Search Holdoff

For IP simulcast subsystems with 16 to 32 subsite capacity, the Transport Network requires longer than 1 second to recover following a failure. To compensate for the subscriber unit scatter, the subscriber units are required to remain on the site for a longer duration following a control channel loss. A message is used to instruct the subscriber units to remain on the site for 10 seconds following the loss of a control channel. The base radio automatically transmits this message upon loss of packets from the prime site.

Base Radio Operational States for Trunked Repeater and HPD

A GTR 8000 Base Radio can be in one of four operational states:

- Standby
- Idle
- Assigned
- Isolated

During initialization, the base radio powers up into the **standby** state and waits for a status packet from the site controller. After initial contact with the site controller has been made, the base radio enters **idle**

mode and sends a status message back to the site controller indicating that it is ready for assignment. The site controller responds with a channel grant message, and the base radio enables for service. If the base radio has a greater home channel preference setting than other base radios at the site, then the zone controller assigns the base radio as the home channel at the site.

After a base radio has been **assigned**, it can begin to handle inbound/outbound traffic. In the case where the base radio fails to receive a number of consecutive status packets from the site controller, the base radio enters **isolated** mode and dekeys. This isolated mode is reported in the Unified Event Manager.

If the base radio becomes operational again and receives status packets from the site controller, it replies with a channel status message. The site controller may then respond with a channel grant, and the base radio becomes enabled for service again.

Base Radio Operational States for Conventional

A GTR 8000 Expandable Site Subsystem channel can be in one of two operational states:

- Standby/Receiving
- Transmit

During initialization, the base radio powers up into the **standby/receiving** state and is enabled for service. The base radio listens for any received transmissions.

After the base radio receives a transmission, it can then key-up and **transmit**.

Packet Data interactions with Multiple NACs


If a base radio supports multiple NACs, such as when using the community base radio feature (F7F/F7E), in addition to a default NAC, inbound data can be received on any incoming NAC and is forwarded to its destination. Outbound data is only transmitted to the default NAC. Outbound data cannot be routed to a selected NAC, it is always sent on the default NAC. Repeated data is only transmitted on the default NAC and does not follow the inbound NAC when community repeater (F7F) is being used.

Supplementary Signaling interactions with Multiple NACs

If a base radio supports multiple NACs, such as when using the community base radio feature (F7F/F7E), in addition to a default NAC, inbound supplementary signaling can be received on any incoming NAC and is forwarded to its destination. If using F7F/F7E, the same that voice would be transmitted, the outbound supplementary signaling is transmitted on either the default NAC or the currently selected NAC. Outbound supplementary signaling cannot be routed to a selected NAC, it is always sent using either the default NAC or the same NAC that voice would be transmitted on according to F7F/F7E functionality.

Site Initialization for the GCP 8000 Site Controller (HPD and Repeater Sites)

The GCP 8000 Site Controller at a remote site follows the general site initialization process.

Figure 154: Site Initialization

Remote_site_initialization

Site Initialization Process

Process:

- 1 After the site controller is powered up, it enters the standby mode and checks for status messages from the standby site controller.
- 2 If status messages are not received before a time-out period, the site controller becomes active, monitors the LAN for base radios, and begins sending status messages.
- 3 When the standby site controller is powered up, it enters the standby mode and receives status messages from the active site controller. The standby site controller remains in the standby mode.
- 4 When the active site controller detects a base radio on the LAN, it sends a report status message to the base radio through the site LAN. This activity takes place with all base radios simultaneously.
- 5 The base radio responds with a channel status reply to the active site controller. The base radio then begins to monitor periodic status messages from the active site controller.
- 6 The active site controller receives the channel status response from the base radio and begins to send background messages to the base radio, then sends a channel grant to the base radio.
- 7 The base radio enters the assigned operational state and keys up. It is now available for operation. If the zone controller has the greatest preference setting in the UNC, the base radio may be assigned as the control channel.

GPB 8000 Reference Distribution Module Operational States

The GPB 8000 Reference Distribution Modules (RDMs) provide redundant reference and Ethernet switching to the base radios. If a failure occurs with one of the RDMs, the other RDM maintains the site. If a GPS unit on an RDM fails, the RDM switches to using the 1PPS reference from the GPS unit on the other RDM.

If both GPS units are non-operational, both RDMs maintain 1PPS reference accuracy for at least four hours. If both RDMs fail, the remote site loses connection to the prime site.

An optional backup for the frequency and time references supplied to the base radios is available either through a TRAK 8835-3 SSR or a TRAK 9100 SSR. The backup SSR provides an extended holdover of at least 72 hours when redundant GPS or certain RDM failures occur.

Illegal Carrier Determination Feature (Trunked)

The Illegal Carrier Determination feature allows base radio channels to continue operating with system-configurable levels of channel interference. In an ASTRO[®] 25 system, the base radio uses Received Signal Strength Indicator (RSSI), an RF Threshold Value, and the Malfunction Timer Value to implement this feature.

Table 117: Illegal Carrier Determination

If the channel receives a...	and is assigned:	and is not assigned:
Valid Network Access Code (NAC)	The base radio does not change since the carrier is considered valid.	If the RF Threshold Value is exceeded, the base radio enters the Illegal Carrier state and generates an Illegal Carrier message to Unified Event Manager (UEM).
Invalid Network Access Code (NAC) OR Carrier activity without NAC	<p>If the RF Threshold Value level is exceeded, the Malfunction Timer Value is activated. After the timer expires, the base radio enters the Illegal Carrier state and generates an Illegal Carrier message to UEM.</p> <p>If the illegal carrier disappears or drops below the RF Threshold Value for 12.5%, but not less than 10 seconds of the time period defined by the Malfunction Timer Value, an event is sent to UEM.</p>	

RF Channel Interference Determination Feature (Conventional)

The RF Channel Interference Determination Feature allows radio channels to detect RF interference and log it to the station log. RF Channel Interference is declared when the Carrier Squelch level is exceeded and none of the receive qualifiers are met. Receive qualifiers are the programmed Private Line (PL), Digital Private Line (DPL), or receive Network Access Code (NAC) for the currently active channel.

Chapter 8

GTR 8000 Expandable Site Subsystem Troubleshooting

This chapter provides fault management and troubleshooting information relating to the GTR 8000 Expandable Site Subsystem.

GTR 8000 Expandable Site Subsystem troubleshooting requires an understanding of hardware-based and software-based diagnostics, as well as testing tools. Support is available from Motorola to assist with all steps in the troubleshooting process.

GTR 8000 Base Radio General Troubleshooting

Table 118: GTR 8000 Base Radio General Troubleshooting

Problem	Troubleshooting
General connectivity problems	<ol style="list-style-type: none"> 1 If you have access to the equipment, check the LEDs to verify that each piece of equipment is connected and operational. See GTR 8000 Base Radio Transceiver LEDs on page 429. 2 In CSS, check the condition of the base radio and all associated devices and links. 3 Verify the configuration of the base radio through UNC and CSS. Verify that the IP address for the base radio is correct. In CSS, send a diagnostic command to enable the base radio. 4 Verify that the DNS Hostname for the base radio is correct. If the DNS Hostname was incorrect and then corrected, further corrections may be needed on the DNS server, UNC, and UEM. See the Troubleshooting chapter in the <i>Authentication Services</i> manual. 5 Verify that the physical cabling is firmly connected and in good condition. Check for any sharp bends or kinks in cabling. Test suspected cabling for noise, continuity, attenuation, and crosstalk. Replace the cabling if necessary. 6 Run ping, traceroute, pathping, and other network administration commands to identify any link or intermediate devices (switch or routers) with high latency or connection problems. 7 If the connection fails to operate normally, send a restart command to the base radio through CSS. Consider cycling power to the base radio if necessary. 8 If the base radio still fails to operate properly, create a backup of the current configuration, then reinstall the software and re-configure the base radio. 9 Replace the base radio if necessary.
Device will not power up	<ol style="list-style-type: none"> 1 If you have access to the equipment, check the LEDs to determine which equipment is connected and operational. See GTR 8000 Base Radio Transceiver LEDs on page 429. 2 In CSS, check the alarms for the base radio.

Table continued...

Problem	Troubleshooting
	<ol style="list-style-type: none"> 3 Check the power cabling and verify that the power source for the base radio is supplying the appropriate voltage. Try connecting the base radios transceiver module to another power source or replace the power cabling if necessary. <p> NOTICE: Check all power sources as there may be more than one.</p> <ol style="list-style-type: none"> 4 Check for any physical damage to the modules and check whether the modules were properly grounded. 5 Replace any defective modules.
Device is in a continuous reset state	Assure reference inputs are connected to the appropriate input.
Analog (4-wire) Portion of V.24 Hybrid Link Failure	<p>In a mixed mode configuration, with hybrid links, and when analog link monitor tone is enabled (Analog Link Idle Check is enabled in the CSS), the base radio detects a link failure when the analog link monitor tone and call activity are absent on the receive line (WL1). Analog Idle Link Check in the CSS should be disabled when the comparator type is ASTRO-TAC with DIGI-TAC or ASTRO-TAC with MLC 8000. When these failure conditions are met, the base radio will:</p> <ol style="list-style-type: none"> 1 Log an occurrence of the failure in the base radios local event log, which is retrievable through the configuration interface. 2 If connected to centralized fault management equipment (optional) then the base radio transmits an alarm indication to the fault manager to alert the system administrator of the failure. 3 A local visual indication is active due to this failure. <p>Recovery of the link failure results in a similar set of actions to indicate that the failure event cleared. A failure of the transport line or a failure of the opposing host on the wireline link both appears to the base radio as a link failure. The base radio cannot distinguish between these two cases.</p>
V.24 Portion of Hybrid Link Fails	<p>In a mixed mode configuration, with hybrid links, the base radio detects a V.24 link failure when packet activity is absent for a period of time on the outbound transmit line. When these failure conditions are met, the base radio will:</p> <ol style="list-style-type: none"> 1 Log an occurrence of the failure in the base radios local event log, which is retrievable through the configuration interface. 2 If connected to centralized fault management equipment (optional) then the base radio transmits an alarm indication to the fault manager to alert the system administrator of the failure. 3 A local visual indication is active due to this failure. 4 Invoke a failure announcement for the 4-wire link because the activity on the 4-wire link is driven by control signaling on the V.24 link. 4-wire link cannot be used when the V.24 link is down. <p>Recovery of the link failure results in a similar set of actions to indicate that the failure event cleared. A failure of the transport line or a failure of the opposing host on the wireline link both appears to the base radio as a link failure. The base radio cannot distinguish between these two cases.</p>
Transceiver Option Card Hardware Malfunction	In the event the base radio detects a hardware issue with the transceiver option card, when used for analog and mixed mode operation, it will:

Table continued...

Problem	Troubleshooting
	<ol style="list-style-type: none"> 1 Log an occurrence of the failure in the base radios local event log, which is retrievable through the configuration interface. 2 If connected to centralized fault management equipment (optional), then the base radio transmits an alarm indication to the fault manager to alert the system administrator of the failure. The alarm is associated with the base radios control module. 3 A local visual indication is active due to this failure.
Front Fan Malfunction	<p>In the event the fan assembly malfunctions, the base radio will:</p> <ol style="list-style-type: none"> 1 Log an occurrence of the failure in the base radios local event log, which is retrievable through the configuration interface. 2 If connected to centralized fault management equipment (optional), then the base radio transmits an alarm indication of “warning” severity to the fault manager to alert the system administrator of the failure. The alarm is associated with the base radios control module. 3 The base radio provides a local visual indication associated with the failure. 4 In the event the base radio detects the maximum operable temperature has been exceeded, then the base radio transitions to a critical malfunction state, log the state change, and generate a fault indication if connected to the UEM.
Power Consumption is greater than 35 W with power efficiency package	<p>The following conditions must be met to obtain a power consumption of less than or equal to 35 W:</p> <ul style="list-style-type: none"> • DC source only • Speaker turned OFF (if equipped with a transceiver option card) • No activation of Aux Out Relays (if equipped with a transceiver option card) • No 29 V AUX loads. For example: site controllers, XHubs, GPB 8000 Reference Distribution Modules, RMCs, etc. • CSS configured for applications not requiring receiver diversity • CSS Fan Holdover configured to “short” (length of time the base radio fan stays ON after transmission) • Ambient temperature of 104 °F (40 °C) or less • Transceiver, power amplifier, power supply, fan, and optional TCXO transceiver option card are all power efficiency package versions
Unable to perform a password reset	<p>If the device module has been replaced and serial port access is not available to configure the IP address, the device may have the account locked out or the back-plane slot has passwords enabled. Connect to the front-panel local Ethernet service port using a fixed IP address and perform the password reset.</p> <p>See Connecting Through an Ethernet Port Link on page 262 and Setting the Local Password Configuration in CSS on page 271.</p>

GCP 8000 Site Controller General Troubleshooting

Table 119: GCP 8000 Site Controller - General Troubleshooting

Problem	Troubleshooting
General connectivity problems	<ol style="list-style-type: none">1 If you have access to the equipment, check the LEDs to verify if each piece of equipment is connected and operational. See GCP 8000 Site Controller LEDs on page 433.2 In the CSS, check the alarms of the site controller and all associated devices and links.3 Verify that the IP address, subnet mask, Site Controller Number, and default gateway for the site controller is correct. In the CSS, send a diagnostic command to enable the site controller.4 Verify if the physical cabling is firmly connected and is in good condition. Check for any sharp bends or kinks in cabling. Test suspected cabling for noise, continuity, attenuation, and crosstalk. Replace the cabling if necessary.5 If the connection fails to operate normally, check the diagnostics, and if needed, contact the Motorola Solution Support Center (SSC).6 If the site controller still fails to operate properly, create a backup of the current configuration, then reinstall the software and reconfigure the site controller.7 Replace the site controller if necessary.
Unit will not power up	<ol style="list-style-type: none">1 If you have access to the equipment, check the LEDs to verify if each piece of equipment is connected and is operational. See GCP 8000 Site Controller LEDs on page 433.2 Check the power cabling and verify if the power source for the site controller is supplying the appropriate voltage. Connect the site controller to another power source or replace the power cabling if necessary.  NOTICE: Check all power sources if there is more than one.3 Check for any burn marks or physical damage to the site controller and check whether the site controller is properly grounded.4 Replace the site controller if necessary.

Table continued...

Problem	Troubleshooting
Unable to perform a password reset	<p>If the device module has been replaced and serial port access is not available to configure the IP address, the device may have the account locked out or the backplane slot has passwords enabled. Perform the following steps:</p> <ol style="list-style-type: none"> 1 Move the device module to a different chassis or to a different slot in the backplane where local passwords are not configured. 2 Configure the IP address and reset the device through the front panel RS-232 serial service port using CSS. 3 Perform the local password reset operation (to clear account information stored in the FRU) through and Ethernet port link using CSS. 4 Move the device module back to the original chassis or slot. 5 Perform the local password reset operation again (to clear account information stored in the backplane). <p>See Connecting Through an Ethernet Port Link on page 262 and Setting the Local Password Configuration in CSS on page 271.</p>

GPB 8000 Reference Distribution Module General Troubleshooting

Table 120: GPB 8000 Reference Distribution Module General Troubleshooting

Problem	Troubleshooting
General connectivity problems	<ol style="list-style-type: none"> 1 If you have access to the equipment, check the LEDs to verify that each piece of equipment is connected and operational. 2 In the Configuration/Service Software (CSS), check the alarms of the GPB 8000 Reference Distribution Module (RDM) and all associated devices and links. See GPB 8000 Reference Distribution Module LEDs on page 437. 3 Verify the configuration of the RDM through Unified Network Configurator (UNC) and CSS. Verify that the IP address for the RDM is correct. In CSS, send a diagnostic command to enable the RDM. 4 Verify that the DNS Hostname for the RDM is correct, if applicable. If the DNS Hostname was incorrect and then corrected, further corrections may be needed on the DNS server, UNC, and UEM. See the Troubleshooting chapter in the <i>Authentication Services</i> manual. 5 Verify redundancy configuration of both RDMs through UNC and CSS. Verify that port 0_Port_Sw-to-Sw is set to Enabled on both RDMs in the Switch Configuration in CSS. If necessary, connect locally to verify RDM #2. 6 Verify that the physical cabling is firmly connected and is in good condition. Check for any sharp bends or kinks in cabling. Test suspected cabling for noise, continuity, attenuation, and crosstalk. Replace the cabling if necessary. 7 If the connection fails to operate normally, check the diagnostics, and if needed, contact Motorola Solution Support Center (SSC). 8 If the RDM still fails to operate properly, create a backup of the current configuration, then reinstall the software and reconfigure the RDM.

Table continued...

Problem	Troubleshooting
Unit will not power up	<p data-bbox="459 243 841 275">9 Replace the RDM if necessary.</p> <hr/> <p data-bbox="459 306 1365 401">1 If you have access to the equipment, check the LEDs to verify that each piece of equipment is connected and is operational. See GPB 8000 Reference Distribution Module LEDs on page 437.</p> <p data-bbox="459 415 967 447">2 In the CSS, check the alarms for the RDM.</p> <p data-bbox="459 462 1352 556">3 Check the power cabling and verify that the power source for the RDM is supplying the appropriate voltage. Connect the RDM to another power source or replace the power cabling if necessary.</p> <p data-bbox="505 571 1243 623"> NOTICE: Check all power sources if there is more than one.</p> <p data-bbox="459 653 1357 716">4 Check for any burn marks or physical damage to the RDM and check whether the RDM is properly grounded.</p> <p data-bbox="459 730 841 762">5 Replace the RDM if necessary.</p>
Unable to perform a password reset	<p data-bbox="459 783 1365 877">If the device module has been replaced and serial port access is not available to configure the IP address, the device may have the account locked out or the backplane slot has passwords enabled. Perform the following steps:</p> <p data-bbox="459 892 1344 955">1 Move the board module to a different chassis or to a different slot in the backplane where local passwords are not configured.</p> <p data-bbox="459 970 1352 1033">2 Configure the IP address and reset the device through the front panel RS-232 serial service port using CSS.</p> <p data-bbox="459 1047 1365 1110">3 Perform the local password reset operation (to clear account information stored in the FRU) through and Ethernet port link using CSS.</p> <p data-bbox="459 1125 1143 1157">4 Move the board module back to the original chassis or slot.</p> <p data-bbox="459 1171 1357 1234">5 Perform the local password reset operation again (to clear account information stored in the backplane).</p> <p data-bbox="459 1249 1365 1312">See Connecting Through an Ethernet Port Link on page 262 and Setting the Local Password Configuration in CSS on page 271.</p>

Troubleshooting Tools

Several tools are available for viewing and monitoring equipment and troubleshooting suspecting problems:

- LEDs
- Unified Event Manager (UEM) to monitor links and components
- Unified Network Configurator (UNC)
- Configuration/Service Software (CSS)
- MOSCAD Network Fault Management (NFM)

In addition, see [Quick Connect RF Coaxial Adapters for GTR 8000 Base Radio Support on page 243](#) for testing system performance.

Links and Components Monitoring in Unified Event Manager

The Unified Event Manager (UEM) monitors critical links and components in the system. Monitoring may take place remotely from a central operations center. Two types of monitoring include:

- Real-time monitoring of UEM Topology Maps, which alert faults as they occur.
- Evaluation of UEM Active Alarms Window on a regularly scheduled basis.

Unified Event Manager Active Alarm Window Analyzation

The Unified Event Manager (UEM) **Active Alarms Window** is useful for troubleshooting because it captures alarms that may occur intermittently or during off-hours. For example, you can review the **Active Alarms Window** to correlate reported loss of service with patterns of critical alarms for links and equipment.

When analyzing the **Active Alarms Window**, look for the following patterns:

- Failures sent with time stamps on or about the same time
- Failures from related equipment:
 - Cards in the same device
 - Equipment part of the same subsystem

Many devices send out events that report both critical and non-critical events. Learn to distinguish between critical and non-critical events.

See the *Unified Event Manager* manual or *UEM Online Help* for further details.


Diagnostic Options in UEM

Table 121: Device Diagnostic Options in UEM

Option	Description
Restart	Requests that the device perform a reset.
Service	Requests that the base radio enters service mode, allowing a technician to make alignment adjustments and run other tests while the base radio is offline.
User Disabled	Requests that the selected site controller disable. After disabling, the site controller isolates itself from the other site controller and the RNG. If the site controller was the active site controller and the standby site controller is not isolated from the system, then the standby site controller becomes active and takes over operations at the site.
Enabled	Requests that the device enter the enabled mode and handle traffic.

MOSCAD Network Fault Management

If MOSCAD Network Fault Management (NFM) equipment is supported at the site, additional status, and alarm information for a device can be viewed through the MOSCAD NFM.

Figure 155: MOSCAD Network Fault Management – Example

When an alarm condition occurs, the alarm device for one of the modules begins to flash red. Selecting the LED box opens an alarm pop-up window indicating details of the alarm. To view the status of all alarms for a particular module within the device, select the alarm LED box corresponding to the particular module. Alarms can be acknowledged by pressing the **Acknowledge** button on the screen.

See the *MOSCAD Network Fault Management* manual for details.

Device Troubleshooting in Unified Network Configurator

Use the Unified Network Configurator (UNC) to verify configuration data during system commissioning and later when you maintain or expand the system. Use UNC to do the following to the device:

- Verify configuration
- Correct configuration errors

See the *Unified Network Configurator* manual for further details.

GTR 8000 Expandable Site Subsystem Troubleshooting in Configuration/Service Software (CSS)

The GTR 8000 Expandable Site Subsystem can be locally or remotely configured or serviced through Configuration/Service Software (CSS). CSS provides access to alarms, status information, and configuration settings for the GTR 8000 Expandable Site Subsystem.

Use CSS for the following tasks which may be useful when troubleshooting the GTR 8000 Expandable Site Subsystem. See the *CSS Online Help* for specific details and instructions when performing these tasks.

- Enable and disable channels and services.
- View and save a log of alarms.
- Verify configurations.
- Gather troubleshooting information that can be escalated to Motorola for evaluation.
- Check the active VLANs for the site controller.

Internal Diagnostic Test Alarm Log

The base radio has been designed with internal diagnostic tests that occur on power up and reset. Diagnostic tests are available for the control module and power supply. If a problem occurs during operation, it is reported as an alarm. All alarms are stored in the Alarm Log, accessible with Configuration/Service Software (CSS). The alarm log contains the name of the diagnostic test that failed and the time since the last power up.

Local Password and SNMPv3 Passphrase Troubleshooting

The password reset mechanism in the Configuration/Service Software (CSS) application can be enabled/disabled. See “Secure Remote Access Configuration > Device Security Configuration - Security Services (Serial)” in the *CSS Online Help* for information. To obtain the keys for resetting either password or SNMPv3 passphrases for the device, contact Motorola Solution Support Center (SSC).



NOTICE: The default values for the local passwords and SNMPv3 passphrases, as well as the keys for the local password reset procedure, may vary by system release. These default values and keys are treated as sensitive information and are provided to your organization through secured communication.

Table 122: Local Password and SNMPv3 Passphrase Troubleshooting

Scenario	SNMPv3 Passphrase Known	Local Password Known	To Reset SNMPv3 Passphrase	To Reset Local Login Password
User is locked out of the local login, but knows SNMPv3 passphrases	✓	✗	See the <i>CSS Online Help</i> “SNMPv3 User Configuration”.	See the <i>CSS Online Help</i> “Resetting Device Passwords.”
User knows the local login, but not the SNMPv3 passphrases	✗	✓	See the <i>CSS Online Help</i> “Reset SNMPv3 Configuration (Serial)”.	See the <i>CSS Online Help</i> “Device Security Configuration – Security Services (Serial)”.
User knows both passphrases and local service password	✓	✓	See the <i>CSS Online Help</i> “SNMPv3 User Configuration”.	See the <i>CSS Online Help</i> “Device Security Configuration – Security Services (Serial)”.
User does not know SNMPv3 passphrase nor service account password	✗	✗	Contact Motorola SSC.	Contact Motorola SSC.

Site Controller Failure Impact on GTR 8000 Base Radio for Trunked Operation

If the link fails between the base radio and the site controller, the base radio dekeys and does not handle any MSU traffic. MSUs attempt to operate on another channel at the site. If another channel is not available, the MSUs attempt to register at another site.

For HPD and repeater site operation, the base radio receives external frequency reference and network time synchronization from the active site controller over the Ethernet link. If there is a loss of the external time and frequency reference source, the base radio continues to maintain its own time and frequency stability to continue operations for a specified amount of time without degradation. Afterwards, operation continues with minimal degradation.

GPB 8000 Reference Distribution Module and GPS Failure Impact on GTR 8000 Base Radios

The base radios receive redundant 1PPS site reference from GPS units through the GPB 8000 Reference Distribution Modules (RDMs). If a failure or interruption of both GPS units occurs, the RDMs can supply the site reference to the base radios for at least four hours.

If both RDMs fail, the remote site loses connection to the prime site.

Motorola Solution Support Center

Motorola Solution Support Center (SSC) can help technicians and engineers resolve system problems, and ensure that warranty requirements are met. Check your contract for specific warranty information.

Motorola assigns a tracking ticket number that identifies each support call. This ticket number allows Motorola to track problems, resolutions, and activities for the call, and if possible, communicate the resolution and a status of call so that the SSC can note the resolution and close the ticket.

Information to Gather Before Calling Motorola

Before calling the Motorola Solution Support Center (SSC), log all steps taken to troubleshoot the problem and any results of those steps. The SSC can use this information to determine the appropriate support actions.

Listed is the following information to collect before calling the SSC:

- System ID number (such as 2CB5). Each zone in the system has a unique system ID number
- Location of the system
- Date the system was put into service
- Software and firmware versions
- Symptom or observation of the problem, such as:
 - When did it first appear?
 - Can it be reproduced?
 - Are there any other circumstances contributing to the problem (for example, loss of power)?
- Maintenance action preceding the problem, such as:
 - Upgrade of software or equipment
 - Changes to hardware or software configuration
 - Reload of software from a backup disk, CD, or DVD with the version and date

Where to Call for Service

After collecting the required information and writing a detailed problem report, contact the Motorola Solution Support Center (SSC) to help with the problem.

Motorola Solution Support Center

The Motorola Solution Support Center (SSC) is the primary Motorola contact. Call Motorola SSC:

- Before any software reload
- To confirm troubleshooting results and analysis before removing and replacing a Field Replaceable Unit (FRU) or Field Replaceable Equipment (FRE) to repair the system

Motorola SSC contact information:

- Phone: (800) 221-7144 for domestic calls and (302) 444-9800 for international calls
- Fax: (847) 725-4073

Subcontractors

The Motorola Solution Service Subcontractor Assessment program ensures that service people Motorola contracts meet strict minimum requirements before they can work on any system. For more information on this program, contact the Motorola representative.

This page intentionally left blank.

Chapter 9

GTR 8000 Expandable Site Subsystem FRU Procedures

This chapter lists the Field Replaceable Units (FRUs) and Field Replaceable Entities (FREs) and includes replacement procedures applicable to the GTR 8000 Expandable Site Subsystem.

Field Replaceable Units (FRUs) and Parts

The GTR 8000 Expandable Site Subsystem is comprised of numerous field replaceable units (FRUs) and field replaceable parts. If replacing a FRU or part, it is essential to obtain the precise FRU Kit Number or Part Number and to review the replacement procedures provided, including all safety precautions and system impact information.

When ordering field replaceable units (FRUs), provide the FRU Kit Number. When ordering field replaceable parts, provide the Part Number. Contact Motorola Solution Support Center (SSC) as needed for numbers not provided here (for cables that are internal to a GTR 8000 Expandable Site Subsystem, the part numbers are not listed in this documentation, but you can locate the part number on the cable itself before contacting Motorola Solution Support Center (SSC). See [Motorola Solution Support Center on page 344](#).



WARNING: To guard against personal injury and/or damage to equipment, switch a trunked base radio to Service Mode when performing service. The GTR 8000 Base Radio periodically keys up to pseudo train its linear transmitter autonomously when it is not assigned by the zone controller. Tx Inhibiting the base radio also prevents the transmitter from keying. Remember to switch the base radio back to Normal Mode when service is complete.

Table 123: GTR 8000 Expandable Site Subsystem Field Replaceable Units

Component Type	FRU Kit Number	Replacement Procedure
Transceiver Module (700/800 MHz)**	DLN6885A	
Transceiver Module (900 MHz)**	DLN6882A	
Transceiver Module (VHF 136–174 MHz)**	DLN6892A	
Transceiver Module (UHF R1, 380–435 MHz)**	DLN6888A	Replacing a GTR 8000 Base Radio Transceiver Module on page 358
Transceiver Module (UHF R2, 435–524 MHz)**	DLN6884A	
Transceiver Module w/OCXO Transceiver Option Card (700/800 MHz)**	DLN6883A	
Transceiver Module w/OCXO Transceiver Option Card (900 MHz)**	DLN6923A	

Table continued...

Component Type	FRU Kit Number	Replacement Procedure
Transceiver Module w/OCXO Transceiver Option Card (UHF R1, 380–435 MHz)**	DLN6889A	
Transceiver Module w/OCXO Transceiver Option Card (UHF R2, 435–524 MHz)**	DLN6886A	
Transceiver Module w/OCXO Transceiver Option Card (VHF 136–174 MHz)**	DLN6893A	
Power Efficiency Transceiver Module w/TCXO* Transceiver Option Card (UHF R1, 380–435 MHz)**	DLN6890A	
Power Efficiency Transceiver Module w/TCXO* Transceiver Option Card (UHF R2, 435–524 MHz)**	DLN6887A	
GCP 8000 Site Controller Mod- ule	DLN6569A	Replacing the GCP 8000 Site Controller Module on page 364
GPB 8000 Reference Distribu- tion Module	DLN6569A	Replacing a GPB 8000 Reference Distribution Module (RDM) on page 368
GGM 8000 Gateway Module		The GGM 8000 Gateway has different FRU kit numbers depending on its functional use. See the <i>System Gateways – GGM 8000</i> manual.
Expansion Hub Module	DLN6677A	Replacing the Expansion Hub on page 373
Fan Module	DLN6898A	Replacing the Fan Assembly on page 374
AC/48 V DC Power Supply	DLN6781A (0182516W14)	Replacing a Power Supply on page 376
Power Efficiency AC/48V DC Power Supply	DLN6793A (0182516W15)	
Power Amplifier Module (700/800 MHz)	DLN6895A	Replacing a Power Amplifier on page 379
Power Amplifier Module (900 MHz)	DLN6894A	
Power Amplifier Module (UHF R1, 380–435 MHz)	DLN6891A	
Power Amplifier Module (UHF R2, 435–524 MHz)	DLN6896A	
Power Amplifier Module (VHF, 136–174 MHz)	DLN6897A	
AC/DC Power Distribution Mod- ule	0184847Y02	

Table continued...

Component Type	FRU Kit Number	Replacement Procedure
AC/DC Power Distribution Module	0184847Y02	Replacing the AC/DC Power Distribution Module on page 396
GTR 8000 Expandable Site Subsystem Backplane	0180706K61	Replacing a GTR 8000 Expandable Site Subsystem Backplane on page 383
Power Supply Backplane	0180706G75	Replacing a GTR 8000 Expandable Site Subsystem Power Supply Backplane on page 389
Primary Subpanel #1	0180706J79	Replacing a Subpanel on the GTR 8000 Expandable Site Subsystem Junction Panel on page 391
Primary Subpanel #2	0180706J82	
Expansion Subpanel #1	0180706J80	
Rx Expansion Subpanel	0180706H26	
Network Expansion Subpanel	0180706J81	
Six Receiver Input Subpanel	0180706H52	
Six Transmit Output Subpanel	0180706J78	
Circuit Audio Subpanel	64009329001	
3600 Simulcast Subpanel*	15009710001, RJ-45 and DB-25 15009710002, Telco	

* Available only for non-IP simulcast systems.

** The transceiver field replacement units are not compatible with ASTRO[®] 25 base radio software distributed before July 2013. BEFORE installing the replacement transceiver, ensure that all base radios at the site meet the minimum software version requirements listed. Contact Motorola Customer Support at 800-422-4210 if you do not have access to compatible software. See [Transceiver Software and Feature Compatibilities on page 353](#) for details.

Table 124: GTR 8000 Expandable Site Subsystem RFDS Field Replaceable Parts

Component Type	Part Number	Replacement Procedure
Power Supply Fan Module	5985167Y02	Replacing a Power Supply Fan on page 377
Site Preselector 700/800 MHz	CFF6056A	Replacing Filters/Preselectors (700/800/900 MHz) on page 398
Site Preselector UHF 455–458.5 MHz	9171232H01	Replacing a Site Preselector (UHF, 455–512 MHz) on page 401
Site Preselector UHF 456.5–460 MHz	9171232H02	
Site Preselector UHF 459.3–462.8 MHz	9171232H19	
Site Preselector UHF 465–468.5 MHz	9171232H03	

Table continued...

Component Type	Part Number	Replacement Procedure
Site Preselector UHF 466.5–470 MHz	9171232H04	
Site Preselector UHF 473–475 MHz	9171232H05	
Site Preselector UHF 474–476 MHz	9171232H06	
Site Preselector UHF 479–481 MHz	9171232H07	
Site Preselector UHF 480–482 MHz	9171232H08	
Site Preselector UHF 485–487 MHz	9171232H09	
Site Preselector UHF 486–488 MHz	9171232H10	
Site Preselector UHF 491–493 MHz	9171232H11	
Site Preselector UHF 492–494 MHz	9171232H12	
Site Preselector UHF 497–499 MHz	9171232H13	
Site Preselector UHF 498–500 MHz	9171232H14	
Site Preselector UHF 503–505 MHz	9171232H15	
Site Preselector UHF 504–506 MHz	9171232H16	
Site Preselector UHF 509–511 MHz	9171232H17	
Site Preselector UHF 510–512 MHz	9171232H18	
Site LNA Module (Site RMC) 700/800/900 MHz	DLN6634A	Replacing a Site RMC/LNA Module or Tray on page 407
Cabinet LNA Module (Cabinet RMC) 700/800/900 MHz	DLN1306A	Replacing an Individual Cabinet RMC/LNA Module on page 412
Site LNA Module (Site RMC) UHF R2, 435–524 MHz	DLN1375A	Replacing a Site RMC/LNA Module or Tray on page 407
Cabinet LNA Module (Cabinet RMC) UHF R2, 435–524 MHz	DLN1374A	Replacing an Individual Cabinet RMC/LNA Module on page 412
Pass Through Module VHF 136–174 MHz and UHF R1, 380–435 MHz	DLN1380A	Replacing an Individual Pass Through Module on page 415
6 Channel Combiner 700 MHz	0184590Y01	Replacing a Cavity Combiner (700/800 MHz) on page 416
6 Channel Combiner 800 MHz	0184590Y02	Replacing a Cavity Combiner (700/800 MHz) on page 416

Table continued...

Component Type	Part Number	Replacement Procedure
6 Channel Combiner UHF 450–465 MHz	0171245H01	
6 Channel Combiner UHF 470–491 MHz	0171245H02	Replacing a Cavity Combiner (UHF) on page 419
6 Channel Combiner UHF 494–509 MHz	0171245H03	
Hybrid Combiner Fan Module	DLN6780A	
Hybrid Combiner 900 MHz (1/2–1/2)	DLN6782A	Replacing a Hybrid Combiner Module (900 MHz) on page 422
Hybrid Combiner 900 MHz (2/3–1/3)	DLN6783A	
Hybrid Combiner 900 MHz (3/5–2/5)	DLN6784A	
Single Duplexer 900 MHz	0182452V23	Replacing a Duplexer (900 MHz) on page 424
Dual Duplexer 900 MHz	0182452V22	
Transmit Post Filter 700 MHz	9184680Y01	Replacing Filters/Preselectors (700/800/900 MHz) on page 398
Transmit Post Filter 800 MHz	9184680Y02	
Transmit Post Filter 900 MHz	9184680Y04	
Transmit Post Filter UHF 450–453.5 MHz	9171244H01	Replacing Transmit Filters (UHF, 450–509 MHz) on page 402
Transmit Post Filter UHF 451.5–455 MHz	9171244H02	
Transmit Post Filter UHF 460–463.5 MHz	9171244H03	
Transmit Post Filter UHF 461.5–465 MHz	9171244H04	
Transmit Post Filter UHF 466.9–468.1 MHz	9171244H19	
Transmit Post Filter UHF 470–472 MHz	9171244H05	
Transmit Post Filter UHF 471–473 MHz	9171244H06	
Transmit Post Filter UHF 476–478 MHz	9171244H07	
Transmit Post Filter UHF 477–479 MHz	9171244H08	
Transmit Post Filter UHF 482–484 MHz	9171244H09	
Transmit Post Filter UHF 483–485 MHz	9171244H10	

Table continued...

Component Type	Part Number	Replacement Procedure
Transmit Post Filter UHF 488–490 MHz	9171244H11	
Transmit Post Filter UHF 489–491 MHz	9171244H12	
Transmit Post Filter UHF 494–496 MHz	9171244H13	
Transmit Post Filter UHF 495–497 MHz	9171244H14	
Transmit Post Filter UHF 500–502 MHz	9171244H15	
Transmit Post Filter UHF 501–503 MHz	9171244H16	
Transmit Post Filter UHF 506–508 MHz	9171244H17	
Transmit Post Filter UHF 507–509 MHz	9171244H18	
Diplexer 700/800 MHz	9184680Y03	For customer configurations. Contact your Motorola Field Representative or Motorola Solution Support Center (SSC). See Motorola Solution Support Center on page 344 .
Phasing Harness 700 MHz	0184590Y03	
Phasing Harness 800 MHz	0184590Y04	
Power Monitor Unit (PMU) 900 MHz	01009421001	
Power Monitor Unit (PMU) VHF 136–174 MHz	0171259H01	Replacing a Power Monitor Unit (PMU) (UHF/VHF/900 MHz) on page 427
Power Monitor Unit (PMU) UHF R1 350–435 MHz	0171206H01	
Power Monitor Unit (PMU) UHF R2 435–524 MHz	0171206H02	
Expansion to Net AUX Conversion Cable Kit	CLN8731A	
System Connector Cable – SCS12 GTR 8000 Expandable Site Subsystem to Champ	30009466001	
Microphone Kit	GMM4063B	
External Speaker Kit	HSN1006A	
External Speaker Cable	0185180U01	
Cable DC Red/Black 2806mm	30009459002	
Cable DC Black/Blue 2806mm	30009459004	
Battery Temp Sensor 3000mm	30009478001	

Table continued...

Component Type	Part Number	Replacement Procedure
Cable Battery Temp Extension 15500mm	30009461003	
GPS Antenna/Receiver	DS0900382701	
Mounting Kit for GPS Timing Unit	DS0900382701	
GPS Primary Surge Protector	DS0971017AA1	
GPS Antenna/Receiver to RDM Cable (125 ft)	DS30C87465CO 1	
GPS Antenna/Receiver to RDM Cable (350 ft)	DS30C87465CO 2	
GPS Antenna/Receiver to RDM Cable (500 ft)	DS30C87465CO 3	
GPS Antenna/Receiver to RDM Cable (1,000 ft)	DS30C87465CO 4	
ASYNC Zone Control Cable	30009455004	
Dongle Adapter – Telco to Trunking Control and DSM	30009467002	
Analog Simulcast Cable Assem- bly	30009468002	
V.24 or Wireline Cable	30009455003	

Transceiver Hardware Generations

As of July 2013, the GTR 8000 Base Radio is shipped with a new generation of transceiver hardware (referred to in this manual as GEN 2). The hardware updates are intended to extend the life of the device as seamlessly as possible. This section details relevant differences and compatibility requirements for GEN 1 and GEN 2 hardware.

Transceiver Software and Feature Compatibilities

The GEN 2 transceiver hardware is backwards compatible and interchangeable with GEN 1 transceiver hardware on ASTRO[®] 25 7.7 and later systems. GEN 1 transceivers can no longer be ordered; however, spare inventory of GEN 1 transceivers can be used as Field Replaceable Unit (FRU) replacements.

All ASTRO[®] 25 system features are supported on GEN 1 and GEN 2 transceivers, with the following exceptions.

Table 125: System Feature Exceptions

Feature	GEN 1 Transceiver	GEN 2 Transceiver
X2 TDMA	Supported	Not Supported
3600 Operation	Not Supported	Supported

GEN 2 transceiver hardware is not compatible with ASTRO[®] 25 GTR 8000 Base Radio software distributed before July 2013. The transfer operation fails if you perform a software download using a SWDL application released before July 2013.

BEFORE installing a FRU replacement or expansion channel at an existing site, ensure that you are using the latest available SWDL application, and that all base radios and receivers at the site meet the minimum software version requirements listed. Contact Motorola Solution Support Center (SSC) at 800-422-4210 if you do not have access to compatible software.

Table 126: Minimum Software Download Version Requirements

ASTRO® 25 System Release	HPD	Site Repeater	Multi-Site	Conventional	3600
7.6 and earlier	Not Supported			N/A	N/A
7.7	HPDDBR_ R07.7X.023	SiteRptrBR_ R07.7X.031	MsBR_ R07.7X.033	N/A	N/A
7.8	HPDDBR_ R07.8X.033	SiteRptrBR_ R07.8X.038	MsBR_ R07.8X.038	N/A	N/A
7.9	HPDDBR_ R07.9X.049	SiteRptrBR_ R07.9X.050	MsBR_ R07.9X.051	ConvRptrBR_ R07.9X.051	Any Version
7.11	HPDDBR_ R07.BX.098	SiteRptrBR_ R07.BX.102_P2 SiteRptrBR_ R07.BX.102_P2	MsBR_ R07.BX.102_X2 MsBR_ R07.BX.102_P2	ConvBR_ R07.BX.100	Any Version
7.12	HPDDBR_ R07.CX.051	SiteRptrBR_ R07.CX.051_X2 SiteRptrBR_ R07.CX.051_P2	MsBR_ R07.CX.051_X2 MsBR_ R07.CX.051_P2	ConvBR_ R07.CX.057	Any Version
7.13	HPDDBR_ R07.DX.073	SiteRptrBR_ R07.DX.079_X2 SiteRptrBR_ R07.DX.079_P2	MsBR_ R07.DX.079_X2 MsBR_ R07.DX.079_P2	ConvBR_ R07.DX.074	Any Version
7.14 and later	Any Version				



CAUTION: It is crucial that a site software download is performed at a trunked ASTRO® 25 site to ensure that all devices are on the same software version, VLAN, and active bank. Failure to perform this step, results in the replacement transceiver or expansion channel to have a mismatch in software versions. If a mismatch in software versions occurs, the transceiver may go into a configuration mode of operation with a reason of 'Invalid Software Version'. A site software download is not available for conventional or trunked 3600 devices.


Identifying Transceiver Hardware Generation

Label

GEN 1 and GEN 2 transceiver modules can be identified by examining the physical hardware label. GEN 2 modules have a light blue label with 'GEN 2' clearly noted on it, while GEN 1 modules have a white label with no GEN identification.

Figure 156: GEN 1 Transceiver Module

GTR8000_XCVR_LED_Closeup_1

Figure 157: GEN 2 Transceiver Module

GTR8000_XCVR_LED_Closeup_4

Configuration/Service Software

GEN 1 and GEN 2 transceiver modules already installed in a system can be identified through the **Hardware Version** screen of the Configuration/Service Software (CSS).

Transceiver FRU Number Mappings

Table 127: Transceiver FRU Number Mappings

Transceiver FRU Number	GEN 1 (Shipped before Nov 2013)	GEN 2 (Shipped starting July 2013)
Transceiver Module (900 MHz)	DLN6778A	DLN6882A
Transceiver Module w/OCXO Transceiver Option Card (900 MHz)	N/A	DLN6923A
Transceiver Module (700/800 MHz)	DLN6566A	DLN6885A
Transceiver Module w/OCXO Transceiver Option Card (700/800 MHz)	DLN1430A	DLN6883A
Transceiver Module (UHF R2, 435–524 MHz)	DLN1346A	
Power Efficiency Transceiver Module (UHF R2, 435–524 MHz)	DLN6789A	DLN6884A

Table continued...

Transceiver FRU Number	GEN 1 (Shipped before Nov 2013)	GEN 2 (Shipped starting July 2013)
Transceiver Module w/OCXO Transceiver Option Card (UHF R2, 435–524 MHz)	DLN1433A	DLN6886A
Power Efficiency Transceiver Module w/TCXO Transceiver Option Card (UHF R2, 435–524 MHz)	DLN6790A	DLN6887A
Transceiver Module (UHF R1, 380–435 MHz)	DLN1395A	
Power Efficiency Transceiver Module (UHF R1, 380–435 MHz)	DLN6786A	DLN6888A
Transceiver Module w/OCXO Transceiver Option Card (UHF R1, 380–435 MHz)	DLN1432A	DLN6889A
Power Efficiency Transceiver Module w/TCXO Transceiver Option Card (UHF R1, 380–435 MHz)	DLN6787A	DLN6890A
Transceiver Module (VHF, 136– 174 MHz)	DLN1376A	DLN6892A
Transceiver Module w/OCXO Transceiver Option Card (VHF 136–174 MHz)	DLN1431A	DLN6893A

Power Amplifier Hardware Generations

Starting in July 2013, the GTR 8000 Base Radio is shipped with a new generation of power amplifier hardware (referred to in this manual as GEN 2). The hardware updates extend the life of the base radio as seamlessly as possible. This section details relevant differences and compatibility requirements for GEN 1 and GEN 2 hardware.

Power Amplifier Software and Feature Compatibilities

The GEN 2 power amplifier hardware is fully backwards compatible and completely interchangeable with GEN 1 power amplifier hardware. GEN 1 power amplifiers can no longer be ordered; however, spare inventory of GEN 1 power amplifiers can be used as Field Replaceable Unit (FRU) replacements.

All ASTRO® 25 system features are supported on GEN 1 and GEN 2 power amplifiers. All ASTRO® 25 system release software is supported on GEN 1 and GEN 2 power amplifiers.

Identifying Power Amplifier Hardware Generation

Label

GEN 1 and GEN 2 power amplifier modules can be identified by examining the physical hardware label. GEN 2 modules have a light blue label with 'GEN 2' clearly noted on it, while GEN 1 modules have a white label with no GEN identification.

Figure 158: GEN 1 Power Amplifier Module



GTR8000_PA_LED_Closeup

Figure 159: GEN 2 Power Amplifier Module



GTR8000_PA_LED_Closeup1

CSS

GEN 1 and GEN 2 power amplifier modules already installed in a system can be identified through the **Hardware Version** screen of the Configuration/Service Software (CSS).

Power Amplifier FRU Number Mappings

Table 128: Power Amplifier FRU Number Mappings

Power Amplifier FRU Number	GEN 1 (Shipped before Nov 2013)	GEN 2 (Shipped starting July 2013)
Power Amplifier Module (900 MHz)	DLN6779A	DLN6894A
Power Amplifier Module (700/800 MHz)	DLN6567A	DLN6895A
Power Amplifier Module (UHF R2, 435–524 MHz)	DLN1347A	DLN6896A

Table continued...

Power Amplifier FRU Number	GEN 1 (Shipped before Nov 2013)	GEN 2 (Shipped starting July 2013)
Power Efficiency Power Amplifier Module (UHF R2, 435–524 MHz)	DLN6792A	
Power Amplifier Module (UHF R1, 380–435 MHz)	DLN1396A	
Power Efficiency Power Amplifier Module (UHF R1, 380–435 MHz)	DLN6788A	DLN6891A
Power Amplifier Module (VHF, 136–174 MHz)	DLN1377A	DLN6897A


Replacing a GTR 8000 Base Radio Transceiver Module

Figure 160: GTR 8000 Base Radio Transceiver Module



GTR8000_XCVR_wSAC

To help you locate the correct transceiver module, the metal card cage is stamped with numbers matching the numbers in [Figure 161: GTR 8000 Expandable Site Subsystem \(repeater shown\) on page 359](#).

Figure 161: GTR 8000 Expandable Site Subsystem (repeater shown)

A25_expandable_subsystem_config_A

Prerequisites: Before replacing the transceiver, pull configuration and hardware information from the base radio into the Unified Network Configurator (UNC) by performing a “Pull All” procedure from the UNC. For instructions on “How to Perform a Pull All”, see the *Unified Network Configurator* manual. This step may not be possible if communication is severed between the base radio and the UNC or if the base radio is within a K core or non-networked site. If this scenario exists, perform any one of the following:

- Use the last known good configuration files from the UNC
- Extract the configuration files from the base radio directly

Procedure:

- 1 Wear an electrostatic discharge (ESD) strap and connect its cable to a verified good ground.



CAUTION: Wear the ESD throughout this procedure to prevent ESD damage to any components.

- 2 Locate the transceiver module being replaced.



NOTICE: See [Figure 161: GTR 8000 Expandable Site Subsystem \(repeater shown\) on page 359](#) to help you locate the correct module. The metal card cage is stamped with numbers matching the numbers in the diagram.

- 3 If the transceiver module is not operational, go to [step 9](#).

- 4 Connect to the transceiver Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
- 5 Save the configuration to the laptop PC as follows:
 - a From the menu, select **File** → **Read Configuration From Device**.
 - b At the confirmation screen, click **OK**.
 - c When the **Progress Monitor** screen is complete, click **OK**.
 - d From the menu, select **File** → **Save As**.
 - e On the **Properties Screen**, enter the IP address of the base radio. Click **OK**.
 - f On the **Save** window, select the directory where you want to save the configuration file, type a meaningful name for the file (use cpl as the extension or do not type an extension). Press **ENTER**.

The configuration is saved to the location indicated. The configuration file is reloaded later to the replacement transceiver module.

- 6 For a trunked base radio, place the base radio into Service Mode, so the system does not attribute the loss of channel to a failure.
 - a From the menu, select **Service** → **Test and Measurement Screen**.
The **Test and Measurement Screen** appears.
 - b Click **Change to Service Mode**.
 - c At the confirmation screen, click **OK**.
The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.
- 7 Optional: It is not necessary to turn off the power supply for the transceiver module you are replacing, as the modules are designed to be swapped out with the power on. If you choose to turn off the power, set the rocker switch on the front of the associated power supply to the Off (O) position.
- 8 Disconnect the Ethernet cable from the service port on the transceiver being replaced.
- 9 Remove the fan assembly unit to gain access to the transceiver module. See [Replacing the Fan Assembly on page 374](#).



IMPORTANT: Although the transceiver module is designed to be swapped out without shutting the power off, you should minimize the amount of time that the fan assembly is removed, so the circuitry that remains powered on does not overheat and shut down.

- 10 Label and disconnect all cables from the ports on the transceiver.
- 11 Using a T20 bit, loosen the two captive screws on the front of the transceiver module, so they disengage from the chassis.
- 12 Using the handle, gently pull the transceiver module straight out, along the guides on which it sits.
- 13 Slide the replacement transceiver module in the card cage slot stamped with the letters XCVR and the number of the transceiver module you are replacing. Slide the transceiver module along the guiding rails until it is engaged. A slight push may be needed to engage the module.



IMPORTANT: If the transceiver module stops well before it is engaged, it is in an incorrect position. Either it is in the wrong slot or it is rotated 180°. The module has a keying feature that prevents it from going all the way into an incorrect slot, or going into the correct slot but rotated 180°. Do not try to force the module.

LEDs on the transceiver turn on when it is engaged.

- 14 Secure the transceiver module to the chassis with the two captive screws on the front of the module.
- 15 Reconnect all cables to the ports on the transceiver.
- 16 Reinstall the fan assembly unit. See [Replacing the Fan Assembly on page 374](#).
- 17 Optional: If you chose to turn off the power, set the rocker switch on the front of the associated power supply to the On (I) position.
- 18 Perform basic device configuration in CSS using the serial port. See [Connecting Through a Serial Port Link on page 258](#).
 - a Set the IP Address and BR_CM Pairing Number for the device. See [Setting the Device IP Address and Pairing Number in CSS on page 260](#).
 - b Set the Serial Security Services. See [Setting the Serial Security Services in CSS on page 261](#).
- 19 Disconnect the laptop PC from the base radios serial service port.
- 20 Perform basic device configuration in CSS using the Ethernet port. See [Connecting Through an Ethernet Port Link on page 262](#).
 - a Set the current date and time. See [Setting the Date and Time in CSS on page 265](#).
 - b Set up the local Password Configuration (optional). See [Setting the Local Password Configuration in CSS on page 271](#).

NOTICE: An IP address must be configured to set up the local password. If the serial port access is not available to configure the IP address, the transceiver may have the account locked out or the backplane slot has passwords enabled. Connect to the front-panel local Ethernet service port using a fixed IP address to perform the password reset. See [Connecting Through an Ethernet Port Link on page 262](#).
- 21 Complete the configuration of the Information Assurance features using CSS, as follows:
 - a Change the SNMPv3 configuration and user credentials. See [Changing SNMPv3 Configuration and User Credentials in CSS on page 265](#).
 - b Create, update, or delete an SNMPv3 user. See [Adding or Modifying an SNMPv3 User in CSS on page 268](#).
 - c Verify the SNMPv3 credentials. See [Performing an SNMPv3 Connection Verification in CSS on page 268](#).
 - d Set the SWDL transfer mode. See [Setting the SWDL Transfer Mode in CSS on page 269](#).
 - e Configure for DNS. See Chapter 7, “Configuring DNS in CSS” in the *Authentication Services* manual.
 - f Configure for SSH. See Chapter 4, “Configuring SSH for RF Site Devices VPMs in CSS” in the *Securing Protocols with SSH* manual or see “Device Security Configuration Remote Access/Login Banner (Ethernet)” in the *CSS Online Help*.

NOTICE: Restore the Clear Protocols parameters.
 - g Enable RADIUS Authentication. See Chapter 7, “Configuring RADIUS Sources and Parameters in CSS” in the *Authentication Services* manual.
 - h Enable Centralized Authentication. See Chapter 7, “Enabling/Disabling Centralized Authentication in CSS” in the *Authentication Services* manual.
 - i Set the Local Cache Size for Centralized Authentication. See Chapter 7, “Setting the Local Cache Size for Central Authentication in CSS” in the *Authentication Services* manual.
 - j Enable Centralized Event Logging (if required by your organization). See Chapter 6, “Enabling/Disabling Centralized Event Logging on Devices in CSS” and Chapter 1, “Event

Logging Client Configuration” for proper hostnames in the *Centralized Event Logging* manual.

- k Set the NTP Server Settings. See [NTP Server Settings in CSS on page 270](#).
- 22** For a conventional or trunked 3600 device, perform a single device software download to transfer and install the latest base radio software using Software Download as follows:
- a Open the Software Download application.
 -  **CAUTION:** Make sure to load the correct version of the software. There is a possibility of a mismatch in software versions when replacing the transceiver module with an on-hand spare. If a mismatch in software versions occurs, this mismatch may cause all base radios at the site to go into a configuration mode of operation with a reason of ‘Invalid Software Version’. To exit out of configuration mode, see CSS Procedures > Changing from Configuration to Normal Mode in the CSS Online Help.
 - b
 - c From the menu, select **File Manager** → **File**.
The **Software Depot File Manager** opens.
 - d From the menu, select **Component Operations** → **Import Fileset**.
The **Import a Fileset Into the Software Depot** dialog box appears.
 - e Click **Browse** and search for the `swdlv3.cfg` file on the CD, or follow path `E:\swdl\swdlv1.cfg` or `swdlv3.cfg`. Click **Open**.
 - f In the **Software Depot** list, click **Generate** to add the file to the Components. Click **OK**.
 - g Exit the **Software Depot File Manager**.
 - h From Software Download, select **Single Device Mode**.
 - i Enter the *<IP address>* of the device. Click **Connect**.
A **Security Level** screen appears.
 - j Choose the required security level. Click **OK**.
 - k In the **Select an option** window, select **Upgrade Software Application**. Click **Continue**.
 - l In the **Operations Type** field, select **Transfer and Install**.
 - m In the **Application Type** field, select the application to install.
 - n From the **Software Component** drop-down list, select a configuration fileset.
 - o Select **Start Operation**.
- 23** Perform a site download and installation for trunked ASTRO® 25 devices. See [Performing a Site Download on page 458](#).
- A site software download is not available for conventional or trunked 3600 devices.
-  **CAUTION:** It is crucial that a site software download is performed at the site to ensure that all devices are on the same software version, VLAN, and active bank. Failure to perform this step, results in the replacement transceiver or expansion channel to have a mismatch in software versions. If a mismatch in software versions occurs, the transceiver may go into a configuration mode of operation with a reason of ‘Invalid Software Version’.
- 24** Restore the Codeplug Archive from backup. Reload the base radio configuration file on the new base radio using CSS, as follows:
- a From the menu, select **File** → **Open**.
 - b Locate and open the previously saved configuration file for the base radio.



NOTICE: If you were not able to back up the configuration from the previous base radio, you can use the configuration from your system build book or use the default base radio configuration file. Specific settings for the base radio must still be configured. See the *CSS Online Help* for GTR 8000 Base Radio for detailed configuration instructions. If the base radio is part of a Power Efficiency Package, make sure that the base radio Tx Power Out in the CSS is limited to 50 W.

- c On the **Properties** window, click **OK**.
- d When the **Progress Monitor** screen is complete, click **OK**.
- e From the menu, select **File** → **Write Configuration To Device**. Click **OK**.
- f On the Ethernet connection confirmation screen, click **OK**.
- g On the **Connection** screen, enter the *<IP address>* and click **Connect**.
- h On the **SNMPv3 PassPhrase Prompt** dialog box, enter the **User Information** and **Passphrase Information**. Click **OK**. If Authentication Services are not enabled on a device, click **OK** when the dialog box appears.
- i On the confirmation screen, click **OK**.
- j When the **Progress Monitor** screen is complete, click **OK**.

The configuration from the file selected is loaded into the base radio. Communication with the base radio is not available until the reset is complete.

25 Read the base radio, as follows:

- a From the menu, select **File** → **Read Configuration From Device**.
- b On the confirmation screen, click **OK**.
- c When the **Progress Monitor** screen is complete, click **OK**.

26 Place the base radio into Normal Mode, as follows:

- a From the menu, select **Service** → **Mode Screen**.
The **Mode Screen** appears.

- b Click **Change to Normal Mode**.

- a At the confirmation screen, click **OK**.

The base radio goes through a reset sequence, which takes a few minutes, and switches operation to the requested mode.

27 On systems with MAC Port locking, disable the locking and then re-enable the locking with the MAC address of the base radio. The device being replaced may be connected to an Ethernet port on a switch which implements MAC Port locking (HP switch, site controller, RDM, or XHub). If so, the Ethernet switch port must be unlocked and relocked to the MAC address of the replacement device. See the *MAC Port Lockdown* manual for instructions on how to disable and enable MAC Port locking.



NOTICE: Following the device restoration, if it was connected to an HP switch port, the HP switch port may have been disabled due to an unexpected MAC address. If so, re-enable the port on the HP switch.

28 Replace the base radio in the UNC. See Chapter 4, “Replacing a Device” *Unified Network Configurator* manual.

29 Discover the base radio in the UEM. See the *Unified Event Manager* manual.

30 Verify that the base radio is operating properly:

- The Status LED on the front of the base radio is green.

- Proper operation is confirmed using software tools, such as Unified Event Manager (UEM), and the Transmitter Metering Screen in Configuration/Service Software (CSS).

Replacing the GCP 8000 Site Controller Module



IMPORTANT: The site controller module can be hot swapped out without losing functionality. The standby site controller automatically becomes the active site controller and takes over if the active site controller is the one being swapped out.

Figure 162: GCP 8000 Site Controller FRU Module



HPD_GCP8000_site_controller_FRU.jpg

Prerequisites: Before replacing the site controller, pull configuration and hardware information from the site controller module into the Unified Network Configurator (UNC) by performing a “Pull All” procedure from the UNC. For instructions on “How to Perform a Pull All” procedure, see the “*Unified Network Configurator*” manual. This step may not be possible if communication is severed between the site controller and the UNC or if the site controller is within a K1/K2 or non-networked site. If this scenario exists, perform any one of the following:

- Use the last known good configuration files from the UNC.
- Extract the configuration files from the site controller directly.

Procedure:

- 1 Wear an Electrostatic Discharge (ESD) strap and connect its cable to a verified good ground.



CAUTION: Wear the ESD strap throughout this procedure to prevent ESD damage to any components.

- 2 Locate the site controller module to be replaced.



NOTICE: See [Figure 161: GTR 8000 Expandable Site Subsystem \(repeater shown\) on page 359](#) to help you locate the correct module. The metal card cage is stamped with numbers matching the numbers in the diagram.

- 3 If the site controller module is non-operational, go to [step 8](#).
- 4 Connect to the site controller Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
- 5 Save the site controller configuration to the laptop PC as follows:
 - a From the menu, select **File** → **Read Configuration From Device**.
 - b At the success message, click **OK**.
 - c From the menu, select **File** → **Save As**.
 - d On the **Properties** window, enter the `<IP address>` of the device. Click **OK**.

- e Specify the directory location where you want to save the configuration file, type a meaningful name for the file. Press **ENTER**.

The site controller configuration is saved to the location indicated. The configuration file is reloaded later to the replacement site controller module.

- 6 Disable the site controller module as follows:

- a From the menu, select **Service** → **Status Panel Screen**.

The **Status Panel Screens** window appears.

- b Select the **Site Controller** tab.

- c From the **User Requested Site Controller State** list box, select **User Disabled**.

The site controller module resets. After approximately two minutes, it is disabled. If this is the active site controller module, control switches over to the standby site controller module.

- 7 Disconnect the Ethernet cable from the service port on the site controller being replaced.

- 8 Remove the fan assembly to gain access to the site controller module. See [Replacing the Fan Assembly on page 374](#).



IMPORTANT: The site controller module is designed to be swapped out without shutting the power off. The fan assembly, however, must be in place within a reasonable amount of time so the redundant site controller module does not overheat and shut down.

- 9 Label and disconnect all cabling on the front of the site controller module.

- 10 Loosen the two captive screws holding the site controller module to the chassis.

- 11 Using the handle, gently pull the used module straight out, along the guides on which it sits.

- 12 Slide in the replacement site controller module into the card cage slot stamped with the letters SC and the number of the site controller module being replaced. Slide the site controller module along the guiding rails until it is engaged. A slight push is needed to engage the module.



IMPORTANT: If the site controller module stops well before it is engaged, it is in an incorrect position. Either it is in the wrong slot or it is rotated 180°. The module has a keying feature that prevents it from going all the way into an incorrect slot, or going into the correct slot but rotated 180°. Do not try to force the module.

- 13 Secure the site controller module with the two captive screws.

- 14 Reconnect all the cabling to the correct ports as previously labeled.

- 15 Reinstall the fan assembly. See [Replacing the Fan Assembly on page 374](#).

- 16 Perform basic device configuration in CSS through the serial port. See [Connecting Through a Serial Port Link on page 258](#).

- a Set the IP address of the device. See [Setting the Device IP Address and Pairing Number in CSS on page 260](#).

- b Set the serial security services. See [Setting the Serial Security Services in CSS on page 261](#).

- 17 Disconnect the laptop PC from the device modules DB-9 serial service port.

- 18 Perform basic device configuration in CSS through the Ethernet port. See [Connecting Through an Ethernet Port Link on page 262](#).

- a Set the current date and time. See [Setting the Date and Time in CSS on page 265](#).

- b Set up the local Password Configuration (optional). See [Setting the Local Password Configuration in CSS on page 271](#).

An IP address must be configured to set up the local password. If the serial port access is not available to configure the IP address, the device may have the account locked out or the backplane slot has passwords enabled. Perform the following:

- 1 Move the device module to a different slot in the backplane where local passwords are not configured.
 - 2 Configure the IP address and reset the device through the front panel RS-232 serial service port using CSS.
 - 3 Perform the local password reset operation (to clear account information stored in the FRU) through and Ethernet port link using CSS.
 - 4 Move the device module back to the original slot.
 - 5 Perform the local password reset operation again (to clear account information stored in the backplane).
- 19 Complete the configuration of the Information Assurance features using CSS, as follows:
- a Change the SNMPv3 configuration and user credentials. See [Changing SNMPv3 Configuration and User Credentials in CSS on page 265](#).
 - b Create, update, or delete an SNMPv3 user. See [Adding or Modifying an SNMPv3 User in CSS on page 268](#).
 - c Verify the SNMPv3 credentials. See [Performing an SNMPv3 Connection Verification in CSS on page 268](#).
 - d Set the SWDL transfer mode. See [Setting the SWDL Transfer Mode in CSS on page 269](#).
 - e Configure for DNS. See Chapter 7, “Configuring DNS in CSS” in the *Authentication Services* manual.
 - f Configure for SSH. See Chapter 4, “Configuring SSH for RF Site Devices and VPMs in CSS” in the *Securing Protocols with SSH* manual or see “Device Security Configuration Remote Access/Login Banner (Ethernet)” in the *CSS Online Help*.
-  **NOTICE:** Restore the Clear Protocols parameters.
- g Enable RADIUS Authentication. See Chapter 7, “Configuring RADIUS Sources and Parameters in CSS” in the *Authentication Services* manual.
 - h Enable Centralized Authentication. See Chapter 7, “Enabling/Disabling Centralized Authentication in CSS” in the *Authentication Services* manual.
 - i Set the Local Cache Size for Centralized Authentication. See Chapter 7, “Setting the Local Cache Size for Central Authentication in CSS” in the *Authentication Services* manual.
 - j Enable Centralized Event Logging (if required by your organization). See Chapter 6, “How to Enable/Disable Centralized Event Logging on Devices in CSS” and Chapter 1, “Event Logging Client Configuration” for proper hostnames in the *Centralized Event Logging* manual.
- 20 Restore the Codeplug Archive from the backup. Using an Ethernet port link connection, reload the site controller configuration file on to the new site controller using CSS, as follows:
- a From the menu, select **File** → **Open**.
 - b Locate and select the previously saved configuration file for the site controller module. Click **OK**.



NOTICE: If you were not able to back up the configuration from the previous site controller module, you can use the configuration from your system build book or use the default configuration file for the site controller module. Specific settings for the site controller module must still be configured. See *CSS Online Help* for detailed configuration instructions.

- c) On the **Properties** window, click **OK**.
- d) When the **Progress Monitor** screen is complete, click **OK**.
- e) From the menu, select **File** → **Write Configuration To Device**. Click **OK** on the confirmation message.

The configuration from the file you selected is loaded into the new site controller module.

21 Enable the site controller module as follows:

- a) From the menu, select **Service** → **Status Panel Screen**.

The **Status Panel Screens** window appears.

- b) Select the **Site Controller** tab.

- c) From the **User Requested Site Controller State** list box, select **Enabled**.

The site controller module is enabled after approximately two minutes.

22 Perform a site software download (SWDL) with the SNMPv3 package (if SNMPv3 is desired) of the device and associated site devices. See [Performing a Site Download on page 458](#).

23 Restore the 802.1x / MAC Port Lockdown feature as follows:

- a) Capture the MAC address of the device on the GCP 8000 switch for all devices connected to the GCP 8000 Site Controller. See “Capturing the MAC Address of a Device Connected to a GCP 8000” in the *MAC Port Lockdown* manual.
- b) Update/verify the site controller MAC Port Lockdown Configuration. See Chapter 6, “Enabling/Disabling 802.1x and MAC Port Lockdown for GCP 8000 in CSS” and “Validating MAC Port Lockdown on a GCP 8000 or GPB 8000” in the *MAC Port Lockdown* manual.
- c) Update/verify the site controller 802.1x configuration on HPD and repeater site controllers. See “Enabling/Disabling 802.1x and MAC Port Lockdown for GCP 8000 in CSS” in the *802.1x Service Ports on Switches* manual.

24 Replace the site controller in the UNC. See Chapter 4, “Replacing a Device” in the *Unified Network Configurator* manual.

25 Discover the site controller in the UEM. See the *Unified Event Manager* manual.

26 Verify that the site controller module is operating properly:

- The Link Status LED for the RJ-45 Service port on the front of the new site controller module is green.
- The Status LED on the front of the site controller is green.
- Use software tools, such as Unified Event Manager (UEM) and CSS, to verify the status of the equipment.

Replacing a GPB 8000 Reference Distribution Module (RDM)


Figure 163: GPB 8000 Reference Distribution Module



HPD_GCP8000_site_controller_FRU.jpg

To help you locate the correct RDM, the metal card cage is stamped with numbers matching the numbers in [Figure 164: GTR 8000 Expandable Site Subsystem \(trunked IP simulcast high availability shown\)](#) on page 369.

Figure 164: GTR 8000 Expandable Site Subsystem (trunked IP simulcast high availability shown)



GTR_8000_RDM_expandable_subsystem_IP_Sim_B

Prerequisites: Before replacing the device, pull configuration and hardware information from the device into the Unified Network Configurator (UNC) by performing a “Pull All” procedure from the UNC. For instructions on “How to Perform a Pull All”, see the *Unified Network Configurator* manual. This step may not be possible if communication is severed between the device and the UNC. If this scenario exists, perform any one of the following:

- Use the last known good configuration files from the UNC.
- Extract the configuration files from the device directly.

Procedure:

- 1 Wear an electrostatic discharge (ESD) strap and connect its cable to a verified good ground.



CAUTION: Wear the ESD strap throughout this procedure to prevent ESD damage to any components.

- 2 Locate the RDM being replaced.



NOTICE: See [Figure 164: GTR 8000 Expandable Site Subsystem \(trunked IP simulcast high availability shown\)](#) on page 369 to help you locate the correct module. The metal card cage is stamped with numbers matching the numbers in the diagram.

- 3 If the RDM is not operational, go to [step 9](#).

- 4 Connect to the RDM Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
- 5 Save the configuration to the laptop PC as follows:
 - a From the menu, select **File** → **Read Configuration From Device**.
 - b At the success message, click **OK**.
 - c From the menu, select **File** → **Save As**.
 - d On the **Properties Screen**, enter the `<IP address>` of the RDM. Click **OK**.
 - e Specify the directory location where you want to save the configuration file, type a meaningful name for the file (use `cpl` as the extension or do not type an extension). Press **ENTER**.

The configuration is saved to the location indicated. The configuration file is reloaded later to the replacement RDM.

- 6 Disable the RDM as follows:
 - a From the menu, select **Service** → **Status Panel Screen**.
The **Status Panel Screens** window appears.
 - b Select the **Reference Distribution Module** tab.
 - c From the **User Requested State** list box, select **User Disabled**.
The RDM resets, after approximately two minutes, it is disabled.
- 7 Optional: If you choose to turn off the power, set the rocker switch on the front of the associated power supply to the Off (O) position.
- 8 Disconnect the Ethernet cable from the service port on the RDM module being replaced.
- 9 Remove the fan assembly to gain access to the RDM. See [Replacing the Fan Assembly on page 374](#).



IMPORTANT: Although the RDM is designed to be swapped out without shutting the power off, minimize the amount of time that the fan assembly is removed, so the circuitry that remains powered on does not overheat and shut down.

- 10 Label and disconnect all cabling on the front of the RDM.
- 11 Using a T20 bit, loosen the two captive screws on the front of the RDM, so they disengage from the chassis.
- 12 Using the handle, gently pull the RDM straight out, along the guides on which it sits.
- 13 Slide in the replacement RDM into the card cage slot stamped with the letters SC and the number of the RDM being replaced. Slide the RDM along the guiding rails until it is engaged. A slight push may be needed to engage the module.



IMPORTANT: If the RDM stops well before it is engaged, it is in an incorrect position. Either it is in the wrong slot or it is rotated 180°. The module has a keying feature that prevents it from going all the way into an incorrect slot, or going into the correct slot but rotated 180°. Do not try to force the module.

The LEDs on the RDM turn on when it is engaged.

- 14 Using a T20 bit, secure the RDM to the chassis with the two captive screws on the front of the module.
- 15 Reconnect all the cabling to the correct ports as previously labeled.
- 16 Reinstall the fan assembly. See [Replacing the Fan Assembly on page 374](#).

17 Optional: If you chose to turn off the power, set the rocker switch on the front of the associated power supply to the On (I) position.

18 Perform basic device configuration using the serial port. See [Connecting Through a Serial Port Link on page 258](#).

- a** Set the IP Address and the Box Number for the device. See [Setting the Device IP Address and Pairing Number in CSS on page 260](#).
- b** Set the Serial Security Services. See [Setting the Serial Security Services in CSS on page 261](#).

19 Disconnect the laptop PC from the RDMs DB-9 serial service port.

20 Perform basic device configuration using the Ethernet port. See [Connecting Through an Ethernet Port Link on page 262](#).

- a** Set the current date and time. See [Setting the Date and Time in CSS on page 265](#).
- b** Set up the local Password Configuration (optional). See [Setting the Local Password Configuration in CSS on page 271](#).

An IP address must be configured to set up the local password. If the serial port access is not available to configure the IP address, the device may have the account locked out or the backplane slot has passwords enabled. Perform the following:

- 1** Move the device module to a different slot in the backplane where local passwords are not configured.
- 2** Configure the IP address and reset the device through the front panel RS-232 serial service port using CSS.
- 3** Perform the local password reset operation (to clear account information stored in the FRU) through and Ethernet port link using CSS.
- 4** Move the device module back to the original slot.
- 5** Perform the local password reset operation again (to clear account information stored in the backplane).

21 Complete the configuration of the Information Assurance features in CSS, as follows:

- a** Change the SNMPv3 configuration and user credentials. See [Changing SNMPv3 Configuration and User Credentials in CSS on page 265](#).
- b** Create, update, or delete an SNMPv3 user. See [Adding or Modifying an SNMPv3 User in CSS on page 268](#).
- c** Verify the SNMPv3 credentials. See [Performing an SNMPv3 Connection Verification in CSS on page 268](#).
- d** Set the Software Download Manager (SWDL) transfer mode. See [Setting the SWDL Transfer Mode in CSS on page 269](#).
- e** Configure DNS using the CSS. See Chapter 7, “Configuring DNS in CSS” in the *Authentication Services* manual.
- f** Configure for Secure SHell (SSH). See Chapter 4, “Configuring SSH for RF Site Devices and VPMs in CSS” in the *Securing Protocols with SSH* manual or see “Device Security Configuration Remote Access/Login Banner (Ethernet)” in the *CSS Online Help*.
- g** Restore the following Clear Protocols parameters in the Remote Access Configuration tab on the Device Security Configuration screen in CSS. See “Device Security Configuration Remote Access/Login Banner (Ethernet)” in the *CSS Online Help*.
- h** Enable RADIUS Authentication . See Chapter 7, “Configuring RADIUS Sources and Parameters in CSS” in the *Authentication Services* manual.

- i Enable Centralized Authentication. See Chapter 7, “Enabling/Disabling Centralized Authentication in CSS” in the *Authentication Services* manual.
 - j Set the Local Cache Size for Centralized Authentication in CSS. See Chapter 7, “Setting the Local Cache Size for Central Authentication in CSS” in the *Authentication Services* manual.
 - k Enable Centralized Event Logging (if required by your organization). See Chapter 6, “Enabling/Disabling Centralized Event Logging on Devices in CSS” and Chapter 1, “Event Logging Client Configuration” for proper hostnames in the *Centralized Event Logging* manual.
 - l Set the NTP Server Settings. See [NTP Server Settings in CSS on page 270](#).
- 22 Perform a single device download to transfer and install the latest RDM software using Software Download as follows:
- a Open the Software Download application.
 -  **CAUTION:** Load the correct version of the software. There is a possibility of a mismatch in software versions when replacing the RDM with an on-hand spare. If a mismatch in software versions occurs, it may cause all base radios at the site to go into a configuration mode of operation with a reason of 'Invalid Software Version'. To exit the base radios out of configuration mode, see CSS Procedures > Changing from Configuration to Normal Mode in the CSS Online Help. If a mismatch in software versions occurs with an RDM, the mismatch may cause a 'critical malfunction', or if the RDM becomes active, may bring the entire site into a configuration mode of operation.
 - b From the menu, select **File** → **File Manager**.
The **Software Depot File Manager** opens.
 - c From the menu, select **Component Operations** → **Import Fileset**.
The **Import a Fileset Into the Software Depot** dialog box appears.
 - d Click **Browse** and search for the `swdlv3.cfg` file on the CD, follow the path `E:\swdl1\swdlv1.cfg` or `swdlv3.cfg`. Click **Open**.
 - e Click **Generate** to add the file to the **Components In the Software Depot** list. Click **OK**.
 - f Exit the **Software Depot File Manager**.
 - g From Software Download, select **Single Device Mode**.
 - h Enter the **<IP address>** of the device. Click **Connect**.
A **Security Level** screen appears.
 - i Choose the required security level. Click **OK**.
 - j In the **Select an Option** drop down list, select **Upgrade Software Application**. Click **Continue**.
 - k In the **Operations Type** drop down list, select **Transfer and Install**.
 - l In the **Application Type** drop down list, select the application to install.
 - m Select **Start Operation**.
The software is transferred and installed on to the device. The transfer and install takes several minutes to complete. When completed, the two progress bars on the **Transfer and Install** window display 100% and a completion message displays in the **Transfer** message box.
- 23 Restore the Codeplug Archive from the backup. Reload the configuration file into the RDM using CSS as follows:

- a From the CSS menu, select **File** → **Open**.
- b Locate and open the previously saved configuration file for the RDM.



NOTICE: If you were not able to back up the configuration from the previous RDM, you can use the configuration from your system build book or use the default RDM configuration file. Specific settings for the RDM must still be configured. See Site Controller Configuration & Service Help > GPB 8000 Reference Distribution in the *CSS Online Help* for RDM detailed configuration instructions.
- c On the **Properties** window, click **OK**.
- d When the **Progress Monitor** screen is complete, click **OK**.
- e From the menu, select **File** → **Write Configuration To Device**. Click **OK** on the confirmation message.

The configuration from the file you selected is loaded into the RDM. Communication with the RDM is not available until the reset is complete.

24 Enable the RDM as follows:

- a From the menu, select **Service** → **Status Panel Screen**.
The **Status Panel Screens** window appears.
- b Select the **Reference Distribution** tab.
- c From the **User Requested State** list box, select **Enabled**.
The RDM is enabled.

25 On systems with MAC Port locking, disable the locking and then re-enable the locking with the MAC address of the RDM. The device being replaced may be connected to an Ethernet port on a switch which implements MAC Port locking (XHub). If so, the Ethernet switch port must be unlocked and relocked to the MAC address of the replacement device. See the *MAC Port Lockdown* manual for instructions on how to disable and enable MAC Port locking.

26 Replace the RDM in the UNC. See Chapter 4, “Replacing a Device” in the *Unified Network Configurator* manual.

27 Discover the RDM in the UEM. See the *Unified Event Manager* manual.


28 Verify that the RDM is operating properly:

- The Status LED on the front of the RDM is green.
- Proper operation is confirmed using software tools, such as UEM, and Configuration/Service Software (CSS).
- Recalibrate the GPS Unit Cable Length Delay Offset. See [1PPS Reference Synchronization on page 287](#).

Replacing the Expansion Hub

When an Expansion Hub is removed, the GCP 8000 Site Controller detects the XHub is not in place and sends a switch fault to the Unified Event Manager. When the XHub is replaced, the site controller automatically detects the new one, enables it, and sends a message to clear the fault in the Unified Event Manager.

Figure 165: Expansion Hub FRU



IMPORTANT: The Expansion Hub can be hot swapped out without losing functionality. The redundant Expansion Hub automatically becomes active and takes over.

Procedure:

- 1 Wear an Electrostatic Discharge (ESD) strap and connect its cable to a verified good ground. Be sure to wear this strap throughout this procedure to prevent ESD damage to any components.
- 2 Remove the fan assembly to gain access to the Expansion Hub module. See [Replacing the Fan Assembly on page 374](#).



IMPORTANT: The Expansion Hub module can be swapped out without shutting the power off.

- 3 Label and disconnect all cabling on the front of the Expansion Hub.
- 4 Using T20 bit, loosen the two captive screws holding the Expansion Hub to the chassis.
- 5 Using the handle, gently pull the used Expansion Hub straight out, along the guides on which it sits.
- 6 Slide in the replacement Expansion Hub module into the card cage slot stamped with the letters SC. Slide the Expansion Hub module along the guiding rails until it is engaged. A slight push is needed to engage it.



IMPORTANT: If the Expansion Hub stops well before it is engaged, then it is in an incorrect position. Either it is in the wrong slot or it is rotated 180°. The module has a keying feature that prevents it from going all the way into an incorrect slot, or going into the correct slot but rotated 180°. Do not try to force it.

- 7 Using a T20 bit, secure the Expansion Hub module with the two captive screws.
- 8 Reconnect all the cabling to the correct ports as previously labeled.
- 9 Reinstall the fan assembly. See [Replacing the Fan Assembly on page 374](#).
- 10 Verify that the Expansion Hub module is operating properly:
 - The Link Status LED for the RJ-45 EXPSN Input port on the front of the new Expansion Hub is green.
 - The Status LED on the front of the Expansion Hub is green.
 - Use software tools, such as Unified Event Manager, to check the alarms of the equipment.

Replacing the Fan Assembly

To prevent overheating, this fan must be in place at all times, except during servicing.




WARNING: When removing a fan module, care should be taken to avoid contacting moving fan blades before and after removal with tools, hands, or other objects. If you are removing the fan module to access or replace the modules behind it, turn off the equipment power and allow the modules to cool before performing any work, as the surfaces of the modules can be extremely hot.



IMPORTANT: The fan assembly can be swapped out without shutting the power off. The replacement fan assembly must be in place within a reasonable amount of time, so that the device module does not overheat and shut down.

Figure 166: Fan Assembly



Procedure:

- 1 Wear an electrostatic discharge (ESD) wrist strap and connect its cable to a verified good ground. This strap must be worn throughout this procedure to prevent ESD damage to any components.
- 2 Using a T20 bit, loosen the three captive screws on the front of the fan assembly, so they disengage from the chassis.
- 3 Using the handle on one end and the edge on the other side, gently pull the fan assembly straight out to disengage the connector.
- 4  **NOTICE:** If the GTR 8000 Expandable Site Subsystem is part of a power efficiency package configuration, the DLN6898A fan module must be used. If the replacement fan module was converted for single fan operation, make sure to convert it for dual fan operation before installing. The DLN6898A fan module can also be used in a non power efficiency package configuration.

Convert for dual fan operation:

- a Lift each connector end out of the pockets of the rubber retainer.
 - b Connect the connector ends together.
 - c Place the connector harness back into the rubber retainer.
- 5 Using the guide pins and the connector on the back of the new fan assembly, push the new fan assembly into place until it feels secure.
 - 6 Using a T20 bit, tighten the three captive screws. Torque to 17 ± 2 in-lb.

- 7 Verify that the fan assembly is operating properly, and the fan Alarm LED is off. You can also use software tools, such as Unified Event Manager or Configuration/Service Software (CSS) to verify the status of the equipment.

Replacing a Power Supply



WARNING: The power supply module contains dangerous voltages which can cause electrical shock to personnel or damage to equipment.



IMPORTANT: The MCPN1082 and 01825165W12 power supplies are not compatible in the 900 MHz frequency band.



NOTICE: The power supply output is directly mapped to a Power Amplifier (PA)/transceiver combination. Removal of a power supply results in a loss of the associated transmit channel until the replacement power supply is inserted and turned ON.

Place the channel into Service Mode before replacing the module so that the system does not attribute the loss of channel to a failure. Placing a channel into Service Mode is performed using either the Unified Event Manager (UEM) or the Configuration/Service Software (CSS).

The power supply can be removed without disabling the site controllers. Auxiliary power is available to the site controllers from any other power supply in the cabinet. An AUX DC bus is automatically set up to provide backup power to the site controllers.

Figure 167: Power Supply



G_series_power_supply_A

Procedure:

- 1 Wear an Electrostatic discharge (ESD) wrist strap and connect its cable to a verified good ground.



CAUTION: Wear The ESD strap throughout this procedure to prevent ESD damage to any components.

- 2 Place the base radio using the power supply module being replaced into Service Mode.
 - a Connect to the base radio transceiver module Ethernet service port using CSS. See [Connecting Through an Ethernet Port Link on page 262](#).
 - b From the menu, select **Service** → **Test and Measurement Screen**.
The **Test and Measurement Screen** appears.

c Click **Change to Service Mode**.

d At the confirmation screen, click **OK**.

The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.

3 Push the power rocker switch to Off (O) on the power supply unit.

4 Using a T20 bit, loosen the two captive screws on the front of the power supply to disengage them from the chassis.



WARNING: Let the power supply module cool before performing the following step which exposes surfaces of the module that can be extremely hot.

5 Pull on the metal handle to disengage the power supply from the backplane, and remove it completely from the chassis.

6 Slide the replacement power supply into place, pushing gently until it seats.

7 Using a T20 bit, tighten the two captive screws on the front of the power supply.

8 Turn the power button to On (I), and verify that the power supply is operating properly:

- The power supply Status LED is green.
- The power supply Alarm LED is off.
- The power supply Fan LED is off.
- Confirm proper operation using software tools, such as the UEM, and the **Power Supply Metering Screen** in CSS.

9 Place the base radio into Normal Mode, as follows:

a From the menu, select **Service** → **Test and Measurement Screen**.

The **Test and Measurement Screen** appears.

b Click **Change to Normal Mode**.

c At the confirmation screen, click **OK**.

The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.

Replacing a Power Supply Fan



WARNING: The power supply module contains dangerous voltages which can cause electrical shock to personnel or damage to equipment.




NOTICE: Replacing the power supply fan requires removing the power supply module. The power supply output is directly mapped to a Power Amplifier (PA)/transceiver combination. Removal of a power supply results in a loss of the associated transmit channel until the replacement power supply is inserted and turned ON.

Place the channel into Service Mode before replacing the module so that the system does not attribute the loss of channel to a failure. Placing the channel into Service Mode is performed using either the Unified Event Manager (UEM) or Configuration/Service Software (CSS).

A power supply can be removed without disabling site controllers if the site controllers are cabled to auxiliary power. Auxiliary power is available from any transceiver still connected to a power supply. An AUX DC bus is automatically set up to provide backup power to the site controllers.

Figure 168: Power Supply Fan



GTR8000_PS_Fan_Front1

Procedure:


- 1 Wear an Electrostatic Discharge (ESD) wrist strap and connect its cable to a verified good ground.
 **CAUTION:** Wear the ESD strap throughout this procedure to prevent ESD damage to any components.
- 2 Place the base radio associated with the power supply fan being replaced into Service Mode.
 - a Connect to the device module Ethernet service port using CSS. See [Connecting Through an Ethernet Port Link on page 262](#).
 - b From the menu, select **Service** → **Test and Measurement Screen**.
The **Test and Measurement Screen** appears.
 - c Click **Change to Service Mode**.
 - d At the confirmation screen, click **OK**.The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.
- 3 Set the rocker switch on the front of the power supply to Off (O).
- 4 Using a T20 bit, loosen the two captive screws on the front of the power supply module to disengage them from the chassis.
 **WARNING:** Let the power supply module cool before performing the following step, which exposes surfaces of the module that can be extremely hot.

- 5 Pull on the metal handle to disengage the power supply from the backplane, and remove it completely from the chassis.
- 6 Remove the fan cover from the power supply module:
 - a Using a T15 bit, remove the four screws that connect the cover to the sides of the power supply module.
 - b Slide the cover off (tilting the top edge out and lifting the bottom edge above the power supply handle).
- 7 Disconnect the power cable located above the fan.
- 8 Remove the two screws that secure the fan to the power supply.
- 9 Remove the fan and insert the new fan.
- 10 Secure the fan to the power supply with the two screws removed in step 8.
- 11 Attach the power cable for the fan to the connection on the power supply.
- 12 Replace the fan cover:
 - a Slide the cover on, tilting the bottom edge in, past the power supply handle.
 - b Using a T15 bit, insert and tighten the four screws that connect the cover to the sides of the power supply module.
- 13 Slide the power supply into place, pushing gently until it seats.
- 14 Using a T20 bit, tighten the two captive screws on the front of the power supply module.
- 15 Turn the power button to On (I), and verify that the power supply is operating properly:
 - The power supply Status LED is green.
 - The power supply Alarm LED is off.
 - The power supply Fan LED is off and the fan is operating.
 - Proper operation is confirmed using software tools, such as the UEM, and the **Power Supply Metering Screen** in CSS.
- 16 Place the base radio into Normal Mode, as follows:
 - a From the menu, select **Service** → **Test and Measurement Screen**.
The **Test and Measurement Screen** appears.
 - b Click **Change to Normal Mode**.
 - c At the confirmation screen, click **OK**.The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.


Replacing a Power Amplifier

[Figure 169: Power Amplifier Module on page 380](#) shows the power amplifier FRU module and the captive screws that secure the power amplifier module to the metal card cage. The location of these screws is similar for the GTR 8000 Expandable Site Subsystem, except the module is positioned vertically.

Figure 169: Power Amplifier Module



See [Figure 170: GTR 8000 Expandable Site Subsystem \(repeater shown\) on page 381](#) to help you locate the correct module. The metal card cage is stamped with numbers matching the numbers.

Figure 170: GTR 8000 Expandable Site Subsystem (repeater shown)

A25_expandable_subsystem_config_A

Procedure:

- 1 Wear an electrostatic discharge (ESD) wrist strap and connect its cable to a verified good ground. This strap must be worn throughout this procedure to prevent ESD damage to any components.
- 2 If the power amplifier is not operational, go to [step 5](#).
- 3 Place the base radio associated with the power amplifier module being replaced into Service Mode so the system does not attribute the loss of channel to a failure.
 - a Connect to the transceiver Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
 - b From the menu, select **Service** → **Test and Measurement Screen**.
 - c Click **Change to Service Mode**.
 - d At the confirmation screen, click **OK**.

The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.

- 4 Optional: If you choose to turn off the power, set the rocker switch on the front of the associated power supply to the Off (O) position.

It is not necessary to turn off the power supply for the power amplifier module you are replacing, as the power amplifier modules can be swapped out with the power on.

- 5 Remove the fan assembly to gain access to the power amplifier module. See [Replacing the Fan Assembly on page 374](#).




WARNING: Let the power amplifier module cool before performing the following step, which exposes surfaces of the module that can be extremely hot.



IMPORTANT: The power amplifier module is designed to be swapped out without shutting the power off. However, minimize the amount of time that the fan is removed, so the circuitry that remains powered on does not overheat and shut down.

- 6 Using a T20 bit, loosen the two captive screws on the front of the power amplifier module so they disengage from the chassis.
- 7 Remove the RF output QN connector from the front of the power amplifier module, as follows.
 - a Pull the power amplifier out of the chassis far enough so that the QN (quick-N) RF output connector is accessible.
 - b Disconnect the cable from the power amplifier.

Figure 171: Power Amplifier RF Cable (Front)



GTR8000_XCVR_RF Cable_On

- 8 Using the handle, gently pull the power amplifier module straight out, along the guides on which it sits.
- 9 Reconnect the RF cable to the RF output QN connector on the front of the power amplifier module, as follows:
 - a While holding the RF cable, slide in the replacement power amplifier module along the guiding rails until the RF cable connector can reach the RF connection on the front of the module.
 - b Push the RF cables connector on to the modules connector until it snaps securely into place.
- 10 Slide in the replacement power amplifier module into the correct card cage until it engages with the backplane. A slight push may be needed to engage the module.



IMPORTANT: If the power amplifier module stops well before it is engaged, it is in an incorrect position. Either it is in the wrong slot or it is rotated 180 °.

- 11 Using a T20 bit, secure the power amplifier module to the chassis with the two captive screws on the front of the module.
- 12 Reinstall the fan assembly. See [Replacing the Fan Assembly on page 374](#).
- 13 Optional: If you chose to turn off the power, set the rocker switch on the front of the associated power supply to the On (I) position.

14 Verify that the power amplifier is operating properly.

- The power amplifier Status and Transmit LEDs are green.
- The Alarm LED is off.
- Proper operation is confirmed using software tools, such as Unified Event Manager, and the Transmitter Metering Screen in Configuration/Service Software (CSS).

15 Place the base radio into Normal Mode, as follows:

- a** From the menu, select **Service** → **Test and Measurement Screen**.
- b** Click **Change to Normal Mode**.
- c** At the confirmation screen, click **OK**.

The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.


Replacing a GTR 8000 Expandable Site Subsystem Backplane

The backplane is the circuit board at the rear of the GTR 8000 Expandable Site Subsystem which connects the base radios and site controller modules. [Figure 172: GTR 8000 Expandable Site Subsystem Backplane Diagram on page 384](#) shows the metal cover and screws that must be removed to access the backplane.



NOTICE: Powering down the GTR 8000 Expandable Site Subsystem causes any affiliated subscribers to relocate to another channel at the site or another channel at an adjacent site. Place the channels into Service Mode before powering down, so that the system does not attribute the loss of channel to a failure.

Figure 172: GTR 8000 Expandable Site Subsystem Backplane Diagram



HPD_GTR8000_XS_Main_Backplane




IMPORTANT: Contact Motorola before and after performing this procedure to obtain instructions for essential additional steps. See [Motorola Solution Support Center on page 344](#).



NOTICE: The procedure assumes the following service access clearances:

- At least 2 ft access at the front of the cabinet or rack
- At least 6 in. at the rear of the cabinet or rack

See [Figure 173: GTR 8000 Expandable Site Subsystem \(repeater shown\) on page 385](#) to help you label each module as you remove it from the backplane. The metal card cage is engraved with numbers matching the numbers.

Figure 173: GTR 8000 Expandable Site Subsystem (repeater shown)

A25_expandable_subsystem_config_A


Procedure:

- 1 Wear an electrostatic discharge (ESD) strap and connect its cable to a verified good ground. This strap must be worn throughout this procedure to prevent ESD damage to any components.
- 2 If the GTR 8000 Expandable Site Subsystem is not operational, go to [step 6](#).
- 3 Place all channels that are using the backplane being replaced into Service Mode, as follows:
 - a Connect to the transceiver Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
 - b From the menu, select **Service** → **Test Measurement Screen**.
The **Test and Measurement Screen** appears.
 - c Click **Change to Service Mode**.
 - d At the confirmation screen, click **OK**.

The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.
- 4 Disable the RDM modules, if installed in the cabinet/rack as follows:
 - a Connect to the RDM Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).

- b** From the menu, select **Service** → **Status Panel Screen**.
The **Status Panel Screens** window appears.
 - c** Select the **Reference Distribution Module** tab.
 - d** From the **User Requested State** list box, select **User Disabled**.
The RDM resets, after approximately two minutes, it is disabled. If this is the active RDM, control switches over to the standby RDM.
 - e** Repeat steps a through d for the other RDM module.
- 5** Disable the site controller modules, if installed in the cabinet/rack as follows:
- a** Connect to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
 - b** From the menu, select **Service** → **Status Panel Screen**.
The **Status Panel Screens** window appears.
 - c** Select the **Site Controller** tab.
 - d** From the **User Requested Site Controller State** list box, select **User Disabled**.
The site controller module resets, after approximately two minutes, it is disabled. If this is the active site controller module, control switches over to the standby site controller module.
 - e** Repeat steps a through d for the other site controller module.
- 6** Push the power rocker switch to Off (O) on each power supply unit.
- 7** Remove the fan assembly units to gain access to the transceiver, power amplifier, site controller, XHubs, or RDMs. See [Replacing the Fan Assembly on page 374](#).
- 8** Using a T20 bit, loosen the two captive screws on the front of the power amplifier modules so they disengage from the card cage.
- 9** Remove the RF output QN connector from the front of the power amplifier modules, as follows.
- a** Pull the power amplifier out of the card cage far enough so the QN (quick-N) RF output connector is accessible.
 - b** Disconnect the cable from the power amplifier.

Figure 174: Power Amplifier RF Cable (Front)



GTR8000_XCVR_RFCable_On

- 10 Using the handle, gently pull the power amplifier modules straight out, along the guides on which it sits, to completely remove it from the card cage.
- 11 Label each power amplifier module with the letters PA and the number engraved in the metal card cage above the slot from which you are removing the module.
- 12 Label and disconnect all cabling on the front of each transceiver, site controller, XHub, or RDM modules.
- 13 Remove each transceiver, site controller, XHub, or RDM modules from the card cage as follows:
 - a Using a T20 bit, loosen the two captive screws on the front of each module, so that they disengage from the card cage.
 - b Using their handles, gently pull the modules until they disengage from the backplane.
 - c Label each module with letters (XCVR, SC, XHUB, or RDM) and the number engraved in the metal card cage above the slot from which you are removing the module.
 - d Slide the modules out of the card cage.
- 14 Remove the fan multi-pin connectors from their ports on the backplane, working from the front of the card cage, with the backplane still secured to the card cage by squeezing the sides of the connector and tilting the connector to one side while disengage it from the backplane.
- 15 Label, then disconnect all cables from the rear of the main GTR 8000 Expandable Site Subsystem card cage. The cables do **not** need disconnecting from the power supply card cage.
- 16 Remove the four corner screws and the thirteen additional screws that secure the metal backplane cover and the backplane circuit board to the rear of the card cage.
- 17 Remove the metal backplane cover and the backplane circuit board.
- 18 Place the new backplane circuit board in the same location and orientation as the one that you removed.
- 19 Secure the new backplane circuit board and the backplane cover to the rear of the card cage with the screws previously removed.
- 20 Connect the fan cables multi-pin connectors to the new backplane, working from the front of the card cage, with the backplane secured to the card cage.
- 21 Reconnect the RF cable to the RF output QN connector on the front of each power amplifier module, as follows:
 - a While holding the RF cable, slide in the power amplifier module into the card cage slot engraved with the letters PA and along the guiding rails until the RF cable connector reaches the RF connection on the front of the module.
 - b Push the RF cables connector on to the modules connector until it snaps securely into place.
- 22 Slide in each power amplifier module until it engages with the backplane. A slight push may be needed to engage the module.

 **IMPORTANT:** If the power amplifier module stops well before it is engaged, it is in an incorrect position. Either it is in the wrong slot or it is rotated 180 °.
- 23 Slide each transceiver, site controller, XHub, or RDM modules into the card cage slot engraved with the appropriate number of the module you are reinstalling. A slight push may be needed to engage the modules.


 **IMPORTANT:** If the module stops well before it is engaged, it is in an incorrect position. Either it is in the wrong slot or it is rotated 180 °.
- 24 Using a T20 bit, secure all modules to the card cage with the two captive screws on the front of each module.
- 25 Reinstall the fan assembly units. See [Replacing the Fan Assembly on page 374](#).

- 26 Reconnect all cables to the card cage backplane.
- 27 Reconnect all cables to the transceiver, site controller, XHub, or RDM modules.
- 28 Set the power supply rocker switches to On (1).
- 29 Enable the site controller modules, if installed in the cabinet/rack as follows:
 - a Connect to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
 - b From the menu, select **Service** → **Service Panel Screen**.
The **Status Panel Screens** window appears.
 - c Select the **Site Controller** tab.
 - d From the **User Requested Site Controller State** list box, select **Enabled**.
The site controller module is enabled after approximately two minutes.
 - e Repeat steps a through d for the other site controller module.
- 30 Enable the RDM modules, if installed in the cabinet/rack as follows:
 - a Connect to the RDM's Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
 - b From the menu, select **Service** → **Status Panel Screen**.
The **Status Panel Screens** window appears.
 - c Select the **Reference Distribution** tab.
 - d From the **User Requested State** list box, select **Enabled**.
The RDM is enabled.
 - e Repeat steps a through d for the other RDM module.
- 31 Place each base radio into Normal Mode, as follows:
 - a Connect to the transceiver Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
 - b From the menu, select **Service** → **Test Measurement Screen**.
The **Test and Measurement Screen** appears.
 - c Click **Change to Normal Mode**.
 - d At the confirmation screen, click **OK**.
The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.
- 32 Verify that the LEDs indicate the modules you removed and reinstalled are operational.
 - The Status LEDs are green.
 - The Alarm LEDs are off.
 - The power supply Fan LED is off.
- 33 Verify that the GTR 8000 Expandable Site Subsystem is operating properly using software tools, such as Unified Event Manager, and Configuration/Service Software (CSS).
- 34 Reconfigure the Security Settings into the Backplane. See [Setting the Serial Security Services in CSS on page 261](#).

Replacing a GTR 8000 Expandable Site Subsystem Power Supply Backplane

The power supply backplane is the circuit board at the rear of the GTR 8000 Expandable Site Subsystem which connects the power supplies. The battery temperature sensor cable also connects to this backplane. [Figure 175: GTR 8000 Expandable Site Subsystem Power Supply Backplane Diagram on page 389](#) shows the metal cover that must be removed to access the backplane, and the ports for cables that must be disconnected to remove the cover.

Figure 175: GTR 8000 Expandable Site Subsystem Power Supply Backplane Diagram



HPD_GTR8000_XS_PS_backplane

Prerequisites: The procedure assumes the following service access clearances:

- At least 2 ft access at the rear of the cabinet or rack, or
- At least 2 ft access on one side of the cabinet or rack, and at least 6 inches at the rear of the cabinet or rack

Procedure:

- 1 Wear an electrostatic discharge (ESD) strap and connect its cable to a verified good ground. This strap must be worn throughout this procedure to prevent ESD damage to any components.
- 2 If the GTR 8000 Expandable Site Subsystem is not operational, go to [step 6](#).
- 3 Place each channel using the power supply backplane being replaced into Service Mode so that the system does not attribute the loss of channel to a failure, as follows:
 - a Connect to the transceiver Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
 - b From the menu, select **Service** → **Test Measurement Screen**.
The **Test and Measurement Screen** appears.
 - c Click **Change to Service Mode**.
 - d At the confirmation screen, click **OK**.
The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.
- 4 Disable the RDM modules, if installed in the cabinet/rack as follows:
 - a Connect to the RDM Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).


- b** From the menu, select **Service** → **Status Panel Screen**.
The **Status Panel Screens** window appears.
 - c** Select the **Reference Distribution Module** tab.
 - d** From the **User Requested State** list box, select **User Disabled**.
The RDM resets, after approximately two minutes, it is disabled. If this is the active RDM, control of trunking switches over to the standby RDM.
 - e** Repeat steps a through d for the other RDM module.
- 5** Disable the site controller modules, if installed in the cabinet/rack as follows:
 - a** Connect to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
 - b** From the menu, select **Service** → **Status Panel Screen**.
The **Status Panel Screens** window appears.
 - c** Select the **Site Controller** tab.
 - d** From the **User Requested Site Controller State** list box, select **User Disabled**.
The site controller module resets, after approximately two minutes, it is disabled. If this is the active site controller module, control switches over to the standby site controller module.
 - e** Repeat steps a through d for the other site controller module.
- 6** Push the power rocker switch to Off (O) on each power supply unit.
- 7** Disengage each power supply from the backplane as follows:
 - a** Using a T20 bit, loosen the two captive screws on the front of the power supply, so they disengage from the chassis.
 **WARNING:** Let the power supply module cool before performing the following step, which exposes surfaces of the module that can be extremely hot.
 - b** Pull on the metal handle to disengage the power supply from the backplane.
- 8** Label, then disconnect all cables from the rear of the power supply card cage.
- 9** Remove the screws that secure the metal backplane cover and the backplane circuit board to the rear of the power supply card cage.
- 10** Remove the metal backplane cover and the backplane circuit board.
- 11** Place the new backplane circuit board in the same location and orientation as the one that you removed.
- 12** Secure the new backplane circuit board and the backplane cover to the rear of the power supply card cage with the screws previously removed.
- 13** Slide each power supply into place, pushing gently until it engages with the backplane.
- 14** Tighten the two captive screws on the front of each power supply.
- 15** Reconnect all cables to the power supply card cage backplane.
- 16** Set the power supply rocker switches to On (I), and verify that each power supply is operating properly.
 - The power supply Status LED is green.
 - The power supply Alarm LED is off.
 - The power supply Fan LED is off.
- 17** Enable the site controller modules, if installed in the cabinet/rack as follows:

- a** Connect to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
 - b** From the menu, select **Service** → **Service Panel Screen**.
The **Status Panel Screens** window appears.
 - c** Select the **Site Controller** tab.
 - d** From the **User Requested Site Controller State** list box, select **Enabled**.
The site controller module is enabled after approximately two minutes.
 - e** Repeat steps a through d for the other site controller module.
- 18** Enable the RDM modules, if installed in the cabinet/rack as follows:
 - a** Connect to the RDM Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
 - b** From the menu, select **Service** → **Status Panel Screen**.
The **Status Panel Screens** window appears.
 - c** Select the **Reference Distribution** tab.
 - d** From the **User Requested State** list box, select **Enabled**.
The RDM is enabled.
 - e** Repeat steps a through d for the other RDM module.
- 19** Place each base radio into Normal Mode, as follows:
 - a** Connect to the transceiver Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
 - b** From the menu, select **Service** → **Test Measurement Screen**.
The **Test and Measurement Screen** appears.
 - c** Click **Change to Normal Mode**.
 - d** At the confirmation screen, click **OK**.
The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.
- 20** Verify that the GTR 8000 Expandable Site Subsystem is operating properly using software tools, such as:
 - Configuration/Service Software (CSS)
 - Unified Event Manager

Replacing a Subpanel on the GTR 8000 Expandable Site Subsystem Junction Panel

The subpanels on the GTR 8000 Expandable Site Subsystem junction panel provide the locations for all the connections to external devices.

Figure 176: Example of a GTR 8000 Expandable Site Subsystem Subpanels



GTR8000_panel



WARNING: Shock hazard. The GTR 8000 Expandable Site Subsystem contains dangerous voltages, which can cause electrical shock or damage to equipment. Remove the AC and DC sources when servicing the junction panel. Also, for a GTR 8000 Expandable Site Subsystem, shut down any other expansion cabinet/racks that are connected to it. Electrical installation work shall be carried out in accordance with the current edition of the NFPA 70 and local building codes. Where required, only a qualified and licensed electrician shall be used for all electrical installations.

Procedure:

- 1 Wear an electrostatic discharge (ESD) strap and connect its cable to a verified good ground. This strap must be worn throughout this procedure to prevent ESD damage to any components.
- 2 Connect to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
- 3  **NOTICE:** Powering down the GTR 8000 Expandable Site Subsystem causes any affiliated subscribers to relocate to another channel at an adjacent site. Disable the site before powering down, so that the system does not attribute the loss of channel to a failure.

To disable the site, perform one of the following actions:

If...	Then...
If the site controllers are in the cabinet/rack,	perform the following actions: a From the menu, select Service → Status Panel Screen . b In the Status Panel Screens window, select the Site Info tab. c In the User Requested Site State list box, select Site OFF .
If the site controllers are at the prime site,	perform the following actions: a From the menu, select Service → Status Panel Screen . b In the Status Panel Screens window, select the Subsite tab.

If...	Then...
	<p>c Click in the User Requested Site State cell of the subsite to be disabled and choose User Ignore.</p>

The site is disabled.

- 4 Push the power rocker switch to Off (O) on each power supply unit.
- 5 Set all the AC supply breakers to the OFF position and open up the DC battery disconnects to power down the entire GTR 8000 Expandable Site Subsystem. Also shut down any other expansion cabinets/racks that are connected to the GTR 8000 Expandable Site Subsystem.
- 6 Label all cables going into the top-side and bottom-side of the junction panel for the subpanel being removed.
- 7 Disconnect all cables from the top-side of the subpanel. Cables disconnect with twist-lock features, threaded housings, snap tabs, or screw locks.
- 8 Disconnect all cables from the bottom-side of the subpanel. For cables connected directly to the subpanel, this can typically be accomplished by removing fasteners or jam nuts. Some cables, such as Telco networking cables, plug into a panel mount coupler.
- 9 Using a T20 bit, remove the two M4 fasteners that secure the subpanel to the junction panel frame and remove the old subpanel.
- 10 Place the new subpanel into the opening.
- 11 Using a T20 bit, secure the subpanel with the two M4 fasteners. Torque to 15 in.-lbs.
- 12 Reconnect all cables to the top- and bottom-side of the subpanel.
- 13 For configuration changes, review the upgrade instructions for required cable connections. Some subpanels are not used in all configurations.
 - a Remove cables in the rack no longer required. One or more fan assembly units may be removed to access all connections. See [Replacing the Fan Assembly on page 374](#).
 - b Install any required new cabling to the rack.
 - c Install any new site level cabling from external devices to the junction panel.
 - d Label the ends of any new cabling that connect to the subpanels for reference.
 - e Remove the plastic label knockouts of the new cables being installed. Leave all unused knockouts in place to prevent debris from entering the cabinet/rack.
 - f Install new Telco panel mount couplers, if required.
 - g Install all rack equipment cables to the subpanel and install each cable.
 - h Reconnect reused and new site cabling going to the cabinet/rack to the appropriate connections.
 - i Reinstall any fan assembly units. See [Replacing the Fan Assembly on page 374](#).
- 14 Set all the AC supply breakers to the ON position and connect the DC battery to power up the GTR 8000 Expandable Site Subsystem. Also restore power to any other expansion cabinets/racks that are connected to the GTR 8000 Expandable Site Subsystem.
- 15 Set the power supply rocker switches to On (I).
- 16 Connect to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
- 17 To enable the site, perform one of the following actions:

If...	Then...
If the site controllers are in the cabinet/rack,	perform the following actions: a From the menu, select Service → Status Panel Screen . b In the Status Panel Screens window, select the Site Info tab. c In the User Requested Site State list box, select Wide Trunking .
If the site controllers are at the prime site,	perform the following actions: a From the menu, select Service → Status Panel Screen . b In the Status Panel Screens window, select the Subsite tab. c Click in the User Requested Site State cell of the subsite to be enabled and choose Enabled .

The site is enabled.


- 18 Verify that the GTR 8000 Expandable Site Subsystem is operating properly using software tools, such as Unified Event Manager, and Configuration/Service Software (CSS).

AC/DC Power Distribution Module Replacement


The power distribution module in the GTR 8000 Expandable Site Subsystem includes all AC and DC output cables that power the GTR 8000 Expandable Site Subsystem. This cabling is in place when you receive the system.

[Figure 177: AC/DC Distribution Module for the GTR 8000 Expandable Site Subsystem \(Cabinet Version, Side View\) on page 394](#) shows the location of the power distribution module output cables, and the metal plate that secures the power distribution module to the junction panel in the cabinet version of the GTR 8000 Expandable Site Subsystem.

Figure 177: AC/DC Distribution Module for the GTR 8000 Expandable Site Subsystem (Cabinet Version, Side View)




[Figure 178: AC/DC Power Distribution Module \(Access Panel Removed\) on page 395](#) shows the power distribution module with the terminal block access panel removed. The power distribution module is wired for six AC outputs, not three as shown.

Figure 178: AC/DC Power Distribution Module (Access Panel Removed)

GTR8000_JP_PowerBox_ACPanel_Off_A

See [Figure 179: Power Distribution Module- AC Distribution Block Diagram](#) on page 395 for the correct wiring and for the terminal block connections. The figure also shows the AC distribution block of the power distribution module. In the diagram:

- L indicates Line or Hot AC power feed.
- N indicates Neutral AC power feed.
- Input cable ground wires should be terminated to the ground bus bar.

Figure 179: Power Distribution Module- AC Distribution Block Diagram

GTR8000_JP_PowerBox_AC_DistrBlock

See [Replacing the AC/DC Power Distribution Module](#) on page 396 for replacement procedures.

Replacing the AC/DC Power Distribution Module



WARNING: Shock hazard. The GTR 8000 Expandable Site Subsystem contains dangerous voltages, which can cause electrical shock or damage to equipment. Remove the AC and DC sources when servicing the power distribution module. Also, for a GTR 8000 Expandable Site Subsystem, shut down any other expansion cabinet/racks that are connected to it. Electrical installation work shall be carried out in accordance with the current edition of the NFPA 70 and local building codes. Where required, only a qualified and licensed electrician shall be used for all electrical installations.



CAUTION: The power distribution module and its cables are heavy. To avoid injury and damage to equipment, have another person help lift and support the equipment when installing or removing the distribution module.

Prerequisites:

The procedure assumes the following service access clearances:

- At least 2 ft access at the rear of the cabinet or rack
- At least 2 ft access on both sides of the cabinet or rack

When and where to use:

Follow this procedure to replace the power distribution module, including its AC and DC output cables.

Procedure:

- 1 Wear an electrostatic discharge (ESD) wrist strap and connect its cable to a verified good ground. This strap must be worn throughout this procedure to prevent ESD damage to any components.
- 2 Connect to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
- 3  **NOTICE:** Powering down the GTR 8000 Expandable Site Subsystem causes any affiliated subscribers to relocate to another channel at an adjacent site. Disable the site before powering down, so the system does not attribute the loss of channel to a failure.

To disable the site, perform one of the following actions:

If...	Then...
If the site controllers are in the cabinet/rack,	perform the following actions: <ol style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Site Info tab. c In the User Requested Site State list box, select Site OFF.
If the site controllers are at the prime site,	perform the following actions: <ol style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Subsite tab. c Click in the User Requested Site State cell of the subsite to be disabled and choose User Ignore.

The site is disabled.

- 4 Push the power rocker switch to Off (O) on each power supply unit.
- 5 Set all the AC supply breakers to the OFF position and open up the DC battery disconnects to power down the entire GTR 8000 Expandable Site Subsystem. Also shut down any other expansion cabinets/racks that are connected to the GTR 8000 Expandable Site Subsystem.

- 6 Label and disconnect all input AC and DC power cables from the power distribution module.
 - 7 Ensure that all power cables in the GTR 8000 Expandable Site Subsystem are free to be removed.
 - a Disconnect all six AC and six DC junction panel power cables that feed from the power supply backplane.
 - b If the cables are tied to the rack, remove the ties.
 - 8 Disengage the power distribution module from the junction panel as follows:

For the rack version of the GTR 8000 Expandable Site Subsystem:

 - Using a T30 bit, remove the two screws on each side of the power distribution module.

For the cabinet version of the GTR 8000 Expandable Site Subsystem:

 - a Using a T30 bit, remove the screw on each side of the power distribution module that secures it to a metal plate next to the junction panel.
 - b Remove the side panel of the cabinet to reach the bolts holding the eyenuts that are on each side of the power distribution module. This prevents them from rotating as the eyenuts are removed, and to prevent them from dropping down into the cabinet.
 - c Remove the eyenuts on each side of the power distribution module that secures the metal plate to the cabinet.
 - d Move the plate back to free the power distribution module from the clips on the metal plate.
 - 9 Lift the power distribution module to remove it, and feed its power cables to remove them from the rack or cabinet.
 - 10 Place the new power distribution module next to the junction panel in the same position and orientation as the module you removed.
 - 11 Secure the power distribution module to the junction panel as follows:

For the rack version of the GTR 8000 Expandable Site Subsystem:

 - Using a T30 bit, secure the two screws on each side of the power distribution module to the junction panel.

For the cabinet version of the GTR 8000 Expandable Site Subsystem:

 - a Slide the metal plate toward the power distribution module until the module is captured under the clips on the metal plate.
 - b Using a T30 bit, secure the screw on each side of the power distribution module to the metal plate.
 - c Secure the metal plate to the cabinet on each side of the power distribution module, using the eyenuts removed previously.
-  **IMPORTANT:** Thoroughly review the information in this documentation regarding the proper torque for tightening eyenuts, to prevent accidents or injury when using them to lift the cabinet. See [Lifting Equipment Racks Vertically on page 135](#).
- 12 Connect the new power distribution module power cables to the appropriate backplane input ports. For backplane connection information, see [Backplanes and Card Cages on page 115](#).
 - 13 Reconnect all input AC and DC input power cables to the appropriate ports in the power distribution module. See [Figure 179: Power Distribution Module- AC Distribution Block Diagram on page 395](#) for the terminal block connections.
 - 14 Secure the cables to the rack with cable ties.
 - 15 Set all the AC supply breakers to the ON position and connect the DC battery to power up the GTR 8000 Expandable Site Subsystem. Also restore power to any other expansion cabinets/ racks that are connected to the GTR 8000 Expandable Site Subsystem.

- 16 Set the power supply rocker switches to On (I).
- 17 Connect to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
- 18 To enable the site, perform one of the following actions:

If...	Then...
If the site controllers are in the cabinet/rack,	perform the following actions: <ol style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Site Info tab. c In the User Requested Site State list box, select Wide Trunking.
If the site controllers are at the prime site,	perform the following actions: <ol style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Subsite tab. c Click in the User Requested Site State cell of the subsite to be enabled and choose Enabled.


The site is enabled.

- 19 Verify that the GTR 8000 Expandable Site Subsystem is operating properly using software tools, including:
 - Unified Event Manager
 - Power Supply Metering Screen in Configuration/Service Software (CSS)


Replacing Filters/Preselectors (700/800/900 MHz)

For the GTR 8000 Expandable Site Subsystem, receive filters (preselectors) and transmit filters can be replaced individually, or the modules may already be secured to a filter tray.

Figure 180: Site Preselector Filter (700/800 MHz)



GTR8000_RFDS_Preselector_Front_2

Figure 181: Transmit Filter (700/800/900 MHz)

GTR8000_RFDS_XS_TXFilter_Front1



WARNING: Shock hazard. The GTR 8000 Expandable Site Subsystem contains dangerous voltages, which can cause severe electrical shock or damage to equipment. Set the rocker switches on the front of the associated power supplies to the Off (O) position before servicing this component in the GTR 8000 Expandable Site Subsystem. Also, shut down any external base radios connected to the system.



IMPORTANT: When using the following procedure to replace or remove the Transmit filter, the warning applies and the site must be powered down before starting the replacement procedure if the entire site is connected to the Transmit filter being removed. Powering down the site causes any affiliated subscribers to relocate to another channel at an adjacent site. Disable the site before powering down so the system does not attribute the loss of channel to a failure. The site can be disabled using Unified Event Manager or the Configuration/Service Software (CSS).

If replacing one preselector filter, it can be replaced without shutting the power down.

When and where to use: The following procedure includes instructions for replacing a filter tray or replacing individual filters on the tray.

Procedure:

- 1 Wear an electrostatic discharge (ESD) strap and connect its cable to a verified good ground. This strap must be worn throughout this procedure to prevent ESD damage to any components.
- 2 Connect to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
- 3  **NOTICE:** Powering down the GTR 8000 Expandable Site Subsystem causes any affiliated subscribers to relocate to another channel at an adjacent site. It is recommended to disable the site before powering down, so the system does not attribute the loss of channel to a failure.

To disable the site, perform one of the following actions:

If...	Then...
If the site controllers are in the cabinet/rack,	perform the following actions: <ol style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Site Info tab. c In the User Requested Site State list box, select Site OFF.

If...	Then...
If the site controllers are at the prime site,	<p>perform the following actions:</p> <ul style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Subsite tab. c Click in the User Requested Site State cell of the subsite to be disabled and choose User Ignore.

The site is disabled.

- 4 Set the rocker switches on the front of the power supplies to the Off (O) position to power down the entire system. For the GTR 8000 Expandable Site Subsystem, power down any external base radios connected to the system.
- 5 To remove the filter or filter tray from the rack, perform one of the following actions:

If...	Then...
If you are replacing an individual filter,	<p>perform the following actions:</p> <ul style="list-style-type: none"> a For a tray that combines receive and transmit filters, label and disconnect the RF input, RF output, ground, and Power Monitor Unit (PMU) cables from the front of the transmit filter. b For a preselector, label and disconnect the RF input, RF output, and ground cables from the front of the filter. c Remove the T20 screws that secure the filter to the tray. d Remove the filter from the tray. e Place the new filter in the tray in the same location and orientation as the filter removed. f Secure the new filter to the existing tray using the T20 screws previously removed. g For a preselector, reconnect the RF input, RF output, and ground cables to the filter. h For a tray that combines receive and transmit filters, reconnect the RF input, RF output, ground, and Power Monitor Unit (PMU) cables to the transmit filter.
If you are replacing the filter and tray,	<p>perform the following actions:</p> <ul style="list-style-type: none"> a For a tray that combines receive and transmit filters, label and disconnect the RF input, RF output, ground, and Power Monitor Unit (PMU) cables from the front of the transmit filter. b For a preselector, label and disconnect the RF input, RF output, and ground cables from the front of the filter. c Using a T30 bit, remove the two screws which secure the filter tray to the rack. d Slide the tray out the front of the rack. e Slide the new filter and tray into the appropriate location through the front of the rack. f Secure the slide rail to the rack using the two screws which were previously removed.

If...	Then...
	<p>g For a preselector, reconnect the RF input, RF output, and ground cables to the filter.</p> <p>h For a tray that combines receive and transmit filters, reconnect the RF input, RF output, ground, and Power Monitor Unit (PMU) cables to the transmit filter.</p>

- 6 Set the rocker switches on the front of the power supplies to the On (I) position, to power up the system. Also, power up any external base radios that were previously powered down.
- 7 Connect to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
- 8 To enable the site, perform one of the following actions:


If...	Then...
If the site controllers are in the cabinet/rack,	<p>perform the following actions:</p> <p>a From the menu, select Service → Status Panel Screen.</p> <p>b In the Status Panel Screens window, select the Site Info tab.</p> <p>c In the User Requested Site State list box, select Wide Trunking.</p>
If the site controllers are at the prime site,	<p>perform the following actions:</p> <p>a From the menu, select Service → Status Panel Screen.</p> <p>b In the Status Panel Screens window, select the Subsite tab.</p> <p>c Click in the User Requested Site State cell of the subsite to be enabled and choose Enabled.</p>

The site is enabled.

- 9 Verify that the GTR 8000 Expandable Site Subsystem is operating properly using fault management software, including:
 - Unified Event Manager
 - Transmitter Metering Screen in Configuration/Service Software (CSS)

Replacing a Site Preselector (UHF, 455–512 MHz)

Figure 182: Site Preselector Filter (UHF)



GTR8000_Site_Preselector_UHF




IMPORTANT: You can replace a site preselector without shutting the power down.

Procedure:

- 1 Wear an electrostatic discharge (ESD) strap and connect its cable to a verified good ground. This strap must be worn throughout this procedure to prevent ESD damage to any components.
- 2 Remove the site preselector from the rack, as follows:
 - a Label and disconnect the left and right QMA cables from the front of the site preselector
 - b Remove the four screws securing the site preselector and 2RU cable guide to the extension bracket using a T20 bit.
 - c Disconnect the ground wire.
- 3 Install the site preselector to the extension bracket, as follows:
 - a Secure the site preselector and 2RU cable guide to the extension bracket using the four screws previously removed.
 - b Reconnect the left and right QMA cables to the site preselector.
 - c Attach the ground wire.
- 4 Verify that the system is operating properly by checking the receiver sensitivity.

Replacing Transmit Filters (UHF, 450–509 MHz)

Figure 183: GTR 8000 Transmit Filter (UHF, 450–509 MHz)



WARNING: Shock hazard. The GTR 8000 Expandable Site Subsystem contains dangerous voltages which can cause severe electrical shock or damage to equipment. Set the rocker switches on the front of the associated power supplies to the Off (O) position before servicing this component.



IMPORTANT: When using this procedure to replace or remove the transmit filter, the warning applies and the site must be powered down before starting the replacement procedure if the entire site is connected to the Transmit filter being removed. Powering down the site causes any affiliated subscribers to relocate to another channel at an adjacent site. Disable the site before powering down so the system does not attribute the loss of channel to a failure. The site can be disabled using Unified Event Manager or the Configuration/Service Software (CSS).

Procedure:

- 1 Wear an electrostatic discharge (ESD) wrist strap and connect its cable to a verified good ground. This strap must be worn throughout this procedure to prevent ESD damage to any components.
- 2 Connect to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
- 3  **NOTICE:** Powering down the GTR 8000 Expandable Site Subsystem causes any affiliated subscribers to relocate to another channel at an adjacent site. It is recommended to disable the site before powering down so the system does not attribute the loss of channel to a failure.

To disable the site, perform one of the following actions:

If...	Then...
If the site controllers are in the cabinet/rack,	perform the following actions: <ol style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Site Info tab. c In the User Requested Site State list box, select Site OFF.
If the site controllers are at the prime site,	perform the following actions: <ol style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Subsite tab. c Click in the User Requested Site State cell of the subsite to be disabled and choose User Ignore.

The site is disabled.

- 4 Set the rocker switches on the front of the power supplies to the OFF (O) position.
- 5 Remove the Tx filter from the rack, as follows:
 - a Label and disconnect the Tx input, antenna output, and ground cables from the transmit filter.
 - b Remove the four screws securing the Tx filter to the flange of the transceiver using T20 bit.
- 6 Install the new Tx filter to the rack, as follows:
 - a Secure the slide rail to the transceiver flange using the four screws previously removed.
 - b Reconnect the Tx input, Antenna output, and ground cables to the transmit filter.
- 7 Set the rocker switches on the front of the power supplies to the ON (I) position.
- 8 Connect to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
- 9 To enable the site, perform one of the following actions:

If...	Then...
If the site controllers are in the cabinet/rack,	perform the following actions: a From the menu, select Service → Status Panel Screen . b In the Status Panel Screens window, select the Site Info tab. c In the User Requested Site State list box, select Wide Trunking .
If the site controllers are at the prime site,	perform the following actions: a From the menu, select Service → Status Panel Screen . b In the Status Panel Screens window, select the Subsite tab. c Click in the User Requested Site State cell of the subsite to be enabled and choose Enabled .


The site is enabled.

- 10 Verify that the system is operating properly by checking the output power.

Site RMC/LNA Module or Tray Replacement

Each Receive Multicoupler/Low Noise Amplifier (RMC/LNA) module is a field replaceable unit (FRU). For an HPD GTR 8000 Expandable Site Subsystems, two Site RMCs/LNAs are included if the CA00862AA option was purchased with the system. For GTR 8000 Expandable Site Subsystems with TDMA dual diversity, two Site RMCs/LNAs are included if the CA01943AA option was purchased. In [Figure 184: Site RMC/LNA Modules in GTR 8000 Expandable Site Subsystem for HPD or TDMA on page 405](#), the Site RMC FRU modules are shown for HPD or TDMA with dual diversity site.


Figure 184: Site RMC/LNA Modules in GTR 8000 Expandable Site Subsystem for HPD or TDMA



HPD_expandable_subsystem_config_A

In [Figure 185: Site RMC/LNA Modules in GTR 8000 Expandable Site Subsystem for Repeater Site on page 406](#), the Site RMC FRU modules are shown for a repeater site.


Figure 185: Site RMC/LNA Modules in GTR 8000 Expandable Site Subsystem for Repeater Site



A25_expandable_subsystem_config_A


Figure 186: Site RMC/LNA Module (Front View) on page 406 shows two Site RMC modules. It identifies the connectors and features on the Site RMC module on the left.

Figure 186: Site RMC/LNA Module (Front View)



GTR8000_RFDS_RMC_Site_Front1

In addition, the tray with the backplane that connects the Site RMC modules is a FRU.

Figure 187: GTR 8000 Site RMC Tray (Rear View)

For replacement procedures see, [Replacing a Site RMC/LNA Module or Tray on page 407](#).

Replacing a Site RMC/LNA Module or Tray



NOTICE: The RMC/LNA modules and backplane connections are designed so the RMC/LNA modules can be swapped out without shutting the power down. The GTR 8000 Expandable Site Subsystem is designed with dual receive paths, so it may be possible to replace one RMC/LNA module without losing channels. However, system performance may be degraded. If the RMC tray is being replaced, both modules must be removed, resulting in the loss of channels. Place the channels in Service Mode before replacing the tray, so the system does not attribute the loss of channel to a failure. Placing a channel in Service Mode is performed using Unified Event Manager or the Configuration/Service Software (CSS).

When and where to use: This procedure provides instructions for replacing an individual Site RMC or a Site RMC tray.

Procedure:

- 1 Wear an electrostatic discharge (ESD) strap and connect its cable to a verified good ground. This strap must be worn throughout this procedure to prevent ESD damage to any components.
- 2 Disable the site **if both** RMC/LNA modules are being removed by connecting to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#). Perform one of the following actions:

If...	Then...
If the site controllers are in the cabinet/rack,	perform the following actions: <ol style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. The appears. b In the Status Panel Screens window, select the Site Info tab. c In the User Requested Site State list box, select Site OFF.
If the site controllers are at the prime site,	perform the following actions: <ol style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Subsite tab. c Click in the User Requested Site State cell of the subsite to be disabled and choose User Ignore.

The site is disabled.

- 3 Set the rocker switches on the front of the power supplies to the Off (O) position.
- 4 Perform one of the following actions:

If...	Then...
<p>If you are replacing an individual RMC/LNA module, not the RMC tray,</p>	<p>perform the following actions:</p> <ul style="list-style-type: none"> a Label and disconnect the QMA input connectors from the front of the RMC module. The QMA connectors can be disconnected by hand. b Label and disconnect any cables that are connected to the three center expansion connectors. These BNC connectors can be disconnected by hand. c Using a T20 bit, remove the two captive screws which secure the RMC module to the tray. d Using the handle, gently pull the RMC module straight out, along the guides on which it sits. e Set the DIP switches on the new RMC/LNA module, using the information in RMC Attenuation on page 278. f Install the new RMC/LNA module, by following the substeps in step 5.
<p>If you are replacing the RMC tray, not the RMC/LNA modules,</p>	<p>perform the following actions:</p> <ul style="list-style-type: none"> a Remove both Site RMC/LNA modules, by following the previous substeps for replacing an individual module. b Disconnect the ground cabling from the lugs on the rear of the tray. c Disconnect the RMC cable from the 15-pin connector on the rear of the tray. <ul style="list-style-type: none">  NOTICE: If there is no rear or side access, perform substeps 4 and 5 first, disconnecting the RMC cable as soon as you can reach it as you slide the tray forward. d Using a T30 bit, remove the two captive screws which secure the tray to the rack. e Slide the tray out the front of the rack. f Slide the RMC tray into the appropriate location through the front of the rack. g Secure the slide rail to the rack using the two T30 screws which were previously removed. h Reconnect the RMC cable to the 15-pin connector on the back of the tray. i Reconnect the ground cabling from the lugs on the rear of the tray. j Re-install both RMC/LNA modules, by following step 5. Repeat for each module.

5 Install the RMC/LNA modules as follows:

- a** Slide in the module along the guiding rails.
- b** Secure the module to the existing tray using the two T20 captive screws.

- c Reconnect the input RF cables to the QMA connectors on the front of the RMC module.
 - d Reconnect any cables that were connected to the three center BNC expansion connectors.
- 6 Set the rocker switches on the front of the power supplies to the On (I) position.
- 7 If the site was disabled, enable the site by connecting to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#). Perform one of the following actions:

If...	Then...
If the site controllers are in the cabinet/rack,	perform the following actions: <ul style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Site Info tab. c In the User Requested Site State list box, select Wide Trunking.
If the site controllers are at the prime site,	perform the following actions: <ul style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Subsite tab. c Click in the User Requested Site State cell of the subsite to be enabled and choose Enabled.


The site is enabled.

- 8 Verify that the GTR 8000 Expandable Site Subsystem is operating properly using fault management software, including:
- Unified Event Manager
 - Configuration/Service Software (CSS)
- 9 Verify that the RMC/LNA modules are operating properly.
- The Status LED on the front of each RMC/LNA module should be green.
 - The red Alarm LED on the front of each RMC/LNA module should be off.

Individual Cabinet RMC/LNA Module Replacement

The GTR 8000 Expandable Site Subsystem for HPD or TDMA dual diversity includes two Cabinet Receive Multicoupler/Low Noise Amplifier (RMC/LNA) modules to split the receive path among multiple radios. In [Figure 188: Cabinet RMC/LNA Modules in GTR 8000 Expandable Site Subsystem for HPD or TDMA on page 410](#), the Cabinet RMC (A and B) modules are shown **between the row of power amplifiers (PAs) and the row of XCVR / SC modules**. The GTR 8000 Expandable Site Subsystem for trunked IV&D includes one Cabinet Receive Multicoupler/Low Noise Amplifier module.


Figure 188: Cabinet RMC/LNA Modules in GTR 8000 Expandable Site Subsystem for HPD or TDMA



HPD_expandable_subsystem_config_A


In [Figure 189: Cabinet RMC/LNA Modules in GTR 8000 Expandable Site Subsystem for Repeater Site on page 411](#), the Cabinet RMC module is shown **between the row of power amplifiers (PAs) and the row of XCVR / SC modules**.

Figure 189: Cabinet RMC/LNA Modules in GTR 8000 Expandable Site Subsystem for Repeater Site



A25_expandable_subsystem_config_A

Figure 190: Individual Cabinet RMC/LNA Module (Front View)



GTR8000_RFDS_XS_RMC_Cabinet_Front1

For replacement procedures for an Individual Cabinet RMC/LNA Module, see [Replacing an Individual Cabinet RMC/LNA Module on page 412](#).

Replacing an Individual Cabinet RMC/LNA Module



IMPORTANT: The RMC/LNA modules and backplane connections are designed so the modules can be swapped out without shutting the power down. In addition, the GTR 8000 Expandable Site Subsystem is designed with dual receive paths, so it may be possible to replace one RMC/LNA module without losing the channels. However, system performance may be degraded.

If you choose to power down the subsystem, this causes any affiliated subscribers to relocate to another channel at the site or another channel at an adjacent site. Place the channels in Service Mode before powering down so the system does not attribute the loss of channel to a failure. Placing a channel in Service Mode is performed using Unified Event Manager or the Configuration/Service Software (CSS).

Procedure:

- 1 Wear an electrostatic discharge (ESD) strap and connect its cable to a verified good ground. This strap must be worn throughout this procedure to prevent ESD damage to any components.
- 2 Optional: Place all channels in Service Mode if you choose to shut down the power, as follows:
 - a Connect to the transceiver Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
 - b From the menu, select **Service** → **Test Measurement Screen**.
The **Test and Measurement Screen** appears.
 - c Click **Change to Service Mode**.
 - d At the confirmation screen, click **OK**.
The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.
- 3 Optional: If you choose to shut down the power, set the rocker switches on the front of the power supplies to the Off (O) position.
- 4 Remove the individual Cabinet RMC/LNA module, as follows:
 - a Label and disconnect the QMA input connectors from the front of the RMC/LNA module. The QMA connectors can be disconnected by hand.
 - b Using a T20 bit, remove the two captive screws securing the RMC module to the tray.
 - c Using the handle, gently pull the module straight out, along the guides on which it sits.
- 5 Set the DIP switches on the new Cabinet RMC/LNA module. See [RMC Attenuation on page 278](#).
- 6 Install the replacement Cabinet RMC/LNA module, as follows:
 - a Slide in the module along the guiding rails.
 - b Secure the module to the chassis using the two T20 captive screws.
 - c Reconnect the RF input cables to the QMA connector on the front of the RMC/LNA module.
- 7 Optional: If you chose to shut down the power, set the rocker switches on the front of the power supplies to the On (I) position.
- 8 Optional: If the channels were placed in Service Mode, place the channels in Normal Mode, as follows:

a Connect to the transceiver Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).

b From the menu, select **Service** → **Test Measurement Screen**.

The **Test and Measurement Screen** appears.

c Click **Change to Normal Mode**.

d At the confirmation screen, click **OK**.

The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.

9 Verify that the GTR 8000 Expandable Site Subsystem is operating properly using fault management software, including:

- Unified Event Manager
- Configuration/Service Software (CSS)


10 Verify that the RMC/LNA modules are operating properly.

- The Status LED on the front of each RMC/LNA module should be green.
- The red Alarm LED on the front of each RMC/LNA module should be off.

Individual Pass Through Module Replacement


[Figure 191: Pass Through Module on page 414](#) shows the pass through module **between the row of power amplifiers (PAs) and the row of XCVR / SC modules**.

Figure 191: Pass Through Module



A25_expandable_subsystem_config_passthrough

Figure 192: Individual Pass Through Module (Front View)



RMC_pass_through_module_VHF1

For replacement procedures of the Pass Through Module, see [Replacing an Individual Pass Through Module on page 415](#).

Replacing an Individual Pass Through Module



IMPORTANT: The pass through modules and backplane connections are designed so the modules can be swapped out without shutting the power down.

If you choose to power down the subsystem, this causes any affiliated subscribers to relocate to another channel at the site or another channel at an adjacent site. Place the channels in Service Mode before powering down so the system does not attribute the loss of channel to a failure. Placing a channel in Service Mode is performed using Unified Event Manager or the Configuration/Service Software (CSS).

Procedure:

- 1 Wear an electrostatic discharge (ESD) strap and connect its cable to a verified good ground. This strap must be worn throughout this procedure to prevent ESD damage to any components.
- 2 Optional: Place all channels in Service Mode if you choose to shut down the power, as follows:
 - a Connect to the base radio's Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
 - b From the menu, select **Service** → **Test Measurement Screen**.
The **Test and Measurement Screen** appears.
 - c Click **Change to Service Mode**.
 - d At the confirmations screen, click **OK**.
The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.
- 3 Optional: If you choose to shut down the power, set the rocker switches on the front of the power supplies to the Off (O) position.
- 4 Remove the individual pass through module as follows:
 - a Label and disconnect the BNC connectors from the pass through module. The BNC connectors can be disconnected by hand.
 - b Using a T20 bit, remove the two captive screws which secure the pass through module to the tray.
 - c Using the handle, gently pull the module straight out, along the guides on which it sits.
- 5 Install the replacement pass through module as follows:
 - a Slide in the module along the guiding rails.
 - b Secure the module to the chassis using the two T20 captive screws.
 - c Reconnect the RF input cables to the BNC connectors on the pass through module.
- 6 Optional: If you chose to shut down the power, set the rocker switches on the front of the power supplies to the On (I) position.
- 7 Optional: If the channels were placed in Service Mode, place the channels in Normal Mode, as follows:
 - a Connect to the base radio transceiver Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
 - b From the menu, select **Service** → **Test Measurement Screen**.
The **Test and Measurement Screen** appears.
 - c Click **Change to Normal Mode**.

d At the confirmation screen, click **OK**.


The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.

- 8 Verify that the GTR 8000 Expandable Site Subsystem is operating properly using fault management software, including:
 - Unified Event Manager
 - Configuration/Service Software (CSS)
- 9 Verify that the pass through module is operating properly.
 - The Status LED on the front of the pass through module should be green.
 - The red Alarm LED on the front of the pass through module should be off.

Cavity Combiner (700/800 MHz) Replacement

The RF input cable, built in isolator, and tuning knob are shown for one of the six cavities.

Figure 193: Cavity Combiner (700/800 MHz)




GTR8000_expandable_site_subsystem_combiner2

For replacement procedures, see [Replacing a Cavity Combiner \(700/800 MHz\)](#) on page 416

Replacing a Cavity Combiner (700/800 MHz)

The RF input cable, built in isolator, and tuning knob are shown for one of the six cavities.

Figure 194: Cavity Combiner (700/800 MHz)

GTR8000_expandable_site_subsystem_combiner2



WARNING: Shock hazard. The GTR 8000 Expandable Site Subsystem contains dangerous voltages, which can cause electrical shock or damage to equipment. Set the switches on the front of the power supplies to the Off (O) position when servicing this component in the GTR 8000 Expandable Site Subsystem. Also, shut down any other expansion cabinets/racks that are connected to this GTR 8000 Expandable Subsystem.

Burn Hazard. Some surfaces of the combiner can be extremely hot. Remove power and allow the modules to cool before handling or attempting to remove the combiner.



CAUTION: The cavity combiner is heavy. To avoid injury and damage to equipment, have another person help to lift and support the equipment when installing or removing the combiner from the rack. Make certain that the combiner is fully supported when it is free from its mounting rails.



IMPORTANT: Powering down the GTR 8000 Expandable Site Subsystem causes any affiliated subscribers to relocate to another channel at an adjacent site. Disable the site before starting the combiner replacement procedure so the system does not attribute the loss of channel to a failure. You can disable the site using Unified Event Manager or the Configuration/Service Software (CSS).

Procedure:

- 1 Wear an electrostatic discharge (ESD) strap and connect its cable to a verified good ground.



CAUTION: Wear the ESD strap throughout this procedure to prevent ESD damage to any components

- 2 Connect to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
- 3 To disable the site, perform one of the following actions:

If...	Then...
If the site controllers are in the cabinet/rack,	perform the following actions: <ol style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Site Info tab. c In the User Requested Site State list box, select Site OFF.
If the site controllers are at the prime site,	perform the following actions: <ol style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Subsite tab. c Click in the User Requested Site State cell of the subsite to be disabled and choose User Ignore.

The site is disabled.

- 4 Set all the switches on the front of the power supplies to the Off (O) position to power down the entire site. Allow the combiner to cool for 15 minutes. Also shut down any other expansion cabinets/racks connected to the GTR 8000 Expandable Site Subsystem.
- 5 After the combiner has cooled for at least 15 minutes, disconnect the cabling from the front of the combiner:
 - a** Remove the 7/16-inch DIN output cable.
 - b** Label and remove the QN-type RF input connectors.
- 6 Remove the combiner from the rack:
 - a** Remove the T30 screws that attach the combiner slide rail to the rack.
 - b** Lift the rear of the combiner slightly to unseat the combiner bracket from the rack.
 - c** With the help of another person, slide the combiner out through the front of the rack. Be sure to support both the front and rear of the combiner as it is removed from the rack.
- 7 Install the replacement combiner in the rack:
 - a** With the help of another person, slide the replacement combiner into the front of the rack in the same position and orientation as the previous combiner.
 - b** Lift the rear of the combiner slightly to engage the combiner to its bracket in the rack.
 - c** Secure the combiner slide rail to the rack with the screws which were previously removed.
- 8 Tune the cavity combiner. See [Cavity Combiner Tuning on page 293](#).
- 9 Reconnect the cabling to the front of the combiner:
 - a** Reconnect the QN-type RF input connectors to the appropriate ports.
 - b** Secure the 7/16-inch RF output cable to the output connector.
- 10 Set the rocker switches on the front of the power supplies to the On (I) position to power up the GTR 8000 Expandable Site Subsystem. Also, restore power to any other expansion cabinets/racks that are connected to the Expandable Site Subsystem.
- 11 Connect to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
- 12 To enable the site, perform one of the following actions:

If...	Then...
If the site controllers are in the cabinet/rack,	perform the following actions: a From the menu, select Service → Status Panel Screen . b In the Status Panel Screens window, select the Site Info tab. c In the User Requested Site State list box, select Wide Trunking .
If the site controllers are at the prime site,	perform the following actions: a From the menu, select Service → Status Panel Screen . b In the Status Panel Screens window, select the Subsite tab. c Click in the User Requested Site State cell of the subsite to be enabled and choose Enabled .

The site is enabled.


13 Verify that the GTR 8000 Expandable Site Subsystem is operating properly using fault management software, including:

- Transmitter Metering Screen in Configuration/Service Software (CSS).
- Unified Event Manager

Replacing a Cavity Combiner (UHF)

The RF input cable, built in isolator, and tuning knob is shown for one of the six cavities.

Figure 195: Cavity Combiner (UHF)



GTR8000_cavity_combiner_UHF_1



WARNING: Shock hazard. The GTR 8000 Expandable Site Subsystem contains dangerous voltages, which can cause electrical shock or damage to equipment. Set the switches on the front of the power supplies to the Off (O) position when servicing this component in the GTR 8000 Expandable Site Subsystem. Also, shut down any other expansion cabinets/racks that are connected to this GTR 8000 Expandable Subsystem.

Burn Hazard. Some surfaces of the combiner can be extremely hot. Remove power and allow the modules to cool before handling or attempting to remove the combiner.



CAUTION: The combiner is heavy. To avoid injury and damage to equipment, have another person to help lift and support the equipment when installing or removing the combiner from the rack. Ensure the combiner is fully supported when it is free from its mounting rails.



IMPORTANT: Powering down the GTR 8000 Expandable Site Subsystem causes any affiliated subscribers to relocate to another channel at an adjacent site. Disable the site before starting the combiner replacement procedure, so that the system does not attribute the loss of channel to a failure. You can disable a site using Unified Event Manager or the Configuration/Service Software (CSS).

Procedure:

- 1 Wear an electrostatic discharge (ESD) strap and connect its cable to a verified good ground. This strap must be worn throughout this procedure to prevent ESD damage to any components.
- 2 Connect to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
- 3 To disable the site, perform one of the following actions:

If...	Then...
If the site controllers are in the cabinet/rack,	perform the following actions: <ol style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Site Info tab. c In the User Requested Site State list box, select Site OFF.
If the site controllers are at the prime site,	perform the following actions: <ol style="list-style-type: none"> a From the menu, select The appears. b In the Status Panel Screens window, select the Subsite tab. c Click in the User Requested Site State cell of the subsite to be disabled and choose User Ignore.

The site is disabled.

- 4 Set all the switches on the front of the power supplies to the Off (O) position to power down the entire GTR 8000 Expandable Site Subsystem. Allow the combiner to cool for 15 minutes. Also shut down any other expansion cabinets/racks that are connected to the GTR 8000 Expandable Site Subsystem.
- 5 After the combiner has cooled for at least 15 minutes, disconnect the cabling from the front of the combiner:
 - a Remove the 7/16-inch DIN output cable.
 - b Label and remove the QN-type RF input connectors.
- 6 Remove the combiner from the rack:
 - a Remove the T30 screws attached to the combiner slide rail to the rack.

- b Lift the rear of the combiner slightly to unseat the combiner bracket from the rack.
 - c With the help of another person, slide the combiner out through the front of the rack. Be sure to support both the front and rear of the combiner as it is removed from the rack.
- 7 Install the replacement combiner in the rack:
- a With the help of another person, slide the replacement combiner into the front of the rack in the same position and orientation as the previous combiner.
 - b Lift the rear of the combiner slightly to engage the combiner to its bracket in the rack.
 - c Secure the combiner slide rail to the rack with the screws which were previously removed.
- 8 Tune the cavity combiner. See [Cavity Combiner Tuning on page 293](#).
- 9 Reconnect the cabling to the front of the combiner:
- a Reconnect the QN-type RF input connectors to the appropriate ports.
 - b Secure the 7/16-inch RF output cable to the output connector.
- 10 Set the rocker switches on the front of the power supplies to the On (I) position, to power up the GTR 8000 Expandable Site Subsystem. Also restore power to any other expansion cabinets/ racks that are connected to the GTR 8000 Expandable Site Subsystem.
- 11 Connect to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
- 12 To enable the site, perform one of the following actions:

If...	Then...
If the site controllers are in the cabinet/rack,	perform the following actions: <ul style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Site Info tab. c In the User Requested Site State list box, select Wide Trunking.
If the site controllers are at the prime site,	perform the following actions: <ul style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Subsite tab. c Click in the User Requested Site State cell of the subsite to be enabled and choose Enabled.

The site is enabled.

- 13 Verify that the GTR 8000 Expandable Site Subsystem is operating properly using fault management software, including:
- Transmitter Metering Screen in Configuration/Service Software (CSS).
 - Unified Event Manager

Replacing a Hybrid Combiner Fan Assembly

Figure 196: Hybrid Combiner Fan Assembly (Front View)



WARNING: When removing a fan module, care should be taken to avoid contacting moving fan blades before and after removal with tools, hands, or other objects. If you are removing the fan module to access or replace the modules behind it, turn off the equipment power and allow the modules to cool before performing any work, as the surfaces of the modules can be extremely hot.



IMPORTANT: The fan assembly is designed to be swapped out without shutting the power off. However, you should minimize the amount of time before the new fan is operational, so the hybrid combiner modules do not overheat.

Procedure:

- 1 Wear an electrostatic discharge (ESD) wrist strap and connect its cable to a verified good ground. This strap must be worn throughout this procedure to prevent ESD damage to any components.
- 2 Cut any of the tie wraps, if necessary, to allow room for the fan assembly removal.
- 3 Using a T20 bit, loosen the four captive screws on the front of the fan assembly, so they disengage from the chassis.
- 4 Gently pull the fan assembly straight out to disengage the connector.
- 5 Align the new fan assembly to fit into the opening of the chassis. Push the fan assembly into place to secure the connector on the back of the fan assembly.
- 6 Tighten the four captive screws. Torque to 17 ± 2 in-lb.
- 7 Verify that the fan assembly is operating properly, and the fan Alarm LED is off.
- 8 Use software tools, such as MOSCAD, to verify the status of the fan.

Replacing a Hybrid Combiner Module (900 MHz)

The hybrid combiner modules in the GTR 8000 Expandable Site Subsystem are field replaceable units (FRUs).

Figure 197: Hybrid Combiner Modules (900 MHz)

IMPORTANT: Powering down a base radio causes any affiliated subscribers to relocate to another channel at an adjacent site. Place any channels connected to the hybrid combiner in Service Mode before starting the combiner replacement procedure, so the system does not attribute the loss of channel to a failure. Placing a channel in Service Mode is performed using Unified Event Manager or the Configuration/Service Software (CSS).


There are at least eight variations of combining that are supported. If the combining scheme is being changed due to the addition or removal of base radios, ensure that:

- the proper modules are used (1/2–1/2, 2/3–1/3, or 3/5–2/5)
- the connections from the base radios to the modules are correct
- the cables between the modules are correct for the desired configuration

See the figures in [RFDS - Hybrid Combiner \(900 MHz\) on page 117](#).

Procedure:

- 1 Wear an electrostatic discharge (ESD) strap and connect its cable to a verified good ground. This strap must be worn throughout this procedure to prevent ESD damage to any components.
- 2 Remove the hybrid combiner fan assembly to gain access to the hybrid combiner modules. See [Replacing a Hybrid Combiner Fan Assembly on page 422](#).
- 3 Locate and place any base radios connected to the hybrid combiner module being replaced in Service Mode, as follows:
 - a Connect to the transceiver Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).

Figure 198: Duplexer Module (900 MHz)

WARNING: Shock hazard. The device contains dangerous voltages which can cause electrical shock or damage to equipment. Set the power supply switches for the affected equipment to the Off (O) position when servicing this component.



IMPORTANT: Powering down the base radio causes any affiliated subscribers to relocate to another channel at the site or another channel at an adjacent site. Place the channel in Service Mode before powering down, so the system does not attribute the loss of channel to a failure. Placing a channel in Service Mode is performed using Unified Event Manager or the Configuration/Service Software (CSS).

Procedure:

- 1 Wear an electrostatic discharge (ESD) wrist strap and connect its cable to a verified good ground. This strap must be worn throughout this procedure to prevent ESD damage to any components.
- 2 Locate and place any base radios connected to the duplexer being replaced in Service Mode, as follows:
 - a Connect to the transceiver Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
 - b From the menu, select **Service** → **Test Measurement Screen**.
The **Test and Measurement Screen** appears.
 - c Click **Change to Service Mode**.
 - d At the confirmation screen, click **OK**.

The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.

- 3 Set the rocker switches on the front of the power supply to the OFF (O) position.
- 4 Replace the duplexer equipment. Perform one of the following actions:

If...	Then...
<p>If you want to replace the duplexer and tray from the rack,</p>	<p>perform the following actions:</p> <ol style="list-style-type: none"> a Label and disconnect the Rx output, Tx input, antenna output, and ground cables from the duplexer. b Using a T30 bit, remove the two M6 screws securing the tray to the rack.

If...	Then...
	<ul style="list-style-type: none"> c Slide the tray out the front of the rack. d Slide the new tray into the front of the rack. e Using a T30 bit, secure the tray to the rack with the two M6 screws previously removed. Torque to 60 in-lb. f Connect the Rx output, Tx input, Antenna output, and ground cables to the duplexer.
<p>If you want to replace a duplexer from the tray,</p>	<p>perform the following actions:</p> <ul style="list-style-type: none"> a Label and disconnect the Rx output, Tx input, antenna output, and ground cables from the duplexer. b Remove the two outer captive M4 fasteners securing the duplexer to the tray. c Slide the duplexer out of the tray. d Slide the new duplexer into the tray, in the same location and orientation as the module that you removed, ensuring to insert the tab on the tray into the slot on the duplexer bracket. e Secure the replacement duplexer to the tray, using the two captive M4 fasteners previously removed. Torque to 17 in-lb. f Connect the Rx output, Tx input, Antenna output, and ground cables to the duplexer.

- 5** Set the rocker switches on the front of the power supply to the ON (I) position.
- 6** Place the base radios in Normal Mode, as follows:
 - a** Connect to the base radio transceiver Ethernet service port using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
 - b** From the menu, select **Service** → **Test Measurement Screen**.
The **Test and Measurement Screen** appears.
 - c** Click **Change to Normal Mode**.
 - d** At the confirmation screen, click **OK**.

The base radio halts activity in the current mode, which takes a few minutes, and switches operation to the requested mode.

Replacing a Power Monitor Unit (PMU) (UHF/VHF/900 MHz)

Figure 199: GTR 8000 Power Monitor Unit (PMU) (UHF/VHF/900 MHz)



WARNING: Shock hazard. The GTR 8000 Expandable Site Subsystem contains dangerous voltages, which can cause electrical shock or damage to equipment. Set the switches on the front of the power supplies to the Off (O) position when servicing this component in the GTR 8000 Expandable Site Subsystem. Also, shut down any other expansion cabinets/racks that are connected to this GTR 8000 Expandable Site Subsystem.



IMPORTANT: Powering down the GTR 8000 Expandable Site Subsystem causes any affiliated subscribers to relocate to another channel at an adjacent site. Disable the site before starting the PMU replacement procedure, so the system does not attribute the loss of channel to a failure. You can disable a site using Unified Event Manager or the Configuration/Service Software (CSS).

Procedure:

- 1 Wear an electrostatic discharge (ESD) wrist strap and connect its cable to a verified good ground. This strap must be worn throughout this procedure to prevent ESD damage to any components.
- 2 Connect to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
- 3 To disable the site, perform one of the following actions:

If...	Then...
If the site controllers are in the cabinet/rack,	perform the following actions: <ol style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Site Info tab. c In the User Requested Site State list box, select Site OFF.
If the site controllers are at the prime site,	perform the following actions: <ol style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Subsite tab.

If...	Then...
	<ol style="list-style-type: none"> c Click in the User Requested Site State cell of the subsite to be disabled and choose User Ignore.

The site is disabled.

- 4 Set all switches on the front of the power supplies to the Off (O) position to power down the entire GTR 8000 Expandable Site Subsystem. Also, shut down any other expansion cabinets/racks that are connected to the GTR 8000 Expandable Site Subsystem.
- 5 Remove the PMU module from the rack, as follows:
 - a Label and disconnect the PMU Out, Tx In, Tx Out, and ground cables from the PMU.
 - b Remove the four screws which secure the PMU to the rack using a T20 bit.
- 6 Install the PMU to the rack, as follows:
 - a Secure the PMU to the rack using the four screws which were previously removed.
 - b Reconnect the PMU Out, Tx In, Tx Out, and ground cables to the PMU.
- 7 Set the rocker switches on the front of the power supplies to the On (I) position, to power up the GTR 8000 Expandable Site Subsystem. Also, restore power to any other expansion cabinets/racks that are connected to the GTR 8000 Expandable Site Subsystem.
- 8 Connect to the network and access the appropriate site controller using Configuration/Service Software (CSS). See [Connecting Through an Ethernet Port Link on page 262](#).
- 9 To enable the site, perform one of the following actions:

If...	Then...
If the site controllers are in the cabinet/rack,	perform the following actions: <ol style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Site Info tab. c In the User Requested Site State list box, select Wide Trunking.
If the site controllers are at the prime site,	perform the following actions: <ol style="list-style-type: none"> a From the menu, select Service → Status Panel Screen. b In the Status Panel Screens window, select the Subsite tab. c Click in the User Requested Site State cell of the subsite to be enabled and choose Enabled.

The site is enabled.

- 10 Verify that the system is operating properly by checking the output power.

GGM 8000 Gateway Replacement

For details on replacing a GGM 8000 Gateway, see the *System Gateways – GGM 8000* manual.

Chapter 10

GTR 8000 Expandable Site Subsystem Reference

Reference information for the GTR 8000 Expandable Site Subsystem includes LED states and specifications for individual GTR 8000 RFDS modules.

This chapter contains supplemental reference information relating to the GTR 8000 Expandable Site Subsystem.

LEDs

Many of the LEDs on the GTR 8000 Expandable Site Subsystem devices provide an indication for one or more the following conditions:

Lamp Test

The Lamp Test state is used to verify that the indicators are operational. For Lamp Test, the LEDs stay in this state for only a second or less.

Failure

Indicates a failure that can only be fixed through replacement. If anything other than a hardware fault is causing the state, an Impaired state is indicated.

Impaired

The device is not fully operational due to internal or external causes. Some corrective action must be taken to get back to 100% operation.

Booting Up


The device is not in service due to running of diagnostics or initializing.

Online

The LEDs for the site controller, RDM, transceiver, and power amplifier modules can be viewed through the door to the left of the fans, with the door opened, or closed.

GTR 8000 Base Radio Transceiver LEDs

Figure 200: Transceiver LEDs (viewable through a drop-down door)



Transceiver Status and Alarm LEDs

The Status LED is green, and the Alarm LED is red. These LEDs are either off, on, or blinking depending on the condition of the transceiver.

Table 129: Transceiver Status and Alarm LEDs

Condition	Green (Status LED)	Red (Alarm LED)
No Power	Off	Off
Lamp Test (During Test)	On	On
Impaired Operation	On	Blinking
Critical Failure	Off	On
Booting Up	Blinking	Off
Operational	On	Off

For detailed information on current operation and fault status, use the Configuration/Service Software (CSS) **Status Panel** screen.

Transceiver Ethernet Link Status LEDs

The following LEDs (see [Figure 200: Transceiver LEDs \(viewable through a drop-down door\)](#) on page 429) indicate Ethernet link connections between the transceiver, site controllers, RDMs, or XHubs, and the front panel service port.

Table 130: Transceiver Ethernet Link Status LEDs

LED Name	Indication	LED Status
ENET SC-A (connection to SITE CTRL A)	Ethernet link inactive (Remote PHY/MAC not detected.)	Off
	Ethernet link established (Remote PHY/MAC detected and auto-negotiation completed.)	Green
	Ethernet link active (Actively transmitting or receiving data.)	Amber (blinking)
ENET SC-B (connection to SITE CTRL B)	Ethernet link inactive (Remote PHY/MAC not detected.)	Off
	Ethernet link established (Remote PHY/MAC detected and auto-negotiation completed.)	Green
	Ethernet link active (Actively transmitting or receiving data.)	Amber (blinking)
ENET SVC (front panel service port)	Ethernet link inactive (Remote PHY/MAC not detected.)	Off
	Ethernet link established (Remote PHY/MAC detected and auto-negotiation completed.)	Green
	Ethernet link active (Actively transmitting or receiving data.)	Amber (blinking)

Transceiver Application-Controlled LEDs

The application-controlled LEDs can be green, red, or amber depending on the conditions.

Table 131: Transceiver Application-Controlled LEDs

Condition	LED 1 Receive Status	LED 2 Control Channel Status	LED 3 Tx/Service Status	LED 4 Infrastructure Payload Link Status
Booting Up*	Green	Green	Green	Green
Lamp Test	Amber	Amber	Amber	Amber
Receiver Inhibited	Amber (blinking)			
Receiver Active	Green			
RF Channel Interference	Red (blinking)			
Monitor Before Data Transmit	Green			
Illegal Carrier	Red (blinking)			
Control Channel (Operating)		Green		
Control Channel (Failsoft)		Green (blinking)		
Service Mode			Amber	
Transmitter Inhibited			Amber (blinking)	
Infrastructure Link Connected (V.24, IP, and 4-wire/V.24)				Green
Partial Infrastructure Link Established (V.24 link established, 4-wire link not established)				Amber
Infrastructure Link Disconnected (V.24, IP, and 4-wire/V-24)				Green (blinking)

* During a normal boot up sequence, LEDs 1 through 4 blink from left to right and from right to left continuously for several seconds.

Transceiver Services-Controlled LEDs

For the service-controlled LEDs, the color of all LEDs must be observed to interpret the condition of the transceiver.


Table 132: Transceiver Services-Controlled LEDs

Condition	LED 5 SWDL/ VLAN	LED 6 Fault	LED 7
Lamp Test	Amber	Amber	Amber
Receiver Inhibited		Red	
Receiver Reference Failure		Red	
Transmitter Inhibited		Red	
SWDL (Software Download trans- fer in progress)	Green		
Warning		Amber	
Minor Hardware Failure		Amber (blinking)	
Major Hardware Failure		Red (blinking)	
Critical Hardware Failure		Red	
VSWR Fault		Red	

Transceiver Option Card Intercom LED


The Transceiver Option Card has a single Intercom LED that indicates the intercom function between the ON (amber) and OFF (green) states.

Figure 201: Transceiver Option Card Intercom LED (viewable behind the fan module)



Power Amplifier LEDs

Figure 202: Power Amplifier LEDs, viewable through a drop-down door



The power amplifier LED color must be observed to interpret the power amplifiers condition. For example:

- If the Alarm LED is red and the Transmit and Status LEDs are not lit, the condition is “PA Failure” and the power amplifier module should be replaced.

Table 133: Power Amplifier LEDs

Condition	Transmit (XMIT)	Status	Alarm
Power Off	Off	Off	Off
Lamp Test	Amber	Green	Red
Not Transmitting	Off	Green	Off
Transmitting at Full Requested Output Power	Green	Green	Off
Transmitting at Less Than Requested Power	Amber	Green	Red
PA Failure	Red	Off	Red
Receive Only	Off	Off	Off
Transmitter Inhibited	Off	Green	Red (blinking)

GCP 8000 Site Controller LEDs

Green LEDs indicate that the device is fine. Yellow warns of a potential problem that requires attention, though not an immediate issue. Red is indicative of a problem requiring immediate attention.


LED colors and states are listed here in order of severity:

- Green - Good/Active
- Green Flashing - Good, In progress, Standby
- Yellow - Warning
- Yellow Flashing - Minor
- Red Flashing - Major Fault
- Red - Critical

GCP 8000 Site Controller Software and Services-Controlled LEDs

Software and Services-Controlled LEDs are visible on the front of a GCP 8000 Site Controller with the service door open.

Figure 203: GCP 8000 Site Controller – Software and Services-Controlled LEDs



site_controller_RDM_LEDs

GCP 8000 Site Controller Software-Controlled LEDs



NOTICE: The trunking and ZC Link LEDs are only valid if the GCP 8000 Site Controller is the active or standby site controller in a fully Enabled state. In a Disabled or Critical Malfunction (CR Malf) state, the LEDs are off. A site controller in one of these states does not know the state of the site nor does it try to communicate with the zone controller.

Table 134: Trunked GCP 8000 Site Controller Software-Controlled LEDs

LED	Applica-tion Use	Green On	Green Blinking	Yellow On	Yellow Blinking	Red Blink-ing	Red On	Off
1	SC state	Active	Standby	Disabled (User Req)			CR Malf (in-cludes VV fail-ure for SWDL)	
2	RNG link	Link Up				Establishing link with RNG		CR Malf or Disabled state, standby, data unconfigured
3	Trunking State	Wide Area		Site Off		Local area (site trunk-ing)	Failsoft (IV&D only)	CR Malf or dis-abled state, standby

Table continued...

LED	Applica- tion Use	Green On	Green Blinking	Yellow On	Yellow Blinking	Red Blink- ing	Red On	Off
4	ZC Link	Active	Standby				Down	CR Malf or Disabled state

Table 135: Conventional GCP 8000 Site Controller Software-Controlled LEDs

LED	Applica- tion Use	Green On	Green Blinking	Yellow On	Yellow Blinking	Red Blinking	Red On	Off
1	SC state	Enabled		Disabled (User Req)			CR Malf	
2	Unused							Unused
3	Unused							Unused
4	Unused							Unused

GCP 8000 Site Controller Services-Controlled LEDs



NOTICE: The hardware controls LED 7, the Hardware Active LED. When active, it indicates that the site controller has ownership of the site controller shared external interfaces.

Table 136: GCP 8000 Site Controller Services-Controlled LEDs

LED	Services Use	Green On	Green Blinking	Yellow On	Yellow Blinking	Red Blinking	Red On	Off
5	SWDL/ VLAN		Version validation or auto- VLAN de- tection	SWDL with com- mon VLAN	SWDL with split VLAN		Not in SWDL with split VLAN	Not in SWDL with Common VLAN
6	Local hard- ware failure (all hard- ware includ- ing GPS)			Warning (such as fan un- plugged)	Minor hard- ware failure	Major hardware failure	Critical hard- ware failure (such as inop- erable fans or switch failure)	Good – no faults
7	Hardware Active	Active						Inactive

GCP 8000 Site Controller Status and Alarm LEDs

The status and alarm LED assignment for the GCP 8000 Site Controller are shown and definitions for each status follow the assignment table.

Table 137: GCP 8000 Site Controller Status and Alarm LED Assignment

LED	No Pow- er	Lamp Test	Failure	Impaired	Booting Up	Online
Status LED (green)	Off	On	Off	On	Flash	On

Table continued...

LED	No Power	Lamp Test	Failure	Impaired	Booting Up	Online
Alarm LED (red)	Off	On	On	Flash	Off	Off

Table 138: GCP 8000 Site Controller Status/Alarm LEDs Definitions

Status	Definitions
No Power	The device is currently without power, both primary power and auxiliary power. The No Power state tells the service technician that there is a fundamental problem.
Lamp Test	The Lamp Test state is used to verify if the indicators are operational.
Booting Up	The Booting Up state indicates that the device is booting or is undergoing diagnostics and is not yet ready to place into service. Even though no failure or impairment is identified, the device is not ready to place into service.
Online	The site controller is fully operational, whether in Active or Standby mode. The Online state is used to indicate that the site controller is fully operational. It may be in a Standby mode or In service. The Online state indicates that the site controller should not be removed as it is possibly involved in active calls. The Standby mode is included in this state, it is important that a field technician should not remove a standby site controller without first informing the system of what he is about to do. This keeps the system from switching over to the standby site controller as it is pulled from the frame.
Impaired	The site controller is not fully operational due to internal or external causes. Some corrective action must be taken to return to 100% functionality. The impaired state also indicates that the current state does not equal the User Requested State of the site. For example, a site in the Site Trunking state due to the diagnostic state from the Network Manager has the Online state. If the site is staying out of Wide Trunking due to a reason other than the User Requested State, such as zone controller Link failure, the Impaired LED is lit. The device state, Enabled/Disabled, is always User Requested. Therefore, the Impaired LED is not shown for this state.
Failure	This status indicates a failure that is fixed only through replacement. If something other than a hardware fault is causing the state, the status is Impaired.

If both site controllers are disabled, one site controller still provides the site reference to the base radios, so the channels can maintain failsoft functionality.

GCP 8000 Site Controller Active/Inactive Status LEDs

The four active/inactive status LEDs are found on the top of the service port area of each site controller module. They are visible by opening the service door.

Table 139: GCP 8000 Site Controller Active/Inactive Status LEDs

Active/Inactive LEDs	Description
SW	Status of connection between the active site controller and the standby site controller.
CPU	Status of connection between the active CPU and the standby site controller.

Table continued...

Active/Inactive LEDs	Description
CP2	Status of connection between the site controller and the base radio
SVC	Status of connection between the site controller and the service computer.

Table 140: GCP 8000 Site Controller Active/Inactive LEDs

Information State	Link Status LED
Link Inactive	Off
Link Established (assumes no activity)	Green
Link Active	Yellow or Amber

GCP 8000 Site Controller Link LEDs

The Link LEDs include the LEDs associated with the service port, site controller expansion ports, Net AUX port, and the gateway port.

Table 141: GCP 8000 Site Controller Link LEDs

LED	Link Inactive	Link Established (assumes no activity)	Link Active
Activity LED (yellow/amber)	Off	Off	Yellow/Amber - constant
Link LED (green)	Off	Green - constant	Green - constant

GPB 8000 Reference Distribution Module LEDs

This information for the GPB 8000 Reference Distribution Module (RDM) covers the LED states. Green LEDs indicate that the device is fine. Yellow warns of a potential problem that requires attention, though not an immediate issue. Red is indicative of a problem requiring immediate attention.


LED colors and states are listed here in order of severity:

- Green - Good/Active
- Green Flashing - Good, In progress, Standby
- Yellow - Warning
- Yellow Flashing - Minor
- Red Flashing - Major Fault
- Red - Critical

GPB 8000 Reference Distribution Module Software and Services-Controlled LEDs

The Software and Services-Controlled LEDs, visible on the front of a GPB 8000 Reference Distribution Module (RDM) with the service door open.

Figure 204: RDM Software and Services-Controlled LEDs



site_controller_RDM_LEDs

GPB 8000 Reference Distribution Module Software-Controlled LEDs

Table 142: RDM Software-Controlled LEDs

LED	Application Use	Green On	Green Blinking	Yellow On	Yellow Blinking	Red Blinking	Red On	Off
1	RDM state	RDM A: Active	RDM B: Active	Disabled (User Req)			Critical Malfunction (VV failure for SWDL)	
2	Unused							
3	Unused							
4	Unused							

GPB 8000 Reference Distribution Module Services-Controlled LEDs



NOTICE: The hardware controls LED 7, the Hardware Active LED. When active, it indicates that the GPB 8000 Reference Distribution Module (RDM) has ownership of the shared external interfaces.

Table 143: RDM Services-Controlled LEDs

LED	Services Use	Green On	Green Blinking	Yellow On	Yellow Blinking	Red Blinking	Red On	Off
5	SWDL/ VLAN		Version validation or auto-VLAN detection	SWDL with common VLAN	SWDL with split VLAN		Not in SWDL with split VLAN	
6	Local hardware failure (all hardware including GPS)			Warning (such as fan unplugged)	Minor hardware failure	Major hardware failure	Critical hardware failure (such as switch failure)	Good – no faults
7	Hardware Active	Active						

GPB 8000 Reference Distribution Module Status and Alarm LEDs

Definitions for each GPB 8000 Reference Distribution Module (RDM) status and alarm follow the assignment table.

Table 144: RDM Status and Alarm LED Assignment

LED	No Power	Lamp Test	Failure	Impaired	Booting Up	Online
Status LED (green)	Off	On	Off	On	Flash	On
Alarm LED (red)	Off	On	On	Flash	Off	Off

Table 145: RDM Status Definitions for the Status/Alarm LEDs

Status	Definitions
No Power	The RDM is currently without power, both primary power and auxiliary power. The No Power state is needed to tell the service technician that there is a fundamental problem.
Lamp Test	The Lamp Test state is used to verify that the indicators are operational.

Table continued...

Status	Definitions
Booting Up	The Booting Up state indicates that the device is booting or is undergoing diagnostics and is not yet ready to place into service. Even though no failure or impairment is identified, the RDM is not ready to place into service.
Online	The Online state is used to indicate that the RDM is fully operational. It may also be in an In Service mode. The Online state indicates that the device should not be removed as it is possibly involved in active calls.
Impaired	The RDM is not fully operational due to internal or external causes. Some corrective action must be taken to return to 100% functionality.
Failure	This status indicates a failure that is fixed only through replacement. If something other than a hardware fault is causing the state, the status is Impaired.

If both RDMs are Impaired, one RDM still provides the site reference to the base radios.

GPB 8000 Reference Distribution Module Active/Inactive Status LEDs

The four active/inactive status LEDs are found on the top of the service port area of each GPB 8000 Reference Distribution Module (RDM). They are visible by opening the service door.

Table 146: RDM Active/Inactive Status LEDs

Active/Inactive LEDs	Description
SW	Status of connection between the RDMs.
CPU	Status of connection between the active CPU and the RDMs.
CP2	Status of connection between the RDM and the base radios.
SVC	Status of connection between the RDM and the service computer.

Table 147: RDM Active/Inactive LEDs

Information State	Link Status LED
Link Inactive	Off
Link Established (assumes no activity)	Green
Link Active	Yellow or Amber

GPB 8000 Reference Distribution Module Link LEDs

The Link LEDs include the LEDs associated with the service port, GPB 8000 Reference Distribution Module (RDM) expansion ports, Net AUX port, and the Gateway port.

Table 148: RDM Link LEDs

LED	Link Inactive	Link Established (assumes no activity)	Link Active
Activity LED (yellow/amber)	Off	Off	Yellow/Amber constant
Link LED (green)	Off	Green constant	Green constant

Expansion Hub LEDs

The LEDs on the Expansion Hub are in the front of the Expansion Hub.

Figure 205: Expansion Hub LEDs




Table 149: Expansion Hub LEDs with Description

LED Label	LED Description
1	A hardware controlled green “MODE” LED. When illuminated, it indicates that the XHub is operating in the ‘Normal’ or ‘Impaired Normal’ mode.
7	A hardware controlled green “ACTIVE” LED. When illuminated, it indicates that the XHub has ownership of the redundant XHub shared external interfaces.
Reset	Not in use.
Status	LED is software-controlled when the XHub is operating in the Normal mode. When illuminated, Green = Online.
Alarm	LED is software-controlled when the XHub is operating in the Normal mode. When illuminated, Red = Failure.

The Status and Alarm LEDs work together to indicate status on the Expansion Hub. The Impaired State of the XHub indicates No Connection with the GCP 8000 Site Controller or GPB 8000 Reference Distribution Module.


Table 150: Expansion Hub Status/Alarm LED Assignment

LED	No Power	Lamp Test	Failure	Impaired	Online
Status LED (green)	Off	On	Off	On	On
Alarm LED (red)	Off	On	On	Flash	Off

Fan Module LED

The fan module has one Fan Alarm LED visible on the lower right corner of its front panel. The Alarm is red during Lamp Test (for 1 second or less), and remains red if the fan failures. A fan failure alarm occurs if the built-in speed sensor detects if either fan drops 30% below rated speed. A red Fan Alarm indicates that the fan module must be replaced.

Figure 206: Fan Module-Alarm LED (lower right corner)



 **NOTICE:** The fan operates at full capability for at least seven days after the fan alarm first occurs, allowing normal operation without requiring an immediate service call.

Hybrid Combiner Fan Module LED

Figure 207: Fan Module-Alarm LED (in the lower left corner)



The fan module has one Fan Alarm LED visible on the lower left corner of its front panel. The Alarm is red during Lamp Test (for a second or less), and remains red if there is a fan failure. A fan failure alarm occurs if the built-in speed sensor detects that either fan drops 30% below rated speed. A red Fan Alarm indicates that the fan module must be replaced.

 **NOTICE:** The GTR 8000 Expandable Site Subsystem operates at full capability for at least seven days after the fan alarm first occurs, allowing normal operation without requiring an immediate service call.

Power Supply LEDs

The power supply has three LEDs visible from the front panel. To interpret its condition, observe the color of all the power supply LEDs. For example:

- If the Alarm and Fan LEDs are red and the Status LED is green, the condition is "Lamp Test"

- If the Alarm LED is red and the Fan and Status LEDs are not lit, the condition is "Power Supply Failure"

Figure 208: Power Supply Module




G_series_power_supply_A

Table 151: Power Supply LEDs

Condition	Fan	Status	Alarm
Power Off	Off	Off	Off
Lamp Test	Red	Green	Red
Online	Off	Green	Off
Impaired	Off	Green	Red (blinking)
Power Supply Failure	Off	Off	Red
Power Supply Fan Failure	Red	Off	Red

RMC/LNA Alarm and Status LEDs

Figure 209: Cabinet RMC/LNA Module



GTR8000_RFDS_XS_RMC_Cabinet_Front1

Receive multicouplers/low noise amplifiers (RMCs/LNAs) have a green Status LED and red Alarm LED next to the DIP switches. These LEDs are either off or on, depending on the condition of the module.

Table 152: RMC/LNA Module LED States

Information State	Alarm LED (red)	Status LED (green)
No Power	Off	Off
Failure	On	Off
Online	Off	On

RFDS Equipment Specifications

This section provides specifications for all the RFDS equipment: transmit filter, diplexer, preselector filters, cavity combiner, and receiver multicoupler / low noise amplifier.



IMPORTANT: Specifications are subject to change without notice.

GTR 8000 Expandable Site Subsystem RFDS Elevation Derating

Above 3000 meters (9800'), the peak power derating for the transmit filter and phasing harness is 1dB/1km (0.3 dB/1000ft). So at 5000 meters (16400') full power is limited to 9-way transmitter combining for 700/800/900 MHz or 4-way for UHF.

Transmit Filter Specifications (700/800/900 MHz)

Table 153: Transmit Filter Specifications (700/800/900 MHz)

	Tx Filter Spec Limit (700/800/900 MHz)	Typical	Notes
Frequency Range	764–776 MHz, 851–870 MHz, 935–941 MHz		
Insertion Loss	0.3 dB	0.15 dB	
Port Return Loss	14 dB	25 dB	
Rx Selectivity (700/800 MHz)	35 dB	40 dB	
Rx Selectivity (900 MHz)	25 dB	30 dB	
RMS Input Power (700/800 MHz)	650 W		
RMS Input Power (900 MHz)	500 W		
Peak Instantaneous Power (700/800 MHz)	32k W		
Peak Instantaneous Power (900 MHz)	11k W		
Passive Intermodulation	–135 dBc		2 x 43 dBm
RF Connector Type	7/16 DIN female		
Power Monitor Connector Type	D-Sub 9-pin male		
Forward and Reflected Power Range	0-500 W		0-5V DC out

Transmit Filter Specifications (UHF)

Table 154: Transmit Filter Specifications (UHF)

	Tx Filter Spec Limit (UHF)	Typical	Notes
Frequency Range	450–453.5 MHz 451.5–455 MHz 460–463.5 MHz 461.5–465 MHz 470–472 MHz 471–473 MHz		

Table continued...

	Tx Filter Spec Limit (UHF)	Typical	Notes
	476–478 MHz		
	477–479 MHz		
	482–484 MHz		
	483–485 MHz		
	488–490 MHz		
	489–491 MHz		
	494–496 MHz		
	495–497 MHz		
	500–502 MHz		
	501–503 MHz		
	506–508 MHz		
	507–509 MHz		
Insertion Loss			
<470 MHz	0.95 dB	0.5 dB	
>470 MHz	1.05 dB	0.7 dB	
Port Return Loss	15 dB	21 dB	
Rx Selectivity	24 dB	26 dB	
RMS Input Power	400 W		
Peak Instantaneous Power	9.7 kW		
Passive Intermodulation	-125 dBc		2 x 43 dBm
RF Connector Type	7/16 DIN female		
Power Monitor Connector Type	D-Sub 9-pin male		
Forward and Reflected Power Range	0–400 W		0-4V DC out

Diplexer Specifications (700/800 MHz)

If 700/800 MHz channels are at the same site, a diplexer is used in place of the transmit filter and a custom configuration is required.

Table 155: Diplexer Specifications

	Diplexer Spec Limit	Typical	Notes
Frequency Range	764–776 MHz 851–870 MHz		
Filter Insertion Loss	0.3 dB	0.15 dB	
Expansion Cable Insertion Loss		0.4 dB	
Port Return Loss	14 dB	25 dB	
Rx Selectivity	35 dB	40 dB	

Table continued...

	Diplexer Spec Limit	Typical	Notes
RMS Input Power	370 W		Each input port
Peak Instantaneous Power	9.0k W		
Passive Intermodulation	-135 dBc		2 x 43 dBm
RF Connector Type	7/16 DIN female		
Power Monitor Connector Type	D-Sub 9-pin male		
Forward and Reflected Power Range	0–500 W		0-5V DC out

Site Preselector Filter Specifications (700/800 MHz)

Table 156: Site Preselector Filter Specifications (700/800 MHz)

	Site Preselector Spec Limit (700/800 MHz)	Typical
Frequency Range	792–825 MHz	
Insertion Loss	1 dB	0.6 dB
VSWR max.	1.5:1	1.3:1
Tx Selectivity	75 dB	78 dB
Test Port Coupling		–30 dB
Input Connector	QMA	
Output Connector	QMA	
Test Port Connector	BNC	

Site Preselector Filter Specifications (UHF, 455–512 MHz)

Table 157: Site Preselector Filter Specifications (UHF 455–512 MHz)

	Site Preselector Spec Limit (UHF)	Typical	Notes
Frequency Range	455–458.5 MHz 456.5–460 MHz 465–468.5 MHz 466.5–470 MHz 473–475 MHz 474–476 MHz 479–481 MHz 480–482 MHz 485–487 MHz 486–488 MHz 491–493 MHz 492–494 MHz		

Table continued...

	Site Preselector Spec Limit (UHF)	Typical	Notes
	497–499 MHz 498–500 MHz 503–505 MHz 504–506 MHz 509–511 MHz 510–512 MHz		
Insertion Loss			
<470 MHz	2.2 dB	1.5 dB	
>470 MHz	2.4 dB	1.7 dB	
Port Return Loss	15 dB	21 dB	
Tx Selectivity	68 dB	71 dB	at Rx band-edge
Test Port Coupling	–28 to –32 dB		
RF Connector Type	QMA female		
Test Port Connector Type	BNC female		

Cavity Combiner Specifications (700/800 MHz)

Table 158: Cavity Combiner Specifications (700/800 MHz)

	Combiner Spec Limit	Typical	Notes
Frequency Range	764–776 MHz, 851–870 MHz		12-way expandable 12-way expandable 6-way only
Insertion Loss			Over power temperature
150 kHz Tx-Tx	4.8 dB	2.5 dB	5.3 dB 12-way limit (700/800 MHz)
250 kHz Tx-Tx	4.3 dB	2.0 dB	
500 kHz Tx-Tx		1.8 dB	
1.0 MHz Tx-Tx		1.7 dB	
3.0 MHz Tx-Tx		1.7 dB	
Frequency Stability	± 40 kHz		Over power temperature
RMS Input Power (700/800 MHz)	100 W		240 W PEP Max
Tx-Tx Isolation			Over power temperature
150 kHz Tx-Tx	27 dB	35 dB	
250 kHz Tx-Tx	30 dB	39 dB	
500 kHz Tx-Tx		44 dB	

Table continued...

	Combiner Spec Limit	Typical	Notes
1.0 MHz Tx-Tx		51 dB	
3.0 MHz Tx-Tx		58 dB	
Input Return Loss	17 dB		
Output Return Loss	11 dB		
Minimum Carrier Spacing	150 kHz		Any valid carrier on any input port
Tx Rejection in Rx Band	40 dB	40 dB	
Passive Intermodulation	-125 dBc		2 x 43 dBm
Input Connector Type	QN female		On circulator
Output Connector Type	7/16 DIN female		On circulator

Cavity Combiner Specifications (UHF)

Table 159: Cavity Combiner Specifications (UHF)

	Combiner Spec Limit	Typical	Notes
Frequency Range	450–465 MHz 470–491 MHz 494–509 MHz		6-way only
Insertion Loss			Over power temperature
150 kHz Tx-Tx	5.3 dB	3.8 dB	
250 kHz Tx-Tx		3.2 dB	
500 kHz Tx-Tx		2.8 dB	
Frequency Stability	± 40 kHz		Over power temperature
RMS Input Power	110 W		200 W PEP Max
Tx-Tx Isolation			Over power temperature
150 kHz Tx-Tx	26 dB	35 dB	
250 kHz Tx-Tx		39 dB	
500 kHz Tx-Tx		44 dB	
Input Return Loss	17 dB		
Output Return Loss	11 dB		
Minimum Channel Spacing	150 kHz		Any valid carrier on any input port

Table continued...

	Combiner Spec Limit	Typical	Notes
Tx rejection in Rx Band			
<470 MHz	21 dB	24 dB	
>470 MHz	18 dB	21 dB	
Passive Intermodulation	-125 dBc		2 x 43 dBm
Input Connector Type	QN female		On circulator
Output Connector Type	7/16 DIN female		On circulator

Receiver Multicoupler/Low Noise Amplifier (RMC/LNA) Specifications (700/800/900 MHz)

Table 160: Site Receiver Multicoupler/Low Noise Amplifier (RMC/LNA) Specifications (700/800/900 MHz)

	Site RMC/LNA Spec Limit	Site RMC/LNA Typical	Notes
Frequency Range	776–902 MHz		
Attenuator Range	0-31 dB		
Default Attenuator Setting	1 dB		Factory preset
Default Gain			Factory preset
Primary Output	9 dB	10.5 dB	
Expansion Outputs	11.8 dB	12.3 dB	
Noise Figure			Factory preset
Primary Output	2.6 dB	2.0 dB	
Expansion Outputs	2.4 dB	1.8 dB	
Third Order Output Intercept			Factory preset
Primary Output		23 dBm	
Expansion Outputs		25 dBm	
Input Connector Type	QMA		
Output Connector Type			
Primary Output	QMA		
Expansion Outputs	BNC (3)		
VSWR max	1.5:1		All ports

Table 161: Cabinet Receiver Multicoupler/Low Noise Amplifier (RMC/LNA) Specifications (700/800/900 MHz)

	Cabinet RMC/LNA Spec Limit	Cabinet RMC/LNA Typical	Notes
Frequency Range	776–902 MHz		

Table continued...

	Cabinet RMC/LNA Spec Limit	Cabinet RMC/LNA Typical	Notes
Attenuator Range	0-31 dB		
Default Attenuator Setting			Factory preset
No Site RMC	0 dB		
With Site RMC	10 dB		
Default Overall Gain			Factory preset
No Site RMC	15 dB	16.3 dB	
With Site RMC	5 dB	6.4 dB	
Noise Figure			Factory preset
No Site RMC	2.4 dB	1.7 dB	
With Site RMC	4.5 dB	3.7 dB	
Third Order Output Intercept			Factory preset
No Site RMC		29 dBm	
With Site RMC		24 dBm	
Input Connector Type	QMA		
Output Connector Type	Harting 6-way		
VSWR max	1.5:1	1.5:1	All ports

Receiver Multicoupler/Low Noise Amplifier (RMC/LNA) Specifications (UHF)

Table 162: Site Receiver Multicoupler/Low Noise Amplifier (RMC/LNA) Specifications (UHF)

	Site RMC/LNA Spec Limit	Site RMC/LNA Typical	Notes
Frequency Range	380–524 MHz		
Attenuator Range	0-31 dB		
Default Attenuator Setting	4 dB		Factory preset
Default Gain			Factory preset
Primary Output	11.0 dB	12.4 dB	
Expansion Outputs	11.5 dB	13.0 dB	
Noise Figure			Factory preset
Primary Output	2.8 dB	2.1 dB	
Expansion Outputs	2.7 dB	2.1 dB	
Third Order Output Intercept			Factory preset
Primary Output		28.5 dBm	
Expansion Outputs		29 dBm	
Input Connector Type	QMA		
Output Connector Type			

Table continued...

	Site RMC/LNA Spec Limit	Site RMC/LNA Typical	Notes
Primary Output	QMA		
Expansion Outputs	BNC (3)		
VSWR max	1.5:1	1.5:1	All ports

Table 163: Cabinet Receiver Multicoupler/Low Noise Amplifier (RMC/LNA) Specifications (UHF)

	Cabinet RMC/LNA Spec Limit	Cabinet RMC/LNA Typical	Notes
Frequency Range	380–524 MHz		
Attenuator Range	0-31 dB		
Default Attenuator Setting			Factory preset
No Site RMC	1 dB		
With Site RMC	15 dB		
Default Overall Gain			Factory preset
No Site RMC	14 dB	15.4 dB	
With Site RMC	0 dB	1.4 dB	
Noise Figure			Factory preset
No Site RMC	2.5 dB	1.8 dB	
With Site RMC	7.0 dB	6.3 dB	
Third Order Output Intercept			Factory preset
No Site RMC		30 dBm	
With Site RMC		19.5 dBm	
Input Connector Type	QMA		
Output Connector Type	Harting 6–way		
VSWR max	1.5:1	1.5:1	All ports

Cabinet RMC Pass Through Module Specifications

Table 164: Cabinet RMC Pass Through Module Specifications

	Cabinet RMC Pass Through Spec Limit	Typical	Notes
Frequency Range	136–174 MHz 380–435 MHz		
Insertion Loss			
VHF:	0.5 dB	0.4 dB	
UHF R1:	1.0 dB	0.9 dB	
Port Return Loss	16 dB		All ports
Input Connector Type	BNC female		
Output Connector Type	Harting 6–way		

Power Monitor Unit (PMU) Specifications (UHF/VHF/900 MHz)

Table 165: PMU (UHF/VHF/900 MHz)

	Power Monitor Unit Spec Limit (UHF/VHF/900 MHz)	Typical	Notes
Operating Frequency Range	136–174 MHz 350–435 MHz 435–524 MHz 935–941 MHz		
Insertion Loss Tx	0.1 dB		
Port Return Loss	14 dB	22 dB	
RMS Input Power			
VHF	500 W		
UHF	400 W		
900 MHz	500 W		
Peak Instantaneous Power			
VHF	12kW		
UHF	10kW		
900 MHz	11kW		
Passive Intermodulation	–150 dBc		2 x 43 dBm
RF Connector Type	7/16 DIN female		
Power Monitor Connector Type	D-Sub 9-pin male		
Forward and Reflected Power Range	0–500 W		0–5 Vdc out

Hybrid Module Specifications (900 MHz)

Table 166: Hybrid Module Specifications (900 MHz)

	Hybrid Module Spec Limit (900 MHz)	Typical	Notes
Frequency Range	935–941 MHz		
Port Return Loss	20 dB	24 dB	All ports
Input Ports Isolation	20 dB	26 dB	All modules
Hybrid Module, 1/2–1/2			
Input 1 Insertion Loss	3.5 dB	3.2 dB	
Input 2 Insertion Loss	3.5 dB	3.2 dB	
Hybrid Module, 2/3–1/3			

Table continued...

	Hybrid Module Spec Limit (900 MHz)	Typical	Notes
Input 1 Insertion Loss	2.2 dB	1.9 dB	
Input 2 Insertion Loss	5.5 dB	5.2 dB	
Hybrid Module, 3/5–2/5			
Input 1 Insertion Loss	2.7 dB	2.4 dB	
Input 2 Insertion Loss	4.7 dB	4.4 dB	
Connector Type	QN female		All ports

Hybrid Combiner Specifications (900 MHz)

Table 167: Hybrid Combiner Specifications (900 MHz)

	Hybrid Combiner Spec Limit (900 MHz)	Typical	Notes
Frequency Range	935–941 MHz		
Port Return Loss	20 dB	23 dB	All ports
Input Ports Isolation	20 dB	25 dB	
RMS Input Power	120 W		
Insertion Loss			
Single 2–way	3.4 dB	3.2 dB	Dual 2-way also
Single 3–way	5.6 dB	5.2 dB	Dual 3-way also
Single 4–way	6.9 dB	6.5 dB	
Single 5–way	8.3 dB	7.7 dB	
Single 6–way	9.1 dB	8.5 dB	
RMS Output Power			
Single 2–way	37 W	44 W	Dual 2-way also
Single 3–way	22 W	28 W	Dual 3-way also
Single 4–way	17 W	21 W	
Single 5–way	12 W	16 W	
Single 6–way	10 W	13 W	
Connector Type	QN female		All ports

Duplexer Specifications (900 MHz)

Table 168: Duplexer Specifications (900 MHz)

	Duplexer Spec Limit (900 MHz)	Typical	Notes
Rx Frequency Range	896–902 MHz		
Tx Frequency Range	935–941 MHz		
Rx Insertion Loss	1.3 dB	0.7 dB	
Tx Insertion Loss	1.2 dB	0.6 dB	

Table continued...

	Duplexer Spec Limit (900 MHz)	Typical	Notes
Port Return Loss	17 dB	23 dB	All ports
Rx Isolation	80 dB	86 dB	Ant-Tx path
Tx Isolation	65 dB	72 dB	Ant-Rx path
3rd Order Intermodulation	-90 dBc		Tx sub-band IM ₃
Max Input RMS Power	120 W		
Peak Instantaneous Power	2.2kW		
Rx Connector Type	QMA female		
Ant Tx Connector Type	QN female		

This page intentionally left blank.

Chapter 11

GTR 8000 Expandable Site Subsystem Disaster Recovery

This chapter provides references and information that assist in the recovery of a GTR 8000 Base Radio, GCP 8000 Site Controller, or GPB 8000 Reference Distribution Module in the event of a failure.

Recovering the GTR 8000 Base Radio

Process:

- 1 To set up the cabinet/rack, connect power, and cable the base radio, see [GTR 8000 Expandable Site Subsystem Installation on page 145](#).
- 2 To replace the GTR 8000 Base Radio transceiver module, see [Replacing a GTR 8000 Base Radio Transceiver Module on page 358](#) and follow steps 1 through 17.
- 3 To replace other hardware devices, such as the power supply, power amplifier, and RFDS, see [GTR 8000 Expandable Site Subsystem FRU Procedures on page 347](#).
- 4 To perform basic device configuration and SWDL download, see [Replacing a GTR 8000 Base Radio Transceiver Module on page 358](#) and follow steps 18 through 30.

Recovering the GPB 8000 Reference Distribution Module

When and where to use: Perform this procedure to recover the GPB 8000 Reference Distribution Module (RDM) in the event of failure.

Process:

- 1 To set up the cabinet/rack, connect power, and cable the RDM, see [GTR 8000 Expandable Site Subsystem Installation on page 145](#).
- 2 To replace the RDM, see [Replacing a GPB 8000 Reference Distribution Module \(RDM\) on page 368](#) and follow steps 1 through 17.
- 3 To replace other hardware devices, such as the power supply, power amplifier, XHub, and RFDS, see [GTR 8000 Expandable Site Subsystem FRU Procedures on page 347](#).
- 4 To perform basic device configuration and SWDL download, see [Replacing a GPB 8000 Reference Distribution Module \(RDM\) on page 368](#) and follow steps 18 through 28.

Recovering the GCP 8000 Site Controller

Process:

- 1 To set up the cabinet/rack, connect power, and cable the site controller, see [GTR 8000 Expandable Site Subsystem Installation on page 145](#).
- 2 To replace the site controller module, see [Replacing the GCP 8000 Site Controller Module on page 364](#) and follow steps 1 through 15.
- 3 To replace other hardware devices, such as the power supply, power amplifier, XHub, and RFDS, see [GTR 8000 Expandable Site Subsystem FRU Procedures on page 347](#).

- 4 To perform basic device configuration and SWDL download, see [Replacing the GCP 8000 Site Controller Module on page 364](#) and follow steps 16 through 26.

Performing a Site Download

Procedure:

- 1 Connect an Ethernet straight through cable between the Ethernet port on the computer and the site controller. The laptop IP address must be set to an address on the subnet of the local site, which varies depending on the site and zone numbers. See [Connecting Through an Ethernet Port Link on page 262](#).

- 2 Open the Software Download application.

A site software download is not available for conventional devices, GPB 8000 Reference Distribution Modules, or Trunked 3600 devices.



CAUTION: Load the correct version of the software. There is a possibility of a mismatch in software versions when replacing a device with an on-hand spare. If a mismatch in software versions occurs, this mismatch may cause all base radios at the site to go into a configuration mode of operation with a reason of 'Invalid Software Version'. To exit the base radios out of configuration mode, see CSS Procedures > Changing from Configuration to Normal Mode in the CSS Online Help.

If a mismatch in software versions occurs with a site controller, this mismatch may cause a 'critical malfunction', or if it becomes active, to bring the entire site into a configuration mode of operation.

- 3 Download and install the necessary software onto the site controllers and devices as follows:

- a From the menu, select **File** → **File Manager**.

The **Software Depot File Manager** opens.

- b From the menu, select **Component Operations** → **Import Fileset**.

The **Import a Fileset Into the Software Depot** dialog box appears.

- c Click **Browse** and search for the `swdlv3.cfg` file on the CD, or follow the path `E:\swdl\swdlv1.cfg` or `swdlv3.cfg`. Click **Open**.

- d To add the file to the **Components In the Software Depot** list, click **Generate**. Click **OK**.

- e Exit the **Software Depot File Manager**.

- f From Software Download, select **Action** → **Use DNS Server**.



NOTICE: Typically, the site is part of an ASTRO[®] 25 system equipped with a DNS server, and therefore the **Use DNS Server** setting (default setting) should be selected. For ASTRO[®] 25 site upgrade scenarios when the system DNS server cannot be reached, select **Use Standard ASTRO IPs**.

The **Load DNS File** selection should only be used in situations where a custom DNS configuration file has been provided. Typically, this option is selected when the site IP addresses are not configured to be part of an ASTRO[®] 25 system.

- g From the **ASTRO Site Type** drop down list, select the type of site.

- h Select the **Zone**, **Site**, and if applicable, the **Subsite**. The Subsite ID is only available when the Site ID is between 1-64.

- i Click **Connect**.

- j If the device supports SNMPv3 protocol, a pop-up window appears with the security level option. Choose the required security level. Click **OK**.



NOTICE: Depending on the size of the system, the window takes a few minutes to update.

If the Ethernet connection to the site uses the Site Controller Service Port, you might need to enter an 802.1x login account to connect to the SC Service Port. An 802.1x account is a centrally managed account.

The system connects to the specified zone and site.

k In the **Operations Type**, select **Transfer and Install**.

l In the **Application Type** select one of the following:

- For an HPD site: select both **HPD Site Controller** and **HPD Base Radio**.
- For a repeater site: select both **Repeater Site Controller** and **Site Repeater**.
- For a simulcast site: select **Multisite Controller**, **Comparator**, and **Multisite Base Radio**.

m In the **Software Component** drop down list, select the version for each site device.

n Click **Start Operation** to download and install the software.

The site controller and base radio software are loaded and installed with the new software.

o Verify that the select devices have installed the desired version of software.



NOTICE: After installation, the new software version is present in the **Running Version** column. If the new version is not present, it indicates a problem.

For more information, consult the “Fixing a Transfer Failure” section of the *Software Download* manual.

In many cases, a second attempt at transferring the software corrects the failure. If further attempts continue to fail, contact System Support.

This page intentionally left blank.