

NORTHERN TELECOM

PRACTICE 297-2401-105
ISSUED: 89 09 29
RELEASE: 01.01 STANDARD

DIGITAL SWITCHING SYSTEMS

DMS*-100 FAMILY INTEGRATED SERVICES DIGITAL
NETWORK

FIBER REMOTE SWITCHING CENTER
GENERAL DESCRIPTION
BCS29 AND UP UNLESS REISSUED

* DMS is a trademark of Northern Telecom

(c) Northern Telecom 1989

CONTENTS

	PAGE
1. INTRODUCTION	7
Using this Manual	7
Purpose of the FRSC	7
Software Identification	7
References	8
2. OVERVIEW OF THE FRSC	9
The LGCI-LCMI Configuration	9
How the FRSC Includes the LGCI-LCMI Configuration	10
3. SYSTEM COMPONENTS	13
Host Link Extension (HLE) - NTB65BA	13
Physical View	13
Functional View	16
Remote Fiber Line Extension (RFLE) - NTB65BA	17
Physical View	17
Functional View	19
Maintenance Trunk Module (MTM)	19
DS-1 Transport System	19
DS-1 Cross-Connect	20
Distribution Frame (DF)	20
Speech Link Connecting Concentrating (SLCC) Frame.	20
Equipment for Basic OAM	20
Equipment for Enhanced OAM	20
LGCI (Firmware Changes)	20
Network (Firmware Changes)	23
4. SYSTEM CONFIGURATION	24
Connections for the HLE	24
To the FSP	24
To the SLCC	24
To the DSX	25
Connections for the RFLE	26
To the FSP	26
To the MTM	26
To the LGEI	26
To the DSX	27
Connections to the Packet Handler	28
Located at the Host	28
Located at the Remote	28
5. OVERVIEW OF THE BASIC OAM INTERFACE	29
Maintaining the DS-1 Transport System	29
Maintaining the RFLE and HLE.	29
Hex Display	29
Sources of Sync and the Hex Display	29
Setting up the switches at the NTB5702	32

Setting up a Terminal to Monitor the NTB56AA . . .	32
Terminal Commands	33
6. MAINTENANCE PROCEDURES FOR THE BASIC OAM	36
Troubleshooting During Power Up	36
Usage Notes	36
NTB56AA Reset Freezes	37
NTB56AA Fails Power Up Diagnostics	37
A DS-1 Link is not Established	37
Hex Display Show "2D"	38
Host NTB56AA Unable to Obtain Sync	39
In Service Maintenance	39
Guidelines for Replacing HLE/RFLE cards.	39
LGCI Fails to Receive WAI After Reset	40
Cannot communicate with the Remote Terminal	40
Printer is Babbling	40
Network Links Fail from InSv	41
Hex Display Shows 70-7F (DS-1 Link is Down)	41
Hex Code is 2D	41
Routine Testing of the BX56AA	42
7. OVERVIEW OF THE ENHANCED OAM INTERFACE	43
How OAM Capabilities are Enhanced	43
Monitoring Capabilities	43
Using a Personal Computer Interface	43
System Configuration	43
Maintenance Center	43
Host Site	43
General Hardware Requirements	44
Maintenance Center	44
Host Site	45
8. SETTING UP THE ENHANCED OAM INTERFACE	47
Installing the Program - Maintenance Center	47
Example Configurations	48
Monitoring One HLE/RFLE Shelf Combination	49
Monitoring Two HLE/RFLE Shelf Combinations	52
Monitoring Three HLE/RFLE Shelf Combinations	56
9. OPERATING THE ENHANCED OAM INTERFACE	61
Datafilling the Specific Configuration	61
Using the Program Status Screen	63
Status Window (Alarms) for Each NTB56AA	65
Message Window (for Logs and Commands)	67
Status Line (for Available Commands)	68
The Command Menu	68
For Normal Operation	70
Querying the System	72
Troubleshooting	74
Managing Files	75
Troubleshooting (in Depth)	75

Using DOS Commands	77
Additional Commands	78
10. PROVISIONING	80
Provisioning Guidelines	80
HLE	80
RFLE	82
Printer and Personal Computer Interfaces	84
Example Configurations	85
Example 1	87
Example 2	87
11. RESTRICTIONS/LIMITATIONS	88
ESA Capabilities	88
Specifications of the Fiber Transport System	88
12. APPENDIX A - LISTING OF THE INSTALL.BAT BATCH FILE	89
13. APPENDIX B - CONFIGURATION FORMS	91

FIGURES

FIG.	TITLE	PAGE
1	The LGCI-LCMI Configuration	10
2	The Fiber RSC Configuration	12
3	The HLE Frame	14
4	Host Link Extension (HLE) Shelf	15
5	BX5702 Paddle Card	16
6	Functional View of the HLE	17
7	The RFLE Frame	18
8	Maintenance Trunk Module Shelf for the RFLE	19
9	Card locations in LGAI Shelf	22
10	Connections to the FSP of the HLE	24
11	Connections from the HLE to the SLCC	25
12	Connections from the HLE to the DSX	25
13	Connections to the FSP of the RFLE	26
14	Connections from the RFLE to the LGEI	27
15	Connections from the RFLE to the DSX	28
16	Codes for Power Up/Self Test and Event/State	30
17	Test Failure Codes	31
18	How the Enhanced OAM Can Be Configured	46
19	Example Configuration for Monitoring One HLE/RFLE Shelf	49
20	Example Configuration for Two HLE/RFLE Shelves	53
21	Example Configuration for Three HLE/RFLE Shelves	57
22	Program Status Screen	64
23	The Command Menu	69
24	The Help Menu Screen	71
25	HLE Frame Provisioning Rules	81
26	RFLE Frame Provisioning Rules	83

27	Connecting the NTB5702 (ISG Compliant)	84
28	FRSC Link Configuration	86
29	Listing of the Batch File	89
30	Command Functions of the Batch File	90
31	Overall Configuration Form	91
32	NTBX56AA Cards One and Two	92
33	NTBX56AA Cards Three and Four	93
34	NTBX56AA Cards Five and Six	94
35	NTBX56AA Cards Seven and Eight	95
36	NTBX56AA Cards Nine and Ten	96
37	NTBX56AA Cards 11 and 12	97

TABLES

TABLE	TITLE	PAGE
A	Host Link Extension Shelf	15

1. INTRODUCTION

USING THIS MANUAL

1.01 This document contains both an overview of the Fiber RSC configuration and the guidelines for provisioning and setting up the Administration and Maintenance interface. Read the first three chapters to obtain an understanding of how the configuration allows the host ISDN office to be remotely located. Read the remaining chapters to obtain the step-by-step procedures that ensure that the Fiber RSC is correctly provisioned and maintained.

PURPOSE OF THE FRSC

1.02 With Integrated Services Digital Network (ISDN), the Operating Company can provide, using a single interface, both voice and data services to its customers. Refer to 297-2401-100 for a description of the ISDN protocols and the types of services offered. Included is a description of the LGCI-LCMI configuration, which is used to offer services from a local office.

1.03 Due to distance limitations of the host network links, the LGCI-LCMI configuration cannot offer ISDN services to remote sites. The Fiber RSC (FRSC) allows the Operating Company to place the LGCI-LCMI configuration at a remote site by transparently extending the host network links with the use of optical fiber transmission facilities.

SOFTWARE IDENTIFICATION

1.04 Software applicable to a specific DMS-100 Family office is identified by a BCS release number and by Northern Telecom (NT) product engineering codes (PEC). The significance of the BCS number and the PEC is described in 297-1001-450 (section 450/32) and in the office feature record D-190.

1.05 A display of the BCS number and PEC for the NT feature packages available in a specific office can be obtained by entering the following command string at a MAP.

PATCHER;INFORM LIST;LEAVE

1.06 The information contained in this Practice applies to Batch Change Supplement (BCS) 29. Note, however, that although the FRSC hardware is available in BCS29, the FRSC configuration will work with an ISDN host office that contains a previous BCS release.

REFERENCES

1.07 References listed as prerequisites are essential for an understanding of this Practice. Those listed as informative contain detailed information concerning other items mentioned in this Practice, but are not essential. References are inserted at the appropriate places in the text.

Note: The documents listed may exist in more than one version. See 297-1001-001 to determine the release code of the version compatible with a specific release of software.

Prerequisite References

DOCUMENT NUMBER	TITLE
297-1001-100	System Description
297-1001-450	Provisioning
297-2401-100	ISDN System Description
297-2401-102	Operations, Administration and Maintenance Reference Manual
297-2401-103	Peripheral Modules Description

Informative References

DOCUMENT NUMBER	TITLE
297-1001-001	Master Index of Practices
241-1001-150	Equipment Identification and Ordering Information
241-1001-500	DPN Maintenance Management
321-3211-201	FMT-150 B/C/D Installation Procedures
321-3211-203	FMT-150 B/C/D Initial Test Procedures
321-3211-301	FMT-150 B/C/D Terminal Interface CRT Operations
321-3211-302	FMT-150 B/C/D Monitor and Control Module Faceplate Operations
321-3211-501	FMT-150 B/C/D Fault-Locate and Maintenance Procedures

2. OVERVIEW OF THE FRSC

THE LGCI-LCMI CONFIGURATION

2.01 Figure 1 on page 10 gives a block diagram view of the LGCI-LCMI configuration as it applies to a local office. Refer to the following sections of the following documents to better understand this configuration and its capabilities:

- * 297-2401-100, Section "Components of the Exchange Termination for BRA". This section gives a physical description of the LGCI and LCMI.
- * 297-2401-102, Section "Providing Service." This section explains the audiences involved in setting up and testing the different loops.
- * 297-2401-102, Section "Trouble Reporting and Clearing." This section explains the trouble indicators of the LGCI-LCMI and provides procedures to clear the trouble.
- * 297-2401-103, Sections "ISDN Line Concentrating Module" and "ISDN Line Group Controller." These two sections provide a functional description of the LCMI and LGCI.




Fig. 1 - The LGCI-LCMI Configuration

HOW THE FRSC INCLUDES THE LGCI-LCMI CONFIGURATION

2.02 Figure 2 on page 12 gives block diagram of the FRSC. Refer to this figure while reading these paragraphs.


Note: Figure 2 on page 12 shows neither the location of the packet handler (which may be located at either the host or the remote), nor link provisioning. Refer to Connections to the Packet Handler on page 28 for more information.

2.03 Placing the LGCI-LCMI configuration at a remote site is done by extending the DS-30 links to the LGCI at a remote site over a DS-1 transmission system. With the FRSC, the following conversions occur:

1. The DS-30 format network ports are converted at the Host Link Extension (HLE) Frame into the DS-1 format.
2. The DS-1 format signals are routed to the optical equipment where they are converted to the DS-3 format and then to fiber

protocol to be transmitted from the Host to the Remote over optical transmission facilities.

3. The DS-3 signals are converted back to the DS-1 format by the Optical Equipment.
 4. The DS-1 signals are routed to the RFLE.
 5. The DS-1 signals are converted back to the DS-30 format by the RFLE.
 6. The DS-30 signals are routed to the LGCI, where they are processed as if they had come directly from the network ports.
- 2.04 Note that redundancy is provided by having equipment support both planes of the Network module.



REMARKS

- SLCC = Speech Link Connecting Concentrating
- HLE = Host Link Extension Equipment
- DF = Distribution Frame
- DSX = DS Cross-Connect
- RFLE = Remote Fiber Link Extension
- NT1 = Network Termination 1

Fig. 2 - The Fiber RSC Configuration

3. SYSTEM COMPONENTS

3.01 This part provides a physical and (where relevant) functional view of the major FRSC components.

HOST LINK EXTENSION (HLE) - NTB65BA

3.02 The main function of the HLE is to convert each DS-30 stream into two DS-1 streams (and the reverse). This is explained in detail in Functional View on page 16.

Physical View

3.03 Refer to Figure 3 on page 14 for a block diagram of the HLE frame. Included are the PECs for shelves and shelf locations.

3.04 Refer to Figure 4 on page 15 for a diagram of a shelf of the HLE. Included are the PECs for individual cards and their locations.




Fig. 3 - The HLE Frame

3.05 Note that Shelf 18 is required for the minimum configuration. This shelf is made up of two Remote Line Extension (RLE) groups. Each group supports up to eight DS-30 links for one plane of the network, so a fully configured shelf, as shown in Figure 4 on page 15, supports up to eight duplicated DS-30 links to the network.




Fig. 4 - Host Link Extension (HLE) Shelf

TABLE A
 HOST LINK EXTENSION SHELF

SLOT	ABBR	NT PEC	REMARKS
01-03, 25-27			NT2X70AE Power Converter
04, 24	DS-30	NT6X40AA	DS-30 Interface
05, 23	DS-60	NTBX56AA	DS-60 Formatter
06-13, 15-22		DS-1	NT6X50AA DS-1 Interface
14		NT0X50AA	Filler
05, 23 (rear)			NTBX5702 Paddleboard

3.06 Note that the Paddleboard, mounted at the rear of the NTBX56AA card, is used to monitor the channels on the RLE. This card has two RS232 connections to which OAM interfaces (a printer or a Personal Computer) are attached. Figure 5 on page 16 shows the physical layout. Refer to Part 5 on page 29 for how to set up and use the printers.




Fig. 5 - BX5702 Paddle Card

Functional View

3.07 The HLE's main function is to map a DS-30 link onto two DS-1 channel formats. These DS-1 channels are routed to DS-1 cards, which provide the physical interface to the fiber transmission equipment. Figure 6 on page 17 shows how the conversion occurs.




Fig. 6 - Functional View of the HLE

3.08 The 6X40AA converts the 8 DS-30 (2.56 Mb/S) stream from the network ports into 4 DS-60 (5.12 Mb/S) streams. The BX56AA maps the DS-30 bits at the DS-60 level into DS-1 bit streams that are usable by the 6X50AA. Each DS-30 stream is mapped onto two DS-1 streams.

REMOTE FIBER LINE EXTENSION (RFLE) - NTB65BA

Physical View

3.09 Figure 7 on page 18 shows in block form the RFLE shelf. Note that the RFLE can contain an MTM shelf.




Fig. 7 - The RFLE Frame

3.10 The RLE for the RFLE contains the same card set as the HLE. Refer to Figure 4 on page 15.

Functional View

3.11 The RFLE performs the same function as the HLE, with a reverse of DS-30 to DS-1 mapping that was done at the host office by the HLE.

MAINTENANCE TRUNK MODULE (MTM)

3.12 The MTM shelf is used to provide the same maintenance functions for the LGCI and LCMI as those for the host site. The provisionable cards include the Line Test Unit (LTU), Scan cards with the Scan Detect cards, Metallic Test Access (MTA) cards, and Incoming/Outgoing Trunk cards. Figure 8 shows the basic configuration.

01 02 03 04 05 06---Provisioned---19 20 21 22

N	N	N	N		N	N	2
T	T	T	T		T	T	X
2	0	2	2		2	0	7
X	X	X	X		X	X	0
4	7	5	5		0	5	A
5	0	3	9		9	0	A
A	A	A	A		A	A	
B	A	A	A		A	A	
							
							
							
							
							
							

Fig. 8 - Maintenance Trunk Module Shelf for the RFLE

DS-1 TRANSPORT SYSTEM

3.13 A DS-1 Transport System, provided by the Operating Company, is used to convert the DS-1 stream to fiber protocol and to send these signals out over fiber links.

3.14 This system must meet certain requirements, which are listed in Specifications of the Fiber Transport System on page 88. The FMT-150B/C system, manufactured by Northern Telecom, meets these requirements and may be used.

DS-1 CROSS-CONNECT

3.15 The DSX is used to cross-connect the DS-1 links from the RFLE and HLE to the fiber equipment.

DISTRIBUTION FRAME (DF)

3.16 The DFs are used to provide access to customer loops and to provide the MTM access to alarm wiring.

SPEECH LINK CONNECTING CONCENTRATING (SLCC) FRAME.

3.17 The SLCC is used to provide, in essence, a patch facility between the LGCI and the RFLE to simplify configuring/reconfiguring of the links.

EQUIPMENT FOR BASIC OAM

3.18 To monitor the RLE shelves, a dedicated printer is required for each plane (so two printers are required per RLE shelf). These hardcopy terminals record status and error messages as well as a debug level. Commands issued at this terminal allow the user to perform local testing, link testing (to the 6X40 and 6X50 cards), and program monitoring. The printers should be Digital Equipment Corporation (DEC) LA-120DA or the equivalent.

3.19 The two connectors on the BX5702 to which the printers are attached monitor the following:

RLE Slot	Connector	System
5	Top	Local Shelf Plane 0
	Bottom	Remote Shelf Plane 0
23	Top	Local Shelf Plane 1
	Bottom	Remote Shelf Plane 1

EQUIPMENT FOR ENHANCED OAM

3.20 With the enhanced OAM interface, an IBM-compatible personal computer is used to monitor and control the system. Refer to Part 7 on page 43.

LGCI (FIRMWARE CHANGES)

3.21 The configuration of the LGCI is the same for the remote site as the host site. Figure 9 on page 22 shows the configuration of the ISDN line group array (LGAI) shelf. Note the following differences with the standard LGCI:

- * The Message/Tone circuit card, the NT6X69AB, is replaced with the NT6X69MA. In this configuration, there is no separate tone card.

Note: These changes are made to compensate for the remote DS-30 signal delay.

- * The DS-30 Interface card is the 6X40AA.

LGAI NT6X02NB

Front View

D	D	D	D	D	D	D	M	M	M	S	S	F	T	F	I	F	M	F	C	F	D	F	F	P	C
S	S	S	S	S	S	S	P	P	P	P	P	I	S	I	S	I	P	I	S	C	S	I	I	O	O
1	1	1	1	1	3	3						L	L	L	L	L	L	L	M	R	3	L	L	W	N
o	o	o	o	o	A	A						L	L	L	L	L	L	L	M	R	0	L	L	E	V
r	r	r	r	r								R	R	R	R	R	R	R				R	R	R	R
D	D	D	D	D																				T	E
C	C	C	C	C																				R	R
H	H	H	H	H																				E	E

SLOT 0 0 0 0 0 0 0 0 0 1 1 1 1 1 1 1 1 1 1 2 2 2 2 2 2
 NO. 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5

Slot	ABBR	NT PEC	Remarks
01-5	DS1	6X50AB	DS1 Interface
01-5	DCH	BX02AA	D-channel Handler (see note)
06-7	DS30A	6X48AA	DS30A Interface
08	MP	6X45BA	Master Processor
09-10	MPM	6X47AB	Master Processor Memory
11	SPM	6X46BA	Signaling Processor Memory
12	SP	6X45BA	Signaling Processor
13	-	0X50AA	Filler
14	TS	6X44AA	Time Switch
15	-	0X50AA	Filler
16	ISP	BX01AA	ISDN Signaling Preprocessor
17	-	0X50AA	Filler
18	MPC	6X69MA	Message Protocol Card
20	CSM	6X42AA	CSM Interface
21	FORM	6X41AA	Formatter
22	DS30	6X40AA	DS30 Interface
23	-	0X50AA	Filler
24	-	0X50AA	Filler
25	-	2X70AD	Power Converter

Note: Each LGCI is provisioned with a minimum of two DCH cards, one in each LGAI.

Fig. 9 - Card locations in LGAI Shelf

NETWORK (FIRMWARE CHANGES)

3.22 Due to system delays introduced by the HLE, RFLE, and the DS-1 transport system, the P-side processor card in the network module has been changed to extend messaging time-out values. Following are the changes made to network modules:

- * NT5X13 Network Module
 - NT3X75AB (instead of NT3X75AA)
- * NT8X10 Network module
 - NT3X75BB (instead of NT3X75BA)

4. SYSTEM CONFIGURATION

4.01 This part provides additional information on connections between components.

CONNECTIONS FOR THE HLE

To the FSP

4.02 The FSP of the HLE is for power and grounding and for including the HLE in the office alarm system. Figure 10 is a physical view of the FSP that includes the endpoints of specific connections.




Fig. 10 - Connections to the FSP of the HLE

To the SLCC

4.03 The DS-30 control cables (NT0X26ZC) from each HLE shelf are connected to the SLCC by going down the left and right sides (from the rear) and connecting at circuit card positions 04 and 24. Refer to Figure 11 on page 25.

FROM		TO					
0X26		Frame	Shelf-Slot	Pins	Frame	Plane	Port
ZC	A B A(C) B(D)	HLE	X-04	10A/B-17A/B 18A/B-25A/B 56A/B-63A/B 64A/B-71A/B	SLC	0	0,1 2,3 0,1 2,3
ZC	A B A(C) B(D)	HLE	X-24	10A/B-17A/B 18A/B-25A/B 56A/B-63A/B 64A/B-71A/B	SLC	1	0,1 2,3 0,1 2,3

X can be one of 18, 32, or 51

Fig. 11 - Connections form the HLE to the SLCC

To the DSX

4.04 Refer to Figure 12.

FROM				TO				
ZXAM	Frme	Shelf	Slot	Pins	Frame	Slot	Pins	Plane
Send/ Rcve	HLE	X	06/07	T/R00-T/R03	DSX/ Fiber	GR1	Ports 0-3	0
			08/09	T/R04-T/R07		GR2	Ports 4-7	0
			10/11	T/R08-T/R11		GR3	Ports 8-11	0
			12/13	T/R12-T/R15		GR4	Ports 12-15	0
Send/ Rcve	HLE	X	06/07	T/R00-T/R03	DSX/ Fiber	GR1	Ports 0-3	1
			08/09	T/R04-T/R07		GR2	Ports 4-7	1
			10/11	T/R08-T/R11		GR3	Ports 8-11	1
			12/13	T/R12-T/R15		GR4	Ports 12-15	1

X can be one of 18, 32, or 51

Fig. 12 - Connections from the HLE to the DSX

CONNECTIONS FOR THE RFLE

To the FSP

4.05 Connections to the FSP of the RFLE are similar to those of the HLE. There are however, a few differences. Refer to Figure 13.




Fig. 13 - Connections to the FSP of the RFLE

To the MTM

4.06 Cables are run from the DF to the MTM backplane.

To the LGEI

4.07 Refer to Figure 14 on page 27.

FROM				TO							
0X26	Frme	Shf	Slot	Pins	Frme	Shf	Slot	Pins	Network Plane	Port	
ZH(A) (B) (C)	RFLE	51	04/ 24	10A/B-17A/B 18A/B-25A/B 56A/B-59A/B 60A/B-63A/B 64A/B-71A/B	IAE/ LGEI	X/ X+14	22	S B E E E L O W	0/1	1 2-3 4 5 6-7	
				or							
ZH(A) (B) (C) ZK(C) (D)	A B A(C) B(D)			10A/B-17A/B 18A/B-25A/B DO NOT CONNECT 56A/B-63A/B 64A/B-71A/B	SLC	1				1 2-3 4-5 6-7	
X can be one 18 or 51											

NOTE: X can be 18 or 51

Pins can be	10A/B-17A/B	Ports	0-1
	18A/B-25A/B		2-3
	56A/B-63A/B		4-5
	64A/B-71A/B		6-7

Fig. 14 - Connections from the RFLE to the LGEI

To the DSX

4.08 Refer to Figure 15 on page 28.

FROM				TO				
ZXAM	Frame	Shlf	Slot	Pins	Frame	Slot	Pins	Plane
Send/ Rcve	RFLE	X	06/07	T/R00-T/R03	DSX/ Fiber	GR1	Port 0-3	0
			08/09	T/R04-T/R07		GR2	Port 4-7	0
			10/11	T/R08-T/R11		GR3	Port 8-11	0
			12/13	T/R12-T/R15		GR4	Port 12-15	0
Send/ Rcve	RFLE	X	06/07	T/R00-T/R03		GR1	Port 0-3	1
			08/09	T/R04-T/R07		GR2	Port 4-7	1
			10/11	T/R08-T/R11		GR3	Port 8-11	1
			12/13	T/R12-T/R15		GR4	Port 12-15	1

X can be one of 18, 32, or 51

Fig. 15 - Connections from the RFLE to the DSX

CONNECTIONS TO THE PACKET HANDLER

4.09 The packet handler, which is part of the host LGC-LCMI configuration, may be located at either the host or remote site. Refer to the Provisioning part for example configurations.

Located at the Host

4.10 If located at the host site, a DS-1 link is provisioned from the DPN packet handler (the DIU) to the DS-1 Transport system. The corresponding DS-1 link is provisioned from the remote DS-1 Transport system to the LGCI.

Located at the Remote

4.11 If located at the remote site, the packet Handler DIU interfaces directly to the remote LGCI.

Note: Regardless of whether the packet handler is locally or remotely located, the provisioning of network ports is not affected, since the packet handler is provisioned by B8ZS DS-1 trunks from the LGCI and is then routed either directly to the Packet Handler or routed through the DS-1 Transmission system and then on to the Packet Handler.

5. OVERVIEW OF THE BASIC OAM INTERFACE

MAINTAINING THE DS-1 TRANSPORT SYSTEM

5.01 Monitoring the DS-1 Transport system is the responsibility of the Operating Company. If the Operating Company chooses to use the FMT150 product, manufactured by Northern, an interface is provided that allows the user to run tests during both initial installation and on a periodic basis. Refer to the appropriate documents that are listed in the Introduction.

MAINTAINING THE RFLE AND HLE.

Hex Display

5.02 This LED, located on the NTB56AA card, displays a series of hex codes when the card is initialized. This LED also displays certain codes when alarms have been detected. Refer to Figure 16 on page 30 for a list of these codes and their meanings.

5.03 Since these codes are in hex, ranges of numbers are based on 16. The value n can range from 0 to F, the equivalent of 0 through 16.

Sources of Sync and the Hex Display

5.04 Note that since the HLE and RFLE establish and maintain sync with different sources, the hex displays for these have different meanings. On the HLE, the BX56AA card syncs with either the first DS-30 link or the other unit, resulting in a hex display of A0 (the first DS-30 link) or AF (the other unit). On the RFLE, the BX56AA can sync with any one of the other 15 DS-1 links or the other unit, resulting in a hex display of An (with n the number of the DS-1 link) or AF (the other unit).

POWER UP/SELF TEST CODES

Code	Description

00	Reset has occurred
01	Processor Test (test processor memory)
02	EPROM Test (Checksum)
03	RAM Test
04	VCXO (VXCO frequency is checked against CPU frequency)
05	6X50 Detection Test (presence of one or more 6X50s is confirmed)
06	Local Link Test (Communication with 6X50s via mtce bits is tested)
07	Control Injection (Communication with 6X50s via control channel is tested)
08	Terminal Communication Test (Communication with 6X50s via terminal bit is tested)
09	Initializing the BX56

EVENT AND STATE CODES

Code	Description

3n	Link n has been lost
4n	Frame Slip on link n
5n	Frame loss on link n
6n	Yellow alarm on link n
7n	Link n is down
80	Activity gained from other unit
An	In sync on link n (inactive unit, n=F)
En	Link n has been established

Fig. 16 - Codes for Power Up/Self Test and Event/State

TEST FAILURE CODES

Code	Description	Action
21	Processor Error	Processor Test failed - Replace BX56
22	EPROM Error	EPROM Checksum failed - Replace BX56
23	RAM Error	External RAM test failed - Replace BX56
24	VCXO Error	No local frame pulse - Replace BX56
25	VCXO Error	VCXO is running too fast or clock is too slow - Replace BX56
26	VCXO Error	VCXO is running too fast or clock is too slow - - Replace BX56
27	No 6X50s Detected	Replace BX56 if 6X50s are present - If not, install 6X50s
28	Local Link Failure	Unable too talk to any 6X50s on the maintenance bus. Replace the BX56, if the error continues, replace 6X50s
29	Control Failure	Unable to talk to any 6X50s on control channel - Replace BX56, if the error continues, replace the 6X50's
2A	Terminal Communication Failure	Unable to talk to any 6X50s on terminal bit - Replace the BX56 if the error continues
2D	No Active Links	Not receiving maintenance code on any DS-1. Check fiber and far end BX56
2E	Giving Up Activity	Unable to sync on any source and forced to give up activity
2F	Looking for Sync	Trying to sync with line frame pulse If this lasts more than 20 seconds: At host site, check 6X40 and DS-30, then replace the BX56 At remote site, replace the BX56, check 6X50s and DS-1s.

Fig. 17 - Test Failure Codes

Setting up the switches at the NTB5702

5.05 There are three switches on the NTB7502 paddle board. These switches, which are locking toggle switches to prevent accidental switching, control the following:

- * top switch - This switch is used for board testing. Having the switch down causes the board to stop when a fault is encountered during a self test. Having the switch up makes the board continue the self tests even if a failure is found. Except when debugging, this switch should be left in the up position.
- * middle - This switch controls the local/remote control for the NTB56A. Having the switch up invokes local control; you control the card from the top connector. Having the switch down invokes remote control; the card is controlled from the bottom connector at the far end. Unless you are using a connector to control a card locally, you should keep this switch down.
- * bottom - This switch resets the NTB56AA. During normal operation, this switch is down. Toggling this switch up and then down resets the NTB56AA.

Setting up a Terminal to Monitor the NTB56AA

5.06 The primary user interface is through terminals connected to the NTB5702. Following are the ways to control the local and remote NTB56AA:

- * Local control of the NTB5702
 - The terminal is connected to the top D connector.
 - The middle switch of the BX5702 is up.
 - Either the middle switch of the far end BX5702 is down or there is no BX5702 at the far end.
- * Remote
 - The terminal is connected to the bottom D connector.
 - Either the middle switch of the far end is BX5702 is down or there is no BX5702 at the far end.

5.07 To select the correct DS-1 allowing use of the remote terminal, enter "F" at the local terminal. The terminal then displays the message "looking for remote terminal communication" and the @ sign. The process of looking for the proper link may take up to 60 seconds. If a link is found the terminal displays which link is being used for terminal communication with the message "***communication confirmed on link N***" (N is the number

of the link.)). If a link is not found, the terminal displays "*** unable to communicate on any link ***."

5.08 Once communication has been established, the remote terminal is used the same way as a local terminal.

Terminal Commands

5.09 Following are the commands that are issued from the terminal. Note that the <M>enu command gives a list of these commands and that the first letter can be used to invoke the command.

* Alarm link n

Sends a yellow alarm on the n link. When the alarm is sent, scanning for errors on other links is stopped, so the alarm command should be issued again to clear the alarm.

* Backspace Key

Changes the being used for backspace. (It cannot be a HEX digit, the current backspace, or Enter.)

* Clear Hex Log

Clears the log of the hex codes which have been displayed on the LED of the BX56AA. To complete the command, issue the password, which is "DEAD."

* Dump Memory

Views blocks of 8031 memory. You are prompted for which type of memory and which address you wish to see. A firmware listing is required to make full use of this feature.

* Escape Key

Changes the being used for ESC. (It cannot be a HEX digit, the current backspace, or Enter.)

* Find Remote Link

Finds the link on which the remote terminal communication is to take place.

* Hex Log Dump

Dumps the contents of the hex log being kept by the BX56AA. The codes are displayed with the most recent first. An empty hex log is initialized to all zeros.

* Loopback

Controls the three types of loopbacks for the RLE shelf:

1. All DS-1 loopback - loops all DS-1 channels back onto the RLE shelf
2. DS-30 loopback - allows all DS-30 links to be looped back onto the Ds-30.
3. Single DS-1 loopback - allows a single DS-1 to be looped back onto the RLE shelf.

* Menu

Displays a list of the commands

* Note :

Allows a single line note to be placed on the paper. The line should be terminated with a closing square bracket. The note could be used for a time stamp to indicate when the system was checked.

* Power-up Results

Displays the results of the self tests. If the command has not been used since the reset, the first line will indicate that a reset has occurred.

* Query

Displays various status information about the BX56AA. Any error conditions are flagged by "****" before and after the message.

* Read Memory

Performs a repeated read of the specified memory location. This command is not useful on a hard copy printer. On a CRT, this command allows changes to be viewed continuously. Hit any key to abort the test (the display stops in a few seconds). Using this command requires a firmware listing.

* Sync Link

On a RFLE, specifies on which DS-1 link to sync. Specifying "F" caused the unit to give up activity.

* Terminal Link

Manually sets the link on which the remote terminal communication is to be run. This command must be executed on both the host and remote ends from a local port.

* <V> Firmware Version

Displays the firmware version of the BX56AA.

* Write to Memory

Writes to the 8031 memory. This command should not be used without a knowledge of the firmware and a listing.

6. MAINTENANCE PROCEDURES FOR THE BASIC OAM

TROUBLESHOOTING DURING POWER UP

6.01 When the HLE or RFLE is powered up, the following sequence should appear on the hex display:

1. 00
2. 01
3. 02
4. 03
5. 04
6. 05
7. 06
8. 07
9. 08
10. 09
11. 2F
12. (2E)
13. E0
14. E1
15. E2
16. E3
17. E4
18. E5
19. E6
20. E7
21. E8
22. E9
23. EA
24. EB
25. EC
26. EE
27. EF
28. A0 (or AF) for the HLE, A0 through AF for the RFLE

6.02 The sequence E0 to EF may be shorter if there are less than eight network links configured. Once both planes are active (flashing A0 or AF), then there should be no alarms on the frame (s).

6.03 Following are possible alarms that may occur when the system is being powered up.

Usage Notes

6.04 The steps are listed in the order of most to least likely cause of trouble. If a step has not solved a problem, continue with the next step.

NTBX56AA Reset Freezes

* Description

The Hex display shows all radix LEDs on (FF) and the Hex output is not flashing (as if the display were in the reset state). This state can occur when the unit is initially powered up or when the card is replaced on a shelf.

* Action

Ensure that the lower toggle switch on the NTB5702 is in the down position. If the condition does not clear within 10-15 seconds, reseal the BX56AA card. If the condition still exists, replace the BX56AA card.

NTBX56AA Fails Power Up Diagnostics

* Description

The Hex display shows a failure code from 20 to 2A. The correct sequence would count from 01 to 09.

* Action

Reseat the NTB56AA card. If the condition still exists, refer to Figure 17 on page 31. In most cases, the first step is to replace the NTB56AA.

A DS-1 Link is not Established

* Description

One of the 'E' codes for establishing a provisioned DS-1 is missing.

* Action

1. Ensure that the NT6X50 cards are the AA or the AB (Rel 60) version.
2. Ensure inter-bay cabling is correct.
3. Reset the NTB56AA card (toggle the lower switch on the NTB5702) to repeat the diagnostic result. Type "P" on the associated printer to verify that the suspect NT6X50AA card was found by checking the power-up results log
4. Replace the suspect NT6X50AA card, using the following chart:

Missing E code	NT6X50AA card slot	
	Plane 0	Plane 1
E0, E1	6	22
E2, E3	7	21
E4, E5	8	20
E6, E7	9	19
E8, E9	10	18
EA, EB	11	17
EC, ED	12	16
EE, EF	13	15

Note: The codes that can appear depend on the configuration. For example, if only four DS-30 links are provisioned for the site, only codes E0 to E7 will appear, since only eight DS-1 links are established.

5. Verify the connections from the DS-1 to the optical transmission equipment. Refer to the NTPs listed in the introduction.
6. Remove the backplane cabling and physically loop the DS-1 back onto itself. Reset the NTB56; if the link still fails to establish, a backplane route has failed.

Hex Display Show "2D"

* Description

The system at one end is fully functional, but it is not receiving the maintenance code from the far-end DS-1 links. Usually, this problem is with the DS-3 links; otherwise, all DS-1 links would have to fail simultaneously. Another trouble source is cabling problems.

* Action

1. Ensure the far end is functioning (A0,AF on the far end hex displays).
2. Verify the far-end transmit side and the local-end receive section of the fiber transmission system.
3. Set a local loopback on the DS-1 links from the HLE/RFLE shelf to verify that the problem originates at the far end. Refer to the command list in Terminal Commands on page 33. When performing the loopback, the hex display should read A0 and AF.
4. Check the cabling of the fiber transmission system.

Host NTB56AA Unable to Obtain Sync

* Description

The hex display on the NTB56AA at the HLE shows "2F" for more than 20 seconds. This indicates that the unit cannot sync to the Network DS-30 links on both planes.

* Action

Check the cable connections to the HLE NT6X40AA cards at the backplane, paying particular attention to link 0. Check and replace the 6X40AA cards if required. If the problem continues, replace the NTB56AA card.

IN SERVICE MAINTENANCE

6.05 Once the system is in service, many of the standard DMS maintenance concepts apply, with the system automatically recovering from external disruptions. For example, if one of the optical cables were to be cut, the remote LGCI would continue to function with the other network plane.

6.06 Since the HLE/RFLE are redundant configurations, a card failure would not interrupt service. Isolation of faults can be done by using these three loopbacks:

1. loop all DS-1s back onto the shelf
2. loop one DS-1 back onto the shelf
3. DS-30 loopbacks - Loop all DS-30 links back onto the DS-30 links

These commands are described in Terminal Commands on page 33.

Guidelines for Replacing HLE/RFLE cards.

6.07 Whenever changing an HLE/RFLE card, follow this sequence:

1. Busy the associated network links.
2. Ensure the plane is the inactive side, with the NTB56AA flashing "AF". If this needs to be done, input <S>yndch at the printer and select the option F on which to sync; this forces the unit to give up activity to the other plane.

Once you have changed the relevant card, return the network links to service.

LGCI Fails to Receive WAI After Reset

* Description

The MAP indicates that there is no message link to the peripheral.

* Action

1. Verify there are no alarms on the fiber transmission equipment and no DS-1 loss indicated on the hex display.
2. Verify the SLCC cross-connections and the cabling from the SLC to the HLE. Refer to Figure 11 on page 25. Remember that a DS-30 link to the HLE is dedicated for the remote MTM.
3. Verify the cabling between the RFLE and the LGCI.
4. Ensure that the message card for the LGCI is the correct version.
5. Check the communication between the host and remote MTM. At this point, if all checks pass, the problem is likely to be external.
6. Reset all NTB56AA cards by toggling the lower switch on the NTB5702.

Cannot communicate with the Remote Terminal

* Description

A terminal that is attached remotely is not responding.

* Action

Ensure the middle toggle switch on the far-end NTB5702 is in the down position. With the local terminal connected to the top RS232 socket, type "F" to establish communication with the far end.

Printer is Babbling

* Description

The printer is continuously printing a response such as 'INVALID COMMAND'.

* Action

1. Reseat the NTB5702, ensuring there are no bent pins on the backplane.
2. Reseat the NTB56AA.

3. Reset the NTB5702.

Network Links Fail from InSy

* Description

The DMS logs/alarms subsystem indicates there is a network link failure. The following assumes all connections have been verified and there are no alarms on the fiber remote equipment.

* Action

1. Test the speech links (at the NET LINKS level of the MAP) to determine whether specific links or an entire plane has failed. If a plane has failed, the message links will immediately show an alarm. Speech links, on the other hand, will not show an alarm unless the DMS has tried to use them.

- If all the links have failed, replace the 6X40AA card on the associated RFLE unit.
- If only one or two fail, check the hex display and print out the hex log to see if a DS-1 failure has occurred. If it has, replace the associated NT6X50AA card. Retest the links, and if they still fail, replace the NTB56AA.

Hex Display Shows 70-7F (DS-1 Link is Down)

* Description

The hex display and logs show the state of the DS-1 links. If a link fails, it will indicate a yellow alarm, frame slips, and frame loss before going down. The following assumes there are no alarms at the fiber transmission equipment.

* Action

Determine whether the failure is at the local or far end by running a local DS-1 loopback at both the HLE and RFLE. If the loopback fails, replace the local NT6X50AA card.

Hex Code is 2D

* Description

The far end system is not sending the required maintenance codes.

* Action

Replace the far end NTB56AA.

Routine Testing of the BX56AA

* Description.

The following procedure checks the power up/self tests for the NTB56AA while the FRSC is in service. Note that if done properly, call processing will not be affected.

* Action

1. Post the LGCI that is located off the RFLE.
 - If the LGCI in INSV and has no problems, continue
 - If the LGCI has any alarms, STOP. Perform maintenance on the LGCI
2. At the HLE remove the BX56AA card for plane 0 (slot 05). Note that LED on the card goes blank, with the far end LEDs going 7n (n hex)
3. Ensure the LGCI goes ISTb.
 - If the LGCI goes SYSB, STOP. Perform maintenance on the LGCI.
4. Reinsert the BX56AA card so that power up/self tests are initiated.
5. Wait for LEDs to settle.
 - If LEDs settle at An (n = hex, 0 to F), continue.
 - If LEDs settle at another value, translate trouble code.
6. Repeat steps 2 through 5 for Plane 1 (slot 23)
7. Repeat steps 2 through 6 for the RFLE (at the remote site).

7. OVERVIEW OF THE ENHANCED OAM INTERFACE

7.01 To better enable maintenance personnel to integrate the OAM of the FRSC into the overall operation of an office, an enhanced OAM interface is available. This interface is provided through an IBM-compatible Personal Computer (PC) that has been loaded with the Enhanced OAM software program.

HOW OAM CAPABILITIES ARE ENHANCED

Monitoring Capabilities

7.02 The FRSC OAM program monitors all of the NTB56AA cards at the host and remote sites. As well as monitoring and reacting upon messages received from the BX56 cards, the program also polls each NTB56 card to ensure that the communication link to each card is functioning correctly.

7.03 The program also saves all messages that come from each NTB56 card to a unique file. These files can be used to trace the history of commands and events that happened to one particular NTB56 card during trouble-shooting.

7.04 All BX56 cards are monitored at the host end. Each NTB56 card at the host end monitors the associated card at the remote end using a dedicated DS-1 communication link.

Using a Personal Computer Interface

7.05 Unlike the Basic OAM Interface, the Enhanced Interface is menu-driven and has on-line help available. Moreover, you can use the program even if you are not familiar with PC operation or the Disk Operating System (Microsoft DOS).

SYSTEM CONFIGURATION

7.06 Hardware is installed at what are called the Maintenance Center and Host site. These concepts are explained below.

Maintenance Center

7.07 A Maintenance center is a location that will monitor the FRSC system on either a permanent basis or a temporary (trouble shooting) basis. This Center contains the (up to four) PCs that are used.

Host Site

7.08 An FRSC Host site will usually be in a Central Office environment. The equipment required at the host site depends on the number of NTB56AA cards being monitored in the complete system (host and remote). This PC program can monitor up to 12 BX56 cards. The number of HLE/RFLE shelf combinations

(either 1, 2 or 3) determines the number of NTB56 cards in the system.

7.09 Figure 18 on page 46 shows how the maintenance Center and the Host office can be configured. The Maintenance Center can access the Host Equipment in the following ways:

* Co-located

In this configuration, the PCs are co-located with the host office equipment. No dial-up is required.

* Remotely Located

In this configuration, the PC dials up the host equipment through modems. This can be a single- or multiple dial up.

GENERAL HARDWARE REQUIREMENTS

Maintenance Center

7.10 Every Maintenance Center, whether locally or remotely located, requires an 'IBM Compatible' PC, running Microsoft DOS, with the following:

* At least 128 kB of memory

* 10 MB hard disk drive (formatted) to store the program and log data

* A floppy disk drive to install system software.

7.11 The configuration of the serial port depends on where the PC is located.

* Remote

A serial port hooked to a 1200 baud Hayes compatible external modem or an internal modem (1200 baud, Hayes compatible). Either the serial port or the internal modem (whichever is used) should be configured as COM1.

* Local

If the maintenance center is co-located at the FRSC host site, the modem will not be necessary, just a serial port configured as COM1.

7.12 Follow instructions that come with the serial port card or the internal Hayes compatible modem to install them. Make sure whichever one that is used is configured as COM1. If you use an external modem, you must connect the serial port to the Hayes compatible external modem with an RS-232 cable.

7.13 The hard disk drive on the PC should already be formatted, but if it is not, you will have to format it using the directions found in the DOS manual.

Host Site

7.14 At the host site, the type of configuration determines the equipment used. Refer to Figure 18 on page 46. In a local configuration, the PC is connected directly to the Programmable Sharing Device (PSD). In a remote configuration, the PC is either connected to the PSD (for multi dial-up) or the Terminal Eliminator (for single dial-up).




Fig. 18 - How the Enhanced OAM Can Be Configured

8. SETTING UP THE ENHANCED OAM INTERFACE

INSTALLING THE PROGRAM - MAINTENANCE CENTER

8.01 Necessary software will automatically be copied to the hard drive of the PC, drive 'C:', using an installation 'batch' program. A floppy disk containing the installation program and the application software is provided by NTI (Product Engineering Code (P0707196)).

8.02 The installation of the FRSC OAM program requires minimal knowledge of PC operation. For a listing of the installation program and a more detailed description of what it does, refer to Appendix A. The following steps show how to install the program on the formatted hard drive of the PC.

1. If not already done, power up the PC and wait for the system-ready prompt (usually 'C>'). Place the installation disk into the floppy drive (drive A)
2. Type

```
>A:INSTALL
```

MOST of the following messages should appear on the screen.

```
In order to install the FRSC OAM program, the files
"Autoexec.bat" and "Config.sys" should be in the root
directory of the C:\ drive. If these files do not
presently exist, they will be created for you.
These files should not be marked as "Hidden" files and
there should be no batch files executed within
"Autoexec.bat"
```

```
This install batch file creates a new directory on the
C: drive called "C:\OAM", and one subdirectory within OAM
called "C:\OAM\HELP". The program also appends some
commands to the "Autoexec.bat" and "Config.sys" files.
Strike a key when ready . . .
```

Note: This is just a general warning and a short description of what the installation program actually does. Batch files can be identified by the fact that their filename is always followed by ".BAT".

3. Hit any key to continue, and note the following messages that appear on the screen:

```
      1 Files(s) copied
A:COMMAND.MNU
A:HELP.MNU
      2 Files(s) copied
A:MAINT.HLP
A:STATUS.HLP
A:SCAN.HLP
A:UPDATE.HLP
A:CLRALM.HLP
A:QSYNC.HLP
A:QPORT.HLP
A:TRAN.HLP
A:FIND.HLP
A:CLRCOMM.HLP
A:PURGE.HLP
A:FIRMW.HLP
A:PASSTHRU.HLP
A:DOSCOM.HLP
A:QUIT.HLP
A:LOOP.HLP
      16 Files(s) copied
C:\CONFIG.SYS
A:CONFIG.DAT
      1 Files(s) copied
C:\AUTOEXEC.BAT
A:EXEC.DAT
      1 Files(s) copied
```

(The screen clears)

Installation of the FRSC OAM system is now complete.
Please remove installation disk from drive A: and
re-boot the computer (ctrl-alt-del) to start the FRSC OAM.

4. Follow the instructions and re-boot the PC by simultaneously pressing the control (Ctrl) key, the alternate (Alt) key and the delete (Del) key. When the computer finishes rebooting, the FRSC OAM program should begin automatic execution. Refer to Part 9 on page 61 for further instructions on using the FRSC OAM program.

EXAMPLE CONFIGURATIONS

8.03 As mentioned in Host Site on page 43, up to 12 BX56 cards can be monitored by one Enhanced OAM Interface program. This means that up to six fully configured HLE shelves (three at the host and three at the remote) can be monitored. In the following sections, instructions are given for setting up a one, two, or three HLE/RFLE-shelf combination.

Monitoring One HLE/RFLE Shelf Combination

8.04 Figure 19 shows how the system could be configured with one HLE shelf at the host office and one RFLE shelf at the remote office. The system has four NTB56AA cards, two in the HLE shelf and two in the RFLE shelf.




Fig. 19 - Example Configuration for Monitoring One HLE/RFLE Shelf

8.05 The following steps describe the required equipment and installation:

1. Ensure that you have the following equipment:

Quantity	Equipment
-----	-----
(1 to 4)	Auto-Answer 1200 baud modem (one per dial in).
(1)	Black Box Terminal Eliminator (Catalog # GL-TL482B) and SPECIAL FIRMWARE TE033189.3E02
(1)	Black Box Programmable Sharing Device (PSD-4, Catalog # GL-TL304B).
(5 + 1 for	Male to male, straight RS-232 cables (NT0X26BK each modem) or equivalent).

2. Locate a table, desk or counter where you can place the Terminal Eliminator, PSD-4 and modem(s). Make sure that there is an AC outlet for the Terminal Eliminator, the PSD-4 and the modem(s).
3. Configure the DIP switches inside the Terminal Eliminator as shown below:

Switch Designation	Settings							
	1	2	3	4	5	6	7	8
-----	-----	-----	-----	-----	-----	-----	-----	-----
SWA - SWE	off	off	on	on	on	on	off	off
SWF	on	on	off	off	off	off	on	off
SWG	off	off	on	on	off	off	off	off

Also, ports 1 - 4 should be configured as DTEs and port 0 should be configured as a DCE using the shunt jumpers for each port.

4. Configure the jumpers and dial setting inside the PSD-4 as shown below:

Switch Designation	Settings
-----	-----
S1S2 (MAIN)	DTE position
S3S4, S5S6, S7S8 and S9S10 (SUBCHANNEL)	In DTE position if hooking to a modem and in DCE position if hooking straight to a PC serial port
SW5 (BAUD RATE DIAL)	Position 6 for 1200 baud
J1 (CHASSIS GROUND)	DISCONNECT position
J2 (TIME OUT)	DISABLE position
J3 (FORMAT)	ASYNCR position
J4 (CONTENTION)	DATA position

5. Label each RS-232 cable on both ends (for identification).
6. Using 4 of the labeled RS-232 cables, connect ports 1 - 4 of the Black Box Terminal Eliminator to the 4 female RS-232 connectors on the 2 NTBX5702 paddle cards on the backplane of the HLE shelf. Make a note of which RS-232 cable is hooked the local and remote port of plane 0 (right side of the HLE shelf, looking from behind the frame) and the local and remote port of plane 1 (the left side of the HLE shelf). Use the form in Appendix B to record the information. This information will be used later to datafill the PC OAM program.
7. Use 1 of the labeled RS-232 cables to connect port 0 of the Terminal Eliminator to the main channel of the PSD-4 unit.
8. Use the remaining RS-232 cables to connect each auto-answer modem to sub-channels 1 to 4 of the PSD-4 unit. Ensure that the auto-answer modem does not echo characters (echo off) and that the modem only responds to incoming calls (ie. does not recognize commands coming in on the RS-232 port). Most modems have dip switches to control character echo and command recognition.

Note: If a PC is to be located at the host location instead of at a dial-up location, simply connect the serial port of the PC to one of the PSD-4 subchannels, as shown by the dotted line. Also, make sure that the subchannel is configured as a DCE by using the sliding switch inside the PSD-4 unit.)

Note: If you only desire one dial up to the host system, you can delete the Black Box Port Sharing Device and all but one Auto-Answer modem. Simply hook the Auto answer modem

straight to port 0 of the Black Box Terminal Eliminator, as shown by the dashed line.

9. Plug phone lines into each of the auto-answer modems.

8.06 This completes the hardware installation for monitoring one HLE shelf and one corresponding RFLE shelf. Please note that if additional HLE/RFLE shelf pairs are added, the number of ports on the Terminal Eliminator can be increased by adding the 4 port expansion board described in the section that follows. If more than 8 NTB56's are to be monitored, a second Terminal Eliminator can be added. Use the directions in the following sections (Monitoring two HLE/RFLE shelf combinations, Monitoring three HLE/RFLE shelf combinations) when expanding your FRSC OAM system.

Monitoring Two HLE/RFLE Shelf Combinations

8.07 Refer to Figure 20 on page 53, which shows two HLE shelves at the host site and two corresponding RFLE shelves at the remote site. The system has 8 NTB56AA cards, four in the HLE shelves and four in the RFLE shelves.




Fig. 20 - Example Configuration for Two HLE/RFLE Shelves

8.08 The following steps describe the required equipment and installation:

1. The required equipment is as follows:

Quantity Description

(1 to 4) Auto-Answer 1200 baud modem (one per dial in).

(1) Black Box Terminal Eliminator (Catalog # GL-TL482B) with 4 port expansion board (Catalog # GL-TL483-C) and SPECIAL FIRMWARE TE033189.3E02

(1) Black Box Programmable Sharing Device (PSD-4, Catalog # GL-TL304B).

(8 + 1 Male to male, straight RS-232 cables (NT0X26BK or for each equivalent).
modem)

2. Locate a table, desk or counter where you can place the Terminal Eliminator and modem(s). Make sure that there is an AC outlet for the Terminal Eliminator, the PSD-4 and the modem(s).
3. Configure the DIP switches inside the Terminal Eliminator as shown below:

Switch Designation	Settings							
	1	2	3	4	5	6	7	8
SWA - SWE, SWH - SWK	off	off	on	on	on	on	off	off
SWF	on	on	off	off	off	off	on	off
SWG	off	off	on	on	off	off	off	off

Also, ports 1 - 8 should be configured as DTEs and port 0 should be configured as a DCE using the shunt jumpers for each port.

4. Configure the jumpers and dial setting inside the PSD-4 as shown below:

Switch Designation	Settings
-----	-----
S1S2 (MAIN)	DTE position
S3S4, S5S6, S7S8 and S9S10 (SUBCHANNEL)	In DTE position if hooking to a modem and in DCE position if hooking straight to a PC serial port
SW5 (BAUD RATE DIAL)	Position 6 for 1200 baud
J1 (CHASSIS GROUND)	DISCONNECT position
J2 (TIME OUT)	DISABLE position
J3 (FORMAT)	ASYNCR position
J4 (CONTENTION)	DATA position

5. Label each RS-232 cable on both ends (for identification).
6. Using 8 of the labeled RS-232 cables, connect ports 1 - 8 of the Black Box Terminal Eliminator (with 4 port expansion board) to the 8 female RS-232 connectors on the 4 NTB5702 paddle cards on the backplane of the HLE shelves. Make a note of which RS-232 cable is hooked the local and remote port of plane 0 (right side of the HLE shelf, looking from behind the frame) and the local and remote port of plane 1 (the left side of the HLE shelf) on both HLE shelves. Use the form in Appendix B to record the information. This information will be used later to datafill the PC OAM program.
7. Use 1 of the labeled RS-232 cables to connect port 0 of the Terminal Eliminator to the main channel of the PSD-4 unit.
8. Use the remaining RS-232 cables to connect each auto-answer modem to sub-channels 1 to 4 of the PSD-4 unit. Ensure that the auto-answer modem does not echo characters (echo off) and that the modem only responds to incoming calls (ie. does not recognize commands coming in on the RS-232 port). Most modems have dip switches to control character echo and command recognition.

Note: If a PC is to be located at the host location instead of at a dial-up location, simply connect the serial port of the PC to one of the PSD-4 subchannels, as shown by the dotted line. Also, make sure that the subchannel is configured as a DCE by using the sliding switch inside the PSD-4 unit.)

Note: If you only desire one dial up to the host system, you can delete the Black Box Port Sharing Device and all but one Auto-Answer modem. Simply hook the Auto answer modem

straight to port 0 of the Black Box Terminal Eliminator, as shown by the dashed line.

9. Plug phone lines into each of the auto-answer modems.

8.09 This completes the hardware installation for monitoring two HLE shelves and two corresponding RFLE shelves. Please note that if an additional HLE/RFLE shelf pair is added, a second Terminal Eliminator should be added to the monitoring system. Use the directions in the following sections when expanding your FRSC OAM system.

Monitoring Three HLE/RFLE Shelf Combinations

8.10 Figure 21 on page 57 shows a system that consists of three HLE shelves at the host site (a fully provisioned HLE frame) and three corresponding RFLE shelves at the remote site (along with the MTM shelf, a fully provisioned RFLE frame). The system has 12 NTBX56AA cards, 6 in the HLE shelves and 6 in the RFLE shelves.




Fig. 21 - Example Configuration for Three HLE/RFL Shelves

8.11 The following steps describe the required equipment and installation:

1. Ensure that you have the following equipment:

Quantity	Description
-----	-----
(1 to 4)	Auto-Answer 1200 baud modem (one per dial in).
(1)	Black Box Terminal Eliminator (Catalog # GL-TL482B) with 4 port expansion board (Catalog # GL-TL483-C) and SPECIAL FIRMWARE TE033189.3E02
(1)	Black Box Terminal Eliminator (Catalog # GL-TL482B) with 4 port expansion board (Catalog # GL-TL483-C) and NORMAL PRODUCTION FIRMWARE (ie. no special firmware order).
(1)	Black Box Programmable Sharing Device (PSD-4, Catalog # GL-TL304B).

(14 + 1 for Male to male, straight RS-232 cables (NT0X26BK each modem) or equivalent).

2. Locate a table, desk or counter where you can place the Terminal Eliminator(s) and modem(s). Make sure that there is a 115 ACV outlet for each Terminal Eliminator, the PSD-4 and the modem(s).

3. Configure the DIP switches inside the Terminal Eliminators as shown below:

Switch Designation	Settings							
	1	2	3	4	5	6	7	8
-----	-----	-----	-----	-----	-----	-----	-----	-----
SWA - SWE, SWH - SWK	off	off	on	on	on	on	off	off
SWF	on	on	off	off	off	off	on	off
SWG	off	off	on	on	off	off	off	off

Also, all ports on both Terminal Eliminators should be configured as DTEs except for port 0. Port 0 on both Terminal Eliminators should be configured as a DCE. Configure the ports using the shunt jumpers.

4. Configure the jumpers and dial setting inside the PSD-4 as shown below:

Switch Designation -----	Settings -----
S1S2 (MAIN)	DTE position
S3S4, S5S6, S7S8 and S9S10 (SUBCHANNEL)	In DTE position if hooking to a modem and in DCE position if hook- ing straight to a PC serial port
SW5 (BAUD RATE DIAL)	Position 6 for 1200 baud
J1 (CHASSIS GROUND)	DISCONNECT position
J2 (TIME OUT)	DISABLE position
J3 (FORMAT)	ASYNC position
J4 (CONTENTION)	DATA position

5. Label each RS-232 cable on both ends (for identification).

Note: For this discussion, the Terminal Eliminator with special firmware (TE033189.3E02) shall be known as "A" and the Terminal Eliminator without special firmware shall be known as "B".)

6. Using 7 of the labeled RS-232 cables, connect ports 1 - 7 of Terminal Eliminator "A" to 7 of the female RS-232 connectors on the 8 NTB5702 paddle cards on the backplane of the HLE shelves. Use 1 RS-232 cable to connect port 8 of Terminal Eliminator "A" to port 0 of Terminal Eliminator "B".

Using 5 of the remaining RS-232 cables, connect ports 1 - 5 of Terminal Eliminator "B" to the remaining female RS-232 connectors on the 8 NTB5702 paddle cards on the backplane of the HLE shelves. Make a note of where each RS-232 cable is hooked, to which local and remote port of plane 0 (right side of the HLE shelf, looking from behind the frame) and which local and remote port of plane 1 (the left side of the HLE shelf) on all three HLE shelves. Use the form in Appendix B to record the information. This information will be used later to datafill the PC OAM program.

7. Use 1 of the labeled RS-232 cables to connect port 0 of the Terminal Eliminator to the main channel of the PSD-4 unit.
8. Use the remaining RS-232 cables to connect each auto-answer modem to sub-channels 1 to 4 of the PSD-4 unit. Ensure that the auto-answer modem does not echo characters (echo off) and that the modem only responds to incoming calls (ie. does not recognize commands coming in on the RS-232 port). Most modems have dip switches to control character echo and command recognition.

Note: If a PC is to be located at the host location instead of at a dial-up location, simply connect the serial port of the PC to one of the PSD-4 subchannels, as shown by the dotted line. Also, make sure that the subchannel is configured as a DCE by using the sliding switch inside the PSD-4 unit.)

Note: If you only desire one dial up to the host system, you can delete the Black Box Port Sharing Device and all but one Auto-Answer modem. Simply hook the Auto answer modem straight to port 0 of the Black Box Terminal Eliminator, as shown by the dashed line.

9. Plug phone lines into each of the auto-answer modems.

8.12 This completes the hardware installation for monitoring three HLE shelves and three corresponding RFLE shelves. Please note that if additional HLE/RFLE frames are added, they should be set up as a separate system, using the above directions. The FRSC OAM program can be used to call each HLE frame (one at a time) or another PC for each additional HLE frame can be installed at the maintenance center for continuous monitoring of all HLE frames.

9. OPERATING THE ENHANCED OAM INTERFACE

DATAFILLING THE SPECIFIC CONFIGURATION

9.01 Upon startup, the program looks for a data file (named PORT.DAT) containing specific information about the host site being monitored. Upon initial installation, this file will not exist and the user will be asked first for the number of NTB56 cards in the system (1 to 12) and then for information about each of these BX56 cards. This information relates a port on the Black Box Terminal Eliminator to a particular BX56 card.

9.02 The NTB56 card connected to port 1 of the Black Box Terminal Eliminator is card 1, the NTB56 card connected to Terminal Eliminator port 2 is card 2 and so on, up to card 8. If there are only 8 BX56 cards, then the system requires only one Terminal Eliminator to monitor all 8 cards and NTB56 card 8 is connected to port 8. However, if more than 8 BX56 cards are being monitored, card 8 is connected to port 1 of the second Terminal Eliminator. This is due to the fact that port 8 of the first Terminal Eliminator is connected to port 0 of the second Terminal Eliminator (See section of installing hardware for monitoring 3 HLE/RFLE shelf combinations for more detail). The NTB56 card 9 would then connect to port 2 of the second Terminal Eliminator and so on.

9.03 The information necessary to answer the FRSC OAM datafill questions will need to be obtained during hardware installation. Use the form in Appendix B to record the necessary information. The following is a list of the information requested about each NTB56 card being monitored by the program.

1. Number of NTB56AA cards

Total number of NTB56AA cards being monitored at both the host and the remote site. This is equal to the number of Terminal Eliminator ports hooked directly to BX56 cards.

2. Site Name

A unique name for the host or remote site that can be up to 8 characters long. The name should not contain blank spaces.

3. Site Location

Where the card is located, at the Host end (along with the DMS Network) or at the Remote end with the peripheral equipment.

4. Associated Far End Port

If datafilling for a remote card, the port monitoring the host card of this remote card. If datafilling for a host

card, the port monitoring the remote card with which this host card is associated.

5. Network Plane

The DMS Network Plane Number (0 or 1).

6. Network Links Supported

The number of DMS DS-30 links being supported by this BX56 card. The answer will be a number from 1 to 8.

7. Specific DMS DS-30 Link Numbers

The corresponding DS30 link number (from the DMS datafill) of each of the links that are supported by each NTB56AA card. You may change this data after all links are entered by answering 'N' to the question "Is the data correct (Y/N)?"

8. Frame Number

The number identifier of the DMS frame that this card resides in.

9. Shelf Position

The DMS frame shelf position. Must be 18 (the bottom RLE shelf), 32 (the middle RLE shelf) or 51 (the top RLE shelf).

10. Port LOG file

The name of the file that you want messages from this NTB56 card to be captured in. Must be 8 characters or less and must not contain any blank spaces.

11. MASTER/MONITOR Mode

The program will now ask the user if they want to log on as a 'MONITOR' or as a 'MASTER.' In the MONITOR mode, a PC can monitor the status of the host site, but can not send commands to the BX56 cards. Also, the communication links are not supervised in the MONITOR mode. In the MASTER mode, the PC has full access to the system and can issue any available BX56 command. Also, a PC in the MASTER mode will supervise the communication link with each NTB56 card and flag any cards that are not responding.

As many as four PCs can be monitoring one host site at the same time but only one of the four PCs can be in MASTER mode. If more than one PC is dialed into the host site, users should coordinate who is to be MASTER and who is to be MONITOR. Hitting carriage return or answering 'N' to this question ('Do you want to log on as MASTER?'), will put the PC in MONITOR mode. Answering 'Y' to this question will put the PC in MASTER mode.

Once the program is started, the Change PC Mode command can be used to query which mode the PC is in, and also to change mode from MASTER to MONITOR or from MONITOR to MASTER.

CAUTION

If more than one PC is monitoring a host site, only one of those PCs should be in MASTER mode. The ability to be the MASTER PC can be passed from one PC to another by first putting the MASTER PC into MONITOR mode (using the Change PC Mode command), and then changing the desired MONITOR PC to MASTER mode. Having two MASTER PCs talking to the same host site can lock-up the PCs and the host maintenance communications equipment (specifically, the Terminal Eliminator).

12. Dial-up vs. Host Access

The program will ask you if you want to dial up a host site. If the PC is located at the host site, and hooks straight to the PSD-4 unit, then the question should be answered 'N' for no. If the PC is using a modem to dial up the host site, then the question should be answered 'Y' for yes. If 'Y' is typed in, the user is prompted for the telephone number of the host site. All Hayes modem dialing conventions can be used; refer to the modem instruction manual for the use of the 'pause' character and such.

USING THE PROGRAM STATUS SCREEN

9.04 After the modem call is made, or 'N' is answered to the telecom module prompt, the normal program status screen will appear, as shown in Figure 22 on page 64.

Port 01	Port 02	Port 03	Port 04
.....
H.18.1.MATE	H.18.0.CO	R.18.1.MATE	R.18.0.CO

<pre>P3 <link establish test passed> P3 <control test passed> P3 <terminal communication test passed> P3 <Q P3 <REMOTE unit INACTIVE PLANE 1> P3 <terminal communication through DS1> P3 <continue on error> P3 <in sync on the other unit> P3 <no tests active> P3 <6X50 boards loopbacks inactive> P3 <terminal communication on link 0A> P3 <activity on link(s) 00 01 02 03 04 05 06 07 08 09 0A 0B 0C P3 0D 0E 0F of P3 <index plus minus center sample delta integrate dac p P3 <0000FF 000001 000004 000002 000002 0 0000 00EF21 000779 000</pre>
ISDN HLE/RLE Press any key for MENU REV1.5

Fig. 22 - Program Status Screen

9.05 The Program Status Screen is made up of three areas:

1. a status window (for each NTB56AA card)
2. a message window (for logs and commands)
3. a status line at the bottom of the screen.

9.06 In addition, there is a command menu accessed by hitting any key on the PC keyboard, and a help menu which is accessed through the command menu. Each of these screen areas will be covered in detail.

Status Window (Alarms) for Each NTB56AA

9.07 A Link Status display board appears for each port data-filled in the system. All alarms and link information is displayed here. The display is updated every time a LOG is received with link status information.

9.08 Condition of the System:

9.09 Following are the types of indicators that can appear and their meaning.

* No alarms

A port with no alarms, supporting 5 DS-30 Network links with all DS1 links established will look like this:

Port 1-----	. means DS1 link established - means not datafilled
----------------------	--

If an alarm is received, then the number of the link is displayed and the alarm type is displayed beneath it, as shown in the next items.

* DS-1 Alarm

Link Number->	Port 1 ..3.....----- ALARM	<-- reverse video
---------------	----------------------------------	-------------------

link # and 'ALARM' -- reverse video

* Frame Loss

Link Number->	Port 1 ..3.....----- Frame	<-- highlighted normal video
---------------	----------------------------------	------------------------------

* Frame Slip

```
Link Number-> 

|               |
|---------------|
| Port 1        |
| ..3.....----- |
| Slip          |

 <-- normal video
```

The above alarms remain on the status board until they are cleared by selecting the 'Clear Alm Flags' option from the COMMAND menu.

- * A DS-1 has been lost

If a link is lost, the link number is indicated flashing with a DS-1(s) LOST message. Other alarms associated with this link only are cleared. The following example shows a port which has lost DS-1 link number 3.

```


|                 |
|-----------------|
| Port 1          |
| ..3.....-----   |
| DS-1(s) L O S T |


```

If a link fails, it will indicate a yellow alarm, frame slips, and frame loss before going down. The following assumes there are no alarms at the fiber transmission equipment.

Determine whether the failure is at the local or far end by running a local DS-1 loopback at both the HLE and RFLE. If the loopback fails, replace the local NT6X50AA card.

- * Port does not have sync

If a port does not have sync, then a 'No sync' message is displayed. If sync was lost during normal operation, the message is in reverse video. If sync is lost as a result of a reset occurring, the message is written in normal video.

- * Communication Link is down

Whenever there are no user commands being executed, the communication link to each port is monitored by the PC. When a NTBX56AA card fails to answer 3 polls, the link is marked as down, and the message "COMM LINK DOWN" is displayed in flashing letters for that port window, as in the following:

```
Port 1
.....
COMM LINK DOWN
```

When the communication link is down, the information in the port status window is not accurate. Steps must then be taken to re-establish the communication link, which usually means replacing the far end NTB56.

9.10 Additional Alarm Information:

9.11 Underneath each port window, there is a line containing the following information:

- * NTB56AA card site location (Host or Remote)
- * shelf position (18, 32 or 51)
- * network plane supported (0 or 1), and
- * source of sync, either the Mate card (MATE) or the Central Office (CO).

9.12 The following example shows this information line:

```
Port 1
..23.....
DS-1(s) L O S T
H,18,1,MATE
```

9.13 In this example, the NTB56AA monitored by port 1 is at the Host site (H), on shelf 18, supporting network plane 1 and synced to its mate card (ie. flashing AF on the NTB56AA hex display).

Message Window (for Logs and Commands)

9.14 All incoming logs from the NTB56AA cards being monitored are displayed in the message window. This window's size is made proportionate to the number of status windows needed on the screen. The more status windows, the smaller the message window and vice versa. Also, when commands are executed, the outgoing commands and the responses from the NTB56AA cards are shown in the message window. When you execute a command, you

should watch the message window to be sure the command executed as expected.

Status Line (for Available Commands)

9.15 At the bottom of the screen is a status line. During normal monitoring, the line tells the FRSC OAM software revision number and the available options (ie. Hit Any Key for Command Menu). During command execution, the status line will contain appropriate information to the command being executed.

THE COMMAND MENU

9.16 The command menu is used to query or troubleshoot the FRSC system and to update the information on the PC screen. The menu is pulled up to the left part of the screen by hitting any key on the PC keyboard. Notice that when the command menu is on the screen, there are directions for its use on the Status Line at the bottom of the screen. A command is executed by using the arrow keys on the PC keyboard to selecting a command, and then pressing Enter.

Note: Only the MASTER PC can execute BX56 commands. If a BX56 command is executed by a PC in the MONITOR mode, an error message is displayed and the command is aborted.

9.17 Figure 23 on page 69 shows the Command Menu.

COMMAND MENU	Port 02	Port 03	Port 04
Abort Menu
HELP			
Scan Recent Alm			
Update Port	H.18.0.CO	R.18.1.MATE	R.18.0.CO
Clear Alm Flags			
Query Sync Link	h test passed>		
Query Port Data	passed>		
Translate Links	unication test passed>		
Find Mtc Link	NACTIVE PLANE 1>		
Clear Comm	unication through DS1>		
Polling OFF/ON	rror>		
LinkAudit OFF/ON	e other unit>		
	ve>		
Purge LOG files	oopbacks inactive>		
	unication on link 0A>		
BX56 F/W Version	ink(s) 00 01 02 03 04 05 06 07 08 09 0A 0B 0C		
Set/Rem Loopback	0D 0E 0F of 1		
Passthru	inus center sample delta integrate dac p		
DOS Command	000004 000002 000002 0 0000 00EF21 000779 0000		
QUIT to DOS			

Select COMMAND MENU item using arrow keys and press <ENTER>

Fig. 23 - The Command Menu

9.18 These commands are divided into 6 distinct groups (separated by a blank line):

1. Normal Operation
2. Querying system information
3. Troubleshooting
4. Managing files
5. Troubleshooting in depth
6. Using DOS commands

9.19 The commands used to support these functions are explained in the following sections.

Note: BX56 commands are marked as "MASTER Mode Only."

For Normal Operation

* Abort Menu Command

This command exits the command menu, and returns the PC to its normal monitoring mode. The command menu can also be exited by placing the cursor on a space with no command and hitting enter.

* HELP command

This command pulls up the Help menu on the right side of the PC screen. Once this screen is up, you can get help for commands by using the arrow keys to choose the command in the help menu and hitting enter. This brings up a window with information text on your choice. You can scroll through the text using the PC keyboard arrow keys.

Exit the Help screen by hitting the escape key (ESC). In addition to help on each command available from the command menu, there is also help available on reading port status information (Status Display) and executing maintenance procedures (Mtc Procedures). Figure 24 on page 71 shows the help screen.

Port 01	Port 02	Port 03	** HELP MENU **
.....	Abort Menu
			Mtc Procedures
			Status Display
			Scan Recent Alm
H.18.1.MATE	H.18.0.CO	R.18	Update Port
			Clear Alm Flags
			Query Sync Link
P1 V			Query Port Data
P1 < BX56AA firmware issue 2 version 1.0			Translate Links
P1 <			
P1 V			Find Mtc Link
P2 V			Clear Comm
P3 V			Polling OFF/ON
P4 V			LinkAudit OFF/ON
			Purge LOG files
			BX56 F/W Version
			Set/Rem Loopback
			Passthru
			DOS Command
			QUIT to DOS

Select HELP MENU item using arrow keys and press <ENTER>

Fig. 24 - The Help Menu Screen

* Scan Recent Alm Command

Selecting this item from the command menu allows the user to examine the last 40 most recent LOGS received by the system from all ports.

The LOGS are arranged in order of reception, with the more recent logs occurring towards the bottom of the file. (i.e. oldest LOG at the top of the file, most recent log at the bottom)

The user can scroll through these LOGs using the cursor arrow keys, and the paging keys (PageUp, PageDown, Home, End).

Pressing the <ESC> key quits this option and resumes OAM normal operation.

* Update Port Command (MASTER Mode Only)

Selecting this item from the command menu allows the user to update the status and state information maintained by the system for the specified port. This is done by sending the 'P' command and the 'Q' command to the NTB56. The 'P' command queries power-up results and the 'Q' command queries current card status.

At Selection of this option the user is prompted for a port number.

This option is used to inform the system of the state of the HLE/RLE links during startup, or following an interruption in the OAM cable connections.

This command is executed automatically upon FRSC OAM program startup and upon re-establishment of a lost communication link.

Note: If a link has not been established, then its number will be left on the status board. Since the system has no way of knowing if this link was lost or never established, the LOST alarm is not raised.

* Clear Alm Flags Command

The system will not clear DS1 link ALARMS, Frame Loss and Frame Slip alarms automatically. Selecting this option will only clear these three 'soft' alarms. It will not clear LOST link indications from the board.

Querying the System

* Query Sync Link Command

This option is used to find out the sync source for a specified port. At Selection of this option the user is prompted for a port number.

The HOST units derive their sync source from the DS-30 Network Links. The remote units derive sync off one of the DS1 links. The remote side unit will seek a sync source from one of the DS1 links 0 to E.

The 'active' unit means the unit which is generating the sync from a DS1 link (BX56 HEX display An where n is one of HEX 0 to HEX E).

The 'inactive' unit (the other plane) gains its sync signal from the 'active' unit (BX56 HEX display AF).

Note: The 'active' and 'inactive' designations are NOT related to which DMS Network plane is considered active.

Both planes of the HLE/RLE Remote equipment are to be considered active because they are carrying the exact same traffic. The DMS active side depends on the DMS XPM and the DMS NM.

* Query Port Data

The 'Query Port Data' option displays the datafill information for a specified port. The data includes:

- Site Name
- Location (Host site or Remote site)
- Associated Far End Port
- Network Plane supported
- Number of Network Links supported
- DMS Frame number
- DMS shelf position
- Port Prefix designation
- LOG file name for this port

Following is an example output.

```
Query BX56 Port Datafill Information
PORT: 1
Associated Far End Port : 3
Site Name : isdn HOST
Frame Number 1 / Shelf Position 18
Network plane 1 --- 8 DS30 links
Port Prefix : P1 Log filename : p1.log
```

* Translate Links

The DS-30 Network links are transported to the remote site using DS1 trunks. One DS30 is supported by 2 DS1 trunks. The maintenance links are also supported by the same DS1s.

This option permits the user to query which DS1 links support which DS-30, and which DS-30 is supported by a specific DS-1. At Selection of this option, the user is prompted for a port number, the direction (DS-1 to DS-30 or DS-30 to DS-1), and then either the DS-1 or the DS-30 link number and network module

The DS-30 links designations are in terms of the HLE DS-30 ports and not the DMS Network Link numbers.

Troubleshooting

* Find Mtc Link Command (MASTER Mode Only)

Communication with the far-end site HLE/RLE equipment is accomplished by establishing a maintenance link.

On selection of this option, the user is prompted to enter a Port number. This command takes several seconds to complete (about 45 seconds). On successful completion, the following message will appear on the main window:

P# COMMUNICATION ESTABLISHED ON LINK ##

If the command is unsuccessful then the message will read:

P# UNABLE TO ESTABLISH COMMUNICATION ON ANY LINK

If this occurs, re-execute the command.

If a maintenance command is issued to a far-end port and no response is received then execute this option on the related near-end port to establish communication. In order to find out which far end port is associated with the port you are trying to communicate with, use the Query Port Data command (Associated Far End Port). For example:

```
Near-end port   Plane 0   connected to Port 1
Far-end port    Plane 0   connected to Port 2
```

Execute the 'Find Mtc Link' on Port 1 to establish the Port 2 maintenance link.

* Clear Comm Command (MASTER Mode Only)

This option clears a corrupted communication link to a BX56 port. The user is queried for the port number. If this command is not successful in re-establishing normal operation, check port cabling and for far-end ports, execute the 'Find Mtc Link' option.

* Change PC Mode

As many as four PCs can be monitoring one host site. Each PC can be in one of two modes, the MONITOR mode or the MASTER mode.

In the MONITOR mode, a PC can monitor the status of the host site, but can not send commands to the BX56 cards. Also, the communication links are not supervised in the MONITOR mode.

In the MASTER mode, the PC has full access to the system and can issue any available BX56 command. Also, a PC in the MASTER mode will supervise the communication link with each NTB56 card and flag any cards that are not responding.

The Change PC Mode command can be used to query which mode the PC is in, and also to change mode from MASTER to MONITOR or from MONITOR to MASTER.

CAUTION

If more than one PC is monitoring a host site, only one of those PCs should be in MASTER mode. The ability to be the MASTER PC can be passed from one PC to another by first putting the MASTER PC into MONITOR mode (using the Change PC Mode command), and then changing the desired MONITOR PC to MASTER mode. Having two MASTER PCs talking to the same host site can lock-up the PCs and the host maintenance communications equipment.

Managing Files

* Purge LOG files Command

This option allows the user to erase the contents of the LOG files and start clean. All the Port log files are re-initialized to an empty state.

In addition, this option will recover LOG file operation if the existing LOG files are inadvertently erased from the DOS command level. All previous data will be lost.

This system also automatically monitors the disk space availability on the system. If the disk becomes full to a specified capacity, the LOG files are automatically re-initialized, preventing the OAM LOGS from completely over-running the disk capacity. Some reserve disk capacity is always maintained on the PC system.

Troubleshooting (in Depth)

* BX56 F/W Version Command (MASTER Mode Only)

This option queries the BX56 firmware version installed on system for a specified port.

This is used to enable the user to verify the system is running the correct firmware version.

* Set/Rem Loopback Command (MASTER Mode Only)

This option permits the user to set DS1 loopbacks on the system for a specified port. DS1 loopbacks can be used to trouble shoot remoted link problems. (Note: The DMS-100

speechloop test should pass with the appropriate DSIs in loopback, but the message test will not pass.)

The loopback types available are

All DSI links
Individual links

The system keeps track of what loopbacks are set. If a link is looped for a particular loop type, then selecting 'Set/Rem Loopback' will remove the loopback.

DSI loopbacks loop the NT6X50AA pack onto itself. Setting these loopbacks will raise alarms on the related far-end port of the system.

Loopbacks are only allowed on the near-end DSIs because far-end DSI loopbacks will cause a loss of communication with the host-end processor (NTBX56AA).

* Passthru Command (MASTER Mode Only)

This is a diagnostic option not required for general operation of the system. It permits direct communication with the specified port.

This option is passworded and should be used with caution since inadvertent system disruption is possible.

For this mode only, prefix all numbers entered including HEX link numbers with an '#'.

CAUTION

Always exit this mode when finished by pressing <ESC>. Remaining in this mode for an extended period of time may result in loss of data on the other ports in the system. If this mode has been active for an extended period of time and loss of data is suspected, then execute the 'Update Port' command to recover.

Using DOS Commands

* DOS Command

Selecting this item from the command menu allows the user to execute any command on the PC without terminating the current OAM session.

The user is prompted for the DOS command to be executed. The command is executed, showing the results on the screen. Pressing any key following execution of the DOS command resumes OAM operation.

LOGs received from the remotes (HLE/RLE) will be buffered during this time and processed once the OAM process is resumed. Loss of data could occur if the system is left in the suspended state (waiting for a key to be pressed) for an extended period of time. The system is in its normal processing state when the status line at the bottom of the screen reads:

"Press any key for Menu"

This function can be used to scan specific port LOG files using the DOS 'type' or 'more' function, print all or a portion of the files and any other related activities. This function can also be used to save datafill specific to one site (for future use) and allow new datafill for a new site. Also, previous datafill files that were saved can be brought back up as the current datafill file. (See Additional Commands section for more detail).

CAUTION

Do not delete the LOG files using the DOS delete command or subsequent LOG data will be lost. To delete LOG files and start new log files use the 'Purge LOG files' option on the COMMAND menu. If the LOG files are accidentally deleted under DOS, then immediately execute the 'Purge LOG files' option to restore normal operation.

For more information on DOS command, consult a DOS Reference Manual.

* QUIT to DOS Command

This option executes a complete shutdown of the OAM system and then exits to the DOS environment.

The user is queried to confirm this request.

Additional Commands

9.20 Even though knowledge of DOS commands is not essential to the OAM program operation, there are a few DOS commands that can be very useful. These commands are listed below. For more detailed information on DOS commands, consult a DOS reference manual. All of the DOS commands described below can be executed from within the FRSC OAM program, using the 'DOS Command' option from the command menu.

* Type DOS command

The type command allows a user to view an ascii text file on the computer screen. The format is 'Type (FN.FT)' where FN.FT is the filename and filetype of the file to be typed. This command is useful to examine log files. If a '| more' is appended to the type command, the computer will pause after each screen full of text until told to continue by the user by hitting any key.

* Print DOS command

If the PC in use has access to a printer, files can be printed out using this command. The format is 'Print (FN.FT)' where FN.FT is the filename and filetype of the file to print. This command is useful in printing out log files and datafill files without leaving the FRSC OAM program.

* DIR DOS command

This is the DIRectory command. The format of this command is 'DIR'. This command displays the files that are on the hard disk. This command is useful for keeping track of datafill files and port log files. The '| more' option, described in the 'TYPE' command, can also be used with the 'DIR' command.

* Rename DOS command

This command is used to rename files on the PC disk; use this command with extreme care. The format is 'Rename (FN1.FT1) (FN2.FT2)' where FN1.FT1 is the filename and filetype of the file to be renamed, and FN2.FT2 is the new filename and filetype.

This command can be used to change the datafill used by the OAM program. First the current datafill file, PORT.DAT, is renamed to some filename easily remembered, for instance the host sitename of the site that this data file describes. At this point, you can either recall a previous datafill file by renaming it to PORT.DAT (use the DIR and Type commands to find out what files are available), or start a new datafill file by rebooting the PC (control-alternate-delete). When the FRSC OAM program restarts, you will be queried for new datafill information because the program could not find the file PORT.DAT.

* Exit DOS

Use this command to return to the OAM program.

10. PROVISIONING

PROVISIONING GUIDELINES

HLE

10.01 Figure 25 on page 81 shows the basic provisioning rules for the HLE frame.

<u>Equipment</u>	<u>PEC</u>	<u>Position</u>	<u>Rule</u>
Common framework	NT0X25AA		1
Earthquake framework	NT0X25AH		1
Frame Supervisory Panel	NTNX26BH	45	7
RLE Shelf	NTBX5501	18	AP
RLE Shelf	NTBX5501	32,51	2
RLE Paddle Board	NTBX5702		6
Fan Unit			3
Cage Filler Panel Asbly	NT0X84AA	65	AP
Cage Filler Panel Asbly	NT0X84AA		2
Circuit cards			4
Cables			5

Provisioning Rules

AP = Always Provided

1 = Provide either common or earthquake framework

2 = Determine how many RLE shelves are required based on each RLE shelf supporting 8 DS-30 links per plane.

3 = Provide one per frame

4 = Refer to the System Component part for a layout of the RLE shelf. Provide enough DS-1 cards to support the DS-30 network ports for the LGICs and MTMs. Each DS-30 port requires two DS-1 links. Work each shelf group from the outside in. Provide NT0X50 for unused slots.

5 = Following are the cables required:

NT0X26ZC - DS-30 between the HLE and SLCC
(One cable per group of four DS-30 links)

NE-ABAM 18 pair - DS-1 between HLE and DSX-1
(Four pairs per DS-30 per plane, so 32 pairs per plane per shelf). Separate cables should be used per plane.

6 = Two NTBX5702s per NTBX5501 RLE shelf

7 = Contains two NT0X91AEs and two NT0X91AAs

Fig. 25 - HLE Frame Provisioning Rules

10.02 In addition, the following rules are to be followed to determine HLE requirements:

* After determining the total number of DS-1 links that are to be connected from remote sites, subtract the DS-1 links carrying Packet Handler traffic since these will be routed to the DIU.

- * Divide the number of DS-1 links by two to obtain the shelf requirements for both planes.
- * The minimum configuration is one RLE shelf. With all three shelves fully configured, the HLE supports 48 DS-1 links per plane over 24 NT6X50AA cards or 24 DS-30 ports per plane.
- * Provision the DIU at the Packet Handler to support additional DS-1 links. One DS-1 link is used for packet handling per LGCI.
- * The DS-1 links are provisioned to account for supporting two planes, except for the DS-1 to the packet handler.

RFLE

10.03 Figure 26 on page 83 shows the basic provisioning rules for the RFLE frame.

<u>Equipment</u>	<u>PEC</u>	<u>Position</u>	<u>Rule</u>
Common framework	NT0X25AA		1
Earthquake framework	NT0X25AH		1
Frame Supervisory Panel	NTNX26BH	45	7
RLE Shelf	NTBX5501	18	AP
RLE Shelf	NTBX5501	32,51	2
RLE Paddle Board	NTBX5702		6
Fan Unit	NT3X90AC		3
Maintenance Trunk Module	NT2X58CA	65	4
MTM Circuit cards	NT2X58AW	65	4
Cage Filler Panel Asbly	NT0X84AA		2
RLE Circuit cards			5
Cables			6

Provisioning Rules

AP = Always Provided

1 = Provide either common or earthquake framework.

2 = Determine how many RLE shelves are required based on each RLE shelf supporting 8 DS-30 links per plane.

3 = Provide one per frame

4 = Determine requirements for line testing and frame alarm scanning for remote frames.

5 = Refer to the System Component part for a layout of the RLE shelf. Provide enough DS-1 cards to support the DS-30 network ports for the LGCIs and MTMs. Each DS-30 port requires two DS-1 links. Work each shelf group from the outside in. Provide NT0X50AAs for unused slots.

6 = Following are the cables required:

NT0X26ZC - DS-30 between the RFLE and SLCC
(One cable per group of four DS-30 links)

NTNX36CK - With the RFLE, the DS-30 of the MTM is hard-wired to the FSP of the RFLE. Use this cable to connect the FSP (C03/C04) to the RLE shelf. When the DS-30 ports of MTM are not hard-wired, a kit (NTBX66WB) is provided so that the NTNX36CK can be used.

Use the NTNX36CL cable to connect the RLE shelf directly to the LGCI.

7 = Two NTBX5702s per NTBX5501 RLE shelf

8 = Contains two NT0X91AEs and two NT0X91AAs

Fig. 26 - RFLE Frame Provisioning Rules

10.04 In addition, the following rules are to be followed to determine RFLE requirements:

- * For each remote site calculate the number of ISDN lines using the same rules as for a host site, with 20 lines per drawer and limiting each LGCI to support 420 lines.
- * Determine the number of DS-30 ports required by multiplying the number of ISDN line cards by two B channels; D-channel traffic is routed to the Packet Handler from the Ds-1s of the LGCI.
- * Multiply the number of DS-30 ports by two to determine the number of DS-1 links required per network plane.

Printer and Personal Computer Interfaces

10.05 If the printer interface is to be used, two printers are required per RLE shelf. These printers can be at the host or remote site.

10.06 If the personal computer interface is used, one to four PCs can be used. Refer to Part 7 on page 43.

10.07 To comply with Isolated System Ground (ISG), use current loop converters on the cable from the Paddle Board (NTBX5702) to the printer. Figure 27 shows the configuration and order codes. Note that this equipment is duplicated for each NTB57AA if the system is to be ISG-compliant.




Fig. 27 - Connecting the NTB5702 (ISG Compliant)

EXAMPLE CONFIGURATIONS

10.08 Remember that because of the RLE configuration, the LGCI is limited to a maximum of eight C-side links per plane. Figure 28 on page 86 shows the overall configuration in terms of the number of links.




Fig. 28 - FRSC Link Configuration

Example 1

10.09 The following example shows how the FRSC could be provisioned. This is a non-blocking configuration, in order to highlight the capacity of the FRSC. The example assumes the following:

- * One RLE shelf of the HLE is fully configured.
- * One LGCI at one site is used
- * Eight duplicated DS-30 ports extended to the remote site
- * One DS-30 is dedicated to the MTM.

10.10 With this configuration, there are seven DS-30 links (32 channels each) available for call processing. Two of these seven links have seven messaging channels each, so,

$(32 \times 7) - (7 \times 2) = 224 - 14 = 210$ channels
210 channels are available for voice or circuit switched data

10.11 This means that this configuration can support 105 ISDN lines with no concentration.

Example 2

10.12 This example assumes the following:

- * Two RLE shelves of the HLE are fully configured.
- * One LGCI at one remote site is used
- * 16 duplicated DS-30 ports extended to the remote site
- * One DS-30 is dedicated to the MTM.

10.13 With this configuration, there are 15 DS-30 links (32 channels each) available for call processing. Two of these links have seven messaging channels each, so,

$(32 \times 15) - (7 \times 2) = 480 - 14 = 466$ channels
466 channels are available for voice or circuit switched data

10.14 This means that this configuration can support 233 ISDN lines with no concentration.

11. RESTRICTIONS/LIMITATIONS

ESA CAPABILITIES

11.01 Although the LGCI-LCMI configuration is located at a remote site, this configuration is not the same as the Remote Switching Center, which contains the Remote Cluster Controller (RCC). The RCC, which is not presently an ISDN-based peripheral, has the ability to process local calls should communication with the Host switch be cut off. The Fiber RSC does not have this capability.

SPECIFICATIONS OF THE FIBER TRANSPORT SYSTEM

11.02 The customer-provided DS-1 transport system must meet the following requirements:

- * A DS-1 interface that is compatible with:
 - Technical Advisory no. 34, "Interconnection Specification for Digital Cross Connects," October 1970, AT&T
 - Technical Advisory no. 42, "Digroup Terminal and Digital Interface Frame Technical Reference and Compatibility Specification," August 1981, AT&T
 - Figure 2-2, "Mask of Tolerable Sinusoidal Jitter and Wander," CCITT Recommendation, Q.503
 - * A delay of no greater than 220 microseconds measured from the host DS-1 interface of the RLE shelf of the HLE to the remote DS-1 interface at the RLE shelf of the RFLE
 - * A Bit Error Rate (BER) performance better than 1×10^{-9} bits.
- 11.03 Note that a system that meets these requirements is the FMT150, manufactured by Northern Telecom.

12. APPENDIX A - LISTING OF THE INSTALL.BAT BATCH FILE

12.01 Figure 29 shows the listing of the batch file "INSTALL.BAT". This batch file installs the FRSC OAM software onto the hard drive (C:) of a PC. The line numbers are just for reference and are not part of the batch file.

```
1 echo off
2 echo In order to install the FRSC OAM program, the files
3 echo "Autoexec.bat" and "Config.sys" should be in the root
4 echo directory of the C:\ drive. If these files do not
5 echo presently exist, they will be created for you.
6 echo These files should not be marked as "Hidden" files and
7 echo there should be no batch files executed within
8 echo "Autoexec.bat"
9 echo This install batch file creates a new directory on the
10 echo C: drive called "C:\OAM", and one subdirectory
11 echo within OAM called "C:\OAM\HELP". The program also
12 echo appends some commands to the "Autoexec.bat"
13 echo and "Config.sys" files.
14 pause
15 c:
16 cd c:
17 md oam
18 cd oam
19 copy a:main.exe
20 copy a:*.mnu
21 md help
22 cd help
23 copy a:*.hlp
24 cd c:\
25 copy c:\config.sys+a:config.dat c:\config.sys
26 copy c:\autoexec.bat+a: exec.dat c:\autoexec.bat
27 cls
28 echo Installation of the FRSC OAM system is now complete.
29 echo Please remove installation disk from drive A: and
30 echo re-boot the computer (ctrl-alt-del) to start the FRSC OAM
31 echo on
```

Fig. 29 - Listing of the Batch File

12.02 Figure 30 on page 90 shows the functions performed by these commands.

Line Description

-
- 1 Turns echo off to keep commands from going to the screen
 - 2-13 Displays a brief message on the screen. This message warns that if the files AUTOEXEC.BAT and CONFIG.SYS already exist on the PC hard drive (C:), they should be in the root dir (C:\). If they do not exist, they will be automatically created.
 - 14 This puts the message "Strike any key when ready . " on the display and waits for a keyhit before continuing.
 - 15 Changes the current drive to the hard disk (C:).
 - 16 Changes the current directory to the root directory (C:\).
 - 17 Creates the OAM subdirectory on the C: drive
 - 18 Goes to the new OAM subdirectory.
 - 19 Copies the OAM program (MAIN.EXE) to the OAM subdirectory.
 - 20 Copies the pop-up menu files (COMMAND.MNU, HELP.MNU) to the OAM subdirectory.
 - 21 Creates another subdirectory, HELP, underneath the subdirectory OAM.
 - 22 Goes to the new HELP subdirectory.
 - 23 Copies all of the text files used for on-line help system.
 - 24 Changes the directory back to the root (C:\).
 - 25 Appends the line "Files = 20" to the file "CONFIG.SYS". If CONFIG.SYS did not exist, it is created, containing only this one line. This command in CONFIG.SYS tells the system how many files can be opened simultaneously. The FRSC OAM program opens a log file for every port (up to 12) and also opens 3 files for program operation.
 - 26 Appends the lines "cd c:\oam" and "main.exe" to the file "AUTOEXEC.BAT". If AUTOEXEC.BAT did not exist, it is created containing only these two lines. When the PC starts up, this file is always executed first. By changing directories to OAM and executing MAIN.EXE, this makes the FRSC OAM program start automatically whenever the PC starts.
 - 27 Clears the screen.
 - 28- Tells the user that in order to start the FRSC OAM program, you must reboot the system.
 - 30
 - 31 Turns echo back on.

Fig. 30 - Command Functions of the Batch File

12.03 In summary, the INSTALL.BAT program creates two new subdirectories (OAM and HELP), copies the OAM program (MAIN.EXE) into the OAM subdirectory and the help files into the HELP subdirectory, updates CONFIG.SYS to allow for 20 simultaneously open files, and changes AUTOEXEC.BAT to make the OAM program execute automatically upon system start-up.

13. APPENDIX B - CONFIGURATION FORMS

13.01 The following is a list of information that should be captured during hardware installation of the FRSC OAM system. This information will be used to datafill the FRSC OAM program for a specific site.

1. Number of NTB56AA cards at the _____
Host and Remote sites (1 - 12)

(One HLE/RFLE shelf Combination: 4 cards)
(Two HLE/RFLE shelf Combination: 8 cards)
(Three HLE/RFLE shelf Combination: 12 cards)

2. Name for the Host site : _____
(Must be a unique and contain up to 8 characters)

3. Name for the Remote site : _____
(Must be a unique and contain up to 8 characters)

4. For each card: (1 - 12)
(Only fill out the same number of cards as answered in question 1)

Fig. 31 - Overall Configuration Form

NTBX56AA Card 1:

- A. Location (Host/Remote) : _____
- B. Far End Port (1 - 12) : _____
- C. DMS Network Plane (0/1) : _____
- D. Number of Network Links Supported (1 - 8) : _____

- E. Specific Network Link Numbers (From DMS Datafill) :
 - Link 0: _____ Link 4: _____
 - Link 1: _____ Link 5: _____
 - Link 2: _____ Link 6: _____
 - Link 3: _____ Link 7: _____

- F. DMS Frame Number (1 - 99) : _____

- G. DMS Shelf Position _____
(18: Bottom shelf, 32: Middle shelf,
51: Top shelf) :

- H. Port Log Filename _____
(Can contain up to 8 characters, such as P1.log)

NTBX56AA Card 2:

- A. Location (Host/Remote) : _____
- B. Far End Port (1 - 12) : _____
- C. DMS Network Plane (0/1) : _____
- D. Number of Network Links Supported (1 - 8) : _____

- E. Specific Network Link Numbers (From DMS Datafill) :
 - Link 0: _____ Link 4: _____
 - Link 1: _____ Link 5: _____
 - Link 2: _____ Link 6: _____
 - Link 3: _____ Link 7: _____

- F. DMS Frame Number (1 - 99) : _____

- G. DMS Shelf Position _____
(18: Bottom shelf, 32: Middle shelf,
51: Top shelf) :

- H. Port Log Filename _____
(Can contain up to 8 characters, such as P1.log)

Fig. 32 - NTBX56AA Cards One and Two

NTBX56AA Card 3:

-
- A. Location (Host/Remote) : _____
 - B. Far End Port (1 - 12) : _____
 - C. DMS Network Plane (0/1) : _____
 - D. Number of Network Links Supported (1 - 8) : _____
 - E. Specific Network Link Numbers (From DMS Datafill) :
 - Link 0: _____ Link 4: _____
 - Link 1: _____ Link 5: _____
 - Link 2: _____ Link 6: _____
 - Link 3: _____ Link 7: _____
 - F. DMS Frame Number (1 - 99) : _____
 - G. DMS Shelf Position
(18: Bottom, 32: Middle, 51: Top shelf) _____
 - H. Port Log Filename
(Can contain up to 8 characters, such as P1.log) _____

NTBX56AA Card 4:

-
- A. Location (Host/Remote) : _____
 - B. Far End Port (1 - 12) : _____
 - C. DMS Network Plane (0/1) : _____
 - D. Number of Network Links Supported (1 - 8) : _____
 - E. Specific Network Link Numbers (From DMS Datafill) :
 - Link 0: _____ Link 4: _____
 - Link 1: _____ Link 5: _____
 - Link 2: _____ Link 6: _____
 - Link 3: _____ Link 7: _____
 - F. DMS Frame Number (1 - 99) : _____
 - G. DMS Shelf Position
(18: Bottom shelf, 32: Middle shelf,
51: Top shelf) : _____
 - H. Port Log Filename
(Can contain up to 8 characters, such as P1.log) _____

Fig. 33 - NTBX56AA Cards Three and Four

NTBX56AA Card 5:

-
- A. Location (Host/Remote) : _____
 - B. Far End Port (1 - 12) : _____
 - C. DMS Network Plane (0/1) : _____
 - D. Number of Network Links Supported (1 - 8) : _____
 - E. Specific Network Link Numbers (From DMS Datafill) :

 Link 0: _____ Link 4: _____
 - Link 1: _____ Link 5: _____
 - Link 2: _____ Link 6: _____
 - Link 3: _____ Link 7: _____

 - F. DMS Frame Number (1 - 99) : _____

 - G. DMS Shelf Position _____
(18: Bottom shelf, 32: Middle shelf,
51: Top shelf) :

 - H. Port Log Filename _____
(Can contain up to 8 characters, such as P1.log)

NTBX56AA Card 6:

-
- A. Location (Host/Remote) : _____
 - B. Far End Port (1 - 12) : _____
 - C. DMS Network Plane (0/1) : _____
 - D. Number of Network Links Supported (1 - 8) : _____
 - E. Specific Network Link Numbers (From DMS Datafill) :

 Link 0: _____ Link 4: _____
 - Link 1: _____ Link 5: _____
 - Link 2: _____ Link 6: _____
 - Link 3: _____ Link 7: _____

 - F. DMS Frame Number (1 - 99) : _____

 - G. DMS Shelf Position _____
(18: Bottom shelf, 32: Middle shelf,
51: Top shelf) :

 - H. Port Log Filename _____
(Can contain up to 8 characters, such as P1.log)

Fig. 34 - NTBX56AA Cards Five and Six

NTBX56AA Card 7:

-
- A. Location (Host/Remote) : _____
 - B. Far End Port (1 - 12) : _____
 - C. DMS Network Plane (0/1) : _____
 - D. Number of Network Links Supported (1 - 8) : _____
 - E. Specific Network Link Numbers (From DMS Datafill) :
 - Link 0: _____ Link 4: _____
 - Link 1: _____ Link 5: _____
 - Link 2: _____ Link 6: _____
 - Link 3: _____ Link 7: _____
 - F. DMS Frame Number (1 - 99) : _____
 - G. DMS Shelf Position _____
(18: Bottom shelf, 32: Middle shelf,
51: Top shelf) :
 - H. Port Log Filename _____
(Can contain up to 8 characters, such as P1.log)

NTBX56AA Card 8:

-
- A. Location (Host/Remote) : _____
 - B. Far End Port (1 - 12) : _____
 - C. DMS Network Plane (0/1) : _____
 - D. Number of Network Links Supported (1 - 8) : _____
 - E. Specific Network Link Numbers (From DMS Datafill) :
 - Link 0: _____ Link 4: _____
 - Link 1: _____ Link 5: _____
 - Link 2: _____ Link 6: _____
 - Link 3: _____ Link 7: _____
 - F. DMS Frame Number (1 - 99) : _____
 - G. DMS Shelf Position _____
(18: Bottom shelf, 32: Middle shelf,
51: Top shelf) :
 - H. Port Log Filename _____
(Can contain up to 8 characters, such as P1.log)

Fig. 35 - NTBX56AA Cards Seven and Eight

NTBX56AA Card 9:

-
- A. Location (Host/Remote) : _____
 - B. Far End Port (1 - 12) : _____
 - C. DMS Network Plane (0/1) : _____
 - D. Number of Network Links Supported (1 - 8) : _____
 - E. Specific Network Link Numbers (From DMS Datafill) :
 - Link 0: _____ Link 4: _____
 - Link 1: _____ Link 5: _____
 - Link 2: _____ Link 6: _____
 - Link 3: _____ Link 7: _____
 - F. DMS Frame Number (1 - 99) : _____
 - G. DMS Shelf Position _____
(18: Bottom shelf, 32: Middle shelf,
51: Top shelf) :
 - H. Port Log Filename _____
(Can contain up to 8 characters, such as P1.log)

NTBX56AA Card 10:

-
- A. Location (Host/Remote) : _____
 - B. Far End Port (1 - 12) : _____
 - C. DMS Network Plane (0/1) : _____
 - D. Number of Network Links Supported (1 - 8) : _____
 - E. Specific Network Link Numbers (From DMS Datafill) :
 - Link 0: _____ Link 4: _____
 - Link 1: _____ Link 5: _____
 - Link 2: _____ Link 6: _____
 - Link 3: _____ Link 7: _____
 - F. DMS Frame Number (1 - 99) : _____
 - G. DMS Shelf Position _____
(18: Bottom shelf, 32: Middle shelf,
51: Top shelf) :
 - H. Port Log Filename _____
(Can contain up to 8 characters, such as P1.log)

Fig. 36 - NTBX56AA Cards Nine and Ten

NTBX56AA Card 11:

--

- A. Location (Host/Remote) : _____
- B. Far End Port (1 - 12) : _____
- C. DMS Network Plane (0/1) : _____
- D. Number of Network Links Supported (1 - 8) : _____
- E. Specific Network Link Numbers (From DMS Datafill) :
 - Link 0: _____ Link 4: _____
 - Link 1: _____ Link 5: _____
 - Link 2: _____ Link 6: _____
 - Link 3: _____ Link 7: _____
- F. DMS Frame Number (1 - 99) : _____
- G. DMS Shelf Position _____
(18: Bottom shelf, 32: Middle shelf,
51: Top shelf) :
- H. Port Log Filename _____
(Can contain up to 8 characters, such as P1.log)

NTBX56AA Card 12:

--

- A. Location (Host/Remote) : _____
- B. Far End Port (1 - 12) : _____
- C. DMS Network Plane (0/1) : _____
- D. Number of Network Links Supported (1 - 8) : _____
- E. Specific Network Link Numbers (From DMS Datafill) :
 - Link 0: _____ Link 4: _____
 - Link 1: _____ Link 5: _____
 - Link 2: _____ Link 6: _____
 - Link 3: _____ Link 7: _____
- F. DMS Frame Number (1 - 99) : _____
- G. DMS Shelf Position _____
(18: Bottom shelf, 32: Middle shelf,
51: Top shelf) :
- H. Port Log Filename _____
(Can contain up to 8 characters, such as P1.log)

Fig. 37 - NTBX56AA Cards 11 and 12
