

35 TRANSMITTER DISTRIBUTOR

ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	2	Main Bail Trip Assembly	
2. ADJUSTMENTS	4	Locking bail spring	16
Clutch Mechanism		Main bail	16
Clutch shoe lever spring	5	Signal Contact Assembly	
Clutch shoe spring	5	Signal contact	20
Clutch Trip Magnet Assembly		Signal contact link spring	20
Armature bail spring	23	Signal contact spring.	20
Clutch magnet assembly	21,22	Signal Pulse Refinement (Strobe).	26,27
Main bail latch spring	23	Start-Stop Switch Assembly	
Clutch Trip Mechanism		Start-stop switch bracket.	14
Clutch latchlever spring	6	Tight-tape intermediate arm	14
Clutch shoe lever	6	Tight-tape intermediate arm spring.	14
Clutch trip lever	6	Tight-tape start-stop contact spring	14
Clutch trip lever spring.	6	Tape Guide Mounting Plate	
Code Sensing Fingers		Replacing and positioning tape guide- plate	9
Feed wheel detent.	17	Tape Guideplate	
Sensing finger spring	17	Tape lid	7
Cover Assemblies		Tape guide	8
Removing coverplate.	4	Tape Lid Assembly	
Removing front panel	4	Coverplate detent spring	24
Removing tape guideplate.	4	Tape lid release button spring	24
Removing top plate.	4	Tape lid spring	24
Removing transmitter distributor assembly	4	Tape-Out Contact Mechanism	
Feed Pawl Mechanism		Tape-out contact assembly.	12
Feed pawl	18	Tape-out contact bracket.	12
Feed pawl spring	18	Tape-out sensing pin spring.	12
Transfer lever spring.	18	Tape-Out Sensing Pin Mechanism	
Gold-Plated Signal Contacts		Depressor bail torsion spring.	13
Cleaning	28	Intermediate tape-out bail spring	13
Servicing for low-voltage applications.	28	Tape-out sensing pin.	13
Main Bail Assembly			
Feed ratchet detent spring.	15		
Main bail spring.	15		
Main bail trip lever	15		
Start-stop lever detent spring.	15		

CONTENTS	PAGE
Top Plate and Coverplate Mounting	
Replacing and positioning top plate . .	10
Replacing and positioning coverplate . .	11
Transfer Bail Stabilizer Mechanism	
Stabilizer spring	19
Transfer bail stabilizer	19
Transmitter Distributor Gear	
Transmitter distributor gear	25
3. VARIABLE FEATURES	26
Auxiliary Contact Assembly	
Initial Adjustments	
Normally open contact spring	39
Normally open contact stiffener	39
Swinger	39
Secondary Adjustment	
Contact bracket	40
Contact assembly	40
Operating bail spring	40
Final Adjustment (Strobing)	
Contact bracket	41
Auxiliary Contact Assembly (35E Unit Only)	
Final Adjustment (Strobing)	
Contact bracket	43
Code Reading Contacts	
Initial Adjustments	
Normally closed contacts — backstop	35
Normally closed contacts — spring tension	35
Normally open contacts — backstop . .	35
Normally open contacts — spring tension	35
Secondary Adjustments	
Contact assembly	36
Contact bracket	36
Eccentric upstop	37
Sensing arm spring	37
Split bail eccentric	37
Final Adjustments (Strobing)	
Contact bracket	38

CONTENTS	PAGE
Code Reading Contacts (35E Units Only)	
Final Adjustment (Strobing)	
Contact bracket	42
Rubout Sensing Mechanism	
Rubout sensing mechanism	34
Timing bail spring	34
Timing Contact Mechanism (Late Design)	
Cam follower spring	30
Timing contact alignment	30
Timing contact bracket (preliminary) . .	31
Timing contact gap	30
Timing contact spring	31
Timing Contact Refinement	
Timing contact requirements (strobe)	32, 33
Timing Contact Mechanism (Early Design)	
Cam follower spring	29
Timing contact bracket	29
Timing contact spring	29
Timing contact swinger	29

1. GENERAL

1.01 This section provides adjustment information for the 35 transmitter distributor (Figure 1). It is reissued to include recent engineering changes, additional information on the timing contact mechanism, code reading assembly, auxiliary contact assembly, and the adjustment requirements. Since this is a general revision, marginal arrows ordinarily used to indicate changes and additions are omitted.

1.02 This section contains the requirements and adjusting procedures for the maintenance of the 35 transmitter distributor.

1.03 The adjustment of the 35 transmitter distributor is arranged in a sequence that would be followed if a complete readjustment of the unit were undertaken.

1.04 When an adjustment is completed, tighten loosened nuts or screws.

- 1.05 The covers may be removed for inspection and minor repair of the unit.

CAUTION: DISCONNECT THE UNIT FROM ITS POWER SOURCE AS A SAFETY PRECAUTION WHEN MORE EXTENSIVE MAINTENANCE IS UNDERTAKEN.

- 1.06 The adjusting illustrations indicate adjusting tolerances, positions of moving parts, spring tensions, and angle at which to apply the scale when measuring spring tensions.


- 1.07 If a part mounted on shims is removed, the number of shims used at each of its mounting screws should be noted so that shim pile-up may be replaced when part is remounted.

- 1.08 If parts or assemblies are removed for readjustment and subsequently replaced, recheck any adjustment that may have been affected by removal of these parts or assemblies.

- 1.09 The spring tensions given in this section are indications (not exact values) and should be checked with proper spring scales in the position indicated. Replace springs which do not meet the requirements and for which no adjusting procedure is given.

- 1.10 References made to left or right, up or down, front or rear, etc, apply to the unit in its normal operating position as viewed from the operator's position.

- 1.11 When a requirement calls for the clutch to be disengaged, the clutch shoe lever must be fully latched between its trip lever and latchlever so that the clutch shoes release their tension on the clutch drum. To accomplish this, rotate the main shaft by hand until the clutch reaches its stop position, then apply a screwdriver to the cam disc stop-lug and push the disc in its normal direction of shaft rotation until the latchlever seats in its notch in the disc.



(Right Front View)

Figure 1 - 35 Transmitter Distributor

2. ADJUSTMENTS

2.01 Cover Assemblies

(A) REMOVING FRONT PANEL

Pull outward on lower right and left rear corner of front panel and slide panel toward the front. Replace in reverse order.

(B) REMOVING COVERPLATE

Lift left end of coverplate to disengage detents then slide plate toward the left to disengage spring plate. Replace in reverse order.

(C) REMOVING TOP PLATE


With front and rear mounting screws loosened (do not disturb mounting nuts) and tape lid raised, lift plate upward. Refer to 2.07 when replacing the plate.

(D) REMOVING TAPE GUIDEPLATE

With front and rear mounting screws loosened (do not disturb mounting nuts) and tape lid raised, lift plate upward. Refer to 2.04 when replacing the plate.

(E) REMOVING TRANSMITTER DISTRIBUTOR ASSEMBLY

Remove right and left mounting screws attached to base and lift assembly upward to disengage main shaft gear. Transmitter is equipped with plug that mates with connector in base. After unit is plugged in, insert mounting screws (3). Check alignment of main shaft gear with driving gear. Refer to 2.22.




2.02 Clutch Mechanism

Note 1: Adjustments (A) and (B) should not be disturbed unless associated mechanisms have been removed for servicing or there is reason to believe that the requirements are not met.


Note 2: Remove transmitter distributor from its base prior to adjustment. See 2.01 (E).

(A) CLUTCH SHOE LEVER SPRING



Requirement
With clutch engaged, hold cam disc to prevent turning.
Min 15 oz --- Max 20 oz
to move shoe lever in contact with stop-lug.

To Measure
Invert unit. Rotate main shaft until clutch shoe lever and stop-lug are up.



(B) CLUTCH SHOE SPRING

Requirement
With clutch drum removed, hook spring scale as shown
Min 3 oz --- Max 5 oz
to start primary shoe moving away from secondary shoe at point of contact.

SECTION 574-225-700

2.03 Clutch Trip Mechanism

Note: Remove transmitter distributor from its base prior to adjustment. See 2.01 (E).

(C) CLUTCH LATCHLEVER SPRING


Requirement

Clutch engaged and rotated until latch-lever is on low part of disc
 Min 3 oz --- Max 5-1/2 oz
 to start latch moving.

(D) CLUTCH TRIP LEVER SPRING

Requirement

With clutch engaged
 Min 7 oz --- Max 10-1/2 oz
 to start clutch trip lever moving.



(B) CLUTCH SHOE LEVER

Requirement

Clearance as shown should be
 Min 0.055 inch --- Max 0.085 inch
 greater with clutch engaged* than with clutch disengaged.
 * (Pull shoe lever with force of 32 oz and release slowly to engage clutch shoes.)

To Adjust

With clutch disc clampscrews loosened, place wrench over stop-lug and move disc. Tighten clampscrews.

(A) CLUTCH TRIP LEVER

(1) Requirement

(Remove coverplate, 2.01.)
 With clutch disc stop-lug opposite clutch trip lever, clearance between inner surface of lug and lever, play taken up to make clearance maximum
 Min 0.012 inch --- Max 0.025 inch

To Adjust


Loosen clamp nut on clutch trip bail eccentric (friction tight) and rotate eccentric to its lowest point. Position eccentric to meet requirement. Tighten clamp nut.

(2) Requirement

Play taken up to make clearance minimum
 Some clearance

To Adjust

Refine (1) Requirement.



2.04 Tape Guideplate

(A) TAPE LID

Note 1: Remove top and tape guideplates, lubricate prior to adjustment.

(1) Requirement (Preliminary)

With tape lid held against notch in top guideplate

- (a) Feed wheel groove in tape lid should align with slot in plate.
- (b) Hole in tape lid for tape-out pin should align with hole in plate. (Gauge by eye.)
- (c) Clearance between pivot shoulder and tape lid
Min some---Max 0.010 inch

To Adjust

With tape lid bracket mounting nuts (2) loosened, insert tip of TP170283 gauge through slot and into groove of lid; position tape lid bracket. Retighten nuts.

(2) Requirement

Tape lid front bearing surface, A, should touch tape guideplate. Clearance, B, measured at fin of tape lid which is in line with rear tape guide. (See Note 3.)

Min 0.010 inch---Max 0.018 inch For fixed width tape guides

Min 0.015 inch---Max 0.018 inch For variable width tape guides

Note 2: When both plates are assembled on unit, left edge of lid may touch top plate and some change in this clearance may be expected.

To Adjust


With tape lid bearing bracket mounting screws friction tight and tape lid pressed against tape guideplate, position bearing bracket. Recheck (1) Requirement. Tighten screws.

(3) Requirement

Release button should have some endplay when lid is latched against tape guideplate.

To Adjust

With eccentric mounting post locknut friction tight and tape lid raised, rotate high part of eccentric toward tape guideplate. Close lid and rotate eccentric toward bracket until latch just falls under flat on post. Recheck by depressing button. With lid held down, tip of latch should clear post as button is operated. Tighten locknut.



2.05 Tape Guideplate (continued)

(B) TAPE GUIDE

(1) Requirement

With tape gauge positioned as shown, clearance between right and left tape guide and gauge



Min some---Max 0.003 inch

(2) Requirement


Edge of wear plate should be flush with edge of tape guideplate.

To Adjust

With each tape guide mounting nut friction tight, move wear plate upward until it overhangs edge of tape guideplate. Place gauge in position and move gauge and wear plate downward until both studs engage edge of tape guideplate to align common edge. Hold gauge and wear plate and position each guide. (Gauge may touch but not bind.) The tape should not ride on the side of either tape guide. Tighten nuts.



2.06 Tape Guide Mounting Plate

REPLACING AND POSITIONING TAPE GUIDEPLATE

Note: Position tape-out sensing pin stop arm (2.10) in its lowest position and hold start stop bail extension from ratchet wheel.

- (1) Requirement
Shoulder of feed wheel post should not interfere with top plate or tape guideplate mounting brackets.
To Adjust
See Note. With feed wheel bearing post clamp nut friction tight, position the post. Tighten clamp nut.
- (2) Requirement
Tape guideplate should rest firmly against at least three projections of front and rear plate.
To Adjust
See Note. With clamp nut that secures tape guideplate mounting bracket (front and rear) friction tight, trip clutch, and rotate shaft until sensing pins are in their uppermost position. With tape lid raised and start-stop lever in RUN position, press guideplate into position while guiding mounting screws into notch of front and rear plate. Engage tip of tape-out pin with hole in tape guideplate.
- (3) Requirement
Outer edge of front and rear mounting bracket should be located flush with shoulder of mounting stud so that edge of tape guideplate projects over front and rear plate by an equal amount. Gauge by eye. See 2.21.
To Adjust
Move tape guideplate toward the front or rear. Tighten nuts only after top plate (2.07) is adjusted.

2.07 Top Plate and Coverplate Mounting

REPLACING AND POSITIONING TOP PLATE

To Check

Loosen nuts (friction tight) that secure mounting screws to plate. Press top plate into position while guiding top plate mounting screws into notch of front and rear plate. Position each sensing pin in its slot. Make sure that top plate seats firmly against projections of front and rear plate (3 projections should engage) and tight-tape arm extension is under top plate.

(1) Requirement

Mating edge of top plate should be flush to 0.003 under flush with edge of tape guideplate (within area of tape lid) when plate engages at least 5 projections.

To Adjust

Position top plate, tighten mounting screws, and then tighten nuts that secure tape guideplate mounting brackets (2.06).

(2) Requirement

Feed wheel slot should align with slot in tape guideplate so that feed wheel rotates freely with detents and feed pawl disengaged (freewheeling).

To Adjust

Position top plate toward front or rear to align slot.


(3) Requirement

Clearance between projection of tape lid and top plate (tape lid latched)

Min 0.010 inch---Max 0.020 inch at curved portion	} For fixed width tape guides
Min 0.010 inch---Max 0.018 inch at flat portion	
Min 0.015 inch---Max 0.018 inch at flat portion	

To Adjust

If necessary, loosen tape lid bearing bracket mounting screw (2.04) and position tape lid. Retighten screws and recheck requirements in 2.04.




2.08 Top Plate and Coverplate Mounting (continued)

REPLACING AND POSITIONING COVERPLATE

- (1) Requirement
Right edge of coverplate should be held flush against left edge of top plate by the coverplate detents.
- (2) Requirement
Coverplate should rest against at least three of the four projections (front and rear plate).
- (3) Requirement
Front edge of coverplate and top plate should align.

To Adjust

With detenting nut clampscrew (front and rear plate) friction tight, move clampscrews to their extreme lower right position then tighten screws. Loosen detent bracket and spring plate mounting nuts. Place cover on unit and position horizontally to meet the requirements. Retighten mounting nuts.



2.09 Tape-Out Contact Mechanism

TAPE-OUT CONTACT ASSEMBLY

(1) Requirement

Coverplate and top plate removed; start-stop lever in STOP position; removal of tape guideplate optional. With tape-out spring bracket friction tight, move bracket downward until tape-out pin extension clears insulated portion of contact swinger. With gram scale applied as shown

Min 8 grams---Max 15 grams
to separate normally closed contacts.

To Adjust

Remove bail spring and contact assembly. Form the contact swinger with the TP110445 spring bender.

(2) Requirement


Clearance between normally open contacts

Min 0.008 inch---Max 0.015 inch

To Adjust

Form upper contact spring using the TP110445 spring bender.

Note: Replace contact assembly with swinger over tape-out pin extension. Place spring bracket shoulder bushing on upper hole and the washer on lower mounting hole. Tighten screws.



TAPE-OUT CONTACT BRACKET

Requirement

With tape-out pin depressed by tape under tape lid, clearance between tape-out pin extension and insulator on swinger contact

Min 0.006 inch---Max 0.020inch

To Adjust

Position switch bracket with its mounting screws loosened. Tighten screws.

TAPE-OUT SENSING PIN SPRING

Requirement

With start-stop lever in RUN position

Min 38 grams---Max 45 grams
to move pin to a position flush with tape guideplate.

To Adjust

With contact bracket lower mounting screw loosened position the spring bracket. Tighten screws.

2.10 Tape-Out Sensing Pin Mechanism

TAPE-OUT SENSING PIN

(1) Requirement

With start-stop lever in **FREE** wheeling or **STOP** position, tip of tape-out pin should be flush to 0.010 inch under flush below top surface of tape guideplate.

To Adjust


Place start-stop lever in **STOP** position. With stop arm clampscrew friction tight, position the stop arm. Tighten clampscrew.

(2) Requirement

With start-stop lever in **RUN** position, clearance as shown should be at least 0.055 inch.

To Adjust

Place start-stop lever in **RUN** position and loosen tape-out bail clampscrew. Position extension arm with tommy wrench or similar tool. Tighten clampscrew. Recheck (1) Requirement.



DEPRESSOR BAIL TORSION SPRING

Requirement

Tape-out bail spring unhooked. Start-stop lever in **STOP** position
 Min 2-3/4 oz --- Max 5-1/2 oz
 to start intermediate tape-out bail moving away from tape-out pin depressor bail.

INTERMEDIATE TAPE-OUT BAIL SPRING

Requirement

With start-stop lever in its **RUN** position, hook spring scale in loop.
 Min 3 oz --- Max 5 oz
 to pull spring to its installed length.

2.11 Start-Stop Switch Assembly

(A) START-STOP SWITCH BRACKET

(1) Requirement

With start-stop lever in RUN position and clutch in its disengaged position, clearance between start-stop bail extension and insulator on start-stop switch swinger
 Min 0.006 inch---Max 0.015 inch

To Adjust


With switch bracket mounting screws loosened, position the bracket. Tighten screws.

(2) Requirement

Start-stop bail extension should fully engage insulated portion of switch swinger.

To Adjust

Loosen contact pile-up mounting screws and align contact assembly. Tighten screws.



(B) TIGHT-TAPE START-STOP CONTACT SPRING

Requirement

With start-stop lever in RUN position
 Min 3 oz---Max 4 oz.
 to separate contacts.

To Adjust

Form swinger with TP110445 spring bender.

Note: Recheck Adjustments (A) and (C).

(C) TIGHT-TAPE INTERMEDIATE ARM

Requirement

With start-stop lever in RUN position, tight tape start-stop contacts should function as follows.

(a) Remain closed when tight tape bail is raised 0.045 inch.

(b) Open as bail is raised to height of 0.075 inch.


To Adjust

With tight-tape intermediate arm clamp-screw loosened, position the arm at its adjusting slot. Tighten clamp-screw.


(D) TIGHT-TAPE INTERMEDIATE ARM SPRING

Requirement

With start-stop lever in RUN position,
 Min 20 grams (3/4 oz)---Max 40 grams (1-1/2 oz)
 to start intermediate arm moving away from its yield arm.



2.12 Main Bail Assembly



(C) START-STOP LEVER DETENT SPRING
(Not on relay controlled unit)

Requirement

Start-stop lever in RUN position
— Min 14 oz ---Max 22 oz
to start detent bail moving away from start-stop lever detent.

(D) MAIN BAIL TRIP LEVER

Requirement (Replace top plate)

Unit in stop position, clearance between tip of highest sensing pin and top surface of tape guideplate should be flush to 0.005 inch below.


To Adjust

With clutch disengaged, loosen front and rear transfer lever guide eccentric post locknuts. Position highest point of eccentric post (as indicated by dot on end of post) toward left and rotate post so that its eccentric positions trip lever. Tighten locknuts.

(B) FEED RATCHET DETENT SPRING

Requirement

With main shaft in stop position and feed pawl held away from its ratchet
— Min 8 oz ---Max 13 oz
to start roller moving away from ratchet.



(A) MAIN BAIL SPRING

Requirement (Top plate removed)

Clutch disengaged, unit on its back. Spring unhooked from main bail
— Min 6 oz ---Max 10 oz
to pull spring to installed length.

2.13 Main Bail Trip Assembly


(A) MAIN BAIL

Requirement

Main bail in lowest position, horizontal clearance between main bail arm and main bail latchlever should be
 Min some---Max 0.015 inch

To Adjust

Position main bail eccentric screw with nut on eccentric screw loosened (and high part of eccentric screw to the right). Tighten nut. Check and refine, if necessary, MAIN BAIL TRIP LEVER (2.12).



(B) LOCKING BAIL SPRING

Requirement

With unit tilted toward the left and in stop position
 Min 10 oz---Max 14 oz
 to start bail moving.


2.14 Code Sensing Fingers

(A) SENSING FINGER SPRING

Requirement

Unit in upright position, sensing fingers in their uppermost position, and rubout delete bail (if present) held away from the sensing finger

Min 2 oz---Max 3 oz
to move a sensing finger to a position flush with the tape guideplate.




(Top View)

(B) FEED WHEEL DETENT

Requirement

With tape lid raised, sensing fingers down, high part of feed wheel detent eccentric toward the right, rubout perforated tape toward the right, and play in tape taken up lightly toward the right. Tip of each sensing finger should be centrally located in the code holes.



(Rear View)

To Adjust

Hold feed pawl away and position feed wheel detent eccentric screw with nut on eccentric screw friction tight. Tighten nut. See figure of 2.12.

2.15 Feed Pawl Mechanism

(A) FEED PAWL

Requirement (Top plate removed)

With high part of eccentric toward the right and sensing fingers in their lowermost position, clearance between feed pawl and ratchet tooth just engaged.

Min some---Max 0.003 inch

To Adjust

With eccentric screw locknut loosened, position the screw. Tighten locknut.


Recheck requirement at four positions of ratchet approximately 90 degrees apart. Replace top plate.

(B) FEED PAWL SPRING

Requirement

With unit tilted toward the left and main shaft in its stop position

Min 2 oz---Max 3-1/2 oz to start pawl moving.



(C) TRANSFER LEVER SPRING

Requirement

With unit resting on its rear plate and main shaft in its stop position

Min 1/2 oz---Max 1-1/2 oz to start each lever moving.

2.16 Transfer Bail Stabilizer Mechanism

(A) TRANSFER BAIL STABILIZER


Requirement

- (a) With the RUBOUT combination selected, rotate main shaft until no. 3 transfer lever is on high part of its cam. Check clearance between side of transfer bail extension and its latch.
- (b) Repeat above procedure with a NULL combination selected and check the clearance on other latch. Clearance in marking and spacing position should be equal within 0.002 inch.

To Adjust

With stabilizer assembly mounting screws friction tight, position the assembly. Tighten screws.

Note: Latches should drop in place as other transfer levers cam the transfer bail. Where possible, use a signal checking device to refine this adjustment following SIGNAL CONTACT (2.17).

(B) STABILIZER SPRING

Requirement

With unit upright and main shaft in stop position
 Min 2-1/2 oz---Max 5 oz
 to start stabilizer latch moving.

2.17 Signal Contact Assembly

(A) SIGNAL CONTACT


Requirement (Coverplate and contact box cover removed)

Contact gap in the marking position and the spacing position should be equal when clearance between respective contacts is maximum. (Engage clutch and rotate main shaft slowly.)

To Adjust

With contact box mounting screws friction tight, position box with its eccentric. Tighten screws.

Note: Use TEST SET (1B) to refine adjustment. Refer to 2.23



(B) SIGNAL CONTACT SPRING

Requirement

With main shaft in stop position and cover of contact box removed, unhook toggle link spring and move transfer bail to spacing position (right)

Min 2 oz --- Max 3-1/2 oz
to open spacing contacts (left).

(C) SIGNAL CONTACT LINK SPRING

Requirement

With main shaft in stop position and stabilizer spring unhooked, move latches away from transfer bail extension (2.16). Hold toggle firmly against contacts.

Min 6 oz --- Max 12 oz
to start transfer bail extension moving.

2.18 Clutch Trip Magnet Assembly

CLUTCH MAGNET ASSEMBLY — PRELIMINARY

(1) Requirement

In energized position armature should contact top core face and should have

Min some---Max 0.004 inch

clearance at bottom core face at point of least clearance when play is taken up to make clearance a maximum.

To Adjust

Remove magnet bracket mounting screws and magnet assembly from unit. Loosen two screws on bottom of magnet assembly and position mounting hinge until required condition is obtained. Tighten screws.


(2) Requirement

With high part of eccentric toward top of assembly, clearance between armature bail and eccentric backstop when armature is held in energized position should be

Min 0.045 inch---Max 0.055 inch

To Adjust

Loosen eccentric backstop screw clamp nut. With high part of eccentric toward top of assembly, position screw. Tighten clamp nut.



(Rear View)

2.19 Clutch Trip Magnet Assembly (continued)

CLUTCH MAGNET ASSEMBLY — PRELIMINARY (Continued)

(3) Requirement

With magnet assembly replaced and clutch disengaged, clearance between end of armature bail extension and main bail latch

— Min 0.007 inch---Max 0.015 inch


With clutch magnet armature in attracted position, clearance between vertical surfaces of main bail and its latchlever

Min some (See 2.20)

To Adjust

With magnet bracket mounting screws friction tight, move bracket to its lowermost position, then position bracket by means of adjusting lug on bracket (visible through hole in rear plate). Tighten screws. Refine requirements if necessary.

Note: The above adjustments may be considered final unless ac power is used, a check should be made to insure that the chatter is at a minimum. If excessive chatter is present, Requirement (1) will have to be refined and Requirements (2) and (3) rechecked.




2.20 Clutch Trip Magnet Assembly (continued)

ARMATURE BAIL SPRING

Requirement

With armature in de-energized position and main bail latchlever held away from the armature bail extension

Min 1 oz---Max 2 oz
to start armature moving.



MAIN BAIL LATCH SPRING

Requirement

With unit inverted and main bail latch released

Min 3/4 oz---Max 2 oz
to start main bail latch moving.

2.21 Tape Lid Assembly


(A) COVERPLATE DETENT SPRING

Requirement

With spring scale applied to center of one detent

Min 28 oz---Max 40 oz
to start plunger moving.

Note: Outer edge of each mounting bracket should be approximately in line with shoulder of its mounting stud. Replace tape guideplate, tape-out tension spring, top plate, and coverplate.




(B) TAPE LID RELEASE BUTTON SPRING

Requirement

With tape guideplate held horizontally and tape lid unlatched

Min 28 oz---Max 48 oz
to start tape lid bail moving.



(C) TAPE LID SPRING

Requirement

With tape lid release button held fully depressed and tape guideplate in horizontal position

Min 2-1/2 oz---Max 4-1/2 oz
to move open end of tape lid against the guideplate.

2.22 Transmitter Distributor Gear


TRANSMITTER DISTRIBUTOR GEAR

Requirement


There should be only a perceptible amount of backlash between the intermediate drive gear and transmitter distributor gear. Rotate gears 360 degrees and check every 90 degrees to take care of any gear eccentricity or shaft wobble.

To Adjust

With transmitter distributor mounting screws (3) loosened, position the unit on base. Tighten screws.



2.23 Signal Pulse Refinement



CAUTION: ON ALL UNITS EQUIPPED WITH A SIGNAL REGENERATOR CIRCUIT, REMOVE THE SIGNAL REGENERATOR CARD BEFORE APPLYING TEST SET (1B) TIMING PROBES TO CONTACT ACCESS TERMINALS. FOR SIGNAL GENERATORS EQUIPPED WITH ARC SUPPRESSORS, THE ARC SUPPRESSOR SHOULD BE DISCONNECTED WHEN SIGNAL IS BEING CHECKED. FOR SIGNAL GENERATORS EQUIPPED WITH FILTER NETWORK CIRCUIT CARDS, THE FILTER NETWORK CIRCUIT CARD SHOULD BE REMOVED WHEN THE SIGNAL IS BEING CHECKED.

SIGNAL PULSE REFINEMENT — FINAL ADJUSTMENT WITH TEST SET (1B) OR STROBE
(11.0 Unit Code - Speeds up to and including 100 wpm)

Procedure

Plug signal distortion test set into signal line to view pulse image generated by the marking and spacing contacts. Synchronize signal generator with TEST SET (1B) so that end of stop pulse image aligns with the 200 mark on TEST SET (1B) scale when both units are operated at same speed and transmission is continuous.

Note 1: Figures appearing in () in 2.23 and 2.24 are relaxed requirements for transmitter distributor sets used in circuits that employ a signal regenerator.

Note 2: End of stop pulse image should not vary from the 200 mark by more than one scale division. If a greater variation occurs, move the scale until the variations extend equally on either side of the 200 mark.

(1) Requirement

- (a) Each marking code pulse should start no later than the 8th (12th) mark of the pulse under observation and start no earlier than 92nd (88th) mark of the previous pulse.
- (b) Each marking code pulse should end no earlier than the 92nd (88th) mark of the pulse under observation and no later than the 8th (12th) mark of the following pulse.
- (c) Each marking code pulse may have one break provided the break is not over three divisions wide and provided the break occurs only at the end of the code pulse image between the 92nd (88th) mark and the end of the image.
- (d) The stop pulse should start no earlier than the 92nd (88th) mark of the last intelligence pulse and start no later than the 8th (12th) mark of the stop position.

2.24 Signal Pulse Refinement (continued)

- (e) The stop image should not change in length or position, when viewed on TEST SET (1B), to exceed one division while changing from R to Y selection (or equivalent codes). If necessary, reorient 200 mark on stop scale with end of stop pulse image.

To Adjust

With signal contact box mounting screws friction tight, rotate the eccentric (right or left). Tighten mounting screws and recheck adjustment.

(2) Requirement

When the spacing contact of the signal generator is wired the spacing contact should meet the following requirements.

- (a) Each spacing code pulse should start no later than the 8th (12th) mark of the pulse under observation and start no earlier than the 92nd (88th) mark of the previous pulse.
- (b) Each spacing pulse should end no earlier than the 92nd (88th) mark of the pulse under observation and end no later than the 8th (12th) mark of the following pulse.
- (c) Each spacing pulse may have one break provided the break is not over three divisions wide and provided the break occurs only at the end of the code pulse image between the 92nd (88th) mark and the end of the image.
- (d) The start pulse should start no earlier than the 192nd (188th) mark of the stop pulse and start no later than the 8th (12th) mark of the start pulse. The start pulse should end no earlier than the 92nd (88th) mark of the start pulse and end no later than the 8th (12th) mark of the number one pulse.

To Adjust

Same as above. Recheck marking contact if a spacing adjustment is made.

Note 3: If the signal requirements cannot be met, refine TRANSMITTER DISTRIBUTOR GEAR (2.22) and TRANSFER BAIL STABILIZER (2.16) with signal viewed on TEST SET (1B).

SECTION 574-225-700

2.25 Gold-Plated Signal Contacts

(A) Units may have signal contacts made of either unplated or gold-plated tungsten. If in doubt as to the type of contacts, remove signal generator cover and inspect contacts for gold plating.

(B) Cleaning

- (1) Use twill jean cloth (KS2423, TP107162) to clean gold-plated contacts.
- (2) Open contacts. Drop strip of twill jean between them. Close contacts. Draw twill jean part way through. Open contacts and withdraw twill jean.
- (3) This procedure prevents small fibres at edges of twill jean strip from becoming lodged between contacts.
- (4) Clean unplated tungsten contacts in accordance with standard procedures.

(C) Servicing for Low-Voltage Applications

- (1) For standard applications including those with data sets, observe standard maintenance procedures and intervals. Low-voltage applications are covered below.
- (2) The recommended cleaning interval for gold plated contacts in special low level applications (less than 250 microwatts) having an average weekly use of 60 hours should not exceed 90 days. This interval may be reduced, dependent on the signal circuit configuration, usage, and environment. Contacts should be cleaned as described in (B) Cleaning, above.

Note 1: Applying operating voltage of standard TEST SET (1B) directly to contacts may damage gold plating and impair low-voltage operation. When electrically adjusting or testing contacts (2.17) use an intermediate device, keyed by the contacts, to interrupt current to stroboscopic lamp of test set. This intermediate device must be capable of being keyed by a 3- to 20-volt change at maximum of 20 milliamperes.

Note 2: Normally for low-voltage applications contacts should be used in circuits operating between 3 and 20 volts dc at a current level not to exceed 60 milliamperes. Between 20 and 70 volts dc the current should be adjusted so as not to exceed a 120 milliwatt power level. The contacts are not normally intended for use on voltages above 70 volts dc. Exceeding this level for an appreciable length of time may result in damage to gold plating and make them unfit for low-voltage applications.

Note 3: The above information also applies to 2.17, 2.23, and 2.24 of this section.

3. VARIABLE FEATURES

3.01 Timing Contact Mechanism (Early Design)


(C) TIMING CONTACT SPRING

Requirement

Min 5 oz ---Max 8 oz
to move spring from stiffener.

To Adjust

Remove contact bracket assembly, loosen contact pile-up mounting screws and bend contact spring with bender (TP110445). Retighten pile-up mounting screws and check. Replace contact bracket assembly. Refine adjustments (A) and (B), if necessary.



(D) CAM FOLLOWER SPRING

Requirement

With unit in stop position and timing contact swinger held away
Min 2 oz ---Max 4 oz
to start the cam follower moving.

(A) TIMING CONTACT BRACKET

(1) Requirement

With follower on low part of cam contacts should be closed when nylon pad is raised 0.006 inch and open when pad is raised 0.010 inch.

(2) Requirement

With follower on any peak of cam, contact gap should be
Min 0.003 inch
on units prior to serial No. 42200
Min 0.015 inch

(B) TIMING CONTACT SWINGER

Requirement

With contact closed
Min 2 oz ---Max 3 oz
to just separate contacts

To Adjust

Bend swinger with spring bender TP110445.

To Adjust

Place unit in stop position. Adjust contact bracket by means of screwdriver lug, visible through hole in rear plate, with bracket mounting screws loosened. Tighten screws.


3.02 Timing Contact Mechanism (Late Design)

Note: The timing contact assembly must be removed to check the following requirements.

(A) CAM FOLLOWER SPRING

Requirement

With the unit upright and in the stop position, it should require
Min 2 oz ---Max 4 oz
to start the cam follower moving.




(B) TIMING CONTACT ALIGNMENT

Requirement

The contact points should be in line and the head of the plunger should be centered in the hole in the lower contact spring as gauged by eye.

To Adjust

With the contact assembly mounting screws friction tight, position the contact springs. Tighten screws firmly.



(C) TIMING CONTACT GAP

Requirement

With the plunger depressed flush with the bushing, the contact gap should be
Min 0.045 inch ---Max 0.065 inch

To Adjust

Bend the lower contact spring.

(Rear View)

3.03 Timing Contact Mechanism (Late Design)

TIMING CONTACT SPRING


Requirement

Min 3-1/2 oz --- Max 4-1/2 oz
to open the normally closed contacts.

To Adjust

Bend the contact swinger.

Note: Replace the timing contact assembly at this time.



TIMING CONTACT BRACKET — PRELIMINARY



(1) Requirement

With the unit in the stop position
Min 0.008 inch --- Max 0.011 inch
gap between the contacts.

(2) Requirement

With cam follower on each low
part of cam and clearance taken
up between plunger and cam
follower.

Min some --- clearance between
plunger and contact swinger.



(Rear View)

To Adjust


With unit in the indicated position and the timing contact bracket mounting screw and contact adjusting clamp nut friction tight, position the contact assembly by means of the eccentric to meet Requirements (1) and (2). Tighten the mounting screw and eccentric clamp nut and recheck the adjustments.

Related Adjustment

TIMING CONTACT REQUIREMENTS (3.04)

3.04 Timing Contact Refinement

**CAUTION: ON ALL UNITS
EQUIPPED WITH A SIGNAL
REGENERATOR CIRCUIT,
REMOVE THE SIGNAL
REGENERATOR CARD
BEFORE APPLYING
TEST SET (1B)
TIMING PROBES
TO CONTACT
ACCESS
TERMINALS.**



TIMING CONTACT REQUIREMENTS (STROBE) (Using TEST SET (1B))

- (1) Zero the test set as previously described (2.23).
- (2) The light image of the timing contacts should meet the following requirements for speeds up to and including 100 wpm.
 - (a) Open for a minimum of 20 divisions between the 25 division and 75 division points of each 100 division pulse.
Open for a minimum of 120 divisions between the 25 division and 175 division points of the stop pulse.
 - (b) The close to open transitions should be in multiples of 100 divisions ± 5 divisions from the close to open transition of the start pulse.
 - (c) There should be no contact break between the 0 division point and the close to open transition point and no contact break between the 75 division point and 100 division point of each pulse. There should be no contact break between 175 division point and the 200 division point of the stop pulse.

3.05 Timing Contact Refinement (continued)

- (d) Check and refine, if necessary, TIMING CONTACT BRACKET (3.01) for early design, or TIMING CONTACT BRACKET-PRELIMINARY (3.03) for later design.
- (e) The timing contacts should be open in the rest position of the transmitter distributor.

To adjust, loosen the two timing contact bracket mounting screws until they are friction tight. Position the timing contact assembly by means of the screwdriver lug on the bracket visible through a hole in the rear plate so that the requirements are met. Tighten the screws and recheck the image on the TEST SET (1B) stroboscope.

3.06 Rubout Sensing Mechanism

(A) RUBOUT SENSING MECHANISM

Requirement

With RUBOUT code combination selected and timing bail on low part of its cam, the start-stop contact gap should be


Min 0.018 inch---Max 0.025 inch

Use light thumb pressure to hold bail against its cam when checking gap.

To Adjust

Position the timing arm on the yield arm with its clampscrew friction tight.

Tighten screws.



(B) TIMING BAIL SPRING

Requirement

Min 5-1/2 oz ---Max 8 oz
to start the bail moving, when
clutch is disengaged.

3.07 Code Reading Contacts

Initial Adjustments

Note: Initial adjustments should be made with the code reading contact assembly removed from the transmitter unit.



(A) NORMALLY CLOSED CONTACTS — BACKSTOP

Requirement



The lower contact leaves for all levels should be parallel to the mounting plate and in line with one another.

To Adjust

Bend backstop to meet requirement.



UPPER CONTACT LEAF



(B) NORMALLY CLOSED CONTACTS — SPRING TENSION

(1) Requirement

With swinger held away
Min 2 oz---Max 6 oz

to move lower contact leaf away from backstop.

To Adjust

Bend lower leaf. If it is necessary to bend backstop to obtain required tension, reposition backstop to meet NORMALLY CLOSED CONTACTS — BACKSTOP adjustment.

(2) Requirement

Min 30 grams---Max 40 grams
to open normally closed contacts.

To Adjust

Bend swinger.

(C) NORMALLY OPEN CONTACTS — BACKSTOP

Requirement

Min 0.010 inch---Max 0.015 inch
gap between normally open contacts.

To Adjust

Bend associated backstop to meet requirement.

(D) NORMALLY OPEN CONTACTS — SPRING TENSION

Requirement

Min 30 grams---Max 40 grams
to move normally open contacts away from backstop.

To Adjust

Bend upper contact leaf. If it is necessary to bend backstop to obtain required tension, reposition backstop to meet NORMALLY OPEN CONTACTS — BACKSTOP adjustment.

3.08 Code Reading Contacts (continued)

Secondary Adjustments

Note: The secondary adjustments should be made with the code reading contact assembly installed in the transmitter, and with the contact assembly bracket approximately centered in its adjustment range.


(A) CONTACT ASSEMBLY

Requirement

The swinger of each contact pile-up should be aligned with its associated sensing arm, as gauged by eye.

To Adjust

Loosen the screws which mount the contact assembly to the contact bracket, and position the assembly to meet requirement. Tighten screws.




(B) CONTACT BRACKET

Requirement

With the NULL combination selected and the upstop post out of the way
 Min 0.015 inch---Max 0.025 inch
 gap between contact assembly swingers and insulator on contact sensing arm.

To Adjust

Loosen the contact bracket mounting screws ((A) CONTACT ASSEMBLY) and position the bracket to meet requirements. Tighten screws.



3.09 Code Reading Contacts (continued)

Secondary Adjustments (continued)

(A) ECCENTRIC UPSTOP


Requirement

With RUBOUT combination selected, clutch engaged, and main shaft rotated until the sensing arms are in their uppermost position, there should be

Min some---Max 0.008 inch clearance between the upper contact leaf and its backstop.

To Adjust

Loosen the nut that secures the eccentric upstop to the front plate and turn the eccentric until the requirement is satisfied. The high part of the eccentric should be toward left. Tighten nut.



(B) SENSING ARM SPRING

Requirement

With clutch disengaged
Min 2-1/2 oz---Max 3-1/2 oz
to start sensing arm moving.

(C) SPLIT BAIL ECCENTRIC


Requirement

With the NULL combination selected and clutch tripped, clearance between the transfer levers and associated sensing arms

Min 0.005 inch---Max 0.010 inch

To Adjust

Rotate the split bail eccentric with its locknut loosened. Tighten locknut.



SECTION 574-225-700

3.10 Code Reading Contacts (continued)

Final Adjustments (Strobing)

CONTACT BRACKET


Note 1: A TEST SET (1B) operating at 600 opm with an II unit code scale should be used for strobing.

- (1) Requirement
Code reading contact trace should begin at 95 +30 divisions in the no. 1 pulse and end at 5 +30 divisions in the no. 8 pulse and have a minimum pulse length of 550 divisions and a maximum pulse length of 670 divisions.
- (2) Requirement
Marking pulse breaks to be confined to first and last 10 scale divisions of trace.
- (3) Requirement
Spacing pulse (trace) length full scale trace without breaks.

To Adjust

Loosen the contact bracket mounting screws and position bracket to meet requirements. Tighten screws.


Note 2: If requirements cannot be met, recheck Initial and Secondary Adjustments and refine if necessary.



3.11 Auxiliary Contact Assembly

Initial Adjustments

Note: The initial adjustments should be made with the auxiliary contacts removed from the transmitter unit.



3.12 Auxiliary Contact Assembly (continued)

Secondary Adjustments

Note: The secondary adjustments should be made with the auxiliary contacts installed.

(A) CONTACT BRACKET

Requirement

With clutch disengaged and latched, clearance between the insulator on the swinger and the bail

Min 0.040 inch---Max 0.050 inch

To Adjust

Position the contact bracket with its mounting screws loosened. Tighten screws.


(B) CONTACT ASSEMBLY

Requirement

The swinger insulator should be centrally located with respect to its operating bail.

To Adjust

Loosen the contact assembly screws and position the swinger and contact springs. Tighten screws.



(C) OPERATING BAIL SPRING

Requirement

Clutch disengaged

Min 5 oz---Max 7 oz

to move follower roller away from low part of its cam.

3.13 Auxiliary Contact Assembly (continued)

Final Adjustment (Strobing)

CONTACT BRACKET

Note 1: A TEST SET (1B) operating at 600 opm with an II unit code scale should be used for strobing.


Requirement

Auxiliary contact trace should begin at 60 +25 divisions in the no. 2 pulse and end at 30 +25 divisions in the no. 7 pulse and have a minimum pulse length of 420 divisions and a maximum pulse length of 520 divisions.

To Adjust

Loosen the contact mounting bracket screws and position bracket to meet requirements. Tighten screws.

Note 2: If requirements cannot be met, recheck Initial and Secondary Adjustments.



SECTION 574-225-700

3.14 Code Reading Contacts (35E Unit Only)

Final Adjustment (Strobing)

CONTACT BRACKET

Note 1: A TEST SET (1B) operating at 600 opm with an 11 unit code scale should be used for strobing.


- (1) Requirement
Code reading contact trace should begin at 65 +20 divisions in the start pulse and end at 20 +20 divisions in the no. 8 pulse and have a minimum pulse length of 715 divisions and a maximum pulse length of 795 divisions.
- (2) Requirement
Marking pulse breaks of 6 divisions or less are permissible within allowable tolerance variations.
- (3) Requirement
Spacing pulse (trace) length, full scale trace without breaks.

To Adjust

Loosen the contact bracket mounting screws and position bracket to meet requirements. Tighten screws.

Note 2: If requirements cannot be met, recheck Initial and Secondary Adjustments and refine if necessary.

Note 3: This unit (35E) is wired for contacts 3 through 7 only.



3.15 Auxiliary Contact Assembly (35E Unit Only)

Final Adjustment (Strobing)

CONTACT BRACKET

Note: A TEST SET (1B) operating at 600 opm with an 11 unit code scale should be used for strobing.

(1) Requirement

The normally open auxiliary contact trace should begin at 15 +20 divisions in the no. 1 pulse and end at 75 +20 divisions of the no. 7 pulse and have a minimum pulse length of 620 divisions and a maximum pulse length of 700 divisions.

(2) Requirement

Marking pulse breaks of 6 divisions or less are permissible within allowable tolerance variations.

To Adjust

Loosen the contact mounting bracket screws and position bracket to meet requirements. Tighten screws.

