

SWITCHING SYSTEMS MANAGEMENT
NO. 1 ELECTRONIC SWITCHING SYSTEM
DATA ADMINISTRATION
QUARTER-HOUR MEASUREMENTS

CONTENTS	PAGE	Figures	CONTENTS	PAGE
1. GENERAL	1		1. Block Diagram of Quarter-Hour Output Messages	6
2. FIXED QUARTER-HOUR COUNT TC15	2		2. Output Message Format—TC15 (CTX-5 and CTX-6)	7
TC15 OUTPUT MESSAGE FORMAT	2		3. Output Message Format—TC15 (CTX-7)	9
INCLUSION OF TC15 ITEMS ON THE H OR C SCHEDULES	2		4. Output Message Format—TC15 (CTX-7 and CTX-8)	11
TC15 ACTIVATION	2		5. Output Message Format—TC15 (CTX-8)	14
3. SELECTED QUARTER-HOUR SCHEDULE (A) DA15	3		6. ESS 1400 Schedule A—Typical Entries	18
ESS 1400 FORM SCHEDULE A ASSIGNMENTS	3		7. Output Message Format—DA15	19
DA15 OUTPUT MESSAGE FORMAT	3		8. Output Message Format—SP15	20
DA15 ACTIVATION	3		9. Output Message Format—HL15	21
4. SIGNAL PROCESSOR QUARTER-HOUR COUNT SP15	4		1. GENERAL	
SP15 OUTPUT MESSAGE FORMAT	4		1.01 The quarter-hour measurements are blocks of 15 minute data printed on a teletypewriter (TTY) that gives machine status indications every 15 minutes, all day, every day. The network administrator is responsible for gathering and processing quarter-hour traffic data. This section describes the methods used to schedule, collect, and print out traffic data associated with the quarter-hour schedules including administrative recommendations for its use.	
SP15 ACTIVATION	4		1.02 When this section is reissued, the reason for reissue will be listed in this paragraph.	
5. HILO 4-WIRE NETWORK COUNT HL15	5			
HL15 OUTPUT MESSAGE FORMAT	5			
HL15 ACTIVATION	5			
6. ADMINISTRATIVE USE OF THE QUARTER-HOUR DATA	5			

NOTICE

Not for use or disclosure outside the
Bell System except under written agreement

SECTION 6i(5)

1.03 The title for each figure includes a number(s) in parentheses which identifies the paragraph(s) in which the figure is referenced.

1.04 Quarter-hour schedules permit network administrators to obtain data on selected traffic items at more frequent intervals than the hourly schedules provide. There are four quarter-hour schedules that provide the following traffic data.

- TC15 office counts and load measurements
- DA15 selected items from the H or C schedule
- SP15 signal processor heavy load condition indicators

Note: Later generics move these counts to the TC15 schedule.

- HL15 office counts and load measurements related to HILO 4-wire network operation.

1.05 The quarter-hour output messages have changed in number, size and content. Figure 1 contains a block diagram of quarter-hour messages to give an overview of these changes.

2. FIXED QUARTER-HOUR COUNT TC15

TC15 OUTPUT MESSAGE FORMAT

2.01 The TC15 output message is a fixed collection of selected 15-minute traffic counts. The counts collected on this schedule are moved to holding registers and may be added to totaling registers on each quarter-hour. These totaling registers accumulate totals for the hourly or the daily schedules. The accumulators from which the counts are taken are reset to zero when the data is transferred.

2.02 The TC15 output message formats for generic programs CTX-5 through CTX-8 are shown in Fig. 2, 3, 4, and 5.

INCLUSION OF TC15 ITEMS ON THE H OR C SCHEDULE

2.03 Most TC15 traffic items may be included in the hourly H and C schedules. Refer to DFMP, Division H, Section 6i(2), Data Administration—Hourly Measurements for assignment methods and recommendation.

2.04 The measurements listed below cannot be included in the C and H schedules.

- Peripheral order buffer queue peg count.
- Dial tone speed delays over 11 seconds.
- Code blocked calls.
- Trunk group control blocked calls.
- Signal processor trunk scan connections.
- Total number of times signal processor failed to complete all nonsupervisory work on time.
- Total number of times the signal processor failed to find an idle timed scan junior register.
- Total number of times the signal processor failed to find an idle bylink hit timing junior register.
- Total number of times the signal processor failed to find an idle bylink dialing junior register
- Total number of signal processor failures to find an idle bylink J-POB.

TC15 ACTIVATION

2.05 The printing of this schedule may be requested by the network administration or the maintenance TTY using the following input activate message:

LS-QUARTER-T,0N.

2.06 Response: These counts will continue to be printed every quarter-hour.

2.07 The request for terminating the printouts is made with the following input message:

LS-QUARTER-T,0F.

2.08 It is recommended that the TC15 be left in the *ON* state (activated).

2.09 The TC15 may also be activated by the system when any of the following conditions exist.

- The line load control is activated.
- An overload conditions exists (as determined by the program)
- Emergency action when call store memory is erased (CTX-4 and later generic programs).

3. SELECTED QUARTER-HOUR SCHEDULE (A) DA15

3.01 The selected quarter-hour schedule DA15 may consist of up to 50 traffic items selected from the H and C schedules. It is provided with CTX-7 and later generic programs. Set card SQHTC controls the size of the DA15 up to 50 traffic items.

3.02 This schedule permits network administrators to obtain data on selected traffic items at more frequent intervals than the normal schedules provide and to obtain data of particular interest without a complete H or C schedule printing. It is expected to be of use particularly in analyzing service problems and overload conditions.

ESS 1400 Form Schedule A Assignments

3.03 The DA15 schedule should include items which may require a closer surveillance such as:

- Customer digit receiver, transmitter and receiver overflows
- Call processing registers such as trunk to trunk memory and automatic message accounting (AMA) registers
- Any item that is critical in an office at any given time. Example: One junctor group is overloaded and requires a close surveillance.

3.04 Data will be entered on the DA15 schedule according to the No. 1 ESS 1400 Form schedule A assignments. All type measurement codes and equipment group or office count numbers that are valid for entry on the H and C schedules are valid on the DA15 schedule. Items entered on the selected DA15 schedule may be changed according to the procedure for changing items on

the H or C schedule. Refer to DFMP, Division H, Section 6i(2), for assignment entries.

3.05 In order to obtain meaningful counts on the DA15 schedule, the traffic items must be selected from those entered on the H and C schedules.

3.06 Each item entered on the DA15 schedule requires two corresponding call store words that serve as totaling and holding registers. At the end of each quarter-hour period, data is moved from the totaling register (which is then zeroed) to the holding register where it is available for requested printouts.

3.07 The number of DA15 measurements is determined by the quantity assigned on the schedule A, ESS 1400 Form. Including spare, the number may be a maximum of 50 (00 through 49).

3.08 Changes in this schedule are recent change hunted.

3.09 Refer to Fig. 6 for typical entries on the schedule A, ESS 1400 Form.

DA15 OUTPUT MESSAGE FORMAT

3.10 The DA15 output message is printed following the TC15 output message. It is printed in the same order as assigned on schedule A. Refer to Fig. 7 for an explanation of the DA15 output message format.

DA15 ACTIVATION

3.11 The printing of this schedule may be requested by the network administration or the maintenance TTY using the following input message:

LS-SEQU-0N.

3.12 Response is an immediate printout of the last clock quarter-hour counts. These counts will continue to be printed every quarter-hour.

3.13 The request for terminating the printouts is made with the following input message:

LS-SEQU-0F

SECTION 6i(5)

4. SIGNAL PROCESSOR QUARTER-HOUR COUNT SP15

4.01 The SP15 quarter-hour schedule provides counts to indicate when the signal processor is becoming overloaded. These messages may be used to monitor the call processing activities of the signal processor during heavy traffic or overloads. The complete schedule requires 20 seconds to print and contains 14 items (13 items in Issue 1 of CTX-7) printed on three lines. With CTX-7, Issue 8 and CTX-8, Issue 3 and later generic programs, the SP15 output message will be deleted and the SP counts will be included in the TC15 output message.

SP15 OUTPUT MESSAGE FORMAT

4.02 The format of the SP15 printout and an explanation of the counts is shown in Fig. 8. An explanation of each line is given in the next three paragraphs.

4.03 *SP BUSY* contains counts of deviations from the intended SP work schedule because of a heavy-load condition. The first count is the number of low priority nonsupervisory slips. The second count is the number of intervals between executions of this job which contained more than one low priority nonsupervisory slip. This count is zero in offices without incoming bylink. The third SP BUSY count indicates the number of times POB execution work is rescheduled. The fourth count of the SP BUSY line is the number of SP failures to complete high priority supervisory scanning work in their scheduled intervals.

4.04 *SP HOP OVFL* contains three counts and an indicator flag word. The first count is the number of line service request hopper overflows and trunk seizures. Second count is answer hopper overflows. The third item is a count of the number of hopper overflows that caused K-level (signal processor hopper overflow) interrupts in the central control. The fourth count is a flag word identifying which hoppers overflowed causing K-level interrupts recorded in the third count.

4.05 *SP REG OVFL* consists of decimal counts of failure to find certain registers and

J-POBs, and a peg count of incoming seizures. The counts are:

- Failures to find idle timed scan junior registers
- Failures to find idle step-by-step hit timing junior registers
- Failures to find idle step-by-step junior registers
- Failures to find idle step-by-step J-POBs
- Incoming bylink seizures.

High counts in the SP REG OVFL line may indicate underengineering of the corresponding registers.

SP15 ACTIVATION

4.06 The SP15 message can be requested from the network administration TTY with the following input messages.

- *SP-TRAF-TON.* = Print the SP15 message at 15 minute intervals until canceled.
- *SP-TRAF-TOF.* = Do not print the SP15 message unless a threshold is exceeded.

4.07 The SP15 message can be obtained every 15 minutes on either the maintenance or the network administration TTY after the input message has been typed.

4.08 The SP15 message will print automatically on both TTYs whenever certain SP thresholds are exceeded. The thresholds are:

- (a) Low priority nonsupervisory slips greater than or equal to 700.
- (b) Multiple low priority nonsupervisory slips between step-by-step (SXS) junior register processing greater than or equal to 0.
- (c) Failures to complete POB execution part 2 greater than or equal to 300.
- (d) Failures to complete high priority supervisory scan part 1 or part 2 greater than or equal to 180.

(e) SP attempts to scan lines when line scanning was off due to full line service request hopper greater than or equal to 1800.

(f) Failures to find idle step-by-step dialing junior registers greater than or equal to 0.

4.09 The maximum tolerable values for the SP15 counts have not yet been established. It is likely that the counts can become somewhat greater than the threshold values before service is measurably affected.

5. HILO 4-WIRE NETWORK COUNT HL15

HL15 OUTPUT MESSAGE FORMAT

5.01 Output message HL15 is a fixed collection of selected 15-minute traffic counts. It contains office counts and load measurements relating to the HILO 4-wire portion of a No. 1 ESS office.

5.02 The HL15 output message is available with CTX-8, Issue 4 but only when the HILO package is loaded. Refer to Fig. 9 for a description of the output message.

HL15 ACTIVATION

5.03 The HL15 will be activated when the TC15 is activated. It will print out with the TC15. The TC15 will print first and the HL15 will follow.

6. ADMINISTRATIVE USE OF THE QUARTER-HOUR DATA

6.01 Listed below are some of the purposes the quarter-hour data may be used.

- (1) Monitoring load service data
- (2) Analysis of load service problems
- (3) Providing data for call processing capacity determination
- (4) Monitoring abnormal traffic load conditions.

6.02 Data may be gathered from the TC15, SP15, and HL15 quarter-hour schedules as required. Traffic measurements not available on any of these schedules, but required for a specific data gathering situation, may be assigned on the DA15 via schedule A. However, the measurements assigned to the DA15 must also be assigned to the C or H schedule. Refer to Part 3 of this section for DA15 assignments.

6.03 Load-service data may require monitoring for the following reasons:


- (1) After a cutover or an addition
- (2) During a transition period
- (3) To monitor a load or service item that is near its limit.

6.04 Trouble analysis of load—service problems may be more readily identified using the quarter-hour data for the following reasons.

- (1) The item of data required to identify the trouble may only appear on the quarter-hour schedule.
- (2) Some severe traffic load peaks may be masked in the hourly measurements but become obvious in the quarter-hour data.
- (3) A quarter-hour may peak resulting in a service problem in some hour not normally monitored. This can be identified in the quarter-hour data because it collects data every 15 minutes, all day, every day.

6.05 Some of the quarter-hour data is used for determining the call capacity of the central control (CC) and signal processor (SP). Refer to DFMP, Division H, Section 6i(6), Data Administration, PATROL for capacity administration of the CC and SP.

6.06 The quarter-hour data is used to monitor adnormal traffic load conditions. Refer to DFMP, Division H, Section 6m, Abnormal Traffic/Load Conditions, for administrative procedures.



(RADR = Receiver Attachment Delay Reports)

Note 1: TC15 contains traffic load, overload, and service indicators.

Note 2: SP15 contains counts to indicate when the signal processor is becoming overloaded.

Note 3: DA15 contains up to 50 traffic items selected from the H or C schedule by the network administrator.

Note 4: SP15 is deleted and the SP counts are included in the TC15 output message.

Note 5: HILO and HL15 counts are available only when the HILO package is loaded.

Fig. 1—Block Diagram of Quarter-Hour Output Messages (1.05)

TC15 OUTPUT MESSAGE FORMAT (CTX-5 AND CTX-6 Generic Programs)

```

TC15 aaaaaa b      c
ddddd  eeeee  fffff  ggggg  hhhhh
iiii  jjjj  kkkkk  llll  mmmmm
nnnnn  ooooo  ppppp  rrrrr
    
```

EXPLANATION OF VARIABLE FIELD

All readings are for the last clock quarter-hour.

- aaaaaa = Office identification
- b = Originator of printout
 - M = Requested by maintenance TTY
 - T = Requested by traffic TTY
 - L = Requested by line load control program
 - Ø = Requested by overload program
 - = Can be any combination of above sources (MT, ØL, LØTM, etc)
- c = Cause of printout
 - CDPR = Customer dial pulse receive queue overflow
 - CTTR = Customer TOUCH-TONE receiver queue overflow
 - M = Multifrequency receiver queue overflow
 - RV = Revertive pulse receiver queue overflow
 - TT = Trunk combination TOUCH-TONE and dial pulse receiver queue overflow
 - DPR = Trunk dial pulse receiver queue overflow
 - MISC = There has been a system reinitialization within the last 15 minutes
No overflow exists

- ddddd = Total originating calls
- eeeeee = Total incoming calls
- fffff = Total incoming calls that have overflowed due to matching loss (IML)
- ggggg = Dial tone speed test initiations from dial pulse lines
- hhhhh = Dial tone speed test initiations from TOUCH-TONE lines
- iiii = Dial pulse line dial tone delays greater than 3 seconds
- jjjjj = TOUCH-TONE line dial tone delays greater than 3 seconds
- kkkkk = Total main program cycles (E-to-E)
- lllll = Line scan completion (in offices without a signal processor this count is always 000000)

Fig. 2—Output Message Format—TC15 (CTX-5 and CTX-6) (Sheet 1 of 2) (2.02)

SECTION 6i(5)

- mmmmmm** = POB queue peg count
- nnnnnn** = Dial tone delays, either dial pulse or TOUCH-TONE, greater than 11 seconds
- oooooo** = Peg count of signal processor trunk scan completions (See Note.)
- pppppp** = Total number of times the signal processor failed to complete POB execution within the allotted time (See Note.)
- rrrrrr** = Total number of signal processor failures to complete all nonsupervisory work within a 5-ms interval (See Note.)

Note: Available with CTX-6, Issue 8 (in offices without a signal processor this count will be 000000).

Fig. 2—Output Message Format—TC15 (CTX-5 and CTX-6) (Sheet 2 of 2) (2.02)

TC15 OUTPUT MESSAGE FORMAT (SP-CTX-7, Issue 1; CC-CTX-7 and Later Generic Programs)

TC15	aaaaaa	b	c	dd:dd	ee/ee
INC	TA	IO	DT	TT	OR
ffffff	hhhhh	jjjjj	lllll	nnnnnn	pppppp
gggggg	iiiiii	kkkkkk	mmmmm	oooooo	
EE/LS	POEX	RM	RD	RR	CB/TGC
qqqqqq	sssss	uuuuuu	wwwww	yyyyyy	222222
rrrrrr	ttttt	vvvvv	zzzzz	zzzzz	333333

EXPLANATION OF VARIABLE FIELDS

- aaaaaa = Office identification
- b = Originator of printout
 - M = Requested by maintenance TTY
 - T = Requested by traffic TTY
 - L = Requested by line load control program
 - Ø = Requested by overload program
 - = Can be any combination of above sources (MT, ØL, LOTM, etc)
- c = Cause of printout
 - CDPR = Customer dial pulse receiver queue overflow
 - CTTR = Customer TOUCH-TONE receiver queue overflow
 - MF = Multifrequency receiver queue overflow
 - RV = Revertive pulse receiver queue overflow
 - DP = Dial pulse receiver queue overflow
 - MISC = Other than receiver queue overflow
- dd:dd = Time of collect
- ee/ee = Date of collect
- ffffff = Total incoming calls
- gggggg = Incoming call first failure to match
- hhhhh = Total tandem calls
- iiiiii = Tandem calls first failure to match
- jjjjj = Total intraoffice calls
- kkkkkk = Intraoffice calls — overflow
- lllll = Dial tone speed test initiations from dial pulse lines

Fig. 3—Output Message Format—TC15 (CTX-7) (Sheet 1 of 2) (2.02)

SECTION 6i(5)

mmmmmm = Dial pulse line dial tone delays greater than 3 seconds
 nnnnnn = Dial tone speed test initiations from TOUCH-TONE lines
 oooooo = TOUCH-TONE line dial tone delays greater than 3 seconds
 pppppp = Total originating calls
 qqqqqq = Total main program cycles (E-to-E)
 rrrrrr = Line scan completions
 ssssss = POB queue
 tttttt = Dial tone delays, either dial pulse or TOUCH-TONE, greater than 11 seconds
 uuuuuu = Multifrequency receiver attachment tests
 vvvvvv = Multifrequency receiver attachment delays over 3 seconds.
 wwwwww = Dial pulse receiver attachment tests
 xxxxxx = Dial pulse receiver attachment delays over 3 seconds
 yyyyyy = Revertive pulse receiver attachment tests
 zzzzzz = Revertive pulse receiver attachment delays over 3 seconds
 222222 = Calls encountering network management code block controls
 333333 = Calls encountering network management trunk group controls
 0/0 0:00 = Month/date hour:quarter-hour

```

A 30 TC15 000222 T          14:30 5/25
      INC  TA      IO      DT      TT      OR
000091 000000 000036 000012 000022 000171
000000 000000 000000 000000 000000
EE/LS  PO/EX      RM      RD      RR      CB/TGC
010079 000008 000050 000000 000000 000000
043746 000000 000000 000000 000000 000000
  
```

Fig. 3—Output Message Format—TC15 (CTX-7) (Sheet 2 of 2) (2.02)

TC15 OUTPUT MESSAGE FORMAT (SP-CTX-7, Issue B; SP-CTX-8, Issue 3 and Later Generic Programs)

TC15	aaaaaa	b	c	dd:dd	ee/ee/ee
INC	TA	IO	DT	TT	OR
ffffff	hhhhh	jjjjj	lllll	nnnnn	ppppp
ggggg	iiii	kkkkk	mmmmm	ooooo	
EE/LS	PO/EX	RM	RD	RR	CB/TGC
qqqqq	sssss	uuuuu	wwwww	yyyyy	22222
rrrrr	ttttt	vvvvv	xxxxx	zzzzz	33333
TS/FS	PI/BLS	TR/HR	BJ/BP	LH/TH	KH/HOP
44444	66666	88888	<u>AAAAA</u>	<u>BBBBB</u>	<u>CCCCC</u>
55555	77777	99999	<u>DDDDD</u>	<u>EEEEEE</u>	<u>FFFFFFF</u>

EXPLANATION OF VARIABLE FIELDS

- aaaaaa = Office identification
- b = Originator of printout
 - M = Requested by maintenance TTY
 - T = Requested by traffic TTY
 - L = Requested by line load control program
 - Ø = Requested by overload program
 - = Can be any combination of above sources (MT, ØL, LØTM, etc)
- c = Cause of printout
 - CDPR = Customer dial pulse receiver queue overflow
 - CTTR = Customer TOUCH-TONE receiver queue overflow
 - MF = Multifrequency receiver queue overflow
 - RV = Revertive pulse receiver queue overflow
 - DP = Dial pulse receiver queue overflow
 - MISC = Other than receiver queue overflow
- dd:dd = Time of collect
- ee/ee = Date of collect
- ffffff = Total incoming calls
- ggggg = Incoming call first failure to match
- hhhhh = Total tandem calls
- iiii = Tandem calls first failure to match
- jjjjj = Total intraoffice calls
- kkkkk = Intraoffice calls — overflow
- lllll = Dial tone speed test initiations from dial pulse lines

Fig. 4—Output Message Format—TC15 (CTX-7 and CTX-8) (Sheet 1 of 3) (2.02)

SECTION 6i(5)

mmmmmm	= Dial pulse line dial tone delays greater than 3 seconds
nnnnnn	= Dial tone speed test initiations from TOUCH-TONE lines
oooooo	= TOUCH-TONE line dial tone delays greater than 3 seconds
pppppp	= Total originating calls
qqqqqq	= Total main program cycles (E-to-E)
rrrrrr	= Line scan completions
ssssss	= POB queue
tttttt	= Dial tone delays, either dial pulse or TOUCH-TONE, greater than 11 seconds
uuuuuu	= Multifrequency receiver attachment tests
vvvvvv	= Multifrequency receiver attachment delays over 3 seconds
wwwwww	= Dial pulse receiver attachment tests
xxxxxx	= Dial pulse receiver attachment delays over 3 seconds
yyyyyy	= Revertive pulse receiver attachment tests
zzzzzz	= Revertive pulse receiver attachment delays over 3 seconds
222222	= Calls encountering network management code block controls
333333	= Calls encountering network management trunk group controls
444444	= Total number of signal processor trunk scan completions
555555	= Total number of times the signal processor failed to complete all nonsupervisory work within a 5 msec interval
666666	= Total number of times the signal processor completed POB execution
777777	= Total incoming bylink seizures
888888	= Total number of times the signal process or failed to find an idle timed scan junior register
999999	= Total number of times the signal processor failed to find an idle bylink hit timing junior register
<u>AAAAAA</u>	= Total number of times the signal processor failed to find an idle bylink dialing junior register
<u>BBBBBB</u>	= Total number of line service request hopper overflows
<u>CCCCCC</u>	= Total number of all hopper overflows which caused K-level interrupts
<u>DDDDDD</u>	= Total number of signal processor failures to find an idle bylink J-POB
<u>EEEEEE</u>	= Total number of trunk seizure and answer hopper overflows
<u>FFFFFFF</u>	= Octal flag word indicating which hoppers overflowed adding to count CCCCCCC (Notes 1 and 2)

Fig. 4—Output Message Format—TC15 (CTX-7 and CTX-8) (Sheet 2 of 3) (2.02)

LS-QUAR-TON.OK

```

M 01 TC15 000222 T MISC 0:01 0/0
      INC      TA      IO      DT      TT      OR
      000004  000000  000002  000049  000127  000005
      000000  000000  000000  000000  000000
      EE/LS   PO/EX    RM      RD      RR      CB/TGO
      040005  000000  000000  000000  000000  000000
      101667  000000  000000  000000  000000  000000
      TS/FS   PI/BLS  TR/HR  BJ/BP  LH/TH  KH/HOP
      008933  035732  000000  000000  000000  000000
      000000  000000  000000  000000  000000  000000
    
```

Note 1: For CTX-7, Issue 9, generic program (nonsignal processor offices), the hopper overflow is not added to CCCCC. The octal flag work still indicates which hoppers overflowed.

Note 2: Layout of hopper overflow information flag word with corresponding parameter set card names for the hoppers.

BIT	HOPPER OVERFLOW INDICATION	PARAMETER SET CARD
0	MF digit reception hopper	MFH
1	Revertive pulsing digit reception hopper	RDH
2	Bylink reorder, abandon, and interdigital timing hopper	BLH
3	TOUCH-TONE digit reception hopper	TTH
4	Trunk dial pulse hopper	TDH
5	Customer dial pulse digit reception and abandon hopper	DPH
6	Release dial tone hopper	DTH
7	Revertive digit output pulsing hopper	RPH
8	Centrex key hopper	CTH
9	Miscellaneous scan hopper	MSH
10	Trunk dial pulse output pulsing hopper	DOH
11	Ringling trip hopper	RTH
12	Hit scan result hopper	HSH
13	Trunk seizure and answer hopper	TSH
14	Line ferrod disconnect hopper	LFH
16	TTY hopper	TYH
18	K-level interrupt hopper	KLH
21	Error found in one of the previously described hopper overflow reports by the overflow program	—

Fig. 4—Output Message Format—TC15 (CTX-7 and CTX-8) (Sheet 3 of 3) (2.02)

TC15 OUTPUT MESSAGE FORMAT (CTX-8, Issue 4)

TC15	aaaaaa	b	cd	ee:ee	ff/ff/ff			
INC	TA		IO		DT	TT		OR
gggggg	iiiiii		kkkkkk		mmmmmm	oooooo		qqqqqq
hhhhhh	jjjjjj		llllll		nnnnnn	pppppp		
EE/LS	PO/EX		RM		RD	RR		CB/TGC
rrrrrr	tttttt		vvvvvv		xxxxxx	zzzzzz		333333
ssssss	uuuuuu		wwwwww		yyyyyy	222222		444444
TS/FS	PI/BLS		TR/HR		BJ/BP	LH/TH		KH/HOP
555555	777777		999999		<u>BBBBBB</u>	<u>CCCCCC</u>		<u>DDDDDD</u>
666666	888888		<u>AAAAAA</u>		<u>EEEEEE</u>	<u>FFFFFF</u>		<u>GGGGGGGG</u>

EXPLANATION OF VARIABLE FIELDS

- aaaaaa = Office identification
- b = Originator of printout
 - M = Requested by maintenance TTY
 - T = Requested by traffic TTY
 - L = Requested by line load control program
 - Ø = Requested by overload program
 - = Can be any combination of above sources (MT, ØL, LOTM, etc)
- c = H if dddd is a HILO queue overflow
 - = Blank if dddd is a 2-wire queue overflow
- d = Cause of printout
 - CDPR = Customer dial pulse receiver queue overflow
 - CTTR = Customer TOUCH-TONE receiver queue overflow
 - MF = Multifrequency receiver queue overflow
 - RV = Revertive pulse receiver queue overflow
 - DP = Dial pulse receiver queue overflow
 - MISC = Other than receiver queue overflow
- ee:ee = Time of collect
- ff/ff/ff = Date of collect
- gggggg = Total incoming calls
- hhhhhh = Incoming call first failure to match
- iiiiii = Total tandem calls
- jjjjjj = Tandem calls first failure to match

Fig. 5—Output Message Format—TC15 (CTX-8) (Sheet 1 of 4) (2.02)

kkkkkk	= Total intraoffice calls
lllll	= Intraoffice calls — overflow
mmmmm	= Dial tone speed test initiations from dial pulse lines
nnnnn	= Dial pulse line dial tone delays greater than 3 seconds
ooooo	= Dial tone speed test initiations from TOUCH-TONE lines
ppppp	= TOUCH-TONE line dial tone delays greater than 3 seconds
qqqqq	= Total originating calls
rrrrr	= Total main program cycles (E-to-E)
sssss	= Line scan completions
ttttt	= POB queue
uuuuu	= Dial tone delays, either dial pulse or TOUCH-TONE, greater than 11 seconds
vvvvv	= Multifrequency receiver attachment tests
wwwww	= Multifrequency receiver attachment delays over 3 seconds
xxxxx	= Dial pulse receiver attachment tests
yyyyy	= Dial pulse receiver attachment delays over 3 seconds
zzzzz	= Revertive pulse receiver attachment tests
22222	= Revertive pulse receiver attachment delays over 3 seconds
33333	= Calls encountering network management code block controls (combined HILO and 2-wire)
44444	= Calls encountering network management trunk group controls (combined HILO and 2-wire)
55555	= Total number of trunk scan completions
66666	= Total number of failures to complete all nonsupervisory work within a 5 msec interval
77777	= Total number of times the POB execution was completed within the allotted time
88888	= Total incoming bylink seizures
99999	= Total number of failures to find an idle timed scan junior register
<u>AAAAA</u>	= Total number of times the signal processor failed to find an idle bylink hit timing junior register.
<u>BBBBB</u>	= Total number of times the signal processor failed to find an idle bylink dialing junior register
<u>CCCCC</u>	= Total number of line service request hopper overflows
<u>DDDDD</u>	= Total number of all hopper overflows which caused K-level interrupts
<u>EEEEEE</u>	= Total number of signal processor failures to find an idle bylink J-POB
<u>FFFFFFF</u>	= Total number of trunk seizure and answer hopper overflows
<u>GGGGGGG</u>	= Octal flag word indicating which hoppers overflowed. In offices with a signal processor, this count indicates which hoppers overflowed adding to count <u>DDDDD</u> (Note 1).

Fig. 5—Output Message Format—TC15 (CTX-8) (Sheet 2 of 4) (2.02)

LS-QUAR-TON.OK

```

M 01 TC15 000222 T MISC 0:01 0/0
      INC TA IO DT TT OR
      000004 000000 000002 000049 000127 000005
      000000 000000 000000 000000 000000
      EE/LS PO/EX RM RD RR CB/TGO
      040005 000000 000000 000000 000000 000000
      101667 000000 000000 000000 000000 000000
      TS/FS PI/BLS TR/HR BJ/BP LH/TH KH/HOP
      008933 935732 000000 000000 000000 000000
      000000 000000 000000 000000 000000 00000000
    
```

Note 1: Layout of hopper overflow information flag word with corresponding parameter set card names for the hoppers:

BIT	HOPPER OVERFLOW INDICATION	PARAMETER SET CARD
0	MF digit reception hopper	MFH
1	Revertive pulsing digit reception hopper	RDH
2	Bylink reorder, abandon, and interdigital timing hopper	BLH
3	TOUCH-TONE digit reception hopper	TTH
4	Trunk dial pulse hopper	TDH
5	Customer dial pulse digit reception and abandon hopper	DPH
6	Release dial tone hopper	DTH
7	Revertive digit output pulsing hopper	RPH
8	Centrex key hopper	CTH
9	Miscellaneous scan hopper	MSH
10	Trunk dial pulse output pulsing hopper	DOH
11	Ringing trip hopper	RTH
12	Hit scan result hopper	HSB
13	Trunk seizure and answer hopper	TSH
14	Line ferrod disconnect hopper	LFH
16	TTY hopper	TYH
18	K-level interrupt hopper	KLH
21	Error found in one of the previously described hopper overflow reports by the overflow program	—

Fig. 5—Output Message Format—TC15 (CTX-8) (Sheet 3 of 4) (2.02)

General Notes :

- (a) All counts contained in the message, unless stated otherwise, are 2-wire counts. Where noted, the counts are combined HILO and 2-wire.
- (b) In a combined HILO/2-wire office, all three sections of this message will be printed, when requested.
- (c) In a 2-wire only office, all three sections of this message will be printed.
- (d) In a HILO only office, only the third section of the message, beginning with the header TS/FS PI/BLS, etc, will be printed.

Fig. 5—Output Message Format—TC15 (CTX-8) (Sheet 4 of 4) (2.02)

DA15 OUTPUT MESSAGE FORMAT (CTX-7 AND LATER GENERIC PROGRAMS)

DA 15 aaa bb:bb:bb cc/cc dd:dd:dd ee/ee

ITM	TMC	EGO	CNT
f	ggg	hhhh	iiiiii
f	ggg	hhhh	iiiiii
f	ggg	hhhh	iiiiii
f	ggg	hhhh	iiiiii
f	ggg	hhhh	iiiiii
f	ggg	hhhh	iiiiii
f	ggg	hhhh	iiiiii
f	ggg	hhhh	iiiiii
f	ggg	hhhh	iiiiii
f	ggg	hhhh	iiiiii
f	ggg	hhhh	iiiiii

EXPLANATION OF VARIABLE FIELD

aaa = Office identifying number
bb:bb:bb = Time (hour:minute:second) of last collect
cc/cc = Date (month:day) of last collect
dd:dd:dd: = Time (hour:minute:second) of previous last collect
ee/ee = Date (month:day) of previous last collect
f = 0-49 = Number of traffic items appearance in list
ggg = Type measurement code
hhhh = Equipment, group, or office count number
iiiiii = Traffic count

Fig. 7—Output Message Format—DA15 (3.10)

SP15 OUTPUT MESSAGE FORMAT

```

      SP15 aaaaaa bbb cc:cc:cc dd/dd
SP BUSY      eeeeee ffffff gggggg      hhhhhh      iiiiii
SP HOP OVFL  jjjjjj kkkkkk mmmmmm      nnnnnnnn
SP REG OVFL  pppppp qqqqqq rrrrrr      ssssss      tttttt

```

EXPLANATION OF VARIABLE FIELD

aaaaaa = Office identifying number
 bbb = AUT — Requested automatically by traffic measurements program whenever certain counts in the SP15 message exceed threshold limits during the last quarter-hour
 = MAN — Requested manually that the SP15 message be printed each subsequent quarter until canceled.
 cc:cc:cc = Time of print. Data collected is for the last quarter-hour. (The counts eeeee through ttttt are described below).
 dd/dd = Date of print
 eeeee = SP low priority nonsupervisory slips
 fffff = Multiple low-priority nonsupervisory slips occurring during scheduled 30-millisecond intervals.
 (The scheduled 30-millisecond interval is delineated by the execution of the SXS pulse count junior register processor job.)
 ggggg = SP failures to complete POB execution part 2 during last quarter-hour
 hhhhh = SP failures to complete high priority supervisory scan work in its scheduled intervals.
 iiiii = SP attempts to scan lines when line scanning was turned off due to a full line service request hopper.
 jjjjj = Line service request hopper overflows.
 kkkkk = Trunk seizure and answer hopper overflows.
 mmmmm = Hopper overflows which caused K-level interrupts
 nnnnn = Octal flag word indicating which hoppers overflowed adding to count mmmmm.
 ppppp = SP failures to find an idle timed scan junior register.
 qqqqq = SP failures to find an idle bylink (SXS) hit timing junior register.
 rrrrr = SP failures to find an idle bylink (SXS) dialing junior register.
 sssss = SP failures to find an idle bylink (SXS) J-POB
 ttttt = Incoming bylink seizures

Note: The SP15 output message format was provided with CTX-7, Issue 1, generic program. With CTX-7, Issue 8, and CTX-8, Issue 3 and later generic programs, the SP15 will be deleted and the SP counts will be included in the TC15 output message.

Fig. 8—Output Message Format—SP15 (4.02)

HL15 OUTPUT MESSAGE FORMAT (CTX-8, Issue 4 and Later Generic Programs)

HL15	aaaaaa	b	c	dd:dd	ee/ee		
	INC	RM	RD		CB/TGC	EE/PO	TA
	ffffff	hhhhh	kkkkkk		mmmmmm	oooooo	rrrrrr
	gggggg	jjjjj	lllll		nnnnnn	pppppp	

EXPLANATION OF VARIABLE FIELD

- aaaaaa = Office identification
- b = Originator of printout
 - M = Requested by maintenance TTY
 - T = Requested by traffic TTY
 - L = Requested by line load control program
 - Ø = Requested by overload program
 - = Can be any combination of above sources (MT, ØL, LØTM, etc)
- c = Cause of printout
 - CDPR = Customer dial pulse receiver queue overflow
 - CTTR = Customer TOUCH-TONE receiver queue overflow
 - MF = Multifrequency receiver queue overflow
 - RV = Revertive pulse receiver queue overflow
 - DP = Dial pulse receiver queue overflow
 - HMF = HILO multifrequency receiver queue overflow
 - HRV = HILO revertive pulse receiver queue overflow
 - HDP = HILO trunk dial pulse receiver queue overflow
 - MISC = Other than receiver queue overflow
- dd:dd = Time of collect
- ee/ee = Date of collect
- ffffff = HILO incoming calls peg count
- gggggg = HILO incoming calls first failure to match
- hhhhh = HILO multifrequency receiver attachment delay report (RADR) test
- jjjjj = HILO multifrequency RADR test failures
- kkkkkk = HILO dial pulse RADR tests
- lllll = HILO dial pulse RADR test failures
- mmmmmm = Calls affected by network management code block controls
- nnnnnn = HILO calls affected by network management trunk group controls
- oooooo = E-E program cycles
- pppppp = POB queue peg count
- rrrrrr = HILO tandem call attempts

Fig. 9—Output Message Format—HL15 (5.02)