



**NORTEL**

Nortel Communication Server 1000

# Element Manager System Reference - Administration

Release: 6.0  
Document Revision: 03.20

[www.nortel.com](http://www.nortel.com)

---

NN43001-632

Nortel Communication Server 1000  
Release: 6.0  
Publication: NN43001-632  
Document release date: 23 March 2010

Copyright © 2010 Nortel Networks. All Rights Reserved.

While the information in this document is believed to be accurate and reliable, except as otherwise expressly agreed to in writing NORTEL PROVIDES THIS DOCUMENT "AS IS" WITHOUT WARRANTY OR CONDITION OF ANY KIND, EITHER EXPRESS OR IMPLIED. The information and/or products described in this document are subject to change without notice.

Nortel, Nortel Networks, the Nortel logo, and the Globemark are trademarks of Nortel Networks.

All other trademarks are the property of their respective owners.

---

# Contents

---

## **New in This Release** **9**

- Deployment changes 9
- Unified Communication Management 9
- Phone Provisioning 9
- Dialing Plan 10
- CLID-C: Enhance Override CLID Presentation Restriction 10
- FAXS Modem Pass Through 10
- Patching enhancements 10
- Fault Management (SNMP) 11
- MALT and VNR Enhancement 11
- Access Restriction 11
- TLS and SRTP Enhancements 12
- Unicode Name Directory 12
- Other 12
  - Revision History 12

---

## **How to get help** **15**

- Contents 15
- Getting help from the Nortel Web site 15
- Getting help over the telephone from a Nortel Solutions Center 15
- Getting help from a specialist by using an Express Routing Code 16
- Getting help through a Nortel distributor or reseller 16

---

## **Introduction** **17**

- Subject 17
- Applicable Systems 17
- Intended Audience 17
- Conventions 17
  - Terminology 17
  - Related information 17
  - Technical Documentation 18

---

## **Overview** **19**

- Contents 19
- Element Manager overview 19

---

Key features	21
Signaling Server	21
Call Server and Media Gateway	22
IP Line and Voice Gateway	22
<hr/>	
<b>How to use Element Manager</b>	<b>25</b>
Contents	25
Launching Element Manager	25
Navigation	26
Configuring data	29
Logging off	29
<hr/>	
<b>Links</b>	<b>31</b>
Contents	31
Introduction	31
Virtual Terminals	31
<hr/>	
<b>System</b>	<b>35</b>
Contents	35
Introduction	36
Events	36
Import Event Preference Table (EPT)	39
SNMP	40
Maintenance	42
Centralized Software Upgrade	53
Emergency Services Diagnostics	75
Loops	113
Superloops	116
MSDL/MSIP Cards	118
Conference/TDS/Multifrequency Cards	119
Tone Senders and Detectors	119
Digitone Receivers	120
Multi Frequency Receivers	121
Class Modem Units	122
Extended Dial Tone Detectors	124
Peripheral Equipment	126
<hr/>	
<b>IP Network</b>	<b>129</b>
Contents	129
Introduction	129
IP Network	129
IP Telephony Nodes	129
Add a new IP Telephony Node	132
Import IP Telephony Nodes file	133
Export IP Telephony Node file	136
Delete an IP Telephony Node	136

---

---

Node Details	136
Signaling Server commands	144
Meridian Alternate Routing and Vacant Number Routing Causes	148
Media Gateways	149
Adding an IPMG	150
Media Gateway configuration	152
Media Gateway configuration	152
Ethernet Diagnostics	154
Media Gateway Controller commands	155
Adding VGW channels	156
Deleting VGW channels	157
Digital Trunking for IPMG	158
MGC Report logs	160
32 Channel Secure Media Card (MC32S) commands	162
Report logs	163
Zones	164
Numbering Zones	173
Host and Route Tables	174
Network Address Translation (NAT)	175
Quality of Service Thresholds (QoS)	176
Personal Directories	179
Unicode Name Directory	179
Interfaces	180
Application Module Link	180
Value Added Server	182
Property Management System	184
Engineered Values	185
Emergency Services	189
Service Parameters	189
Access Numbers and Routing	190
Response Locations	195
Subnet Information	198
Dynamic ELIN	201
Virtual Office Phone	203
Database Replication Control	204
State Control	205
Software	206
Software	210

---

## **Customers, Routes and Trunks**

**215**

Contents	215
Introduction	215
Customers	215
Application Module Link	218

---

Attendant	219
Call Detail Recording	220
Call Party Name Display	220
Call Redirection	221
Centralized Attendant Service	224
Controlled Class of Service	225
Flexible Feature Codes	226
Features	230
Listed Directory Numbers	232
Mobile Service Directory Number	233
ISDN and ESN Networking	233
Night Service	236
Feature Packages	237
Intercept Treatments	240
Multi Party Operations	242
Recorded Overflow Announcement	242
SIP Line Service	243
Timers	243
Route and Trunk Configuration	244

---

## **Dialing and Numbering Plans** **263**

Contents	263
Introduction	263
Electronic Switched Network	263
Flexible Code Restriction	266
Incoming Digit Translation	269

---

## **Phones** **273**

Contents	273
Introduction	274
Limitations of deploying multiple Element Managers to manage a single Call Server	275
Feature Operation during Upgrade	275
Database Update	276
Station Fast Sync feature	277
Templates	278
Create a Template	279
Create a Template from an existing phone	280
View a Template	282
Update a Template	282
Delete a Template	282
Export and Import Templates	282
Search Phones	286
Program Phone Keys	289
Edit Phones	292

---

Edit single or multiple phones	292
Phone properties that can change without breaking the Template association	292
Employee reference field support when exporting and import phone database	293
Export and Import of employee reference field	293
Move Phones	298
Retrieve Phones	298
Delete Phones	300
Swap Phones	300
Courtesy Change	301
Reports	301
IP Attendant	302
Searching a 3260 phone	303
Adding a 3260 Phone	304
Editing a 3260 Phone	305
Deleting a 3260 Phone	306
Moving a 3260 Phone	306
Migration	307

---

## **Tools**

**309**

Contents	309
Introduction	309
Backup and Restore	309
Call Server Initialization	319
Call Server INI ACTIVE Command	320
Call Server INI INACTIVE Command	320
Call Server INI BOTH Command	320
Call Server SYSLOAD ACTIVE	321
Call Server SYSLOAD INACTIVE Command	321
Call Server SYSLOAD BOTH Command	322
Date and Time	322
System time synchronization options	323
System Date and Time	325
Current System Date and Time	326
Time Zone	328
Network Time Protocol	329
Network Time Synchronization	333
Logs and Reports	335
Call Server Report	336
Equipped Feature Packages	338
Peripheral Software Version Data	338
System License Parameters	339
Operational Measurements	340

<b>Security</b>	<b>349</b>
<b>Support</b>	<b>351</b>
Contents	351
Introduction	351
Help	351
Release Notes	352
<b>Appendix A</b>	<b>353</b>

---

## New in This Release

---

### Deployment changes

Element Manager (EM) for Communication Server 1000 Release 6.0 is available on Commercial Off The Shelf (COTS) and Linux based CP PM servers. The VxWorks based ISP1100 hardware is not supported in this release.

The move to COTS and Linux CP PM allows more flexibility to deploy only the applications you want on that hardware. This includes Element Manager.

### Unified Communication Management

Prior to this release, Element Manager (EM) could be deployed on VxWorks or on Linux based server with Enterprise Common Manager (ECM). In CS 1000 Release 6.0, ECM has been overhauled to provide a more comprehensive management solution. ECM is now Unified Communication Management (UCM) and provides the management for a number of elements. Element Manager, Networking Routing System Management, and Subscriber Manager all operate under UCM umbrella. With this release, Element Manager is only deployed as part of UCM.

For more information, see *Unified Communication Management* (NN43001-116).

### Phone Provisioning

Prior to this release Phone Provisioning was not available on a VxWorks system. With CS 1000 Release 6.0, Element Manager is only deployed on UCM, which provides all users access to Phone Provisioning. The following functional enhancements are additions to Phone Provisioning for this release:

- Graphical interface for Phone Key Programming.
- Terminal Number (TN) enhancements to provide the ability to span TNs beyond a single card.
- Support for employee reference in import/export of telephones.

- Ability to create a new telephone template from an existing telephone configuration.
- Export and Import for telephone templates.
- Ability to migrate phone data from Element Manager to Subscriber Manager.
- Publish additional telephone attributes in Subscriber Manager.
- Un-Marp DN of an account in Subscriber Manager

For more information about Subscriber Manager, refer to *Subscriber Manager Fundamentals* (NN43001-120).

## Dialing Plan

Element Manager provides a user interface for new commands and prompts for Zone Based Dialing and Zone Based Parameters. Two links are added in the existing Zones page of Element Manager. These two links lead to two new pages to configure a number of parameters using overlay LD 117. EM also provides options for every customer to enable the Dialing Plan feature. For more information refer to *Dialing Plans Reference* (NN43001-283).

## CLID-C: Enhance Override CLID Presentation Restriction

In CS 1000 Release 6.0, you can configure currently existing PII (Privacy Indicator Ignore) prompt for all the ISDN interfaces on the Route page of EM. A new AUXP (Auxiliary Application) prompt is introduced in overlay 16 (RDB) to enhance the ability of the system to honor or ignore the Privacy indicator for a Calling Party Privacy call for each incoming route.

## FAXS Modem Pass Through

The FAXS/Modem Pass Through adds support to existing telephone provisioning architecture with the introduction of new Class of Service Modem Pass Through on CS 1000 Release 6.0.

## Patching enhancements

Enhancements to the patching mechanism handles obsolete patches and provides a way to deliver special instructions for a patch during installation as part of the patch.

The technician is alerted that a patch has special instructions (for example INI required; other patch requirements; hardware specific requirements).

Some patches may depend on other patches to be in service before the most recent patch is activated.

## Fault Management (SNMP)

The concept of SNMP profiles is introduced with Communication Server 1000 Release 6.0. The SNMP Profile Manager page in Unified Communications Manager (UCM) provides a common interface for configuring SNMP parameters on all Communication Server 1000 Network Elements.

CS 1000 Release 6.0 introduces the following enhancements to SNMP:

- New commands in LD 117 and Element Manager for enabling or disabling the sending of traps for any network element
- Suppression of traps for network elements based on severity
- Ability to configure trap destination ports is extended to all elements

Configuration of SNMP by Element Manager at the system level propagates upward to the SNMP Profile Manager. Changes made in Element Manager apply to all CS 1000 elements.

## MALT and VNR Enhancement

The MALT (Meridian ALternate Routing) and Vacant Number Routing (VNR) Enhancement feature provides call clearing treatment for vacant number calls over IP domain. VNR is a default route used to route untranslated, invalid, or unassigned called numbers (dialed numbers, DN's).

With this feature, you can perform MALT on the Call Server for an additional 10 causes other than the existing six, when the call is routed by VNR to the IP network. You can configure these extra MALT causes in Element Manager. If the call is determined to be a VNR call which is tried at least once to route over an IP route, then the call receives vacant number treatment.

## Access Restriction

CS 1000 Access Restrictions prevents port-based attacks and user customizable IP filtering, starting with CS 1000 Release 6.0. The platforms that this feature applies to are MGC, MC32S, CPP4 and CP PM. The Signaling Server platform runs on Linux which has its own firewall, thus this feature is not relevant for that platform.

Port blocking is required by customers who need the capability to close off access to applications and other unused ports. Examples include closing down rlogin on the TLAN interface. A port blocker is required because the call server cannot close applications.

For information about Access Restriction in Element Manager, see *Security Management Fundamentals*(NN43001-604).

## TLS and SRTP Enhancements

Transport Layer Security (TLS) and SIP Real-Time Transport Protocol (SRTP) were implemented in CS 1000 release 5.0. CS 1000 Release 6.0 enhances the implementation to better meet the requirements of security conscious customers, and to better interoperate with third parties.

A new prompt **Enable Secure Media** is introduced under the Microsoft Unified Messaging section in EM.

## Unicode Name Directory

Unicode Name Directory is a server application storing the database of user names translated to various languages. This feature delivers a CPND capability in Unicode and can hold multiple Unicode names for each DN for a large enterprise customer. You can select a Unicode language preference to match the Unicode Name and Personal Directories. Subscriber Manager and Element Manager are both required when using Unicode Name Directory.

## Other

### Revision History

<b>March 2010</b>	Standard 03.20. This document is up-issued to remove unsupported content.
<b>October 2009</b>	Standard 03.19. This document is up-issued to support MG XPEC.
<b>June 2009</b>	Standard 03.18. This document is up-issued to provide information concerning deploying more than one Element Manager to manage a single Call Server and the effects on the EM Phone provisioning application and to provide a procedure for removing control M characters from TM configuration files.
<b>June 2009</b>	Standard 03.17. This document is up-issued to support Communication Server 1000 Release 6.0. This NTP may contain information on or refer to products and naming conventions that are not supported in this release. This information is included for legacy purposes and convenience only. This includes but is not limited to items, such as: SSC; ISP 1100; ITG Pentium cards; and Media Cards running certain IP Line applications.
<b>May 2009</b>	Standard 03.16. This document is up-issued to support Communication Server 1000 Release 6.0. This NTP may contain information on or refer to products and naming conventions that are not supported in this release. This information is included for legacy purposes and convenience only. This includes but is not limited to items, such as: SSC; ISP 1100; ITG Pentium cards; and Media Cards running certain IP Line applications.
<b>July 2008</b>	Standard 02.15. This document is up-issued to update the Station Fast Sync feature section.
<b>April 2008</b>	Standard 02.14. This document is up-issued to add patching information.
<b>March 2008</b>	Standard 02.12. This document is up-issued to add information about Zone 0 and CR Q01834961.

<b>February 2008</b>	Standard 02.11. This document is up-issued to reflect changes in technical content.
<b>January 2007</b>	Standard 02.10. This document is up-issued to reflect changes in technical content.
<b>December 2007</b>	Standard 02.09. This document is up-issued to support Communication Server 1000 Release 5.5.
<b>August 2007</b>	Standard 01.05. This document is up-issued to support Microsoft Exchange Server 2007 Unified Messaging.
<b>June 2007</b>	Standard 01.03. This document is up-issued for: (1) to specify that PDT access is required to access the Element Manager patching feature. (2) to indicate that the rows in the Excel spreadsheet must be completed sequentially. (3) to correct the graphic Digit Conversion Tree Configuration Web page. (4) to provide more information about QoS threshold values. (5) to correct the graphic Clock Controller Basic Properties Web page.
<b>May 2007</b>	Standard 01.01. This document is up-issued to support Communication Server 1000 Release 5.0. This document contains information previously contained in the following legacy document, now retired: Element Manager System Administration (553-3001-332).
<b>August 2005</b>	Standard 3.00. This document is up-issued to support Communication Server 1000 Release 4.5.
<b>September 2004</b>	Standard 2.00. This document is up-issued for Communication Server 1000 Release 4.0.
<b>October 2003</b>	Standard 1.00. This document is a new NTP for Succession 3.0. It was created to support a restructuring of the Documentation Library. This document contains information previously contained in the following legacy document, now retired: Element Management (553-3023-222). Some content from Element Management (553-3023-222) also appears in Succession 1000 Element Manager: Installation and Configuration (553-3001-232).



---

# How to get help

---

## Contents

This section contains information about the following topics:

- “Getting help from the Nortel Web site” (page 15)
- “Getting help over the telephone from a Nortel Solutions Center” (page 15)
- “Getting help from a specialist by using an Express Routing Code” (page 16)
- “Getting help through a Nortel distributor or reseller” (page 16)

## Getting help from the Nortel Web site

The best way to get technical support for Nortel products is from the Nortel Technical Support Web site:

[www.nortel.com/support](http://www.nortel.com/support)

This site provides quick access to software, documentation, bulletins, and tools to address issues with Nortel products. From this site, you can:

- download software, documentation, and product bulletins
- search the Technical Support Web site and the Nortel Knowledge Base for answers to technical issues
- sign up for automatic notification of new software and documentation for Nortel equipment
- open and manage technical support cases

## Getting help over the telephone from a Nortel Solutions Center

If you do not find the information you require on the Nortel Technical Support Web site, and you have a Nortel support contract, you can also get help over the telephone from a Nortel Solutions Center.

In North America, call 1-800-4NORTEL (1-800-466-7835).

Outside North America, go to the following Web site to obtain the telephone number for your region:

[www.nortel.com/callus](http://www.nortel.com/callus)

### **Getting help from a specialist by using an Express Routing Code**

To access some Nortel Technical Solutions Centers, you can use an Express Routing Code (ERC) to quickly route your call to a specialist in your Nortel product or service. To locate the ERC for your product or service, go to:

[www.nortel.com/erc](http://www.nortel.com/erc)

### **Getting help through a Nortel distributor or reseller**

If you purchased a service contract for your Nortel product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller.

---

# Introduction

---

This document is a global document. Contact your system supplier or your Nortel representative to verify that the hardware and software described are supported in your area.

## Subject

This document describes the Element Manager interface.

## Applicable Systems

This document applies to the following systems:

- Communication Server 1000M Single Group (CS 1000M SG)
- Communication Server 1000M Multi Group (CS 1000M MG)
- Communication Server 1000E (CS 1000E)

## Intended Audience

This document is intended for individuals responsible for administering CS 1000 and Meridian 1 systems.

## Conventions

### Terminology

In this document, the following systems are referred to generically as system:

- Communication Server 1000E (CS 1000E)
- Communication Server 1000M (CS 1000M)
- Meridian 1

## Related information

This section lists information sources that relate to this document.

## Technical Documentation

The following technical documents are referenced in this document:

- *Unified Communications Management Common Services Fundamentals* (NN43001-116)
- *Signaling Server IP Line Applications Fundamentals* (NN43001-125)
- *Network Routing Service Fundamentals* (NN43001-130)
- *SIP Line Fundamentals* (NN43001-508)
- *CP PM Co-resident Call Server and Signaling Server Fundamentals* (NN43001-509)
- *Subscriber Manager Fundamentals* (NN43001-120)
- *Transmission Parameters Reference* (NN43001-282)
- *Dialing Plans Reference* (NN43001-283)
- *Security Management Fundamentals* (NN43001-604).
- *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315)
- *System Management Reference* (NN43001-600)
- *Communication Server 1000 Fault Management - SNMP* (NN43001-719)
- *Software Input Output Reference — Maintenance* (NN43001-711)
- *Branch Office Installation and Commissioning* (NN43001-314)
- *System Redundancy Fundamentals* (NN43001-507)
- *Software Input Output Administration* (NN43001-611)

---

# Overview

---

## Contents

This section contains information about the following topics:

[“Element Manager overview” \(page 19\)](#)

[“Key features” \(page 21\)](#)

[“Signaling Server” \(page 21\)](#)

[“Call Server and Media Gateway” \(page 22\)](#)

[“IP Line and Voice Gateway” \(page 22\)](#)

## Element Manager overview

Element Manager is a Web-based user interface used to configure and maintain CS 1000 components.

Element Manager is deployed with the Nortel Unified Communications Management solution on a Linux based operating system. UCM provides logon and security features for Element Manager.

For more information about UCM, see *Unified Communication Management* (NN43001-116).

For more information about installing the Linux operating system, see *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315).

With Subscriber Manager, an administrator can create an account, publish/display phone attributes, and add and configure phone services for subscribers with available Templates in Element Manager. A template contains attributes common to a CS 1000 phone type. Once a template is created, you can use it to apply these common attributes to a group

of phones, without having to repetitively define the same value for each phone. In general, using a template is a more efficient method of adding large numbers of phones than maintaining each phone individually.

**Note:** It is possible to deploy more than one EM pointing to a Call Server using Deployment Manager, but the EM Phone provisioning application (**Phones**) does not support this. See, “[Limitations of deploying multiple Element Managers to manage a single Call Server](#)” (page 275).

Element Manager is a simple and user-friendly Web-based interface that supports a broad range of system management tasks, including:

- configuration and maintenance of IP Peer and IP Telephony features
- configuration and maintenance of traditional routes and trunks
- configuration and maintenance of numbering plans
- configuration of Call Server data blocks
- maintenance commands, system status inquiries, backup and restore functions
- patch upload, patch activation, firmware download

Element Manager has many features to help administrators manage systems with greater efficiency. Examples are as follows:

- Web pages provide a single point-of-access to parameters that were traditionally available through multiple overlays.
- Parameters are presented in logical groups to increase ease-of-use and speed-of-access.
- The *hide or show information* option enables administrators to see information that relates directly to the task at hand.
- Full-text descriptions of parameters help administrators reduce configuration errors.
- To simplify response selection, configuration screens offer preselected defaults, lists, checkboxes, and range values.
- To simplify the importing of phones to the database a Comma Separated Value (CSV) file can be used.

**Note 1:** All screen captures in this chapter are applicable to CS 1000E and CS 1000M systems. Where there is no indicator, the screen and commands are available on both.

**Note 2:** Option 81C and 61C must be upgraded to a CS 1000 M (SG or MG) in order to deploy it with UCM.

## Key features

The following functional areas can be accessed using Element Manager:

- **Links** — Provides access to Virtual Terminal sessions.
- **IP Network** — Helps the user access all functions related to managing IP Networks. These functions include data and physical structure configuration, high-profile operational activities, and administrative/maintenance functions.
- **System** — Provides access to system-wide configuration and basic hardware/software management, including supported maintenance overlays and configuration.
- **Customers** — Allows the user to view and edit customer properties.
- **Routes and Trunks** — Provides access to all functions required to create and manage trunks.
- **Dialing and Numbering Plans** — Provides a way to configure all Electronic Switched Network (ESN) data blocks for the Call Server. Network Routing Service cannot be launched from inside EM from CS 1000 Release 6.0 onwards. To access configuration for the Network Routing Service (NRS), you must log on through UCM.
- **Phones**— Enables users to import and configure phones for the Call Server.
- **Tools** — Provides general administrative tools, features and functions, and allows the user to find and access task-related pages, including Reports.
- **Security** — Allows the user to perform Security functions, including IP Security.

## Signaling Server

Element Manager enables administrators to perform the following activities on the Signaling Server:

- reset
- access the maintenance window
- download new IP Phone firmware
- upgrade IP Phone firmware
- view report log
- view Operational Measurements (OM) data
- Telnet
- patching

- increase Virtual Trunk capacity and perform configuration tasks on Virtual Trunks
- configure and manage the Web-based services for Personal Directory, Redial List, and Callers List
- add, delete, view, and edit Signaling Server information

## Call Server and Media Gateway

For Call Server and Media Gateway, Element Manager enables administrators to configure and manage the following data:

- Configuration Record
- Customer Data Block
- Route Data Blocks
- Trunks
- ESN Data Block
- Patching

To learn more about parameters that can be configured and managed in Element Manager, see *System Management Reference (NN43001-600)*.

## IP Line and Voice Gateway

Element Manager enables administrators to perform the following activities on the IP Line and Voice Gateway Media Cards:

- View and configure Simple Network Management Protocol (SNMP) parameters and add IP addresses for forwarding SNMP traps.
- View and configure Voice Gateway profile data.
- View and edit Quality of Service (QoS) parameters.
- Use Local Area Network (LAN) configuration to configure the Management LAN (ELAN) subnet, Telephony LAN (TLAN) subnet, and Routes.
- View and edit Simple Network Time Protocol (SNTP) Server and Client information.
- View and configure file server access for downloading firmware for IP Phones.
- View and select the Loss and Level Plan for the country. For more information about selecting the Loss and Level Plan for the country, see *Transmission Parameters Reference (NN43001-282)*.
- Add, remove, view, and edit card properties of Voice Gateway Media Cards.

To learn more about IP Line and Voice Gateway Media Card parameters that can be configured and managed in Element Manager, see *IP Line Application Fundamentals (NN43001-125)*.

The following maintenance activities are supported when using Element Manager for IP Line and Voice Gateway Media Card:

- reset Voice Gateway Media Card
- enable/disable Voice Gateway Media Card
- access the maintenance window to the Voice Gateway Media Card
- download new loadware/firmware for upgrades
- run Syslog reports
- obtain Operational Measurement (OM) data
- Telnet to the card
- patching

To learn more about the IP Line and Voice Gateway maintenance activities that are supported by Element Manager, see [“IP Network” \(page 129\)](#).



---

# How to use Element Manager

---

## Contents

This section contains information about the following topics:


- “Launching Element Manager” (page 25)
- “Timeout after a period of inactivity” (page 26)
- “Navigation” (page 26)
- “Configuring data” (page 29)
- “Logging off” (page 29)

## Launching Element Manager

Element Manager is installed with the Nortel Unified Communications Management (UCM) solution on a Nortel CP PM server or on one of the Commercial off the shelf (COTS) servers:

Start Element Manager from the UCM solution. This solution supports Single Sign-on so that you can access multiple systems. Users access UCM Common Services through Microsoft Internet Explorer 6.02600 or later. For information about how to log on to UCM Common Services, configure the UCM Common Services, and log on to Element Manager, see *Unified Communications Management* (NN43001-116).

**Figure 1**  
**Element Manager System Overview Web page**



### **Timeout after a period of inactivity**

Element Manager times out after a period of inactivity. Users are logged off without warning in all Element Manager Web pages. The exception is the **Edit** Web pages. When a user is works on this Web page, a message appears that warns of the impending timeout action. Click OK (on the warning message) within the remaining timeout period (5 minutes) to reset the timer. If no response occurs within the five-minute warning period, the session is cancelled, and the user must log in again. Data modifications made on screen, but not submitted to the system, are lost.

### **Navigation**

The Element Manager navigator is on the left side of the Web page as shown in [Figure 2 "Element Manager navigator" \(page 27\)](#).

**Figure 2**  
**Element Manager navigator**



Links in the Element Manager navigator are structured as follows:

- **Home**
- **Links**
  - Virtual Terminals
- **System**
  - Alarms
  - Maintenance
  - Core Equipment
  - Peripheral Equipment
  - IP Network
  - Interfaces

- Engineered Values
- Emergency Services
- Geographic Redundancy
- Software
- **Customers**
- **Routes and Trunks**
  - Routes and Trunks
  - D-Channels
  - Digital Trunk Interface
- **Dialing and Numbering Plans**
  - Electronic Switched Network
  - Flexible Code Restriction
  - Incoming Digit Conversion
- **Phones**
  - Templates
  - Report
  - Properties
  - Migration
- **Tools**
  - Backup and Restore
  - Call Server Initialization
  - Date and Time
  - Logs and Reports
- **Security**
  - Passwords
  - Policies
  - Login Options

During periods of high call volume, Element Manager Web pages load slowly.

## Configuring data

In many cases, users can edit data using configuration Web pages. At the bottom of the configuration Web pages, the following four buttons appear:

- **Submit** — Transmits changes to the Call Server.
- **Refresh**— Refreshes data from the Call Server. Refresh overwrites any changes not yet submitted.
- **Delete** — Deletes the item being edited or configured.
- **Cancel** — Discards the changes and returns to the appropriate configuration page.

## Logging off

To log off Element Manager and UCM, click the **Logout** link in the top right corner of the Web page.



---

# Links

---

## Contents

This section contains information about the following topics:

[“Introduction” \(page 31\)](#)

[“Virtual Terminals” \(page 31\)](#)

## Introduction


The features available under the **Links** branch of the Element Manager navigator enable Element Manager to be the single point of management access to Web pages and character-based interfaces.

Use the Virtual Terminal feature to access any IP-based elements on the network. On the Call Server, users can access context-sensitive online help, which provides detailed information about system prompts and error messages.

## Virtual Terminals

Click the **Virtual Terminals** link to open the **Virtual Terminal Sessions** Web page as shown in [Figure 3 "Virtual Terminal Sessions Web page" \(page 31\)](#).

**Figure 3**  
**Virtual Terminal Sessions Web page**



The **Virtual Terminal Sessions** Web page enables users to bookmark the connection details to any IP-based element on the network. Virtual Terminal can be used to connect to an element which supports Telnet, Rlogin or SSH2.

Virtual Terminal (VT) sessions are secured using SSL and SSH. If the element doesn't support SSH then normal TCP fallback is also provided (either to the Telnet or Rlogin server) to connect to the elements.

#### ATTENTION

Java Runtime Environment (JRE) version 1.5 must be installed for the Virtual Terminal Emulator to run properly.

Follow the steps in [Procedure 1 "Adding a Virtual Terminal session"](#) (page 32) to add a Virtual Terminal Session .

#### Procedure 1 Adding a Virtual Terminal session

Step	Action
1	On the <b>Virtual Terminal Sessions</b> Web page, click <b>Add</b> . The <b>Add Virtual Terminal Session</b> Web page appears, as shown in <a href="#">Figure 4 "Add Virtual Terminal Session Web page"</a> (page 32).

**Figure 4**  
**Add Virtual Terminal Session Web page**

- 2 Enter a **Name** and **IP Address** for the session.
- 3 Select the **Type** from the list.
- 4 Click **Save** to save.
- 5 To cancel the session, click **Cancel**.

--End--

To access a Virtual Terminal Session that is already created, click the name of the Virtual Terminal Session on the **Virtual Terminal Sessions** Web page. A **Virtual Terminal** window appears in a separate browser window.

**Note 1:** Virtual terminal prompts for pdt2 password, but you can press Enter and give the admin1 or admin2 password to get connected, and pdt2 password is not mandatory if you start Virtual Terminal through UCM.

**Note 2:** Upon initial launch of Virtual terminal, the user is prompted for the PDT2 level password. Entering this password will navigate user to the PDT2 shell of the Call Server. The user can also carriage return past the PDT2 password prompt. This action will prompt the user for a new username for other accounts on the Call Server. The user can provide admin1 or admin2 login credentials allowing overlay access to the Call Server.

**Note 3:** For security reasons, each Virtual Terminal session is forced to time out in 20 minutes.

The Virtual Terminal window provides a menu with the following items:

- Current Overlay
- Current Prompt
- Search M1 Help Files
- About Terminal Client

When the user enters an overlay, the Current Overlay and Current Prompt menu items are enabled.

Click the **Help -> Current Overlay** link to open a Help window containing help for that particular overlay.

Click the **Help -> Current Prompt** link to open a Help window explaining the definition of the prompt, along with acceptable responses.

Follow the steps in [Procedure 2 “Editing an existing Virtual Terminal session” \(page 33\)](#) to edit an existing Virtual Terminal session.

#### **Procedure 2** **Editing an existing Virtual Terminal session**

<b>Step</b>	<b>Action</b>
1	Select the radio button beside the appropriate Virtual Terminal name on the <b>Virtual Terminal Sessions</b> Web page.
2	Click <b>Edit</b> .

The information about the Virtual Terminal Session selected is displayed in the fields.

- 3 Edit the **Name** and **IP Address** values as necessary.
- 4 To change this session so that it logs into a Call Server, select the **Call Server** check box.
- 5 Click **Save** to save the changes.
- 6 Click **Cancel** to undo any changes made.

---

--End--

---

**Procedure 3**  
**Deleting an existing Virtual Terminal Session**

<b>Step</b>	<b>Action</b>
1	Select the radio button beside the appropriate Virtual Terminal name on the <b>Virtual Terminal Sessions</b> Web page.
2	Click <b>Delete</b> to remove the Virtual Terminal Session information completely.

---

--End--

---

---

# System

---

## Contents

This section contains information about the following topics:

- “Introduction” (page 36)
- “Maintenance” (page 42)
  - “Application Module Link Diagnostics” (page 46)
  - “Background Signaling and Switching Diagnostics” (page 49)
  - “Call Trace Diagnostics” (page 50)
  - “Clock Controller Diagnostics” (page 56)
  - “Core Common Equipment Diagnostics” (page 57)
  - “Core Input/Output Diagnostics” (page 61)
  - “D-channel Diagnostics” (page 63)
  - “D-Channel Expansion Diagnostics” (page 66)
  - “Digital Trunk Diagnostics” (page 69)
  - “Digital Trunk Maintenance Diagnostics” (page 72)
  - “Emergency Services Diagnostics” (page 75)
  - “Ethernet Diagnostics” (page 77)
  - “Ethernet Quality of Service Diagnostics” (page 82)
  - “Input/Output Diagnostics” (page 84)
  - “Intergroup Switch and System Clock Generator Diagnostics” (page 87)
  - “MSDL Diagnostics” (page 91)
  - “Multifrequency Sender Diagnostics” (page 93)
  - “Multifrequency Signaling Diagnostics” (page 96)
  - “Network and Peripheral Equipment Diagnostics” (page 98)
  - “Network and Signaling Diagnostics” (page 103)
  - “TMDI Diagnostics” (page 105)
  - “Tone and Digit Switch Diagnostics” (page 106)

- “Trunk Diagnostics” (page 108)
- “Zone Diagnostics” (page 111)
- “Loops” (page 113)
- “Superloops” (page 116)
- “MSDL/MSIP Cards” (page 118)
- “Conference/TDS/Multifrequency Cards” (page 119)
- “Tone Senders and Detectors” (page 119)

## Introduction

The **System** branch of the Element Manager navigator provides access to diagnostic tools that enable users to issue a variety of commands to the components of the CS 1000 system.


The following buttons appear on some or all of the System Web pages:

- **Submit** — Transmits changes to the Call Server.
- **Refresh** — Refreshes data from the Call Server. Refresh overwrites any changes not yet submitted.
- **Cancel** — Discards the changes and returns to the appropriate configuration Web page.

## Events

To configure or edit Events information, click the **Alarms > Events** link in the **System** branch of the Element Manager navigator. The **Events** Web page appears as shown in [Figure 5 "Events Web page" \(page 36\)](#).

**Figure 5**  
**Events Web page**



To display event default severity, event thresholds and site-specific event preferences, click the **Event Defaults and Preferences** link to open the **Event Defaults and Preferences** Web page as shown in [Figure 6 "Event Defaults and Preferences Web page"](#) (page 37).

**Figure 6**  
**Event Defaults and Preferences Web page**

Managing: [192.167.102.3](#)  
System > Alarms > Events > Event Defaults and Preferences

## Event Defaults and Preferences

**Thresholds**

[Edit...](#)

Global Window Timer Length: 1 minute  
Suppression Threshold Value: 15

**Search for Event Defaults** [Hide](#)

Criteria:

Severity:  [▼](#)

Event Category:  [Lookup](#)

**Event Defaults**

[Edit...](#) [Refresh](#)

**Event Preference Table**

[Add...](#) [Import](#) [Export](#) [Delete All](#) [Delete](#) [Refresh](#)

Event Key *	Severity	Escalation Value	Hits

To edit the Suppression Threshold Value and Global Window Timer Length that are common to all events, in the **Thresholds** section click **Edit**. The **Edit Thresholds** Web page appears as shown in [Figure 7 "Edit Thresholds Web page"](#) (page 38).

**Figure 7**  
**Edit Thresholds Web page**

Managing: [192.167.102.3](#)  
System > Alarms > Events > Event Defaults and Preferences > Edit Thresholds

---

### Edit Thresholds

Global Window Timer Length:  \* (1 - 60 minutes)  
Time used to measure both the escalation and suppression thresholds

Suppression Theshold Value:  \* (5 - 127)  
Applies to all events and suppresses events that flood the system

Enter the desired changes and click **Save**.

Search for event defaults by clicking either the **Severity** or **Event Category** radio buttons. Enter the Search criteria and click **Search**. The results appear in the **Event Defaults** section.

To maintain a list of system events, from the **Events** Web page click the **System Events** link. The **System Events** Web page appears as shown in [Figure 8 "System Events Web page" \(page 39\)](#).

**Figure 8**  
**System Events Web page**



The System Event List Size in the **Collection Limit** section is the upper limit to the number of events collected in the System Event List. To edit this limit, click **Edit**.

All events collected in the system event list are displayed in the text area at the bottom of the page.

Use this page to import an Event Preference Table from a user specified location to the switch.

### **Import Event Preference Table (EPT)**

Use this page to import an Event Preference Table from a user specified location to the switch.

To display this page, choose **System>Alarms>Events>Event Defaults and Preferences**. In the Event Preference Table Section, click **Import**.

The Event Preference Table page appears.

**Note:** The user needs to change the Security settings in Microsoft Internet Explorer while doing Import EPT. This file is residing at the user PC which uses ActiveX FileSystemObject to do the validations. This provides access to the local file system of the PC using even JavaScript code. Microsoft IE has a field called "Initialize and script ActiveX controls not marked as safe" under IE -> Tools -> Security -> Custom Level. This field needs to be either set to "Prompt" or "Enable". When this field is set to Disabled it doesn't allow IE to create ActiveX object and we find an error called "Automation server can not create object" and our validation for the file fails. If the IE Security level setting is set to High then no ActiveX controls is allowed, hence it should be set to Medium with the specified field to set to either "Prompt" or "Enable".

#### Procedure 4 Import Event Preference Table

Step	Action
1	Click <b>Browse</b> , to browse for the Event Preference Table.
2	Click <b>Import &amp; Activate</b> to import the Event Preference Table to the switch.
3	Click <b>Cancel</b> to return to the Event Defaults and Preferences without importing a Event Preference Table to the switch.
--End--	

## SNMP

The SNMP Profile Manager provides a common interface for configuring SNMP parameters on all CS 1000 Network Elements. You can use SNMP Profile Manager which is part of the UCM solution, to add, modify and delete SNMP profiles. Profiles can be configured and assigned to the following types of UCM managed elements:

- Element Manager
- Call Server (configuration settings are migrated to the SS, VGMC, and MGC)
- NRSM (configuration settings are migrated to NRS)

Fault management is implemented in Element Manager.

To configure or edit SNMP information, click the **Alarms > SNMP** link in the System branch of the Element Manager navigator. The **SNMP Configuration** Web page appears as shown in [Figure 9 "SNMP Configuration Web page"](#) (page 41).

**Figure 9**  
**SNMP Configuration Web page**

Managing: 172.16.100.2  
System > Alarms > SNMP Configuration

---

### SNMP Configuration

**System Info**

System name:

System contact:

System location:

Navigation site name:

Navigation system name:

**Management Information Base Access**

Administrator group 1:  \*

Administrator group 2:  \*

Administrator group 3:  \*

System management read:  \*

System management read/write:  \*

**Alarm**

Trap community:

Alarm threshold:  ▼  
Alarms below this threshold will be suppressed

Options:  Enable trap sending

Trap Destination:

IP address 1:  Port 1:

IP address 2:  Port 2:

IP address 3:  Port 3:

The information entered on this Web page corresponds to the SNMP data traditionally configured using LD 117 - Ethernet and Alarm Management.

The SNMP parameters are grouped in three logical groups in the SNMP Configuration Web page:

- System Info
- Management Information Base Access
- Alarm


Configuration of SNMP by Element Manager at the system level propagates upward to the SNMP Profile Manager. Changes made in Element Manager apply to all CS 1000 elements.

For detailed information about SNMP, see *Communication Server 1000 Fault Management - SNMP* (NN43001-719).

## Maintenance

When the user clicks the **Maintenance** link in the **System** branch of the Element Manager navigator, the **Maintenance** Web page appears. The user can choose how the options are presented. If the user chooses **Select by Functionality**, the diagnostic tool options are presented by functionality as shown in [Figure 10 "Maintenance diagnostic tools presented by functionality"](#) (page 42).

**Figure 10**  
**Maintenance diagnostic tools presented by functionality**



The following tool options are available from this Web page:


- AML Diagnostics
- Background Signaling and Switching
- Call Trace Diagnostics
- Centralized Software Upgrade
- Clock Controller Diagnostics
- Core Common Equipment Diagnostics
- Core Input/Output Diagnostics
- D-Channel Diagnostics
- D-Channel Expansion Diagnostics
- Digital Trunk Diagnostics
- Digital Trunk Maintenance Diagnostics
- Emergency Services Diagnostics
- Ethernet Diagnostics
- Ethernet Quality of Service Diagnostics
- Geographic Redundancy Diagnostics
- Input/Output Diagnostics
- InterGroup Switch & System Clock
- MSDL Diagnostics
- Multifrequency Sender Diagnostics
- Multifrequency Signaling Diagnostics
- Network and Peripheral Equipment Diagnostics
- Network and Signaling Diagnostics
- TMDI Diagnostics
- Tone and Digit Switch Diagnostics
- Trunk Diagnostics
- Zone Diagnostics

**Note:** Depending on the type of system being accessed, not all options may be available.

If the user chooses **Select by Overlay**, the following options are presented by LD numbers, as shown in [Figure 11 "Call Server diagnostic tools presented by overlay" \(page 45\)](#):


- LD 30 - Network and Signaling
- LD 32 - Network and Peripheral Equipment
- LD 34 - Tone and Digit Switch
- LD 36 - Trunk
- LD 37 - Input/Output
- LD 39 - Intergroup Switch and System Clock
- LD 45 - Background Signaling and Switching
- LD 46 - Multifrequency Sender
- LD 48 - Link
- LD 54 - Multifrequency Signaling
- LD 60 - Digital Trunk Interface and Primary Rate Interface
- LD 75 - Digital Trunk
- LD 80 - Call Trace
- LD 96 - D-Channel
- LD 117 - Ethernet and Alarm Management
- LD 135 - Core Common Equipment
- LD 137 - Core Input/Output
- LD 143 - Centralized Software Upgrade

**Figure 11**  
**Call Server diagnostic tools presented by overlay**



If selecting an overlay that corresponds to more than one functionality, choose the desired functionality in the **Select Group** list, as shown in [Figure 12 "Select Group list" \(page 46\)](#).

**Figure 12**  
**Select Group list**



This document presents the options by functionality, with cross-references to the appropriate overlay.

The following sections provide information about each functionality.

### Application Module Link Diagnostics

Click the **AML Diagnostics** link in the list of **Maintenance** functionalities to open the **Link: AML Diagnostics** Web page as shown in [Figure 13 "AML Diagnostics Web page"](#) (page 47).

**Figure 13**  
**AML Diagnostics Web page**

Managing: [207.179.153.99](#)  
 System » Maintenance » Link: AML Diagnostics

**Link: AML Diagnostics**

Diagnostic Commands	Command Parameters	Action
STAT AML - Get AML status	<input type="text"/> (device #)	<input type="button" value="Submit"/>
DIS AML - Disable AML	<input type="text"/> (device #)	<input type="button" value="Submit"/>
ENL AML - Enable AML	<input type="text"/> (device #)	<input type="button" value="Submit"/>

Instruction: Select command, add value and click on [Submit]

The commands available from this Web page correspond to the AML diagnostics traditionally performed by using LD 48.

To perform AML commands using this Web page, follow the steps in [Procedure 5 "Performing AML commands" \(page 47\)](#).

#### **Procedure 5** **Performing AML commands**

Step	Action
1	Select one of the following commands from the first <b>Commands</b> list: <ol style="list-style-type: none"> <li>a STAT AML - Get AML status</li> <li>b STAT ELAN - Check status of all specified / all configured ELANs</li> <li>c EST AML - Establish layer 2 on AML</li> <li>d MAP AML - Get card information of one or all AMLs</li> <li>e RLS AML - Release layer 2 on AML</li> <li>f SLFT AML - Perform self-test on AML</li> </ol>

- g UPLD AML - Upload parameter table 1 to 4 from AML
- 2 (Optional) Enter the device number in the **Command Parameters** text box.
- 3 Click **Submit**.

---

--End--

---

To disable AML using this Web page, follow the steps in [Procedure 6 "Disabling AML"](#) (page 48).

#### Procedure 6 Disabling AML

Step	Action
1	Select one of the following commands from the second <b>Commands</b> list: <ol style="list-style-type: none"> <li>a DIS AML - Disable AML</li> <li>b DIS AML - Disable AUTO recovery on AML</li> <li>c DIS AML - Disable layer 2 on AML</li> <li>d DIS AML - Disable layer 7 on AML</li> <li>e DIS AML - Disable MDL error reporting on AML</li> <li>f DIS ELAN - Disable ELAN (server/client task)</li> </ol>
2	(Optional) Enter the device number in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .

---

--End--

---

To enable AML using this Web page, follow the steps in [Procedure 7 "Enabling AML"](#) (page 48).

#### Procedure 7 Enabling AML

Step	Action
1	Select one of the following commands from the third <b>Commands</b> list: <ol style="list-style-type: none"> <li>a ENL AML - Enable AML</li> <li>b ENL AML - Enable Automatic set-up on AML</li> <li>c ENL AML - Enable AUTO recovery on AML</li> </ol>

- d ENL AML - Enable Layer 2 on AML
  - e ENL AML - Enable Layer 7 on AML
  - f ENL AML - Enable MDL error reporting on AML
  - g ENL ELAN- Enable ELAN (server task)
- 2 (Optional) Enter the device number in the **Command Parameters** text box.
  - 3 Click **Submit**.

---

--End--

---

### Background Signaling and Switching Diagnostics

The **Background Signaling and Switching diagnostics** Web page is applicable only to Large Systems.

Click the **Background Signaling and Switching** link in the list of **Call Server** functionalities to open the **Background Signaling and Switching Diagnostics** Web page, as shown in [Figure 14 "Background Signaling and Switching Diagnostics Web page"](#) (page 49).

**Figure 14**  
**Background Signaling and Switching Diagnostics Web page**

Managing: **192.167.100.3**  
System » [Maintenance](#) » Background Signaling and Switching Diagnostics

---

### Background Signaling and Switching Diagnostics

Diagnostic Commands	Command Parameters	Action
TEST - Perform continuity test for specified (all) loops	<input type="text" value=""/> (loop/none)	<input type="button" value="Submit"/>

Instruction: Select command, add value and click on [Submit]

The commands available from this Web page correspond to the Background Signaling and Switching command traditionally performed using LD 45 - Background Signaling and Switching Diagnostics.

This Web page is used to perform the TEST command. This command performs a continuity test for specified loops.

**Procedure 8**  
**Performing the TEST command**

<b>Step</b>	<b>Action</b>
1	Select the <b>Diagnostic Command</b> from the list.
2	Enter the loop number in the <b>Command Parameters</b> box.  <b>Note:</b> To run the TEST command on all loops, leave the <b>Command Parameters</b> box empty.
3	Click <b>Submit</b> .

---

--End--

---

### **Call Trace Diagnostics**

Click the **Call Trace Diagnostics** link in the list of **Maintenance** diagnostic tools to open the **Call Trace Diagnostics** Web page, as shown in [Figure 15 "Call Trace Diagnostics Web page" \(page 51\)](#).

**Figure 15**  
**Call Trace Diagnostics Web page**

Managing: [192.167.102.3](#)  
 System » [Maintenance](#) » Call Trace Diagnostics

### Call Trace Diagnostics

Diagnostic Commands	Command Parameters	Action
TRAC - List Route, type and status of trunks for a Customer	<input type="text"/> (cust# acod#) <input type="checkbox"/> DEV	Submit
TRAD - Trace DTI/DLI calls on a channel of a loop	<input type="text"/> (loop# ch#)	Submit
TRAT - Trace calls for an attendant of a customer	<input type="text"/> (cust# atnd#) <input type="checkbox"/> DEV	Submit
TRIP - Trace Calls for IP Phone	<input type="text"/> (IP Address)	Submit

Instruction: Select command, add value and click on [Submit]

The commands available from this Web page correspond to the Call Trace diagnostics traditionally performed by using LD 80 - Call Trace Diagnostics.

This Web page is used to perform the following Call Trace functions:

- TRAC commands
- TRAD commands
- TRAT commands
- TRIP commands

To perform TRAC commands, follow the steps in [Procedure 9 “Performing TRAC commands”](#) (page 52).

**Note:** To issue a detailed call trace select the **DEV** checkbox.

**Procedure 9**  
**Performing TRAC commands**

---

<b>Step</b>	<b>Action</b>
1	Select one of the following commands from the first <b>Commands</b> list: <ul style="list-style-type: none"><li>a TRAC - List Route, type and status of trunks for a Customer</li><li>b TRAC - Trace calls for specified customer and DN/LSC DN</li><li>c TRAC - Trace calls for specified customer, route and member</li><li>d TRAC - Trace calls on specified Digital Subscriber Loop (0-7)</li><li>e TRAC - Trace calls associated with the specified unit</li><li>f TRAC - Trace calls on specified key for specified unit</li></ul>
2	Enter the customer number and the acod number in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .

---

--End--

---

To perform TRAD commands, follow the steps in [Procedure 10](#) "Performing TRAD commands" (page 52).

**Procedure 10**  
**Performing TRAD commands**

---

<b>Step</b>	<b>Action</b>
1	Select the following command from the second <b>Commands</b> list: <ul style="list-style-type: none"><li>a TRAD - Trace DTI/DLI calls on a channel of a loop</li></ul>
2	Enter the loop number and channel number in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .

---

--End--

---

To perform TRAT commands, follow the steps in [Procedure 11](#) "Performing TRAT commands" (page 53).

**Note:** To issue a detailed call trace select the **DEV** checkbox.

---

**Procedure 11**  
**Performing TRAT commands**

<b>Step</b>	<b>Action</b>
1	Select one of the following commands from the third <b>Commands</b> list: <ul style="list-style-type: none"> <li>a TRAT - Trace calls for an attendant for a customer</li> <li>b TRAT - Trace calls on a key of an attendant of a customer</li> <li>c TRAT - Trace attendant calls for a unit</li> <li>d TRAT - Trace attendant calls on specified key of a unit</li> </ul>
2	Enter the customer number and attendant number in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .
--End--	

To perform TRIP commands, follow the steps in [Procedure 12 "Performing TRIP commands"](#) (page 53).

**Procedure 12**  
**Performing TRIP commands**

<b>Step</b>	<b>Action</b>
1	Select the following command from the fourth <b>Commands</b> list: <ul style="list-style-type: none"> <li>a TRIP - Trace calls for IP Phone</li> </ul>
2	Enter the required parameters in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .
--End--	

**Centralized Software Upgrade**

Click the **Centralized Software Upgrade** link in the list of **Maintenance** diagnostic tools to open the **Centralized Software Upgrade** Web page, as shown in [Figure 16 "Centralized Software Upgrade Web page"](#) (page 54).

**Figure 16**  
**Centralized Software Upgrade Web page**

Managing: [192.167.102.3](#)  
 System » [Maintenance](#) » Centralized Software Upgrade

## Centralized Software Upgrade

Diagnostic Commands	Command Parameters	Action
- ----Upgrade Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ----Enabling and Disabling Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ----Status Commands ----	<input type="text"/>	<input type="button" value="Submit"/>

Instruction: Select command, add value and click on [Submit]

To perform Upgrade commands, follow the steps in [Procedure 13](#) “Performing Upgrade commands” (page 54).

### Procedure 13 Performing Upgrade commands

Step	Action
1	Select the following commands from the first <b>Commands</b> list: <ol style="list-style-type: none"> <li>a UPGMG - Upgrade IPMG</li> <li>b UPGMG ALL - Upgrade ALL IPMGs</li> <li>c UPGMGCOMMIT - Initiate Reboot of the IPMG after upgrade</li> <li>d UPGMGCOMMI ALL - Initiate Reboot of all the IPMG after upgrade</li> <li>e UPGMGBOOT - Upgrade the bootrom of the IPMG</li> </ol>
2	Enter the required parameters in the <b>Command Parameters</b> text box.

- 3 Click **Submit**.

---

--End--

---

To perform Enabling and Disabling commands, follow the steps in [Procedure 14 “Performing Enabling and Disabling commands” \(page 55\)](#).

**Procedure 14**  
**Performing Enabling and Disabling commands**

Step	Action
1	Select the following commands from the second <b>Commands</b> list: <ul style="list-style-type: none"> <li>a ENL AUTOUPGMG - Enable Automatic Software Upgrade</li> <li>b DIS AUTOUPGMG - Disable Automatic Software Upgrade</li> </ul>
2	If ENL AUTOUPGMG is used, select either SEQ or SIM from the menu.
3	Click <b>Submit</b> .

---

--End--

---

To perform Status commands, follow the steps in [Procedure 15 “Performing Status commands” \(page 55\)](#).

**Procedure 15**  
**Performing Status commands**

Step	Action
1	Select the following commands from the third <b>Commands</b> list: <ul style="list-style-type: none"> <li>a PRT AUTOUPGMG - Displays settings of Automatic Software Upgrade feature</li> <li>b UPGMG STAT - Provides display details of the specified IPMG upgrade status</li> <li>c UPGMGSETUP - Display the current CSU Setting</li> <li>d UPGMGABORT - Abort and display centralized software upgrades</li> <li>e HELP - Provides a list of all supported commands</li> </ul>
2	If UPGMG STAT is used, enter the Superloop # and Shelf # in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .

---

--End--

---

## Clock Controller Diagnostics

Click the **Clock Controller Diagnostics** link in the list of **Maintenance** diagnostic tools to open the **Digital Trunk Interface and Primary Rate Interface: Clock Controller Diagnostics** Web page as shown in [Figure 17 "Digital Trunk Interface and Primary Rate Interface: Clock Controller Diagnostics Web page"](#) (page 56).

**Figure 17**  
**Digital Trunk Interface and Primary Rate Interface: Clock Controller Diagnostics Web page**

Managing: [192.167.102.3](#)  
System » [Maintenance](#) » Digital Trunk Interface and Primary Rate Interface :Clock Controller Diagnostics

### Digital Trunk Interface and Primary Rate Interface :Clock Controller Diagnostics

Action:  In Side:

**SUPERLOOP TYPE**

004 IPMG

008 IPMG

Card Status	Clock State	Clock Controller	Group	Side	Primary Reference	Secondary Reference	Auto Switch Clock	Cabinet Clock Source	Error/Info
<b>IP DB Port</b>   <b>Port Status</b>									
Instruction: Select command, add value and click on [Submit]									

This Web page is used to maintain the digital trunk interface and the primary rate interface clock controllers.

The commands available from this Web page correspond to the Clock Controller data traditionally maintained by using LD 60 - Digital Trunk Interface and Primary Rate Interface Clock Controller.

This Web page shows the status of the Clock Controller card.

To perform Clock Controller maintenance activities using this Web page follow the steps in [Procedure 16 "Performing Clock Controller maintenance activities"](#) (page 57).

---

**Procedure 16**  
**Performing Clock Controller maintenance activities**

---

<b>Step</b>	<b>Action</b>
<b>1</b>	Select one of the following commands from the <b>Action</b> list: <b>a</b> SCK - Get Status of the Clock <b>b</b> ENL CC - Enable the Clock <b>c</b> DIS CC - Disable the Clock <b>d</b> TRCK - Set the Clock Controller <b>e</b> DSCK - Disable the clock for loop <b>f</b> ENCK - Enable the secondary clock reference for card <b>g</b> EREF - Enable auto switchover of reference clocks <b>h</b> IDC - Get card ID of Clock Controller Card <b>i</b> MREF - Disable switchover of system clocks <b>j</b> SEFT CC - Execute self test
<b>2</b>	Select a Cabinet number from the <b>In Side</b> list.
<b>3</b>	Select the appropriate sub-parameters.
<b>4</b>	Click <b>Submit</b> .

---

--End--

---

**Core Common Equipment Diagnostics**

Click the **Core Common Equipment Diagnostics** link in the list of **Maintenance** diagnostic tools to open the **Core Common Equipment Diagnostics** Web page, as shown in [Figure 18 "Core Common Equipment Diagnostic Web page"](#) (page 58).

**Figure 18**  
**Core Common Equipment Diagnostic Web page**

Managing: [192.167.102.3](#)  
 System » [Maintenance](#) » Core Common Equipment Diagnostics

---

### Core Common Equipment Diagnostics

Diagnostic Commands	Command Parameters	Action
STAT CPU - Core status for both CPUs	(none)	<input type="button" value="Submit"/>
ENL CNI - Enable CNI card/port(c=side,s=slot,p=port)	(c# s#/c# s# p#)	<input type="button" value="Submit"/>
TEST CPU - Test the inactive core	(none)	<input type="button" value="Submit"/>
SCPU - Switch cores	(none)	<input type="button" value="Submit"/>
STAT HEALTH HELP - Help for health commands	(none)	<input type="button" value="Submit"/>
STAT GR - Status of Geographic Redundancy	(none)	<input type="button" value="Submit"/>

Instruction: Select command, add value and click on [Submit]

The commands available from this Web page correspond to the Core Common Equipment data traditionally maintained by using LD 135 - Core Common Equipment.

To execute status commands using this Web page, follow the steps in [Procedure 17 "Performing Core Common Equipment Status commands"](#) (page 58).

**Procedure 17**  
**Performing Core Common Equipment Status commands**

Step	Action
1	Select one of the following commands from the first <b>Commands</b> list: <ol style="list-style-type: none"> <li>a STAT CPU - Core status for both CPUs</li> <li>b STAT CNI - Status of configured CNI (c=side, s=slot, p=port)</li> <li>c STAT MEM - Status of SIMMs on both CPs</li> <li>d STAT EXT - Status of all Extender pair designations</li> <li>e STAT SUTL - Status of system utility</li> </ol>

- 2 Enter appropriate **Command Parameters** wherever applicable.
- 3 Click **Submit**.

---

--End--

---

To execute CNI commands using this Web page, follow the steps in [Procedure 18 "Performing Core Common Equipment CNI commands"](#) (page 59).

**Procedure 18**  
**Performing Core Common Equipment CNI commands**

Step	Action
1	Select one of the following commands from the second <b>Commands</b> list: <ol style="list-style-type: none"> <li>a ENL CNI - Enable CNI card/port (c=side, s=side, p=port)</li> <li>b DIS CNI - Disable CNI all, card or port</li> <li>c DSPL - Display active core contents</li> <li>d DSPL ALL - Display active core contents for all</li> <li>e IDC CPU - Print card ID for active core</li> <li>f IDC CNI - Print card ID for CNI on active side</li> <li>g ENL EXT - Enable specified Extender pair</li> </ol>
2	Enter the required parameters in the <b>Commands Parameters</b> text box.
3	Click <b>Submit</b> .

---

--End--

---

To execute test commands using this Web page, follow the steps in [Procedure 19 "Performing Core Common Equipment test commands"](#) (page 59).

**Procedure 19**  
**Performing Core Common Equipment test commands**

Step	Action
1	Select one of the following commands from the third <b>Commands</b> list: <ol style="list-style-type: none"> <li>a TEST CPU - Test the inactive core</li> <li>b TEST CNI - Test CNI card/port (c=card, s=slot, p=port)</li> <li>c TEST IPB - Test backplane on Secondary Interprocessor Bus</li> </ol>

- d TEST LCD - Test the LCD display on the active CP card
  - e TEST LED - Test LEDs
  - f TEST SUTL - Test system utility
- 2 Enter appropriate **Command Parameters** wherever applicable.
  - 3 Click **Submit**.

---

--End--

---

To execute miscellaneous commands using this Web page, follow the steps in [Procedure 20 "Performing Core Common Equipment miscellaneous commands"](#) (page 60).

**Procedure 20**  
**Performing Core Common Equipment miscellaneous commands**

Step	Action
1	Select one of the following commands from the fourth <b>Commands</b> list: <ul style="list-style-type: none"> <li>a SCPU - Switch cores</li> <li>b SPLIT - Put a redundant system into single mode</li> <li>c CDSP - Clear maintenance displays</li> <li>d CMAJ - Clear major alarm and reset power fail transfer</li> <li>e CMIN - Clear the minor alarm for all customers</li> <li>f CUTOVR - Transfer call processing from active to standby cores</li> <li>g JOIN - Synchronize the memory and drives</li> </ul>
2	Click <b>Submit</b> .

---

--End--

---

To execute status health commands using this Web page, follow the steps in [Procedure 21 "Performing Core Common Equipment status health commands"](#) (page 60).

**Procedure 21**  
**Performing Core Common Equipment status health commands**

Step	Action
1	Select one of the following commands from the fifth <b>Commands</b> list: <ul style="list-style-type: none"> <li>a STAT HEALTH HELP - Help for health commands</li> </ul>

- b STAT HEALTH - Overall health status
  - c STAT HEALTH AML - AML health status
  - d STAT HEALTH DSPDB - DSP Daughterboard health status (applicable only to systems with Media Gateway Controllers containing DSP Daughterboards)
  - e STAT HEALTH IPL - IPL health status
  - f STAT HEALTH ELAN - ELAN health status
  - g STAT HEALTH HW - Hardware health status
- 2 Click **Submit**.

---

--End--

---

To execute Geographic Redundancy commands using this Web page, do the following:

**Procedure 22**  
**Performing Core Common Equipment Geographic Redundancy commands**

Step	Action
1	Select one of the following commands from the sixth <b>Commands</b> list: <ul style="list-style-type: none"> <li>a STAT GR - Status of Geographic Redundancy</li> <li>b TEST GR - Test Geographic Redundancy</li> <li>c CLR GR - Clear operation for the secondary CS</li> </ul>
2	Enter appropriate <b>Command Parameters</b> wherever applicable.
3	Click <b>Submit</b> .

---

--End--

---

### Core Input/Output Diagnostics

Click the **Core Input/Output Diagnostics** link in the list of **Maintenance** tools to open the **Core Input/Output Diagnostics** Web page as shown in [Figure 19 "Core Input/Output Diagnostics Web page" \(page 62\)](#).

This Web page is used to obtain the status of PPP and Ethernet links. The commands available from this Web page correspond to the tools traditionally maintained using LD 137 - Core Input/Output Diagnostics.

**Figure 19**  
**Core Input/Output Diagnostics Web page**

Managing: [192.167.102.3](#)  
 System » [Maintenance](#) » Core Input/Output Diagnostics

### Core Input/Output Diagnostics

Diagnostic Commands	Command Parameters	Action
STAT - Status of both IOPs and ethernet link	(none) <input type="checkbox"/> ELNK	<input type="button" value="Submit"/>
DATA RDUN - Sector level check on both hard disks	(none)	<input type="button" value="Submit"/>
IDC - Print ID of active IOP	(none)	<input type="button" value="Submit"/>

Instruction: Select command, add value and click on [Submit]

To perform diagnostic commands using this Web page, follow the steps in [Procedure 23 “Performing Core Input/Output diagnostic commands”](#) (page 62).

**Procedure 23**  
**Performing Core Input/Output diagnostic commands**

Step	Action
1	Use the first <b>Commands</b> list to perform the following diagnostic activities: <ol style="list-style-type: none"> <li>a STAT - Status of both IOPs and CMDUs and ethernet link</li> <li>b STAT RDUN - Status of both disks</li> <li>c STAT FMD - Status of active Fixed Media Devices</li> <li>d STAT RMD - Status of active Removable Media Devices</li> </ol>
2	Click <b>Submit</b> .
3	Use the second <b>Commands</b> list to perform the following diagnostic activities: <ol style="list-style-type: none"> <li>a DATA RDUN - Sector level check on both hard disks</li> </ol>

- b** TEST RDUN - Test file level check on both hard disks
- 4** Click **Submit**.
- 5** Use the third **Commands** list to perform the following diagnostic activities:
  - a** IDC - Print IDs of both CMDUs and active IOP
  - b** SDID - Display security device information
- 6** Click **Submit**.

---

--End--

---

### D-channel Diagnostics

Click the **D-channel Diagnostics** link in the list of **Maintenance** diagnostic tools to open the **D-Channel Diagnostics** Web page as shown in [Figure 20 "D-channel Diagnostics Web page"](#) (page 63).

**Figure 20**  
**D-channel Diagnostics Web page**

Managing: [192.167.102.3](#)  
System » [Maintenance](#) » D-Channel Diagnostics

### D-Channel Diagnostics

Diagnostic Commands	Command Parameters	Action
Status for D-Channel (STAT DCH)		<input type="button" value="Submit"/>
Disable Automatic Recovery (DIS AUTO)	<input type="checkbox"/> ALL	<input type="button" value="Submit"/>
Enable Automatic Recovery (ENL AUTO)	<input type="checkbox"/> FDL	<input type="button" value="Submit"/>
Test Interrupt Generation (TEST 100)		<input type="button" value="Submit"/>
Establish D-Channel (EST DCH)		<input type="button" value="Submit"/>

DCH  DES  APPL\_STATUS  LINK\_STATUS  AUTO\_REC  PDCH  BDCH  
 010 PIV\_VDCH OPER EST ACTV AUTO

Instruction: Select command, add value and click on [Submit]

This Web page is used to test and maintain D-channel links and D-channel Interface (DCHI) cards. The commands available from this Web page correspond to the D-channel data traditionally maintained using the following overlays:

- LD 37 - Input/Output Diagnostic
- LD 48 - Link Diagnostic
- LD 96 - D-channel Diagnostic

To execute status commands using this Web page, follow the steps in [Procedure 24 "Performing D-channel status commands" \(page 64\)](#).

**Procedure 24**  
**Performing D-channel status commands**

Step	Action
1	Select one of the following commands from the first <b>Commands</b> list: <ul style="list-style-type: none"><li>a Status for D-Channel (STAT DCH)</li><li>b Status for Service Message (STAT SERV)</li></ul>
2	Click <b>Submit</b> .
--End--	

To execute disable commands using this Web page, follow the steps in [Procedure 25 "Performing D-channel disable commands" \(page 64\)](#).

**Procedure 25**  
**Performing D-channel disable commands**

Step	Action
1	Select one of the following commands from the second <b>Commands</b> list: <ul style="list-style-type: none"><li>a Disable Automatic Recovery (DIS AUTO)</li><li>b Disable D-Channel (DIS DCH). Select the ALL check box to disable all D-Channels.</li><li>c Disable Local Loop Back (DIS LLB)</li><li>d Disable Remote Loop Back (DIS RLB)</li><li>e Disable Test Mode (DIS TEST)</li></ul>
2	Click <b>Submit</b> .
--End--	

To execute enable commands using this Web page, follow the steps in [Procedure 26 "Performing D-channel enable commands" \(page 65\)](#).

---

**Procedure 26**  
**Performing D-channel enable commands**

---

<b>Step</b>	<b>Action</b>
<b>1</b>	Select one of the following commands from the third <b>Commands</b> list: <ul style="list-style-type: none"><li><b>a</b> Enable Automatic Recovery (ENL AUTO)</li><li><b>b</b> Enable D-Channel (ENL DCH). To force a loadware download at the same time, select the FDL check box.</li><li><b>c</b> Enable Local Loop Back (ENL LLB)</li><li><b>d</b> Enable Remote Loop Back (ENL RLB)</li><li><b>e</b> Enable Test Mode (ENL TEST)</li></ul>
<b>2</b>	Click <b>Submit</b> .

---

--End--

---

To execute test commands using this Web page, follow the steps in [Procedure 27 "Performing D-channel test commands" \(page 65\)](#).

**Procedure 27**  
**Performing D-channel test commands**

---

<b>Step</b>	<b>Action</b>
<b>1</b>	Select one of the following commands from the fourth <b>Commands</b> list: <ul style="list-style-type: none"><li><b>a</b> Test interrupt Generation (TEST 100)</li><li><b>b</b> Test Loop Back (Test 101)</li><li><b>c</b> Test Interrupt Handler (TEST 200)</li><li><b>d</b> Test Interrupt Handler-to-link (TEST 201)</li></ul>
<b>2</b>	Click <b>Submit</b> .

---

--End--

---

To execute D-Channel commands using this Web page, follow the steps in [Procedure 28 "Performing D-channel commands" \(page 66\)](#).

**Procedure 28**  
**Performing D-channel commands**

---

<b>Step</b>	<b>Action</b>
<b>1</b>	Select one of the following commands from the fifth <b>Commands</b> list: <ul style="list-style-type: none"><li><b>a</b> EEstablish D-Channel (EST DCH)</li><li><b>b</b> Get Physical Address and switch settings (MAP DCH)</li><li><b>c</b> Reset DCH and Inhibit Signaling (RST DCH)</li><li><b>d</b> Release D-Channel (RLS DCH)</li><li><b>e</b> Switch to Standby D-Channel (SDCH DCH)</li></ul>
<b>2</b>	Click <b>Submit</b> .

---

--End--

---

**D-Channel Expansion Diagnostics**

Click the **D-Channel Expansion Diagnostics** link in the list of **Maintenance** diagnostic tools to open the **Link: D-Channel Expansion Diagnostics** Web page as shown in [Figure 21 "Link: D-Channel Expansion Diagnostics Web page"](#) (page 67).

**Figure 21**  
**Link: D-Channel Expansion Diagnostics Web page**

Managing: [207.179.153.99](#)  
 System » Maintenance » Link: D-Channel Expansion Diagnostics

---

**Link: D-Channel Expansion Diagnostics**

Diagnostic Commands	Command Parameters	Action
STAT MSDL - Status of MSDL card	(none)	Submit
DIS MSDL - Disable the given MSDL card	(none)	Submit
ENL MSDL - Enable the given MSDL card	(none)	Submit

**MSDL STATUS**  
 No MSDL devices are configured in the system

---

Instruction: Select command, add value and click on [Submit]

Cancel

This Web page is used to test and maintain Multipurpose Serial Data Link (MSDL) cards. The commands available from this Web page correspond to the MSDL data traditionally configured by using LD 48 - Link Diagnostic.

To perform MSDL diagnostic activities using this Web page, follow the steps in [Procedure 29 "Performing D-channel Expansion MSDL diagnostic commands"](#) (page 67).

**Procedure 29**  
**Performing D-channel Expansion MSDL diagnostic commands**

Step	Action
1	Select one of the following commands from the first <b>Commands</b> list: <ol style="list-style-type: none"> <li>a STAT MSDL - Status of MSDL card</li> <li>b STAT MSDL full - Status MSDL card and available RAM</li> <li>c SLFT MSDL - Self test on the given MSDL card</li> <li>d RST MSDL - Power-On rest the given MSDL card</li> </ol>

- 
- 2 Click **Submit**.
- 

--End--

---

To execute disable commands using this Web page, follow the steps in [Procedure 30 "Performing D-channel Expansion disable commands"](#) (page 68).

**Procedure 30**  
**Performing D-channel Expansion disable commands**

---

<b>Step</b>	<b>Action</b>
1	Select one of the following commands from the second <b>Commands</b> list: <ul style="list-style-type: none"><li>a DIS MSDL all - Disable the given MSDL card</li><li>b DIS MSDL ALL - Disable all ports and then the MSDL card</li><li>c DIS MSDL AUDM - Disable MSDL auditing for the MSDL card</li><li>d DIS MSDL DBG - Disable debugger option for the MSDL card</li></ul>
2	Click <b>Submit</b> .

---

--End--

---

To execute enable commands using this Web page, follow the steps in [Procedure 31 "Performing D-channel Expansion enable commands"](#) (page 68).

**Procedure 31**  
**Performing D-channel Expansion enable commands**

---

<b>Step</b>	<b>Action</b>
1	Select one of the following commands from the third <b>Commands</b> list: <ul style="list-style-type: none"><li>a ENL MSDL - Enable the given MSDL card</li><li>b ENL MSDL all - Enable all ports and then the MSDL card</li><li>c ENL MSDL AUDM - Enable MSDL auditing for the MSDL card</li><li>d ENL MSDL FDL - Force download loadware to the MSDL card</li></ul>

---

2 Click **Submit**.

--End--

## Digital Trunk Diagnostics

Click the **Digital Trunk Diagnostics** link in the list of **Maintenance** diagnostic tools to open the **Digital Trunk Interface and Primary Rate Interface: Digital Trunk Diagnostics** Web page as shown in [Figure 22 "Digital Trunk Interface and Primary Rate Interface: Digital Trunk Diagnostics Web page"](#) (page 69).

**Figure 22**  
Digital Trunk Interface and Primary Rate Interface: Digital Trunk Diagnostics Web page

Managing: [192.167.102.3](#)  
System > [Maintenance](#) > Digital Trunk Interface and Primary Rate Interface :Digital Trunk Diagnostics

### Digital Trunk Interface and Primary Rate Interface :Digital Trunk Diagnostics

Diagnostic Commands	Command Parameters	Action
STAT - Get Status of loop(s) <input type="button" value="v"/>	<input type="text"/> (loop#)	<input type="button" value="Submit"/>
STAT - Get Status of the Channel <input type="button" value="v"/>	<input type="text"/> (# ch#)	<input type="button" value="Submit"/>
LOVF - List Threshold Overflows for Route <input type="button" value="v"/>	<input type="text"/> (cus# route#)	<input type="button" value="Submit"/>
ATLP - Daily routine auto loop test <input type="button" value="v"/>	<input type="text"/> (0 or 1)	<input type="button" value="Submit"/>

Instruction: Select command, add value and click on [Submit]

This Web page is used to test and maintain Digital Trunk Cards. The commands available from this Web page correspond to the DTI/PRI data traditionally maintained by using LD 60 - Digital Trunk Interface and Primary Rate Interface Diagnostics.

Use this Web page to issue maintenance commands on cards, channels, or routes by using the appropriate command list and parameter text box.

To perform maintenance activities on a Digital Trunk Card using this Web page, follow the steps in [Procedure 32 “Performing maintenance activities on a Digital Trunk Card”](#) (page 70).

**Procedure 32**  
**Performing maintenance activities on a Digital Trunk Card**

Step	Action
1	Select one of the following commands from the first <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a STAT - Get Status of loop(s)</li> <li>b DISL - Disable network and DTI/PRI cards of loop</li> <li>c DISI - Disable loop (when all channels are idle)</li> <li>d ENCH - Enable all channels on 2.0 Mb/s DTRI/PRI</li> <li>e ENLL - Enable network and DTI/PRI cards of loop</li> <li>f LCNT - List contents of alarm counters on loop(s)</li> <li>g RCNT - Reset alarm counters of all DTI/PRI loops</li> <li>h SLFT - Self Test on the loop)</li> <li>i DSYL - Disable yellow alarm processing for loop</li> <li>j ENYL - Enable yellow alarm processing for loop</li> <li>k DLBK - Disable remote loop back test</li> <li>l RLBK - Close loop at carrier interface point for testing</li> <li>m RMST - Perform remote loop back test on loop</li> </ul>
2	Enter the Loop number in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .
--End--	

To perform maintenance activities on a Channel belonging to a Digital Trunk Card using this Web page, follow the steps in [Procedure 33 “Performing maintenance activities on a Channel”](#) (page 70).

**Procedure 33**  
**Performing maintenance activities on a Channel**

Step	Action
1	Select one of the following commands from the second <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a STAT - Get Status of the channel</li> </ul>

- b DSCH - Disable the channel
  - c ENCH - Enable the channel
  - d SLFT - Self Test on the channel
  - e DLBK - Disable remote loop back test on channel
  - f RLBK - Close channel at carrier interface point
  - g RMST - Perform far end loop test on Channel
  - h RSET - Reset thresholds for channel on loop
- 2 Enter the Loop number and the Channel number, separated by a space, in the **Command Parameters** text box.
  - 3 Click **Submit**.

---

--End--

---

To perform maintenance activities on a Digital Trunk Route using this Web page, follow the steps in [Procedure 34 "Performing maintenance activities on a Digital Trunk Route"](#) (page 71).

**Procedure 34**  
**Performing maintenance activities on a Digital Trunk Route**

Step	Action
1	Select one of the following commands from the third <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a LOVF - List Thresholds Overflows for the Route</li> <li>b CMIN - Clear minor alarm indication for customer</li> </ul>
2	Enter the Customer number and the Route number, separated by a space, in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .

---

--End--

---

To perform maintenance activities on a card using this Web page, follow the steps in [Procedure 35 "Performing maintenance activities on a card"](#) (page 71).

**Procedure 35**  
**Performing maintenance activities on a card**

Step	Action
1	Select one of the following commands from the fourth <b>Commands</b> drop-down list:

- a ATLP - Daily routine automatic card test
  - b CDSP - Clear maintenance display
- 2 Enter the 0 or 1 in the **Command Parameters** text box.
  - 3 Click **Submit**.

---

--End--

---

### Digital Trunk Maintenance Diagnostics

Click the **Digital Trunk Maintenance Diagnostics** link in the list of **Maintenance** diagnostic tools to open the **Digital Trunk Diagnostics** Web page as shown in [Figure 23 "Digital Trunk Diagnostics Web page"](#) (page 72).

**Figure 23**  
**Digital Trunk Diagnostics Web page**

Managing: 192.167.102.3  
System » Maintenance » Digital Trunk Diagnostics

---

### Digital Trunk Diagnostics

Diagnostic Commands	Command Parameters	Action
STAT DDCS - Status for All DDCS loops or loop	<input type="text" value="((loop))"/>	<input type="button" value="Submit"/>
DIS DDCS - Disable DDCS number	<input type="text" value="(number)"/>	<input type="button" value="Submit"/>
ENL DDCS - Enable DDCS number	<input type="text" value="(number)"/>	<input type="button" value="Submit"/>
CDSP - Clear Display on active CPU	<input type="text" value="(none)"/>	<input type="button" value="Submit"/>

Instruction: Select command, add value and click on [Submit]

The commands available from this Web page correspond to the digital trunk diagnostics traditionally performed by using LD 75 - Digital Trunk Diagnostics.

To get status information about a digital trunk using this Web page, follow the steps in [Procedure 36 “Performing status commands on a digital trunk” \(page 73\)](#).

**Procedure 36**  
**Performing status commands on a digital trunk**

Step	Action
1	Select one of the following status commands from the first <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a STAT DDCS - Status for all DDCS loops or loop</li> <li>b STAT DDSL - Status for all DDSLs or DDSL number</li> <li>c STAT DTCS - Status for all DTCS loops or DTCS loop</li> <li>d STAT DTRC - Status of RDC on loop</li> <li>e STAT DTSL - Status of all DTSLs or DTSL number</li> <li>f STAT DTVC - Status of VDC on loop</li> <li>g STAT LSSL - Status of LSSL number for APNSS</li> <li>h STAT LSRC - Status of RDC on Signaling Link number</li> <li>i STAT LSVC - Status of VDC on Signaling Link number</li> </ul>
2	Enter the Loop number in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .
--End--	

To disable an entity on a digital trunk using this Web page, follow the steps in [Procedure 37 “Performing disable commands on a digital trunk” \(page 73\)](#).

**Procedure 37**  
**Performing disable commands on a digital trunk**

Step	Action
1	Select one of the following disable commands from the second <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a DIS DDSC - Disable DDSC number</li> <li>b DIS DDSL - Disable DDSL number</li> <li>c DIS DTCS - Disable DTCS loop</li> <li>d DIS DTRC - Disable RDC on Loop</li> <li>e DIS DTSL - Disable DTSL number</li> </ul>

- f DIS DTVC - Disable VDC on loop
  - g DIS LSSL - Disable LSSL number for APNSS
  - h DISI DDSCS - Disable all Channels on Loop as idle
  - i DISI DTCS - Disable DTCS loop
- 2 Enter the appropriate number in the **Command Parameters** text box.
  - 3 Click **Submit**.

---

--End--

---

To enable an entity on a digital trunk using this Web page, follow the steps in [Procedure 38 "Performing enable commands on a digital trunk" \(page 74\)](#).

**Procedure 38**  
**Performing enable commands on a digital trunk**

Step	Action
1	Select one of the following enable commands from the third <b>Commands</b> drop-down list: <ul style="list-style-type: none"><li>a ENL DDSC - Enable DDSC number</li><li>b ENL DDSL - Enable DDSL number</li><li>c ENL DTCS - Enable DTCS loop</li><li>d ENL DTRC - Enable RDC on Loop</li><li>e ENL DTSL - Enable DTSL number</li><li>f ENL DTVC - Enable VDC on loop</li><li>g ENL LSSL - Enable LSSL number for APNSS</li></ul>
2	Enter the appropriate number in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .

---

--End--

---

To perform miscellaneous commands on a digital trunk using this Web page, follow the steps in [Procedure 39 "Performing miscellaneous commands on a digital trunk" \(page 75\)](#).

**Procedure 39**  
**Performing miscellaneous commands on a digital trunk**

Step	Action
1	Select one of the following enable commands from the fourth <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a CDSP - Clear display on active CPU</li> <li>b CMIN - Clear minor alarm for all customers</li> <li>c STRT - Start DDSL number</li> </ul>
2	Enter the necessary parameters.
3	Click <b>Submit</b> .

--End--

**Emergency Services Diagnostics**

Click the **Emergency Services Diagnostics** link in the list of Maintenance diagnostic tools to open the **Emergency Services Diagnostics** Web page as shown in [Figure 24 "Emergency Services Diagnostics Web page"](#) (page 75).

**Figure 24**  
**Emergency Services Diagnostics Web page**

Managing: [192.167.100.3](#)  
 System > [Maintenance](#) > Emergency Services Diagnostics

---

**Emergency Services Diagnostics**

Diagnostic Commands	Command Parameters	Action
- ---- Emergency Response Location Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- Subnet Information Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- --- Dynamic Location Identification Commands ---	<input type="text"/>	<input type="button" value="Submit"/>

Instruction: Select command, add value and click on [Submit]

---

To perform Emergency Response Location commands using this Web page, follow the steps in [Procedure 40 “Performing Emergency Response Location commands”](#) (page 76).

**Procedure 40**  
**Performing Emergency Response Location commands**

---

<b>Step</b>	<b>Action</b>
1	Select one of the following commands from the first <b>Commands</b> drop-down list: <ul style="list-style-type: none"><li>a PRT ERL - Print Emergency Response Location</li><li>b ENL ERL - Enable ERL</li><li>c DIS ERL - Disable ERL</li></ul>
2	Enter the required parameters in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .

---

--End--

---

To perform Subnet Information commands using this Web page, follow the steps in [Procedure 41 “Performing Subnet Information commands”](#) (page 76).

**Procedure 41**  
**Performing Subnet Information commands**

---

<b>Step</b>	<b>Action</b>
1	Select one of the following commands from the second <b>Commands</b> drop-down list: <ul style="list-style-type: none"><li>a PRT SUBNET - Print Subnet Location</li><li>b PRT SUBNET NTH - Print Subnet Locations Starting from Index #</li><li>c PRT SUBNET ERL - Print All Subnet Locations for ERL</li><li>d PRT SUBNET ECL - Print All Subnet Locations for ECL</li><li>e EST SUBNETLIS - Test Subnet Location</li></ul>
2	Enter the required parameters in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .

---

--End--

---

To perform Dynamic Location Identification commands using this Web page, follow the steps in [Procedure 42 "Performing Dynamic Location Identification commands"](#) (page 77).

**Procedure 42**  
**Performing Dynamic Location Identification commands**

---

<b>Step</b>	<b>Action</b>
<b>1</b>	Select one of the following commands from the third <b>Commands</b> drop-down list: <ul style="list-style-type: none"><li><b>a</b> PRT ELIN - Print Dynamic ELIN</li><li><b>b</b> STAT ELIN - Get Status of Dynamic ELIN</li><li><b>c</b> STAT ELIN ACTIVE - Get Status of active Dynamic ELIN</li></ul>
<b>2</b>	Enter the required parameters in the <b>Command Parameters</b> text box.
<b>3</b>	Click <b>Submit</b> .

---

--End--

---

### **Ethernet Diagnostics**

Click the **Ethernet Diagnostics** link in the list of Maintenance diagnostic tools to open the **Ethernet Diagnostics** Web page as shown in [Figure 25 "Ethernet Diagnostics Web page"](#) (page 78).

**Figure 25**  
Ethernet Diagnostics Web page

### Ethernet Diagnostics

Status Commands [ -- Filters ]	Command Parameters
STAT LINK IP - Link status -- IP <span style="float: right;">▼</span>	<input type="text"/> <input type="button" value="Submit"/>
STAT SERV - Server status <span style="float: right;">▼</span>	<input type="text"/> <input type="button" value="Submit"/>
STIP TN - IP Status -- TN <span style="float: right;">▼</span>	<input type="text"/> <input type="button" value="Submit"/>
PRT IPDN - Print DNs with a given IP address <span style="float: right;">▼</span>	<input type="text"/> <input type="button" value="Submit"/>
ECNT FW - Etherset Count -- FWID MajorVer MinorVer Filter <span style="float: right;">▼</span>	<input type="text"/> <input type="button" value="Submit"/>
RST ZONE - Reset IP Phone -- Zone START/STOP HH:MM <span style="float: right;">▼</span>	<input type="text"/> <input type="button" value="Submit"/>
STAT IPMG - Print status of the given or all IPMGs <span style="float: right;">▼</span>	<input type="text"/> <input type="button" value="Submit"/>
STAT RFC2833 - RFC2833 Status -- TN <span style="float: right;">▼</span>	<input type="text"/> <input type="button" value="Submit"/>

Instruction: Select command, add value and click on [Submit]

This Web page is used to maintain Ethernet elements. The commands available from this Web page correspond to the data traditionally maintained by using LD 117- Ethernet Quality of Service Diagnostics.

To execute Link status commands, follow the steps in [Procedure 43 "Performing Link status commands"](#) (page 78).

#### **Procedure 43** **Performing Link status commands**

Step	Action
1	Select one of the following commands from the first <b>Commands</b> drop-down list: <ol style="list-style-type: none"> <li>a STAT LINK IP - Link Status -- IP</li> <li>b STAT LINK SRV - Link Status -- Server</li> <li>c STAT LINK NAME - Link Status -- Host Name</li> <li>d STAT LINK NODE - Link Status -- Node ID</li> </ol>

- 2 Enter the required command parameters in the **Command Parameters** text box.
- 3 Click **Submit**.

---

--End--

---

To execute server status commands, follow the steps in [Procedure 44](#) "Performing server status commands" (page 79).

**Procedure 44**  
**Performing server status commands**

Step	Action
1	Select one of the following commands from the second <b>Commands</b> drop-down list: <ol style="list-style-type: none"> <li>a STAT SERV - Server Status</li> <li>b STAT SERV IP - Server Status --IP</li> <li>c STAT SERV TYPE - Server Status -- Type</li> <li>d STAT SERV APP - Server Status -- Application</li> <li>e STAT SERV NAME - Server Status -- Name</li> <li>f STAT SERV NODE - Server Status -- Node ID</li> </ol>
2	Enter the required command parameters in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .
--End--	

To execute IP status commands, follow the steps in [Procedure 45](#) "Performing IP status commands" (page 79).

**Procedure 45**  
**Performing IP status commands**

Step	Action
1	Select one of the following commands from the third <b>Commands</b> drop-down list: <ol style="list-style-type: none"> <li>a STIP TN - IP Status -- TN</li> <li>b STIP TYPE - IP Status -- Type</li> <li>c STIP ZONE - IP Status -- Zone</li> <li>d STIP NODE - IP Status -- Node ID</li> </ol>

- e STIP HOSTIP - IP Status -- Host IP
  - f STIP ACF - IP Status -- Active Call Failover
  - g STIP TERMIP - IP Status -- Term IP
  - h STIP FW - IP Status -- FWID MajorVer MinorVer Filter
  - i STIP MODL - IP Status -- ModelName
- 2 Enter the required command parameters in the **Command Parameters** text box.
  - 3 Click **Submit**.

---

--End--

---

To execute print commands, follow the steps in [Procedure 46 “Performing print commands”](#) (page 80).

**Procedure 46**  
**Performing print commands**

- | Step | Action   |
|------|--|
| 1    | Select one of the following commands from the fourth Commands drop-down list: <ul style="list-style-type: none"> <li>a PRT IPDN - Print DNs with a given IP address</li> <li>b PRT DNIP Print IP address(es) with a given DN</li> <li>c PRT IPR - Print information for the given IPMG</li> <li>d PRT IPMG - Print information for the given IPMG</li> </ul> |
| 2    | Enter the required command parameters in the <b>Command Parameters</b> text box.   |
| 3    | Click <b>Submit</b> .  |

---

--End--

---

To execute Etherset Count commands, follow the steps in [Procedure 47 “Performing Etherset Count commands”](#) (page 80).

**Procedure 47**  
**Performing Etherset Count commands**

- | Step | Action  |
|------|---|
| 1    | Select one of the following commands from the fifth <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a ECNT FW - Etherset Count -- FWID MajorVer MinorVer Filter</li> </ul> |

- b ECNT MODL - Etherset Count -- Model
  - c ECNT PEC - Etherset Count -- PEC
  - d ECNT ZONE - Etherset Count -- Zone Customer #
  - e ECNT CARD - Etherset Count -- Loop Shelf Card Customer#
  - f ECNT NODE - Etherset Count -- Node ID
  - g ECNT SS - Etherset Count -- HostName
- 2 Enter the required command parameters in the **Command Parameters** text box.
  - 3 Click **Submit**.

---

--End--

---

To execute Reset IP Phone commands, follow the steps in [Procedure 48 "Performing Reset IP Phone commands" \(page 81\)](#).

**Procedure 48**  
**Performing Reset IP Phone commands**

- | Step | Action   |
|------|--|
| 1    | Select one of the following commands from the sixth <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a RST ZONE - Reset IP Phone -- Zone START/STOP HH:MM</li> <li>b RST FW - Reset IP Phone -- FWID START/STOP HH:MM</li> </ul> |
| 2    | Enter the required command parameters in the <b>Command Parameters</b> text box.   |
| 3    | Click <b>Submit</b> .  |

---

--End--

---

To execute IPMG commands, follow the steps in [Procedure 49 "Performing IPMG commands" \(page 81\)](#).

**Procedure 49**  
**Performing IPMG commands**

- | Step | Action  |
|------|---|
| 1    | Select one of the following commands from the seventh <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a STAT IPMG - Print status of the given or all IPMGs</li> <li>b STAT IPMG SUMMARY - Print status of all IPMGs</li> </ul> |

- 2 Enter the required command parameters in the **Command Parameters** text box.
- 3 Click **Submit**.

---

--End--

---

To execute RFC2833 commands, follow the steps in [Procedure 50 "Performing RFC2833 commands" \(page 82\)](#).

**Procedure 50**  
**Performing RFC2833 commands**

---

Step	Action
1	Select one of the following commands from the eighth <b>Commands</b> drop-down list: <ol style="list-style-type: none"><li>a STAT RFC2833 - RFC2833 Status - TN</li><li>b ENL RFC2833PRT - Enable the info Message Printing</li><li>c DIS RFC2833PRT - Disable the info Message Printing</li></ol>
2	Enter the required command parameters in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .

---

--End--

---

**Ethernet Quality of Service Diagnostics**

Click the **Ethernet Quality of Service Diagnostic** link in the list of **Maintenance** diagnostic tools to open the **Ethernet Quality of Service Diagnostics** Web page as shown in [Figure 26 "Ethernet Quality of Service Diagnostics Web page" \(page 83\)](#).

**Figure 26**  
**Ethernet Quality of Service Diagnostics Web page**

Managing: [207.179.153.99](#)  
 System » [Maintenance](#) » Ethernet Quality Of Service Diagnostics

---

### Ethernet Quality Of Service Diagnostics

**Action**  **Zone Number**  **Attribute**

**Action**  **Zone Number**  **Level**

---

Instruction: Select command, add value and click on [Submit]

This Web page is used to issue commands on elements by using the appropriate **Action** drop-down list and the corresponding Zone Number and Attribute or Level text boxes.

The commands that are available from this Web page correspond to data traditionally maintained by using LD 117 - Zone Configuration and Diagnostic.

To perform maintenance activities for Zone Attributes, follow the steps in [Procedure 51 "Performing maintenance activities for Zone Attributes"](#) (page 83).

**Procedure 51**  
**Performing maintenance activities for Zone Attributes**

Step	Action
1	Select one of the following commands from the <b>Action</b> drop-down list: <ul style="list-style-type: none"> <li>a Print QoS attribute for Zone (PRT AQOS)</li> <li>b Print Zone IP statistics (PRT ZQOS)</li> </ul>

- 2 Enter the appropriate value in the corresponding **Zone Number** and **Attribute** text box.
- 3 Click **Submit**.

---

--End--

---

To perform maintenance activities for Zone Levels, follow the steps in [Procedure 52 "Performing maintenance activities for Zone Levels"](#) (page 84).

**Procedure 52**  
**Performing maintenance activities for Zone Levels**

Step	Action
1	Select one of the following commands from the <b>Action</b> drop-down list: <ol style="list-style-type: none"><li>a Change Zone Notification Level (CHG ZQNL)</li><li>b Print Zone Notification Level (PRT ZQNL)</li></ol>
2	Enter the appropriate value in the corresponding <b>Zone Number</b> and <b>Level</b> text box.
3	Click <b>Submit</b> .

---

--End--

---

### Input/Output Diagnostics

Click the **Input/Output Diagnostics** link in the list of **Maintenance** diagnostic tools to open the **Input Output Diagnostics** Web page as shown in [Figure 27 "Input/Output Diagnostics Web page"](#) (page 85).

**Figure 27**  
**Input/Output Diagnostics Web page**

Managing: **192.167.102.3**  
 System » Maintenance » Input Output Diagnostics

---

### Input Output Diagnostics

Diagnostic Commands	Command Parameters	Action
- ---- TTY Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- Printer Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- MSDL Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- Miscellaneous Commands ----	<input type="text"/>	<input type="button" value="Submit"/>

**MSDL STATUS**  
 No MSDL devices are configured in the system

---

Instruction: Select command, add value and click on [Submit]

The commands available from this Web page correspond to the Input/Output diagnostics traditionally performed using LD 37 - Input/Output.

To execute TTY commands, follow the steps in [Procedure 53 “Performing Input/Output TTY commands”](#) (page 85).

**Procedure 53**  
**Performing Input/Output TTY commands**

Step	Action
1	Select one of the following commands from the first Commands drop-down list: <ul style="list-style-type: none"> <li>a STAT TTY - Get status of TTY device(s)</li> <li>b ENL TTY - Enable TTY</li> <li>c DIS TTY - Disable TTY</li> </ul>
2	Enter the required command parameters in the <b>Command Parameters</b> text box.

- 
- 3 Click **Submit**.

---

--End--

---

To execute Printer commands, follow the steps in [Procedure 54](#) “Performing Input/Output Printer commands” (page 86).

**Procedure 54**  
**Performing Input/Output Printer commands**

Step	Action
1	Select one of the following commands from the second <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a STAT PRT - Get status of Printer(s)</li> <li>b ENL PRT - Enable Printer</li> <li>c DIS PRT - Disable Printer</li> </ul>
2	Enter the required command parameters in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .

---

--End--

---

To execute MDSL commands, follow the steps in [Procedure 55](#) “Performing Input/Output MDSL commands” (page 86).

**Procedure 55**  
**Performing Input/Output MDSL commands**

Step	Action
1	Select one of the following commands from the third <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a STAT MSDL - Get status of MSDL card(s)</li> <li>b ENL MSDL - Enable MSDL device</li> <li>c DIS MSDL - Disable MSDL device</li> <li>d SLFT MSDL - Self test MSDL device</li> <li>e RST MSDL - Reset MSDL device</li> </ul>
2	Enter the required command parameters in the <b>Command Parameters</b> text box.

3 Click **Submit**.

---

--End--

---

To use the miscellaneous commands, do the following:

Step	Action
1	Select one of the following commands from the fourth <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a STAT - Get status of all I/O devices in system</li> <li>b STAT XSM - Get status of the system monitor</li> <li>c STAT LINK - Get status of CDR data Link(s)</li> <li>d CMIN - Clear minor alarm for all customers</li> <li>e CDSP - Clear maintenance display on active CPU</li> </ul>
2	Enter the required command parameters in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .

---

--End--

---

### Intergroup Switch and System Clock Generator Diagnostics

Click the **Intergroup Switch and System Clock Generator Diagnostics** link in the list of **Call Server** functionalities to open the **Intergroup Switch and System Clock Generator Diagnostics** Web page as shown in [Figure 28 "Intergroup Switch and System Clock Generator Diagnostics Web page"](#) (page 88).

**Figure 28**  
**Intergroup Switch and System Clock Generator Diagnostics Web page**

Managing: [192.167.102.3](#)  
 System » [Maintenance](#) » Intergroup Switch and System Clock Generator Diagnostics

---

### Intergroup Switch and System Clock Generator Diagnostics

Diagnostic Commands	Command Parameters	Ac
STAT FIJI - Status of FIJI in specified Grp, Side	<input type="text"/> (grp# side#)	<input type="button" value="Sub"/>
DIS ALRM - Disable specified Alarm (or all) for FIJI	<input type="text"/> (grp# side# (alarm#))	<input type="button" value="Sub"/>
ENL ALRM - Enable specified Alarm (or all) for FIJI	<input type="text"/> (grp# side# (alarm#))	<input type="button" value="Sub"/>
TEST 360 - Perform 360 test on FIJI card	<input type="text"/> (grp# side# (time#))	<input type="button" value="Sub"/>
CDSP - Clear Maintenance Display on active CPU	<input type="text"/> (none)	<input type="button" value="Sub"/>

Instruction: Select command, add value and click on [Submit]

The commands available from this Web page correspond to the Intergroup Switch and System Clock Generator diagnostics traditionally performed using LD 39.

To use status commands, follow the steps in [Procedure 56 “Performing Intergroup status commands”](#) (page 88).

**Procedure 56**  
**Performing Intergroup status commands**

Step	Action
1	Select one of the following commands from the first <b>Commands</b> drop-down list: <ol style="list-style-type: none"> <li>a STAT FIJI - Status of FIJI on specified Grp, Side</li> <li>b STAT PER - Status of specified PS card</li> <li>c STAT SCG - Status of specified SCG card (0 or 1)</li> <li>d STAT RING - Status of all FIJI cards on specified Ring</li> </ol>

- 2 Enter the group number and side number in the **Command Parameters** text box.
- 3 Click **Submit**.

---

--End--

---

To use the disable commands, follow the steps in [Procedure 57](#) “Performing Intergroup disable commands” (page 89).

**Procedure 57**  
**Performing Intergroup disable commands**

Step	Action
1	Select one of the following commands from the second <b>Commands</b> drop-down list: <ol style="list-style-type: none"> <li>a DIS ALRM - Disable specified Alarm (or all) for FIJI</li> <li>b DIS FIJI - Disable FIJI in specified Group and Side</li> <li>c DSPS - Disable specified PS card</li> <li>d DIS SCG - Disable specified SCG card (0 or 1)</li> <li>e DIS RING - Disable all FIJI cards on specified Ring</li> <li>f DIS RALM - Disable all alarms for all RIJI cards in Ring</li> </ol>
2	Enter the required command parameters in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .

---

--End--

---

To use the enable commands, follow the steps in [Procedure 58](#) “Performing Intergroup enable commands” (page 89).

**Procedure 58**  
**Performing Intergroup enable commands**

Step	Action
1	Select one of the following commands from the third <b>Commands</b> drop-down list: <ol style="list-style-type: none"> <li>a ENL ALRM - Enable specified Alarm (or all) for FIJI</li> <li>b ENL FIJI - Enable FIJI in specified Group and Side</li> <li>c ENPS - Enable specified PS card</li> <li>d ENL SCG - Enable specified SCG card (0 or 1)</li> </ol>

- e ENL RING - Enable all FIJI cards on specified Ring
  - f ENL RALM - Enable all alarms for all FIJI cards in Ring
- 2 Enter the required command parameters in the **Command Parameters** text box.
  - 3 Click **Submit**.

---

--End--

---

To use the test commands, follow the steps in [Procedure 59 “Performing Intergroup test commands” \(page 90\)](#).

**Procedure 59**  
**Performing Intergroup test commands**

Step	Action
1	Select one of the following commands from the fourth <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a TEST 360 - Perform 360 test on FIJI card</li> <li>b TEST FIJI - Self Test FIJI Card</li> <li>c TEST BKPL - Test backplane</li> <li>d TEST CMEM - Test connection memory</li> <li>e TEST LINK - Perform Link test to identify hardware faults</li> <li>f TEST ALL - Perform FIJI diagnostic test</li> </ul>
2	Enter the required command parameters in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .

---

--End--

---

To use the miscellaneous commands, follow the steps in [Procedure 60 “Performing Intergroup miscellaneous commands” \(page 90\)](#).

**Procedure 60**  
**Performing Intergroup miscellaneous commands**

Step	Action
1	Select one of the following commands from the fifth <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a CDSP - Clear Maintenance Display on active CPU</li> <li>b CMIN - Clear minor alarm for all customers</li> </ul>

- c ARCV ON - Set auto-recovery operation for ring
  - d ARCV OFF - Reset auto-recovery operation for ring
  - e ALRD ON - Turn on alarm display for all FIJI cards
  - f ALRD OFF - Turn off alarm display for all FIJI cards
  - g RSET - Reset thresholds for switchover functionality
  - h RSTR - Restore Ring(s)
  - i SCLK - Switchover to the other SCG
  - j SLCK FRCE - Force clock to switch to other SCG
  - k SWRG - Switch Call Processing to specified ring
- 2 If SWRG is selected, enter appropriate **Command Parameter**.
- 3 Click **Submit**.

---

--End--

---

### MSDL Diagnostics

Click the **MSDL Diagnostics** link in the list of Maintenance diagnostic tools to open the **Multipurpose Serial Data Link (MSDL) Diagnostics** Web page as shown in [Figure 29 "MSDL Diagnostics Web page" \(page 92\)](#).

**Figure 29**  
**MSDL Diagnostics Web page**

Managing: **192.167.102.3**  
System » Maintenance » MSDL Diagnostics

---

### MSDL Diagnostics

Diagnostic Commands	Command Parameters	Action
Disable MSDL Device (DIS) ▾	<input type="checkbox"/> FDL <input type="checkbox"/> FULL <input type="checkbox"/> ALL	<input type="button" value="Submit"/>

**MSDL STATUS**  
No MSDL devices are configured in the system

Instruction: Select command, add value and click on [Submit]

The commands available from this Web page correspond to the MSDL diagnostics traditionally performed by using LD 96 - D-channel.

This Web page is used to perform the following MSDL diagnostic functions:

- Disable MSDL Device (DIS)
- Enable MSDL Device (ENL)
- Self Test (SLFT)
- Get Status of MSDL Device (STAT)
- Causes Power-On Reset of MSDL Device (RST)

To perform diagnostic activities using this Web page, follow the steps in [Procedure 61 "Performing MSDL diagnostic activities"](#) (page 93).

---

**Procedure 61**  
**Performing MSDL diagnostic activities**

Step	Action
1	Select the required <b>Diagnostic Command</b> from the <b>Commands</b> drop-down list.
2	To update the loadware, select the <b>FDL (Force Download)</b> check box when the Enable MSDL Device command is selected.
3	To check the status of all MDSL devices, select the <b>Full</b> check box when the Get Status of MSDL Device command is selected.
4	Enter the required command parameters in the <b>Command Parameters</b> text box.
5	Click <b>Submit</b> .

---

--End--

---

**Multifrequency Sender Diagnostics**

The **Multifrequency Sender Diagnostics** Web page is available only on Large Systems.

Click the **Multifrequency Sender Diagnostics** link in the list of **Maintenance** diagnostic tools to open the **Multifrequency Sender Diagnostics** Web page as shown in [Figure 30 "Multifrequency Sender Diagnostics Web page"](#) (page 94).

**Figure 30**  
**Multifrequency Sender Diagnostics Web page**

Managing: **192.167.102.3**  
 System » Maintenance » Multifrequency Sender Diagnostics

### Multifrequency Sender Diagnostics

Diagnostic Commands	Command Parameters	Action
- ---- Loop Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- Card Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- Alarm Commands ----	<input type="text"/>	<input type="button" value="Submit"/>

Instruction: Select command, add value and click on [Submit]

The commands available from this Web page correspond to the Multifrequency Sender diagnostics traditionally performed by using LD 46.

To use the loop commands, follow the steps in [Procedure 62 “Performing Multifrequency Sender loop commands”](#) (page 94).

**Procedure 62**  
**Performing Multifrequency Sender loop commands**

Step	Action
1	Select one of the following commands from the first <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a STAT - Get Status of MFS loop</li> <li>b ENLL - Enable loop</li> <li>c DISL - Disable loop</li> <li>d MFS - Test and enable MFS loop</li> </ul>
2	Enter the required command parameters in the <b>Command Parameters</b> text box.

- 
- 3 Click **Submit**.
- 

--End--

---

To use the card commands, follow the steps in [Procedure 63 “Performing Multifrequency Sender card commands”](#) (page 95).

**Procedure 63**  
**Performing Multifrequency Sender card commands**

Step	Action
1	Select one of the following commands from the second <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a ENLX - Enable Conf/TDS/MFS card on loop</li> <li>b DISX - Disable Conf/TDS/MFS card on loop</li> </ul>
2	Enter the required command parameters in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> button.

---

--End--

---

To use the alarm commands, follow the steps in [Procedure 64 “Performing Multifrequency Sender alarm commands”](#) (page 95).

**Procedure 64**  
**Performing Multifrequency Sender alarm commands**

Step	Action
1	Select one of the following commands from the third <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a CMAJ - Clear major alarm and reset power fail</li> <li>b CDSP - Clear Maint display on active CPU</li> <li>c CMIN - Clear minor alarm for all customers</li> </ul>
2	Enter the required command parameters in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .

---

--End--

---

## Multifrequency Signaling Diagnostics

Click the **Multifrequency Signaling Diagnostics** link in the list of **Maintenance** diagnostic tools to open the **Multifrequency Signaling Diagnostics** Web page as shown in [Figure 31 "Multifrequency Signaling Diagnostics Web page"](#) (page 96).

**Figure 31**  
**Multifrequency Signaling Diagnostics Web page**

Managing: [192.167.102.3](#)  
System » Maintenance » Multifrequency Signaling Diagnostics

### Multifrequency Signaling Diagnostics

Diagnostic Commands	Command Parameters	Action
----- Card Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
----- Unit Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
----- Miscellaneous Commands ----	<input type="text"/>	<input type="button" value="Submit"/>

Instruction: Select command, add value and click on [Submit]

The commands available from this Web page correspond to the Multifrequency Signaling diagnostics traditionally performed by using LD 54 - Multifrequency Signaling.

To use the card commands, follow the steps in [Procedure 65 "Performing Multifrequency Signaling card commands"](#) (page 96).

### Procedure 65 Performing Multifrequency Signaling card commands

Step	Action
1	Select one of the following commands from the first <b>Commands</b> drop-down list: <ol style="list-style-type: none"> <li>a STAT - Get status of MFC or MFE card</li> </ol>

- b DISC - Disable MFC/MFE card
  - c ENLC - Enable MFC or MFE card
  - d MIDN - Reset/Initialize all idle MFC or MFE cards
- 2 Enter the required command parameters in the **Command Parameters** text box.
  - 3 Click **Submit**.

---

--End--

---

To use the unit commands, follow the steps in [Procedure 66 “Performing Multifrequency Signaling unit commands”](#) (page 97).

**Procedure 66**  
**Performing Multifrequency Signaling unit commands**

Step	Action
1	Select one of the following commands from the second <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a STAT - Get status of specified MFC or MFE unit</li> <li>b DISU - Disable XMFC/XMFE channel</li> <li>c ENLU - Enable MFC/MFE channel</li> <li>d MTST - Invoke loop around test on unit with digit and level</li> <li>e ATST - Invoke automatic loop test for unit</li> </ul>
2	Enter the required command parameters in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .

---

--End--

---

To use the miscellaneous commands, follow the steps in [Procedure 67 “Performing Multifrequency Signaling miscellaneous commands”](#) (page 97).

**Procedure 67**  
**Performing Multifrequency Signaling miscellaneous commands**

Step	Action
1	Select one of the following commands from the third <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a STAT - List all disabled MFC channels in system</li> <li>b CMIN - Clear minor alarm for all customers</li> </ul>

- c CDSP - Clear the mtc display on active CPU
  - d CMAJ - Clear major alarm and reset power fail transfer
- 2 Enter the required command parameters in the **Command Parameters** text box.
  - 3 Click **Submit**.

---

--End--

---

### Network and Peripheral Equipment Diagnostics

Click the **Network and Peripheral Equipment Diagnostics** link in the list of **Maintenance** diagnostic tools to open the **Network & Peripheral Diagnostics** Web page as shown in [Figure 32 "Network and Peripheral Diagnostics Web page"](#) (page 98).

**Figure 32**  
Network and Peripheral Diagnostics Web page

Managing: [192.167.102.3](#)  
System » [Maintenance](#) » Network & Peripheral Diagnostics

---

### Network & Peripheral Diagnostics

Diagnostic Commands	Command Parameters	Action
- ---- Loop Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- Shelf Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- Card Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- Unit Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- M39XX Unit Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- DSL Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- Application Commands ----	<input type="text"/>	<input type="button" value="Submit"/>

Instruction: Select command, add value and click on [Submit]

This Web page is used to test and maintain network and peripheral equipment. The commands available from this Web page correspond to the data traditionally maintained by using the LD 32 - Network and Peripheral Equipment Diagnostic.

These commands are split among separate drop-down lists, grouped by equipment type.

The command lists are as follows:

- Loop Commands
  - Network Loop
    - ENLL - Enable network loop
    - DISL - Disable network loop
  - Super Loop
    - STAT - Get status of Superloop
    - SUPL - Print data for one or all Superloops
    - IDC - Print Card ID for Superloop and associated Controller
    - XNTT - Do self-test of Network card for specified Superloop
    - ENLL - Enable specified Superloop
    - XRST - Reset the specified Superloop
- Shelf Commands
  - DISS - Disable the shelf
  - ENLS - Enable specified shelf
  - LBSY - List TNs of all busy units
  - LDIS - List TNs of all disabled units
  - LIDL - List TNs of all idle units
  - LMNT - List TNs of all maint. busy units
- Card Commands
  - General Card Commands
    - STAT - Get card status
    - ENLC - Enable and reset card
    - DISC - Disable peripheral card
    - IDC - Print card ID for PE card
  - MISP Card Commands
    - STAT - Print status of MISP appl/card
    - ENLL - Enable MISL loop
    - ENLL BRIL - Enable BRIL application on MISP loop
    - ENLL BRIT - Enable BRIT application on MISP loop
    - IDC - Print MISP card ID

- DISL - Disable MISP loop
- DISL BRIL - Disable BRIL application on MISP loop (Large System)
- DISL BRIT - Disable BRIT application on MISP loop
- DISL BRIE - Disable BRIE application on MISP loop
- BRI BRSC Card Commands
  - STAT - Get status of BRI card
  - IDC - Print BRSC card and LW version
  - DISC BRI - Disable the BRSC BRI application
  - DISC - Disable specified card
  - ENLC BRI - Enable the BRSC BRI application
  - ENLC - Enable specified card
- PS Card Commands
  - STAT PER - Get status of PS card
  - ENPS - Enable PS card and associated loops
  - DSPS - Disable Peripheral Signaling card
- Network Card Commands
  - STAT NWK - Check status of N/W card with specified loop
  - ENLN - Enable network card with specified loop
  - DISN - Disable network card with specified loop
- XPEC Controller Commands
  - XPEC - Print data for all or specified Controller(s)
  - ENXP - Enable Controller and associated cards
  - ENXP XPC - Enable Controller, not the associated cards
  - DSXP - Disable Controller and all connected cards
  - XPCT - Self-test on Controller
  - IDCS - Print card ID for cards
- Unit Commands
  - General Unit Commands
    - STAT - Get unit status
    - ENLU - Enable unit
    - IDU - Print set ID
    - DISU - Disable unit
    - STAT VTRM - Display virtual trunk unit status

- M39XX Unit Commands
  - FDLC - Cancel/stop flash download for M39xx
  - FDLU - Conditional download to one M39xx
  - FWVU - Print firmware versions on M39xx
  - FSUM - Print firmware versions on M39xx
- DSL Commands
  - STAT - Get status of SILC or UILC
  - ENL AUTO - Enable automatic link recovery
  - ENRB - Enable Remote Loop Back for DSL
  - DIS AUTO - Disable automatic link recovery
  - DISU - Disable the DSL
  - DSRB - Disable Remote Loop Back for DSL
  - IDC - Print SILC/UILC card ID
  - PERR - Print protocol log for the card
  - DISC - Disable SILC/UILC card
  - FDIS NCAL - Force disconnect the connection
  - STAT NCAL - List all current connections - DSL
  - PCON - Print configuration and LAPD parameters for specified DSL
  - DISI - Disable the card when idle
  - DSTS - Disable Disable Remote Loop Back test mode
  - ENLC - Enable SILC/UILC card
  - EISI - Enable the card when idle
  - EISU - Enable specified DSL
  - ESRB - Enable Remote Loop Back
  - ESTS - Enable Remote Loop Back test mode
  - ESTU - Establish D Channel Link
  - PLOG - Print protocol log
  - PMES - Print Layer 3 message log
  - PTAB - Upload and Print Layer 3 message configuration
  - PTRF - Print traffic data
  - RLBT - Perform Remote Loop Back test
  - RLSU - Release D Channel Link
- Application Commands

- DISL BRIL - Disable and remove BRIL application from MISP card
- DISL BRIT - Disable and remove BRIT application from MISP card
- DISL BRIE - Disable and remove BRIE application from MISP card
- ENLL BRIL - Enable BRI application on MISP Card and force download of the loadware
- ENLL BRIT - Enable BRIT application on MISP card and force download of the loadware
- ENLL BRIE - Enable BRIE application on MISP card and force download of the loadware
- DIS BRIL - Disable BRIL application on MISP Card
- DIS BRIT - Disable BRIT application on MISP Card
- DIS BRIE - Disable BRIE application on MISP Card
- PERR BRIL - Upload error log for BRIL application on MISP Card
- PERR BRIT - Upload error log for BRIT application on MISP Card
- PERR BRIE - Upload error log for BRIE application on MISP Card
- PERR BRIL - Print protocol log for BRIL application on MISP Card
- PERR BRIT - Print protocol log for BRIT application on MISP Card
- PERR BRIE - Print protocol log for BRIE application on MISP card
- STAT BRIL - Get status of MISP card and BRIL application
- STAT BRIT - Get status of MISP card and BRIT application
- STAT BRIE - Get status of MISP card and BRIE application

Use this Web page to issue diagnostic commands on the network and peripheral equipment by using the appropriate **Diagnostic Commands** drop-down list and the corresponding **Command Parameters** text box. The required parameters for the selected command are indicated to the right of the **Command Parameters** text box after the command is selected.

To perform maintenance activities using this Web page, follow the steps in [Procedure 68 "Performing Network and Peripheral maintenance activities" \(page 102\)](#).

**Procedure 68**  
**Performing Network and Peripheral maintenance activities**

---

<b>Step</b>	<b>Action</b>
1	Select a command from one of the <b>Diagnostic Commands</b> drop-down lists.

---

- 2 Enter the appropriate value in the corresponding **Command Parameters** text box. The required parameters for the selected command are indicated to the right of the **Command Parameters** box once the command is selected.
- 3 Click the corresponding **Submit** button.

---

--End--

---

### Network and Signaling Diagnostics

Click the **Network and Signaling Diagnostics** link in the list of **Maintenance** diagnostic tools to open the **Network & Signaling Diagnostics** Web page as shown in [Figure 33 "Network and Signaling Diagnostics Web page"](#) (page 103).

**Figure 33**  
**Network and Signaling Diagnostics Web page**

Managing: [192.167.102.3](#)  
System » [Maintenance](#) » Network & Signaling Diagnostics

### Network & Signaling Diagnostics

Diagnostic Commands	Command Parameters	Action
- ---- Loop Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- Shelf/Card/Unit Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- BRI Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- Superloop Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- Alarm Commands ----	<input type="text"/>	<input type="button" value="Submit"/>

Instruction: Select command, add value and click on [Submit]

The commands available from this Web page correspond to the Network and Signaling diagnostics traditionally performed by using LD 30 - Network and Signaling.

This Web page is used to perform the following Network and Signaling diagnostic functions:

- Loop Commands
  - ENLL - Enable network loop
  - DISL - Disable loop
  - LDIS - List disabled loops
  - LENL - List enabled loops
  - LOOP - Test network memory on loop(s)
  - STAT - Get status of all/specified N/W loops
  - TTSM - Test TSM of a loop
- Shelf/Card/Unit Commands
  - UNTT - Signaling test on specified card or unit
  - SHLF - Test loop l, shelf s (Large System)
  - CPED - Clear contents of ctrlr maint display (Large System)
  - RPED - Read contents of ctrlr maint display (Large System)
  - TTWI - Test TSM of the N/W card (Large System)
- BRI Commands
  - SLFT - Selftest on ISDN BRI line card
  - SLFT - Selftest ISDN BRI line card (Large System)
  - SLFT - Selftest on MISP card
  - STEI - Query Term Edpt Identifiers and USIDs (Large System)
  - TEIT - Perform TEI check on DSL
- Superloop Commands
  - ENLL - Enable specified Superloop
  - DISL - Disable specified Superloop
  - ENLL - Enable sl, download periph s/w ver
- Alarm Commands
  - CMAJ - Clear major alarm and reset power fail
  - CDSP - Clear Maint display on active CPU
  - CMIN - Clear minor alarm for all customers

To perform diagnostic activities using this Web page, follow the steps in [Procedure 69 "Performing Network and Signaling diagnostic activities"](#) (page 105).

**Procedure 69**  
**Performing Network and Signaling diagnostic activities**

Step	Action
1	Select the required <b>Diagnostic Command</b> from the drop-down list.
2	Enter any required <b>Command Parameters</b> . The required parameters for the selected command are indicated to the right of the <b>Command Parameters</b> text box once the command is selected.
3	Click <b>Submit</b> .

--End--

### TMDI Diagnostics

T1 Multipurpose Digital Interface (TMDI) cards are used only in CS 1000MSmall Systems. Click the **TMDI Diagnostics** link in the list of Call Server diagnostic tools to open the **TMDI Diagnostics** Web page as shown in [Figure 34 "TMDI Diagnostics Web page" \(page 105\)](#).

**Figure 34**  
**TMDI Diagnostics Web page**

Managing: [207.179.153.99](#)  
 System > Maintenance > TMDI Diagnostics

---

### TMDI Diagnostics

Diagnostic Commands	Command Parameters	Action
Enable TMDI Card (ENL) ▾	<input type="checkbox"/> FDL <input type="checkbox"/> FULL <input type="checkbox"/> ALL	Submit

**TMDI STATUS**

Instruction: Select command, add value and click on [Submit]

Cancel

This Web page is used to test and maintain TMDI (DTI/PRI/DCH) cards. The commands available from this Web page correspond to the TMDI data traditionally configured by using LD 96 - D-channel.

To perform diagnostic activities using this Web page, follow the steps in [Procedure 70 "Performing TMDI diagnostic activities" \(page 106\)](#).

**Procedure 70**  
**Performing TMDI diagnostic activities**

<b>Step</b>	<b>Action</b>
<b>1</b>	Select one of the following Actions from the <b>Commands</b> drop-down list: <ul style="list-style-type: none"><li><b>a</b> Enable TMDI Card (ENL)</li><li><b>b</b> Disable TMDI card (DIS)</li><li><b>c</b> Reset TMDI card (RST)</li><li><b>d</b> Self Test on TMDI Card (SLFT)</li><li><b>e</b> Get TMDI Status (STAT)</li></ul>
<b>2</b>	Select one of the following <b>Command Parameters</b> : <ul style="list-style-type: none"><li><b>a</b> FDL</li><li><b>b</b> FULL</li><li><b>c</b> ALL</li></ul>
<b>3</b>	Click <b>Submit</b> .

---

--End--

---

### **Tone and Digit Switch Diagnostics**

Click the **Tone and Digit Switch Diagnostics** link in the list of Maintenance diagnostic tools to open the **Tone and Digit Switch and Digitone Receiver Diagnostics** Web page as shown in [Figure 35 "Tone and Digit Switch and Digitone Receiver Diagnostics Web page" \(page 107\)](#).

**Figure 35**  
**Tone and Digit Switch and Digitone Receiver Diagnostics Web page**

Managing: [192.167.102.3](#)  
 System » [Maintenance](#) » Tone and Digit Switch and Digitone Receiver Diagnostics

---

### Tone and Digit Switch and Digitone Receiver Diagnostics

Diagnostic Commands	Command Parameters	Action
- ---- Loop Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- Card and Unit Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- Miscellaneous Commands ----	<input type="text"/>	<input type="button" value="Submit"/>

Instruction: Select command, add value and click on [Submit]

This Web page is used to execute tone, digit switch, and digitone receiver diagnostics. The commands available from this Web page correspond to the TMDI data traditionally configured by using LD 34 - Tone and Digital Switch.

To perform diagnostic activities using this Web page, follow the steps in [Procedure 71 "Performing Tone and Digit diagnostic activities" \(page 107\)](#).

#### Procedure 71 Performing Tone and Digit diagnostic activities

Step	Action
1	Select one of the following commands from the <b>Diagnostic Commands</b> drop-down lists: <ul style="list-style-type: none"> <li>• Loop Commands               <ul style="list-style-type: none"> <li>— STAT - Get status TDS loop</li> <li>— DISL - Disable tone and digit loop</li> <li>— DISX - Disable Conf/TDS/MFS card on loop I and I + 1</li> </ul> </li> </ul>

- ENLX - Enable Conf/TDS/MFS card on loop I and I + 1
  - ENLL - Enable tone and digit loop
  - MFR - Test ANI Feature Group D Multifrequency receiver units
  - TDS - Test outpulsers and channels on loop
  - Card and Unit Commands
    - SDTR - Get status of DTR/MFR or XDT card/unit
    - DISR - Disable specified TDS/MFS card/unit
    - ENLR - Enable the DTR/MFR card/unit
    - DTR - Test specified Digitone receiver card/unit
    - MFR - Test ANI Multifrequency Card/Unit
  - Miscellaneous Commands
    - ENLM - Enable all the TDS loops of the given IPMG
    - DISM - Disable all the TDS loops of the given IPMG
    - CMIN - Clear the minor alarm for all customers
    - CDSP - Clear the mtc display on active CPU
    - CMAJ - Clear major alarm and reset power fail transfer
    - MFR - Test all ANI Feature Group D MFR receiver units
- 2 Enter any required **Command Parameters**. The required parameters for the selected command are indicated to the right of the **Command Parameters** text box once the command is selected.
- 3 Click the corresponding **Submit** button.

---

--End--

---

### Trunk Diagnostics

Click the **Trunk Diagnostics** link in the list of **Maintenance** diagnostic tools to open the **Trunk Diagnostics** Web page as shown in [Figure 36 "Trunk Diagnostics Web page"](#) (page 109).

**Figure 36**  
**Trunk Diagnostics Web page**

Managing: **192.167.102.3**  
 System » Maintenance » Trunk Diagnostics

---

### Trunk Diagnostics

Diagnostic Commands	Command Parameters	Action
- ---- Card Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- Unit Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- Customer Route Commands ----	<input type="text"/>	<input type="button" value="Submit"/>
- ---- Miscellaneous Commands ----	<input type="text"/>	<input type="button" value="Submit"/>

Instruction: Select command, add value and click on [Submit]

This Web page is used to test and maintain trunk cards. The commands available from this Web page correspond to the data traditionally maintained by using LD 36 - Trunk Diagnostic.

To use the card commands, follow the steps in [Procedure 72 “Performing Trunk card commands”](#) (page 109).

#### **Procedure 72** **Performing Trunk card commands**

Step	Action
1	Select one of the following commands from the first <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a STAT - Get card status</li> <li>b ENLC - Enable and reset card</li> <li>c DISC - Disable card</li> </ul>
2	Enter the required command parameters in the <b>Command Parameters</b> text box.

- 3 Click **Submit**.

---

--End--

---

To use the unit commands, follow the steps in [Procedure 73 “Performing Trunk unit commands”](#) (page 110).

**Procedure 73**  
**Performing Trunk unit commands**

---

<b>Step</b>	<b>Action</b>
1	Select one of the following commands from the second <b>Commands</b> drop-down list: <ul style="list-style-type: none"><li>a ENLU - Enable unit</li><li>b LDIC - Number of days since last inc. call</li><li>c DISU - Disable unit</li><li>d RSET - Reset thresholds for the trunk</li><li>e TPPM - Test the specified PPM trunk</li></ul>
2	Enter the required command parameters in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .

---

--End--

---

To use the customer route commands, follow the steps in [Procedure 74 “Performing Trunk customer route commands”](#) (page 110).

**Procedure 74**  
**Performing Trunk customer route commands**

---

<b>Step</b>	<b>Action</b>
1	Select one of the following commands from the third <b>Commands</b> drop-down list: <ul style="list-style-type: none"><li>a LDIC - List days since last incoming call for customer</li><li>b LMAX - List trunk with max idle days for customer</li><li>c LNDS - List trunks with no disconnect sup. for customer</li><li>d LOVF - List threshold overflows for customer</li><li>e RAN - Test recorded announcement device</li></ul>
2	Enter the required command parameters in the <b>Command Parameters</b> text box.

3 Click **Submit**.

---

--End--

---

To use the miscellaneous commands, follow the steps in [Procedure 75 "Performing Trunk miscellaneous commands"](#) (page 111).

**Procedure 75**  
**Performing Trunk miscellaneous commands**

Step	Action
1	Select one of the following commands from the fourth <b>Commands</b> drop-down list: <ul style="list-style-type: none"> <li>a CMIN - Clear minor alarm for all customers</li> <li>b CDSP - Clear the mtc display on active CPU</li> </ul>
2	Enter the required command parameters in the <b>Command Parameters</b> text box.
3	Click <b>Submit</b> .

---

--End--

---

### Zone Diagnostics

Click the **Zone Diagnostics** link in the list of **Maintenance** diagnostic tools to open the **Maintenance Commands for Zones** Web page as shown in [Figure 37 "Maintenance Commands for Zones Web page"](#) (page 112).

**Figure 37**  
**Maintenance Commands for Zones Web page**

Managing: **192.167.102.3**  
 System » [Maintenance](#) » Maintenance Commands for Zones

---

### Maintenance Commands for Zones

**Action**

**Zone Number**

---

Zone Number	State	Resource Type	Intrazone Strategy	Zone Intent	Bandwidth(Kbps)	Usage(Kbps)	Peak(%)
0	ENABLED	SHARED	BQ	MO	1000000	0	0
1	ENABLED	SHARED	BQ	MO	1000000	0	0
2	ENABLED	SHARED	BQ	VTRK	1000000	0	0
3	ENABLED	SHARED	BQ	MO	1000000	0	0

Number of Zones configured = 4

This Web page is used to enable and disable zones and to view various parameters, properties, and behaviors associated with the configured zones. The commands available from this Web page correspond to the data traditionally maintained by using LD 117 - Ethernet and Alarm Management.

This Web page also includes a table that shows the status and settings for the configured zones.

To perform maintenance activities using this Web page, follow the steps in [Procedure 76 "Performing Zone maintenance activities" \(page 112\)](#).

#### **Procedure 76** **Performing Zone maintenance activities**

Step	Action
1	Select one of the following commands from the <b>Actions</b> drop-down list: <ul style="list-style-type: none"> <li>a Print Intrazone Statistics per Local Zone (PRT INTRAZONE)</li> </ul>

- b Print Bandwidth Property (PRT ZBW)
  - c Print Description (PRT ZDES)
  - d Print Dialing Plan and Access Codes (PRT ZDP)
  - e Print Time Change property (PRT ZTP)
  - f Show Branch Office Behaviour (STAT ZBR)
  - g Show Status (STAT ZONE)
  - h Enable a Zone (ENL ZONE)
  - i Disable a Zone (DIS ZONE)
  - j Enable a Zone's Branch Office Behaviour (ENL ZBR)
  - k Disable a Zone's Branch Office Behaviour (DIS ZBR)
  - l Print Adaptive Network Bandwidth Management and CAC Parameters (PRT ZCAC)
  - m Print Interzone Statistics (PRT INTERZONE)
  - n Reset CAC Statistics (CLR CACR)
  - o Print Zone Alternate Prefix Information (PRT ZALT)
  - p Show Alternate Routing Status (STAT ZALT)
  - q Print Alarm Suppression Time Period (PRT ZAST)
- 2 Select the **Zone Number** assigned to a configured zone from the drop-down list.
  - 3 Click **Submit**.

---


--End--

---

## Loops

To configure or edit Loops (Common Equipment) information, click the **Core Equipment > Loops** link of the **System** branch of the Element Manager navigator. The **Common Equipment** Web page appears (see [Figure 38 "Loops Web page" \(page 114\)](#)).

**Figure 38**  
**Loops Web page**



The **Common Equipment** Web page contains buttons that act as links to additional Web pages. The following functions can be performed from these pages:

- add and delete Tone and Digit Switch (TDS) numbers
- add and delete Digital Trunk Interface Loop (DLOP) numbers
- add and delete Conference loop (CONF) numbers
- configure parameters for the following Feature Packages:
  - Integrated Digital Access (Package 122)
  - 2 Mbit Digital Trunk Interface (Package 129)
  - Dial Tone Detection (Package 138)
  - 2.0 Mb/s Primary Rate Interface (Package 154)

The information entered in this section corresponds to CEQU (Common Equipment) data traditionally configured using LD 17 - Configuration Record 1.

To save changes made in this section, click **Submit** at the bottom of the **Common Equipment** Web page.

To check the status of a loop, select a loop and click on **Status** button. The loop status is displayed below in the system response pane.

Managing: 192.168.209.63 Username: admin  
System » Core Equipment » Loops

### Loops

-Select a loop-- Add... Enable Disable Status Delete Refresh

Loop Number *	Loop Type	Current status
1 <input type="radio"/> 000	Digital Trunk Interface	
2 <input type="radio"/> 003	2.0 Mb/s Digital Trunk Interface	
3 <input type="radio"/> 016	Extended Conference	
4 <input type="radio"/> 030	DPNSS Channel Switch	
5 <input type="radio"/> 034	2.0 Mb/s Primary Rate Interface	
6 <input type="radio"/> 036	Tone and Digit Switch	
7 <input type="radio"/> 045	Digital Trunk Interface	
8 <input type="radio"/> 047	MG Conference	
9 <input checked="" type="radio"/> 223	IP Conference	

System Response Hide

```

STAT 223
-----
IPCNFC 00 DSBL 00 BUSY 00 REQ
IPCHAN 00 DSBL 00 BUSY 00 REQ

```

In the above Loops web page, from the **Select a loop** drop-down list choose IP Conference and then click **Add**. The **IP Conference Loop Number Details** web page appears.

Managing: 192.168.55.143 Username: admin  
System » Core Equipment » Loops » IP Conference Loop Number Details

### IP Conference Loop Number Details

IP Conference loop number:  \* ( 0 - 255 )  
Node Id:  \* ( 0 - 9999 )

\* Required value. Save Cancel

Enter IP Conference loop number, Node Id and then click **Save**.

In the Loops web page, from the **Select a loop** drop-down list choose IP Tone and Digit Switch and then click **Add**. The **IP TDS Loop Number Details** web page appears.

Managing: 192.168.55.143 Username: admin  
System » Core Equipment » Loops » IP TDS Loop Number Details

### IP TDS Loop Number Details

IP TDS loop number:  \* ( 0 - 255 )  
Node Id:  \* ( 0 - 9999 )

\* Required value. Save Cancel

Enter IP TDS loop number, Node Id and then click **Save**.

## Superloops

To view, configure or edit Superloop information, click the Core Equipment > Superloop link of the System branch of the Element Manager navigator. The **Superloops** Web page appears as shown in [Figure 39 "Superloops Web page"](#) (page 116).

**Figure 39**  
**Superloops Web page**

Managing: [172.16.100.2](#)  
System » Core Equipment » Superloops

### Superloops

Superloop Number *	Superloop Type
1 <input type="radio"/> 4	IPMG

To view, configure, or edit a Superloop click on the corresponding Superloop Number. The **Superloops Details** Web page appears as shown in [Figure 40 "Superloop Details Web page"](#) (page 116)

**Figure 40**  
**Superloop Details Web page**

Managing: [172.16.100.2](#)  
System » Core Equipment » [Superloops](#) » Superloops Details(4 IPMG)

### Superloops Details(4 IPMG)

**Shelf 0**

Zone number:  (0 - 255)

IP based media gateway 0:

ELAN IP address:

IPMG type: MGC

ELAN passthrough port:

Faceplate ELAN port:

Backplane ELAN connection:

TLAN passthrough port:

Faceplate TLAN port:

Backplane TLAN connection:

**Shelf 1**

Zone number:  (0 - 255)

IP based media gateway:

ELAN IP address:

IPMG type: MGC

ELAN passthrough port:

Faceplate ELAN port:

Backplane ELAN connection:

TLAN passthrough port:

Faceplate TLAN port:

Backplane TLAN connection:

The information entered on this Web page corresponds to the Superloop (SUPL) command available in LD 97 - Configuration Record 2.

To save changes made in the **Superloop Details** Web page, click Save at the bottom.

To add a Superloop, click the Add button on the **Superloops** Web page. The **Add Superloop** Web page appears, as shown in [Figure 41 "Add Superloop Web page"](#) (page 117).

**Figure 41**  
**Add Superloop Web page**

Managing: [172.16.100.2](#)  
System > Core Equipment > Superloops > Add Superloop

### Add Superloop

Superloop: 0

Superloop type: Carrier

Network card slot:  Left  
 Right

Extended peripheral equipment controller:  \* (1 - 95)

Select the Superloop type from the drop-down list. For IPMG superloop type, the Add Superloop web page appears as shown in the following figure.

**Figure 42**  
**Add IPMG Superloop**

Managing: [192.168.209.105](#) Username: admin2  
System > Core Equipment > Superloops > Add Superloop

### Add Superloop

Superloop: 52

Superloop type: IPMG

Shelf 0	Shelf 1
Bandwidth zone number: <input type="text"/> (0 - 255)	Bandwidth zone number: <input type="text"/> (0 - 255)
ELAN IP address: 192.1	ELAN IP address: <input type="text"/>
IPMG type: MGC	IPMG type: MGC
ELAN passthrough port: CE	ELAN passthrough port: CE
Faceplate ELAN port: 1E	Faceplate ELAN port: 1E
Backplane ELAN connection: 1ELAN	Backplane ELAN connection: 1ELAN
TLAN passthrough port: CT	TLAN passthrough port: CT
Faceplate TLAN port: 2T	Faceplate TLAN port: 2T
Backplane TLAN connection: 2TLAN	Backplane TLAN connection: 2TLAN

Save Cancel

Fill in the appropriate information and click Save to add the new Superloop.

## MSDL/MSIP Cards

The Multipurpose Serial Data Link / Multi-Purpose ISDN Signaling Processor (MSDL/MSIP) Cards navigation link appears the **Fast Download Control Web** page, as shown in [Figure 43 "Fast Download Control Web page"](#) (page 118).

**Figure 43**  
**Fast Download Control Web page**

Card Type	Download Type
1 Application Module Link	Conditional
2 Basic Rate Interface Trunk	Conditional
3 Basic Rate Signaling Concentrator	Conditional
4 Basic Rate Signaling Concentrator Application	Conditional
5 BRI Line Cards	Conditional
6 BRI Trunk Universal ISDN Protocol Engine	Conditional
7 D-Channel Cards	Conditional
8 DITI Application Loadware	Conditional
9 Meridian Packet Handler	Conditional
10 Multipurpose ISDN Signaling Link Cards	Conditional
11 Multipurpose Serial Data Link Cards	Conditional
12 Primary Rate Interface Universal ISDN Protocol Engine	Conditional
13 Serial Data Interface Cards	Conditional
14 T1/E1 Application Loadware	Conditional

The **Fast Download Control** Web page appears only for large systems. The page displays the table with the card type and the download type. The download type for any card can be changed.

To configure download type for a single card, follow the steps in [Procedure 77 "Editing Fast Download Control \(single card\)"](#) (page 118).

### Procedure 77 Editing Fast Download Control (single card)

Step	Action
1	From the <b>Fast Download Control</b> Web page, click on the card you want to edit. The <b>Edit</b> Web page for the selected card appears.
2	Choose the <b>Download type</b> from the drop-down menu list.
3	Click <b>Save</b> or click <b>Cancel</b> to return to the <b>Fast Download Control</b> Web page.

--End--

To configure download type for all cards, follow the steps in [Procedure 78](#) "Editing Fast Download Control all cards" (page 119).

**Procedure 78**  
**Editing Fast Download Control all cards**

Step	Action
1	From the <b>Fast Download Control</b> Web page, click <b>Edit All</b> to edit all the cards in the list. The <b>Edit All</b> Web page appears.
2	Choose the <b>Download type</b> from the drop-down menu list.
3	Click <b>Save</b> or click <b>Cancel</b> to return to the <b>Fast Download Control</b> Web page.

--End--

## Conference/TDS/Multifrequency Cards

Click on the **Conference/TDS/Multifrequency Cards** link of the Element Manager Navigator to open the **Conference/TDS/Multifrequency Cards** Web page, as shown in [Figure 44](#) "Conference/TDS/Multifrequency Cards Web page" (page 119).

**Figure 44**  
**Conference/TDS/Multifrequency Cards Web page**


Select a **Conference Pad** from the list, enter a **Dual Tone Multifrequency** value and click **Save** or click **Cancel** to return to the **System Overview** Web page.

## Tone Senders and Detectors

Element Manager supports the configuration of Digitone receivers, Tone Detectors, and Multi Frequency Senders and Receivers. Click the **Core Equipment > Tone Senders And Detectors** link in the **System** branch of

the Element Manager navigator. The **Tone Senders And Detectors** Web page appears, as shown in [Figure 45 "Tone Senders and Detectors Web page"](#) (page 120).


**Figure 45**  
**Tone Senders and Detectors Web page**



### Digitone Receivers

To display details of and to configure Digitone Receivers, from the **Tone Senders And Detectors** Web page, click the **Digitone Receivers** link. The **Digitone Receivers** Web page appears, as shown in [Figure 46 "Digitone Receivers Web page"](#) (page 120).

**Figure 46**  
**Digitone Receivers Web page**




This Web page is used to display details of Digitone Receivers. Users can view, add, delete, and move Terminal Numbers.

To delete a Digitone Receiver, select the radio button beside the Terminal Number and click **Delete**.

To move a Digitone Receiver card from one terminal to another, from the **Digitone Receivers** Web page, select the radio button beside the Terminal Number and click **Move**. The **Move Digitone Receiver** Web page appears, as shown in [Figure 47 "Move Digitone Receiver Web page" \(page 121\)](#).

**Figure 47**  
**Move Digitone Receiver Web page**



Managing: [192.167.102.3](#)  
System » Core Equipment » [Tone Senders and Detectors](#) » [Digitone Receivers](#) » Move

---

### Move Digitone Receiver

Source Terminal Number: 004 0 03 00  
Destination Terminal Number:  -  
Source and Destination Loop Number should be the same.

Enter the Destination Terminal Number and click **Save**.

To delete a Digitone Receiver, select the radio button beside the Terminal Number and click **Delete**.

### Multi Frequency Receivers

To display details of and to configure Multi Frequency Receivers, from the **Tone Senders And Detectors** Web page, click the **Multi Frequency Receivers** link. The **Multi Frequency Receivers** Web page appears, as shown in [Figure 48 "Multi Frequency Receivers Web page" \(page 122\)](#).

**Figure 48**  
**Multi Frequency Receivers Web page**

Managing: [192.167.102.3](#)  
 System » Core Equipment » [Tone Senders and Detectors](#) » Multi Frequency Receivers

---

## Multi Frequency Receivers

Maintenance Commands

[Refresh](#)

	Terminal Number ▲	Card Density	Last Modified Date
1	<input type="radio"/> 008 0 00 01	8D	19 FEB 2007
2	<input type="radio"/> 008 0 00 02	8D	19 FEB 2007

This Web page is used to display details of Multi Frequency Receivers. Users can view, add, delete, and move Terminal Numbers.

To delete a Multi Frequency Receiver, select the radio button beside the Terminal Number and click **Delete**.

To move a Multi Frequency Receiver card from one terminal to another, from the **Multi Frequency Receivers** Web page, select the radio button beside the Terminal Number and click **Move**. The **Move Multi Frequency Receiver** Web page appears, as shown in [Figure 49 "Move Multi Frequency Web page"](#) (page 122).

**Figure 49**  
**Move Multi Frequency Web page**

Managing: [192.167.102.3](#)  
 System » Core Equipment » [Tone Senders and Detectors](#) » [Multi Frequency Receivers](#) » Move

---

## Move Multi Frequency Receiver

Source Terminal Number: 004 0 03 00  
 Destination Terminal Number:  -  
Source and Destination Loop Number should be the same.

Enter the Destination Terminal Number and click **Save**.

### Class Modem Units

To display details of and to configure Class Modem Units, from the **Tone Senders And Detectors** Web page, click the **Class Modem Units** link. The **Class Modem Units** Web page appears, as shown in [Figure 50 "Class Modem Units Web page"](#) (page 123).

**Figure 50**  
**Class Modem Units Web page**

Managing: [192.167.102.3](#)  
 System » Core Equipment » [Tone Senders and Detectors](#) » Class Modem Units

### Class Modem Units

Maintenance Commands

[Refresh](#)

	Terminal Number	Card Density	Last Modified Date
1	<input type="radio"/> 008 0 10 00	8D	19 FEB 2007

This Web page is used to display details of Class Modem Units. Users can view, add, delete, and move Terminal Numbers.

To delete a Class Modem Unit, select the radio button beside the Terminal Number and click **Delete**.

To move a Class Modem Unit card from one terminal to another, from the **Class Modem Unit** Web page, select the radio beside the Terminal Number to move and click **Move**. The **Move Class Modem Units** Web page appears, as shown in [Figure 51 "Move Class Modem Units Web page"](#) (page 123).

**Figure 51**  
**Move Class Modem Units Web page**

Managing: [192.167.102.3](#)  
 System » Core Equipment » [Tone Senders and Detectors](#) » [Class Modem Units](#) » Move

### Move Class Modem Unit

Source Terminal Number: 004 0 04 00  
 Destination Terminal Number:  -  
Source and Destination Loop Number should be the same.

Enter the Destination Terminal Number and click **Save**.

## Extended Dial Tone Detectors

To display details of and to configure Extended Dial Tone Detectors, from the **Tone Senders And Detectors** Web page, click the **Extended Dial Tone Detectors** link. The **Extended Dial Tone Detectors** Web page appears, as shown in [Figure 52 "Extended Dial Tone Detectors Web page" \(page 124\)](#).

**Figure 52**  
**Extended Dial Tone Detectors Web page**

Managing: [192.167.102.3](#)  
System » Core Equipment » [Tone Senders and Detectors](#) » Extended Dial Tone Detectors

### Extended Dial Tone Detectors

Maintenance Commands

	Terminal Number *	Extended Tone Detector Table	Dial Tone Detection	Last Modified Date
1 <input type="radio"/>	<a href="#">008 0 04 03</a>	00	Yes	19 FEB 2007

This Web page is used to display details of Extended Dial Tone Detectors. Users can view, add, delete, and move Terminal Numbers.

To delete an Extended Dial Tone Detector, select the radio button beside the Terminal Number and click **Delete**.

To add an Extended Dial Tone Detector, click **Add**. The **Add Extended Dial Tone Detector** Web page appears, as shown in [Figure 53 "Add Extended Dial Tone Detector Web page" \(page 125\)](#).

**Figure 53**  
**Add Extended Dial Tone Detector Web page**

Managing: [192.167.102.3](#)  
 System > Core Equipment > Tone Senders and Detectors > Extended Dial Tone Detectors > Add

---

### Add Extended Dial Tone Detector

Terminal Number:  \*

Extended Tone Detector Table:  ▼

Dial Tone Detection:

**Procedure 79**  
**Adding an Extended Dial Tone Detector**

Step	Action
1	Enter the Terminal Number of the Extended Dial Tone Detector.
2	Select the <b>Extended Tone Detector Table</b> from the drop-down list.
3	Check the box beside <b>Dial Tone Detection</b> , if required.
4	Click <b>Save</b> .

--End--

To move an Extended Dial Tone Detector card from one terminal to another, from the **Extended Dial Tone Detectors** Web page, select the radio button beside the Terminal Number to move and click **Move**. The **Move Extended Dial Tone Detectors** Web page appears, as shown in [Figure 54 "Move Extended Dial Tone Detectors Web page" \(page 126\)](#).

**Figure 54**  
**Move Extended Dial Tone Detectors Web page**

Managing: [192.167.102.3](#)  
System » Core Equipment » [Tone Senders and Detectors](#) » [Extended Dial Tone Detectors](#) » Move

---

### Move Extended Dial Tone Detector

Source Terminal Number: 004 0 02 00  
Destination Terminal Number:  -  
Source and Destination Loop Number should be the same.

Enter the Destination Terminal Number and click **Save**.

## Peripheral Equipment

The **Peripheral Equipment** Web page displays parameters such as Timers, Multi-Frequency levels, Make-Break ratio.

To view, configure, or edit Peripheral Equipment click the Peripheral Equipment link of the System branch of the Element Manager navigator. The **Peripheral Equipment** Web page appears as shown in [Figure 55 "Peripheral Equipment Web page" \(page 127\)](#).

**Figure 55**  
**Peripheral Equipment Web page**

Managing: **172.16.100.2**  
 System » Peripheral Equipment

---

### Peripheral Equipment

Companding law:  A Law  
 Mu Law

Quiet Code: 0

Allowable Continuity Faults:  \* (1 - 32767 per time slice)

Cyclic Redundancy Check Failures:  \* (1 - 32767 per input cable)

#### Timers

Minimum Switchhook Flash:  \* (20 - 768 ms)

Maximum Switchhook Flash:  \* (120 - 1275 ms)

Off Hook Validation:  \* (0 - 1275 ms)

Dial Pulse:  \* (15 - 120 ms)

Interdigit:  \* (0 - 1275 ms)

Dial Pulse On:  \* (15 - 1275 ms)

Post Flash:  \* (0 - 1275 ms)

#### Multi Frequency

Minimum Receiver Level:

Transmit Level Code for Identifier 0:

Transmit Level Code for Identifier 1:

#### Make-Break Ratio

10 Pulse:  (pulse per second)

12 Pulse:  (pulse per second)

20 Pulse:  (pulse per second)

[Fast Download Control](#)

To configure or edit the Peripheral Equipment, enter the appropriate values and click **Save**. If you enter invalid values, the system displays an error message and the original values are retained. A link for Fast Download Control is provided.



---

# IP Network

---

## Contents

This section contains information about the following topics:

- “Introduction” (page 129)
- “IP Network” (page 129)
  - “IP Telephony Nodes” (page 129)
  - “Media Gateways” (page 149)
  - “32 Channel Secure Media Card (MC32S) commands” (page 162)
  - “Zones” (page 164)
  - “Network Address Translation (NAT)” (page 175)
  - “Quality of Service Thresholds (QoS)” (page 176)
  - “Personal Directories” (page 179)
  - “Unicode Name Directory” (page 179)
- “Interfaces” (page 180)
- “Engineered Values” (page 185)
- “Emergency Services” (page 189)
- “Geographic Redundancy” (page 203)
- “Software” (page 206)

## Introduction

The **IP Network** link of the **System** branch of the Element Manager navigator enables the user to view the version of software that is installed on the elements.

## IP Network

### IP Telephony Nodes

The Node management in Communication Server 1000 Release 6.0 introduces a new work flow on the User Interface (UI) with Add and Modify functions of the Node. This introduces the Cluster concept, where

a Cluster represents a group of physical servers that shares the same configuration properties. The same set of services are configured and enabled on all physical servers within a Cluster.

The Nodes also provide scalability (by deploying multiple Nodes) and optionally Load sharing (by distributing processing to other Node members).

Each Node belongs to a Call Server and has a one-to-many relationship with Call Server. The IP Nodes resides on two LAN subnets: ELAN and TLAN.

The Node must have minimum one signalling server as a Node element in order for that Node to be operational. The administrator can add as many servers to be part of the Node and all the Node elements will have the same set of application services enabled. However, only one physical server can be active at a time. This active server can run all the configured services on that physical server, for example, UNISim LTPS, SIPGw, and H323Gw can all be configured and enabled on the same server. The LTPS application is one exception where several servers can run active instances of LTPS service. The LTPS application does support load sharing.

The SIP Line application in CS 1000 Release 6.0 cannot co-reside with LTPS or any other virtual trunk applications like SIPGw or H323Gw. The Node management interface does not allow the user to configure SIP Line service any other application services.

The gateway application services operate on a service IP address configured to be on the TLAN of the network and this IP address floats between active and standby servers. The standby server takes over this IP address when the active instance goes down. The active and standby roles are dynamically assigned through a service specific election process that runs on the servers.

In CS 1000 Release 6.0, the Centralized Deployment Manager (CDM), deploys software applications from Unified Communication Management (UCM).

The Node management interface adds servers in to a Node from the list of servers that UCM has learned. Before you add the servers to a Node, it is required that the CDM feature deploys the necessary software application to each of the Linux servers.

To view the **IP Telephony Nodes** Web page, select the Nodes: Servers, Media Cards link in the IP Network branch of the Element Manager navigator. The IP Telephony Node Web page appears as shown in, [Figure 56 "IP Telephony Nodes Web page"](#) (page 131).

**Figure 56**  
**IP Telephony Nodes Web page**

Managing: 192.168.209.63 Username: admin2  
System » IP Network » IP Telephony Nodes

**IP Telephony Nodes**  
Click the Node ID to view or edit its properties.

Add... Import... Export... Delete Print | Refresh

Node ID	Components	Enabled Applications	ELAN IP	Node/TLAN IPv4	Status
1	3	LTPS, PD, Gateway ( SIPGw )	-	192.168.110.110	Changed
43	1	LTPS, PD, Gateway ( SIPGw )	-	192.168.55.43	Changed
54	1	LTPS, PD	-	0.0.0.2	Failed
59	2	LTPS, Gateway ( SIPGw )	-	192.168.55.59	Changed
87	2	LTPS, PD, Gateway ( SIPGw )	-	192.168.55.2	Failed
175	1	NONE	-	192.168.55.177	Changed
1111	1	NONE	-	192.168.55.177	Changed
9990	1	NONE	-	192.168.55.177	Changed
9999	1	NONE	-	192.168.55.177	Changed

Show:  Nodes  Component Servers and Cards  IPv6 Address

The **IP Telephony Nodes** Web page appears showing the following information:

- Node ID – the ID number for each node
- Components – the number of components associated to each node
- Enabled Applications – the applications enabled to each node
- ELAN IP – the IP address for the ELAN
- Node/TLAN IP – the IP address for the TLAN
- Status – the status of the node

The **IP Telephony Nodes** Web page also contains buttons that link to additional Web pages:

- Add - add a new node
- Import - Import a node files
- Export - export a node file
- Delete - delete a node

To view Component Servers and Cards check the Component Servers and Cards box at the bottom of the **IP Telephony Nodes** Web page.

To view IP address, check the IPv6 Address box at the bottom of the **IP Telephony Nodes** Web page.

### Add a new IP Telephony Node

Click the Add button from the summary page to start the add work flow for creating a new Node to be part of the Call Server where Element Manager is hosted. The **New IP Telephony Node** Web page appears as shown in, [Figure 57 "New IP Telephony Node Web page"](#) (page 132). For information about adding a new IP Telephony node refer to *Signaling Server IP Line Applications Fundamentals* (NN43001-125).

**Figure 57**  
**New IP Telephony Node Web page**

Managing: 192.168.55.143 Username: admin2  
System > IP Network > IP Telephony Nodes > New IP Telephony Node

### New IP Telephony Node

Step 1: Define the new Node and its services.  
You will also require pre-configured servers with appropriate application software already deployed to host the selected services.

Node ID:  \* (0-9999)

Call server IP address:  \*

TLAN address type:  IPv4 only  
 IPv4 and IPv6

**Embedded LAN (ELAN)**

Gateway IP address:  \*

Subnet mask:  \*

**Telephony LAN (TLAN)**

Node IPv4 address:  \*

Subnet mask:  \*

Node IPv6 address:

Applications:  SIP Line  
 UNISim Line Terminal Proxy Server (LTPS)  
 Virtual Trunk Gateway (SIPGw, H323Gw)  
 Personal Directory (PD)

**Figure 58**  
**New IP Telephony Node Web page1**

Managing: 192.168.55.143 Username: admin2  
System > IP Network > IP Telephony Nodes > New IP Telephony Node

### New IP Telephony Node (ID:44)

Step 3: Virtual Trunk Gateway Configuration Details.

General | SIP Gateway Settings | SIP Gateway Services

Vtrk gateway application:  Enable gateway service on this node

**General**

Vtrk gateway application: SIP Gateway (SIPGw) ▼

SIP domain name:  \*

Local SIP port:  \* (1 - 65535)

Gateway endpoint name:  \*

Gateway password:  \*

Application node ID:  \* (0-9999)

Enable failsafe NRS:

SIP ANAT:  IPv4


**Virtual Trunk Network Health Monitor**

Monitor IP addresses (listed below)  
Information will be captured for the IP addresses listed below.

Monitor IP:  Add

Monitor addresses:  Remove

**Figure 59**  
**New IP Telephony Node Web page2**



Managing: 192.168.55.143 Username: admin2  
 System » IP Network » IP Telephony Nodes » New IP Telephony Node

**New IP Telephony Node (ID:44)**  
 Step 3: Virtual Trunk Gateway Configuration Details.

General | **SIP Gateway Settings** | SIP Gateway Services

SIP ANAT:  IPv4  
 IPv6

**SIP Gateway Settings**

TLS Security: Security Disabled

Port: 5061 (1 - 65535)

Number of byte re-negotiation: 0

Options:  Client authentication  
 X509 certificate authority


Proxy Or Redirect Server:

Primary TLAN IP address: 0.0.0.0  
The IP address can have either IPv4 or IPv6 format based on the value of "TLAN address type"

Port: 5060 (1 - 65535)

Transport protocol: TCP

**Figure 60**  
**New IP Telephony Node Web page3**



Managing: 192.168.55.143 Username: admin2  
 System » IP Network » IP Telephony Nodes » New IP Telephony Node

**New IP Telephony Node (ID:44)**  
 Step 4: Confirm new Node details.  
 Review the new Node definition and click Finish to commit.

Node ID: 44

Node IPv4 address: 1.2.3.4

Node IPv6 address:

Domain: s

Application(s): Gateway ( SIPGw )

Servers: hpss8

Save the new Node by clicking Finish below. Configuration details will be transmitted to associated servers, which will require a reboot.

In order to bring the Node into service, you must create a routing entry in the associated customer record, in order to associate user phones with the service applications provided by the Node.

Enter all the fields with appropriate values and click on **Finish** to save the new node.

### Import IP Telephony Nodes file

Use the import functionality to import a local configuration file from a local work station (XML format) or from a Linux signaling server.

In the case of configuration file imported from a local work station, you must enter the configuration parameters in the file in a standard template model. This template follows the same model as the existing config.ini

file format. You can enter as much as information to a local file and then import, edit, and save, using the import UI page, on the Call Server just like any IP Telephony Node.

Click the Import button, the **IP Telephony Import** Web page appears as shown in, [Figure 61 "Import IP Telephony Nodes Web page" \(page 134\)](#). The options for the import operation are displayed in the **IP Telephony Import** Web page, the options are import from an XML file stored on local work station or import from a Leader server that is already part of a Node.

**Figure 61**  
**Import IP Telephony Nodes Web page**

The selected XML file that is selected to import goes through two sets of validations before the file can be saved on to the system:

- An invalid XML file format is determined when you click the Preview button to preview the content, the UI will be displayed with a message indicating invalid XML file.
- If the file is valid, the next set of validations make sure that the content inside passes the filed and dependency validations. This validation is determined when you click the Save button to save the configuration to the Call Server.

When Node configuration files generated by TM application are to be imported by EM, you must remove the ^M (control M) characters from the Node files using procedure [Procedure 80 "Removing \(control M\) characters from Telephony Manager configuration files" \(page 135\)](#).

The Node configuration files generated by TM application are obtained from the same place inside the Call Server (`/u/db/node/`) as any of the EM application generated Node files.

Whether TM generated or EM generated, the Node configuration file names would be the same (nodexxxx.cfg and nodexxxx.btp) when stored on the Call Server.

During a Call Server upgrade, if the Node files that are being backed up actually come from TM application then you must remove the ^M characters from the files. Use the following procedure before they are loaded with an EM application.

**Procedure 80**  
**Removing (control M) characters from Telephony Manager configuration files**

Step	Action
1	Use an FTP program to move the Node configuration files from the Call Server to any unix server, the files would have the naming as nodexxxx.cfg and nodexxxx.btp where the xxx is the node id number.
2	You can edit these config files to see if they have ^M characters present inside
3	If ^M characters are present, run the <code>dos2unix</code> command on each of the files.  The <code>dos2unix</code> command can be found on any unix server under <code>/usr/bin/</code> folder .
4	The syntax of the command would be as follows: <ul style="list-style-type: none"> <li>• <code>dos2unix &lt;old file name&gt; &lt;new file name&gt;</code> Keep the output file name the same as the input file name, you can check the time stamp and/or edit the file to verify if ^M characters have been removed.</li> <li>• Do this for both the xxxx.cfg and the xxxx .btp files. For example for node3434.cfg (config file) and node3434.btp (bootp file) the syntax would be: <pre>— dos2unix node3434 .cfg node3434 .cfg — dos2unix node3434 .btp node3434 .btp</pre> </li> </ul>
5	Edit the config and bootp files to check if the ^M chars have been removed.
6	Use an FTP program to move the the files back to the Call Server under <code>/u/db/node/</code> folder
7	Launch EM and open up the IP Node Telephony page, the Node summary page is displayed correctly.


--End--

## Export IP Telephony Node file

You can export a previously configured IP Telephony Node to an XML file format and save it to a local desktop. The Export function is limited to one selected Node at a time. If you select more than one node, the Export button remains disabled.

To export a IP Telephony Node to an XML file select a Node on the **IP Telephony Nodes** Web page and click Export. The export saves the configuration files in an XML format file as shown in [Figure 62 "Export IP Telephony Node file"](#) (page 136).

**Figure 62**  
**Export IP Telephony Node file**



## Delete an IP Telephony Node

To delete an IP Telephony Node select, the Node and click the **Delete** button. A confirmation window appears.

## Node Details

Click the Node ID to view or edit the properties of the node. The **Node Details** Web page for the Node selected appears as shown in, [Figure 63 "Node Details Web page"](#) (page 137).

**Figure 63**  
Node Details Web page

Managing: 192.168.209.111 Username: admin1  
System » IP Network » IP Telephony Nodes

**Node Details (ID: 99 - LTPS, PD, MS)**

Node ID: 99 \* (0-9999)

Call server IP address: 192.168.209.111 \*

Embedded LAN (ELAN)  
Gateway IP address: 192.168.209.1 \*  
Subnet mask: 255.255.255.0 \*

TLAN address type:  IPv4 only  
 IPv4 and IPv6

Telephony LAN (TLAN)  
Node IPv4 address: 2.3.6.54 \*  
Subnet mask: 255.255.255.0 \*

Node IPv6 address: 2120:2340:2345:3455:3330:0100:3456:9999

\* Required Value.

**Associated Signaling Servers & Cards**

Servers(s) with (hostname-ELAN IP-TLAN IP) not registered with primary security server: (Test\_Hostname-2.3.65.46-1.2.3.4), (hpss6-192.168.55.184-192.168.55.185)

Select to add

Hostname	Type	Deployed Applications	ELAN IP	TLAN IPv4	TLAN IPv6	Role
<input type="checkbox"/> hpss6	Signaling_Server	NONE	192.168.55.184	192.168.55.185	0000:0000:0000:0000:0000:0000:0000:0000	Leader
<input type="checkbox"/> Test_Hostname	Media Card	NONE	2.3.65.46	1.2.3.4		Follower

Show  IPv6 address

Note: Only server(s) that are not part of any other IP telephony node and deployed application(s) that match the service(s) selected for this node are available in the servers list.

The **Node Details** Web page is organized to list the IP Telephony common Node properties on the left side of the page and Application Service sections are on the right side. These appear as links that you can click to display in to the configuration parameter page. For example clicking the **Voice Gateway (VGW) and Codecs** link displays in to the **Voice Gateway (VGW) and Codecs** Web page as shown in, [Figure 64 "Voice Gateway \(VGW\) and Codecs Web page"](#) (page 137).

**Figure 64**  
Voice Gateway (VGW) and Codecs Web page

Managing: 192.168.55.152 Username: admin2  
System » IP Network » IP Telephony Nodes

**Node ID: 9992 - Voice Gateway (VGW) and Codecs**

General | [Voice Codecs](#) | [Fax](#)

General

Echo Cancellation:  Use canceller, with tail delay: 128

Dynamic attenuation

Voice Activity Detection Threshold: -17 (-20 - +10 DBM)

Idle Noise Level: -65 (-327 - +327 DBM)

Signaling Options:  DTMF Tone Detection  
 Low latency mode  
 Remove DTMF delay (squench DTMF from TDM to IP)  
 Modem/Fax pass-through  
 V.21 Fax Tone Detection  
 R factor calculation

Voice Codecs

Codec G711:  Enabled (required)

Voice payload size: 20 (milliseconds per frame)

Voice Playback (jitter buffer) delay: 40 80 (milliseconds)

Note: Changes made on this page will NOT be

Click the Save or Cancel to return you to the **Node Details** Web page. When you save on the **Voice Gateway (VGW) and Codecs** Web page saves only the codec parameters, you must click the Save button on the **Node Details** Web page to save the complete Node property.

You can configure the following IP Telephony Node Properties by clicking on the appropriate link on the **Node Details** Web page:

- Voice Gateway (VGW) and Codecs
- Quality of Service (QOS)
- LAN
- Numbering Zones
- MCDN Alternate Routing Treatment (MALT) Causes

You can configure the applications associated to the Node by clicking the appropriate link on the **Node Details** Web page. The applications associated to a Node appear on the left and can include applications such as the following:

- Terminal Proxy Server (TPS)
- Gateway (SIPGw)
- SIP Line
- LTPS
- Personal Directories (PD)

When you click on **Gateway (SIPGw)** link in the Node Details web page, the **Virtual Trunk Gateway Configuration Details** Web page displays as shown in the following figure.

Managing: 192.168.209.91 Username: sowdnhb  
System » IP Network » IP Telephony Nodes

### Node ID: 999 - Virtual Trunk Gateway Configuration Details

General | SIP Gateway Settings | SIP Gateway Services

Vtrk gateway application:  Enable gateway service on this node

General	Virtual Trunk Network Health Monitor
Vtrk gateway application: SIP Gateway (SIPGw) ▾	<input type="checkbox"/> Monitor IP addresses (listed below)
SIP domain name: nortel *	Information will be captured for the IP addresses listed below.
Local SIP port: 5060 * (1 - 65535)	Monitor IP: <input type="text"/> Add
Gateway endpoint name: nortel *	Monitor addresses:
Gateway password: <input type="password"/> *	<input type="text"/>
Enable failsafe NRS: <input type="checkbox"/>	Remove
SIP ANAT: <input type="radio"/> IPv4 <input checked="" type="radio"/> IPv6	

\* Required Value. Note: Changes made on this page will NOT be transmitted until the Node is also saved. Save

When you click on **Sip Line** link in the Node Details web page, the **Sip Line Configuration Details** Web page displays as shown in the following figure.

Managing: 192.168.209.111 Username: admin2  
System » IP Network » IP Telephony Nodes » Node Details » SIP Line Configuration

### Node ID: 1 - SIP Line Configuration Details

General | SIP Line Gateway Settings | SIP Line Gateway Service

SIP Line Gateway Service

Branch / GR Office Settings:

SLG Role: MO ▾

SLG Mode: S1/S2 ▾

MO SLG IP: 2001:db::98:53  
The IP address can have either IPv4 or IPv6 format based on the value of "TLAN address type"

MO SLG Port: 5070 \* (1 - 65535)

MO SLG Transport: TCP ▾

GR SLG IP: 2001:db::98:54  
The IP address can have either IPv4 or IPv6 format based on the value of "TLAN address type"

GR SLG Port: 5070 \* (1 - 65535)

GR SLG Transport: TCP ▾

IVR Settings:

SLG IVR proxy IP: 0.0.0.0

\* Required Value. Note: Changes made on this page will NOT be transmitted until the Node is also saved. Save Cancel


Enter the appropriate values in all the required fields and click **Save** to configure Sip line.

For complete information about IP Telephony Nodes configuration see, *Signaling Server IP Line Applications Fundamentals* (NN43001-125), *SIP Line Fundamentals* (NN43001-508), *Dialing Plans Reference* (NN43001-283), and *IP Peer Networking Installation and Commissioning* (NN43001-313).

## Nodes: Servers, Media Cards

Click the **IP Network > Maintenance and Reports** link in the **System** branch of the Element Manager navigator to open the **Node Maintenance and Reports** Web page, as shown in [Figure 65 "Node Maintenance and Reports Web page"](#) (page 140).

**Figure 65**  
**Node Maintenance and Reports Web page**



This Web page contains information about configured Signaling Servers and IP Telephony cards and is arranged by node. Click the **plus sign (+)** beside the Node ID number to view the elements assigned to the node.

For more information about IP Telephony, see *Signaling Server IP Line Application Fundamentals (NN43001-125)*.

Six buttons are located to the right of the TN column for each IP Telephony element:

- **GEN CMD** — Launches the **General Commands** Web page.
- **RPT LOG** — Launches the **Report Utility** Web page.
- **SYS LOG** — Launches the System log file Web page for Signaling Servers.
- **OM RPT** — Launches the **Operational Management Report** Web page.
- **Reset** — Resets the element.

**Note:** When resetting the Signaling Server on which the Web server is located, wait approximately five minutes before logging in again.

- **Virtual Terminal** — Opens a Telnet connection to the element over the Telephony Local Area Network (TLAN) subnet using the element's IP Address.
- **Status** — Displays the status of the element.

## General Commands

Click the **GEN CMD** button, located beside the information for an IP Telephony element as shown in [Figure 65 "Node Maintenance and Reports Web page"](#) (page 140), to open the **General Commands** Web page for that element. See [Figure 66 "General Commands Web page"](#) (page 141).

**Figure 66**  
**General Commands Web page**

From this Web page, users can issue commands to selected groups.

To issue an IP Line application command:

Step	Action
1	Select a group from the left-hand <b>Group</b> drop-down list. The corresponding commands for that group display in the <b>Command</b> drop-down list.
2	Select a <b>Command</b> from the <b>Command</b> drop-down list.
3	Click <b>Run</b> .

The results appear in the box at the bottom of the Web page.

--End--

Detailed procedures for issuing General Commands can be found in *Signaling Server IP Line Application Fundamentals (NN43001-125)*.

Commands related to the node password include:

- `nodePwdDisable` — disables the node password
- `nodePwdEnable` — enables the node password
- `nodePwdShow` — displays the node password
- `nodeTempPwdClear` — clears the temporary node password
- `nodePwdSet` — sets the node password
- `nodeTempPwdSet` — sets the temporary node password

Passwords must conform to certain compositional rules.

To set the node password:

Step	Action
1	Select <b>nodePwd</b> from the <b>Group</b> drop-down list.
2	Select <b>nodePwdSet</b> from the <b>Command</b> drop-down list.
3	Enter the password in the <b>Node Password</b> text box. The password must be 6 - 14 characters in length. Valid entries are digits 0 through 9, and special character *.
4	Click <b>RUN</b> . If a non-zero length password is configured, all IP Phones that attempt to register after the password is set display a prompt requesting the node password before enabling the TN to be modified.
--End--	

A temporary node password can be configured to give temporary user access to the TN for configuration. A temporary node password removes the need to distribute the node password and the requirement to change it afterwards. The temporary node password automatically deletes itself after it has been used the defined number of times or when the duration expires, whichever comes first.

To set a temporary node password:

Step	Action
1	Select <b>nodePwd</b> from the <b>Group</b> drop-down list.
2	Select <b>nodeTempPwdSet</b> from the <b>Command</b> drop-down list.
3	Enter the temporary password in the <b>Node Password</b> text box. The password must be 6 - 14 characters in length. Valid entries are digits 0 through 9, and special character *.
4	Enter the number of times that you want to enable the temporary password to be used in the <b>Uses</b> text box (maximum is 1000 times).
5	Enter the duration, in hours, for the temporary password in the <b>Timeout</b> text box (maximum is 240 hours).
6	Click <b>RUN</b> .
--End--	

From the **General Commands** Web page, any IP address can be pinged from this element. The default IP address is the address of the Call Server.


To ping an IP address:

Step	Action
1	Verify that the entry in the IP address text box is correct.
2	Enter the number of pings that to send in the <b>Number of Pings</b> text box.
3	Click <b>Ping</b> .
--End--	

### System Log

Click the **SYS LOG** button, located beside the information for the Signaling Server, to open the **Application Logs** Web page for the Signaling Server, as shown in [Figure 67 "Application Web page" \(page 144\)](#). The Application logs are part of the Base Manager.

**Figure 67**  
**Application Web page**



Element Manager redirects you to Base Manager to run the System Log for the Signaling Server. For more information about Application Logs and accessing Base Manager refer to *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315) and *Unified Communications Management Common Services Fundamentals* (NN43001-116).

### Signaling Server commands

Element Manager provides support for executing Signaling Server command line interface (CLI) maintenance commands.

To run Signaling Server commands from Element Manager, select the **Maintenance and Reports** link in the IP Network branch of Element Manager navigator. The **Node Maintenance and Reports** Web page appears as shown in, [Figure 65 "Node Maintenance and Reports Web page"](#) (page 140).


#### Procedure 81 Running Signaling Server commands

Step	Action
1	Choose a Signaling Server and click <b>GEN CMD</b> . The <b>General Commands</b> Web page appears. See, <a href="#">Figure 68 "Signaling Server General Commands"</a> (page 145).
2	Select the Signaling Server CLI command group that you want to access from the <b>Group</b> drop-down list.
3	Choose a command from the <b>Command</b> drop-down list.

4 Click **Run** to execute the command.

--End--

**Figure 68**  
**Signaling Server General Commands**




For a list of available Signaling Server commands that can be run using Element Manager, refer to *Software Input Output Reference — Maintenance* (NN43001-711).

### Operational Measurement Reports

The **OM** (Operational Measurement Report) **RPT** button enables users to view OM information. Click the **OM RPT** button, located beside information for an IP Telephony element as shown in [Figure 65 "Node Maintenance and Reports Web page"](#) (page 140), to open the **OM Reports** Web page for that element, as shown in [Figure 69 "OM Reports Web page"](#) (page 146).

**Figure 69**  
**OM Reports Web page**



To view an OM Report file:

Step	Action
1	In the Select File column, click the option button beside the OM Report to be viewed.  <b>Note:</b> The limit of OM Report files is eight. Only the eight most recent OM Report files are available on the system.
2	Click <b>View OM File</b> .

--End--


The contents of the file appear in the box at the bottom of the Web page.

### Virtual Terminal

The Virtual Terminal is an integral part of the enhanced navigation tools for Element Manager.

Click the **Virtual Terminal** button on the **Node Maintenance and Reports** Web page to open the **Virtual Terminal** window, as shown in [Figure 70](#) "Virtual Terminal window" (page 147).

**Figure 70**  
**Virtual Terminal window**



The Virtual Terminal is a Web-based window that enables access to the character-based interfaces supported by the components of the CS 1000system, including all overlays not supported by Element Manager Web pages. The Virtual Terminal can also be used to add new links to the system components or other Element Manager servers using the Bookmarks feature.

### ATTENTION

Virtual Terminal requires the Java Runtime Environment (JRE).

To access the Virtual Terminal for a particular IP device:

Step	Action
1	Choose the IP device you want to access on the <b>Node Maintenance and Reports</b> Web page.

- 2 Click the **Virtual Terminal** button beside that node.
- 3 Enter the user name and password.

---

--End--

---

For more information about accessing and using the Virtual Terminal, refer to [“Virtual Terminals” \(page 31\)](#).

### **Meridian Alternate Routing and Vacant Number Routing Causes**

This feature deals with Vacant Number Routing (VNR) calls at the CS 1000 that is routed over H323/SIP. Assume that the call fails to route to the destination (for example, with reason: No entry present in the NRS/SPS or due to rejection from the destination side). With this development, the call gets disconnected with a cause which matches one of the Meridian Alternate Routing (MALT) cause codes, or disconnects with an indication to “use MALT”. Based on this information, MALT is performed at the Call Server to retry the call using an alternate route. If MALT exhausts all the MALT routes in the VNR Route List Index then the treatment corresponding to the disconnect cause is provided.

If the call clearing message has the cause as ‘unassigned number’ or ‘invalid Number format’ in all the accessed entries of the VNR RLI, then vacant number treatment will be provided.

With the default MALT handling, there are six causes which perform MALT at the CS1K:

- 3 – No route to destination
- 27 – Destination is out of service
- 34 – No circuit or channel available
- 38 – Network out of service
- 41 – Temporary failure
- 42 – Switching equipment congestion

A configurable option is provided in Element Manager for the different vendors (subdivided into “all Nortel Component” and “third party”, but potentially extensible, should the need be identified) in order to configure causes (other than MALT causes) to do MALT at CS 1000. The EM provisions the below causes to be configured to perform MALT. The unassigned number cause will be by default configured to perform MALT for Nortel and Third Party vendors.

- 01 – unassigned number
- 20 – subscriber absent

- 47 – Resources unavailable
- 51 – Call rejected; blocked by MBG
- 52 – Outgoing call barred
- 53 – Outgoing call barred in closed user group
- 54 – Incoming call barred
- 55 – Incoming call barred in closed user group
- 63 – service or option not available
- 127 – Interworking unspecified

To configure MALT, click the **IP Network > Nodes: Severs, Media Cards** link in the **System** branch of the Element Manager navigator. The **IP Telephony Nodes** Web page appears. Click the **Node ID** of the node you want to configure and select the **MCDN Alternative Routing Treatment (MALT) Causes** hyperlink, the **MCDN Alternative Routing Treatment (MALT) Causes** Web page appears as shown in [Figure 71 "MCDN Alternative Routing Treatment \(MALT\) Causes Web page"](#) (page 149).

**Figure 71**  
**MCDN Alternative Routing Treatment (MALT) Causes Web page**

Managing: 172.16.100.2  
System > IP Network > IP Telephony Nodes

Node ID: 1200 - MCDN Alternative Routing Treatment (MALT) Causes

Nortel Vendor Causes:	Third Party Vendor Causes:
<input checked="" type="checkbox"/> UnassignedNumber	<input checked="" type="checkbox"/> UnassignedNumber
<input type="checkbox"/> Subscriber absent	<input type="checkbox"/> Subscriber absent
<input type="checkbox"/> Resources unavailable	<input type="checkbox"/> Resources unavailable
<input type="checkbox"/> Service or option not available	<input type="checkbox"/> Service or option not available
<input type="checkbox"/> Internetworking unspecified	<input type="checkbox"/> Internetworking unspecified
<input type="checkbox"/> Call rejected; blocked by MGB	<input type="checkbox"/> Call rejected; blocked by MGB
<input type="checkbox"/> Outgoing call barred	<input type="checkbox"/> Outgoing call barred
<input type="checkbox"/> Outgoing call barred in closed user group	<input type="checkbox"/> Outgoing call barred in closed user group
<input type="checkbox"/> Incoming call barred	<input type="checkbox"/> Incoming call barred
<input type="checkbox"/> Incoming call barred in closed user group	<input type="checkbox"/> Incoming call barred in closed user group

Note: Changes made on this page will NOT be transmitted until the Node is also saved.

Save Cancel

### ATTENTION

If a Media Card is added after the Linux server is upgraded, then a Node Save and Transfer is required. For more information, see *Signaling Server IP Line Applications Fundamentals* (NN43001-125).

## Media Gateways

To access Media Gateways in Element Manager select the **Media Gateways** link in the IP Network branch of Element Manager navigator. The **Media Gateways** Web page appears, as shown in [Figure 72 "Media Gateways Web Page"](#) (page 150).

Element Manager displays Media Gateway type as MGC for a Media Gateway Controller and MGX for an MG XPEC Media Gateway Extended Peripheral Equipment Controller. The MG XPEC is used to convert a CS 1000M Intelligent Peripheral Equipment shelf (IPE) to a CS 1000E Media Gateway.

**Figure 72**  
**Media Gateways Web Page**

Managing: [192.168.203.117](#) Username: admin2  
System » IP Network » Media Gateways

### Media Gateways

	IPMG	IP Address	Zone	Type
<input type="radio"/>	<a href="#">000.00</a>	47.11.216.79	000	<a href="#">MGC</a>
<input type="radio"/>	<a href="#">004.00</a>	255.255.254.11	002	<a href="#">MGC</a>
<input type="radio"/>	<a href="#">004.01</a>	1.2.3.1	004	<a href="#">MGX</a>
<input type="radio"/>	<a href="#">008.00</a>	192.168.62.93	004	<a href="#">MGC</a>
<input type="radio"/>	<a href="#">016.00</a>	1.2.3.6	000	<a href="#">MGC</a>
<input type="radio"/>	<a href="#">032.00</a>	1.5.6.4	000	<a href="#">MGC</a>
<input type="radio"/>	<a href="#">036.00</a>	192.168.209.108	000	<a href="#">MGC</a>
<input type="radio"/>	<a href="#">060.00</a>	1.1.2.3	000	<a href="#">MGC</a>
<input type="radio"/>	<a href="#">108.00</a>	1.85.26.56	000	<a href="#">MGC</a>

### Adding an IPMG

Perform the following procedure to add an IPMG.

#### Procedure 82 Adding an IPMG

Step	Action
1	In the <b>Media Gateways</b> web page, click <b>Add</b> . The Add IPMG web page appears.

Managing: 192.168.209.105 Username: admin2  
vays

### Add IPMG

Choose a Superloop Number:  and Shelf:

2 Choose a number and required shelf from **Choose a Superloop Number and Shelf** drop-down lists.

3 Click **Add**.

The Add IPMG with Input Description and Input Value fields web page appears.

Managing: 192.168.209.105 Username: admin2  
System > IP Network > Media Gateways > Add IPMG

### Add IPMG

Choose a Superloop Number:  and Shelf:

Input Description	Input Value
ELAN IP address:	<input type="text" value="192.1"/>
Bandwidth zone number:	<input type="text"/> Range: 0 - 255
IPMG type:	<input type="text" value="MGC"/>
ELAN passthrough port:	<input type="text" value="CE"/>
Faceplate ELAN port:	<input type="text" value="1E"/>
Backplane ELAN connection:	<input type="text" value="1ELAN"/>
TLAN passthrough port:	<input type="text" value="CT"/>
Faceplate TLAN port:	<input type="text" value="2T"/>
Backplane TLAN connection:	<input type="text" value="2TLAN"/>

4 Enter the appropriate values in the fields and select the required IPMG type in the **IPMG type** field.

5 Click **Save**.

--End--

## Media Gateway configuration

To view, add, and configure a Media Gateway Controller (MGC) or the MG XPEC, select the **Media Gateways** link in the IP Network branch of Element Manager navigator. For information about the configuration of the MGC and MG XPEC, refer to *Communication Server 1000E Installation and Commissioning* (NN43041-310), *Communication Server 1000E - Upgrades* (NN43041-458), and *Communication Server 1000M and Meridian 1 Large System Installation and Commissioning* (NN43021-310).

## Media Gateway configuration

To view or configure the current settings of a Media Gateway Controller, select the **Media Gateways** link in the IP Network branch of Element Manager navigator as shown in the following figure. For information about the configuration of the Media Gateway Controller, refer to *Communication Server 1000E Installation and Commissioning* (NN43041-310), *Communication Server 1000E - Upgrades* (NN43041-458), and *Communication Server 1000M and Meridian 1 Large System Installation and Commissioning* (NN43021-310).

**Figure 73**  
**Media Gateway Configuration**

Managing: 192.168.209.105 Username: admin2  
System » IP Network » Media Gateways » Add PMG » IPMG 20 0 Media Gateway (MGS) Configuration

### IPMG 20 0 Media Gateway (MGS) Configuration

**- Media Gateway (MGS)**

Hostname: MGS \*

Embedded LAN (ELAN) IP address: 192.168.55.33

Embedded LAN (ELAN) gateway IP address: 192.168.55.1

Embedded LAN (ELAN) subnet mask: 255.255.254.0

Telephony LAN (TLAN) IP address: 0.0.0.0

Telephony LAN (TLAN) gateway IP address: 0.0.0.0

Telephony LAN (TLAN) subnet mask: 255.255.254.0

**- DSP Daughterboard**

Type of the DSP daughterboard: DB32

Telephony LAN (TLAN) IP address: 0.0.0.0

Telephony LAN (TLAN) gateway IP address: 0.0.0.0

Telephony LAN (TLAN) subnet mask: 255.255.254.0

Hostname: DB1 \*

**+ VGW and IP phone codec profile**

Media Gateway Configuration has the option to enable or disable the R-factor option for the MGC card. R-factor is disabled by default as it has an impact on the density of DSP DB.

**Figure 74**  
Media Gateway Configuration (continued)

Hostname: DB2

**- VGW and IP phone codec profile**

Enable echo canceller

Echo canceller tail delay: 128 (milliseconds)

Enable dynamic attenuation

Voice activity detection threshold: 1 (0 - 4 DBM)

Idle noise level: 0 (0 - 1 DBM)

**R factor calculation**

DTMF tone detection

Enable low latency mode

Remove DTMF delay (squelch DTMF from TDM to IP)

Enable modem/fax pass through mode

Enable V.21 FAX tone detection

Fax TCF method: 2

FAX maximum rate: 14400 (bps)

FAX playout nominal delay: 100 (0 - 300 milliseconds)

Media Based CLID is the new field added for Communication Server Release 7.0. Media Gateway Configuration has the option to enable or disable the Media based CLID.

**Figure 75**  
Media Gateway Configuration (continued1)

**NORTEL CS 1000 ELEMENT MANAGER**

Telephony LAN (TLAN) IPv6 address: [ ]

Telephony LAN (TLAN) subnet mask: 255.255.254.0

Hostname: DB2

**+ VGW and IP phone codec profile**

**+ QoS**

**- Media Based CLID**

Media based CLID

Caller ID type: Bell202

Auto detection

Analog line card D-A transmission loss: 0.0 (-13.5 to +13.0 decibel) [Lookup](#)

**- Call Server LAN**

**Embedded LAN (ELAN) configuration**

Geographic redundancy

Primary call server IP address: 192.168.55.152

Primary call server hostname: Primary\_CS

Signaling port: 15000

Broadcast port: 15001 (1024 - 65535)

**Telephony LAN (TLAN) configuration**

Enter appropriate values in all the fields and click **Save**.

## Ethernet Diagnostics

To run the MGC Ethernet Diagnostic commands from Element Manager, select the **Media Gateways** link in the IP Network branch of Element Manager navigator. The **Media Gateways** Web page appears. See, .

### Procedure 83 Running MGC Ethernet Diagnostics

Step	Action
1	Choose an MGC and select Ethernet Diagnostics from the <b>More Actions</b> drop-down list. The <b>Ethernet Diagnostics</b> Web page appears.

Managing: 192.168.209.105 Username: admin2  
System » IP Network » Media Gateways » Ethernet Diagnostics

### Ethernet Diagnostics

Status Commands [- Filters]	Command Parameters
STAT LINK IP - Link status -- IP	<input type="text"/> <input type="button" value="Submit"/>
STAT SERV - Server status	<input type="text"/> <input type="button" value="Submit"/>
STIP TN - IP Status -- TN	<input type="text"/> <input type="button" value="Submit"/>
PRT IPDN - Print DNs with a given IP address	<input type="text"/> <input type="button" value="Submit"/>
ECNT FW - Etherset Count -- FWID MajorVer MinorVer Filter	<input type="text"/> <input type="button" value="Submit"/>
RST ZONE - Reset IP Phone -- Zone START/STOP HH:MM	<input type="text"/> <input type="button" value="Submit"/>
STAT IPMG - Print status of the given or all IPMGs	<input type="text"/> <input type="button" value="Submit"/>
STAT RFC2833 - RFC2833 Status -- TN	<input type="text"/> <input type="button" value="Submit"/>

Instruction: Select command, add value and click on [Submit]

- 2 Select the MGC status command group that you want to access from the **Command** drop-down list.
- 3 Click **Submit** to execute the command.

--End--

## Media Gateway Controller commands

Element Manager provides support for executing the Media Gateway Controller (MGC) command line interface (CLI) maintenance commands.

**Note:** Not all MGC commands are supported from Element Manager as they affect basic system configuration parameters and are used by the system administrator to closely monitor the system using serial connection.

The following MGC CLI command groups are supported from Element Manager:


- General — General purpose commands
- System — MGC platform administration and maintenance commands
- Voice Gateway — Voice Gateway application administration and maintenance commands
- Special — Special purpose PDT commands
- Security — Intra-system and cryptographic key support commands

To run MGC commands from Element Manager, select the **Media Gateways** link in the IP Network branch of Element Manager navigator. The **Media Gateways** Web page appears. See, .

### Procedure 84 Running MGC commands

Step	Action
1	Choose an MGC and select General Commands from the More Actions drop-down list. The <b>General Commands</b> Web page appears. See, <a href="#">Figure 76 "General Commands" (page 156)</a> .
2	Select the MGC CLI command group that you want to access from the <b>Group</b> drop-down list.
3	Choose a command from the <b>Command</b> drop-down list.
4	Click <b>Run</b> to execute the command.
--End--	

**Figure 76**  
**General Commands**



For a list of available MGC commands that can be run using Element Manager, refer to *Software Input Output Reference — Maintenance* (NN43001-711).

### Adding VGW channels

To open the VGW channel from Element Manager, select the **Media Gateways** link in the IP Network branch of Element Manager navigator. The **Media Gateways** Web page appears. See, .

Step	Action
1	Choose an IPMG and select <b>VGW Channels</b> from the <b>More Actions</b> drop-down list. The <b>VGW Channels</b> Web page appears.

Managing: 192.167.100.3  
System » IP Network » Media Gateways » VGW Channels - IPMG 004 00

### VGW Channels - IPMG 004 00

Add Delete Multi-Delete Refresh

Terminal No	Description	Customer	Zone
004 0 11 00	MGC_VGW	0	000
004 0 11 01	MGC_VGW	0	000
004 0 11 02	MGC_VGW	0	000
004 0 11 03	MGC_VGW	0	000
004 0 11 04	MGC_VGW	0	000
004 0 11 05	MGC_VGW	0	000
004 0 11 06	MGC_VGW	0	000
004 0 11 07	MGC_VGW	0	000
004 0 11 08	MGC_VGW	0	000
004 0 11 09	MGC_VGW	0	000

- 2 Click **Add** to add an VGW channel.

Managing: 192.168.209.105 Username: admin2  
System » IP Network » Media Gateways » VGW Channels - IPMG 020 00 » Add VGW channels

### Add VGW channels

Number of VGW Channels:

Trunk data block:

Terminal Number:

Designator field for trunk:

Extended Trunk:

Customer number:

Save Cancel

- 3 Select the number of required channels from the **Number of VGW Channels** drop-down list.
- 4 Enter the **Terminal Number** (the superloop and shelf numbers of the IPMG, the card number, and the unit).
- 5 Enter the appropriate values in all the fields and click **Save**.  
The VGW Channels IPMG Web page appears. The MGC has been added to the list.


--End--

### Deleting VGW channels

To open the VGW channel from Element Manager, select the **Media Gateways** link in the IP Network branch of Element Manager navigator. The **Media Gateways** Web page appears. See, .

Step	Action
------	--------

- 1 Choose an IPMG and select **VGW Channels** from the **More Actions** drop-down list. The **VGW Channels** Web page appears.



- 2 Select the number of required channels from the **Number of VGW Channels** drop-down list.
- 3 Click **Delete** to delete an VGW channel.  
or click **Multi-Delete** to delete multiple channels as shown in the following figure.

--End--

## Digital Trunking for IPMG


Perform the following procedure for digital trunking in media gateways.

### Procedure 85 Configuring conference TDS

Step	Action
------	--------

- 1 In the Element Manager screen, select **IP Network > Media Gateways**. The Media Gateway Web page appears.


**Figure 77**  
Media Gateways Web page



2 Select the IPMG superloop and click the **Digital Trunking** button.

The Digital Trunking Web page appears as shown in the following figure.

**Figure 78**  
Digital Trunking for IPMG Web page



3 From the Add drop down menu, select DLOP to add a DLOP loop.

The IPMG DLOP Web page appears as shown in the following figure.

**Figure 79**  
**IPMG DLOP Web page**

- 4 Enter the **Digital Trunk Interface Loop Number** (0 – 255).
- 5 Enter appropriate values in all the fields.
- 6 Click **Save**. It does not become available until a loop number has been entered and TAB has been used to move the cursor.  
A confirmation box appears.
- 7 Click **OK** to complete the configuration.
- 8 The updated loop configuration page appears and the new Conference loop is displayed.

---

--End--

---

### MGC Report logs

To generate MGC report logs from Element Manager, select the **Media Gateways** link in the IP Network branch of Element Manager navigator. The **Media Gateways** Web page appears. Choose an MGC and select **Report Log** from the **More Actions** drop-down list. The **MGC Report Log** Web page appears, as shown in [Figure 80 "MGC Report Logs Web page"](#) (page 161).

The following buttons at the top of this Web page provide one-click access to the following functions:


- RDSCONVERT — Convert a report log file to text
- RDPREV — Open the previous log file
- RDNEXT — Open the next log file
- RDOPEN — Open the latest report file

- RDSHOW — Show a summary of the report file
- RDTAIL — Show x records up to the newest record in the report file (where x is the configured display size).
- RDHEAD — Show x records starting from the oldest record in the report file (where x is the configured display size).

To view selected detail data on records in the report file, use the text boxes, the drop-down lists, and the following buttons:

- RDGO — Displays the record specified in the adjacent text box (where -1 is the oldest record and 1000 is the most recent).
- RD — Browses the report records. Enter the number of records to skip and the number of records to display in the adjacent text boxes.
- RDS — Browses the report records with (symbolic) memory dump. Enter the number of records to skip, and select the number of records to display using the adjacent text box and drop-down list.
- VIEW — Views selected records. Enter a starting record number and select the number of records to view using the adjacent text box and drop-down list. Negative numbers indicate records previous to the starting record.

**Figure 80**  
**MGC Report Logs Web page**



Managing: 192.167.100.3  
System » IP Network » Media Gateways » MGC Report Logs

### MGC Report Logs

Element IP : 192.167.100.20 Element Type : MGC

Report Log File Name with Path  RDSHOW RDTAIL RDHEAD RDGO RD RDS VIEW

Display Record Number

Skip Records  Display Records  RD

Skip Records  Display Records  RDS

Start Record Number  Display Records  VIEW

Click a button to invoke a command.

For more information about Media Gateway commands see, *Software Input Output Reference — Maintenance (NN43001-711)*.

## 32 Channel Secure Media Card (MC32S) commands

Element Manager provides support for executing MC32S command line interface (CLI) maintenance commands.


The following MC32S CLI command groups are supported from Element Manager:

- General — General purpose commands
- System — System commands
- Voice Gateway — Voice Gateway application administration and maintenance commands
- Special — Special purpose (PDT commands)
- Security — Intra-system and cryptographic key support commands

**Note:** Not all MC32S commands are supported from Element Manager as they affect basic system configuration parameters and are used by the system administrator to closely monitor the system using serial connection.

To run MC32S commands from Element Manager, select the **Maintenance and Reports** link in the IP Network branch of Element Manager navigator. The **Node Maintenance and Reports** Web page appears. Click **GEN CMD** for the MC32S card from the list. The **General Commands** Web page appears for the MC32S card, as shown in [Figure 81 "MC32S General Commands Web page"](#) (page 162).

**Figure 81**  
**MC32S General Commands Web page**



**Procedure 86**  
**Running MC32S commands**

---

<b>Step</b>	<b>Action</b>
1	Select the MC32S CLI command group that you want to access from the <b>Group</b> drop-down list.
2	Choose a command from the <b>Command</b> drop-down list.
3	Click <b>Run</b> to execute the command.

---

--End--

---

For a list of available MC32S commands that can be run using Element Manager, refer to *Software Input Output Reference — Maintenance* (NN43001-711).

**Report logs**

To generate MC32S report logs from Element Manager, select the **Maintenance and Reports** link in the IP Network branch of Element Manager navigator. The **Node Maintenance and Reports** Web page appears. Choose an MC32S card and click **RPT Log**. The **Node Report Logs** Web page appears, as shown in [Figure 82 "MC32S Node Report Logs Web page"](#) (page 164).

The following buttons at the top of this Web page provide one-click access to the following functions:

- RDSCONVERT — Convert a report log file to text
- RDPREV — Open the previous log file
- RDNEXT — Open the next log file
- RDOPEN — Open the latest report file
- RDSHOW — Show a summary of the report file
- RDTAIL — Show x records up to the newest record in the report file (where x is the configured display size).
- RDHEAD — Show x records starting from the oldest record in the report file (where x is the configured display size).

To view selected detail data on records in the report file, use the text boxes, the drop-down lists, and the following buttons:

- RDGO — Displays the record specified in the adjacent text box (where -1 is the oldest record and 1000 is the most recent).
- RD — Browses the report records. Enter the number of records to skip and the number of records to display in the adjacent text boxes.
- RDS — Browses the report records with (symbolic) memory dump. Enter the number of records to skip, and select the number of records to display using the adjacent text box and drop-down list.
- VIEW — Views selected records. Enter a starting record number and select the number of records to view using the adjacent text box and drop-down list. Negative numbers indicate records previous to the starting record.


**Figure 82**  
**MC32S Node Report Logs Web page**

For more information about MC32S commands see, *Software Input Output Reference - Maintenance* (NN43001-711).

## Zones

To configure or edit Bandwidth Zone information or Numbering Zone information, click the **Zones** link in the **IP Network** branch of the Element Manager navigator. The **Zones** Web page appears as shown in [Figure 83 "Zones Web page" \(page 165\)](#).

**Figure 83**  
Zones Web page



Bandwidth Zones are used for alternate call routing between IP stations and for Bandwidth management. Numbering Zones are used to route calls through a centralized call server.

To view, configure, or edit Bandwidth Zones click on the Bandwidth Zones link of **Zones** Web page. The **Bandwidth Zones** Web page appears as shown in the following figure.

**Figure 84**  
Bandwidth Zones

Managing: [192.168.55.143](#) Username: admin  
System » IP Network » Zones » Bandwidth Zones

---

## Bandwidth Zones

[Add...](#) [Edit...](#) [Import...](#) [Export](#) [Maintenance...](#) [Delete](#) [Refresh](#)

Zone	Intrazone Bandwidth	Intrazone Strategy	Interzone Bandwidth	Interzone Strategy	Resource Type	Zone Intent	Description
1 263	1000000	BQ	1000000	BQ	SHARED	MO	
2 264	1000000	BQ	1000000	BQ	SHARED	MO	
3 265	1000000	BQ	1000000	BQ	SHARED	MO	
4 266	1000000	BQ	1000000	BQ	SHARED	MO	
5 267	1000000	BQ	1000000	BQ	SHARED	MO	
6 268	1000000	BQ	1000000	BQ	SHARED	MO	
7 269	1000000	BQ	1000000	BQ	SHARED	MO	
8 270	1000000	BQ	1000000	BQ	SHARED	MO	
9 271	1000000	BQ	1000000	BQ	SHARED	MO	
10 272	1000000	BQ	1000000	BQ	SHARED	MO	
11 273	1000000	BQ	1000000	BQ	SHARED	MO	
12 274	1000000	BQ	1000000	BQ	SHARED	MO	

The user can view a spreadsheet with the configuration values of the Zone Basic Property and Bandwidth Management pages of all the configured zones in the Call Server. Click the **Configuration Spreadsheet** link. A Microsoft Excel spreadsheet appears, which can be saved to the user's local drive.

**Note:** Enter all rows sequentially in the Microsoft Excel spreadsheet. If a blank row is encountered further rows are ignored.

To add zones on the **Zones** Web page, select a Zone number from the list and click to Add.

This Web page contains links to the six categories of Zone configuration data for each Zone configured. Click the plus sign to the left of next to the Zone number to see the following information:

- Basic Property and Bandwidth Management
- Adaptive Network Bandwidth Management and CAC
- Alternate Routing for Calls between IP Stations
- Branch Office Dialing Plan and Access Codes
- Branch Office Time Difference and Daylight Saving Time Property

For information about configuring the MG 1000B, see *Branch Office Installation and Commissioning* (NN43001-314).

To edit basic properties, click the **Zone Basic Property and Bandwidth Management** link. The **Zone Basic Property and Bandwidth Management** Web page appears. See [Figure 85 "Zone Basic Property and Bandwidth Management Web page"](#) (page 166).

**Figure 85**  
**Zone Basic Property and Bandwidth Management Web page**

Input Description	Input Value
Zone Number (ZONE):	1 (0 - 8000)
Intrazone Bandwidth (INTRA_BW):	1000000 (0 - 1000000)
Intrazone Strategy (INTRA_STGY):	Best Quality (BQ)
Interzone Bandwidth (INTER_BW):	1000000 (0 - 1000000)
Interzone Strategy (INTER_STGY):	Best Quality (BQ)
Resource Type (RES_TYPE):	Shared (SHARED)
Zone Intent (ZBRN):	BMG (BMG)
Description (ZDES):	test

The information entered on this Web page corresponds to the ZONE, ZBRN, and ZDES data traditionally configured using LD 117 - Ethernet and Alarm Management.

To save changes made in **Zone Basic Property and Bandwidth Management** parameters, click Submit at the bottom of the Web page.

To return to the **Zones** Web page, click the Zones link in the navigation path at the top of the Web page.

To configure the Adaptive Network Bandwidth Management feature, click the **Adaptive Network Bandwidth Management and CAC** link. The **Adaptive Network Bandwidth Management and CAC** Web page appears, as shown in [Figure 86 "Adaptive Network Bandwidth Management and CAC Web page"](#) (page 167).

**Note:** Do not configure ANBWM for Zone 0 or Virtual Trunk zones. ANBWM is not supported in Zone 0 or VTRK zone.

**Figure 86**  
**Adaptive Network Bandwidth Management and CAC Web page**

Input Description	Input Value
Zone Member (ZONE)	1
Enable Call Admission Control Feature (STATE)	<input type="checkbox"/>
QoS Response Time Increase (ZQRT)	10 (1-100 %)
QoS Response Time Interval (ZQRTI)	5 (1-120 min)
Warning Alarm Threshold (ZQWAT)	85 (1-99 %)
Unacceptable Alarm Threshold (ZQUAT)	75 (1-99 %)
R Alarm Coefficient (CR)	50 (1-100)
Packet Loss Alarm Coefficient (CPL)	50 (1-100)
Delay Alarm Coefficient (CD)	50 (1-100)
Jitter Alarm Coefficient (CJc)	50 (1-100)
Coefficient for QoS (COQs)	50 (1-100)
Record Validity Time Interval (CACVTI)	48 (1-255 sec)

Submit Refresh Cancel

If the Adaptive Network Bandwidth Management feature is enabled using the **Enable Call Admission Control Feature (STATE)** check box, then the other parameters can be adjusted as required:

- QoS Response Time Increase (ZQRT): Bandwidth limit increment, as a percentage of the QoS factor for the zone
- QoS Response Time Interval (ZQRTI): Time (in minutes) between bandwidth limit increments
- Warning Alarm Threshold (ZQWAT): A QoS value, which is lower than this value, but higher than the Critical (Unacceptable) Alarm Threshold, triggers a Major Alarm.
- Critical Alarm Threshold (ZQUAT): A QoS value, which is lower than this value, triggers an Unacceptable (Critical) Alarm.
- R Alarm Coefficient (CR): Value used to calculate the QoS value for the zone.
- Packet Loss Alarm Coefficient (CPL): Value used to calculate the QoS value for the zone.
- Delay Alarm Coefficient (CD): Value used to calculate the QoS value for the zone.

- Jitter Alarm Coefficient (CJ): Value used to calculate the QoS value for the zone.
- Coefficient of QoS (CQoS): Value used to calculate the overall QoS value for the zone.
- Recent Validity Time Interval (CACVT): Amount of time (in hours) for zone-to-zone record validity. When this interval expires, records for unused zones are purged from the tables.

To configure the Alternate Routing feature, click the Alternate Routing for Calls between IP Stations link. The **Alternate Routing for Calls between IP Stations** Web page appears, as shown in [Figure 87 "Alternate Routing for Calls between IP Stations"](#) (page 168).

**Figure 87**  
**Alternate Routing for Calls between IP Stations**

CS 1000 ELEMENT MANAGER Help | Logout

Managing: 192.168.55.143 Username: admin  
System » IP Network » Zones » Bandwidth Zones » Bandwidth Zones 263 » Edit Bandwidth Zone » Alternate Routing for Calls between IP Stations (Zone263)

---

**Alternate Routing for Calls between IP Stations (Zone263)**

Alternate routing prefix digits:  ( 0 - 999999 )

Alarm suppression time period:  ( 0 - 3600 seconds )

Re-route for all calls:

Enable alternate routing feature:

Alternate call routing for unregistered devices:

Note: Alternate Routing (ALT), in combination with Adaptive Network Bandwidth Management (CAC) allows maintenance of QoS by re-routing interzone calls through alternate paths. Independently, Alternate Routing is based on bandwidth exhaustion.

- Enter a maximum of 7 digits in **Alternate Routing Prefix Digits**.
- Enter an Alarm suppression time period.
- Select the **Re-route for All Calls** check box to enable the feature for all calls.
- Select the **Enable Alternate Routing feature** check box to enable the Alternative Call Routing for NBWM feature.
- Select the **Alternate call routing for unregistered devices** check box to enable the Alternative Call Routing for unregistered devices.
- Click **Save** to enter the data.

To edit dialing plan and access code parameters for a Zone's MG 1000B offices, click the **Branch Office Dialing Plan and Access Codes** link on the **Zones** Web page. The **Zone Dialing Plan and Access Codes** Web page appears. See [Figure 88 "Zone Dialing Plan and Access Codes Web page"](#) (page 169).

**Figure 88**  
**Zone Dialing Plan and Access Codes Web page**

Managing: [192.167.102.3](#)  
System » IP Network » [Zones](#) » Zone 1 » Zone Dialing Plan and Access Codes

### Zone Dialing Plan and Access Codes

Input Description	Input Value
Zone Number (ZONE):	<input type="text" value="1"/>
Prefix (ACB_DC1):	<input type="text"/>
Country Code/Trunk Code (ACB_DC2):	<input type="text"/>
Destination Network Code (ACB_DC3):	<input type="text"/>
Dialed Access Code (ACB_LOC_AC):	No Access Code (NONE) ▼
New Access Code (ACB_LD_AC):	No Access Code (NONE) ▼

The information entered on this Web page corresponds to the Zone Dialing Plan and Access Codes (ZACB) command available in LD 117 - Ethernet and Alarm Management.

To save changes made in **Zone Dialing Plan and Access Code** parameters, click **Submit** at the bottom of the Web page.

To return to the **Zones** Web page, click the **Zones** link in the navigation path at the top of the page.

To access the time difference and daylight saving time properties for a Zone's MG 1000B Offices, click the **Branch Office Time Difference and Daylight Saving Time Property** link on the **Zone List** Web page. The **Time Difference and Daylight Saving Time Property** Web page appears (see [Figure 89 "Time Difference and Daylight Saving Time Property Web page"](#) (page 170)).

**Figure 89**  
**Time Difference and Daylight Saving Time Property Web page**

Managing: **192.167.102.3**  
 System » IP Network » [Zones](#) » Zone 1 » Time Difference and Daylight Saving Time

---

## Time Difference and Daylight Saving Time

**Time Difference Property**

Input Description	Input Value
Time Difference (TIME_DIFF):	<input style="width: 50px;" type="text" value="0"/>

**Daylight Saving Time Property**

Input Description	Input Value
Zone Number (ZONE):	<input style="width: 50px;" type="text" value="1"/>
Use Daylight Saving Time (USE_DST):	<input type="checkbox"/>
Active Status of Daylight Saving Time (DST_ACT):	<input type="text" value="No"/>
Start Month (START_MON):	January <input type="button" value="v"/>
Start Week (START_WEEK):	1 <input type="button" value="v"/>
Start Day (START_DAY):	Sunday <input type="button" value="v"/>
Start Hour (START_HOUR):	1 <input type="button" value="v"/>
End Month (END_MON):	January <input type="button" value="v"/>
End Week (END_WEEK):	1 <input type="button" value="v"/>
End Day (END_DAY):	Sunday <input type="button" value="v"/>
End Hour (END_HOUR):	1 <input type="button" value="v"/>

The information entered on this Web page corresponds to the ZTDF and ZDST command data traditionally configured using LD 117 - Ethernet and Alarm Management.

To save changes made in Time Difference and Daylight Saving Time properties, click **Submit** at the bottom of the Web page.

To return to the **Zones** Web page, click the **Zones** link in the navigation path at the top of the page.

Select Media Services Zone Properties link in the Bandwidth Zones web page. The **Media Services Zone Properties** web page appears.

CS 1000 ELEMENT MANAGER
Help | Logout

Managing: **192.168.55.143** Username: admin  
 System » IP Network » [Zones](#) » [Bandwidth Zones](#) » [Bandwidth Zones 263](#) » [Edit Bandwidth Zone](#) » [Media Services Zone Properties \(Zone 263\)](#)

---

### Media Services Zone Properties (Zone 263)

There are no Media Service Routing Number configured.

To add media services zone properties, click **Add** in the Media Services web page. The Add Media Services Zone Properties web page appears.

CS 1000 ELEMENT MANAGER Help | Logout

Managing: 192.168.55.143 Username: admin  
System > IP Network > Zones > Bandwidth Zones > Bandwidth Zones 263 > Edit Bandwidth Zone > Media Services Zone Properties (Zone 263) > Add Media Services Zone Properties (Zone 263)

### Add Media Services Zone Properties (Zone 263)

Customer number: 1 \*

Media services routing DN: 121 \*

IP conference service DN: 126

IP music service DN: 44

IP recorded announcement service DN: 77

IP tone service DN: 5454

IP attendant service DN: 6565

\* Required value. Save Cancel

Enter all the fields and click **Save** to add the media services.

To delete any zone, select the zone in the Zones web page and then click **Delete** in the Media Services web page. The Message from web page appears.

CS 1000 ELEMENT MANAGER Help | Logout

Managing: 192.168.55.143 Username: admin  
System > IP Network > Zones > Bandwidth Zones

### Bandwidth Zones

Add... Edit... Import... Export Maintenance... Delete Refresh

Zone *	Resource Type	Zone Intent	Description
1 1	SHARED	BMG	TEST
2 263	SHARED	MO	test
3 264	SHARED	MO	
4 265	SHARED	MO	
5 266	1000000	BQ	1000000 BQ SHARED MO
6 267	1000000	BQ	1000000 BQ SHARED MO
7 268	1000000	BQ	1000000 BQ SHARED MO
8 269	1000000	BQ	1000000 BQ SHARED MO
9 270	1000000	BQ	1000000 BQ SHARED MO
10 271	1000000	BQ	1000000 BQ SHARED MO
11 272	1000000	BQ	1000000 BQ SHARED MO
12 273	1000000	BQ	1000000 BQ SHARED MO


Message from webpage: Are you sure you want to delete the selected bandwidth zone? OK Cancel

If you want to import any zone from the server, click on **Import**. The Import Bandwidth Zones web page appears.



Click on **Browse** to search for the zone.csv file from the server desktop. Select the file and then click **Import** to import the bandwidth zone.

If you want to export any zone to your local server, select the required zone and click on **Export**. The zone.csv file is downloaded to your local as shown in the following figure.



To add the maintenance commands, click on **Maintenance**. The following Maintenance Commands for Zones web page appears.

**CS 1000 ELEMENT MANAGER**

Managing: 192.168.55.143 Username: admin  
System » IP Network » Zones » Bandwidth Zones » Maintenance Commands for Zones

---

**Maintenance Commands for Zones**

Action:

Zone Number:

Zone Number	State	Resource Type	Intrazone Strategy	Zone Intent	Bandwidth(Kbps)	Usage(Kbps)	Peak(%)
1	ENABLED	SHARED	BQ	MO	1000000	0	0
2	ENABLED	SHARED	BQ	MO	1000000	0	0
3	ENABLED	SHARED	BQ	MO	1000000	0	0
4	ENABLED	SHARED	BQ	MO	1000000	0	0
5	ENABLED	SHARED	BQ	MO	1000000	0	0
6	ENABLED	SHARED	BQ	MO	1000000	0	0
7	ENABLED	SHARED	BQ	MO	1000000	0	0
11	ENABLED	SHARED	BQ	MO	1000000	0	0
12	ENABLED	SHARED	BQ	MO	1000000	0	0
13	ENABLED	SHARED	BQ	MO	1000000	0	0
14	ENABLED	SHARED	BQ	MO	1000000	0	0

Select the required Action and Zone number from the drop-down lists and click **Submit**.

## Numbering Zones

Numbering Zones provides you with an interface to configure various parameters for Zones-based Parameters, Flexible Dial Plan, and Direct Inward Dial number and provides an option for every customer to enable the Zone Based Dialing (ZBD) feature.

Element Manager provides the following capabilities to configure NUMZONE for the ZBD feature:

- adding a new Numbering Zone
- deleting a Numbering Zone
- editing the Zone Based Parameters
- flexible Dial Plan and Direct Inward Dial Number Configurations
- config.ini changes in Nodes page
- enabling Numbering Zones for every customer in Feature Options

To view, configure, or edit Numbering Zones click on the Numbering Zones link of **Zones** Web page. The **Numbering Zones** Web page appears as shown in the following figure.

**Figure 90**  
**Numbering Zones Web page**

Zones	Site prefix	Country code	Area code	E164 Location code	Location code	National code	International code	Phone display	Tone table	Description
1								0	0	Default nu...

For information about configuring of ZBD in the **IP Telephony Nodes** Web page and configuration of a Numbering Zone, see *Dialing Plans Reference* (NN43001-283).

## Host and Route Tables

Host and Route tables are located on the Ethernet LAN configuration page, that is used to configure and list the Ethernet LAN settings of the Call Server.

A host name can be up to 16 characters in length. The first character of a host name must be a letter of the alphabet. A character may be a letter, number or underscore (\_). A period is used as a delimiter between domain names. Spaces and tabs are not permitted. No distinction is made between upper and lower case.

To access the Host and Route Tables click Host and Route Tables link of the IP Network branch of the Element Manager navigator. The **Host and Route Tables** Web page appears as shown in the following figure.

For more information refer to *Signaling Server IP Line Applications Fundamentals* (NN43001-125).

**Figure 91**  
**Host and Route Tables Web page**

### Host and Route Tables

Configure Ethernet LAN IP address for the Ethernet Interface

**Status**

Edit... Activate

SUBNET MASK : 255.255.255.0

**Host**

Host IP address configuration

Add... Enable Disable Delete Refresh

	Host Identifier *	Host Name	Host IP Address	Ethernet Link Status	Status	Media Gateway
1	<input type="radio"/> 1	SECONDARY_ENET	137.135.128.254	Inactive	Enabled	0
2	<input type="radio"/> 2	LOCAL_PPP_IF	137.135.192.4	--	Enabled	0
3	<input type="radio"/> 3	REMOTE_PPP_IF	100.1.1.1	--	Enabled	0
4	<input type="radio"/> 4	CPPM_CS	172.16.100.2	Active	Enabled	0
5	<input type="radio"/> NIL	localhost	127.0.0.1	--	--	0

**Route**

Configure and manage routing entries

Add... Enable Disable Delete Refresh

	Route Identifier	Network IP Address	Gateway IP Address	Status *	Media Gateway
1	<input type="radio"/> NIL	127.0.0.1	127.0.0.1	--	0
2	<input type="radio"/> NIL	172.16.100.0	172.16.100.2	--	0
3	<input type="radio"/> NIL	127.0.0.0	127.2.0.1	--	0
4	<input type="radio"/> 1	0.0.0.0	172.16.100.1	Enabled	0

## Network Address Translation (NAT)

To configure or edit Network Address Translation (NAT) information, click the **Network Address Translation** link in the **IP Network** branch of the Element Manager navigator. The **Network Address Translation (NAT)** Web page appears, as shown in [Figure 92 "Network Address Translation \(NAT\) Web page"](#) (page 176).

**Figure 92**  
**Network Address Translation (NAT) Web page**

Managing: [192.167.102.3](#)  
 System » IP Network » Network Address Translation (NAT)

---

### Network Address Translation (NAT)

Input Description	Input Value	
Echo Server 1 IP Address	<input type="text" value="0.0.0.0"/>	
Echo Server 1 Port	<input type="text" value="10000"/>	Range: 1000 to 65535
Echo Server 2 IP Address	<input type="text" value="0.0.0.0"/>	
Echo Server 2 Port	<input type="text" value="10000"/>	Range: 1000 to 65535
NAT Session Timeout Value (seconds)	<input type="text" value="30"/>	Range: 20 to 600

Note: IP address 0.0.0.0 means that the default local Echo Server will be enabled

The information entered on this Web page corresponds to data traditionally configured using LD 117 - Ethernet and Alarm Management.

To configure the Echo Server 1 and 2 IP addresses and port numbers, enter the values in corresponding input fields.

**Note:** Echo Server 1 and 2 default IP addresses use the TLAN network interface IP address of the LTPS card.

Enter the NAT session timeout value. Click the **Submit** button to save the changes. For more information, see *Signaling Server IP Line Application Fundamentals (NN43001-125)*.

## Quality of Service Thresholds (QoS)

The threshold values chosen provide accurate statistics without unnecessary network loading. If you increase your sample rate or your sample duration you will utilize/consume more of the bandwidth.

Nortel recommends that you use the default values. You can change thresholds depending on the voice quality level you want to have without alarms reported. For example, Call Packet Loss Unacceptable Threshold (UPKL) - default is 7 percent (entered as 70).

The zone basis threshold parameters allow for an overall level of alerts based on aggregated data for the zone. QoS samples are collected from active sets in the zone periodically by polling or received asynchronously, depending on the set firmware. The statistics received are compared to the call basis thresholds and violations are counted. The zone basis threshold parameters define the level at which alarms are sent out. These indicate the percentage of the samples that may exceed the defined per call thresholds for the different QoS metrics. For example, if the zone threshold for a particular metric is set to 2 percent, then zone alarms are issued if over 2 percent of the samples for that metric exceed the per call unacceptable threshold set for that metric.

The zone defaults for the warning items are higher than those for the unacceptable items (20 percent compared to 2 percent). The assumption is that the per call warnings thresholds are set at levels such that several warning alarms are normally issued. However, an overall problem with the zone should only be indicated if there are a significant number of such violations. On the other hand, there should be almost no unacceptable alarms and it is appropriate that these be set to a far lower zone percentage threshold.

The per call thresholds should be first adjusted to a level appropriate for the installation. After that the zone thresholds should be set, taking into consideration the per call threshold settings. If the per call thresholds are set low then more violations are to be expected, and the zone thresholds should be set higher to compensate. The converse is true for high per call threshold settings.

To configure or edit Quality of Service Threshold information, click the **Quality of Service Thresholds (QoS)** link in the **IP Network** branch of the Element Manager navigator. The **Quality of Service (QoS) Thresholds** Web page appears (see [Figure 93 "Quality of Service \(QoS\) Thresholds Web page" \(page 178\)](#)).

**Figure 93**  
Quality of Service (QoS) Thresholds Web page

Quality Of Service (QoS) Thresholds		
QoS Zone Basis Threshold Parameters		
Input Description	Input Value	
Zone Latency Warning Threshold (ZLWT):	<input type="text" value="20"/>	Range: 1 to 100 %
Zone Jitter Warning Threshold (ZJWJ):	<input type="text" value="20"/>	Range: 1 to 100 %
Zone Packet Loss Warning Threshold (ZWPKL):	<input type="text" value="20"/>	Range: 1 to 100 %
Zone R Factor Warning Threshold (ZWR):	<input type="text" value="20"/>	Range: 1 to 100 %
Zone Latency Unacceptable Threshold (ZLAT):	<input type="text" value="2"/>	Range: 1 to 100 %
Zone Jitter Unacceptable Threshold (ZJIT):	<input type="text" value="2"/>	Range: 1 to 100 %
Zone Packet Loss Unacceptable Threshold (ZUPKL):	<input type="text" value="2"/>	Range: 1 to 100 %
Zone R Factor Unacceptable Threshold (ZUR):	<input type="text" value="2"/>	Range: 1 to 100 %
Sample Rate Window (ZARW):	<input type="text" value="300"/>	Range: 60 to 3600 s
Minimum Sample Count (MSZW):	<input type="text" value="100"/>	Range: 50 to 1000
QoS Call Basis Threshold Parameters		
Input Description	Input Value	
Call Latency Warning Threshold (CLAT):	<input type="text" value="40"/>	Range: 5 to 100 ms
Call Jitter Warning Threshold (CJIT):	<input type="text" value="20"/>	Range: 5 to 200 ms
Call Packet Loss Warning Threshold (CPKL):	<input type="text" value="20"/>	Range: 5 to 100 %
Call R Factor Warning Threshold (CRF):	<input type="text" value="65"/>	Range: 20 to 94
Call Latency Unacceptable Threshold (CLAT):	<input type="text" value="100"/>	Range: 5 to 500 ms
Call Jitter Unacceptable Threshold (CJIT):	<input type="text" value="40"/>	Range: 5 to 500 ms
Call Packet Loss Unacceptable Threshold (CUPKL):	<input type="text" value="70"/>	Range: 5 to 250 %
Call R Factor Unacceptable Threshold (CUR):	<input type="text" value="60"/>	Range: 20 to 94
Sampling Period (SAMP):	<input type="text" value="30"/>	Range: 5 to 60 s
<input type="button" value="Submit"/> <input type="button" value="Refresh"/> <input type="button" value="Cancel"/>		

From this Web page, Quality of Service (QoS) Thresholds can be viewed and edited. Every node in the system has the same threshold values.

The information entered on this Web page corresponds to data traditionally configured using LD 117 - Ethernet and Alarm Management.

The threshold parameters are grouped as follows:

- QoS Zone Basis Threshold Parameters
- QoS Call Basis Threshold Parameters

To save changes made to the threshold parameters, click **Submit** at the bottom of the Web page.

For more information, see *Software Input Output Reference - Maintenance (NN43001-711)*.

#### **ATTENTION**

Changes to Quality of Service parameters do not take effect until a Call Server data dump is performed.


## Personal Directories

The Personal Directories Web page provides access to two links:

- **Server Configuration:** allows the administrator to enter the database backup and restore configuration details
- **User Profile Configuration:** allows the administrator to modify a user profile in the database

To access the **Personal Directories** Web Page click the IP Network > Personal Directories link in the System branch of the Element Manager navigator.

**Figure 94**  
**Personal Directories Web page**



For more information about Personal Directories, Redial List, and Callers List, see *Signaling Server IP Line Application Fundamentals (NN43001-125)*.

## Unicode Name Directory

The Unicode Name Directory feature enables the displaying of called or caller party name in Unicode format and use languages other than English for name displaying. It enhances the functionality of Unicode display capable Unistim terminals

The Unicode Name Directory System Management Solution (SMS) provides a solution to provision localized names (up to seven different languages) on subscriber base and generate subscriber telephony account's calling line IDs/URIs (CLID/URI) in network level to serve Unicode Name Directory server.

To successfully configure Unicode Name Directory on the Call Server side, enable the Name Directory Application and configure Lightweight Directory Access Protocol (LDAP) synchronization parameters. Name Directory Application is enabled in the Call Server only if Personal Directory Application Server is configured.

Management of Unicode Name Directory is an integral part of Subscriber Manager, for more information on Unicode Name Directory and the role of Subscriber Manager refer to *Subscriber Manager Fundamentals* (NN43001-120).

For information about Unicode Name Directory and its configuration, see *Signaling Server IP Line Application Fundamentals* (NN43001-125).


## Interfaces

Element Manager supports the Value Added Server and Property Management System data blocks traditionally configured in LD 17.

### Application Module Link

To access Application Module Link click Interfaces > Application Module Link in the System branch of the Element Manager navigator. The **Application Module Link** Web page appears as shown in [Figure 95 "Application Module Link Web page"](#) (page 180).

**Figure 95**  
**Application Module Link Web page**



To view or edit an Application Module Link click a port number. The **Application Module Link Details** Web page appears as shown in [Figure 96 "Application Module Link Details Web page"](#) (page 181).

**Figure 96**  
**Application Module Link Details Web page**

Managing: [172.16.100.2](#)  
System > Interfaces > Application Module Link > Application Module Link Details 16

---

### Application Module Link Details 16

Link Type: ELAN  
 Description:   
 Maximum octets :  (per HDLC frame)

To edit the information, enter the appropriate values and click **Save**.

To Add a new Application Module Link click the Add button in the **Application Module Link** Web page. The **New Application Module Link** Web page appears as shown in [Figure 97 "New Application Module Link Web page"](#) (page 181).

**Figure 97**  
**New Application Module Link Web page**

Managing: [172.16.100.2](#)  
System > Interfaces > Application Module Link > New Application Module Link

---

### New Application Module Link


Port number:  \* (16 - 127)  
 AML over ELAN  
 Description:   
 Link control system parameters  
 Maximum octets :  (per HDLC frame)

To create a new Application Module Link, enter the appropriate information and click Save.

## Value Added Server


Click the **Interfaces > Value Added Server** link in the **System** branch of the Element Manager navigator. The **Value Added Server** Web page appears as shown in [Figure 98 "Value Added Server Web page"](#) (page 182).

**Figure 98**  
**Value Added Server Web page**



To add a Value Added Server, click **Add**. The **Add Value Added Server** Web page appears, as shown in [Figure 99 "Add Value Added Server Web page"](#) (page 183).

**Figure 99**  
**Add Value Added Server Web page**



Managing: [192.167.104.53](#)  
 System > Interfaces > Value Added Server > Add Value Added Server

---

## Add Value Added Server

**Application Module Link**  
 Associate a Value Added Server with a configured Application Module Link.

**Ethernet LAN Link**  
 Associate a Value Added Server with a configured Application Module Link over Ethernet.

To associate a Value Added Server with a configured Application Module Link, click **Application Module Link**. The **Application Module Link Web page** appears, as shown in [Figure 100 "Application Module Link Web page"](#) (page 183).

**Figure 100**  
**Application Module Link Web page**



Managing: [192.168.55.143](#) Username: admin2  
 System > Interfaces > Value Added Server > Add Value Added Server > Application Module Link

---

## Application Module Link

Value added server ID:  \*

Application module Link:

AML port configured in ADAN

Application security:

Interval:

Time interval for checking the link for overload in five second increments.

Message count threshold:  \* (10 - 9999)

\* Required value.

Enter the parameters for the new Value Added Server and click **Save**.

To associate a Value Added Server with a configured Application Module Link over Ethernet, from the **Add Value Added Server** Web page click **Ethernet LAN Link**. The **Ethernet Link** Web page appears, as shown in [Figure 101 "Ethernet Link Web page"](#) (page 184).

**Figure 101**  
**Ethernet Link Web page**

The screenshot shows the 'Ethernet Link' configuration page. At the top, it indicates the managed IP is 192.167.104.53 and the navigation path is System > Interfaces > Value Added Server > Add Value Added Server > Ethernet Link. The page title is 'Ethernet Link'. The configuration fields are: 'Value Added Server ID' (text input), 'Ethernet LAN Link' (dropdown menu), 'Application Security' (checkbox), 'Interval' (dropdown menu), and 'Message Count Threshold' (text input). Below the 'Interval' dropdown, there is a note: 'Time interval for checking the link for overload in five second increments'. At the bottom right, there are 'Save' and 'Cancel' buttons.

Enter the parameters for the new Value Added Server and click **Save**.

### Property Management System

Click the **Interfaces > Property Management System** link in the **System** branch of the Element Manager navigator. The **Property Management System** Web page appears, as shown in [Figure 102 "Property Management System Web page"](#) (page 185).

**Figure 102**  
**Property Management System Web page**

Managing: [192.167.104.53](#)  
 System » Interfaces » Property Management System

---

### Property Management System

Interface:

Number of Call Registers used:  \* (5 - 1023)

Port Number:

PMSI port configured in ADAN

Acknowledgement Time:  (seconds)

Minor alarm when link is not responding:

Number of Retransmissions per message:

Polling Timer:  \* (0 - 31 minutes)

Enter the parameters for the new Property Management System and click **Save**.

## Engineered Values

The configuration of the system depends on the value of certain parameters. To configure and edit system parameters, click the **Engineered Values** link in the **System** branch of the Element Manager navigator. The **Engineered Values** Web page appears as shown in [Figure 103 "Engineered Values Web page" \(page 185\)](#).

**Figure 103**  
**Engineered Values Web page**

CS 1000 ELEMENT MANAGER Help | Logout

Managing: [192.168.55.143](#) Username: admin2  
 System » Engineered Values

---

### Engineered Values

Configuration of the system depends on the value of certain parameters. These parameters are configured and viewed under engineered values.

- Buffer and Queue Management**  
View and edit the input/output buffer and queue allocations for various devices and applications.
- Call Register**  
View and edit the allocation of Call registers for specific applications and configure the parameters.
- Idle Set Display**  
View and configure the idle set display information. User can also enable or disable the display of the information.
- Call Detail Recording**  
Configure and view the call detail recording parameters.
- Miscellaneous Parameters**  
Configure and view other hardware and software configuration parameters.

To configure the input/output buffer and queue allocations for various devices and applications, click **Buffer and Queue Management**. The **Buffer and Queue Management** Web page appears as shown in [Figure 104 "Buffer and Queue Management Web page"](#) (page 186).

**Figure 104**  
**Buffer and Queue Management Web page**

Managing: 192.168.55.143 Username: admin2  
System > Engineered Values > Buffer And Queue Management

---

### Buffer And Queue Management

#### Buffer Management

Low priority input buffers:  \* (96 - 5000)  
High priority input buffers:  \* (16 - 5000)  
Output buffers:  \* (16 - 2048)  
Digital trunk input buffers:  \* (35 - 1000)  
Digital trunk output buffers:  \* (4 - 100)

#### Queue Management

Auxiliary input queue size:  \* (20 - 255)  
Auxiliary Output Queue Size:  \* (20 - 255)

\* Required value.

Enter the desired parameters within the ranges indicated and click **Save**.

To configure the allocation of Call Registers for specific applications, from the **Engineered Values** Web page click **Call Registers**. The **Call Registers** Web page appears as shown in [Figure 105 "Call Register Web page"](#) (page 187).

**Figure 105**  
**Call Register Web page**

Enter the desired parameters within the ranges indicated and click **Save**.

To configure idle set display information, from the **Engineered Values** Web page click **Idle Set Display**. The **Idle Set Display** Web Page appears as shown in [Figure 106 "Idle Set Display Web page" \(page 187\)](#).

**Figure 106**  
**Idle Set Display Web page**

Enter the desired display information and click **Save**.

To configure Call Detail Recording parameters, from the **Engineered Values** Web page click **Call Detail Recording**. The **Call Detail Recording** Web page appears as shown in [Figure 107 "Call Detail Recording Web page"](#) (page 188).

**Figure 107**  
**Call Detail Recording Web page**

The screenshot shows a web page titled "Call Detail Recording" for a system managed at IP address 192.167.102.3. The breadcrumb trail is "System » Engineered Values » Call Detail Recording". The page contains the following configuration options:

- Format: OLD (dropdown menu)
- Priority over Call Processing:
- Calling Line ID:
- Duration 0.5:
- Call record output on TTY with 0.5 second duration accuracy for Japan (checkbox, currently unchecked)
- Message Registration or Periodic Pulse Metering: Message Registration (dropdown menu)

At the bottom right of the form area, there are "Save" and "Cancel" buttons.

Enter the desired parameters and click **Save**.

To configure other hardware and software parameters, from the **Engineered Values** Web page click **Miscellaneous Parameters**. The **Miscellaneous Parameters** Web page appears as shown in [Figure 108 "Miscellaneous Parameters Web page"](#) (page 189).

**Figure 108**  
**Miscellaneous Parameters Web page**

Managing: **192.167.102.3**  
 System » [Engineered Values](#) » Miscellaneous Parameters

---

### Miscellaneous Parameters

Number of CPU:

Pulse Code Modulation Companding Law:

Minor Alarm on Attendant consoles:

**Error Messages**

Monitor Hardware:

Monitor Software:

Software Audit:

Digitone Burst Time:   (milliseconds)

Call Forward Saved on Sysload:

16 button Dual Tone Multi-Frequency Operation:

Cadence increments:   (milliseconds)

Multiple Loop Directory Number:

Incoming Calls by Fully Restricted Station:

Automatic Call Distribution - Auxiliary Data System Customers:

Speed Call Lists:  \* (0 - 8191)

Display Messages for Background Terminal:  \* (20 - 255)

Original Carrier Access Code Format Support:

Enter the desired parameters and click **Save**.

## Emergency Services

Element Manager supports the Emergency Services Client Mobility feature, which allows users to manage the location of phones, and to process emergency calls according to the caller's current data.

### Service Parameters

The **Service Parameters** Web page allows users to modify system-wide configuration settings.

Click the **Emergency Services > Service Parameters** link in the **System** branch of the Element Manager navigator to open the **Service Parameters** Web page, as shown in [Figure 109 "Service Parameters Web page" \(page 190\)](#).

**Figure 109**  
**Service Parameters Web page**

Managing 192.167.166.3  
System > Emergency Services > Service Parameters

### Service Parameters

Input Description	Input Value
Location Information Service (LIS):	None (None)

Dynamic ELIN Timeout value (DYNAMIC\_ELIN\_TIMEOUT): 180 ( 5 - 1440 Minutes )

Reuse oldest ELIN during overflow (DYNAMIC\_ELIN\_REUSE):

- Choose a **Location Information Service** from the first drop-down list.
  - If Internal Subnet Location Information Service is selected, the **Lookup Private Address for Subnet** check box is displayed.
  - If External Discovery Manager is selected, the **External Location Update Timeout** text box is displayed.
- Enter a **Dynamic ELIN Timeout value**.
- Check **Reuse oldest ELIN during overflow**, if necessary.
- Click **Submit**.

### Access Numbers and Routing

The **Access Numbers and Routing** Web page allows users to process Emergency Service information which are specific to each Customer.

Click the **Emergency Services > Access Numbers and Routing** link in the **System** branch of the Element Manager navigator to open the **Access Numbers and Routing** Web page, as shown in [Figure 110 "Access Numbers and Routing Web page"](#) (page 191).

**Figure 110**  
**Access Numbers and Routing Web page**

Managing: [192.167.100.3](#)  
 System » Emergency Services » Access Numbers and Routing

---

### Access Numbers and Routing

Emergency Services Directory Number (ESDN) is used to handle emergency calls and hence treated with high priority.

Emergency Services Access Data for

Default Calling Number: 9674444  
 On-Site Notification Station DN:

#### Emergency Services Directory Numbers

	Entry#	Directory Number	Routing Method	Route Value	Directing Digits	Misdial Prevention	Misdial Delay	Last ESDN Digit Repetition
<input type="radio"/>	1	911	ESRT	1	4444	NO		
<input type="radio"/>	2	811	ESRT	1	234	NO		

---

Number of ESDN blocks printed = 2

To add an Emergency Services Directory Number, click **Add**. The **Add Emergency Services Directory Number** Web page appears, as shown in [Figure 111 "Add Emergency Services Directory Number Web page"](#) (page 192).

**Figure 111**  
**Add Emergency Services Directory Number Web page**

Managing: [192.167.104.53](#)  
System > Emergency Services > Access Numbers and Routing > Add Customer 0 Emergency Services Directory Number

### Add Customer 0 Emergency Services Directory Number

ESDN Entry: 3 ▾

Directory Number:  \*

Directing Digits:  \*

Routing Method:

Route Number: 1 ▾

Route List Index: ▾

Misdial Prevention:

Misdial Delay: 2 ▾ (seconds)

Last ESDN Digit Repetition:

Save Cancel

To edit an existing Emergency Services Directory Number, from the **Access Numbers and Routing** Web page click the **Entry#**. The **Edit Emergency Services Directory Number** Web page appears, as shown in [Figure 112 "Edit Emergency Services Directory Number Web page"](#) (page 193).

**Figure 112**  
**Edit Emergency Services Directory Number Web page**

The screenshot shows a web page titled "Edit Emergency Services Directory Number Entry 1". The page contains the following fields and controls:

- Directory Number:
- Directing Digits:
- Routing Method:
  - Route Number:
  - Route List Index:
- Misdial Prevention:
- Misdial Delay:  (seconds)
- Last ESDN Digit Repetition:

A "Save" button is located at the bottom right of the form area.

To edit the CLID configuration for a Customer, select a Customer from the **Choose a customer** drop-down list and click **Edit**. The **Edit Access Numbers and Routing** Web page appears, as shown in [Figure 113 "Edit Access Numbers and Routing Web page"](#) (page 194).

**Figure 113**  
**Edit Access Numbers and Routing Web page**

Input Description	Input Value
Customer Number (CUST):	0
Emergency Services Directory Number (ESDN):	911
Emergency Services Access Routing Method (ROUTING):	Route Number (ESRT) 15
Directing Digits (DDGT):	4444
Default ESA Calling Number (DFCL):	967444
On-Site Notification station DN (OSDN):	

Submit Refresh Cancel

To add a new CLID configuration for a Customer, from the **Access Numbers and Routing** Web page click **Add**. The **Add Access Numbers and Routing** Web page appears, as shown in [Figure 114 "Add Access Numbers and Routing Web page"](#) (page 195).

**Figure 114**  
**Add Access Numbers and Routing Web page**

Managing: [10.11.128.18](#)  
System » Emergency Services » [Access Numbers and Routing](#) » Add Access Numbers and Routing

### Add Access Numbers and Routing

Input Description	Input Value
Customer Number (CUST):	2
Emergency Services Directory Number (ESDN):	<input type="text"/>
Emergency Services Access Routing Method (ROUTING):	Route Number (ESRT)
Directing Digits (DDGT):	<input type="text"/>
Default ESA Calling Number (DFCL):	<input type="text"/>
On-Site Notification station DN (OSDN):	<input type="text"/>

Choose a Customer from the **Customer Number** drop-down list. Complete the information in the remaining fields and click **Submit**.

To delete the CLID configuration for a customer, from the **Access Numbers and Routing** Web page click **Delete**.

### Response Locations

Click the **Emergency Services > Emergency Response Locations** link in the **System** branch of the Element Manager navigator to open the **Emergency Response Location** Web page, as shown in [Figure 115 "Emergency Response Location Web page" \(page 196\)](#).

**Figure 115**  
**Emergency Response Location Web page**

Managing: [192.167.100.3](#)  
 System » Emergency Services » Emergency Response Location

### Emergency Response Location

Goto ERL

	ERL	State	Site Name	Location Description	Route Number	Route List Index	Access Code	Prepend Digits	Locator	Onsite Notification DN
<input type="radio"/>	256	DIS								
<input type="radio"/>	257	DIS		ZONE1						
<input type="radio"/>	258	DIS		ZONE2						

Number of ERLs printed = 3, Total number of ERLs = 3

Items per page

This Web page allows users to add, enable, disable, or delete Emergency Response Locations (ERLs).

To add an ERL, click the radio button for the ERL and click **Add**.

To enable an ERL, click the radio button for the ERL and click **Enable**.

To disable an ERL, click the radio button for the ERL and click **Disable**.

To delete an ERL, click the radio button for the ERL and click **Delete**.

To edit an ERL, click the ERL number. The **Edit Emergency Response Location** Web page appears, as shown in [Figure 116 "Edit Emergency Response Location Web page"](#) (page 197).

**Figure 116**  
**Edit Emergency Response Location Web page**

Managing: [192.167.100.3](http://192.167.100.3)  
System » Emergency Services » [Emergency Response Location](#) » Edit Emergency Response Location

---

### Edit Emergency Response Location

Input Description	Input Value
Emergency Response Locator (ERL):	<input type="text" value="256"/>
Site Name (SITENAME):	<input type="text"/>
Location Description (LOCDESC):	<input type="text"/>
Routing Method (ROUTING):	Route Number (RT) <input type="text"/>
Access Code (AC):	Null (NULL) <input type="text"/>
Prepend Digits (PREPEND):	<input type="text"/>
Locator (LOCATOR):	<input type="text"/>
On-Site Notification DN (OSDN):	<input type="text"/>

To add an ERL, from the **Emergency Response Location** Web page click **Add**. The **Add Emergency Response Location** Web page appears, as shown in [Figure 117 "Add Emergency Response Location Web page" \(page 198\)](#).

**Figure 117**  
**Add Emergency Response Location Web page**

Input Description	Input Value
Emergency Response Locator (ERL):	<input type="text"/>
Site Name (SITENAME):	<input type="text"/>
Location Description (LOCDESC):	<input type="text"/>
Routing Method (ROUTING):	Route Number (RT) <input type="text"/>
Access Code (AC):	Null (NULL)
Prepend Digits (PREPEND):	<input type="text"/>
Locator (LOCATOR):	<input type="text"/>
On-Site Notification DN (OSDN):	<input type="text"/>

Enter the information for the new ERL and click **Submit**.

### Subnet Information

The Subnet Location Information Web pages allow users to modify subnet information.

Click the **Emergency Services > Subnet Information** link in the **System** branch of the Element Manager navigator to open the **Subnet Location Information Service** Web page, as shown in [Figure 118 "Subnet Location Information Service Web page" \(page 199\)](#).

**Figure 118**  
**Subnet Location Information Service Web page**

Managing: [192.167.102.3](#)  
 System » Emergency Services » Subnet Location Information Service

---

## Subnet Location Information Service

**Maintenance**  
[Emergency Services Diagnostics](#) (LD 117)

**Configuration**

Goto Subnet Index

	IP Address	Mask bits	Emergency Response Location	Emergency Caller Location	Location Description
<input type="radio"/>	<a href="#">192.167.102.3</a>	32	256	4444	

---

Number of entries in range [1, 30] = 1, Total number of entries in Subnet Lookup Table = 1 Items per page   |  |  |

The Maintenance section contains a link to the **Emergency Services Diagnostics** Web page. See “[Emergency Services Diagnostics](#)” (page 75).

The Configuration section lists the configured subnet entries. To delete a configured Subnet Location, select the appropriate radio button beside an IP Address and click **Delete**.

To edit a configured Subnet Location, click the Subnet Location **IP Address**. The **Edit Subnet Location Information** Web page appears, as shown in [Figure 119 "Edit Subnet Location Information Web page"](#) (page 200).

**Figure 119**  
**Edit Subnet Location Information Web page**

Managing: [192.167.102.3](#)  
System » Emergency Services » [Subnet Location Information Service](#) » Edit Subnet Location Information

---

### Edit Subnet Location Information

Input Description	Input Value
IP Address (IP):	<input type="text" value="192.167.102.3"/> *
Mask bits (MASKBITS):	<input type="text" value="32"/> * ( 1 - 32 )
Emergency Response Location (ERL):	<input type="text" value="256"/> * ( 1 - 65535 )
Emergency Caller Location (ECL):	<input type="text" value="4444"/> * ( 0 - 65535 )
Location Description (LOCATIONDESCRIPTION):	<input type="text"/>

To add a Subnet Location, from the **Subnet Location Information Service** Web page click **Add**. The **Add Subnet Location Information** Web page appears, as shown in [Figure 120 "Add Subnet Location Information Web page"](#) (page 201).

**Figure 120**  
**Add Subnet Location Information Web page**

Managing: [192.167.100.3](#)  
 System » Emergency Services » [Subnet Location Information Service](#) » Add Subnet Location Information

---

### Add Subnet Location Information

Input Description	Input Value
IP Address (IP):	<input type="text" value="0.0.0.0"/>
Mask bits (MASKBITS):	<input type="text"/> ( 1 - 32 )
Emergency Response Locator (ERL):	<input type="text"/> ( 1 - 65535 )
Emergency Caller Locator (ECL):	<input type="text"/> ( 0 - 65535 )
Location Description (LOCATIONDESCRIPTION):	<input type="text"/>

Enter the information for the new Subnet Location and click **Submit**.

### Dynamic ELIN

The Dynamic Identification Web pages allow users to modify Dynamic Emergency Location information.

Click the **Emergency Services > Dynamic ELIN** link in the **System** branch of the Element Manager navigator to open the **Dynamic ELIN** Web page, as shown in [Figure 121 "Dynamic ELIN Web page"](#) (page 202).

**Figure 121**  
**Dynamic ELIN Web page**

Managing: [192.167.102.3](#)  
 System » Emergency Services » Dynamic ELIN

### Dynamic ELIN

[Refresh](#)

Emergency Response Location	Terminal Number	Dynamic ELIN	State	Mapped DN	Expiry Time (MM/DD HH:MM)
No Dynamic ELINs configured					

This Web page lists the configured Dynamic ELINs.

To delete an ELIN, click the radio button for the ELIN and click **Delete**.

To add an ELIN, click **Add**. The **Add Dynamic Location Identification Number** Web page appears, as shown in [Figure 122 "Add Dynamic Location Identification Number Web page"](#) (page 202).

**Figure 122**  
**Add Dynamic Location Identification Number Web page**

Managing: [192.167.100.3](#)  
 System » Emergency Services » [Dynamic Location Identification Number](#) » Add Dynamic Location Identification Number

### Add Dynamic Location Identification Number

Input Description	Input Value
Emergency Response Location (ERL):	<input type="text"/> (1 - 65535)
Terminal Number (TN):	<input type="text"/>

Enter the information for the new ELIN and click **Submit**.

### Virtual Office Phone

The Virtual Office Phone Web pages allow users to maintain lists of mapped and unused Virtual Office TNs.

Click the **Emergency Services > Virtual Office Phone** link in the **System** branch of the Element Manager navigator to open the **Virtual Office Phone** Web page, as shown in [Figure 123 "Virtual Office Phone Web page"](#) (page 203).

**Figure 123**  
**Virtual Office Phone Web page**

Managing: [192.167.102.3](#)  
System » Emergency Services » Virtual Office Phone

### Virtual Office Phone

Incoming and outgoing calls to emergency services are provided to virtual office phones

**Mapped Virtual Office TNs**

Add... Delete Refresh

Customer ▲	Emergency DN	Number of TNs in pool	Starting TN	TN Reservation
1 <input type="radio"/>	911	1	096 0 00 00	20

**Virtual Office TNs In Use**

Trace Refresh

Virtual Office TN ▲	Virtual Office DN	TN	Timer	Signalling IP

To delete a Mapped Virtual Office TN, click the radio button for the Customer and click **Delete**.

To Add a Mapped Virtual Office TN, click **Add**, enter the information for the new Virtual Office TN, and click **Save**.

This Web page includes two sections listing Mapped Virtual Office TN Pools and Virtual Office TNs in use.

## Geographic Redundancy

Geographic Redundancy is available only on CPP IV and CP PM systems.

## Database Replication Control

To configure or edit Database Replication information, click the Geographic Redundancy > Database Replication Control link in the System branch of the Element Manager navigator. The **Database Replication Control** Web page appears as shown in [Figure 124 "Database Replication Control Web page" \(page 204\)](#).

**Figure 124**  
**Database Replication Control Web page**

On the **Database Replication Control** Web page, you can configure the following information:

- Rule Number for backup and Restore
- Automatic Replication Backup (ABKUP)
- Automatic Replication restore
- Automatic Sysload

**Note:** You must configure one SCS backup rule before **Database Replication Control** Web page can be configured.

You can also create a Secret string. You create a mandatory Secret string for encryption and decryption of a zipped database and database replication.

## State Control

To configure State Control information, click the **Geographic Redundancy > State Control** link in the **System** branch of the Element Manager navigator. The **State Control** Web page appears as shown in [Figure 125 "State Control Web page"](#) (page 205).

**Figure 125**  
**State Control Web page**

Managing: [Buffy 1 \(47.11.139.4\)](#)  
System » Geographic Redundancy » State Control

### State Control

Input Description	Input Value
Geographic Redundancy Threshold (GRTHR):	<input type="text" value="1"/>
Short Term Failure Timeout in minutes (STFTO):	<input type="text" value="5"/>
Fault Clearance Timeout in minutes (FCTO):	<input type="text" value="5"/>
Secondary CS Deactivation Mode (SDAM):	<input type="text" value="Automatic (AUTO)"/>

On the **State Control** Web page, users can configure:

- Associated Secondary Call Server
- Threshold1 (Number Of IP phones registered)
- Threshold2 (Number of Media Gateways registered)
- Short Term Failure Timeout in minutes
- Fault Clearance Timeout in minutes
- Secondary CS Deactivation Mode

The information entered on this Web page corresponds to the commands available in LD 117.

For more information about Geographic Redundancy, see *System Redundancy Fundamentals (NN43001-507)*.

## Software

The **Software** link of the **System** branch of the Element Manager navigator can be used to perform patching of the Call Server or the Media Gateway.

To have access to the patching feature, you must enter the administration password configured in LD 17 and have PDT access. Patches can be downloaded from the Nortel web site using any web browser.

For MGC and VGMC loadware distribution and functionality instructions, refer to the "Enterprise Voice Solutions Patch Reference and Best Practice Guidelines" located on the Enterprise Solutions PATCH Library (ESPL) page at [www.nortel.com/espl](http://www.nortel.com/espl). Authorized users can log in to the ESPL using their e-mail address as Login ID, SAM ID or Norpass password. If the user does not have access to the ESPL page, it will show as "Not available". Users who do not have access can contact Nortel ESPL support for assistance, or can follow the New User Registration link from the main ESPL Login page.

### Call Server PEPs

Perform Call Server patching by clicking the **Software > Call Server PEPs** link in the **System** branch of the Element Manager navigator. The **Call Server** Web page appears, as shown in [Figure 126 "Call Server Web page" \(page 207\)](#).

**Figure 126**  
**Call Server Web page**

Managing: **192.167.102.3**  
 System » Software » Call Server

---

### Call Server

User PEPs       Dependency lists

PEP Setting		PEP Bin (Total: 0; Limit: 15)	
PEP File Name	<input type="text"/> <input type="button" value="Browse..."/>		
Days PEP vulnerable to sysload	<input type="text" value="3"/>	<input type="button" value="--&gt;"/>	<input type="button" value="Load and Activate"/>
In service initialize threshold	<input type="text" value="5"/>	<input type="button" value="&lt;&lt;--"/>	
In service days to monitor inits	<input type="text" value="7"/>		

Select Command	PEP ID	Apply to All	
PEP Status (PSTAT) <input type="button" value="v"/>	<input type="text"/>	<input type="checkbox"/>	<input type="button" value="Submit"/>

```

System has no loaded patches.
Total number of in service patches      = [ 0 ]
Total number of out-of-service patches = [ 0 ]
Protected heap allocated = [ 208KB ]
Protected heap free      = [ 3887KB ] ( 94% )
  
```

From the **Call Server** Web page, the user can:

- load and activate a new Product Enhancement Package (PEP)
- get the status of a single PEP or all PEPs (PSTAT)
- activate a single PEP or all PEPs (PINS)
- deactivate a single PEP or all PEPs (POOS)
- remove a single PEP or all PEPs (POUT)
- view the details on a PEP (PLIS)

The **PEP Setting** section at the top left of the Web page enables the user to select files and choose settings. Clicking the right arrow (->>) button moves PEP files into the **PEP Bin** section. Clicking the left arrow (<<-) button moves PEP files out of the **PEP Bin** section. Click **Load and Activate** to submit the selected PEP to the call server. Results are displayed at the bottom of the screen.


**Note:** The user can download only 15 PEP files at a time. To install more than 15 PEPs on a single entity, the user must run the utility again.

All PEP commands require the PEP ID. After selecting the PEP command from the drop-down list, enter the **PEP ID** in the text box.

The **Apply to All** check box is enabled for all commands with the exception of the PLIS command. Clicking the **Submit** button executes the command. Results are displayed at the bottom of the screen.

PEP Management can be applied to Call Servers. Element Manager enables users to load Matrix DepLists (MDP) to the Call Server and manage the MDPs by using the Management DepList commands. Click the **Dependency lists** radio button. See [Figure 127 "Call Server Web page - Dependency Lists"](#) (page 208).

**Figure 127**  
**Call Server Web page - Dependency Lists**



Managing: [192.167.102.3](#)  
System > Software > Call Server

## Call Server

User PEPs
  Dependency lists

**Dependency list Setting**

Dependency list File Name

Select Command	DepList Name	
DEPLIST Load (DLOAD) <input type="button" value="v"/> Days PEP vulnerable to sysload <input type="text" value="3"/> In service initialize threshold <input type="text" value="5"/> In service days to monitor inits <input type="text" value="7"/>	<input type="text" value="All"/> <input type="button" value="v"/>	<input type="button" value="Submit"/>

Call Server:  
-----  
System has no loaded Dependency Lists.

PEP lists are populated with individual PEPs contained in an update when a Matrix DepList is opened. The **Refresh** command refreshes the contents of an MDP on a target system and enables the user to load MDPs properly.

PEP Management supports the following commands:

- load and activate a new PEP (DLOAD)
- get the status of a single PEP or all PEPs (DSTAT)
- activate a single PEP or all PEPs (DINS)
- deactivate a single PEP or all PEPs (DOOS)
- remove a single PEP or all PEPs (DOUT)
- view the details on a PEP (DLIS)

Each PEP in the Matrix DepList has its own PEP handle and can be uninstalled, similar to current multipatch functionality.

### Loading and Activating PEP Settings on the Call Server

Step	Action
1	Select the <b>User PEPs</b> radio button on the <b>Call Server</b> page.
2	Click <b>Browse</b> . The <b>Choose file</b> window appears.
3	Choose a file to be downloaded and click <b>Open</b> .
4	Enter the number of <b>Days PEP vulnerable to sysload</b> .
5	Enter the <b>In service initialize threshold</b> .
6	Enter the <b>In service days to monitor inits</b> .
7	Click the -->> (right arrow) button to move the PEP files into the PEP Bin section.
8	Click <b>Load and Activate</b> to submit the selected PEPs to the call server. Results are displayed at the bottom of the screen.

--End--

### Additional Commands

From the **Select Command** list select one of the following:

- **PEP Status (PSTAT)** - Shows the status of the PEP
- **PEP In-Service (PINS)** - Places the PEP in service
- **PEP Out-Of-Service (POOS)** - Takes the PEP out of service
- **PEP Out (POUT)** - Unloads the PEP
- **PEP List (PLIS)** - Lists information about the PEP

Once the appropriate command has been selected, select either **PEP ID** and enter the PEP ID that you want to execute the command on or select **Apply to All** to execute the selected command on all of the PEPs. Once this has been completed, select **Submit**.

### Loading and Activating Dependency lists on the Call Server

Step	Action
1	Select the <b>Dependency lists</b> radio button on the <b>Call Server</b> page.
2	Click <b>Browse</b> . The <b>Choose file</b> window appears.
3	Choose a file to be downloaded and click <b>Open</b> .
4	Click <b>Load and Activate</b> to submit the selected Deplist to the call server.

--End--

### Additional Commands

From the **Select Command** box select one of the following:

- **DEPLIST Load (DLOAD)** - Loads the Deplist
- **DEPLIST Status (DSTAT)** - Shows the status of the Deplist
- **DEPLIST In-Service (DINS)** - Places the Deplist in service
- **DEPLIST Out-Of-Service (DOOS)** - Takes the Deplist out of service
- **DEPLIST Out (DOUT)** - Unloads the Deplist
- **DEPLIST List (DLIS)** - Lists information about the Deplist

Once the appropriate command has been selected, select the **Deplist Name** that you would like to execute the command on. Once this has been completed, select **Submit**.

The following other changes can be executed when loading a Deplist:

- Enter the number of **Days PEP vulnerable to sysload**
- Enter the **In service initialize threshold**
- Enter the **In service days to monitor inits**



#### WARNING

Service updates that contain many PEPs can take time to install.


### Software

The **Software** link of the **System** branch of the Element Manager navigator can also be used to upload and store files, upgrade firmware, and perform patching activities.

## Centralized File Upload

The file upload function enables users to upload and store loadware and firmware files on the Signaling Server. These files can then be downloaded to network elements, using the functions available under the **Software > File Upload** link in the **System** branch of the navigator. The **Centralized File Upload** Web page appears as shown in

**Figure 128**  
Centralized File Upload Web page



For more information about the file upload function, see *Signaling Server IP Line Application Fundamentals (NN43001-125)*.

## IP Phone Firmware

The **Software > IP Phone Firmware** link in the **System** branch of the Element Manager navigator allows users to upgrade IP Phone firmware. For more information, see *Signaling Server IP Line Application Fundamentals (NN43001-125)*.

## Voice gateway media card loadware

The **Software > Voice Gateway Media Card** link in the **System** branch of the Element Manager navigator allows users to upgrade VGMC loadware as shown in the following figure. For more information, see *Signaling Server IP Line Application Fundamentals (NN43001-125)*.

**Figure 129**  
**VGMC Loadware Upgrade**



### Media Cards

Click the **Software > Media Cards PEPs** link in the **System** branch of the Element Manager navigator to open the **Media Cards** Web page as shown in [Figure 130 "Media Cards Web page" \(page 213\)](#).

**Figure 130**  
Media Cards Web page

From this Web page the following functions can be performed:

- load and activate a new PEP
- view the status of a single PEP or all PEPs (PSTAT)
- activate a single PEP or all PEPs (PINS)
- deactivate a single PEP or all PEPs (POOS)
- remove a single PEP or all PEPs (POUT)
- view the details on a PEP (PLIS)

The **PEP Setting** section at the top left of the Web page enables users to select files and choose settings.

#### **Procedure 87** **Loading and Activating PEP Settings to the Signaling Server**

Step	Action
1	Select the correct <b>Element</b> type and then <b>Platform</b> type.
2	Click <b>Browse</b> . The <b>Choose file</b> window appears.

- 3 Choose a file to be downloaded and click **Open**.
- 4 Enter the number of **Days PEP vulnerable to sysload**.
- 5 Enter the **In service initialize threshold**.
- 6 Enter the **In service days to monitor inits**.
- 7 Click the -->> (right arrow) button to move the PEP files into the PEP Bin section.
- 8 Click **Load and Activate** to submit the selected PEPs to the call server.

Results are displayed at the bottom of the screen.

---

--End--

---

Clicking the -->> (right arrow) button moves PEP files into the **PEP Bin** section. Likewise, clicking the <<-- (left arrow) button moves PEP files out of the **PEP Bin** section. Click **Load and Activate** to submit the selected PEPs to the call server. Results are displayed at the bottom of the screen.

**Note:** A maximum of 15 PEP files can be downloaded at a time. If more than 15 PEPs must be installed on a single entity, the utility must be run again.

Click the **PSTAT** button to open the **Type** Web page for the selected element.

All PEP commands require the PEP ID. After selecting the PEP **Command** from the drop-down list, enter the **PEP ID** in the text box.

The **Apply to All** check box is enabled for all commands with the exception of the PLIS command. Clicking the **Submit** button executes the command. Results are displayed at the bottom of the screen.

**Additional Commands:**

---

# Customers, Routes and Trunks

---

## Contents

This section contains information about the following topics:

["Introduction" \(page 215\)](#)

["Customers" \(page 215\)](#)

["Route and Trunk Configuration" \(page 244\)](#)

["Routes and Trunks" \(page 244\)](#)

["D-channels" \(page 254\)](#)

["Digital Trunk Interface" \(page 258\)](#)


## Introduction

The **Customers** and **Routes and Trunks** branches of the Element Manager navigator are used to launch Web pages that enable the user to configure and edit data relating to customers and their equipment.

## Customers

When the user clicks the **Customers** branch of the Element Manager navigator, the **Customers** Web page appears, as shown in [Figure 131 "Customers Web page" \(page 216\)](#). To configure customer data, click the **Customer Number**.

**Figure 131**  
**Customers Web page**



Managing: [192.167.100.3](#)  
Customers

---

### Customers

Buttons: Add... Delete Refresh

	Customer Number *	Total Routes	Total Trunks
1	<input type="radio"/> 00	2	20
2	<input type="radio"/> 01	0	0

**Note:** To create a new customer, you must create a new role in Unified Communications Management (UCM) and modify the permissions for that role so that Customer Tenant Mappings reflect permissions for all customers to be added. For information about creating a new roll in UCM, refer to *Unified Communications Management Common Services Fundamentals* (NN43001-116).

To add a new customer, click **Add**.

The **Basic Configuration** Web page appears, as shown in [Figure 132 "Basic Configuration Web page"](#) (page 217).

**Figure 132**  
**Basic Configuration Web page**

Managing: [192.167.100.3](#)  
[Customers](#) > [Add Customer](#) > [Basic Configuration](#)

---

### Basic Configuration

Customer number:  \* (0 - 99)

ANI Attendant Billing number:  \*


ANI Listed Directory Number:  \*

The information entered in this Web page corresponds to Default Customer Data Block information traditionally configured using LD 15 - Customer Data Block.

Enter the required information in the three fields and click **Save**.

The **Customer Details** Web page appears, as shown in [Figure 133 "Customer Details Web page"](#) (page 218).

**Figure 133**  
**Customer Details Web page**



This Web page contains links to web pages where users can configure additional parameters for each route data block.

### **Application Module Link**

The **Application Module Link** Web page allows users to configure the Application Module Link data block for a customer. Click **Application Module Link** to open this Web page, as shown in [Figure 134 "Application Module Link Web page"](#) (page 219).

**Figure 134**  
**Application Module Link Web page**

Enter the **Value Added Service Identifier** and Group status events information and click **Save**.

## Attendant

The **Attendant** web page allows users to configure the Application Module Link data block for a customer. Click **Attendant** to open this Web page, as shown in [Figure 134 "Application Module Link Web page"](#) (page 219).

Select the appropriate check boxes in the Attendant Web page and click **Save**.

### Call Detail Recording

The **Call Detail Recording** Web page allows users to configure the Call Detail Recording data block for a customer. Click **Call Detail Recording** to open this Web page, as shown in [Figure 135 "Call Detail Recording Web page"](#) (page 220).

**Figure 135**  
**Call Detail Recording Web page**

The screenshot shows the 'Call Detail Recording' configuration page. At the top, there is a breadcrumb trail: 'Customers » Customer 00 » Edit » Call Detail Recording'. The page title is 'Call Detail Recording'. Below the title, there are several configuration options:

- Call Detail Recording:
- Incoming Packet data call:
- Outgoing Packet data call:
- Auxiliary Identification Output:
- Display each record in new line:
- Coordinated Dialing Plan Record:
- End to End Signaling digits in CDR record:
- Buffer Data Interface:
- CDR on Originally Dialed Trunk Route:
- Bearer Capability:
- Port:
- Calling Number Identification:
- Charge Account Number length:
- Forced Charge Account:
- Minimum number of digits for FCA code:
- FCA network class of service:  (0 - 99)

Enter the appropriate information and click **Save**.

### Call Party Name Display

The **Call Party Name Display** Web page allows users to configure the Call Party Name Display data block for a customer. Call Party Name Display names for Incoming Digit Conversion (IDC) are supported on this Web page. Click **Call Party Name Display** to open this Web page, as shown in [Figure 136 "Call Party Name Display Web page"](#) (page 221).

**Figure 136**  
**Call Party Name Display Web page**

Managing: [192.167.104.53](#)  
[Customers](#) > Customer 00 > [Edit](#) > Call Party Name Display

### Call Party Name Display

Configuration:

Maximum length:

Static allocation of name storage:

Default length:

Designator for multiple appearance DNs:

Display reasons for call redirection:

Set mnemonics for different types of call redirection

Call forward all calls:

Call forward no answer:

Hunt or call forward busy:

Call pickup:

Call transfer:

Attendant alternative answering:

Emergency Consultation:

Call forward Non Intercom call:

Enter the appropriate information and click **Save**.

**Note:** The **Static Allocation of name storage** check box will be checked and not editable if the BGD package is enabled.

### Call Redirection

The **Call Redirection** Web page allows users to configure the Call Redirection data block for a customer. Click **Call Redirection** to open this Web page, as shown in [Figure 137 "Call Redirection Web page" \(page 222\)](#).

**Figure 137**  
**Call Redirection Web page**

Managing: [192.168.209.63](#) Username: admin2  
[Customers](#) » [Customer 00](#) » [Customer Details](#) » Call Redirection

---

### Call Redirection

CFNA treatment for DID calls:

DID forward no answer ring cycles:

CFNA treatment for external trunk DID calls:

CFNA treatment for other calls:

Call forward to trunk access code:

Customer call forwarded DN:  ( 0 - 23 digits )

Change call redirection by time of day:

Alternate time option 0, from:   to   -

Alternate time option 1, from:   to   -

Alternate time option 2, from:   to   -

Alternate time option 3, from:   to   -

Call redirection by day:

Days for day option 0:

Days for day option 1:

Copyright © 2002-2009 Nortel Networks. All rights reserved.

Alternate time option 3, from:   to   -

Call redirection by day:

Days for day option 0:

Days for day option 1:

Days for day option 2:

Days for day option 3:

Redirection Holidays

Do not disturb hunting:

Total redirection count limit:

Options:

- Call forward reminder tone for 500/2500 sets
- CFNA treatment for call waiting calls on a DN
- DID call to second degree busy treatment
- Message center
- Prevention of reciprocal call forward

Call forward:  Originating  
 Forwarding

**Number of normal ringing cycles for CFNA**

Option 0:

Copyright © 2002-2009 Nortel Networks. All rights reserved.

Enter the appropriate information, select appropriate options and click **Save**.

Click **Redirection Holidays** to open the **Redirection Holidays** Web page, as shown in [Figure 138 "Redirection Holidays Web page"](#) (page 223).

This Web page displays holiday redirections for existing dates and allows users to add, edit, or delete holidays.

**Figure 138**  
**Redirection Holidays Web page**

Managing: [192.167.100.3](#)  
Customers » Customer 00 » Edit » Call Redirection » Redirection Holidays

### Redirection Holidays

Add... Delete Refresh

<input type="checkbox"/> Date	Holiday Redirection 0	Holiday Redirection 1	Holiday Redirection 2	Holiday Redirection 3
1 <input type="checkbox"/> Jan 01 2006	YES	NO	NO	NO
2 <input type="checkbox"/> Dec 25 2006	NO	YES	YES	NO

To add a holiday, click **Add**. The **Add Date of Holiday** Web page appears, as shown in [Figure 139 "Add Date of Holiday Web page"](#) (page 223).

**Figure 139**  
**Add Date of Holiday Web page**

Managing: [192.167.100.3](#)  
Customers » Customer 00 » Edit » Call Redirection » Redirection Holidays » Add Date of Holiday

### Add Date of Holiday

Date: 1 January 2006

Holiday Redirection 0:

Holiday Redirection 1:

Holiday Redirection 2:

Holiday Redirection 3:

Save Cancel

Use this Web page to configure holiday redirections for a customer. Enter the holiday information and click **Save**.

## Centralized Attendant Service

The **Centralized Attendant Service** Web page allows users to centralize their attendant services at a single location. From the **Edit** Web page, click **Centralized Attendant Service** to open this Web page, as shown in [Figure 140 "Centralized Attendant Service Web page"](#) (page 224).

**Figure 140**  
**Centralized Attendant Service Web page**

Managing: [192.167.104.53](#)  
[Customers](#) > Customer 00 > [Edit](#) > Centralized Attendant Service

---

### Centralized Attendant Service

Allows customers with multiple locations to centralize their attendant services at a single location.

Status:  Enable Centralized Attendant Service

Main attendant

Incoming Call Indicators

Remote attendant

Active mode after sysload:

Special tone for LDN calls:

Local attendant DN:

Route number:  (0 - 511)

Silent hold DN:

Silent hold recall timer:  (0 - 511 seconds)

Enter the appropriate information and click **Save**.

To edit the Attendant Incoming Call Indicators, click the **Main attendant** radio button, and click **Incoming Call Indicators**. The **Edit Attendant ICI** Web page appears, as shown in [Figure 141 "Edit Attendant ICI Web page"](#) (page 225).

**Figure 141**  
**Edit Attendant ICI Web page**

Managing: [192.167.100.3](#)  
[Customers](#) > [Customer 00](#) > [Edit](#) > [Centralized Attendant Service](#) > [Edit Attendant ICI](#)

---

### Edit Attendant ICI

Station Category Indication priority level 1 :   
Station Category Indication priority level 2 :   
Station Category Indication priority level 3 :   
Station Category Indication priority level 4 :   
Station Category Indication priority level 5 :   
Station Category Indication priority level 6 :   
Station Category Indication priority level 7 :   
Call Forward Busy :   
Call Forward No Answer :   
Dial zero, fully restricted :   
Dial zero :   
Inter-Attendant DN :   
Inter-Attendant Call :   
Intercept :   
Idle Extension Notification :   
Lockout Intercept :   
Listed DN0 :   
Listed DN1 :   
Listed DN2 :

1

Enter the appropriate information and click **Save**.

### Controlled Class of Service

The **Controlled Class of Service** Web page allows users to configure the Controlled Class of Service data block for a customer. Click **Controlled Class of Service** to open this Web page, as shown in [Figure 142 "Controlled Class of Service Web page"](#) (page 226).

**Figure 142**  
**Controlled Class of Service Web page**

Enter the appropriate information and click **Save**.

### Flexible Feature Codes

The **Flexible Feature Codes** Web page allows users to configure the Flexible Feature Codes (FFC) data block for a customer. To access the **Flexible Feature Codes** Web page for a customer, click the **Flexible Feature Codes** link of the **Edit** Web page to open the Web page shown in [Figure 143 "Flexible Feature Codes Web page"](#) (page 226).

**Figure 143**  
**Flexible Feature Codes Web page**

To configure Change Flexible Feature Code end-of-dialing indicator, select the **Change Flexible Feature Code end-of-dialing indicator** checkbox.


Enter the appropriate information and click **Save**.

### Flexible Feature Code Entries

To access Flexible Feature Code Entries click on the **Flexible Feature Code Entries** hyperlink. The **Search for Flexible Feature Code Entries** Web page appears as shown in [Figure 144 "Search for Flexible Feature Code Entries Web page"](#) (page 227).

**Note:** To access **Flexible Feature Code Entries** Web page for a Customer the FCC data block must be configured, see [Procedure 91 "Configuring Flexible Feature Codes"](#) (page 229). If you click the Flexible Feature Code Entries hyperlink before configuring the FCC data block, the message "*FCC Block is not configured. Click on [OK] to configure the FCC block for the customer.*" appears. Click **OK** to automatically configure the FCC data block and open the **Flexible Feature Code Entries** Web page.

**Figure 144**  
**Search for Flexible Feature Code Entries Web page**



Managing: 192.167.100.3  
Customers > Customer 00 > Edit > Flexible Feature Codes > Flexible Feature Code Entries

### Flexible Feature Code Entries

Search for Flexible Feature Code Entries

Flexible feature code type  [Lookup](#)

Value

### Flexible Feature Code Entries

Search for a type or value. Use the Lookup link to populate type prompts or search using "\*" before or after the search text.

To search for specific Flexible Feature Codes, follow the steps in [Procedure 88 "Searching for Flexible Feature Codes"](#) (page 228).

**Procedure 88**  
**Searching for Flexible Feature Codes**

---

<b>Step</b>	<b>Action</b>
1	Click the <b>Flexible feature code type</b> radio button to activate search for Flexible Feature Codes.
2	Click the <b>Look up</b> hyperlink. The <b>Flexible Feature Code Lookup</b> pop up window appears.
3	Click the check box of the required features and click <b>Assign</b> . The selected feature prompt names are displayed in the <b>Specific Feature Code type</b> input box.
4	Click <b>Search</b> . The datagrid lists only the codes for the selected feature.

---

--End--

---

To search for Flexible Feature Codes by Value, follow the steps in [Procedure 89 "Searching for Flexible Feature Codes by Value" \(page 228\)](#).

**Procedure 89**  
**Searching for Flexible Feature Codes by Value**

---

<b>Step</b>	<b>Action</b>
1	Enter the configured Flexible Feature Code value in the <b>Value</b> input box.
2	Check the <b>Value</b> radio button, the <b>Search</b> button is enabled.
3	Click the <b>Search</b> button. The flexible feature code, type, and the value are listed in the datagrid.

---

--End--

---

To search for Flexible Feature Codes using Advanced Search, follow the steps in [Procedure 90 "Searching for Flexible Feature Codes \(Advanced\)" \(page 228\)](#).

**Procedure 90**  
**Searching for Flexible Feature Codes (Advanced)**

---

<b>Step</b>	<b>Action</b>
1	Enter the wildcard character * before or after the search text in the 'Flexible feature code type' input box.
2	Check the <b>Flexible feature code type</b> radio button, the <b>Search</b> button is enabled.

- 3 Click the **Search** button. All the flexible feature code type with the configured values that match the given search text are listed in the datagrid.

---

--End--

---

To configure Flexible Feature Codes for a customer, follow the steps in [Procedure 91 "Configuring Flexible Feature Codes" \(page 229\)](#).

#### Procedure 91 Configuring Flexible Feature Codes

Step	Action
1	In the <b>Flexible Feature Codes</b> Web page, check the box <b>Flexible Feature Confirmation Tone</b> and <b>Conference European Des Postes Tel (CEPT) defaults</b> . The <b>Replacement for * in CEPT default codes</b> appears as a sub prompt for <b>Conference European Des Postes Tel (CEPT) defaults</b> prompt and should be enabled only when <b>Conference European Des Postes Tel (CEPT) defaults</b> prompt is checked.
2	To complete the configuration, click <b>Save</b> .
3	Click <b>Cancel</b> to cancel the action. The <b>Edit</b> Web page is displayed.

---

--End--

---

To add Flexible Feature Codes to the Customer, follow the steps in [Procedure 92 "Adding Flexible Feature Codes" \(page 229\)](#).

#### Procedure 92 Adding Flexible Feature Codes

Step	Action
1	Click on the <b>Flexible Feature Code Entries</b> hyperlink on the Flexible Feature Code Web page. The Flexible Feature Code Entries Web page appears.
2	Click <b>Add</b> in the <b>Flexible Feature Code Entries</b> Web page. The <b>Add Flexible Feature Code</b> Web page appears.
3	Click the <b>Look up</b> hyperlink adjacent to the <b>Flexible feature code type</b> input box. The <b>Flexible Feature Code Lookup</b> popup window appears and lists all the Flexible Feature Codes.
4	Click on a <b>Flexible Feature Code</b> to add to the <b>Flexible feature code type</b> input box.
5	Enter a value in the <b>Value</b> box.

- 6 Click **Save**, to add the Flexible Feature Code. The new Flexible Feature Code is displayed in the **Flexible Feature Code Entries** Web page.

---

--End--

---

## Features

The **Features** Web page allows users to configure the Features data block for a customer. Click **Features** to open this Web page, as shown in [Figure 145 "Features Web page"](#) (page 230).

**Figure 145**  
**Features Web page**

Managing: 192.168.209.63 Username: admin2  
Customers » Customer 00 » Customer Details » Features

### Features

Special prefix number:

Network authorization code:

Internal/external definition:

Analog semi-permanent connection re-connection timer:  (10 - 180)

Network station camp-on to sets on this node:

List entry number delimiter:

Mandatory speed call delimiter:

Lamp status when boss's set has BSFE active and is idle:

Lamp status when boss's set has BSFE active and is busy:

Lamp status when boss's set does not have BSFE active and is idle:

Lamp status when boss's set has BSFE active and is busy:

Lamp status when boss's set does not have BSFE active and is idle:

Lamp status when boss's set doesn't have BSFE active and is busy:

Copyright © 2002-2009 Nortel Networks. All rights reserved.

**Figure 146**  
Feature options

Options:

- Attendant busy display
- Autohold on loop key
- Attendant monitor
- Attendant through dialing
- ACD dialed number identification
- ACD threshold percentage
- Attendant monitor tone
- Break-in to external call
- Break-in to line lockout set
- Break-in warning tone
- Collect call blocking
- Call forward reminder tone for 500/2500 sets
- Charge display at end of call
- Camp-On tone
- CFNA treatment for call waiting calls on a DN
- Coordinated dialing plan routing
- Data services or server
- DID call to second degree busy treatment
- Digit display
- Enhanced busy lamp field

**Figure 147**  
Feature options (Contd)

CS 1000 ELEMENT MANAGER Help | Logout

- Group call pickup
- Hot line access
- Hands-free voice call
- Individual hold lamp option
- Individual hold release option
- Individual hold
- Key ringing sequence
- Key/lamp expansion module
- Lockout
- Last number redial
- Malicious call trace signal
- Message center
- Message waiting unconditional
- Network-Wide LDN
- Override of call forward external
- Position busy with calls on hold
- Presentation status selection on attendant consoles
- Queue thermometer REST
- Redirect of attendant calls when ACG is in night service
- Release on exclusion

For Communication Server 1000 Release 7.0, the Key ringing sequence field is added in the Features web page.

To configure Boss Secretary Filtering Enhancement, select the **Boss Secretary Filtering Enhancement** checkbox.

To configure Virtual Office Automatic Logout, select the **Enable Virtual Office Automatic Logout** checkbox

To configure Conference Display, select the **Change conference display configurations** checkbox.

Enter the appropriate information, select appropriate options and then click **Save**.

### Listed Directory Numbers

The **Listed Directory Numbers** Web page allows users to configure the Listed Directory Numbers data block for a customer. Click **Listed Directory Numbers** to open this Web page, as shown in [Figure 148 "Listed Directory Numbers Web page"](#) (page 232).

**Figure 148**  
**Listed Directory Numbers Web page**

Managing: 192.168.209.63 Username: admin2  
Customers » Customer 00 » Customer Details » Listed Directory Numbers

### Listed Directory Numbers

Departmental listed directory number:

Attendant consoles associated with LDN 0:

Attendant consoles associated with LDN 1:

Attendant consoles associated with LDN 2:

Attendant consoles associated with LDN 3:

Attendant consoles associated with LDN 4:

Attendant console associated with LDN 5:

Listed Directory Number 0:

Listed DN 1:

Listed DN 2:

Listed DN 3:

Listed DN 4:

Listed DN 5:

Attendant incoming indicators

Option:  Network-wide LDN

To configure attendant consoles associated with Listed Directory Numbers, select the **Departmental listed directory number** checkbox.

Enter the appropriate information and click **Save**.

## Mobile Service Directory Number

The **Mobile Service Directory Numbers** Web page allows users to view, edit, add, and delete Mobile Service Directory Numbers. Click **Mobile Service Directory Numbers** to open this Web page, as shown in [Figure 149 "Mobile Service Directory Numbers Web page" \(page 233\)](#). For more information about Mobile Directory Service Numbers and Mobile Extension, refer to *Features and Services Fundamentals - Book 4 of 6* (NN43001-106-B6).

**Figure 149**  
**Mobile Service Directory Numbers Web page**

Managing: [192.167.100.3](#)  
Customers > Customer 00 > Edit > Mobile Service DNs

### Mobile Service Directory Numbers

Mobile Service DN can be dialed by a mobile user in a mobile network to gain access to the enterprise network

Add... Delete Refresh

	DN *	Security Code	Authorization Code	Collect Call Blocking
1	<a href="#">4445555</a>	98765432	YES	YES
2	<a href="#">5556666</a>	87654321	YES	YES

## ISDN and ESN Networking

The **ISDN and ESN Networking** Web page allows users to configure the Integrated Services Digital Network (ISDN) and ESN Networking data block for a customer. Click **ISDN and ESN Networking** to open this Web page, as shown in [Figure 150 "ISDN and ESDN Networking Web page" \(page 234\)](#).

**Figure 150**  
**ISDN and ESN Networking Web page**

Managing: 192.168.55.152 Username: admin2  
 Customers > Customer 00 > Customer Details > ISDN and ESN Networking

**ISDN and ESN Networking**

**General Properties**

Flexible trunk to trunk connection option:

Flexible orbiting prevention timer:

Country code:  (p - 9999)  
Code for processing the called number

National access code:

International access code:

Options:  Transfer on ringing of supervised external trunks  
 Connection of supervised external trunks

Network option:  Coordinated dialing plan routing

Integrated services digital network:

Microsoft converged office dialing plan:

Private dialing plan for non-DID users:  Coordinated dialing plan  
 Uniform dialing plan

Copyright © 2002-2009 Nortel Networks. All rights reserved.

Enter the appropriate information and click **Save**.

When ISDN is enabled in ISDN and ESN Networking page, the Microsoft converged office dialing plan fields become active and editable as shown in the following figure.

**Figure 151**  
**ISDN and ESN Networking Web page with ISDN enabled**

Managing: 192.168.55.152 Username: admin2  
 Customers > Customer 00 > Customer Details > ISDN and ESN Networking

**ISDN and ESN Networking**

**General Properties**

Flexible trunk to trunk connection option:

Flexible orbiting prevention timer:

Country code:  (p - 9999)  
Code for processing the called number

National access code:

International access code:

Options:  Transfer on ringing of supervised external trunks  
 Connection of supervised external trunks

Network option:  Coordinated dialing plan routing

Integrated services digital network:

Microsoft converged office dialing plan:

Private dialing plan for non-DID users:  Coordinated dialing plan  
 Uniform dialing plan

Copyright © 2002-2009 Nortel Networks. All rights reserved.

When ISDN is enabled and the Microsoft converged office dialing plan is in Mixed Mode, private dialing plan fields are become active and editable as shown in the following figure.

**Figure 152**  
**Private dialing plan**

Customers » Customer 00 » Customer Details » ISDN and ESN Networking

### ISDN and ESN Networking

**General Properties**

Flexible trunk to trunk connection option:

Flexible orbiting prevention timer:

Country code:  (p - 9999)  
Code for processing the called number

National access code:

International access code:

Options:  Transfer on ringing of supervised external trunks  
 Connection of supervised external trunks

Network option:  Coordinated dialing plan routing

Integrated services digital network:

Microsoft converged office dialing plan:

Private dialing plan for non-DID users:  Coordinated dialing plan  
 Uniform dialing plan

**Calling Line Identification**

Copyright © 2002-2009 Nortel Networks. All rights reserved.

To configure Calling Line Identification (CLID) parameters, click **Calling Line Identification Entries**. The **Calling Line Identification Entries Web page** appears, as shown in [Figure 153 "Calling Line Identification Entries Web page"](#) (page 235).

**Figure 153**  
**Calling Line Identification Entries Web page**

Managing: **192.167.100.3**

Customers » Customer 00 » Edit » ISDN and ESN Networking » Calling Line Identification Entries

### Calling Line Identification Entries

**Search for CLID**

Criteria:

CLID Range:

**Calling Line Identification Entries**

To search for a CLID, enter the **CLID Range** and click **Search**.

To add a CLID, click **Add**. The **New Calling Line Identification Web page** appears, as shown in [Figure 154 "New Calling Line Identification Web page"](#) (page 236).

**Figure 154**  
**New Calling Line Identification Web page**

Managing: [192.167.104.53](#)  
[Customers](#) > Customer 00 > [Edit](#) > [ISDN and ESN Networking](#) > [Calling Line Identification Entries](#) > New Calling Line Identification

---

### New Calling Line Identification

**General Properties**

Entry Id:  \*

National Code:  (0 - 999999)  
Code for national home number

Local Code:  (1-12 digits)  
Code for home local number or listed DN

Home Location Code:  (1-7 digits)

Local Steering Code:  (1-7 digits)

Use DN as DID: YES

**Emergency Services Access**

Emergency Local Code:  (1-12 digits)  
Code for home local number during Emergency calls

Emergency Options:  Home national number for emergency services access calls  
 Append the originating directory number for emergency services access calls

**Calling Party Name Display**

Roman characters:

Enter the parameters for the new CLID and click **Save**.

### Night Service

The **Night Service** Web page allows users to configure the Night Service data block for a customer. Click **Night Service** to open this Web page, as shown in [Figure 155 "Night Service Web page" \(page 237\)](#).

**Figure 155**  
**Night Service Web page**

Managing: [192.167.100.3](#)  
[Customers](#) » [Customer 00](#) » [Edit](#) » Night Service

---

### Night Service

First night service DN by time of day:   
Hour and minute for first night service DN:   
Second night service DN by time of day:   
Hour and minute for second night service DN:   
Third night service DN by time of day:   
Hour and minute for third night service DN:   
Fourth night service DN by time of day:   
Hour and minute for fourth night service DN:

Enter the appropriate information and click **Save**.

### Feature Packages

The **Feature Packages** Web page allows users to view and edit the parameters associated with feature packages. Click **Feature Packages** to open this Web page.

Click the plus sign located to the left of the Feature Packages heading to expand the feature packages, as shown in [Figure 156 "Feature Packages Web page"](#) (page 238).

**Figure 156**  
**Feature Packages Web page**

- Feature Packages	
+ Do Not Disturb Individual	Package: 9
+ End-to-End Signaling	Package: 10
+ Message Waiting Center	Package: 46
+ New Flexible Code Restriction	Package: 49
+ Set Relocation	Package: 53
+ Network Alternate Route Selection	Package: 58
+ Distinctive Ringing	Package: 74
+ Departmental Listed Directory Number	Package: 76
+ Command Status Link	Package: 77
+ Pretranslation	Package: 92
+ Dialed Number Identification System	Package: 98
+ Malicious Call Trace	Package: 107
+ Incoming Digit Conversion	Package: 113
+ Directed Call Pickup	Package: 115
+ Enhanced Music	Package: 119
+ Station Camp-On	Package: 121
+ Integrated Digital Access	Package: 122
+ Digital Private Network Signaling System 1	Package: 123
+ Flexible Tones and Cadences	Package: 125
+ Multifrequency Compelled Signaling	Package: 128
+ International Supplementary Features	Package: 131
+ Enhanced Night Service	Package: 133
+ Integrated Services Digital Network	Package: 145

7

**Figure 157**  
**Feature Packages Web page (Contd)**

The screenshot displays a web interface for managing feature packages. It features a list of packages with expandable/collapsible icons (+/-) and package numbers. Below the list, there are three input fields: a text box for 'Media services routing number' (containing '2345'), a dropdown for 'Numbering plan identifier (NPI)' (set to 'Private'), and a dropdown for 'Type of number (TON)' (with a menu open showing options: ESN\_CDP, ESN\_POP, ESN\_LWC, ESN\_SPN, International, Local, National, and Unknown). 'Save' and 'Cancel' buttons are visible at the bottom right. A copyright notice 'Copyright © 2002-2010 Nortel Networks. All rights reserved.' is at the bottom left.

+ International Supplementary Features	Package: 131
+ Enhanced Night Service	Package: 133
+ Integrated Services Digital Network	Package: 145
+ Flexible Services	Package: 152
+ Network Attendant Service	Package: 159
+ Flexible Numbering Plan	Package: 160
+ Trunk Failure Monitor	Package: 182
+ Radio Paging	Package: 187
+ DPNSS Network Services	Package: 231
+ M911 Enhancement Display	Package: 249
+ Called Party Control on Internal Calls	Package: 310
+ DPNSSI Message Waiting Indication	Package: 325
+ M3900 Product Enhancement	Package: 386
- IP Media Services	Package: 422

Media services routing number:

Numbering plan identifier (NPI):

Type of number (TON):

ESN\_CDP  
 ESN\_POP  
 ESN\_LWC  
 ESN\_SPN  
 International  
 Local  
 National  
 Unknown

Save Cancel

Copyright © 2002-2010 Nortel Networks. All rights reserved.

Enter the Media services routing number. Choose the Numbering plan identifier and Type of number from the respective drop-down lists and then click **Save**.

**Note:** The only feature packages whose parameters can be viewed and edited are those that have been enabled on the system. Feature packages cannot be removed or added from Element Manager.

Click the plus sign located to the left of the feature package name to view and edit the parameters associated with the feature package. For feature packages that are not equipped for the customer, Element Manager includes a button labeled **To Order**. This button provides a link to information on how to order the feature package.

Enter the appropriate information and click **Save**.

#### **ATTENTION**

If configuring M3900 System Initiated Language (Package 386) and Japanese is selected as the default language, the user must explicitly configure the set-to-set-messages (MSG 1 to MSG10). Otherwise, the customer information does not load when clicking **Submit** and does not display.

## Intercept Treatments

The **Intercept Treatments** Web page allows users to configure the Intercept Treatments data block for a customer. Click **Intercept Treatments** to open this Web page, as shown in [Figure 158 "Intercept Treatments Web page"](#) (page 240).

**Figure 158**  
**Intercept Treatments Web page**

Managing: [192.167.100.3](#)  
[Customers](#) > Customer 00 > [Edit](#) > Intercept Treatments

### Intercept Treatments

Congestion tone for all trunks :

Direct inward system access lockout :

Flexible line lockout :

Do not disturb :

Intercept RAN Route Number :  \* (0-511)

Emergency services access misdialled call :

Intercept RAN Route Number :  \* (0-511)

[Additional Treatment Options](#)

Enter the appropriate information and click **Save**.

To configure additional prompts for Intercept Treatments, click **Additional Treatment Options** . The **Intercept Treatments Options** Web page appears, as shown in [Figure 159 "Intercept Treatments Options Web page"](#) (page 241).

**Figure 159**  
Intercept Treatments Options Web page

Managing: [192.167.100.3](#)  
Customers » Customer 00 » Edit » Intercept Treatments » Intercept Treatments Options

### Intercept Treatments Options

Condition	Station	Attendant	Tie Trunk	Non Tie	Ran Route
<a href="#">Access denied</a>	Overflow tone	Overflow tone	Overflow tone	Attendant	
<a href="#">Call to vacant number</a>	Overflow tone	Overflow tone	Overflow tone	Attendant	
<a href="#">Calls to listed directory number</a>	Not applicable	Overflow tone	Not applicable	Not applicable	
<a href="#">Call to a lockout set</a>	Busy tone	Busy tone	Busy tone	Busy tone	
<a href="#">Maintenance busy numbers</a>	Overflow tone	Overflow tone	Overflow tone	Attendant	
<a href="#">Restricted call</a>	Overflow tone	Not applicable	Overflow tone	Not applicable	
<a href="#">Redirection count limit exceeded</a>	Attendant	Overflow tone	Attendant	Attendant	
<a href="#">MFC call to vacant office</a>	Overflow tone	Overflow tone	Overflow tone	Attendant	
<a href="#">MFC call to vacant number</a>	Overflow tone	Overflow tone	Overflow tone	Attendant	
<a href="#">MFC congestion</a>	Overflow tone	Overflow tone	Overflow tone	Attendant	

To edit an Intercept Treatment for a customer, click the **Condition**. The **Edit** Web page for that Condition is displayed, as shown in [Figure 160 "Edit Condition Web page"](#) (page 241).

**Figure 160**  
Edit Condition Web page

Managing: [192.167.100.3](#)  
Customers » Customer 00 » Edit » Intercept Treatments » Intercept Treatments Options » Edit Access denied

### Edit Access denied

Station:

Attendant:

Tie Trunk:

Non Tie:

Intercept RAN Route Number:  \* (0 - 611)

Enter the appropriate information and click **Save**.

## Multi Party Operations

The **Multi Party Operations** Web page allows users to configure the Multi Party Operations data block for a customer. Click **Multi Party Operations** to open this Web page, as shown in [Figure 161 "Multi Party Operations Web page"](#) (page 242).

**Figure 161**  
**Multi Party Operations Web page**

The screenshot shows the 'Multi-Party Operations' configuration page. It is divided into two main sections: 'Flexible Misoperation Options' and 'Programming of Control Digits'. In the 'Flexible Misoperation Options' section, there are dropdown menus for 'Ringing No Answer treatment' (set to 'Standard Operation'), 'All Other Cases' (set to 'Disconnect'), 'Rings before forwarding/disconnecting' (set to '6'), and 'Rings before forwarding to transferring station' (set to '4'). There are also checkboxes for 'Mandatory Recall required prior to dialing control digits' (unchecked), 'Ignore Switchhook Flash signal from 500/2500 sets' (unchecked), and 'Manual Hold after enquiry' (unchecked). A 'Control digit Timeout' dropdown is set to '14'. The 'Programming of Control Digits' section includes dropdown menus for 'Conference' (set to '1'), 'Toggle' (set to '2'), and 'Disconnect' (set to '3'). There are checkboxes for 'Consultation Connection Disconnect Option alternative' (unchecked) and 'Manual forced camp on' (unchecked). At the bottom, the 'Attendant Clearing during Night Service' dropdown is set to 'No Automatic Treatment'.

Enter the appropriate information and click **Save**.

## Recorded Overflow Announcement

The **Recorded Overflow Announcement** Web page allows users to configure the Recorded Overflow Announcement data block for a customer. Click **Recorded Overflow Announcement** to open this Web page, as shown in [Figure 162 "Recorded Overflow Announcement Web page"](#) (page 243).

**Figure 162**  
**Recorded Overflow Announcement Web page**

Managing: 192.168.209.115 Username: admin2  
 Customers > Customer 00 > Customer Details > Recorded Overflow Announcement

**Recorded Overflow Announcement**

First RAN Route:  (0 - 511)

Time Delay:  (0 - 2044 seconds)

Second RAN Route:  (0 - 511)

Time Delay:  (2 - 2044 seconds)

Treatment during waiting time:

Music Route:  (0 - 511)

ICI key numbers that may receive ROA:

ICI key numbers separated by space

Option:  Recorded overflow announcement

Enter the appropriate information and click **Save**.

### SIP Line Service

The SIP Line Service package 417 must be equipped in order to enable SIP Line Service on CS 1000 system.

The **SIP Service** Web page allows users to configure SIP Line Service parameters.

You can enable or disable SIP Line Service by clicking the check box. Once the service is enabled, the rest of the SIP Line service parameters are displayed. The SIP root domain is a mandatory field when SIP Line service is enabled. The User Agent DN is an optional field but when this DN prefix is configured in the customer page, it is used to build the HOT U key information on the **Phones** Web page for SIPL Phones.

For more information, see *SIP Line Fundamentals* (NN43001-508).

**Figure 163**  
**SIP Service Web page**

Managing: 192.168.209.115  
 Customers > Customer 00 > SIP Service

**SIP Service**

SIP Line Service

Root domain:

User agent DN prefix:

Optional features:  None Multimedia

### Timers

The **Timers** Web page allows users to configure the Timers data block for a customer. Click **Timers** to open this Web page, as shown in [Figure 164 "Timers Web page" \(page 244\)](#).

**Figure 164**  
Timers Web page

Managing: [192.167.100.3](#)  
Customers » Customer 00 » Edit » Timers

---

### Timers

Switch hook flash timing :

Permanent hold timer :  ( 1 - 63 )

Dial tone and interdigit timeout for non-DTMF sets :

Dial tone and interdigit timeout for DTMF sets :

Line disconnect tone timer for 500/2500 telephones :  ( seconds )

Delayed answer timer :  ( 0 - 120 seconds )

Busy tone/overflow tone timeout :  ( 2 - 60 seconds )

Duration between reminder cadences :  ( 2 - 120 seconds )

Attendant queue timing threshold :  ( 0 - 255 seconds )

Auto dial delay :  ( seconds )

Attendant forward no answer timer :  ( 0 - 126 seconds )

Attendant forward buzz tone :  ( seconds )

Night forward no answer or ring cycles :  ( 0 - 63 )

Attendant delay on hold timer :  ( seconds )

Length of Howler tone :  ( 0 - 600 seconds )

Network alternate route selection interdigit timer :

Enter the appropriate information and click **Save**.

**Note:** The **Attendant forward no answer timer** and **Attendant forward buzz tone** must be even numbers.

## Route and Trunk Configuration

There are three options in the **Routes and Trunks** branch of the Element Manager navigator.

### Routes and Trunks

Click the **Routes and Trunks** link on the **Routes and Trunks** branch of the Element Manager navigator to open the **Routes and Trunks** Web page, as shown in [Figure 165 "Routes and Trunks Web page" \(page 245\)](#). From this Web page, users can view information about existing customers, routes, and trunks.

**Figure 165**  
Routes and Trunks Web page

Managing: [192.168.55.143](#) Username: admin2  
Routes and Trunks » Routes and Trunks

### Routes and Trunks

- Customer: 0	Total routes: 6	Total trunks: 111	Add route
- Route: 1	Type: ADM	Description: NONE	Edit Add trunk
+ Route: 2	Type: AWR	Description: AWR	Edit Add trunk
+ Route: 3	Type: AWR	Description: AWY	Edit Add trunk
+ Route: 4	Type: TIE	Description: TEST	Edit Add trunk
+ Route: 5	Type: AWR	Description: AWU	Edit Add trunk
+ Route: 13	Type: TIE	Description: MANUA	Edit Add trunk
+ Customer: 1	Total routes: 1	Total trunks: 1	Add route
- Customer: 4	Total routes: 0	Total trunks: 0	Add route
- Customer: 20	Total routes: 0	Total trunks: 0	Add route

This Web page also contains buttons that link to additional Web pages. Follow these links to

- add a new route
- edit route data
- add a new trunk
- edit trunk data
- delete multiple trunks

### Route Properties

Click the **Edit** button beside a Route row to open the **Route Property Configuration** Web page for the selected customer and route. See [Figure 166 "Route Property Configuration Web page" \(page 246\)](#).

**Note:** If there are a large number of routes or trunks, this Web page can be slow to load.

The information entered in the **Basic Configuration** section of this Web page corresponds to Route Data Block information traditionally configured using LD 16 - Route Data Block.

**Note:** H.323 and SIP must not use the same route.

For information about configuring routes, see *IP Peer Networking Installation and Commissioning (NN43001-313)*.

**Figure 166**  
Route Property Configuration Web page

Managing: 192.168.209.81 Username: s0w4ld  
Routes and Trunks > Routes and Trunks > Customer 0, Route 1 Property Configuration

### Customer 0, Route 1 Property Configuration

**- Basic Configuration**

Route data block (RDB) (TYPE): RDB

Customer number (CUST): 00

Route number (ROUT): 1

Designator field for trunk (DES): TEST

Trunk type (TKTP): TIE

Incoming and outgoing trunk (ICOG): Incoming and Outgoing (IAO)

Access code for the trunk route (ACOD): 2345

Trunk type M911P (M911P):

The route is for a virtual trunk route (VTRIO):

Digital trunk route (DTRIO):

Integrated services digital network option (ISDN):

Mode of operation (MODE):

Interface type for route (IFC): Meridian M1 (BL1)

Private network identifier (PNI): 0 (0 - 32700)

Network calling name allowed (NCNA):

Network call redirection (NCRD):

Channel type (CHTY): B-channel (BCH)

Call type for outgoing direct dialed TIE route (CTYP): Unknown Call type (UJYVN)

Insert ESN access code (INAC):

Integrated service access route (ISAR):

Display of access prefix on CLID (DAPC):

Mobile extension route (MBKR):

Mobile extension outgoing type (MBXOT): National number (NPA)

Mobile extension timer (MBXT): 0 (0 - 8000 milliseconds)

Calling number dialing plan (CHNDP): Unknown (UJYVN)

**- Basic Route Options**

**- Network Options**

**- General Options**

**- Advanced Configurations**

Submit Refresh Delete Cancel

### Basic Configuration

In the **Basic Configuration** section of this Web page (see [Figure 167 "Basic Configuration for routes" \(page 247\)](#)), the following functions can be performed:

- Assign a **Route Number** (ROUT) using the drop-down list.
- Enter a **Designation** (DES) for the route.
- Select a **Trunk Type** (TKTP) from the drop-down list.
- Use the drop-down list to indicate that the trunk is **Incoming and/or Outgoing** (ICOG).
- Assign an **Access Code** (ACOD) to the trunk route.

Element Manager may request that users enter data for additional parameters, depending on what is entered in the Basic Configuration fields. Choices in the drop-down lists for every parameter in the Basic Configuration fields are determined by the data entered above that field.

**Figure 167**  
**Basic Configuration for routes**

Managing: 192.168.209.115  
 Routes and Trunks » Routes and Trunks » Customer 0, New Route Configuration

### Customer 0, New Route Configuration

**- Basic Configuration**

Route data block (RDB) (TYPE):

Customer number (CUST):

Route number (ROUT):

Designator field for trunk (DES):

Trunk type (TKTP):

Incoming and outgoing trunk (ICOG):

Access code for the trunk route (ACOD):

+ Basic Route Options  
 + Network Options  
 + General Options  
 + Advanced Configurations

To save changes made in this section, click **Submit** at the bottom of the **Route Property Configuration** Web page.

### Basic Route Options

In the Basic Route Options section (see [Figure 168 "Basic Route Options configuration" \(page 248\)](#)), use the check boxes to activate the following options for this route:

- Billing Number Required (BILN)
- Call Detail Recording (CDR)
- Controls or timers (CNTL)
- Conventional (TIE trunk only) (CNVT)
- Incoming DID Digit Conversion (IDC)
- Process Notification Networked Calls (PNNC)

In addition, use the drop-down list to select a Multi-frequency Compelled or MFC Signaling (MFC) type.

**Note:** The route used in this example is a TIE trunk route. The inputs requested by Element Manager vary depending on the responses to earlier input requests, including Trunk Type (TKTP).

Depending on which boxes are selected in the preceding list, Element Manager requests that users enter data for additional parameters, as shown in [Figure 168 "Basic Route Options configuration" \(page 248\)](#).

**Figure 168**  
**Basic Route Options configuration**

**- Basic Route Options**

Attendant announcement (ATAN)

Billing number required (BILN)

- Billing number length (BLEN)

- Billing number (BNUM)

- Billing number displayed (BDSP)

Call detail recording (CDR)

- CDR records generated on incoming calls (INC)

- CDR record printing content option for redirected calls (LAST)

- Time to answer output in CDR (TTA)

- CDR ACQ Q initial connection records to be generated (QREC)

- CDR on outgoing calls (OAL)

North American toll scheme (NATL)

Controls or timers (CNTL)

Conventional (Tie trunk only) (CNVT)

Incoming DID digit conversion on this route (IDC)

Multifrequency compelled or MFC signaling (MFC)

Process notification networked calls (PNNC)

To save changes made in this section, click **Submit** at the bottom of the **Route Property Configuration** Web page.

**Network Options**

Figure 169 "Network Options for routes" (page 248) provides an example of the input requested in the **Network Options** section for the route shown in Figure 166 "Route Property Configuration Web page" (page 246). The actual input that Element Manager requests varies depending on the type of route and the responses to earlier input requests.

**Figure 169**  
**Network Options for routes**

**- Network Options**

Input Description	Input Value
Electronic Switched Network pad control (ESN)	<input type="checkbox"/>
Signaling arrangement (SIGO)	<input type="text" value="Standard (STD)"/>
Route Class (RCLS)	<input type="text" value="Route Class marked as external (EXT)"/>
Off-Hook Queuing (OHQ)	<input type="checkbox"/>
Off-Hook Queue Threshold (OHQT)	<input type="text" value="0"/>
Call back queuing (CBQ)	<input type="checkbox"/>
Number of Digits (NDIG)	<input type="text" value="2"/>
Authcode (AUTH)	<input type="checkbox"/>

To save changes made in this section, click **Submit** at the bottom of the **Route Property Configuration** Web page.

## General Options

Figure 170 "General Options for routes" (page 249) provides an example of the input requested in the **General Options** section for the route shown in Figure 166 "Route Property Configuration Web page" (page 246). The actual input that Element Manager requests varies depending on the type of route and the responses to earlier input requests.

**Figure 170**  
**General Options for routes**

- General Options

M1 is the only controlling party on incoming calls (CPDC)

Dial tone on originating calls (DLTN)

Hold failure threshold (HOLD)

Trunk access restriction group (TARG)

Search method for outgoing trunk member (SRCH)  ▼

Alternate trunk route for outgoing trunks (STEP)  Range: 0 - 511

Actual outgoing toll digits to be ignored for code restriction (OABS)

Display IDC name (DNAM)

Enable equal access restrictions (EQAR)

ACD DNIS route (DNIS)

To save changes made in this section, click **Submit** at the bottom of the **Route Property Configuration Web page**.

## Advanced Configurations

Figure 171 "Advanced Configurations for routes" (page 250) provides an example of the input requested in the **Advanced Configurations** section for the route shown in Figure 166 "Route Property Configuration Web page" (page 246). The actual input that Element Manager requests varies depending on the type of route and the responses to earlier input requests.

**Figure 171**  
**Advanced Configurations for routes**

- Advanced Configurations

Malicious call trace alarm is allowed for external calls (ALRM)

Allow last re-directing number (ARDN) ARDN (NO)

ANI identifier number (ANTK)

AC15 timed reminder recall (ATRR)

Auto terminate (AUTO)

Collect call blocking allowed (CCBA)

Call forward restriction (CFWR)

Maximum number of CNI digits (CLEN) 1

Time (in seconds) that an extension is allowed to ring or be On-hold or Call Park before the trunk is disconnected (DCT)  Range: 0 - 511

North American distinctive ringing for incoming calls (DRNG)

Home local number (HLCL)

Home national number (HNTN)

In-band automatic number identification route (IANI)

Internal/external definition (IDEF) Use network info (NET)

Identify originating party (IDOP)

Insert (INST)

Manual outgoing trunk route (MANO)

Malicious Call Trace Delay Time in seconds (MCDT) 0

To save changes made in this section, click **Submit** at the bottom of the **Route Property Configuration** Web page.

### New Trunk Configuration

Click the **Add Trunk** button beside a Customer Row or a Trunk Row to open the **New Trunk Configuration** Web page for the selected customer, route, and trunk, as shown in [Figure 172 "New Trunk Configuration Web page" \(page 251\)](#).

**Figure 172**  
**New Trunk Configuration Web page**

Managing: **192.168.55.143** Username: admin2  
 Routes and Trunks » Routes and Trunks » Customer 0, Route 1, New Trunk Configuration

---

### Customer 0, Route 1, New Trunk Configuration

- Basic Configuration

Input Description	Input Value
Multiple trunk input number (MTINPUT)	<input type="text"/>
Trunk data block (TYPE)	<input type="text" value="ADM"/>
Terminal Number (TN)	<input type="text"/>
Designator field for trunk (DES)	<input type="text"/>
Customer number (CUST)	<input type="text" value="0"/>
Route number, Member number (RTMB)	<input type="text"/>
Card Density (CDEN)	<input type="text"/>
Trunk Group Access Restriction (TGAR)	<input type="text"/>
Channel ID for this trunk. (CHID)	<input type="text"/>
Increase or decrease the member numbers (INC)	<input type="text" value="Increase channel and member number (YES)"/>

+ Advanced Trunk Configurations

The **New Trunk Configuration** Web pages are divided into two categories:

1. Basic Configuration
2. Advanced Trunk Configurations

### Basic Configuration

In the **Basic Configuration** section of these Web pages (see ), users can perform the following tasks:

- Enter a **Designator field (DES)** for the trunk.
- Select an **Extended Trunk (XTRK)** card type from the drop-down list.
- Edit the route or member number in the **Route number, Member number (RTMB)** text box. The range is 0-4000.
- Use the **Level 3 Signaling (SIGL)** drop-down list to select a Level 3 signaling method.
- Use the **Start arrangement Incoming (STRI)** drop-down list to select a start arrangement for incoming calls.
- Use the **Start arrangement Outgoing (STRO)** drop-down list to select a start arrangement for outgoing calls.

- Use the **Increase or decrease the member numbers (INC)** drop-down list to select either increasing channel numbers and member numbers or increasing channel numbers and decreasing member numbers.
- Click the **Class of Service (CLS) Edit** button to view Class of Service information for the trunk. See [Figure 173 "Class of Service Configuration Web page"](#) (page 252).

**Figure 173**  
**Class of Service Configuration Web page**

**Class of Service Configuration**

- Class of Service

Input Description	Input Value
- ACD Priority (CLS)	<input type="text" value=""/>
- Analog Semi-Permanent Connections (CLS)	<input type="text" value=""/>
- ARF Supervised COT (CLS)	<input type="text" value=""/>
- Barring (CLS)	<input type="text" value=""/>
- Battery Supervised COT (CLS)	<input type="text" value=""/>
- Busy Tone Supervised COT (CLS)	<input type="text" value=""/>
- Calling Line Identification (CLS)	<input type="text" value=""/>
- Calling party (CLS)	<input type="text" value=""/>
- Central Office Ringback (CLS)	<input type="text" value=""/>
- Centrex Switchhook Flash (CLS)	<input type="text" value=""/>
- Dial Pulse (CLS)	<input type="text" value=""/>
- DTR PAD value (CLS)	<input type="text" value=""/>
- Echo Canceling (CLS)	<input type="text" value=""/>
- Hong Kong DTI (CLS)	<input type="text" value=""/>
- Loop Break Supervised COT (CLS)	<input type="text" value=""/>
- Make-break ratio for dial pulse (CLS)	<input type="text" value=""/>
- Manual Incoming (CLS)	<input type="text" value=""/>
- Media Security (CLS)	<input type="text" value=""/>
- Network Hook Flash Over M911P (CLS)	<input type="text" value=""/>

**Note:** The member used in this example is a TIE trunk. The inputs requested by Element Manager may vary depending on the responses to earlier input requests.

To save changes made in this section, click **Submit** at the bottom of the New **Member Configuration** Web page.

**Advanced Trunk Configurations**

[Figure 174 "Advanced Configurations for trunks"](#) (page 253) provides an example of the input requested in the **Advanced Trunk Configurations** section for the TIE Trunk shown in .

**Figure 174**  
**Advanced Configurations for trunks**

**- Advanced Trunk Configurations**

Music conference loop:  ( 0 - 159 )

Call modification features restriction:

Digit collection ready:

Multifrequency digit level: 0

Multifrequency PAD:

Night service group number: 0

Night service directory number:

Pulse code modulation law:

Pad category table number for digital trunks: 1

Private line directory number:

Signaling category table number: 1

Answer and disconnect supervision required:

Step-by-step CO trunk:

Trunk identifier:

**Note:** The member used in this example is a TIE trunk. The inputs requested by Element Manager may vary depending on the responses to earlier input requests.

To save changes made in this section, click **Submit** at the bottom of the Web page.

### Delete multiple trunk members

Click **Multi-Del** located beside a member row to open the **Delete multiple trunk members** Web page for the selected member, as shown in [Figure 175 "Delete multiple trunk members page" \(page 254\)](#). On this Web page, the information for the Parent Route is read-only.

**Figure 175**  
Delete multiple trunk members page

Managing: [192.167.102.3](#)  
Routes and Trunks » [Routes and Trunks](#) » Customer 0, Route 1, Delete multiple trunk members

---

**Customer 0, Route 1, Delete multiple trunk members**

**Parent Route Information**

Input Description	Input Value
Customer number (CUST_NUM)	0
Route number (ROUT_NUM)	1
Route description (ROUT_DES)	PIV_H323
Trunk type (TKTP)	IPTI
Total trunk members (TOTL_TN)	10

**Select TN and deleting number**

Selection Description	Selection Value
Set starting TN number to be deleted (OUT)	Trunk: 1; TN: 096 0 02 00
Set total trunk number to be deleted (up to 32)	1

To delete multiple trunk members using this Web page:

Step	Action
1	Use the <b>Set starting TN to be deleted</b> drop-down list to determine the start of the deletion list.
2	Use the <b>Set total trunk number to be deleted</b> drop-down list to indicate the total number of trunks to be deleted (up to 32).
3	Click <b>Delete</b> .

--End--

### D-channels

Click the **D-Channels** link on the **Routes and Trunks** branch of the Element Manager navigator to open the **D-Channels** Web page. This Web page allows users to configure or edit D-channel information, as shown in [Figure 176 "D-Channels Web page"](#) (page 255).

**Figure 176**  
**D-Channels Web page**

Managing: [192.167.102.3](#)  
Routes and Trunks » D-Channels

---

## D-Channels

**Maintenance**

- [D-Channel Diagnostics \(LD 96\)](#)
- [Network and Peripheral Equipment \(LD 32, Virtual D-Channels\)](#)
- [MSDL Diagnostics \(LD 96\)](#)
- [TMDI Diagnostics \(LD 96\)](#)
- [D-Channel Expansion Diagnostics \(LD 48\)](#)

**Configuration**

Choose a D-Channel Number:  and type:

- Channel: 10	Type: DCH	Card Type: DCIP	Description: PIV_VDCH	<input type="button" value="Edit"/>
---------------	-----------	-----------------	-----------------------	-------------------------------------

### Maintenance

This sections contains links to the following commands:

- [D-Channel Diagnostics \(LD 96\)](#)
- [Network and Peripheral Equipment \(LD 32, Virtual D-Channels\)](#)
- [MSDL Diagnostics \(LD 96\)](#)
- [TMDI Diagnostics \(LD 96\)](#)
- [D-Channel Expansion Diagnostics \(LD 48\)](#)

For more information about these commands, see [“System” \(page 35\)](#).

### Configuration

From the **D-Channels** Web page users can view basic information about existing D-channels.

This Web page also contains buttons that link to additional Web pages. Follow these links to do the following:

- add a new D-channel
- edit D-channel data

To add a new D-channel, select a number from the **Choose a D-channel Number** drop-down list, select a D-channel **type** from the type drop-down list, and click **to Add**. To edit the configuration information about an existing D-channel, click the **Edit** button located to the right of the Description field.

Click the **to Add** button, or any of the **Edit** buttons, to open the **D-Channels Property Configuration** Web page for that channel, as shown in [Figure 177 "D-Channels Property Configuration Web page"](#) (page 256)).

**Note:** H.323 and SIP can use the same D-channel.

**Figure 177**  
**D-Channels Property Configuration Web page**

Managing: [192.167.102.3](#)  
Routes and Trunks » [D-Channels](#) » D-Channels 1 Property Configuration

---

### D-Channels 1 Property Configuration

- Basic Configuration

Input Description	Input Value
Action Device And Number (ADAN) (TYPE)	DCH
D channel Card Type (CTYP)	<input type="button" value="v"/>
Group number (GRP)	<input type="button" value="v"/>
Device number (DNUM)	<input type="button" value="v"/>
Port number (PORT)	<input type="button" value="v"/>
Designator (DES)	<input type="text"/>
Recovery to Primary (RCVP)	<input type="checkbox"/>
User (USR)	<input type="button" value="v"/>
Interface type for D-channel (IFC)	Meridian DMS-100 (D100) <input type="button" value="v"/>
Country (CNTY)	ETS 300 =102 basic protocol (ETSI) <input type="button" value="v"/>
D-Channel PRI loop number (DCHL)	<input type="text"/>
Primary Rate Interface (PRI)	<input type="text"/> <input type="button" value="more PRI"/>
Secondary PRI2 loops (PRI2)	<input type="text"/>
Release ID of the switch at the far end (RLS)	25 <input type="button" value="v"/>
Central Office switch type (CO_TYPE)	100% compatible with Bellcore standard (STD) <input type="button" value="v"/>
Integrated Services Signaling Link Maximum (ISLM)	200 <span style="color: green;">Range: 1 - 4000</span>

In the **D-Channels Property Configuration** Web page, users can:

- Enter information about the **Basic Configuration** Web page.
  - The information entered in this section corresponds to ADAN and ADAN DCH (Action Device and Number, D-channel and back-up D-channels) data traditionally configured using LD 17 - Configuration Record 1. In addition to basic D-channel configuration, additional information can be entered for optional settings in the following two categories:
    - Basic D-channel options (BSCOPT)
    - Advanced D-channel options (ADVOPT)

These options are shown in [Figure 178 "Basic and Advanced D-Channel options"](#) (page 257).

**Figure 178**  
**Basic and Advanced D-Channel options**

The screenshot shows a configuration interface with the following sections and fields:

- Basic options (BSCOPT)**
  - Primary D-channel for a backup DCH (PDCH) [dropdown]
  - PINX customer number (PINX\_CUST) [dropdown]
  - Progress signal (PROG) [dropdown]
  - Calling Line Identification (CLID) [dropdown]
  - Output request Buffers (OTBF) 32 [dropdown]
  - D-channel transmission Rate (DRAT) 56 kb/s when LCMT is AMI (56K) [dropdown]
  - Channel Negotiation option (CNEG) No alternative acceptable, exclusive. (1) [dropdown]
  - Remote Capabilities (RCAP) [Edit button]
- + - Change protocol timer value (TIMR)**
  - B channel Service messaging. (BSRV) [checkbox]
- Advanced options (ADVOPT)**
  - Layer 3 call control message count per 5 second time interval (ISDN\_MCNT) 300 [text input] Range: 60 - 350
  - Number of Status Enquiry Messages sent within 128 ms (SEMT) 1 [dropdown]
  - Map channel number to timeslots on a PRI2 loop (OCHID) [checkbox checked]
- + H323 Overlap Signaling Settings (H323)**
  - Overlap Timer (OVLT) [dropdown]
  - Multilocation Business Group Allowed (MBGA) [checkbox]
  - Network Attendant Service Allowed (NASA) [checkbox]
- + - Link Access Protocol for D-channel (LAPD)**
- + Feature Packages**


- Configure information about the **Feature Packages** Web page.
  - Digital Private Networking Signaling System 1 (Package 123)
  - Virtual Network Services (Package 183)

To save changes made in this section, click **Submit** at the bottom of the **D-channels Property Configuration** Web page.

### Digital Trunk Interface

When the user clicks the **Digital Trunk Interface** link on the **Routes and Trunks** branch of the Element Manager navigator, the **Digital Trunk Interface** Web page appears, as shown in [Figure 179 "Digital Trunk Interface Web page"](#) (page 258). This Web page allows the user to configure or edit Digital Trunk Interface information.

**Figure 179**  
**Digital Trunk Interface Web page**



From this Web page, users can access additional Web pages to perform the following functions:

- configure Digital Trunk Interface Data Block (DDB) information
- configure System Timer (SYSTI) parameters for:
  - 2.0 Mb Primary Rate Interface (PRI2)
  - 2.0 Mb Digital Trunk Interface (DTI2)
- configure Loop Timer (LPTI) parameters for:
  - 2.0 Mb Primary Rate Interface (PRI2)
  - 2.0 Mb Digital Trunk Interface (DTI2)

- configure PAD Category (PAD) parameters for:
  - 1.5 Mb Primary Rate Interface (PRI)
  - 1.5 Mb Digital Trunk Interface (DTI)
  - 2.0 Mb Primary Rate Interface (PRI2)
  - 2.0 Mb Digital Trunk Interface (DTI2)
  - Basic Rate Line Interface (BRIL)
  - Basic Rate Trunk Interface (BRIT)
- configure ABCD Bit Signaling Category (ABCD) parameters for the 2.0 Mb Digital Trunk Interface (DTI2)

To configure or edit Digital Trunk Interface Data Block (DDB) information, click **Digital Trunk Interface Data Block (DDB)**. The **Threshold Set List** Web page appears. See [Figure 180 "Threshold Set List Web page"](#) (page 259).

**Figure 180**  
**Threshold Set List Web page**

Managing: [192.167.102.3](#)  
Routes and Trunks > [Digital Trunk Interface](#) > Threshold Set List

---

## Threshold Set List

+ **Clock Controller Basic Properties**

Please Choose the

---

- **Threshold Set Index -- 00**

Remote (yellow) Alarm clear threshold: 3  
 Bipolar violation Count threshold: 2  
 Loss of Frame Alignment Counter: 3  
 Bipolar Violation maintenance and out-of-service threshold: 3 2  
 Slip Rate Non-Tracking: 5 3

From this Web page, users can access additional Web pages to perform the following functions:

- edit Clock Controller Basic Properties
- add a Threshold Set Index
- edit an existing Threshold Set Block

Users can edit Clock Controller properties by clicking the **Edit** button next to the **Clock Controller Basic Properties** button. The **Clock Controller Basic Properties** Web page appears, as shown in [Figure 181 "Clock Controller Basic Properties Web page"](#) (page 260).

**Figure 181**  
**Clock Controller Basic Properties Web page**

Input Description	Input Value
Clock Controller Card Number (MGCLK):	<input type="text"/> (supi# sh# card#)
- Primary Reference (PREF):	<input type="text"/> (card#)
- Secondary Reference (SREF):	<input type="text"/> (card#)
Multi Purpose Serial Data Link Idle Code Selection (ICS):	<input type="text"/>

Submit Refresh Cancel

Users can then enter the required information in the text boxes.

To add or edit a Threshold Set Index, follow the steps in [Procedure 93 "Adding or editing a Threshold Set Index"](#) (page 260).

**Procedure 93**  
**Adding or editing a Threshold Set Index**

Step	Action
<i>To add a Threshold Set Index</i>	
1	Select a <b>Threshold Set Index</b> from the drop-down list.
2	Click to <b>Add</b> .

To edit the configuration information in an existing Threshold Set Block, click **Edit** located to the right of the index number.

--End--

When the **to Add** button or a Threshold Set Index Edit button is clicked on [Figure 180 "Threshold Set List Web page"](#) (page 259), the **Threshold Set Block** Web page for that index appears, as shown in [Figure 182 "Threshold Set Block Web page"](#) (page 261).

**Figure 182**  
**Threshold Set Block Web page**

Managing: [192.167.102.3](#)  
Routes and Trunks » [Digital Trunk Interface](#) » [Threshold Set List](#) » Threshold Set Block

---

### Threshold Set Block

Input Description	Input Value
Threshold set (TRSH):	<input style="width: 50px;" type="text" value="1"/>
Remote (yellow) Alarm clear threshold (RALM):	<input style="width: 50px;" type="text" value="3"/>
Bipolar violation Count threshold (BIPC):	<input style="width: 50px;" type="text" value="2"/>
Loss of Frame Alignment Counter (LFAC):	<input style="width: 50px;" type="text" value="3"/>
Bipolar Violation maintenance and out-of-service threshold (BIPV):	<input style="width: 100px;" type="text" value="3 2"/>
Slip Rate Tracking mode maintenance (SRTK):	<input style="width: 100px;" type="text" value="5 30"/>
Slip Rate Non-Tracking (SRNT):	<input style="width: 100px;" type="text" value="5 3"/>
Loss of Frame Alignment maintenance and out-of-service thresholds (LFAL):	<input style="width: 100px;" type="text" value="17 511"/>
Slip Rate Improvement Monitoring time in minutes (SRIM):	<input style="width: 50px;" type="text" value="2"/>
Slip Rate Maintenance Maximum (SRMM):	<input style="width: 50px;" type="text" value="2"/>

The information entered in this section corresponds to DDB (Digital Trunk Interface Data Block) information traditionally configured using LD 73 - Digital Trunk Interface.

To save changes made in this section, click **Submit** at the bottom of the **Threshold Set Block** Web page.



---

# Dialing and Numbering Plans

---

## Contents

This section contains information about the following topics:

["Introduction" \(page 263\)](#)

["Electronic Switched Network" \(page 263\)](#)

["Flexible Code Restriction" \(page 266\)](#)

["Incoming Digit Translation" \(page 269\)](#)

## Introduction

Element Manager enables users to configure the Dialing and Numbering Plans for the Call Server and the Network Routing Service (NRS) Manager. The information configured in the Dialing and Numbering Plans corresponds to the Command Line Interface (CLI) prompts and responses for Electronic Switched Network (ESN) data traditionally configured in LD 86, LD 87, and LD 90.

For more information about the overlays referred to in this chapter, see *Software Input Output Administration (NN43001-611)* and *Software Input Output Reference - Maintenance (NN43001-711)*.

## Electronic Switched Network

To configure or edit the Dialing and Numbering Plan for the Electronic Switched Network, click the **Electronic Switched Network** link in the **Dialing and Numbering Plans** branch of the Element Manager navigator. The **Electronic Switched Network (ESN)** Web page appears as shown in [Figure 183 "Electronic Switched Network \(ESN\) Web page" \(page 264\)](#). From this Web page users can configure the Dialing and Numbering Plan for each customer on the Electronic Switched Network.

Element Manager provides access to the following Dialing and Numbering Plan parameters:

- Network Control & Services
- Coordinated Dialing Plan (CDP)
- Numbering Plan (NET)

**Figure 183**  
**Electronic Switched Network (ESN) Web page**

Managing: [192.167.100.3](#)  
Dialing and Numbering Plans » Electronic Switched Network (ESN)

---

### Electronic Switched Network (ESN)

- Customer 00
  - Network Control & Services
    - Network Control Parameters (NCTL)
    - ESN Access Codes and Parameters (ESN)
    - Digit Manipulation Block (DGT)
    - Route List Block (RLB)
    - Incoming Trunk Group Exclusion (ITGE)
    - Network Attendant Services (NAS)
  - Coordinated Dialing Plan (CDP)
    - Local Steering Code (LSC)
    - Distant Steering Code (DSC)
    - Trunk Steering Code (TSC)
  - Numbering Plan (NET)
    - Access Code 1
      - Home Area Code (HNPA)
      - Home Location Code (HLOC)
      - Location Code (LOC)
      - Numbering Plan Area Code (NPA)
      - Exchange (Central Office) Code (NXX)
      - Special Number (SPN)
      - Network Speed Call Access Code (NSCL)
      - Free Calling Area Screening (FCAS)
      - Free Special Number Screening (FSNS)
    - Access Code 2
      - Home Area Code (HNPA)
      - Home Location Code (HLOC)
      - Location Code (LOC)
      - Numbering Plan Area Code (NPA)
      - Exchange (Central Office) Code (NXX)

### Network Control and Services

Under Network Control and Services, users can click the links to configure or modify the parameters associated with the following items:

- Network Control Parameters (NCTL)
- ESN Access Codes and Parameters (ESN)
- Digit Manipulation Block (DGT)
- Route List Block (RLB)
- Incoming Trunk Group Exclusion (ITGE)
- Network Attendant Services (NAS)

The Network Control Parameters (NCTL) that are configurable using Element Manager correspond to data traditionally configured in LD 87. The settings for the remaining five items under Network Control & Services correspond to CLI prompts and responses in LD 86.

To view the total free and used Location Codes (LOCs), click **Customer xx > Network Control & Services > ESN Access Codes and Basic Parameters**. The **ESN Access Codes and Basic Parameters** Web page appears as shown in [Figure 184 "ESN Access Codes and Basic Parameters Web page"](#) (page 265).

**Figure 184**  
**ESN Access Codes and Basic Parameters Web page**

Managing: [192.167.102.3](#)  
Dialing and Numbering Plans » [Electronic Switched Network \(ESN\)](#) » Customer 0 » Network Control & Services » ESN Access Codes and Basic Parameters

---

### ESN Access Codes and Basic Parameters

Input Description	Input Value
Maximum number of Digit Manipulation tables (MXDM):	100 (0 - 1000)
Maximum number of Route Lists (MXRL):	100 (0 - 1000)
Time of Day Schedules (TODS): (Items separated by a space)	0 00 00 23 59
Routing Controls (RTCL):	<input type="checkbox"/>
Check for Trunk Group Access Restrictions (TGAR):	<input type="checkbox"/>
NCOS Map (NMAP): (Items separated by a space)	00-0 01-0 02-0 03-0 04-0 05-0 06-0 07-0 08-0 09-0 10-0 11-0 12-0 13-0 14-0 15-0 16-0 17-0 18-0 19-0 20-0 21-0 22-0 23-0 24-0 25-0 26-0 27-0 28-0 29-0 30-0 31-0 32-0 33-0 34-0 35-0 36-0 37-0 38-0 39-0 40-0 41-0
Maximum number of Supplemental Digit restriction blocks (MXSD):	100 (0 - 1500)
Maximum number of Incoming Trunk Group exclusion tables (MXIX):	100 (0 - 255)
Maximum number of Free Calling area screening tables (MXFC):	100 (0 - 255)

This feature has its own packaging (LOCX). The package must be added under **Customers > Customer xx Property Configuration > Feature Packages**. This package can be activated only when the FNP package is enabled.

### Coordinated Dialing Plan

Under Coordinated Dialing Plan (CDP), users can click links to configure or modify parameters associated with the following codes:

- Local Steering Code (LSC)
- Distant Steering Code (DSC)
- Trunk Steering Code (TSC)

The Coordinated Dialing Plan parameters that are configurable using Element Manager correspond to data traditionally configured in LD 87.

### Numbering Plan

Under Numbering Plan (NET), users can click links to configure or modify parameters associated with the following codes:

- Home Area Code (HNPA)
- Home Location Code (HLOC)
- Location Code (LOC). Maximum number of LOCs is 16 000.
- Numbering Plan Area Code (NPA)
- Exchange (Central Office) Code (NXX)
- Special Number (SPN)
- Network Speed Call Access Code (NSCL)

These codes can also be configured using the prompts and responses in LD 90.


Numbering Plan (NET) is also used to configure the following two LD 87 features:

- Free Calling Area Screening (FCAS)
- Free Special Number Screening (FSNS)

### Flexible Code Restriction

To configure or edit Flexible Code Restriction information, click the **Flexible Code Restriction** link in the **Dialing and Numbering Plans** branch of the Element Manager navigator. The **Flexible Code Restriction** Web page appears, as shown in [Figure 185 "Flexible Code Restriction Web page" \(page 267\)](#).

**Figure 185**  
**Flexible Code Restriction Web page**



This Web page contains **Edit FCR** buttons that link to **Flexible Code Restriction Property** Web pages for each of the customers configured on the Call Server.

To view the list of Flexible Code Restriction Trees for a customer, click the **Edit FCR** button located beside the customer number. The **Flexible Code Restriction** Property Web page for the selected customer opens (see [Figure 186 "Flexible Code Restriction Property Web page" \(page 268\)](#)).

**Figure 186**  
**Flexible Code Restriction Property Web page**

Managing: **192.167.100.3**  
Dialing and Numbering Plans » Flexible Code Restriction » Customer 00 Flexible Code Restriction Property

---

### Customer 00 Flexible Code Restriction Property

- Code Restriction Tree Number: 0	Edit CRNO
- Code Restriction Tree Number: 1	New CRNO
- Code Restriction Tree Number: 2	New CRNO
- Code Restriction Tree Number: 3	New CRNO
- Code Restriction Tree Number: 4	New CRNO
- Code Restriction Tree Number: 5	New CRNO
- Code Restriction Tree Number: 6	New CRNO
- Code Restriction Tree Number: 7	New CRNO
- Code Restriction Tree Number: 8	New CRNO
- Code Restriction Tree Number: 9	New CRNO
- Code Restriction Tree Number: 10	New CRNO
Code Restriction Tree Number: 11	New CRNO
Code Restriction Tree Number: 12	New CRNO
Code Restriction Tree Number: 13	New CRNO
Code Restriction Tree Number: 14	New CRNO
- Code Restriction Tree Number: 15	New CRNO

The **Flexible Code Restriction Property** Web page contains buttons that link to Code Restriction Tree Configuration Web pages for each Code Restriction Tree Number (CRNO). If there is an existing configuration for the CRNO, the button is labeled **Edit CRNO**. If a configuration has not been defined for the CRNO, the button is labeled **New CRNO**. Click the **Edit CRNO/New CRNO** button to open the **Code Restriction Tree Configuration** Web page for the corresponding CRNO, as shown in [Figure 187 "Code Restriction Tree Configuration Web page" \(page 269\)](#).

**Figure 187**  
**Code Restriction Tree Configuration Web page**

Managing: [192.167.100.3](#)  
 Dialing and Numbering Plans » Flexible Code Restriction » Customer 00 Flexible Code Restriction Property » Code Restriction Tree 0 Configuration

---

### Code Restriction Tree 0 Configuration

**- Code Restriction Tree Number Configuration**

Input Description	Input Value
Code Restriction Tree Number (CRNO)	<input type="text" value="0"/>
Initial - Allow or deny all codes. (INIT)	<input type="text" value="ALLOW"/>
Digit sequence to be denied. (DENY)	<input type="text" value="1"/>
Create new DENY <input type="text" value="1"/> Starting from <input type="text"/>	<input type="button" value="Add New"/>
Digit sequence to be allowed. (ALLOW)	
Create new ALLOW <input type="text" value="1"/> Starting from <input type="text"/>	<input type="button" value="Add New"/>
Digit sequence to be bypassed. (BYP)	
Create new BYPS <input type="text" value="1"/> Starting from <input type="text"/>	<input type="button" value="Add New"/>

By entering values in the appropriate text boxes, users can:

- add or edit digit sequences to be enabled
- add or edit digit sequences to be denied


The information entered in this section corresponds to data traditionally configured using LD 49 - Flexible Code Restriction and Incoming Digit Conversion.

To save changes made in the configuration for this Code Restriction Tree, click **Submit** at the bottom of the Web page.

## Incoming Digit Translation

To configure or edit Incoming Digit Translation information, click the **Incoming Digit Translation** link in the **Dialing and Numbering Plans** branch of the Element Manager navigator. The **Incoming Digit Translation Web page** appears, as shown in [Figure 188 "Incoming Digit Translation Web page"](#) (page 270).

**Figure 188**  
**Incoming Digit Translation Web page**



This Web page contains **Edit IDC** buttons that link to **Incoming Digit Conversion Property** Web pages for each of the customers configured on the Call Server.

To view the list of Incoming Digit Conversion Trees for a customer, click the **Edit IDC** button located beside the customer number. The **Incoming Digit Conversion Property** Web page for the selected customer appears. See [Figure 189 "Incoming Digit Conversion Property Web page" \(page 271\)](#).

**Figure 189**  
**Incoming Digit Conversion Property Web page**

Managing: [192.167.100.3](#)  
Dialing and Numbering Plans » Incoming Digit Conversion » Customer 00 Incoming Digit Conversion Property


---

### Customer 00 Incoming Digit Conversion Property

- Digit Conversion Tree Number: 0	Edit DCNO
- Digit Conversion Tree Number: 1	New DCNO
- Digit Conversion Tree Number: 2	New DCNO
- Digit Conversion Tree Number: 3	New DCNO
- Digit Conversion Tree Number: 4	New DCNO
- Digit Conversion Tree Number: 5	New DCNO
- Digit Conversion Tree Number: 6	New DCNO
- Digit Conversion Tree Number: 7	New DCNO
- Digit Conversion Tree Number: 8	New DCNO
- Digit Conversion Tree Number: 9	New DCNO
- Digit Conversion Tree Number: 10	New DCNO
- Digit Conversion Tree Number: 11	New DCNO
- Digit Conversion Tree Number: 12	New DCNO
- Digit Conversion Tree Number: 13	New DCNO
- Digit Conversion Tree Number: 14	New DCNO
- Digit Conversion Tree Number: 15	New DCNO
- Digit Conversion Tree Number: 16	New DCNO

The **Incoming Digit Conversion Property** Web page contains buttons that link to **Digit Conversion Tree Configuration** Web pages for each Digit Conversion Tree Number (DCNO). If there is an existing configuration for the DCNO, the button is labeled **Edit DCNO**. If a configuration has not been defined for the DCNO, the button is labeled **New DCNO**. Click the **Edit DCNO/New DCNO** button to open the **Digit Conversion Tree Configuration** Web page for the corresponding DCNO. From this Web page, users can configure Incoming Digit Conversion data.

**Figure 190**  
**Digit Conversion Tree Configuration Web page**



The information entered in this section corresponds to data traditionally configured using LD 49 - Flexible Code Restriction and Incoming Digit Conversion.

---

# Phones

---

## Contents

This section contains the following topics:

- “Introduction” (page 274)
- “Database Update” (page 276)
- “Station Fast Sync feature” (page 277)
- “Templates” (page 278)
- “Search Phones” (page 286)
- “Program Phone Keys” (page 289)
- “Edit Phones” (page 292)
- “Employee reference field support when exporting and import phone database” (page 293)
- “Export and Import of employee reference field” (page 293)
- “Move Phones” (page 298)
- “Retrieve Phones” (page 298)
- “Delete Phones” (page 300)
- “Swap Phones” (page 300)
- “Courtesy Change” (page 301)
- “Reports” (page 301)
- “IP Attendant” (page 302)


[“Migration” \(page 307\)](#)

## Introduction

EM Phone Provisioning functionality provides an interface to provision phones on CS 1000 systems.

You access Phone Provisioning through the Phones branch of the Element Manager navigator as shown in the following figure.

**Figure 191**  
**Phone Provisioning navigation**



Use Element Manager to configure phones for the Call Server. The configuration information described in this chapter corresponds to the Command Line Interface (CLI) prompts and responses for Telephone Administration traditionally configured in LD 10 and LD 11.

Additional information is retrieved from the Call Server for validation purposes corresponds to Print Routines traditionally performed in LD 20, LD 21, and LD 22.

For more information about the overlays described in this chapter, see *Software Input Output Administration (NN43001-611)* and *Software Input Output Reference - Maintenance (NN43001-711)*.

## Limitations of deploying multiple Element Managers to manage a single Call Server

You can deploy more than one Element Manager to manage a single Call Server using Deployment Manager, but the EM Phone provisioning application (**Phones**) does not support this. The issues with duplicate Element Managers are as follows:

- Changes made in **Phones** in one Element Manager are not synchronized with other Element Managers. You should perform a “Retrieve and Reconcile All” operation on other Element Managers to synchronize with Call Server. However, the non PBX fields (Subscriber and Template links) of a telephone are not updated even with this retrieval.
- The phone updates made directly through CLI might not be reflected in any Element Manager
- Subscriber Manager considers these duplicate Element Manager applications as different Service Providers even though they are pointing to the same Call Server. As a result, in some work flows you can have duplicate telephony accounts for the same telephone.

The EM Phone provisioning application keeps invalid data stated in the above. Any operations starting with this invalid data would lead to more inconsistencies.

## Feature Operation during Upgrade

When Element Manager is upgraded to CS 1000 Release 6.0 the phone data is not automatically upgraded. Complete the steps below to perform the upgrade.

Perform the following operations to upgrade from CS 1000 Release 5.5 to CS 1000 Release 6.0 network for a system without Subscriber Manager.

### Procedure 94 Upgrading to CS 1000 Release 6.0 without Subscriber Manager

Step	Action
1	Upgrade to CS 1000 Release 6.0.

- 2 Launch Element Manager.
- 3 Follow the step in procedure [Procedure 108 "Retrieve Phones" \(page 299\)](#) to populate the phone database.

---

--End--

---

Perform the following operations to upgrade from CS 1000 Release 5.5 to CS 1000 Release 6.0 network for a system with Subscriber Manager.

**Procedure 95**  
**Upgrading to CS 1000 Release 6.0 with Subscriber Manager**

Step	Action
1	Upgrade to CS 1000 Release 6.0.
2	Launch Element Manager.
3	Follow the step in procedure <a href="#">Procedure 108 "Retrieve Phones" (page 299)</a> to populate the phone database.
4	Run Account synchronization from Subscriber Manager. Accounts created in Release 5.5 are automatically removed from Subscriber Manager.
5	Run the Migration utility to re-create accounts based on CPND names (See, <a href="#">"Migration" (page 307)</a> ).

---

--End--

---

**Note:** The phone templates and the link from phone to templates created in Release 5.5 are lost during this upgrade. This limitation is corrected from Release 6.0 onwards.

You can follow the manual work around steps to bring back template information and link them to the corresponding phones.

Create templates from existing phones. (See, ["Create a Template from an existing phone" \(page 280\)](#).) This allows you to create templates quickly rather than creating them from scratch.

Use the Bulk Phone Edit procedure to link the selected phones with the template. (See, [Update phones using the phone Templates.](#))

## Database Update

When you start Phones for the first time, the application automatically updates the database in the background. You must perform the update before you manage telephones to retrieve configuration changes in packages, customer data blocks, and CPND customer blocks. The

following message appears: "Please wait for requested page to load while system properties are being updated.". You can configure telephones when the update finishes.

To manually update the database, click on the Properties link of the Phones branch of the Element Manager navigator and click Update in the Database Update section of the **Properties** Web page.

The **Database Update** Web page appears, as shown in [Figure 192 "Database Update Web page" \(page 277\)](#)

**Figure 192**  
**Database Update Web page**

Managing: [EM on pecm1100\(172.16.100.2\)](#)  
Phones > Properties

### Properties

#### Database Update

Clicking the update button will initiate retrieval of system, customers and CPND customer properties from the Call Server.

Last Updated: 2009-01-28 11:05:45.0

Update

#### Courtesy Change

When courtesy change is enabled, changes are transmitted to the call server only if the phone is not busy.

Enable  
 Disable

Save

The Last Updated field displays the timestamp of the last update performed.

## Station Fast Sync feature

The Station Fast Sync feature keeps the Phones Database synchronized with the PBX.

When a phone is modified on call server using CLI, then SNMP trap is sent from the Call Server to Element Manager with error code MGMT0001. When Element Manager receives the notification, it retrieves changes or deletes the TN/DN as required. This functionality is enabled by configuring the Element Manager IP address as an SNMP trap destination in LD 117. The EM IP address is configured automatically when EM Phones is launched for the first time. However, if changes from the CLI are not being reflected in EM Phones, it is recommended to verify that the management trap destination is correct using LD 117 See *Communication Server 1000 Fault Management - SNMP (NN43001-719)*.

A log entry is created for each Fast Sync notification received.

### ATTENTION

A manual Retrieve and Reconcile All must be performed periodically to ensure data consistency with the Call Server. The automatic fast synchronization update relies on SNMP traps and overlay access to maintain the data. Blocked or dropped SNMP traps and overlay conflicts can result in a data mismatch between the Call Server and EM.

## Templates

Use Element Manager to access Templates that contain attributes common to a CS1000 phone type. After you create a template, use it to apply common attributes to a group of telephones, without having to repetitively define the same value for each telephone. In general, using a template is a more efficient method of adding large number of telephones than individually maintaining each telephone.

The administration pages for Templates are organized as a link named Templates inside the Phones section of EM navigator.

Click the Templates link to open the Templates Web page as shown in [Figure 193 "Templates Web page" \(page 278\)](#). The Templates Web page lists all available templates by name, the telephone type to which they apply, and the time and date of the last update. The action bar has buttons to add, export, import, and delete templates.

### ATTENTION

Due to performance considerations, the recommended maximum number of templates supported by the system is 1000.

**Figure 193**  
**Templates Web page**

Managing: EM on pecm1100(172.16.100.2)  
Phones  Templates

### Templates

Add... Export Import Delete Refresh

<input type="checkbox"/>	Template Name	Phone Type	Last Updated
<input checked="" type="checkbox"/>	2500 Digitone Standard	2500	2009-03-82 13:34:22
<input type="checkbox"/>	M2006	M2006	2009-03-82 14:02:57

## Create a Template

To add a template, click **Add** on the Templates Web page. The Template Details Web page appears as shown in [Figure 194 "Template Details Web page"](#) (page 279). Select the telephone type to use for the Template.

**Figure 194**  
**Template Details Web page**

The screenshot shows the 'Template Details' web page. At the top, it says 'Managing: CS1000E\_Node5 (192.167.100.3)' and 'Phones > Templates > Template Details'. Below this is a navigation bar with 'General Properties', 'Features', and 'Keys'. The 'General Properties' section contains several input fields: 'Template name:' (with an asterisk), 'Telephone type:' (a dropdown menu showing '500 - Analog Sta'), 'Designation:' (with an asterisk), 'Directory number:' (with an asterisk), and 'CLID entry:' (with an asterisk). The 'Features' section is a table with columns 'Feature', 'Description', and 'Value'. It lists features like AACD, ABDA, ADAY, AGRA, AGTA, and AHOL with their respective values. The 'Single Line Features' section is another table with columns 'Feature' and 'Value', listing FTR CFW, FTR SCU, and FTR SCC, all with 'NUL - Unassigned' as the value. At the bottom right, there are 'Save' and 'Cancel' buttons.

The fields marked with an asterisk (\*) are mandatory.

The Template name identifies the template. If a template exists with the same name as specified, then an error message, "Template name already in use. Please specify another Template name." appears when you try to save the new template.

The templates are not system-specific; therefore, all the phone features and keys applicable to the selected phone type are available for configuration in the Template Details Web page. The available features and key features change based on the selected phone type.

#### **ATTENTION**

Enter a partial DN as part of the key configuration parameter to enable a phone configured with this template to pick up a DN according to the partial DN.

Configure all required parameters, and click **Save** to save the template and return to the Templates Web page. The view refreshes to display the newly-added template.

#### **ATTENTION**

The status of the Validation appears, listing validation errors that occur. If validation errors occur, repeat the relevant sections of this procedure to correct the errors.

After you create a template, you can use it to add telephones to the system. When you use a template to add a telephone, only those keys and features that are valid for the system in context appear in the Phone Details Web page.

### **Create a Template from an existing phone**


You can define a new template from an existing telephone configuration.

Select a telephone to convert to a phone template and view the new template in the Template Details Web page.

#### **Procedure 96** **Save a phone as template**


<b>Step</b>	<b>Action</b>
1	To open the Search for Phones Web page, click the <b>Phones</b> branch of the Element Manager navigator.
2	Select the telephone to save as a template from the Search Result section of the <b>Search for Phones</b> Web page.  <i>Note:</i> You can create a template only from one telephone. An error message appears if you select multiple phones for creating a template.
3	Select <b>Save As Template</b> from the <b>More Actions</b> list as shown in <a href="#">Figure 195 "Search For Phones Web page with option to save a phone as template" (page 281)</a> .

**Figure 195**  
**Search For Phones Web page with option to save a phone as template**



The **Template Details** Web page appears as shown in [Figure 196](#) "Template Details Web page with the select phone converted into a template" (page 281) .

**Figure 196**  
**Template Details Web page with the select phone converted into a template**



- 4 Enter a template name in the **Template name field**.

**Note:** The Template name must be unique. If you enter an existing template name that an error message appears.

- 5 Click **Save** to save the template.

**Search for Phones** Web page appears. The information of selected phone is converted into a telephone template.

---

--End--

---

### View a Template

To view template details, click the template name link in the **Templates** Web page. The **Template Details** Web page appears displaying the selected template.

### Update a Template

To update a template, click the template name link in the **Templates** Web page. The **Template Details** Web page appears displaying the selected template.

Make the required modifications to the template and save the changes.

**Note:** When you update a Template, the telephones associated with this Template are not automatically updated. See, Update phones using the phone Templates.

### Delete a Template

Select any template from the **Templates** Web page and click Delete to remove the template.

You must confirm the deletion. When you click OK, the selected template is deleted immediately. If you click Cancel, the deletion is cancelled and the **Templates** Web page appears.

**Note:** When you delete a template, its association with telephones is removed, but the telephones are not deleted.

### Export and Import Templates


You can export and import templates in CSV format.

Template data configured at one EM is not available for every EM in the UCM Common Services framework. You must perform a manual export and import procedure to share this data between various Element Managers.

You import and export Templates from the **Templates** Web page as shown in [Figure 197 "Import and Export Templates" \(page 283\)](#).

**Note:** No data validation occurs when you import a template. You must ensure that proper values are present under all fields in the CSV file that you import.

**Figure 197**  
**Import and Export Templates**



You can use a comma-delimited ASCII text file, with a file extension of CSV as the data file. The first line or record of the file must contain the names of the fields that you import. You must enclose each field in the record in quotation marks. The first field in the data record is template name and is used as the key during the import. Existing templates are updated if a template with the same name exists and a new template is created, if the template name does not exist.

The following are the mandatory fields required for a template import:

- TEMPLATE\_NAME
- PHONE
- DES

Depending on the imported telephone type, other mandatory fields are required. For example in case of an IP Phone, **Zone** is a mandatory field. If any of the mandatory fields are missing in a data record, the import process ignores that data record. The other data requirements for import of templates as well as the list of field names to be used for import of templates are similar to Import Telephones. See, Import Telephones.

**Note:** You cannot import CPND because templates do not support them.

The following is a sample of data in CSV format.

```
"TEMPLATE_NAME","PHONE","DES","ZONE","KEY0",
"1110 for HR dept","1110","Test","000","SCR 2 D"
```

**Note 1:** In the above sample data, Key0 is configured with partial DN.

**Note 2:** The UI reports errors encountered during the import operation. You can modify the CSV file and try the import again.


**Note 3:** The template import is shorter than the telephone import operation so no log file is written.

[Procedure 97 "Export Templates" \(page 284\)](#) describes the step you complete to export one or more templates.

#### Procedure 97 Export Templates


Step	Action
1	Click the <b>Templates</b> link on the EM navigator. The <b>Templates</b> Web page appears.
2	Select the list of templates to export.
3	Click <b>Export</b> .
4	The <b>Bulk Export for Templates</b> Web page appears as shown in <a href="#">Figure 198 "Bulk Export for Templates Web page" (page 284)</a> .

**Figure 198**  
**Bulk Export for Templates Web page**



- 5 Click the **Download Exported Templates** link to download and save the exported data to your computer as shown in [Figure 199 "Download Exported Template" \(page 285\)](#).

**Figure 199**  
**Download Exported Template**



--End--

Procedure 98 "Import Templates" (page 285) describes the steps to import one or more templates.

**Procedure 98**  
**Import Templates**

Step	Action
1	Click the <b>Templates</b> link on the EM navigator. The <b>Templates</b> Web page appears.
2	Click <b>Import</b> . The <b>Import Templates</b> Web page appears as shown in <a href="#">Figure 200 "Import Templates Web page" (page 286)</a> .

**Figure 200**  
**Import Templates Web page**

Managing: [EM on pecm1100\(172.16.100.2\)](#)  
[Phones](#) > [Templates](#) > [Import Templates](#)

### Import Templates

File name:

Import option:  Overwrite existing template  
An existing template will be overwritten if a template with the same name is imported.

### Import Templates Results

- 3 Specify the source file name by performing one of the following steps:
  - Type the path and file name of the source file in the CSV file name box.
  - Click **Browse** to locate and select the file.
- 4 Click **Import** to perform the Import operation.

---

--End--

---

## Search Phones

Access the Phones functions in Element Manager from the **Search for Phones** Web page. Search for phones based on the following criteria:

- Prime DN
- Phone Type
- Terminal Number
- Designation
- Customer

- Template
- UXID

For example, to search for a telephone type, select Phone Type as the criteria and a telephone type from the Value list. [Procedure 99 "Search for phones" \(page 287\)](#) describes searching for telephones using template as the criteria.

### Procedure 99 Search for phones

Step	Action
1	Click the <b>Phones</b> branch of the Element Manager navigator to open <b>Search for Phones Web</b> page, as shown in <a href="#">Figure 201 "Search for Phones Web page" (page 287)</a> .

**Figure 201**  
Search for Phones Web page



- 2 Select **Template** as the criteria from the **Criteria** list.

**Note:** If you select no template as the criteria then the search returns all phones not associated to a template.

- 3 Enter a **Value** for the template to search for.
- 4 Click **Search**. The **Search for Phones** Web page displays the telephones that match the specified Template as shown in [Figure 202 "Search for Phones Web page" \(page 288\)](#).

**Figure 202**  
**Search for Phones Web page**

Search for Phones

Advanced | Hide

Criteria: Template Value: ABDA

Results per page 20 Search Reset

Phones Found ( 28 )

Add... Import... Retrieve... Delete <more actions> Refresh

	Customer	TN	Prime DN	Destination	Phone Type	Template,*	UUID
1	<input type="checkbox"/>	0	000.1.08.00	4502	A1	M2008	ABDA
2	<input type="checkbox"/>	0	000.1.08.01	4504	A2	M2008	ABDA
3	<input type="checkbox"/>	0	000.1.08.02	4506	A3	M2008	ABDA
4	<input type="checkbox"/>	0	100.0.02.04	4753	DL	2050PC	ABDA
5	<input type="checkbox"/>	0	100.0.02.05	4754	DL	2050PC	ABDA
6	<input type="checkbox"/>	0	100.0.02.06	7000	IP1230	1230	ABDA
7	<input type="checkbox"/>	0	100.0.02.07	1002	ABDA	2004P1	ABDA
8	<input type="checkbox"/>	0	100.0.02.08	1003	ABDA	2004P1	ABDA
9	<input type="checkbox"/>	0	100.0.02.09	1004	ABDA	2004P2	ABDA

Page 1 1 - 20 of 28 Page 1 of 2

--End--

To search using additional criteria, click the Advanced link in the top right corner. The **Advanced Search for Phones** Web page appears, as shown in [Figure 203 "Advanced Search for Phones Web page" \(page 289\)](#).

Enter the criteria for the advanced search and click Search.

**Figure 203**  
**Advanced Search for Phones Web page**

Managing: CS1000E\_Node5 (192.167.100.3)  
 Phones > Advanced Search for Phones

**Advanced Search for Phones** Basic | Hide

Logic	(	Field	Comparison	Value	)
1	(	ABDA-CDR on Abandoned Calls	=	Allowed	)
2	OR				
3	AND				
4	AND				
5	AND				

Add Criteria

Results per page: 20 Search Reset

Phones Found ( 1 )

Add Import... Retrieve... Delete <more actions> Refresh

	Customer	TN+	Prime CDR	Occupation	Phone Type	Template	UUID
1	0	100.0.02.20	4000	2004	2004P2		


**Note:** If you select "LIKE" or "NOT LIKE" operator under the **Logic** column and enter a value (Eg: ABC) without the % wild card, then % is appended for this value during search (Eg: %ABC%). This option behaves like "contains" operator.

## Program Phone Keys

You can program telephone keys by using a graphical image of the telephone.

You can program telephone keys from the **Phone Details** Web page by using the graphical image of the telephone, which appears when you click on the telephone image at the top left of the page as shown in the figure below.

**Figure 204**  
Phone graphical interface



**Procedure 100**  
Programing phone keys using phone graphical interface

Step	Action
1	From the Search Result section of the <b>Search for Phones</b> Web page, click the telephone to be updated. The <b>Phone Details</b> Web page appears.
2	Click on the telephone image at the top left of the page. The graphical interface for the select telephone appears.
3	Click the key button of the telephone you want to program. The select box for the selected key of the Keys section of the <b>Phone Details</b> Web page appears highlighted.
4	Change the key configuration as required.
5	Click <b>Finish</b> to add the telephone. The window closes and the <b>Search for Phones</b> Web page appears.

--End--

The Phone Graphical Interface window has help, minimize, maximize, and the close buttons on the title bar. To open the corresponding help page for the telephone displayed, click the question mark.

Use the minimize and maximize buttons to hide and display the graphical image window. Hover the mouse over the key buttons on the image to display a tool tip with the key number and the current configured value. See [Figure 205 "Phone Graphical Interface navigation"](#) (page 291).

**Figure 205**  
**Phone Graphical Interface navigation**



When minimized, the Phone Graphical interface title bar remains visible. You can move the title bar so it does not obscure your view of the **Phone Details** Web page. However, you cannot drag and place the title bar on top of the navigation pane of the browser.

You can configure telephones with a key-based add-on module. Use the navigation button at the bottom to navigate to the extended keys for the telephone.

## Edit Phones

Use the Edit feature to edit a single telephone or multiple telephones.

**Note:** You can update only one field at a time. Old Value and New Value fields are either boxes or lists. When you select a field to update, additional old and new values appears that correspond to the Key field parameters.

### Edit single or multiple phones

Click the Phones branch of the Element Manager navigator to open the **Search for Phones** Web page.

To edit a single telephone or multiple telephones, perform the following procedure.

**Note:** UXTY cannot be changed using Bulk Phone Edit for UEXT types. Bulk Phone Edit of UEXT types from one UXTY to another UXTY is not supported.

### Phone properties that can change without breaking the Template association

Certain properties differ for various telephones; therefore, changing these properties does not break the telephone-to-template association. The following is a list of properties:

- Designator (DES): This property is part of the General Properties section of the phone details page.
- Station Control Password (SCPW): This property is part of the Features section of the phone details page.
- Directory number parameter of any key feature.

In addition, certain properties are not part of the template, and can be changed in the phone.

- Terminal Number (TN): This property is part of the General Properties section of the phone details page
- Call Party Name Display (CPND): This property is part of the Keys section of the phone details page.
- Voice Mail Box (VMB): This property is part of the Keys section of the phone details page.

## Employee reference field support when exporting and import phone database

Including this attribute in the export and import tools enables you to retain important data that is not persisted on the call server such as the employee reference and template ID. You can export and the import employee reference fields along with other supported telephone fields. The employee reference field stores the ID of the subscriber who owns the telephone. This field is the link between a telephone in EM Phone Provisioning and a subscriber in Subscriber Manager.

When you need to retain this offline data, perform [Procedure 101 "Retaining offline data" \(page 293\)](#).

### Procedure 101 Retaining offline data

Step	Action
1	Export the Phones database as a CSV file with the mandatory fields (TN, CUSTOMER, PHONE, DES), Template ID, and Employee Reference field.
2	Perform the Retrieve and Reconcile procedure to populate the phone database.
3	Import phones from the CSV file generated in step 1 to re-establish the link from telephone to template and telephone to subscriber.
--End--	

## Export and Import of employee reference field

Certain limitations apply while importing the EMPLOYEEREFERENCE field. In the import CSV file, if you update the EMPLOYEEREFERENCE field of an existing telephone, the following work flow occurs:

- EM Phone Provisioning updates the employee reference field in the telephone database.
- An update account notification is sent to Subscriber Manager. Because the notification is not an update to an existing account, Subscriber Manager ignores this notification.
- Run the Account Synchronization operation to synchronize the account differences between EM phone provisioning and Subscriber Manager. Account synchronization resynchronize the accounts as follows:

- Account Synchronization finds that the older account exists in Subscriber Manager but not in EM phone provisioning. This account is automatically removed from Subscriber Manager.
- Account Synchronization identifies a newer account in EM phone provisioning but not in Subscriber Manager, but the account has a subscriber ID in the directory. The newer account is automatically created in Subscriber Manager.

**Procedure 102**  
**Generating a report and exporting phones with employee reference in the selected report field**

Step	Action
1	Select <b>Report</b> from the <b>Phones</b> branch of the EM navigator. The <b>Edit a Report</b> Web page appears.
2	In the Field Selection section, select the fields to include in the report. Include EMPLOYEEREFERENCE field as well.
3	In the Custom Criteria section, select the criteria to determine which telephones are included in the report.
4	Select <b>CSV</b> as the report format from the Report Format list.
5	Click <b>Generate Report</b> . The <b>Download Generated Report</b> Web page appears.
6	Download the report. <ul style="list-style-type: none"> <li>• EMPLOYEEREFERENCE field is included in the generated report.</li> <li>• All telephones linked to a subscriber have a value for the EMPLOYEEREFERENCE field.</li> <li>• All telephones not linked to a subscriber do not have a value for the EMPLOYEEREFERENCE field.</li> </ul>
--End--	

**Procedure 103**  
**Generating a report and exporting phones with employee reference field as the criteria.**

Step	Action
1	Select <b>Report</b> from the <b>Phones</b> branch of the EM navigator. The <b>Edit a Report</b> Web page appears.
2	Select the fields to include in the report.

- 3 In the Custom Criteria section, select the EMPLOYEEREFERENCE field.
  - The corresponding Value field changes to a text box.
  - The corresponding Comparison list contains only the equal to (=) operator.
- 4 Enter a value in the **Value** field.
- 5 Select **CSV** as the report format from the Report Format list.
- 6 Click **Generate Report** .  
The **Download Generated Report** Web page appears.
- 7 Download the report.
  - EMPLOYEEREFERENCE field is in the generated report.
  - All telephones linked to a subscriber have a value for the EMPLOYEEREFERENCE field.

---

--End--

---

**Procedure 104**  
**Importing a new phone with employee reference field**

Step	Action
1	Modify the generated CSV, and add a new telephone with a valid employee reference field.
2	Click <b>Import</b> on the <b>Search for Phones</b> Web page. The <b>Import Phones</b> Web page appears.
3	Specify the name of the source file by performing one of the following steps: <ul style="list-style-type: none"> <li>• Type the path and name of the file in the import source file text box</li> <li>• Click <b>Browse</b> to locate and select the file.</li> </ul>
4	Click <b>OK</b> to import the file. The <b>Import Status</b> Web page appears indicating the success or failure of the import.
5	Click <b>Common Manager</b> to go to UCM home page.
6	Click the <b>Subscribers</b> link in UCM. The <b>Search for Subscribers</b> Web page appears.

- 7 Enter the subscriber's last name in the **Name** field of the search criteria, and click **Search**. Use the name of the subscriber whose ID you used in step 1.

The **Search for Subscriber** Web page appears with search results that match the search criteria.

- 8 Click the name of the subscriber.

The **Subscriber Details** Web page appears with a new account added to the account list.

---

--End--

---

**Procedure 105**  
**Importing an existing phone with no update to employee reference field**

Step	Action
1	Modify the generated CSV to update an existing telephone. Update the DN of Key 0 so that the change is visible in Subscriber Manager.
2	Click <b>Import</b> on the <b>Search for Phones</b> Web page. The <b>Import Phones</b> Web page appears.
3	Specify the name of the source file by performing one of the following steps: <ul style="list-style-type: none"> <li>• Type the path and name of the file in the import source file text box</li> <li>• Click <b>Browse</b> to locate and select the file.</li> </ul>
4	Click <b>OK</b> to import the file. The <b>Import Status</b> Web page appears indicating the success or failure of the import operation.
5	Click <b>Common Manager</b> to go to UCM home page.
6	Click the <b>Subscribers</b> link in UCM. The <b>Search for Subscribers</b> Web page appears.
7	Enter the subscriber's last name in the <b>Name</b> field of the search criteria and click <b>Search</b> . Use the subscriber name that you used in step 1. The <b>Search for Subscriber</b> Web page appears with search results that match the search criteria.
8	Click the name of the subscriber.

The **Subscriber Details** Web page appears with the DN changes made to the account in the account list.

---

--End--

---

**Procedure 106**  
**Importing an existing phone with updated employee reference field**

Step	Action
1	Modify the generated CSV to update an existing telephone. Update the employee reference field to another valid subscriber.
2	Click <b>Import</b> on the <b>Search for Phones</b> Web page. The <b>Import Phones</b> Web page appears.
3	Specify the name of the source file by performing one of the following steps: <ul style="list-style-type: none"><li>• Type the path and name of the file in the import source file text box</li><li>• Click <b>Browse</b> to locate and select the file.</li></ul>
4	Click <b>OK</b> to import the file. The <b>Import Status</b> Web page appears indicating the success or failure of the import.
5	Click <b>Common Manager</b> to go to UCM home page.
6	Click the <b>Subscribers</b> link in UCM. The <b>Search for Subscribers</b> Web page appears.
7	Enter the subscriber's last name in the <b>Name</b> field of the search criteria, and click <b>Search</b> . Use the subscriber name that you used in step 1. The <b>Search for Subscriber</b> Web page appears with search results that match the search criteria.
8	Click the name of the subscriber. The <b>Subscriber Details</b> Web page appears with no changes made to the account in the account list. No changes are made to the account list of the subscriber whose employee reference field you used in step 1.

---

--End--

---

## Move Phones

You can move a telephone to another TN with the same property values. To do this, perform the steps in [Procedure 107 "Move Phones" \(page 298\)](#).

### Procedure 107 Move Phones

Step	Action
1	<p>From the <b>Search Results</b> section of the <b>Search for Phones</b> Web page, select <b>Move</b> from the <b>&lt;more actions&gt;</b> list.</p> <p>The <b>Move TN</b> Web page appears, as shown in <a href="#">Figure 206 "Move TN Web page" (page 298)</a>.</p>

**Figure 206**  
**Move TN Web page**

**Note:** For Attendant consoles/phones, the Move TN Web page displays two prompts for *Terminal Number* and *Secondary Terminal Number*.

- 2 Enter the TN to move the telephone, and click **Submit**.

--End--

## Retrieve Phones

The Retrieve Phones function synchronizes data from the Call Server to the Phones database. Perform the steps in [Procedure 108 "Retrieve Phones" \(page 299\)](#).

## Procedure 108 Retrieve Phones

Step	Action
1	From the <b>Search for Phones</b> Web page, click <b>Retrieve</b> .
2	The <b>Retrieve Options</b> Web page appears, as shown in <a href="#">Figure 207 "Retrieve Options Web page"</a> (page 299).

**Figure 207**  
**Retrieve Options Web page**

Managing: CS1000E\_Node5 (192.167.100.3)  
Phones > Retrieve Options

### Retrieve Options

Phones selected  
 All phones and reconcile  
 Custom

Customer:   
 Type:   
 Terminal Number:   
 Card density:   
 Designator:   
 Tenant:   
 Modified since: Month:  Day:  Year:

Submit Cancel

- 3 Select one of the Retrieve Options, as follows:
- Select **Phones selected** to retrieve the telephones in the phone **Search Results** section.
  - Select **All phones and reconcile** to retrieve the telephones.
  - Select **Custom** and enter any combination of search criteria to retrieve telephones that meet those criteria.
- 4 Click **Submit**.

--End--

**Note 1:** The maximum session time in UCM is 2 hours by default. You need to change the maximum session time for import operation that exceeds 2 hours in the UCM Session Properties section. To change the maximum session time refer to *Unified Communication Management* (NN43001-116).

**Note 2:** It is recommended to perform 'retrieve and reconcile' operation only by one user at a time. EM Phone Provisioning does not support concurrent users for the 'retrieve and reconcile' operation.

## Delete Phones

To delete telephones, perform the steps in [Procedure 109 "Delete Phones" \(page 300\)](#).

### Procedure 109 Delete Phones

Step	Action
1	From the <b>Search for Phones</b> , search for telephones based on a search criteria.
2	Click the boxes beside all the telephones to delete.
3	Click <b>Delete</b> .
4	Click <b>OK</b> to confirm the deletion of the telephones selected, or click <b>Cancel</b> to stop the operation.
--End--	

## Swap Phones

When you swap telephones, two telephones exchange TNs. The following limitations apply to a swap:

- You can swap only two telephones at a time.
- The telephones to be swapped must belong to the same customer.
- The telephones to be swapped must have compatible TN types. For example, you cannot swap an analog (500/2500-type) telephone with a digital telephone.
- Swapping is not supported for DCS telephones. Element Manager does not control the allocation of virtual TNs for DCS telephones.
- If the synchronization status of one of the telephones to be swapped is New, it must be swapped with another telephone with a synchronization status of New.
- The telephones to be swapped must have the same VCE or DTA Class of Service.
- Swapping is not supported for IP Phones.
- Swapping is not supported with the BFS feature.

- Swapping is not supported if one of the telephones is an ACD telephone in the acquired state.
- Swapping is not supported for telephones with a branch office link.

#### Procedure 110 Swap Phones

Step	Action
1	From the <b>Search for Phones</b> , search for telephones based on a search criteria.
2	From the list of telephones, select the two telephones to swap.
3	Select <b>Swap</b> from the <b>&lt;more actions&gt;</b> list. The changes are submitted to the database.
--End--	

## Courtesy Change

The Courtesy Change feature checks the telephone busy/idle status before transmitting changes to the Call Server. If the telephone is busy, the change is not transmitted; the active call is disconnected, and the following error message appears: "Telephone is busy. Changes are not transmitted."

Before a telephone call is transmitted to the Call Server, the LD 32 STAT command is used to check the idle/busy status of the telephone. If the telephone is busy, then the changes are not committed to the Call Server and you must perform the operation again.

Nortel recommends that you turn off this feature before doing an bulk import operation.

## Reports

Element Manager provides the ability to construct complex SQL queries against the Phones database. The results can be in either HTML or CSV format. If you choose HTML format, only a maximum of 1000 records appear.

Click the **Reports** link of the **Phones** branch of the Element Manager navigator. The **Edit a Report** Web page appears, as shown in [Figure 208 "Edit a Report Web page" \(page 302\)](#).

**Figure 208**  
**Edit a Report Web page**

Enter the desired criteria and report format. Click **Generate Report** to generate the report.

## IP Attendant

The IP Attendant feature supports phone or console provisioning of type 3260 using the EM Phone Provisioning. The system supports a maximum of 64 attendant consoles.

The Web Services feature provides support for the IP Attendant phone through EM Phone Provisioning Web Services.

You can navigate to the Search For Phones Web page by clicking the **Phones** link in the Phone Provisioning home page. From the Search For Phones Web page, you can perform the following actions.

- Search for a 3260 Phone.
- Add a 3260 Phone.
- Edit a 3260 Phone.
- Delete a 3260 Phone.
- Move a 3260 Phone.

The following figure shows the Search For Phones Web page.

**Figure 209**  
**Search For Phones Web page**

**Search For Phones** Advanced | Hide

Criteria: Phone Type Value 3260 - IP Attendant Console

Results Per Page: 10 Search

Phones Found (12)

Add... Import... Retrieve... Delete <More Actions> Refresh

	Customer	TN	Prime DN	Designation	Phone Type	Template	UXID
1	0	096 0 00 00 (096 0 00 01)			3260		
2	0	096 0 00 02 (096 0 00 03)			3260		
3	0	096 0 00 04 (096 0 00 07)			3260		
4	0	096 0 00 05 (096 0 00 06)			3260		
5	0	096 0 00 16 (096 0 00 19)			3260		
6	0	096 0 03 03 (096 0 03 08)			3260		
7	0	096 0 03 04 (096 0 03 02)			3260		
8	0	096 0 03 05 (096 0 03 06)			3260		
9	0	096 0 03 09 (096 0 03 11)			3260		
10	0	096 0 06 02 (096 0 06 03)			3260		

1-10 of 12 Page 1

Copyright © 2002-2009 Nortel Networks. All rights reserved.

The details of the IP Attendant 3260 Phone can be viewed at the Telephone Details Web page. This page has the following four tabs providing information about the phones.

- General Properties
- Features
- Keys
- User Fields

#### **ATTENTION**

The Secondary Terminal Number is a mandatory parameter for a 3260 phone type.

#### **Searching a 3260 phone**

You can search for an IP Attendant 3260 Phone, based on phone type or Terminal number.

To search for a 3260 Phone, based on the phone type, use the following procedure.

Step	Action
1	In the Search For Phones Web page, select <b>Phone Type</b> from the drop-down list corresponding to the <b>Criteria</b> field.
2	Select the value <b>3260 - IP Attendant Console</b> from the drop-down list available in the <b>Value</b> field.
3	Click <b>Search</b> .  The page refreshes to display the search results with the Primary and Secondary TN corresponding to each result as shown in the following figure.

--End--

**ATTENTION**

To search for a 3260 Phone, based on the Terminal Number, select the value **Terminal Number** in the **Criteria** field. Select the value as **Primary/Secondary TN value**.

**Adding a 3260 Phone**

To add a 3260 Phone, use the following steps.

Step	Action
1	In the Search for Phones Web page, click <b>Add</b> .  The New Phones Web page opens as shown in the following figure.

Managing: [EM on ntec-dell3\(47.152.232.2\)](#)  
[Phones»New Phones](#)

---

### New Phones

Number of phones:  \* (1-100)

Customer:

Phone Type 3260 - IP Attendant Console  
 Template  
 Copy From TN

Options:

<input type="checkbox"/> Default value for DES	<input type="text" value=""/> * (1-6 characters)
<input type="checkbox"/> Default value for ZONE <small>Only applicable to IP phone types</small>	<input type="text" value=""/>
<input type="checkbox"/> Default value for Node Id <small>Only applicable to UEXT-SIPL phone types</small>	<input type="text" value=""/>
<input type="checkbox"/> Automatically assign TN starting TN	<input type="text" value=""/>
<input type="checkbox"/> Automatically assign DN starting DN	<input type="text" value=""/>

\* Required value

2 Select the radio button corresponding to the **Phone Type** field.

3 Select **3260 - IP Attendant Console** from the drop-down list corresponding to the **Phone Type** field.

4 Click **Preview**.

The Telephone Details Web page appears.

5 Complete the fields with the required values for the phone.

6 Click **Save**.

The Search For Phones Web page appears.

You can view the details of the phone by clicking on the Terminal Number and opening it.

---

--End--

---

### Editing a 3260 Phone

To edit a 3260 Phone, use the following procedure.

Step	Action
1	In the Search For Phones Web page, click on the Terminal Number of the 3260 Phone to edit.  The Telephone Details Web page appears.
2	Edit the values in the fields as required.

**ATTENTION**

The Secondary TN field is a non-editable field.

- 3 Click **Save** to save the changes.  
The Search For Phones Web page appears.

---

--End--

---

**Deleting a 3260 Phone**

To delete a 3260 Phone, use the following procedure.

Step	Action
1	In the Search For Phones Web page, select the check box corresponding to the 3260 phone to be deleted.
2	Click <b>Delete</b> .  The system displays a dialog box asking for confirmation to delete the phone.
3	Click <b>OK</b> to delete the phone.  The page refreshes to display the Search For Phones Web page.

---

--End--

---

**Moving a 3260 Phone**

To move a 3260 Phone, use the following procedure.

Step	Action
1	In the Search For Phones Web page, select the check box corresponding to the 3260 phone to be moved.
2	Select the value <b>Move</b> from the <b>More Actions</b> drop-down list.  The Move TN Web page appears as shown in the following figure.

Managing: [EM on ntec-dell3\(47.152.232.2\)](#)  
Phones»Move TN

---

### Move TN

Terminal Number:	From	<input type="text" value="096 0 00 02"/>	To	<input type="text"/> *
Second Terminal Number:	From	<input type="text" value="096 0 00 03"/>	To	<input type="text"/> *

The current Primary and Secondary TNs are displayed in the **From** fields.

- 3 Fill in the required values in the **To** fields corresponding to the **Terminal Number** and **Second Terminal Number** fields.
- 4 Click **Submit** to move the phone to the specified TNs.

The page refreshes to display the Search For Phones Web page.

---

--End--

---


## Migration

Use the Migration tool to migrate telephone data from Element Manager to Subscriber Manager. This tool associates the telephone with existing subscribers, or adds a subscriber and then add accounts to them.

You can migrate only telephones that have a CPND name configured. During migration, the tool checks with the Subscriber Manager for a subscriber with the same name as the CPND name in the telephone. Based on the search result, it either adds an account under the existing subscriber, or creates a new subscriber and then adds an account under it.

To start the Migration tool, select on the **Migration** link on the **Phones** branch of the Element Manager navigator. The **Migration** Web page appears as shown in [Figure 210 "Migration Web page" \(page 308\)](#).

**Figure 210**  
Migration Web page




To create a new subscriber when a CPND name mismatch occurs, ensure the **Create new subscriber** box is selected.

When you click **Migrate**, a confirmation message box appears before the migration starts.

While the migration is in progress, the system displays a status page that provides the current status of the migration. The page is refreshed every 5 seconds with the latest status.

After the migration is complete, the page shows the summary as shown in [Figure 211 "Migration Results Web page" \(page 308\)](#).

**Figure 211**  
Migration Results Web page



---

# Tools

---

## Contents

This section contains the following topics:

[“Introduction” \(page 309\)](#)

[“Backup and Restore” \(page 309\)](#)

[“Call Server Initialization” \(page 319\)](#)

[“Date and Time” \(page 322\)](#)

[“Logs and Reports” \(page 335\)](#)

## Introduction

The following Call Server Tools can be accessed through Element Manager:

- Backup and Restore
- Call Server Initialization
- Date and Time
- Logs and Reports


## Backup and Restore

The **Backup and Restore** link of the **Tools** branch of the Element Manager navigator provides access to Call Server Backup and Restore functions, as well as Personal Directories Backup and Restore functions.

### Call Server

In the Services branch of the Element Manager navigator, click **Backup and Restore > Call Server**. The **Call Server Backup and Restore Web** page opens (see [Figure 212 "Call Server Backup and Restore Web page" \(page 310\)](#)).

**Figure 212**  
**Call Server Backup and Restore Web page**




**Note:** Backup Rules and Backup Schedules are available only on CPP IV and CP PM systems.

### **Backup**

To back up the Call Server, click the **Backup** link on the **Call Server Backup and Restore** Web page. The **Call Server Backup** Web page opens, as shown in [Figure 213 "Call Server Backup Web page"](#) (page 311).

**Figure 213**  
**Call Server Backup Web page**



Managing: [192.167.102.3](#)  
Tools » Backup and Restore » [Call Server Backup and Restore](#) » Call Server Backup

---

## Call Server Backup

Action

---

Select **Backup** from the **Action** drop-down list and click **Submit**. The **Call Server Backup Waiting** Web page opens to indicate that the backup is in progress.

The Backup function invokes a data dump and writes the Call Server data to the primary and internal backup drives.

The Backup function performs the same task as the EDD CLI command traditionally configured in LD 43.

A summary of the results of the EDD appears at the bottom of the **Call Server Backup** Web page.

### Performing manual database replication

To manually invoke the database replication process, select **Backup According to Rule** from the **Action** drop-down list, and click **Submit**. The **Backup Rule Number** drop-down list appears. In the **Backup Rule Number** drop-down list, enter the Backup Rule number to use for the restore operation. Click **Submit**.

For more information on backing up and restoring databases for Geographic Redundancy, see *System Redundancy Fundamentals (NN43001-507)*.

### Restore

The Call Server Restore function restores the backed-up files from the internal backup device to the primary device. The Restore function performs the same task as the CLI RIB command traditionally configured in LD 43.

**WARNING**

The process to restore data using the Element Manager interface is immediate. There is no warning or detailed information provided on the specifics of the data to be restored.

Also, note that a "cold start" of the system is required before the restored data is in effect.

Click the **Restore** link on the **Call Server Backup and Restore** Web page. The **Call Server Restore** Web page opens (see [Figure 214 "Call Server Restore Web page"](#) (page 312)).

**Figure 214**  
**Call Server Restore Web page**

Managing: [192.167.102.3](#)  
Tools > Backup and Restore > [Call Server Backup and Restore](#) > Call Server Restore

---

## Call Server Restore

Action

---

Select **Restore from Backup Data (RES)** in the **Action** drop-down list, and click **Submit**.

**Note:** The database for Element Manager IP Telephony is updated immediately after the restore. Other call server databases require a cold start after the restore.

For information about the server databases and when they were created, select **Database issue and creation date** in the **Action** drop-down list, and click **Submit**. The information is displayed in the text area below the command.

To manually invoke a database restore process, select **Restore According to Rule (RSR X Y)** from the **Action** drop-down list. The **Backup Rule Number** and **Restore Version** drop-down lists appear, as well as the **Apply Filtering** checkbox.

In the **Backup Rule Number** drop-down list, enter the Backup Rule number to use for the restore operation.

For more information on backing up and restoring databases for Geographic Redundancy, see *System Redundancy Fundamentals (NN43001-507)*.

### Backup Rules

To add or edit a Backup Rule, click the **Backup Rules** link on the **Call Server Backup and Restore** Web page. The **Backup Rules** Web page opens as shown in [Figure 215 "Backup Rules Web page"](#) (page 313).

**Figure 215**  
**Backup Rules Web page**

Managing: [192.167.100.3](#)  
Tools » Backup and Restore » [Call Server Backup and Restore](#) » Backup Rules

### Backup Rules

	Rule Number	Rule Type	Rule Name	SCS IP Address	Versions
<input type="radio"/>	1	SCS	BACKUP1	0.0.0.0	2

To view a log of backup attempts, select a **Backup Rule** and click **History**. The **Backup History** Web page opens. This Web page displays information for each backup attempt based on the given Backup Rule.

To add a Backup Rule, click **Add** on the **Backup Rules** Web page. The **Add Backup Rule** Web page opens. To edit a Backup Rule, click the Backup Rule Number. The **Edit Backup Rule** Web page opens, as shown in [Figure 216 "Edit Backup Rule Web page"](#) (page 314).

**Figure 216**  
**Edit Backup Rule Web page**

Managing: [192.167.100.3](#)  
Tools > Backup and Restore > [Call Server Backup and Restore](#) > [Backup Rules](#) > Edit Backup Rule 1

---

## Edit Backup Rule 1

**Rule Type:** Secondary Call Server   
Only one backup rule of type Fixed Media Device or Removable Media Device can be configured

**Rule Name:**

**ELAN IP Address of Secondary CS for Geographic Redundancy:**

**Number of versions kept:**

The following Backup Rule Types are available:

- Fixed Media Device
- Removable Media Device
- FTP
- Secondary Call Server

For more information on configuring backup rules for Geographic Redundancy, see *System Redundancy Fundamentals (NN43001-507)* ().

### Backup Schedules

Backup schedules provide the user with the ability to schedule backup operations associated with a specified backup rule. To add or edit a Backup Schedule, click the **Backup Schedules** link on the **Call Server Backup and Restore** Web page. The **Backup Schedules** Web page opens as shown in [Figure 217 "Backup Schedules Web page" \(page 315\)](#)

**Figure 217**  
**Backup Schedules Web page**

Managing: [192.167.100.3](#)  
Tools » Backup and Restore » Call Server Backup and Restore » Backup Schedules

### Backup Schedules

[Refresh](#)

	Schedule Number	Rule Number	Rule Name	Rule Type	Frequency	Day	Hour	Minutes
<input type="radio"/>	1	1			M	1	2	5

To add a Backup Schedule, click **Add**. The **Add Backup Schedule** Web page opens. To edit a Backup Schedule, click the **Schedule Number**. The **Edit Backup Schedule** Web page opens, as shown in [Figure 218 "Edit Backup Schedule Web page"](#) (page 316).

**Figure 218**  
**Edit Backup Schedule Web page**

Managing: [192.167.100.3](#)  
 Tools > Backup and Restore > [Call Server Backup and Restore](#) > [Backup Rules](#) > [Backup Schedules](#) > Edit Backup Schedule 1

---

## Edit Backup Schedule 1

Backup Rule:: 1-BACKUP1  
 Frequency:: Monthly  
 Day:: 1  
 Hour:: 2  
 Minute:: 5

Save Cancel

Each backup schedule defines a total of six associated parameters, as follows:

- **Backup Schedule Number** — up to ten backup schedules can be defined, numbered from one to ten.
- **Backup Rule** — specifies the backup rule number associated with this backup schedule. The backup rule number must be previously configured.
- **Frequency** — defines how often the scheduled backup operation occurs. The default is D. Not more than one backup schedule can be defined with Frequency set to the value A. Options are:
  - M (monthly)
  - W (weekly)
  - D (daily)
  - A (automatic — immediately after every EDD)
- **Day** — specifies the day on which the backup occurs with a default value of SU. When Frequency is M, the range is 1 to 31 with a default value of 1. This parameter does not apply when Frequency is set to either of the values D or A. When Frequency is W, the range is the days of the week as follows:
  - SU
  - MO
  - TU

- WE
  - TH
  - FR
  - SA
- **Hour** — specifies the hour in the day on which the backup occurs. The range is 0 to 23, with a default of 3. This parameter does not apply when **FREQ** is set to the value **A**.
  - **Minute** — specifies the minute in the hour in the day on which the backup occurs. The range is 0 to 59.

To update Backup Schedules, click **Automatic Schedules**. The **Update Backup Schedules** Web page opens, as shown in [Figure 219 "Update Backup Schedules Web page"](#) (page 317).

**Figure 219**  
**Update Backup Schedules Web page**

Managing: [192.167.102.3](#)  
Tools > Backup and Restore > [Call Server Backup and Restore](#) > [Backup Schedules](#) > Update Backup Schedules

### Update Backup Schedules

All the Backup Schedules of type Secondary Call Server are scanned and associated Backup Schedules are updated.

Frequency: Monthly ▾  
Day: 1 ▾  
Hour: 0 ▾  
Minute: 0 ▾  
Delay: 3 ▾

Save Delete Cancel


Backup schedules are supported only on CP PII, CP PIV and CP PM systems. A backup schedule can be created, modified, deleted, and printed by the respective command options **NEW**, **CHG**, **OUT**, and **PRT**.

### Personal Directories Backup and Restore

To backup or restore Personal Directories click the **Backup and Restore > Personal Directories** link of the Tools branch or the Element Manager Navigator.

The **Personal Directories Backup and Restore** Web page opens and shown in the following figure.


**Figure 220**  
**Personal Directories Backup and Restore Web page**



To backup Personal Directories click the Personal Directories Backup link of the **Personal Directories Backup and Restore** Web page.

The **Personal Directories Backup** Web page opens as shown in the following figure.

**Figure 221**  
**Personal Directories Backup Web page**

The screenshot shows a web browser interface for the "Personal Directories Backup" page. At the top, it says "Managing: 172.16.100.2" and "Tools > Backup and Restore > Personal Directories Backup and Restore > Personal Directories Backup". Below this is a horizontal line and the title "Personal Directories Backup". Underneath the title, there is an "Action" section with a dropdown menu set to "Backup", and "Submit" and "Cancel" buttons. Below the buttons, there are five input fields with labels: "Remote backup IP address", "Remote backup userid", "Remote backup password", "Remote backup full path", and "Remote backup file name".

To backup Personal Directories, enter the backup information and click **Submit**.

To restore Personal Directories click the Personal Directories Restore link of the **Personal Directories Backup and Restore** Web page.

The **Personal Directories Restore** Web page opens as shown in the following figure.

**Figure 222**  
**Personal Directories Restore Web page**

Managing: 172.16.100.2  
 Tools > Backup and Restore > Personal Directories Backup and Restore > Personal Directories Restore

**Personal Directories Restore**

Action: FTP from Remote Site [Submit] [Cancel]

Remote backup IP address:

Remote backup userid:

Remote backup password:

Remote backup full path:

Remote backup file name:

To restore Personal Directories, enter the backup information to restore and click **Submit**.

For information on Backup and Restore functions of Personal Directories, “[Personal Directories](#)” (page 179).

## Call Server Initialization

The Call Server Initialization page is used to invoke Call Server INI & Call Server SYSLOAD commands.

Click the **Call Server Initialization** link in the **Tools** branch of the Element Manager navigator. The **Call Server Initialization** Web page opens, as shown in [Figure 223 "Call Server Initialization Web page"](#) (page 319).

**Figure 223**  
**Call Server Initialization Web page**

**Call Server Initialization**

Commands executed from this page will reboot the Call Server and the Element Manager user will be logged out

[INI ACTIVE] [SYSLOAD ACTIVE]

**CPU Information**  
 Disk State : NOT REDUNDANT  
 Activity State : Active  
 Health : 14

To check for the message displayed, roll the mouse over buttons displayed on the page.

If there is an INI command on the button, then the following message is displayed, “Restarts the Application Server”.

If it is a SYSLOAD command, then another message is displayed, “Restarts the Application Server as well as the Operating System”.

### **Call Server INI ACTIVE Command**

The Call server is a Redundant System or a Split System on the Active side.

#### **Procedure 111 Initializing the INI ACTIVE command**

<b>Step</b>	<b>Action</b>
1	Click <b>INI ACTIVE</b> . A confirmation message is displayed.
2	Click <b>OK</b> . The Call Server is rebooted and the Element Manager user is logged out.
--End--	

### **Call Server INI INACTIVE Command**

The Call server is Redundant System on the Inactive side.

#### **Procedure 112 Initializing the INI INACTIVE command**

<b>Step</b>	<b>Action</b>
1	Click <b>INI INACTIVE</b> . A confirmation message is displayed.
2	Click <b>OK</b> . The inactive core is rebooted.
--End--	

### **Call Server INI BOTH Command**

The Call Server is a CPP Redundant System.

**Procedure 113**  
**Initializing the INI BOTH command**

Step	Action
1	Click <b>INI BOTH</b> . A confirmation message is displayed.
2	Click <b>OK</b> . The Call Server is rebooted and the Element Manager user is logged out.
--End--	

**Call Server SYSLOAD ACTIVE**

The Call server is a Redundant System or a Split System on the Active side.

**Procedure 114**  
**Initializing the SYSLOAD ACTIVE command**

Step	Action
1	Click <b>SYSLOAD ACTIVE</b> . A confirmation message is displayed.
2	Click <b>OK</b> . The Call Server is rebooted and the Element Manager user is logged out.
--End--	

**Call Server SYSLOAD INACTIVE Command**

The Call server is Redundant System on the Inactive side.

**Procedure 115**  
**Initializing the SYSLOAD INACTIVE command**

Step	Action
1	Click <b>SYSLOAD INACTIVE</b> . A confirmation message is displayed.
2	Click <b>OK</b> .

The inactive core goes for sysload.

---

--End--

---

### Call Server SYSLOAD BOTH Command

The Call Server has a Redundant System.

#### Procedure 116

#### Initializing the SYSLOAD BOTH command

---

Step	Action
1	Click <b>SYSLOAD BOTH</b> . A confirmation message is displayed.
2	Click <b>OK</b> . The Call Server is rebooted and the Element Manager user is logged out.

---

--End--

---

**Note:** If the selected command is not executed successfully for any reason, such as an overlay conflict for example, the following error message is displayed, "The command was not executed successfully. Try again."

## Date and Time

The date and time management covers the configuration of time synchronization options, as well as the setting of the actual date and time, and time zone related settings. An important concept is that there is a recommended configuration for any elements that are part of a CS 1000 system (these are running CS 1000 applications, such as CS, SS, SIPL, PD).

Timezone offsets for distributed phone subscribers is separately configurable through the Element Manger Branch Office zone configuration. In order to ensure that the configuration for a CS 1000 system is consistent, the configuration must be done using Element Manager.

The purpose of system-level coordination of the operating system date and time configuration for all elements of a single CS 1000 system is to facilitate the interpretation of system event and error messages generated by different elements.

The CS 1000 system level date and time management in Element Manager allows the configuration of Network Time Protocol (NTP) and Network Time Synchronization (NTS). The NTS client and NTP usage are mutually exclusive options for the CS 1000 system. A Call Server may be designated as the NTS master and utilize NTP to synchronize its own time.

In Element Manager, the configuration setting of NTP requires the systemadmin permissions, whereas setting of the actual date/time clock requires either systemadmin or timeadmin permissions.

For any other Linux servers that are not part of a CS 1000 system, configuration is done using Base Manager of UCM. See, *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315).

Configuration of time synchronization options performed from Element Manager overrides those previously performed by CLI, Base Manager, or the install tool on all system elements. Conversely, if changes are attempted later on at the individual element level that may interfere with the system time synchronization options chosen at the system level using Element Manager.

Nortel recommends that you use the ELAN interface for all NTP communication within a system. This would be to communicate to CS 1000 NTP primary and secondary servers. The CS 1000 NTP primary and secondary servers would normally communicate with external NTP clock sources using their TLAN connections. If TLAN is not available, then ELAN would be used. In all cases, it is necessary to ensure that appropriate routing is in place for communication between devices. This applies for communication to external sources and also for communication with CS 1000 NTP primary and secondary servers if the ELAN network interfaces of devices are on different subnets.

### **System time synchronization options**

The following are the time synchronization options offered. Only one such option may be chosen. All configuration for these options is done solely by Element Manager and conveyed to all system elements.

- NTS client (Call Server as NTS client) can be configured to allow the Call Server to be synchronized from a ISDN digital trunk D-channel. The Call Server then pushes time directly to all system elements. An exception is standalone Element Manager, where Element Manager is not running on an element with any of the Call Server, SS, SIPL, or PD applications. In such as case, Base Manager must be used to set appropriate time synchronization, if required, on that element
- NTS Master (Call Server as NTS master) can be configured to allow the Call Server to act as the NTS Master. This Call Server provides time synchronization to other Call Servers set up as NTS slaves across

MCDN. The system with Call Server as NTS master may use NTP configuration to maintain time from external time sources or internal hardware clock of the CS 1000 Primary NTP server.

- CS 1000 system level primary and, optionally, secondary NTP servers are configured on Linux system elements that are part of this CS1000 system. The secondary NTP server would act as a backup for the primary NTP server, and normally synchronize time with the primary NTP server and then try with other external sources. The default is that the element on which Element Manager is running is set as the CS 1000 primary NTP server, but that can be altered. All other Linux system elements (including EM if applicable) will synchronize to these CS 1000 NTP servers. Configuration is done by EM and pushed to all Linux elements.

The CS 1000 primary and secondary NTP servers can source their time in two ways:

- The CS 1000 primary and secondary NTP servers use their internal hardware clocks. The date/time has to be set using Base Manager on the primary (assuming that the secondary NTP server will sync time from the primary NTP server in normal operation).
- External NTP clock sources are used. The internal system primary and secondary NTP servers are synchronized from external clock sources, up to 10, with optional single key security. The secondary NTP server would normally synchronize with the primary NTP server, and only synchronized with the external sources if the primary is not available.

If you use NTP security, all the clock source servers need to have the same private key. This means that an internal primary NTP server can not use a different key to access an external server than that which is used for servicing requests from internal clients. The implication is that if the external connection is to be secured, the internal connections would also have to be secured using the same single key as the external connections. Also, all the external servers need to have the same private key to service the requests from the internal servers or other Linux NTP clients.

**Note:** In previous releases, the Call Server supported configuration of two external clock sources with different private keys for each, but only a single private key is supported in Communication Server 1000 Release 6.0.

When NTP configuration is done using EM, the ELAN IP addresses of system elements are obtained from UCM element information and used for the configuration of such elements as primary or secondary NTP servers.

When NTP is utilized, you must configure each element with time zone and daylight saving adjustments. Element Manager supports Windows-style selection of time zones. The time zone you select determines the time zone regions and subregions to be used on Linux system elements. The configuration associated with the time zone you select is applied to all system elements

## System Date and Time

The **System Date and Time** Web page offers configuration of the following:

- The ability to configure the Date and Time for the system
- The ability to configure the Time Zone
- The option to configure Network Time Protocol for the system
- The option to configure Network Time Synchronization for the system

**Note:** If there are no time synchronization options currently chosen (i.e., neither NTP nor NTS are configured) then a warning appears.

Click the **Date and Time** link in the **Tools** branch of the Element Manager navigator. The **System Date and Time** Web page opens, as shown in [Figure 224 "System Date and Time Web page" \(page 325\)](#).

**Figure 224**  
**System Date and Time Web page**

The screenshot displays the 'System Date and Time' configuration page. At the top, it shows 'Managing: 172.16.100.2' and 'Software Version: 6.0'. The main title is 'System Date and Time' with a subtitle: 'The system clock may be set manually, or synchronized with a network time server.' Below this, there are four main sections, each with an 'Edit...' button:

- Current System Date and Time:** Includes a 'Sync Now' button and shows the current date as '13 February 2009' and time as '15:56:49'.
- Time Zone:** Shows the current zone as '(GMT-04:00) Atlantic Time (Canada) (with Daylight Saving adjustments)'.
- NetworkTimeProtocol:** Includes 'Sync Now' and 'Edit...' buttons. Shows 'Key ID: 1234', 'Private Key: \*\*\*\*\*', 'Primary NTP server IP: 192.168.55.45', and 'Secondary NTP server IP: 192.168.55.41'.
- Network Time Synchronization:** Shows 'Node role: NTS Master'.

The **System Date and Time** Web page summarizes the following sections:

- Current System Date and Time: The time displayed is always the Call Server time.
- Time zone: The time zone configured for the CS 1000 system is displayed
- Network Time Protocol: The NTP server (Primary/Secondary) details are displayed. If security is configured then the key id and private key are shown (masked), otherwise a message is displayed with "Not configured".
- NTS configuration is displayed (NTS Master/NTS Slave/NTS Stand-alone).

### Current System Date and Time

The Current System Date and Time section displayed on the **System Date and Time** Web page displays the current date and time on the CS 1000 Call Server. When you select Edit, you can manually set the date and time on the Call Server or NTP server. Manually setting the date and time is not an operation that you would normally perform in the cases where either NTP or NTS were configured because manual adjustments would be overwritten.

The Sync Now button initiates re-application of the date and time configuration to all elements. If NTP is in use on the system this results in an immediate synchronization with external NTP sources and/or the CS 1000 primary NTP server.

If the NTP is in use, then you are redirected to Base Manager to set the date and time on the internal Primary NTP server and if NTS is in use then you configure the date and time on the Call Server and in the case of a Linux based Call Server it is done through redirection to the Base Manager.

Use the Edit button in the following scenarios:

- If the system is running as NTS slave then time is set on the Call Server. For a VxWorks Call Server clicking Edit brings up a new page to set the time. For the CP PM Co-Resident CS & SS on Linux, the Base Manager of the CS server is opened in a new window.
- If the system is using NTP, then clicking Edit opens the Base Manager time page of the Primary NTP server in a new window.
- In the case of NTS master or NTS stand-alone (i.e., NTS disabled), then if NTP is in use clicking Edit opens the Base Manager time page.
- If time synchronization is not configured, a warning is normally given when accessing the page. Clicking Edit allows the time on the Call

Server to be set. For a VxWorks Call Server clicking Edit brings up a new page to set the time. For the CP PM Co-Resident CS & SS on Linux, the Base Manager of the CS server is opened in a new window.

If NTP is being used on the system, then after setting the time, click Sync Now, to immediately start time synchronization to all elements.

For more information about configuring Date and Time using Base Manager, refer to *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315).

**Procedure 117**  
**Editing date and time on a VxWorks Call Server**

Step	Action
1	Click <b>Edit</b> in the Current System Date and Time section of the <b>System Date and Time</b> Web page. The <b>Edit Date and Time</b> Web page opens, as shown in <a href="#">Figure 225 "Edit Date and Time Web page" (page 328)</a>
2	Enter the Date and Time in the appropriate fields.
3	If necessary enter the value for the Daily Time Adjustment to compensate for a fast or slow system clock.
4	Click <b>Save</b> . The <b>System Date and Time</b> Web page opens with the new time settings.
5	If NTP is being used on the system, click <b>Sync Now</b> to immediately start time synchronization to all elements.
--End--	

**Figure 225**  
**Edit Date and Time Web page**

Tools > System Date and Time > Edit Date and Time

### Edit Date and Time

**Date**

Day: 15 Month: October Year: 2008 \*

**Time**

Hours: 11 \* Minutes: 10 \* Seconds: 18 \*

**Daily Time Adjustment**  
Adjust time of day during the midnight routines to compensate for a fast or slow system clock

Increment + Adjustment 000 \* (0 - 250 milliseconds)

Save Cancel

## Time Zone

The **Time Zone** Web page displays the time zones and lists all the supported zones and UTC values. The time zone selected is used to set the time on the Call Server and Linux elements. For the case of a VxWorks Call Server internal mapping is also done of the offset from UTC and Daylight Saving time start and end dates. For a VxWorks Call Server, the Daylight Saving time start and end dates will be configured on the Call Server using the internally mapped values. For Linux devices, the Linux time region Daylight Saving time information is used.

If the time zone selected has automatic Daylight Saving adjustments built in, the text on the screen indicates that as "(with Daylight Saving adjustments)", otherwise the text indicates "(no Daylight Saving adjustments)". Some time zones (e.g., currently those associated with Jerusalem and Tehran) have Daylight Saving dates that vary each year. These are not handled and you must manually change the time zones for these regions upon entering or leaving the Daylight Saving calendar period. When such time zones are selected, the text on the screen indicates "(manual time zone change required when entering or leaving Daylight Saving period)".

### Procedure 118 Editing the Time Zone

Step	Action
1	Click <b>Edit</b> in the Time Zone section of the <b>System Date and Time</b> Web page.  The <b>Time Zone</b> Web page opens as shown in the following figure.
2	Select the Time Zone from the list.
3	Click <b>Save</b> .  The <b>System Date and Time</b> Web page opens with the new time zone setting.

--End--

**Figure 226**  
**Time Zone Web page**

Managing: 192.168.209.122 Username: admin2  
Tools » Date and Time » System Date and Time » Time Zone

#### Time Zone

**Warning:** Altering the time zone may have an impact on system operation. Scheduled tasks may not run when expected, and other time-dependent application behavior may be affected. Larger time differences may result in system stability issues and security certificate expiry. Your current management session may be terminated and then it will be necessary to log in again.

Time Zone:

These settings will be propagated to all servers associated with CS1000 system.

Region: (GMT-02:00) Mid-Atlantic

\*Required value.

### Network Time Protocol

Prior to CS 1000 Release 6.0, Element Manager used overlay configuration of the Call Server (CS) on VxWorks to support system level NTP configuration. The NTP configuration only applied to the CS and all of the VxWorks based Communication Server 1000 system elements derived their time from the CS through a pbxLink.

You must use Element Manager to configure time synchronization settings that are used on the Call Server as well as all other system elements. The configuration of NTP differs from the support that was present prior to Release 6.0. Some settings for polling interval, query offset, and alarms which were applicable for VxWorks based CS are not offered now, since the Call Server now synchronizes only with internal system primary or

secondary NTP servers, and not with external clock sources. These settings will be hardcoded now and ten minutes for polling will be the mid-range of Linux NTP clients.

If this is the first time that NTP is being configured, once the **Synchronize System Clock with NTP** check-box is checked, the UI is loaded with a default configuration. The default configuration has the server running Element Manager selected as the internal Primary NTP server, and internal clock sources (hardware clock on this server) is used. If NTP had been previously configured on the system, but subsequently disabled then the previous configuration is displayed.

The default selection for transfer mode is "Secure". This selection requires the operator to enter the Key ID and Private key. Only a single key is supported to be applied for NTP protocol security between external clock sources as well as between internal system NTP servers and other system Linux elements. Only MD5 authentication is supported for NTP security. Selecting insecure transfer mode disables the fields for Key ID and Private key and the key data is not removed.

When you click the Sync Now button in the Network Time Protocol section, a ntpconfig command is sent to the Linux element with the pre-configured NTP details.

### **CS1000 Linux System Elements**

The NTP Configurations propagate into all Linux elements associated with the CS1000 system. Default configuration shows the list of Linux elements registered with the CS1000 system. Linux elements that are not associated with the CS1000 system can be added and removed manually and updates the same for CS1000 system-level NTP servers.

### **CS1000 system-level NTP server(s)**

The selection of a primary internal NTP server is mandatory, whereas a secondary internal NTP server is optional, but recommended when there are two or more Linux based elements configured in the CS 1000 system.

The secondary internal NTP server's NTP client normally gets its time source from the primary internal NTP Server. If the Primary internal NTP server does not respond to the Secondary, then the Secondary gets its time source from the first external NTP server which responds to polling by the Secondary.

NTP clients running on Linux base elements which are "Not a clock server", as well as on the VxWorks-based Call Server, get their time source from the Primary internal NTP server, or from the Secondary internal NTP server, if the Primary does not respond to polling by the other NTP clients in the CS 1000 system.

If NTP has not already been configured for the CS1000 system, the default value for is the ELAN address Element Manager for the system. The drop down boxes for primary and secondary server IP addresses provide the choice of any Linux server associated with the given CS1000 system. ELAN IP's are always shown even if the hostname is on TLAN.

**Note:** The Primary and Secondary IP addresses must be different and the system validates the IP addresses before they are accepted.

### External Servers

The selection of External server(s) enables the additional fields labeled "NTP server IP" thereby allowing the operator to enter the IP addresses of one to ten external clock sources. The internal system primary and secondary NTP servers are Synchronized with these servers. The list is an ordered list, such that the first external source listed is contacted first, and if that fails then move on down the list. If the list is not in correct order then it may be necessary to delete sources and re-add in desired order. A newly added external server IPs is added to the end of the list.

If necessary to reach external servers then IP routing configuration may have to be performed on devices. This would not normally be required for devices that reach external sources by the TLAN, since the default route for most devices uses the TLAN. An IP route is required if the ELAN has to be used to reach an external source. The IP routes would have to be performed on the primary and secondary servers if required, and Base Manager can be used for this configuration. If external servers are not provided, the primary NTP server will derive its system clock from its internal hardware clock.

**Note:** The maximum number of Network Time Protocol server IP addresses is ten entries and are validated for uniqueness.

### Network Time Protocol configuration

To configure Network Time Protocol, click the **Date and Time** link in the **Tools** branch of the Element Manager navigator. The **System Date and Time** Web page opens.

#### Procedure 119 Configuring Network Time Protocol

Step	Action
1	Click <b>Edit</b> in the Network Time Protocol section of the <b>System Date and Time</b> Web page.  The <b>Network Time Protocol</b> Web page opens as shown in <a href="#">Figure 227 "Network Time Protocol Web page" (page 333)</a> .

- 2 Click the **Synchronize System Clock with NTP** box.  

**Note:** Clicking this box enables Network Time Protocol configuration otherwise only synchronization is available.
- 3 Select **Secure**.  
Secure is the default setting.
- 4 Enter the Key ID and Private Key.
- 5 Select Primary and Secondary IP addresses from the list.  
The drop down boxes for primary and secondary server IP addresses provide the choice of any Linux server associated with the given CS 1000 system.  

**Note:** If NTP has not been configured for the CS 1000 system, the default value for the primary server IP address is the ELAN address of the server hosting Element Manager for the system.
- 6 To select an external server as a clock source click the **External server(s)** box.  
Selecting **External server(s)** enables the additional fields labeled "NTP server IP" which allows you to enter the IP addresses of one to ten external clock sources.  

**Note:** Specifying an external NTP clock sources are optional, and if configured, are used by the local Primary and Secondary NTP servers. If external servers are not configured then the internal hardware clocks are used on the primary and secondary NTP servers.
- 7 Enter an external clock source and click **Add**. You can add up to ten external clock sources. The list is an ordered list, such that the first external source listed is contacted first, and if that fails then the next on the list is used.  

**Note:** You may have to perform IP routing configuration to reach external servers. This would not normally be required for devices that reach external sources by the TLAN, since the default route for most devices uses the TLAN. Base Manager can be used for IP route configuration.
- 8 Click **Save**.  
The parameters are transferred to all system Linux elements.

---

--End--

---

**Figure 227**  
**Network Time Protocol Web page**

Managing: 192.168.55.143 Username: admin2  
 Tools » Date and Time » System Date and Time » Network Time Protocol

---

**Network Time Protocol**

Synchronize System Clock with NTP:

Transfer Mode:  Secure  
 Insecure

Key ID: 666 \*(1-65535)  
 Private Key:  \*(1-16 alpha numeric chars)  
 The length of the private key should be at most 16 characters where #, single quotes and spaces are not accepted.

**CS 1000 Linux system elements**  
 The NTP configuration will be propagated to all Linux elements associated with this CS 1000 system. The ELAN IP addresses of all these elements must be listed below for proper configuration. Add any missing IP addresses to those automatically discovered.

Linux element IP:  Add  
 System Linux element IP addresses: 192.168.55.140 Remove  
 192.168.209.122  
 192.168.209.91  
 Items without a trailing "\*" were manually added and only these may be removed.

**CS1000 system NTP server(s)**  
 CS1000 system NTP server(s) may be your only clock source or may take their time from external servers defined below.

Primary NTP server IP address: 192.168.209.92  
 Secondary NTP server IP address: 192.168.209.101  
 ELAN IPs are always shown even if hostname is on TLAN.

Clock Source:  External server(s)  
 External NTP clock sources are optional and if configured are used by the local Primary and Secondary NTP servers.  
 Add up to ten external clock sources in order of priority. The first item in the list will be used first. Enter an IP Address below and click Add to add it to the bottom of the list.

NTP server IP:  Add  
 External NTP Servers in use: 2.2.2.2 Remove

\*Required value. Save Cancel

## Network Time Synchronization

The clock synchronization feature is designed to work on ISDN networks, using D channel messages. NTS helps to synchronize time across different zones with different time zones for each. The Call Server is configured in master/stand-alone/slave modes for these zones. The stand-alone Call Server doesn't sync up with the master but the slave does sync up with the master. NTS enables the CS 1000 Call Server to derive its system clock from a Digital Trunk Signaling Link (DTRL). All of the other Signaling Servers, Media Gateway Controllers, and Voice Gateway Media Cards associated with the CS 1000 system derive their system clock from the Call Server by signaling over the PBXLink. protocol.

In CS 1000 Release 6.0 support for NTS has been included in the deployment of Linux based servers. If the CS 1000 Call Server NTS Node Role is set as NTS slave then NTP and NTS configurations are mutually exclusive. For roles like stand-alone and master user can configure NTP for the elements to get time synced from the NTP servers. The Time Delta time adjustment factor keeps the Call Server at a difference with the master Call Server. This allows the slave Call Server to keep CS 1000 system time for its local timezone. If there are DST differences between the master NTS and slave NTS then manual adjustments may be required of the offset as the DST starts/ends.

You set the customer of the node and Local Virtual DN in charge of synchronizing the switch (that customer makes and receives the calls to and from the Master/Backup switch). That customer must already exist, prior to referencing it

If NTS is disabled and NTP is not in effect, then an warning message is shown to the user.

The Network Time Synchronization feature ensures that all time stamps in a network are synchronized from one source.

#### **Procedure 120 Configuring Network Time Synchronization**

<b>Step</b>	<b>Action</b>
1	Click <b>Edit</b> in the Network Time Synchronization section of the <b>System Date and Time</b> Web page.  The <b>Network Time Synchronization</b> Web page opens, as shown in <a href="#">Figure 228 "Network Time Synchronization Web page" (page 335)</a> .
2	Select the <b>Node Role</b> form the list.
3	Select the <b>Customer</b> from the list.
4	Enter the <b>Local Virtual DN</b> .
5	Enter the <b>Master/Backup Time Synchronization Number</b> .
6	Choose the mode: <b>Background (BKGD)</b> or <b>Daily Services Routine (DVCS)</b> .
7	If there are Daylight Saving Time (DST) differences between the master NTS and slave NTS then manual adjustments may be required of the offset as the DST starts or ends. Enter the <b>Time Adjustment factor with clock on Master</b> values

8 Click **Save**.

--End--

**Figure 228**  
**Network Time Synchronization Web page**

## Logs and Reports

To access IP Telephony Node Maintenance Reports click the **Logs and Reports > IP Telephony Nodes** link in the **Tools** branch of the Element Manager navigator. The **Node Maintenance and Reports** Web page appears.

For information on IP Telephony Node Maintenance and Reports, see [“Nodes: Servers, Media Cards” \(page 140\)](#).

In addition, information about the database status and synchronization are available under the Reports tab in NRS Manager. For more information on these reports, refer to *IP Peer Networking Installation and Commissioning (NN43001-313)*.

To display information on all IP Phones configured in the system, click the **Logs and Reports > IP Phone Location** link in the **Tools** branch of the Element Manager navigator. The **IP Phone Location** Web page opens, as shown in [Figure 229 "IP Phone Location Web page"](#) (page 336).

**Figure 229**  
**IP Phone Location Web page**

Managing: [192.167.102.3](#)  
Tools » Logs and reports » IP Phone Location

Search for IP Phone Location [Hide](#)

Criteria:

Results per page

IP Phones Found (3) [Refresh](#)

Entry #	Terminal Number	Prime DN	Type	State	Hardware ID	Public IP	ERL	ECL	Location Description	Manual Update	Need Update	Private IP
1	96 0 1 0	8000	1110	REG	180016ca00760f6623	192.167.103.26:5000						
2	96 0 1 1	8001	1110	REG	180016ca0076736623	192.167.103.27:5000						
3	96 0 1 3	8004	1140	REG	18001365ff682a6625	192.168.249.68:5000						

[First](#) | [Prev](#) | [Next](#) | [Last](#)

Enter the search criteria in the **Search for IP Phone Location** section and click **Search**. The results matching the criteria entered are displayed in the **IP Phones Found** section.

### Call Server Report

To access the **Call Server Report** Web page, click the **Logs and Reports > Call Server Report** link in the **Tools** branch of the Element Manager navigator. The **Call Server Report** Web page opens as shown in the following figure.

**Figure 230**  
**Call Server Report Web page**

The following buttons provide one-click access to the following functions:

- RDSCONVERT — Convert a report log file to text
- RDPREV — Open the previous log file
- RDNEXT — Open the next log file
- RDOPEN — Open the latest report file
- RDSHOW — Show a summary of the report file
- RDTAIL — Show x records up to the newest record in the report file (where x is the configured display size).
- RDHEAD — Show x records starting from the oldest record in the report file (where x is the configured display size).

To view selected detail data on records in the report file, use the text boxes, the drop-down lists, and the following buttons:

- RDGO — Displays the record specified in the adjacent text box (where -1 is the oldest record and 1000 is the most recent).
- RD — Browses the report records. Enter the number of records to skip and the number of records to display in the adjacent text boxes.
- RDS — Browses the report records with (symbolic) memory dump. Enter the number of records to skip, and select the number of records to display using the adjacent text box and drop-down list.
- VIEW — Views selected records. Enter a starting record number and select the number of records to view using the adjacent text box and

drop-down list. Negative numbers indicate records previous to the starting record.

### Equipped Feature Packages

To view a list of software feature packages, click the **Logs and Reports > Equipped Feature Packages** link in the **Tools** branch of the Element Manager navigator. The **Equipped Feature Packages List Web page** opens as shown in [Figure 231 "Equipped Feature Packages List Web page"](#) (page 338).

**Figure 231**  
**Equipped Feature Packages List Web page**

Managing: **192.168.209.115**  
Tools » Logs and reports » Equipped Feature Packages

### Equipped Feature Packages

	Package Description	Package Name	Package Number ▲
1	Optional Features	OPTF	1
2	Multi-Customer Operation	CUST	2
3	Call Detail Recording, Teletype Terminal	CDR	4
4	Call Detail Recording, Teletype Terminal	CTY	5
5	Recorded Announcement	RAN	7
6	Time and Date	TAD	8
7	Do Not Disturb Individual	DNDI	9
8	End-to-End Signaling	EES	10
9	Intercept Treatment	INTR	11
10	Automatic Number Identification	ANI	12
11	Automatic Number Identification, Route Selection	ANIR	13
12	Basic Routing	BRTE	14
13	Do Not Disturb Group	DNDG	16
14	Make Set Busy	MSB	17
15	Special Service for 2500 Sets	SS25	18

Items per page: 100 First | Prev | Next | Last

### Peripheral Software Version Data

To view a list of Peripheral Software Version Data, including the loadware version of the Media gateway Controller (MGC) card, click the **Logs and Reports > Peripheral Software Version Data** link in the **Tools** branch of the Element Manager navigator. The **Peripheral Software Version Data Web page** opens as shown in [Figure 232 "Peripheral Software Version Data Web page"](#) (page 339).

**Figure 232**  
Peripheral Software Version Data Web page

Peripheral Software Version Data	
PSWV Version: 123    MDCS Version:	
Peripheral Software Application	Version Number
Extended Network Card (XNET)	23
Carrier Remote IPE Card (LCRI)	02
Extended Peripheral Equipment Controller Card (XPEC)	41
Multipurpose ISDN Signalling Link Basecode Loadware (MISP)	71
MISP BRI Line Application Loadware (BRIL)	83
MISP BRI Trunk Application Loadware (BRIT)	82
MISP Meridian Packet Handler Application Loadware (MPH)	51
Multipurpose Serial Data Link Basecode Loadware (MSDL)	73
MSDL ASYN Application (SDI)	51
MSDL DCH Application (DCH)	72
MSDL Application Module Link Application (AML)	81
BRSC Basecode (BRSC)	71
BRSC BRI Application (BBRI)	54
UIPE PRI Loadware Application (PRIE)	85
UIPE BRIT Loadware Application (BRIE)	87
NI2 TR1268 Datafile (NI02)	26
ISO QSIG PRI2 Interface Datafile (ISIG)	33
NEW ZEALAND Interface Datafile (TCNZ)	13
ETSI Interface Datafile (ETSI)	48
AUSTRIA Interface Datafile (AUS1)	48
DENMARK Interface Datafile (DEN1)	48
FINLAND Interface Datafile (FIN1)	48
GERMANY Interface Datafile (GER1)	53
ITALY Interface Datafile (ITA1)	53

### System License Parameters

To view a list of System License Parameters, click the **Logs and Reports > System License Parameters** link in the **Tools** branch of the Element Manager navigator. The **System License Parameters** Web page opens as shown in the following figure.

**Figure 233**  
**System License Parameters Web page**

Managing: [192.167.102.3](#)  
 Tools » Logs and reports » System License Parameters

---


### System License Parameters

NAME	LIMIT	LEFT	USED
ANALOGUE TELEPHONES	32767	32767	0
CLASS TELEPHONES	32767	32767	0
DIGITAL TELEPHONES	32767	32767	0
DECT USERS	32767	32767	0
IP USERS	32767	32760	7
BASIC IP USERS	32767	32765	2
TEMPORARY IP USERS	32767	32767	0
DECT VISITOR USER	10000	10000	0
ACD AGENTS	32767	32762	5
PCA	32767	32762	5
ITG ISDN TRUNKS	32767	32767	0
H.323 ACCESS PORTS	32767	32757	10
AST	32767	32767	0
SIP CONVERGED DESKTOPS	32767	32765	2
SIP CTI TR87	32767	32767	0
SIP ACCESS PORTS	32767	32757	10
RAN CON	32767	32767	0
MUS CON	32767	32767	0
TNS	32767	32713	54
ACDN	24000	23998	2
AML	16	14	2
IDLE_SET_DISPLAY	CS1000E PIV Node 9		

### Operational Measurements

Element Manager provides users with regularly scheduled reports on system traffic. To access these reports, click the **Logs and Reports > Operational Measurements** link in the **Tools** branch of the Element Manager navigator. The **Call Server Operational Measurements Web page** opens, as shown in [Figure 234 "Operational Measurements Web page" \(page 341\)](#).

**Figure 234**  
**Operational Measurements Web page**



### Traffic Report Collection

To turn traffic report collection On or Off, click **Traffic Report Collection**. The **Traffic Report Collection** Web page opens, as shown in [Figure 235](#) "System Traffic Web page" (page 342).

**Figure 235**  
**System Traffic Web page**

<input type="checkbox"/> Report Title ▾	Report Number	Report Status
1 <input type="checkbox"/> Command status links and application module links	TFS008	Enabled
2 <input type="checkbox"/> D-Channel	TFS009	Enabled
3 <input type="checkbox"/> Dial tone delay	TFS003	Disabled
4 <input type="checkbox"/> ISDN BRI trunk DSL system report	TFS014	Disabled
5 <input type="checkbox"/> ISDN GF transport	TFS010	Disabled
6 <input type="checkbox"/> Junctor group	TFS007	Disabled
7 <input type="checkbox"/> Meridian packet handler	TFS015	Disabled
8 <input type="checkbox"/> Multi-purpose ISDN signaling processor DCH management	TFS012	Disabled
9 <input type="checkbox"/> Multi-purpose ISDN signaling processor messages	TFS013	Disabled
10 <input type="checkbox"/> Multi-purpose ISDN signaling processor traffic	TFS011	Disabled
11 <input type="checkbox"/> Network	TFS001	Disabled
12 <input type="checkbox"/> Processor load	TFS004	Disabled
13 <input type="checkbox"/> QoS IP statistics	TFS016	Disabled
14 <input type="checkbox"/> Selected terminals	TFS005	Disabled
15 <input type="checkbox"/> Service loops	TFS002	Disabled


To enable traffic report collection, select the **Traffic Report Collection** check box. The traffic report collection is enabled.

To disable traffic report collection, clear the **Traffic Report Collection** check box. The traffic report collection is disabled.

### System Traffic

To display details of the system's Traffic reports, click **System Traffic**. The **System Traffic** Web page opens, as shown in [Figure 236 "System Traffic Web page"](#) (page 343).

**Figure 236**  
**System Traffic Web page**



To display a report, click the **Report Title**. The report displays in a new window.

To enable a report, select the report and click **Enable**.

To disable a report, select the report and click **Disable**.

To configure Threshold information, click **Thresholds**. The **Thresholds** Web page is displayed.

To configure report schedules, click **Schedules**. The **Report Schedule** Web page is displayed.

### Customer Traffic

To display details of the Traffic reports for each Customer configured in the system, click **Customer Traffic**. The **Customer Traffic** Web page opens, as shown in [Figure 237 "Customer Traffic Web page" \(page 344\)](#).

**Figure 237**  
**Customer Traffic Web page**

Managing: 192.167.100.3  
 Tools > Logs and reports > Call Server Operational Measurements > Customer Traffic

**Customer Traffic**

Reports For Customer: 0

Enable Disable Thresholds Schedule Refresh

<input type="checkbox"/>	Report Title ▲	Report Number	Report Status
<input type="checkbox"/>	1 Call blocking due to lack of DSP resource	TFC012	Disabled
<input type="checkbox"/>	2 Call park	TFC007	Disabled
<input type="checkbox"/>	3 Customer console measurements	TFC003	Disabled
<input type="checkbox"/>	4 Feature key usage	TFC005	Disabled
<input type="checkbox"/>	5 Incoming trunk group measurements	TFN003	Disabled
<input type="checkbox"/>	6 Individual console measurement	TFC004	Disabled
<input type="checkbox"/>	7 ISPC links establishment	TFC105	Disabled
<input type="checkbox"/>	8 Messaging and auxiliary processor links	TFC008	Disabled
<input type="checkbox"/>	9 Network attendant service	TFC009	Disabled
<input type="checkbox"/>	10 Network class of service measurements	TFN002	Disabled
<input type="checkbox"/>	11 Networks	TFC001	Disabled
<input type="checkbox"/>	12 Radio paging	TFC006	Disabled
<input type="checkbox"/>	13 Route list measurements	TFN001	Disabled
<input type="checkbox"/>	14 Trunks	TFC002	Disabled
<input type="checkbox"/>	15 Use of broadcasting routes Set	TFC111	Disabled

To display Traffic reports for a Customer, select the Customer from the drop-down list.

To enable a report for the selected Customer, select the report and click **Enable**.

To disable a report for the selected Customer, select the report and click **Disable**.


To configure Threshold information for the selected Customer, click **Thresholds**. The **Thresholds** Web page is displayed.

To configure report schedules for the selected Customer, click **Schedules**. The **Report Schedule** Web page is displayed.

### Viewing historic traffic reports

To view the historic traffic reports of each System, Network or Customer, configured in the system, click the **Report Title** in one of the reports. The report is displayed.

**Figure 238**  
**Customer Traffic Web page**



To display Traffic reports for a Customer, select the Customer from the drop-down list.

To enable a report for the selected Customer, select the report and click **Enable**.

To disable a report for the selected Customer, select the report and click **Disable**.

To configure Threshold information for the selected Customer, click **Thresholds**. The **Thresholds** Web page is displayed.

To configure report schedules for the selected Customer, click **Schedules**. The **Report Schedule** Web page is displayed.

### Traffic Parameters

To configure Traffic Parameters for the system, click **Traffic Parameters**. The **Edit Traffic Parameters** Web page opens, as shown in [Figure 239 "Edit Traffic Parameters Web page"](#) (page 346).

**Figure 239**  
**Edit Traffic Parameters Web page**

Managing: [192.167.100.3](#)  
Tools > Logs and reports > [Call Server Operational Measurements](#) > Edit Traffic Parameters

### Edit Traffic Parameters

Line Load Control Level:  ▼  
Blocked group members cannot originate internal or trunk calls.

**Blocking Probabilities**

First:  \* (0 - 100 %)  
Second:  \* (0 - 100 %)  
Third:  \* (0 - 100 %)

Feature Key Customer:  ▼  
Customer which will run the feature key measurements report. Only 1 customer can run this report at a time.

Select a **Line Load Control Level** from the drop-down list.

Enter the **Blocking Probabilities**.

Choose a Customer from the **Feature Key Customer** drop-down list and click **Save**.

**Note:** If the **Line Load Control Level** is set to Off, the **Blocking Probabilities** are disabled.

### Quality of Service

Click **Quality of service** to open the **Ethernet Quality of Service Diagnostics** Web page. For more information, see [“Ethernet Quality of Service Diagnostics”](#) (page 82)


### Bandwidth Management

Click **Bandwidth Management** to open the **Maintenance Commands for Zones** Web page. For more information, see [“Zone Diagnostics”](#) (page 111)

### Individual Traffic Measurement


To configure lines and trunks for Individual Traffic Measurement, click **Individual Traffic Measurement**. The **Individual Traffic Measurement** Web page opens, as shown in [Figure 240 "Individual Traffic Measurement Web page"](#) (page 347).

**Figure 240**  
**Individual Traffic Measurement Web page**



To add a terminal for Individual Traffic Measurement, click **Add**. The **Add TN** Web page opens, as shown in [Figure 241 "Add TN Web page"](#) (page 347).

**Figure 241**  
**Add TN Web page**



Enter the TNs to be added in the **TN** text box. Enter up to five TNs and click **Save**.

**Note:** The TNs must be separated by a comma.

---

# Security

---

The following links are provided under the Security branch of Element Manager:

- Passwords
  - System Passwords
  - Customer Passwords
- Policies
  - Media
  - System Keys
  - File Transfer
  - Port Access Restrictions
- Login Options
  - Shell Login
  - Access Warning

All information about the Security features available in Element Manager is covered and maintained in *Security Management Fundamentals* (NN43001-604).



# Support

---

## Contents

This section contains information about the following topics:

[“Introduction” \(page 351\)](#)

[“Help” \(page 351\)](#)

[“Release Notes” \(page 352\)](#)

## Introduction


The following Support features can be accessed through Element Manager:

- [Help](#)
- [Release Notes](#)

## Help

Element Manager provides context-sensitive online Help. To access Help, click the **Help** link located in the top right corner of the Element Manager Web pages. The **Help** Web page shown in [Figure 242 "Help Web page" \(page 352\)](#) appears.

**Figure 242**  
**Help Web page**



## Release Notes

A Release Note can describe a design change or a product feature that was discovered after market release. Often, a Release Note describes how to work around a product limitation. Click the **Release Notes** link to access the Web-based Helmsman Express application.

---

## Appendix A

---

**WARNING**

Do *not* contact Red Hat for technical support on your Nortel version of the Linux base operating system. If technical support is required for the Nortel version of the Linux base operating system, contact Nortel technical support through your regular channels

This section governs the use of the Red Hat Software and any updates to the Red Hat Software, regardless of the delivery mechanism and is governed by the laws of the state of New York in the U.S.A. The Red Hat Software is a collective work under U.S. Copyright Law. Subject to the following terms, Red Hat, Inc. (“Red Hat”) grants to the user (“Customer”) a license to this collective work pursuant to the GNU General Public License. Red Hat Enterprise Linux (the “Red Hat Software”) is a modular operating system consisting of hundreds of software components. The end user license agreement for each component is located in the component’s source code. With the exception of certain image files identified below, the license terms for the components permit Customer to copy, modify, and redistribute the component, in both source code and binary code forms. This agreement does not limit Customer’s rights under, or grant Customer rights that supersede, the license terms of any particular component. The Red Hat Software and each of its components, including the source code, documentation, appearance, structure and organization are owned by Red Hat and others and are protected under copyright and other laws. Title to the Red Hat Software and any component, or to any copy, modification, or merged portion shall remain with the aforementioned, subject to the applicable license. The “Red Hat” trademark and the “Shadowman” logo are registered trademarks of Red Hat in the U.S. and other countries. This agreement does not permit Customer to distribute the Red Hat Software using Red Hat’s trademarks. If Customer makes a commercial redistribution of the Red Hat Software, unless a separate agreement with Red Hat is executed or other permission granted, then Customer must modify any files identified as “REDHAT-LOGOS” and “anaconda-images” to remove all images containing the “Red Hat” trademark or the “Shadowman” logo. As required by U.S. law, Customer represents and warrants that it: (a) understands that the Software is

subject to export controls under the U.S. Commerce Department's Export Administration Regulations ("EAR"); (b) is not located in a prohibited destination country under the EAR or U.S. sanctions regulations (currently Cuba, Iran, Iraq, Libya, North Korea, Sudan and Syria); (c) will not export, re-export, or transfer the Software to any prohibited destination, entity, or individual without the necessary export license(s) or authorizations(s) from the U.S. Government; (d) will not use or transfer the Red Hat Software for use in any sensitive nuclear, chemical or biological weapons, or missile technology end-uses unless authorized by the U.S. Government by regulation or specific license; (e) understands and agrees that if it is in the United States and exports or transfers the Software to eligible end users, it will, as required by EAR Section 740.17(e), submit semi-annual reports to the Commerce Department's Bureau of Industry & Security (BIS), which include the name and address (including country) of each transferee; and (f) understands that countries other than the United States may restrict the import, use, or export of encryption products and that it shall be solely responsible for compliance with any such import, use, or export restrictions. Red Hat may distribute third party software programs with the Red Hat Software that are not part of the Red Hat Software. These third party programs are subject to their own license terms. The license terms either accompany the programs or can be viewed at <http://www.redhat.com/licenses/>. If Customer does not agree to abide by the applicable license terms for such programs, then Customer may not install them. If Customer wishes to install the programs on more than one system or transfer the programs to another party, then Customer must contact the licensor of the programs. If any provision of this agreement is held to be unenforceable, that shall not affect the enforceability of the remaining provisions. Copyright © 2003 Red Hat, Inc. All rights reserved. "Red Hat" and the Red Hat "Shadowman" logo are registered trademarks of Red Hat, Inc. "Linux" is a registered trademark of Linus Torvalds. All other trademarks are the property of their respective owners.

---

# Index

---

**A**

ABCD Bit Signaling Category 259  
 ABKUP 204  
 ACOD 246  
 ADAN 257  
 Advanced Configurations 249  
 Advanced Trunk Configuration 252  
 ADVOPT 257  
 AML Diagnostics 46  
 ATLP 72  
 ATST 97

**B**

Background Signaling and Switching  
     diagnostics 49  
 Backup 309  
 Basic Rate Line Interface 259  
 Basic Rate Trunk Interface 259  
 Basic Route Options 247  
 BILN 247  
 Branch Office 166  
     Basic Property and Bandwidth  
         Management 166  
 BRSC 100  
 BSCOPT 257

**C**

Call Server 22, 29, 36, 42, 263, 267  
     backup 311  
     restore 311  
 Call Server Select by Functionality 42  
 Call Server Select by Overlay 43  
 Call Trace Diagnostics 50  
 cancel 29, 36  
 CDR 247  
 CDSP 60, 75, 87, 98, 104, 108, 111

Centralized Software Upgrade 53  
 CHG ZQNL 84  
 clock controller 56, 260  
 Clock Controller Diagnostic 56  
 CLR GR 61  
 CLS 252  
 CMAJ 60, 98, 104, 108  
 CMIN 60, 75, 87, 97, 104, 108, 111  
 CNTL 247  
 CNVT 247  
 Code Restriction Tree Number 268  
     common equipment 113  
     common equipment. 114  
     Conference loop numbers 114  
     configuration 29, 36, 246  
     Configuration Record 257  
     Coordinated Dialing Plan 264, 266  
     Core Common Equipment Diagnostics 57  
         Large System 57  
     Courtesy Change 301  
     CPED 104  
     customer 267, 270  
     Customers menu 21, 28  
     CUTOVR 60

**D**

D-channel 63  
 D-channel Diagnostics 63  
 D-Channel Expansion Diagnostics 66  
 D-channel Property Configuration 256  
 Database issue and creation date 312  
 delete 29  
 DES 246, 251  
 Diagnostic Commands 102  
 Dialing and Numbering Plans  
     menu 21, 28  
 Digit Conversion Tree Number 271

Digit Manipulation Block 264  
digit sequences 269  
Digital Trunk Card 70  
Digital Trunk Card Diagnostic 69  
Digital Trunk Interface 258–259, 261  
Digital Trunk Interface and Primary  
Rate Interface  
Clock Controller Diagnostics 56  
Digital Trunk Interface and Primary  
Rate Interface Diagnostic 56  
Digital Trunk Interface and Primary  
Rate Interface Diagnostics 69  
Digital Trunk Interface Data Block 258  
–259, 261  
Digital Trunk Interface Loop numbers 114  
Digital Trunk Maintenance Diagnostics 72  
Digital Trunk Route 71  
DIS 92, 106  
DIS AML 48  
DIS AUTO 64, 101  
DIS BRIE 102  
DIS BRIL 102  
DIS BRIT 102  
DIS CC 57  
DIS CNI 59  
DIS DCH 64  
DIS DDSC 73  
DIS DDSL 73  
DIS DTCS 73  
DIS DTRC 73  
DIS DTSL 73  
DIS DTVC 74  
DIS ELAN 48  
DIS LLB 64  
DIS LSSL 74  
DIS MSDL 68, 86  
DIS MSDL ALL 68  
DIS MSDL AUDM 68  
DIS MSDL DBG 68  
DIS PRT 86  
DIS RLB 64  
DIS TEST 64  
DIS TTY 85  
DIS ZBR 113  
DIS ZONE 113  
DISC 97, 99–101, 109  
DISC BRI 100  
DISI 70  
DISI DDSC 74  
DISI DTCS 74

DISL 70, 99, 104, 107  
DISL BRIE 100  
DISL BRIT 100  
DISN 100  
DISR 108  
DISS 99  
Distant Steering Code 266  
DISU 97, 100–101, 110  
DISX 107  
DSCH 71  
DSPL 59  
DSPL ALL 59  
DSPS 100  
DSRB 101  
DSXP 100  
DSYL 70  
DTR 108

## E

Echo Servers for NAT 176  
EDD 311  
Electronic Switched Network 263  
Access Codes and Parameters 264  
ENCH 70–71  
ENCK 57  
ENL 92, 106  
ENL AML 48  
ENL AUTO 65, 101  
ENL BRIL 102  
ENL BRIT 102  
ENL CC 57  
ENL CNI 59  
ENL DCH 65  
ENL DDSC 74  
ENL DDSL 74  
ENL DTCS 74  
ENL DTRC 74  
ENL DTSL 74  
ENL DTVC 74  
ENL ELAN 49  
ENL EXT 59  
ENL LLB 65  
ENL LSSL 74  
ENL MSDL 68, 86  
ENL MSDL all 68  
ENL MSDL AUDM 68  
ENL MSDL FDL 68  
ENL PRT 86  
ENL RLB 65  
ENL TEST 65

ENL TTY 85  
 ENL ZBR 113  
 ENL ZONE 113  
 ENLC 97, 109  
 ENLC BRI 100  
 ENLL 70, 99, 104, 108  
 ENLL BRIL 99, 102  
 ENLL BRIT 99  
 ENLN 100  
 ENLR 108  
 ENLS 99  
 ENLU 110  
 ENLX 108  
 ENPS 100  
 ENRB 101  
 ENXP 100  
 ENYL 70  
 Equipment Data Dump 311  
 EST AML 47  
 EST DCH 66  
 Ethernet and Alarm Management 41,  
 166, 169, 176  
 Ethernet Diagnostics 77  
 Ethernet Quality of Service Diagnostic Exchange (Central Office) Code 82 266

## F

FDIS NCAL 101  
 FDLC 101  
 FDLU 101  
 Feature Packages 114  
 file upload 211  
 firmware 211  
 Flexible Code Restriction 266–267, 272  
 Flexible Feature Code Entries 227  
 Flexible Feature Codes (FFC) 226  
 Force Download 93  
 Free Calling Area Screening 266  
 Free Special Number Screening 266  
 FSUM 101  
 FWVU 101

## G

General Commands 140–141  
 General Options 249  
 Geographic Redundancy 203

## H

Help 351

Home Area Code 266  
 Home Location Code 266  
 Home menu 27

## I

ICOG 246  
 IDC 99–101, 247  
 IDC CNI 59  
 IDC CPU 59  
 IDCS 100  
 INC 252  
 Incoming Digit Conversion 269, 272  
 Incoming Trunk Group Exclusion 264  
 Input/Output Diagnostics 84  
 IP Line 22–23, 141  
 IP Line application commands 141  
 IP Network 129  
 IP Network menu 21  
 IP Phones 211  
 IP telephony 140, 145  
 IP Telephony 140  
 IP Telephony card 129  
 IP Telephony Information 140  
 IP Telephony Nodes 129

## J

JOIN 60

## L

LBSY 99  
 LCNT 70  
 LD 02 322  
 LD 117 41, 78, 83, 112, 166,  
 169–170, 176  
 LD 15 - Customer Data Block 217  
 LD 16 245  
 LD 17 257  
 LD 30 103  
 LD 32 98  
 LD 36 61, 64, 109, 112  
 LD 37 64, 85  
 LD 43 311  
 LD 48 64, 67  
 LD 49 272  
 LD 54 96  
 LD 73 261  
 LD 86 263, 265  
 LD 87 263, 265–266  
 LD 90 263, 266

LD 96 64, 106–107, 109  
 LD 97 116, 205  
 LDIC 110  
 LDID 110  
 LDIS 99, 104  
 LENL 104  
 LIDL 99  
 Link Diagnostic 67  
 Links menu 21, 27  
 LMAX 110  
 LMNT 99  
 LNDS 110  
 Local Steering Code 266  
 Location Code 266  
 log in 25  
 Logging into Element Manager 25  
 LOOP 104  
 Loop Timer 258  
 Loss and Level Plan 22  
 LOVF 71, 110

## M

maintenance 83–84  
 Maintenance Commands for Zones 111  
 MAP AML 47  
 MAP DCH 66  
 Media Gateway 1000B 22  
 Member Property Configuration  
   advanced 252  
   basic 251  
 MFR 108  
 MIDN 97  
 MISP 99  
 Mobile Service Directory Numbers 233  
 MSDL 67  
 MSDL Diagnostics 91  
 MTST 97  
 Multi-Del 253  
 Multifrequency Signaling Diagnostics 96

## N

NAT 175  
 NAT Echo Servers 176  
 NAT session time-out value 176  
 navigation tree 26  
 Network Address Translation (NAT) 175  
 Network and Peripheral Equipment  
   Diagnostic 98

Network and Peripheral Equipment  
   Diagnostics 98  
 Network and Signaling Diagnostics 103  
 Network Attendant Services 264  
 Network Control and Services 264  
 Network Control Parameters 264  
 Network Loop 99  
 Network Numbering Plan 263  
 Network Options 248  
 Network Speed Call Access Code 266  
 Node ID 140  
 nodes  
   add new 131  
   delete - delete a node 131  
   export node 131  
   import files 131  
 NRS Manager 263  
 Numbering Plan 264, 266  
 Numbering Plan Area Code 266

## O

online Help 351  
 Operational Measurement Report 140  
 Operational Measurements Report 145

## P

PAD Category 259  
 Patch Bin 214  
 PCON 101  
 PERR 101  
 PERR BRIE 102  
 PERR BRIL 102  
 PERR BRIT 102  
 Personal Directory, Redial List, Callers  
   List 179  
 ping an IP address 143  
 PINS 213  
 PLIS 213  
 PLOG 101  
 PMES 101  
 PNNC 247  
 POOS 213  
 POUT 213  
 Primary Rate Interface 258–259  
 PRT AQOS 83  
 PRT DNIP 80–81  
 PRT IPDN 80–81  
 PRT IPMG 80  
 PRT IPR 80

PRT ZBW 113  
 PRT ZDES 113  
 PRT ZDP 113  
 PRT ZONE 112  
 PRT ZQNL 84  
 PRT ZQOS 83  
 PRT ZTP 113  
 PSTAT 213  
 PTAB 101

## Q

QoS 22, 176  
 QoS Call Basis Threshold Parameters 178  
 QoS Zone Basis Threshold  
   Parameters 178  
 Quality of Service 178  
 Quality of Service (QOS) 22  
 Quality of Service Thresholds 176

## R

RAN 110  
 RCNT 70  
 Report Utility 140, 143  
 RES 106  
 reset element 140  
 Restore from Backup Data 312  
 RLS AML 47  
 RLS DCH 66  
 ROUT 246  
 route 245–246  
 Route Data Block 245  
 Route List Block 264  
 Route Properties 245  
 Routes and Trunks menu 28  
 RPED 104  
 RSET 110  
 RST 92  
 RST DCH 66  
 RST MSDL 67, 86  
 RTMB 251

## S

SCPU 60  
 SDCH DCH 66  
 SDTR 108  
 Security menu 28  
 SHLF 104  
 SIGL 251  
 Signaling Server 21, 129, 140, 143

Simple Network Management  
   Protocol 22, 40  
 Simple Network Time Protocol (SNTP) 22  
 SLFT 70–71, 92, 104, 106  
 SLFT AML 47  
 SLFT MSDL 67, 86  
 SNMP 22, 40  
 SNTP 22  
 software upgrade 129  
 Special Number 266  
 SPLIT 60  
 SSSK 57  
 STAT 70, 87, 92, 96–97, 99–100, 104,  
   106–107, 109  
 STAT AML 47  
 STAT CNI 58  
 STAT CPU 58  
 STAT DCH 64  
 STAT DDCS 73  
 STAT DDSL 73  
 STAT DTCS 73  
 STAT DTRC 73  
 STAT DTSL 73  
 STAT DTVC 73  
 STAT ELAN 47  
 STAT GR 61  
 STAT HEALTH 61  
 STAT HEALTH AML 61  
 STAT HEALTH ELAN 61  
 STAT HEALTH HELP 60  
 STAT HEALTH HW 61  
 STAT HEALTH IPL 61  
 STAT LINK 87  
 STAT LINK IP 78  
 STAT LINK NAME 78  
 STAT LINK NODE 78  
 STAT LINK SRV 78  
 STAT LSRC 73  
 STAT LSSL 73  
 STAT L SVC 73  
 STAT MEM 58  
 STAT MSDL 67, 86  
 STAT MSDL full 67  
 STAT NCAL 101  
 STAT NEXT 58  
 STAT NWK 100  
 STAT PER 100  
 STAT PRT 86  
 STAT SERV 64, 79  
 STAT SERV APP 79

- STAT SERV IP 79
  - STAT SERV NAME 79
  - STAT SERV NODE 79
  - STAT SERV TYPE 79
  - STAT TTY 85
  - STAT VTRM 100
  - STAT XSM 87
  - STAT ZBR 113
  - STAT ZONE 113
  - State Control 205
  - STIP HOSTID 80
  - STIP NODE 79
  - STIP TERMIP 80
  - STIP TN 79
  - STIP TYPE 79
  - STIP ZONE 79
  - STRI 251
  - STRO 251
  - STRT 75
  - submit 29, 36
  - Superloop 116
  - SUPL 99
  - System Date and Time 322, 325
  - System Information Web page 26
  - System menu 27
  - System Status 36
  - System Timer 258
  - System Utility 309
- T**
- TDS 108
  - TEIT 104
  - Template 19
  - Templates 28, 278
  - Terminal Session
    - add 32
  - TEST 50
  - TEST 100 65
  - TEST 101 65
  - TEST 200 65
  - TEST 201 65
  - TEST CNI 59
  - TEST CPU 59
  - TEST GR 61
  - TEST IPB 59
  - TEST LCD 60
  - TEST LED 60
  - TEST SUTL 60
  - Threshold Set Block 260
  - Threshold Set Index 260
  - Threshold Set Index, adding 260
  - Threshold Set Index, editing 260
  - time-out 26
  - TKTP 246
  - TMDI Diagnostics 105
  - Tone and Digit Switch Diagnostics 106
  - Tone and Digit Switch numbers 114
  - Tools menu 21, 28
  - TRAC 52
  - TRAT 53
  - TRCK 57
  - TRIP 53
  - trunk 245–246, 250, 253–254
  - Trunk Diagnostic 109
  - Trunk Diagnostics 108
  - Trunk Steering Code 266
  - TTPM 110
  - TTSM 104
  - TTWI 104
- U**
- UNTT 104
  - update 29, 36
  - UPLD AML 48
- V**
- Virtual Terminal 140
  - Virtual Terminal Sessions 31
  - Voice Gateway Media Card 22–23
- X**
- XNTT 99
  - XPCT 100
  - XPEC 100
  - XRST 99
  - XTRK 251
- Z**
- Zone 164
    - Basic Property and Bandwidth Management 166
    - Branch Office Dialing Plan and Access Codes 166
    - Branch Office Time Difference and Daylight Saving Time Property 166, 169
    - Dialing Plan and Access Codes 169

Time Difference and Daylight Saving  
Time Property 169  
Zone Diagnostic 57  
Zone Diagnostics 111





Nortel Communication Server 1000

## Element Manager System Reference - Administration

Release: 6.0

Publication: NN43001-632

Document revision: 03.20

Document release date: 23 March 2010

Copyright © 2010 Nortel Networks. All Rights Reserved.

While the information in this document is believed to be accurate and reliable, except as otherwise expressly agreed to in writing NORTEL PROVIDES THIS DOCUMENT "AS IS" WITHOUT WARRANTY OR CONDITION OF ANY KIND, EITHER EXPRESS OR IMPLIED. The information and/or products described in this document are subject to change without notice.

Nortel, Nortel Networks, the Nortel logo, and the Globemark are trademarks of Nortel Networks.

All other trademarks are the property of their respective owners.

To provide feedback or to report a problem in this document, go to [www.nortel.com/documentfeedback](http://www.nortel.com/documentfeedback).

[www.nortel.com](http://www.nortel.com)

