




2003 Jeep Grand Cherokee Serpentine Belt Replacement

Replace your old serpentine belt with a new one by looking at the old belt routing diagram under the car hood.

Written By: Balaqeel



INTRODUCTION

The serpentine belt is a long, winding, snaking belt that keeps your air conditioning, alternator, and power steering pump running smoothly and effectively. You need to check your serpentine belt every 50,000 to 60,000 miles. If you see cracks on your belt or you noticed any one of these (loss of power steering, squealing noise, the engine overheating, or the belt looks bad) that means it's time to replace your old belt.



TOOLS:

- [Socket Wrench](#) (1)
- [Socket Set](#) (1)

PARTS:

- [Serpentine Belt](#) (1)

Step 1 — Serpentine Belt



- Take a look at the belt routing diagram under the hood. If you didn't find it you can find a picture on the internet or draw one before beginning.

Step 2



- look carefully at how the old belt wraps around the pulleys, so you can replace the new one by practicing and matching the routing.
- A/C Pulley
- Tensioner
- Idler Pulley
- Crankshaft Pulley
- Power Steering Pump Pulley
- Generator Pulley
- Water Pump Pulley

Step 3



- Now, use your 16 mm wrench to reduce the belt tension and get it off.
- Put the socket wrench on the tensioner (Right your belt tensioner, the little square or cave).
- ⓘ Move the wrench clockwise to relieve tension from your belt tensioner.

Step 4




- Remove the old belt and make sure to put the new belt that doesn't have any cracks and looks smooth.
- ⚠ Before installing the new belt check the tensioner pulley for wear by using your hand to spin it.

Step 5



- Install the new belt by lining up all belt ribs in the pulley grooves and wrap it around.
- Start with the A/C Pulley and then wrap it around the tensioner and move on until you end up with the water pump pulley.
- ⓘ When you ready to put the belt back on the alternator, reduce the tension on the belt by using the socket wrench and then slip the belt right over the top.

Step 6



- Make sure at the end to tighten the tensioner and start your car to make sure it's work!
- ⓘ To adjust the tension, loosen the nut with a ratchet, so you can tighten the belt as required.

To reassemble your device, follow these instructions in reverse order.