




MacBook Pro 15" Core 2 Duo Models A1226 and A1260 Bluetooth Board Replacement

Written By: Walter Galan



INTRODUCTION

No signal to Bluetooth? Replace the antenna.



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [Spudger](#) (1)
- [T6 Torx Screwdriver](#) (1)



PARTS:

- [MacBook Pro 15" \(Models A1211/A1226\) Bluetooth Board](#) (1)
- [MacBook Pro 15" \(Models A1211/A1226/A1260\) Bluetooth Cable](#) (1)
- [MacBook Pro 15" \(Model A1260\) Bluetooth Board](#) (1)

Step 1 — Battery



- Use your fingers to push both battery release tabs away from the battery, and lift the battery out of the computer.

Step 2 — RAM Shield



- Remove the three identical 2mm PH000 Phillips screws from the memory door.
- Lift the memory door up enough to grip it and slide it toward you, pulling it away from the casing.

Step 3 — Upper Case



- Remove the two 2.8 mm Phillips screws in the battery compartment near the latch.

Step 4



- Remove the following 6 screws:
 - Two 10 mm T6 Torx screws on either side of the RAM slot.
 - Four 14.5 mm Phillips screws along the hinge.

Step 5



- Remove the four 3.2 mm PH00 Phillips screws on the port side of the computer.

Step 6



- Rotate the computer 90 degrees and remove the two 3.2 mm Phillips screws from the rear of the computer.

Step 7



- Rotate the computer 90 degrees again and remove the four 3.2 mm Phillips screws from the side of the computer.


Step 8



- i** Do not yank the upper case off quickly. The case is attached to the logic board via a ribbon cable.


 - Lift up at the rear of the case and work your fingers along the sides, freeing the case as you go. Once you have freed the sides, you may need to rock the case up and down to free the front of the upper case.
 - There are four plastic clips above the DVD slot, and another above and to the left of the IR sensor. These clips can be very difficult to disengage without prying. They can also be difficult to re-engage during reassembly.
- ★ Reassembly Tip:** Press down firmly on the tip of the top case above the location of each clip until you hear a *snap* to reseat them in their slots.
- ★ Reassembly Tip:** The two center DVD clips will rarely snap back into place properly without help, and downward pressure will instead simply deform the frame around the DVD slot. Support the frame by inserting a plastic spudger into the DVD slot directly under the clip location until it is snug, then press down until you hear the *snap*.

Step 9




- Disconnect the trackpad and keyboard ribbon cable from the logic board, removing tape as necessary.
- ⓘ Note: It is possible to replace the hard drive without disconnecting the keyboard from the chassis, but it will need to be held upright to keep it out of the way, while still allowing you both hands to work on the drive removal.
- ⓘ Be careful when removing the keyboard-trackpad ribbon cable to ensure that the rear of the upper case is disengaged from the area near the hinge. It is easy to accidentally bend the screw receivers on either side of the keyboard.
- Remove the upper case.

Step 10 — Bluetooth Board




- ⓘ The Bluetooth board is located underneath the upper case.
- Disconnect the Bluetooth antenna cable from the Bluetooth board.

Step 11




- Remove the single Phillips screw securing the Bluetooth board to the upper case.

Step 12



- Peel up the Bluetooth data cable from the adhesive on the upper case, removing tape as necessary.

Step 13



- Disconnect the Bluetooth data cable from the upper case.
- Lift the Bluetooth board and attached cable off the upper case.

To reassemble your device, follow these instructions in reverse order.