

DIMENSION[®] PBX
CSS-201L
WRAP-UP

CONTENTS

1. GENERAL
2. EQUIPMENT
3. CROSS CONNECT FIELD ENCLOSURES

4. CABINET SIDE COVERS AND REAR PANELS
5. DOOR MOUNTING AND FINAL CHECKS

1. GENERAL

1.1 This section provides information to add panels and doors to the system and complete the job.

2. EQUIPMENT

216 Type Tool
Screwdriver

3. CROSS CONNECT FIELD ENCLOSURES

- 3.1 If cross connect field enclosures were installed, locate doors and hinge pins.
- 3.2 Hang and align doors as required to cover cross connect field enclosures.
- 3.3 Close doors and insure that magnetic latch holds door closed.
- 3.4 Installation of the cross connect field enclosure is now complete.

4. CABINET SIDE COVERS AND REAR PANELS

- 4.1 Locate and mount the side covers. Secure with the captive screws. Repeat for all other cabinets.
- 4.2 Locate rear panels for each cabinet and verify that cable knockout on the right side facing the rear has been removed. Remove, if it has not already been done.
- 4.3 Locate sponge protector and peel off white paper.
- 4.4 Carefully align rear panel and insure that the cable exists cabinet at knockout. Place sponge between the cable and the rear panel knockout with the adhesive side toward the rear panel.

4.5 Add and secure screws to mount the rear panel. Be especially careful to avoid pinching any of the cable when the screws are tightened.

4.6 Repeat PARS. 4.2 to 4.5 for other cabinets as required.

4.7 Position all of the cabinets into permanent position as specified on the Telephone Company's floor plan. Roll cabinets on to floor rail until locked in position.

4.8 If rollaway assembly is provided, unlatch and store it under the cabinet.

5. DOOR MOUNTING AND FINAL CHECKS

5.1 Locate and mount the front door assembly on each cabinet. Be especially careful not to scratch or deface the front door surface.

5.2 Check alarm panel and verify that all alarm lamps are extinguished and the PASS (Green) light is blinking. Clear all alarm indications if any alarm lamps are lighted.

5.3 Unplug MAAP and verify that the tape cartridge(s) in transport assembly have returned to the park position. (This is the beginning of the tape and the majority of the tape is on the right spool.)

5.4 Store MAAP in the area provided in the Common Control Cabinet.

5.5 Verify that the spare tape(s) cartridge is stored under the tape transport assembly.

PRIVATE

THE INFORMATION CONTAINED HEREIN SHOULD NOT BE DISCLOSED TO UNAUTHORIZED PERSONS. IT IS MEANT SOLELY FOR USE BY AUTHORIZED BELL SYSTEM EMPLOYEES. Printed in U.S.A.

5.6 Place SD's, CD's, Customer Order Document, etc., in the front door storage racks.

5.7 Close all cabinet doors. Use 216 Type tool to lock the door and front casters of each cabinet.

5.8 Now that you have completed all tests prescribed in this handbook and Handbook 282, the system is ready to be turned over to the Telephone Company.

5.9 Another DIMENSION PBX is ready to provide efficient and exotic service to our customers.

Manager, Denver PBX PECC