

SPLICING DROP & BLOCK WIRING

1. General

1.001 This addendum supplements Section
462-200-200, Issue 5, June 1975.

1.002 This addendum is issued to announce
the 3M UDW Connector and the AMP^R Mini
Drop Wire Splice as a company standard.

The following change applies to part 1
of the Section.

1.03 Change this Paragraph to read:
Observe the following rules when
splicing insulated drop and block wires.

Splice tracer conductor to tracer
conductor and plain conductor to plain
conductor.

When splice is to be placed in a wire
span, or under tension, use the AMP^R
Mini Drop Wire Splice.

When splice is to be placed in a wire
run, or not under tension use the 3M
UDW Connector.

3. Splicing Drop to Drop Wire

The following change applies to part 3
of the Section.

Delete paragraph 3.01.