

URGENT INSTRUCTION SUPPLEMENT  
PREPARATION OF CABLE RUNS

1. GENERAL

1.1 The purpose of this UIS is to update the information in Section 131 on the running of 'P' wire on the cable racks.

2. INSTRUCTIONS

2.1 Add Paragraph 3.638 to Section 131. Paragraph 3.638 to read as follows:

3.6.3.8 When running 'P' wire, the R-4397 cable guide can be used, but a piece of vinyl sheathing should be slipped over the rollers. This is to keep the conductors from being skinned or nicked by the rollers. An easier method is to use nylon ties loosely looped and positioned on the cable rack as to retain the 'P' wire on the rack and at the bends, see Figure 16. After the 'P' wire is run, the nylon ties must be removed and the 'P' wire banded as per Section 300.

Engineering Planning Manager  
(Installation)

NOTICE

Not for use or disclosure outside  
Western Electric except under written agreement. Printed in U.S.A.