

OPEN WIRE
STRINGING WIRE FROM MOVING REELS
JOINTLY USED LINES AND
POWER CROSSINGS

NOTES CONCERNING THIS ADDENDUM

This addendum supplements Section G31. 114. 3 and has been issued to include additional requirements for the wearing of rubber gloves when working on wires exposed to higher voltage power circuits and to delete a reference to a type of crossarm not used in this area.

The cross-reference, "See Addendum", should be written at Paragraphs 1.04 and 2.03 which are supplemented.

1. GENERAL

- 1.04 Note: Rubber gloves must be worn by all workmen making any connection between wires exposed to higher voltage power circuits (over 2900 volts to ground or over 5000 volts between wires).

2. JOINTLY USED LINES

- 2.03 Change the reference to "DE crossarm" to read "dead-end crossarm".