



How to replace Huawei Mate 9 Charging Board

This video shows you how to replace huawei mate 9 charging PBC board.

Written By: Witrigs



INTRODUCTION

[video: <https://www.youtube.com/watch?v=4avHFWjsz4k>]

If your huawei mate 9 can not be charged or connected to your computer, you should change its charging port.



TOOLS:

- [Spudger](#) (1)
- [T3 Torx Screwdriver](#) (1)
- [Phillips #0 Screwdriver](#) (1)
- [Suction Handle](#) (1)



PARTS:

- [huawei mate 9 charging port](#) (1)

To reassemble your device, follow these instructions in reverse order.