



Motorola Moto X 2nd Generation Power and Volume flex cable Replacement

Written By: Sophia



 **TOOLS:**

- [T3 Torx Screwdriver](#) (1)
 - [iFixit Opening Picks set of 6](#) (1)
 - [Motorola Eject pin](#) (1)
 - [Spudger](#) (1)
 - [Tweezers](#) (1)
-

Step 1 — Power and Volume flex cable



- Remove SIM card tray.

Step 2



- Remove back cover.

Step 3



- Remove those two rubber cover.

Step 4



- Release power connecting flex connector and battery connector.

Step 5



- Twist off all 18 black torx screws and remove the middle housing from front assembly.

Step 6



- Release power flex connector from connecting flex.

Step 7



- Remove securing bracket and side buttons.

Step 8



- Pry up and remove the power flex.

To reassemble your device, follow these instructions in reverse order.