



iMac Intel 27" EMC 2546 Hard Drive Posts

Prereq only

Written By: Andrew Optimus Goldheart



INTRODUCTION

Prereq only

TOOLS:

- [iMac Opening Tool](#) (1)
- [Plastic Cards](#) (1)
- [Spudger](#) (1)
- [iMac Service Wedge](#) (1)
- [T10 Torx Screwdriver](#) (1)
- [T8 Torx Screwdriver](#) (1)

PARTS:

- [iMac Intel 27" Late 2012-Mid 2017 SSD Upgrade Bundle](#) (1)
- [OWC In-line Digital Thermal Sensor for 3rd party SATA HDD or SSD Upgrade for 27" iMacs 2012 and later models](#) (1)
- [iMac Intel 27" \(2012-2017\) Adhesive Strips](#) (1)

Step 1 — Hard Drive



- Remove the four 8.1 mm T8 screw posts from the hard drive, and transfer them to the replacement drive enclosure.

To reassemble your device, follow these instructions in reverse and use our [Adhesive Strips Guide](#) to reattach the display glass.