

Language: English
 Final size: 52.5mm x 147mm closed, 105mm x 147mm open
 Format: 4 panel fanfold
 Stock:
 Ink:
 Fonts supplied:
 Film:
 Author & coordinator:
 Design & production:

Panel 2, Inside front cover		Panel 3, Inside back cover																																											
<p>Modifying your Telephone Book:</p> <table border="1"> <tr> <td>Add</td> <td>Options, <New>, OK, enter number, OK, enter name, OK, Esc</td> </tr> <tr> <td>Edit</td> <td><tel. entry>, Options, <Edit>, OK, edit number, OK, edit name, OK, Esc</td> </tr> <tr> <td>Delete</td> <td><tel. entry>, Options, <Delete>, OK, Esc</td> </tr> </table> <p>Adjusting the ringer settings:</p> <table border="1"> <tr> <td>Ringer melody</td> <td>Menu, <Ringer Settings>, OK, <Melody>, OK OK, 1...60, OK, Esc</td> </tr> <tr> <td>Ringer volume</td> <td>Menu, <Volume Settings>, OK OK (or 1...8), OK, Esc</td> </tr> <tr> <td>Buzzer off/on</td> <td>Menu</td> </tr> <tr> <td>Mute incoming call</td> <td>Silence</td> </tr> </table> <p>Legend <option> Angle brackets require you to use the arrow keys () to select the given option. <tel. entry> Use the arrow keys to scroll and select a telephone number or name.</p>		Add	Options, <New>, OK, enter number, OK, enter name, OK, Esc	Edit	<tel. entry>, Options, <Edit>, OK, edit number, OK, edit name, OK, Esc	Delete	<tel. entry>, Options, <Delete>, OK, Esc	Ringer melody	Menu, <Ringer Settings>, OK, <Melody>, OK OK, 1...60, OK, Esc	Ringer volume	Menu, <Volume Settings>, OK OK (or 1...8), OK, Esc	Buzzer off/on	Menu	Mute incoming call	Silence	<p style="text-align: center;">Fold</p> <table border="1"> <tr> <td>Handset on</td> <td></td> </tr> <tr> <td>Handset off</td> <td>for longer than 3 seconds</td> </tr> <tr> <td>Keypad lock</td> <td>Menu <Key Lock>, OK or Menu</td> </tr> <tr> <td>Keypad unlock</td> <td></td> </tr> <tr> <td>Mute/unmute</td> <td>/</td> </tr> </table> <p>Making a call:</p> <table border="1"> <tr> <td>Off-hook</td> <td>enter number</td> </tr> <tr> <td>On-hook</td> <td>Enter number</td> </tr> <tr> <td>Telephone Book</td> <td><tel. entry></td> </tr> <tr> <td>Redial List</td> <td><tel. entry></td> </tr> <tr> <td>Caller List</td> <td><Caller List>, OK, <tel. entry></td> </tr> <tr> <td>Call Transfer</td> <td>dial number</td> </tr> <tr> <td>Answer call</td> <td></td> </tr> <tr> <td>Mandown off/on</td> <td>Menu</td> </tr> <tr> <td>Terminate call</td> <td></td> </tr> </table> <p style="text-align: center;">Fold</p>		Handset on		Handset off	for longer than 3 seconds	Keypad lock	Menu <Key Lock>, OK or Menu	Keypad unlock		Mute/unmute	/	Off-hook	enter number	On-hook	Enter number	Telephone Book	<tel. entry>	Redial List	<tel. entry>	Caller List	<Caller List>, OK, <tel. entry>	Call Transfer	dial number	Answer call		Mandown off/on	Menu	Terminate call	
Add	Options, <New>, OK, enter number, OK, enter name, OK, Esc																																												
Edit	<tel. entry>, Options, <Edit>, OK, edit number, OK, edit name, OK, Esc																																												
Delete	<tel. entry>, Options, <Delete>, OK, Esc																																												
Ringer melody	Menu, <Ringer Settings>, OK, <Melody>, OK OK, 1...60, OK, Esc																																												
Ringer volume	Menu, <Volume Settings>, OK OK (or 1...8), OK, Esc																																												
Buzzer off/on	Menu																																												
Mute incoming call	Silence																																												
Handset on																																													
Handset off	for longer than 3 seconds																																												
Keypad lock	Menu <Key Lock>, OK or Menu																																												
Keypad unlock																																													
Mute/unmute	/																																												
Off-hook	enter number																																												
On-hook	Enter number																																												
Telephone Book	<tel. entry>																																												
Redial List	<tel. entry>																																												
Caller List	<Caller List>, OK, <tel. entry>																																												
Call Transfer	dial number																																												
Answer call																																													
Mandown off/on	Menu																																												
Terminate call																																													
<p>Nortel DECT Handset 4065R information For details on the features of this handset, refer to the Nortel DECT Handset 4065R User Guide.</p> <p>Safety information Do not rely on a cordless handset in emergencies.</p> <p>Never use your handset in:</p> <ul style="list-style-type: none"> the vicinity of electrical detonators. shielded rooms. areas where radio transmission is forbidden. aircraft. <p>Do not place your handset near:</p> <ul style="list-style-type: none"> water, moisture, or damp areas. heat sources, direct sunlight, or unventilated areas. devices that generate strong magnetic fields. areas with excessive dust, shock, or temperature. <p>Copyright © Nortel Networks Limited 2007. All rights reserved. Document Number: NN43120-107 Document Release: Standard 01.01 Date: December 2007 * Nortel, the Nortel logo, and the Globemark are trademarks of Nortel Networks.</p>		<p style="text-align: center;">Fold</p> <p style="text-align: center;">DECT Handset 4065R Quick Reference Card</p> <p style="text-align: center;">To provide feedback or report a problem in this document, go to www.nortel.com/documentfeedback.</p> <p style="text-align: center;">NORTEL</p>																																											
Panel 4, back cover		Panel 1, front cover																																											
		Fold																																											