



# Cisco XRV9000

## IOS-XR Release 7.7.2

### IOS-XR System Upgrade/Downgrade Procedure



**Americas Headquarters**  
Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
[www.cisco.com](http://www.cisco.com)  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883

**Asia Pacific Headquarters**  
Cisco Systems, Inc.  
168 Robinson Road  
#28-01 Capital Tower  
Singapore 068912  
[www.cisco.com](http://www.cisco.com)  
Tel: +65 6317 7777  
Fax: +65 6317 7799

**Europe Headquarters**  
Cisco Systems International BV  
Haarlerbergpark  
Haarlerbergweg 13-19  
1101 CH Amsterdam  
The Netherlands  
[www-europe.cisco.com](http://www-europe.cisco.com)  
Tel: +31 0 800 020 0791  
Fax: +31 0 20 357 1100

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).

Cisco Systems, Inc. All rights reserved. CCVP, the Cisco logo, and the Cisco Square Bridge logo are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn is a service mark of Cisco Systems, Inc.; and Access Registrar, Aironet, BPX, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Fast Step, Follow Me Browsing, FormShare, GigaDrive, GigaStack, HomeLink, Internet Quotient, IOS, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, iQuick Study, LightStream, Linksys, MeetingPlace, MGX, Networking Academy, Network Registrar, Packet, PIX, ProConnect, RateMUX, ScriptShare, SlideCast, SMARTnet, StackWise, The Fastest Way to Increase Your Internet Quotient, and TransPath are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0609R)

# Contents

---

Purpose, Scope and Audience .....	3
Obtain Required Package Files .....	3
Configuration Backup .....	3
Pre-Upgrade Tasks .....	4
Software Upgrade .....	5
Classic Method .....	5
Post-Upgrade Tasks .....	7
Caveats .....	7
Classic Method .....	7
Post-Downgrade Tasks .....	9
Caveats .....	9

## **Purpose, Scope and Audience**

This document provides information on the two methods Classic and GISO methods available for system upgrade and downgrade for XRV9000 Series platforms from software version 7.2.2/7.3.3/7.4.2 to 7.7.2 and vice versa.



**Note**

This document covers NGXR to NGXR upgrade procedure only.

Platform	From	To
XRV9000	7.2.2/7.3.3/7.4.2	7.7.2
XRV9000	7.7.2	7.2.2/7.3.3/7.4.2

Cisco Software Manager (CSM) can be used to manage Image, SMUs and SPs. It can help create your own SMU tar ball or find out which SMUs/SPs are applicable to your network. More information on CSM:

[CSM Download page](#)

[User Documentation](#)

It's highly recommended that CSM be used to come up with a list of optimized set of SMUs or Service Packs that should be installed on the release that is going to be deployed. SMUs/SP + Major release can be installed together in one install operation to save time and avoid multiple reloads.

However, in the absence of CSM, the MOP (Method of Procedure) described in this document can be followed for software upgrade of XRV9000 series routers.

## **Obtain Required Package Files**

Mini ISO Package is mandatory to perform the System Upgrade and upgrade needs to be done from XR VM. Additional XR packages listed below are needed depending on the router configuration and required features:

Description	Package Name
Boot Image	xrv9k-fullk9-x-7.7.2.iso
mpls	xrv9k-mpls-2.1.0.0-r772.x86_64.rpm
mpls-rsvp-te	xrv9k-mpls-te-rsvp-3.1.0.0-r772.x86_64.rpm
multicast	xrv9k-mcast-3.1.0.0-r772.x86_64.rpm
ospf	xrv9k-ospf-2.0.0.0-r772.x86_64.rpm
isis	xrv9k-isis-2.1.0.0-r772.x86_64.rpm
li	xrv9k-li-x-1.1.0.0-r772.x86_64.rpm
eigrp	xrv9k-eigrp-1.0.0.0-r772.x86_64.rpm
m2m	xrv9k-m2m-2.0.0.0-r772.x86_64.rpm
mgbl	xrv9k-mgbl-3.0.0.0-r772.x86_64.rpm
k9sec	xrv9k-k9sec-3.2.0.0-r772.x86_64.rpm

## **Configuration Backup**

- Copy the running-configuration to a harddisk on the router.

```
RP/0/RP0/CPU0:XR9000# copy running-config harddisk:/running_config
```

- Copy the running-configuration to a remote scp server

```
RP/0/RP0/CPU0:XR9000#scp harddisk: /<file name> root@1.2.3.4:/auto/config/.
```

## **Pre-Upgrade Tasks**

- System Stability Check: The following commands should be executed to verify basic system stability before the upgrade. At the XR prompt:
  - RP/0/RP0/CPU0:R1#admin show install health  
INFO Platform is: xrv9k  
INFO Collecting Cards Information  
INFO Collecting Sysadmin VMs Information  
INFO Collecting XR VMs Information  
INFO Verifying all the required VMs are running.  
INFO Pass: All required VMs are Running  
INFO Collecting sysadmin VMs data  
INFO Collecting Host data  
INFO Collecting XR VMs data  
INFO Collecting Lead VMs data  
INFO Verifying Test Plugins  
INFO Verifying Plugins results  
INFO Verifying Result for:cal\_version  
INFO Verifying Result for:cal\_smus  
INFO Verifying Result for:cal\_local\_active\_swp  
INFO Verifying Result for:cal\_local\_committed\_swp  
INFO Verifying Result for:cal\_disk\_space  
INFO Verifying Result for:cal\_marker\_files  
INFO Verifying Result for:cal\_mount\_points  
INFO Verifying Result for:cal\_stale\_symlinks  
INFO Verifying Result for:cal\_prepared\_packages  
INFO Verifying Result for:cal\_master\_active\_swp  
INFO Verifying Result for:cal\_master\_committed\_swp  
INFO Verifying Result for:xr\_master\_active\_swp  
INFO Verifying Result for:xr\_master\_committed\_swp  
INFO Verifying Result for:xr\_local\_active\_swp  
INFO Verifying Result for:xr\_local\_committed\_swp  
INFO Verifying Result for:cal\_image  
INFO Verifying Result for:cal\_tmp\_staging\_dir  
INFO Verifying Result for:cal\_install\_tmp\_staging\_dir  
INFO Verifying Result for:cal\_repo\_file\_permission  
INFO Verifying Result for:host\_version  
INFO Verifying Result for:xr\_version  
INFO Verifying Result for:host\_smus  
INFO Verifying Result for:xr\_smus  
INFO Verifying Result for:xr\_disk\_space  
INFO Verifying Result for:xr\_marker\_files  
INFO Verifying Result for:xr\_mount\_points  
INFO Verifying Result for:xr\_stale\_symlinks  
INFO Verifying Result for:xr\_prepared\_packages

```
INFO Verifying Result for:xr_tmp_staging_dir
INFO *****
INFO System is in Consistent State. You can go ahead with next operation.
INFO *****
INFO Total time taken: 4.27931904793 seconds.
```

- **Cost-out IGP:** To minimize traffic loss during the upgrade please follow below steps:

For OSPF use “max-metric” command.

```
RP/0/RP0/CPU0:XR9000(config-ospf)# max-metric router-lsa
```

For ISIS use “spf-overload-bit” command.

```
RP/0/RP0/CPU0:XR9000(config-isis)# set-overload-bit
```

- Check available space in install repository and make sure that sufficient disk space is available

```
sysadmin-vm:0_RP0# show media
```

- Check inactive packages and remove them before upgrading.

```
XR: RP/0/RP0/CPU0:XR9000#install remove inactive all
Sysadmin: sysadmin-vm:0_RP0# show install inactive
```

- Check and delete core files and any other files which are not required in harddisk

```
RP/0/RP0/CPU0:XR9000#run
[xr-vm_node0_RP0_CPU0:~]$cd /misc/disk1
[xr-vm_node0_RP0_CPU0:/misc/disk1]$rm *core*
```

## Software Upgrade

### **Classic Method**

All System Upgrade related install operations should be done in the XR VM plane.

- Download 7.7.2 image from CCO.
- Copy the 7.7.2 iso image / tar file to the router harddisk and verify that file is copied successfully

```
RP/0/RP0/CPU0:XR9000#scp root@1.2.3.4://auto/<image file> /misc/disk1/.
```

- Verify the md5 checksum of the tar/individual rpms with the original MD5 values on CCO

```
[xr-vm_node0_RP0_CPU0:/misc/disk1]$md5sum fullk9-R-XR9000-772.tar
```

- Perform ‘install add’ of 772 tar file / iso image:

```
RP/0/RP0/CPU0:XR9000#install add source harddisk:/ fullk9-R-XR9000-772.tar
```

OR

```
RP/0/RP0/CPU0:XR9000#install add source tftp://auto/.../ xr9k-fullk9-x-7.7.2.iso
```

- Take a note of the install operation id generated by the add operation in the install add step

```
Install operation 1 finished successfully
```

- Activate all the packages

```
RP/0/RP0/CPU0:XRv9000#install activate id 1 noprompt synchronous
```

- “show install request” CLI can be used to monitor the progress of the install operation
- Router will reload at the end of activation to start using the new packages.
- Verify that all the packages are installed correctly in XR and SysAdmin

```
RP/0/RP0/CPU0:XRv9000#show install active
sysadmin-vm:0_RP0# show install active
```

- Execute ‘install commit’ to commit the newly active software (install commit is required after any install activate operation else after router reload, nodes will go back to previously committed software)

```
RP/0/RP0/CPU0:XRv9000#install commit
```

- Verify system stability through commands described under Check System Stability section (3.1) after router comes up with new software
- Verify show version to check router is upgraded.

```
RP/0/RP0/CPU0:XRv9000#show version
```

```
RP/0/RP0/CPU0:R1#show version
Cisco IOS XR Software, Version 7.7.2
Copyright (c) 2013-2022 by Cisco Systems, Inc.
```

#### Build Information:

```
Built By   : ingunawa
Built On   : Wed Oct 26 12:27:45 PDT 2022
Built Host : iox-ucs-072
Workspace  : /auto/srcarchive14/prod/7.7.2/xrv9k/ws
Version    : 7.7.2
Location   : /opt/cisco/XR/packages/
Label      : 7.7.2
```

```
cisco IOS-XRv 9000 () processor
System uptime is 7 minutes
```

- Check to see if there were any failed startup configurations.

```
RP/0/RP0/CPU0:XRv9000#show configuration failed startup
```

- Add recommended SMUs for 7.7.2 if not already in initial tarball (optional)

```
RP/0/RP0/CPU0:XRv9000#install add source harddisk: <mandatory SMU tar file
for 7.7.2>
```

- Activate the recommended SMUs (if recommended smu's were added)

```
RP/0/RP0/CPU0:XRv9000#install activate id <id of install add step> noprompt
synchronous
```

- After system comes up from reload, execute 'install commit'
- Please check "show install committed summary" to make sure your system is upgraded and committed with your desired version/7.7.2

## **Post-Upgrade Tasks**

- Disk cleanup: Once software upgrade has been completed, disk space can be recovered by removing any inactive packages that are no longer needed (if the packages are required at a later time, they can be re-added):

```
RP/0/RP0/CPU0:XRv9000#install remove inactive all
```

- Verify/fix configuration file system (mandatory):

```
RP/0/RP0/CPU0:XRv9000#cfs check
```

- Restore IGP metric if changed before the upgrade (this is done from xr vm)

OSPF

```
RP/0/RP0/CPU0:XRv9000# (config-ospf)# no max-metric router-lsa
```

ISIS

```
RP/0/RP0/CPU0:XRv9000# (config-isis)# no set-overload-bit
```

## **Caveats**

There are no caveats for System Upgrade from 7.2.2, 733 and 742 to 772.

## **Software Downgrade:**

### ***Classic Method***

All System Upgrade related install operations should be done in the XR VM plane.

- Download 7.2.2 mini-ISO and packages tar and SMUs from CCO.  
Copy iso image to tftp / scp / ftp server. Verify the contents of the tar file/iso image"
- Copy the 7.2.2 iso image/tar file to the router harddisk and verify that file is copied successfully

```
RP/0/RP0/CPU0:XRv9000#scp root@1.2.3.4://image/CCO/ fullk9-R-XRv9000-722.tar
```

- Verify the md5 checksum of the tar/individual rpms with the original MD5 values on CCO  
bash-4.2\$ md5sum fullk9-R-XRV9000-722.tar

- [xr-vm\_node0\_RP0\_CPU0:/misc/disk1]\$md5sum fullk9-R-XRV9000-722.tar  
[xr-vm\_node0\_RP0\_CPU0:/misc/disk1]\$

- Perform 'install add' of 722 iso image / tar file:

```
RP/0/RP0/CPU0:XR9000#install add source harddisk:/ fullk9-R-XRV9000-722.tar
```

OR

```
RP/0/RP0/CPU0:XR9000#install add source tftp://auto../ xrv9k-fullk9-x-7.2.2.iso
```

- Take a note of the install operation id generated by the add operation in the install add step

```
Install operation 9 finished successfully
```

- Activate all the packages

```
RP/0/RP0/CPU0:XR9000#install activate id 9 noprompt synchronous
```

- Router will reload at the end of activation to start using the new packages.
- Verify that all the packages are installed correctly in XR and SysAdmin

```
RP/0/RP0/CPU0:XR9000#show install active  
sysadmin-vm:0_RP0# show install active
```

- Execute 'install commit' to commit the newly active software (install commit is required after any install activate operation else after router reload, nodes will go back to previously committed software)

```
RP/0/RP0/CPU0:XR9000#install commit
```

- Verify system stability through commands described under Check System Stability section (3.1) after router comes up with new software

- Verify show version to check router is upgraded.

```
RP/0/RP0/CPU0:XR9000#show version
```

- Check to see if there were any failed startup configurations.

```
RP/0/RP0/CPU0:XR9000#show configuration failed startup
```

- Add recommended SMUs for 7.2.2 if not already in initial tarball (optional)

```
RP/0/RP0/CPU0:XR9000#install add source harddisk: <mandatory SMU tar file for 7.2.2>
```



- Activate the recommended SMUs (if recommended smu's were added)

RP/0/RP0/CPU0:XR9000#install activate id <id of install add step> noprompt synchronous

- After system comes up from reload, execute 'install commit'
- Please check "show install committed summary" to make sure your system is downgraded and committed with your desired version/7.2.2

## **Post-Downgrade Tasks**

- Disk cleanup: Once software upgrade has been completed, disk space can be recovered by removing any inactive packages that are no longer needed (if the packages are required at a later time, they can be re-added):

```
RP/0/RP0/CPU0:XR9000#install remove inactive all
```

- Verify/fix configuration file system (mandatory):

```
RP/0/RP0/CPU0:XR9000#cfs check
```

- Restore IGP metric if changed before the upgrade (this is done from xr vm)

OSPF

```
RP/0/RP0/CPU0:XR9000# (config-ospf)# no max-metric router-lsa
```

ISIS

```
RP/0/RP0/CPU0:XR9000# (config-isis)# no set-overload-bit
```

## **Caveats**

There are no caveats for System Downgrade from 772 to 7.2.2, 733 and 742.

## **Other Boot Options (GISO)**

GISO:

- Create GISO with necessary rpms/pkgs/SMU
- Copy the GISO on to the harddisk
- Use the following command to perform install upgrade GISO from harddisk in one single shot with zero touch

```
RP/0/RP0/CPU0:XR9000#install replace harddisk:/<GISO_image> commit force noprompt
```