

PERIODIC CHECK SECTION

Contents

1. Periodic Check List.....	PERIOD01-10
2. Cleaning.....	PERIOD02-10
2.1 Cleaning the Front Bezel	PERIOD02-10
2.2 Cleaning the Rear Door	PERIOD02-20

1. Periodic Check List

The following table shows the items of the periodic check for the Storage System.

Confirm the following conditions of the Storage System before periodic check.

- There is no abnormal part in the Maintenance Utility window.

Table 1-1 Periodic Check List

No	Item	Tools	Frequency of Periodic Check	Check Time	Reference Page
1	Cleaning	<ul style="list-style-type: none">• Vacuum cleaner• Dry cloth• Philips screwdriver	Once a year	<ul style="list-style-type: none">• 2 min per Front Bezel• 2 min per Rear Door	PERIOD02-10

2.2 Cleaning the Rear Door

1. Clean the rear door from the surface.
2. Open the rear door.
 - (1) Insert the key into the key hole of the door and turn it to the left to unlock (①).
 - (2) Push the upper part of the lever and open the lower part (② , ③).
 - (3) Turn the lever to the left and pull it toward you to open the door (④).
 - (4) Set the open/close lock bar to the inside bottom of the rear door (⑤).
3. Clean the inside of the rear door.
4. Close the rear door.
 - (1) Lift the open/close lock bar on the bottom of the back of the rear door to release the lock (⑤).
 - (2) Close the door. Push the lever and turn it to the right. (⑥).
 - (3) Pull the lever down and push the lower part of the lever (⑦).
 - (4) Insert the key into the key hole of the door and turn it to the right to lock (⑧).

Figure 2-2 Cleaning the Rear Door

