

IBM INSTALLATION INSTRUCTIONS

FC 8006. Install Rack Mount Option in 3583 Model L18/L36/L72

Document Number 19P1504 EC H80336

SSD, Tucson

Written by: B. Schweitzer
Checked by: S. Trail, J. Simkins, C. Kovalik
Approved by: T. Poulton, C. Pilch
Support/DPCE Review by: K. Cowell
Status: Field Use

Note: This Field Feature Bill of Material (FFBM) must be installed only on the 3583 Model L18/L36/L72 for which it is shipped.

| | | | | | |
|----------------------|------------------------|------------------------|------------------------|--|--|
| PN 19P1504 1 of 5 | EC H27554 16 NOV 00 | EC H27767 27 APR 01 | EC H80336 06 JUN 03 | | |
|----------------------|------------------------|------------------------|------------------------|--|--|

Before Installation

1.0 Machines Affected

All 3583 Model L18/L36/L72

2.0 Prerequisites / Concurrent / Companion

None

3.0 FFBM To Be Installed

| FFBM | Description |
|---------|--|
| 19P1408 | Rack Mount Option (FC 8006) and Instructions |

4.0 Preparation

Read and understand the purpose and details of this installation instruction. Check all items and count parts listed on the B/M to be installed to determine that all parts have been received.

You will need the following documentation (as appropriate):

- *IBM TotalStorage Ultrium Scalable Tape Library 3583 Setup and Operator Guide (GA32-0411-xx)*

Note: Go to <http://www.storage.ibm.com/lto> for the latest version of documentation.

5.0 Programming Updates

None.

6.0 Purpose and Description

This FFBM provides the instructions to install a library Rack Mount Option in a 3583 Model L18/L36/L72.

| | | | | | |
|----------------------|------------------------|------------------------|------------------------|--|--|
| PN 19P1504 2 of 5 | EC H27554 16 NOV 00 | EC H27767 27 APR 01 | EC H80336 06 JUN 03 | | |
|----------------------|------------------------|------------------------|------------------------|--|--|

7.0 Installation Time

| Install Hours | Machine Hours | System Hours | No Of Persons |
|---------------|---------------|--------------|---------------|
| 4.0 | 0.5 | 0 | 2 |

8.0 Special Tools and/or Materials Required

Refer to the *IBM TotalStorage Ultrium Scalable Tape Library 3583 Setup and Operator Guide* (GA32-0411-xx) for the required tools.

| | | | | | |
|----------------------|------------------------|------------------------|------------------------|--|--|
| PN 19P1504 3 of 5 | EC H27554 16 NOV 00 | EC H27767 27 APR 01 | EC H80336 06 JUN 03 | | |
|----------------------|------------------------|------------------------|------------------------|--|--|

Installation

9.0 Safety

None.

10.0 Details Of Installation

Note: Any parts that are removed during this change and not specified for reinstallation are to be set to the side for disposition as explained in Section 14.0.

10.1 Installing A Rack Mount Option in 3583 Model L18/L36/L72

- 1. To install the Rack Mount option, refer to **Chapter 2** of the *IBM TotalStorage Ultrium Scalable Tape Library 3583 Setup and Operator Guide* (GA32-0411-xx).

11.0 Test Procedure

N/A

12.0 Field Updating

None.

| | | | | | |
|----------------------|------------------------|------------------------|------------------------|--|--|
| PN 19P1504 4 of 5 | EC H27554 16 NOV 00 | EC H27767 27 APR 01 | EC H80336 06 JUN 03 | | |
|----------------------|------------------------|------------------------|------------------------|--|--|

After Installation

13.0 Field Support Publications

None.

14.0 Parts Disposition

Any removed parts are the property of the customer.

15.0 Machine Records

N/A

| | | | | | |
|----------------------|------------------------|------------------------|------------------------|--|--|
| PN 19P1504 5 of 5 | EC H27554 16 NOV 00 | EC H27767 27 APR 01 | EC H80336 06 JUN 03 | | |
|----------------------|------------------------|------------------------|------------------------|--|--|