

DIMENSION[®] 2000 AND CUSTOM PBX
LINE CLASS OF SERVICE ASSIGNMENTS

CONTENTS

1. GENERAL	3. TEST PREPARATION
2. TEST EQUIPMENT AND DOCUMENTATION	4. TEST PROCEDURE

1. <u>GENERAL</u>	4.052	When WAIT lamp goes off and the tape stops running, decimal points defining the display will appear. A "1" appears in the field under WORD.
1.1 This section provides testing information to verify the feature and restriction assignments to each Line Class of Service.	4.06	Dial Line Class of Service number to be verified and press ENTER key.
	4.061	Line Class of Service number dialed appears in Field 1.
2. <u>TEST EQUIPMENT AND DOCUMENTATION</u>	4.07	Press DISPLAY and EXECUTE keys.
2.1 Maintenance and Administration Panel (MAAP).	4.071	Line Class of Service Feature information is displayed. A "1" designation in a field indicates that the feature is activated.
2.2 Class of Service Assignments table in Customer Order Document (COD).	4.072	Verify the Line Class of Service shown in Field 1 with the Class of Service Feature Assignment in the COD.
3. <u>TEST PREPARATION</u>	4.08	Press CHANGE FIELD key, dial 1, and press ENTER key.
3.1 Refer to the Class of Service Assignments table and determine the numbers assigned to Line Class of Service.	4.081	Field 1 is all blanks.
4. <u>TEST PROCEDURE</u>	4.09	Dial next Line Class of Service to be verified. Press ENTER, DISPLAY, and EXECUTE keys.
4.01 At the Common Control Cabinet, remove MAAP from storage panel and connect the MAAP to the ON LINE connector.	4.091	Line Class of Service dialed appears in Field 1, and feature information is displayed.
4.02 Turn flip chart to Procedure 010, Word 1.	4.092	Verify the Line Class of Service shown in Field 1 with the Class of Service Feature Assignment in the COD.
4.03 Press PROC No. key.	4.10	Repeat Steps 4.08 through 4.092 until all Line Classes of Service activated in the system have been verified.
4.04 Dial 010.	4.11	Turn flip chart to WORD 2 of PROC 010. Press WORD NO. key, dial 2, and depress ENTER key.
4.041 "010" displayed in Procedure Number Field.		
4.05 Press ENTER key.		
4.051 The WAIT lamp will light and in most cases the tape will start running.		

PRIVATE

THE INFORMATION CONTAINED HEREIN SHOULD NOT BE DISCLOSED TO UNAUTHORIZED PERSONS. IT IS MEANT SOLELY FOR USE BY AUTHORIZED BELL SYSTEM EMPLOYEES.

Printed in U.S.A.

- 4.111 A "2" appears in the field number WORD and decimal points appear defining the fields for flip chart displayed (PROC 010, WORD 2).
- 4.12 Dial the Line Class of Service number to be verified and press ENTER key.
- 4.121 Line Class of Service number dialed appears in Field 1.
- 4.13 Press DISPLAY and EXECUTE keys.
- 4.131 Line Class of Service Restriction information is displayed. A "1" designation in a field indicates that the restriction is activated.
- 4.14 Press CHANGE FIELD key, dial 1 and press ENTER key.
- 4.141 Field 1 is all blanks.
- 4.15 Dial the next Line Class of Service to be verified. Press ENTER, DISPLAY, and EXECUTE keys.
- 4.151 Line Class of Service dialed appears in Field 1 and restriction information is displayed.
- 4.152 Verify the Line Class of Service Restriction shown in Field 1 with the Class of Service Assignment in the COD.
- 4.16 Repeat Steps 4.14 through 4.152 until all Line Classes of Service activated in the system have been verified.
- 4.17 All Line Class of Service Assignments have been verified.

Reason for Issue:
New Section

Manager, Denver PBX PECC