

EQUIPMENT TEST LIST
LWM WB MODEM
ANALOG MULTIPLEX TERMINAL EQUIPMENT

| | CONTENTS | PAGE |
|----------------------------|-----------------|-------------|
| 1. GENERAL | | 1 |
| 11.1 OVERALL SYSTEM | | 2 |

the various tests. The "reformatted ETLs" replace the ETL previously provided for this equipment.

1.03 Comments on this section should be made by following the instructions in Bell System Practices (BSP), Section 000-010-015.

1.04 Routine test information is arranged in the following order from left to right: Section number, issue/addendum, test letter or paragraph number, test title, test class, frequency, and the last space is for a locally assigned job number.

1.05 Section 010-300-011 provides Equipment Test List instructions.

1. GENERAL

1.01 This section provides an index and information access system to locate the standard tests applicable to equipment listed in the preceding table of contents. Test classification and frequency of periodic routine are also provided.

1.02 This is the first issuance of the "reformatted ETL" which provides better organization of



NOTICE
Not for use or disclosure outside the
Bell System except under written agreement

11.0 LWM WB MODEM

11.1 LWM WB MODEM; OVERALL SYSTEM

TROUBLE TESTS

| | | | | | |
|-------------|-------|---|--|----|-------|
| 356-400-500 | (1/0) | | 4-KHZ WB TRMSN SIG LEV TESTS | TT | ----- |
| 356-401-500 | (2/0) | 1 | LWM-5 WIDEBAND TRANSMIT TEST | TT | ----- |
| | | 2 | LWM-5 WIDEBAND RECEIVE TEST | TT | ----- |
| | | 3 | LWM-5 VOICE TRANSMISSION TEST | TT | ----- |
| 356-402-500 | (3/1) | 1 | LWM-6 WIDEBAND TRANSMIT TEST | TT | ----- |
| | | 2 | LWM-6 WIDEBAND RECEIVE TEST | TT | ----- |
| | | 3 | LWM-6 VOICE TRANSMISSION TEST | TT | ----- |
| 356-405-500 | (1/0) | | 190-KHZ LWM-2 SIGNAL LEVEL TESTS AND ALIGNMENT | TT | ----- |
| 356-410-500 | (1/0) | | 16-KHZ WIDEBAND TRMSN SIGNAL LEVEL TESTS | TT | ----- |
| 356-411-500 | (1/0) | | ALTERNATE USE PANEL TESTS | TT | ----- |

