


Avaya™ MPS4603-AC PSU Installation Guide

The Avaya MPS4603-AC is a 300W AC PSU (power supply unit) for the Avaya™ C460 switch. See the *C460 Installation and Maintenance Guide* for further information.

Figure 1 MPS4603-AC Front Panel



Key

- 1 Status LED
- 2 Power inlet
- 3 Power switch

Table 1.1 Power Supply Status LED

LED Description	State	Meaning
Power Supply Status	Green	Power supply functioning
	Yellow	Power supply failure

Safety Information



Danger: The fans are on whenever the chassis is turned on.

Installing the PSU in the Avaya C460

- ① You can insert the PSU in any of the three slots.
- 1 Remove the blanking plate or existing PSU if installed.
- 2 Position the module in the slot with the module name at the top of the module.
- 3 Gently slide the module in.
- 4 Gently tighten the screws.
- 5 Connect the PSU to the mains power source.
- 6 Turn the PSU on using the switch on the front panel.

Specifications

Weight

8.5 lb. (3.85 kg)

Power Requirements

Input voltage	100 to 240 VAC, 50 or 60 Hz
Power dissipation	300 W max
Input current	3.9 A at 100 VAC 1.5 A at 240 VAC
Inrush current	15 A at 100 VAC (max.) 30 A at 240 VAC (max.)

Ordering Information

Product	Material Code
Avaya MPS4603-AC	700255078

avaya.com

© 2003 Avaya Inc. All rights reserved. All trademarks identified by the ® or TM are registered trademarks or trademarks, respectively, of Avaya Inc. All other trademarks are the property of their respective owners
Document no. 555-500-111