Lucent Technologies
Bell Labs Innovations

English 123 Announcements/Fragments for
**DEFINITY® AUDIX® R3.2 /
INTUITY™ AUDIX® R5.0-1**

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a1	IF (NUMBER==0)
	THEN
	    f776: the system greeting
	ELSE
	    NUMBER
	ENDIF,
	f745: active.
	f823: ...for all calls

a2	f936: Partial entry deleted.
a3	(f350+NUMBER(3)),(f310+NUMBER(1)),a905(NUMBER(2))
a4	f46: To access your mailbox, press star 7. f117: To reach the covering extension, press star zero. f291: To transfer to another extension, press star 8.
a5	f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a6	f561: You are addressing your message. f285: To add a member, enter extension f224: and pound sign. f328: To delete the previous entry, press star 3. To add a mailing list you have already created, or a public list owned by others, press star 5. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound. f58: For name addressing, press star 2.
a7	f561: You are addressing your message. f286: To add a member, enter last name f224: and pound sign. f328: To delete the previous entry, press star 3. To add a mailing list you have already created, or a public list owned by others, press star 5. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound. f148: For extension addressing, press star 2.
a8	f46: To access your mailbox, press star 7. f291: To transfer to another extension, press star 8.
a9	f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a10	f306: You are changing your password. f212: Please enter password again for confirmation. To delete the password you just entered, press star 3 f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a11	f233: Previous login incorrect. Please re-enter extension f224: and pound sign.
a12	f233: Previous login incorrect. Please re-enter extension f224: and pound sign. f330: Or enter just the pound sign if it's your phone.
a13	f105: To restart at the activity menu, press star 7. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a14	f306: You are changing your password. f210: Please enter a new password f224: and pound sign. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.
a15	f555: To access your mailbox, press star 7. f117: To reach the covering extension, press star zero. f291: To transfer to another extension, press star 8. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.
a16	f306: You are changing your password. f212: Please enter password again for confirmation. To delete the password you just entered, press star 3 f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.
a17	f555: To access your mailbox, press star 7. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.
a18	f555: To access your mailbox, press star 7. f291: To transfer to another extension, press star 8. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.
a19	f327: You are creating a mailing list. f285: To add a member, enter extension f224: and pound sign.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	f328: To delete the previous entry, press star 3. To add a mailing list you have already created, or a public list owned by others, press star 5. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound. f58: For name addressing, press star 2. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a20	f327: You are creating a mailing list. f286: To add a member, enter last name f224: and pound sign. f328: To delete the previous entry, press star 3. To add a mailing list you have already created, or a public list owned by others, press star 5. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound. f148: For extension addressing, press star 2. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a21	f821: You are administering call types.
a22	f821: You are administering call types. f798: Prime time is TIME, f524: to TIME(2), f788: To identify calls as out-of-hours, press 3. f789: Otherwise, press 4.
a23	f821: You are administering call types. f785: Same greeting used for all calls. f786: To identify calls as internal and external, press 1. f787: To identify calls as busy and no answer, press 2.

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a24	f503: You are administering your attendant menu. f502: To record attendant menu, press 1. To listen to attendant menu, press 0. f550: To rewind your attendant menu, press 2. To delete it, press star 3. To stop playback of your attendant menu, press 3. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a25	f373: You are choosing whether to attach a copy of original message to your reply. To include the original, press 9 for yes. To send only your reply, press 6 for no. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a26	f299: You are administering your greeting. f5: To record personal greeting, press 1. To listen to personal greeting, press 0. To select which greeting to use, press star pound. f39: To delete, press star 3. To stop playback, press 3. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a27	f46: To access your mailbox, press star 7.
a28	f529: You are changing your outcalling options. f527: To change number, press 1. To change times, press 2. For instructions on entering your outcalling number, press 3. f528: To turn on, press 9. To turn off, press 6. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a29	f347: You are adding a list. f111: Please enter list id f224: and pound sign. f366: To specify a different owner by extension, press star 3. f363: To approve the list you are creating, press pound.
a30	f302: You are recording announcement fragments. Enter fragment id followed by pound sign. Refer to administration manual for correct id. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a31	f347: You are adding a list. f111: Please enter list id f224: and pound sign. f367: To specify a different owner by name, press star 3. f363: To approve the list you are creating, press pound.
a32	f303: You are recording names. Enter extension f224: and pound sign. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a33	f382: You are scheduling your message for delivery. f341: Enter the number of the month, one through twelve, then two digits for the day of the month, then the pound sign. f487: To delete time, press star 3. To default rest of the delivery time, press pound.
a34	f108: You are recording a message. f167: To approve, press pound. To record from here, press 1. To playback, press 2-3. f24: To delete, press star 3. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
a35	f816: You are listening to a personal greeting. f753: Enter greeting number. f913: If finished, press pound.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a36	f817: You are recording a personal greeting. f753: Enter greeting number. f913: If finished, press pound.
a37	f820: You are selecting which greeting to activate.
a38	f368: You are entering the number for a new list. Please enter a number up to six digits long f224: and pound sign. f369: To replace an existing list, enter that list's number, f224: and pound sign. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a39	f358: You are identifying a list as private or public. f14: To make private, press 1. To make public, press 2. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a40	f370: These are entries in your list. f294: To add entries, press 1. f371: To rewind to current entry, press 2. To rewind to previous entries, press 2 as many times as necessary. To continue playback of list, press 3. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f372: To skip to next entry, press pound. To delete current entry, press star 3. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a41	f360: You are scanning mailing lists. To review list members, press 0. To rewind to previous list, press 2. To continue scanning lists, press 3. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f361: To skip to next list, press pound. To delete list, press star 3. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press

Announcement	Fragments
	star star 9.
a42	f587: You are reviewing a list. f388: To skip, press the pound key. f371: To rewind to current entry, press 2. To rewind to previous entries, press 2 as many times as necessary. To continue playback of list, press 3. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a43	f359: You are changing the status of your list. To modify status, press 9 for yes or 6 for no. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a44	f370: These are entries in your list. f333: To add entries to the list or to change status of list, press 1. f371: To rewind to current entry, press 2. To rewind to previous entries, press 2 as many times as necessary. To continue playback of list, press 3. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f372: To skip to next entry, press pound. To delete current entry, press star 3. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a45	f327: You are creating a mailing list. f329: You have not yet entered enough characters to identify a specific subscriber. To enter the letter Q, press 7; for Z press 9. f484: Enter more characters followed by the pound sign; if you just completed entering the last name, enter the first name. f224: and pound sign. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a46	f815: You are administering your personal greetings.
a47	f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
a48	f549: You are administering your attendant menu. To create attendant menu, press 1. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

a49	# VERSION > 2 is INTUITY FAX feature. FAX enabled == 1, FAX not enabled == 0
	IF (VERSION > 2)
	THEN
	      f108: You are recording a message.
	      IF (NUMBER > 0)
	      THEN
	            f1004: To bypass voice recording and create a fax only message, press pound.
	      ENDIF,
	      f13: To record, press 1. After recording, press 1 again.
	      f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
	ELSE
	      f108: You are recording a message.
	      f13: To record, press 1. After recording, press 1 again.
	      f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
	ENDIF

a50	f299: You are administering your greeting. f36: To record a personal greeting, press 1.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a51	f306: You are changing your password. f210: Please enter a new password f224: and pound sign. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a52	f591: To change your outcalling phone number, press 1. To hear further instructions on programming a pager, press 9. To return to outcalling administration, press 6.
a53	f566: You are responding to an outcall notifying you of new messages. f551: To access your messages, f223: Please enter extension f224: and pound sign. f543: To avoid further notification of these messages, press star pound. f567: Either logging in or pressing star pound will result in the outcall being canceled for the new messages currently in your mailbox. If additional new messages arrive, another outcall will be scheduled."
a54	f347: You are adding a list. f362: If you own the list, press pound. If someone else owns the list f364: enter owner's extension f224: and pound sign. f298: To specify owner by name, press star 2.
a55	f347: You are adding a list. f362: If you own the list, press pound. If someone else owns the list f365: enter owner's name f224: and pound sign. f297: To specify owner by extension, press star 2.
a56	f220: Enter password f224: and pound sign.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a57	f307: You are playing announcements. f221: Enter announcement id and pound sign. Refer to administration manual for correct id. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a58	f308: You are playing announcement fragments. f222: Enter fragment id and pound sign. Refer to administration manual for correct id. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a59	f309: You are playing names. f223: Please enter extension f224: and pound sign. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a60	f223: Please enter extension f224: and pound sign.
a61	f357: You are choosing between subscribers whose names match your entry. To indicate no subscribers match, delete entry by pressing star 3. To change to extension addressing and delete your entry, press star 2. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.
a62	f323: You are responding to a piece of incoming mail. f486: To reply to sender by voice mail, press 1. f41: To forward message with comment at beginning, press 2. f126: To forward message with comment at end, press 3. f8: To record a new message, press 4. f1434: To return to getting messages, press pound. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a63	f348: You are specifying a mailing list to review. f111: Please enter list id f224: and pound sign. f366: To specify a different owner by extension, press star 3. f363: To approve the list you are creating, press pound. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a64	f348: You are specifying a mailing list to review. f111: Please enter list id f224: and pound sign. f367: To specify a different owner by name, press star 3. f363: To approve the list you are creating, press pound. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a65	f348: You are specifying a mailing list to review. f362: If you own the list, press pound. If someone else owns the list f364: enter owner's extension f224: and pound sign. f298: To specify owner by name, press star 2. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a66	f348: You are specifying a mailing list to review. f362: If you own the list, press pound. If someone else owns the list f365: enter owner's name f224: and pound sign. f297: To specify owner by extension, press star 2. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

Announcement	Fragments
a67	f348: You are specifying a mailing list to review. f329: You have not yet entered enough characters to identify a specific subscriber. To enter the letter Q, press 7; for Z press 9. f484: Enter more characters followed by the pound sign; if you just completed entering the last name, enter the first name. f224: and pound sign. f148: For extension addressing, press star 2. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

a68	# VERSION > 2 is INTUITY FAX feature. FAX enabled == 1, FAX not enabled == 0
	IF (VERSION > 2)
	THEN
	    f518: You are creating a voice message which will be delivered to the person specified in your message as soon as possible. Please be aware that in order to forward this message to the recipient, someone will listen to the name and number portion.
	    IF (NUMBER > 0)
	    THEN
	        f1004: To bypass voice recording and create a fax only message, press pound.
	    ENDIF,
	    f13: To record, press 1. After recording, press 1 again.
	    f304: To playback message, press 2-3. To delete your message, press star 3. To approve your message, press pound.
	    f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
	    f46: To access your mailbox, press star 7.
	    f117: To reach the covering extension, press star zero.
	    f291: To transfer to another extension, press star 8.
	    f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.
	ELSE
	    f518: You are creating a voice message which will be delivered to the person specified in your message as soon as possible. Please be aware that in order to forward this message to the recipient, someone will listen to the name and number portion.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	f13: To record, press 1. After recording, press 1 again. f304: To playback message, press 2-3. To delete your message, press star 3. To approve your message, press pound. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f46: To access your mailbox, press star 7. f117: To reach the covering extension, press star zero. f291: To transfer to another extension, press star 8. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9. ENDIF
a69	f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign. f46: To access your mailbox, press star 7. f117: To reach the covering extension, press star zero. f291: To transfer to another extension, press star 8. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9. f516: To leave a message that will be delivered as soon as possible, f380: Please wait.
a70	f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign. f46: To access your mailbox, press star 7. f117: To reach the covering extension, press star zero. f291: To transfer to another extension, press star 8. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9. f274: Please make entry soon, or be disconnected.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0–1

Announcement	Fragments
a71	f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign. f46: To access your mailbox, press star 7. f117: To reach the covering extension, press star zero. f291: To transfer to another extension, press star 8. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9. f515: To be transferred to an operator, f380: Please wait.

a73	# VERSION > 2 is for INTUITY 3.0 Fax Feature.
	# NUMBER(3) == 1 if voice only, 2 if fax only, 3 if voice and fax.
	# NUMBER(4) - 1 fax enabled, 0 - fax disabled
	IF (VERSION > 2)
	THEN
	    f378: You are checking the status of your
	    outgoing messages.
	    # INTUITY 3.0
	    IF (NUMBER(3) == 1)
	    THEN
	        #Voice only
	        f1462: To listen to the message, press 0.
	    ELSE
	        IF (NUMBER(3) == 2)
	        THEN
	            #FAX only
	            IF (NUMBER(4) == 1)
	            THEN
	                f1073: To print, press star 1.
	            ENDIF
	        ELSE
	            #Voice and FAX
	            f1462: To listen to the message,
	            press 0.
	            IF (NUMBER(4) == 1)
	            THEN
	                f1073: To print, press star 1.
	            ENDIF
	        ENDIF
	    ENDIF,
	    f1039: To change or send again, press one.
	    f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing 2, then play by pressing 3. To skip to the next category, press star pound.
	    IF (NUMBER(3) != 2)
	    THEN
	        f339: To replay the last few seconds, press 5. To advance a few seconds, press 6.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

	ENDIF,
	f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
	f377: To delete message, press star 3.
	ELSE
	# DEFINITY AUDIX 3.0, 3.1
	f378: You are checking the status of your outgoing messages.
	f474: To listen, press 0. To change or send again, press 1.
	f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing 2, then play by pressing 3. To skip to the next category, press star pound.
	f339: To replay the last few seconds, press 5. To advance a few seconds, press 6.
	f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
	f377: To delete message, press star 3.
	ENDIF

a74	f819: You are scanning your personal greetings. f781: To skip to the next greeting, press the pound sign. f756: To listen to greeting NUMBER, f760: press 0. f24: To delete, press star 3. f839: To rewind to the previous greeting, press 2. f707: If finished, press star pound. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
a75	f385: To approve delivery time, press pound. To modify delivery time, press star 3 and listen for further instructions.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITYᵀᴹ AUDIX® R5.0-1

Announcement	Fragments

a76	`# VERSION > 2 INTUITY 3.0.`
	`# NUMBER = 1 if fax enabled,`
	`# NUMBER = 0 if fax is not enabled.`
	`# CAD = Call Answer Disable and ABR = Address Before`
	`Record.  XEROX Features`
	`# Introduced in INTUITY 3.0`
	`# NUMBER(2) is CAD and 0 is inactive and 1 is active.`
	`# NUMBER(3) is ABR and 0 is inactive and 1 is active.`
	`# a1174 is called by this announcement to determine the`
	`appropriate`
	`# fragment to be played depending on what features were`
	`active.`
	`IF (VERSION > 2)`
	`THEN`
	`     f305:  You are at the activity menu.`
	`     IF (NUMBER==0 )`
	`     THEN`
	`          f990:  To record and send voice mail`
	`          messages, press 1.`
	`     ELSE`
	`          f991:  To record and send voice mail or fax`
	`          messages, press 1.`
	`     ENDIF,`
	`     f992:  To get messages, press 2.`
	`     f1006:  To record or change the greeting heard by`
	`     callers, press 3.`
	`     f996:  To check your outgoing messages, press 4.`
	`     a1174(NUMBER,NUMBER(2),NUMBER(3)),`
	`     IF( NUMBER == 0 )`
	`     THEN`
	`          f1001:  To change outcalling information,`
	`          press 6. To scan incoming messages`
	`          automatically, press 7. To re-logon, press`
	`          star star 7.`
	`     ELSE`
	`          f1165:  To change outcalling information,`
	`          press 6.  To scan incoming messages`
	`          automatically or print all new faxes, press`
	`          7.  To re-logon, press Star Star 7.`
	`     ENDIF,`
	`     f282:  To have system wait, press star 9. To`
	`     access the names or numbers directory, press star`
	`     star 6. If finished, please hang up or to`
	`     disconnect AUDIX, press star star 9.`
	`ELSE`
	`     f305:  You are at the activity menu.`
	`     f983:  To record and send voice mail messages,`
	`     press 1. To get messages, press 2. To record or`
	`     change the greeting heard by callers, press 3.`
	`     f48:  To check your outgoing messages, press 4. To`
	`     administer mailing list, personal directory,`
	`     password, or account name, press 5. To change`

Announcement	Fragments
	outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9. ENDIF

Announcement	Fragments

a77	# VERSION > 2 INTUITY 3.0.
	# NUMBER = 1 if fax enabled,
	# NUMBER = 0 if fax is not enabled.
	# CAD = Call Answer Disable and ABR = Address Before Record. XEROX Features
	# Introduced in INTUITY 3.0
	# NUMBER(2) is CAD and 0 is inactive and 1 is active.
	# NUMBER(3) is ABR and 0 is inactive and 1 is active.
	# a1174 is called by this announcement to determine the appropriate
	# fragment to be played depending on what features were active.
	IF (VERSION > 2)
	THEN
	    f305: You are at the activity menu.
	    IF (NUMBER==0)
	    THEN
	        f990: To record and send voice mail messages, press 1.
	    ELSE
	        f991: To record and send voice mail or fax messages, press 1.
	    ENDIF,
	    f992: To get messages, press 2.
	    f1013: To administer attendant menu, press 3.
	    f996: To check your outgoing messages, press 4.
	    a1174(NUMBER,NUMBER(2),NUMBER(3)),
	    IF(NUMBER == 0)
	      THEN
	        f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7.
	      ELSE
	        f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logon, press Star Star 7.
	      ENDIF,
	    f291: To transfer to another extension, press star 8.
	    f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
	ELSE
	    f305: You are at the activity menu.
	    f984: To record and send voice mail messages, press 1. To get messages, press 2. To administer attendant menu, press 3.
	    f48: To check your outgoing messages, press 4. To administer mailing list, personal directory,

Announcement	Fragments
	password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7. f291: To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9. ENDIF
a78	f324: You are selecting which greeting will be played to callers. If you want your personal greeting to be played, press 9 for yes. If you press 6 for no, the system greeting will be used. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a79	f536: You are specifying your outcalling time period. The time you specify will be restricted by the times allowed by the system administrator. f545: To delete own time, press star 3. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a80	f536: You are specifying your outcalling time period. The time you specify will be restricted by the times allowed by the system administrator. f535: For outcalling any time, press 1. For outcalling during prime time, press 2. To specify your times, press 3. For system outcalling schedule, press 4. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a81	f378: You are checking the status of your outgoing messages. f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing 2, then play by pressing 3. To skip to the next category, press star pound. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f379: To delete status information, press star 3.
a83	f326: You are doing system administration. To record names, press 4. To play names, press 5. To record a machine name, press 6. To play a machine name, press 7. To record fragments, press 1. To play fragments, press 2. To play announcements, press 3. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a84	f382: You are scheduling your message for delivery. f488: To specify immediate delivery, press pound. Otherwise f340: Enter the hour, one through twelve, then two digits for the minutes, then press 2 for A.M .or 7 for P.M., and the pound sign.
a85	f323: You are responding to a piece of incoming mail. f486: To reply to sender by voice mail, press 1. f41: To forward message with comment at beginning, press 2. f126: To forward message with comment at end, press 3. f8: To record a new message, press 4. f163: To call sender, press zero. f1434: To return to getting messages, press pound. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

a86	# VERSION > 2 is for INTUITY 3.0 Fax Feature.
	# NUMBER(3) == 1 if voice only, 2 if fax only, 3 if voice and fax.
	# NUMBER(4) - 1 - fax enabled, 0 - fax disabled
	IF (VERSION > 2)
	THEN
	    f378: You are checking the status of your outgoing messages.
	    # INTUITY 3.0
	    IF (NUMBER(3) == 1)
	    THEN

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

	`             #Voice only`
	`             f1462:  To listen to the message, press 0.`
	`      ELSE`
	
	`             IF (NUMBER(3) == 2)`
	`             THEN`
	`                  #FAX only`
	`                  IF (NUMBER(4) == 1)`
	`                  THEN`
	`                       f1073:  To print, press star 1.`
	`                  ENDIF`
	`             ELSE`
	`                  #Voice and FAX`
	`                  f1462:  To listen to the message,`
	`                  press 0.`
	`                  IF (NUMBER(4) == 1)`
	`                  THEN`
	`                       f1073:  To print, press star 1.`
	`                  ENDIF`
	`             ENDIF`
	`      ENDIF,`
	`      f1038:  To re-record message before delivery,`
	`      press one.`
	`      f376:  To skip to the next header, press the pound`
	`      sign. To listen to the header, rewind by pressing`
	`      2, then play by pressing 3. To skip to the next`
	`      category, press star pound.`
	`      f339:  To replay the last few seconds, press 5. To`
	`      advance a few seconds, press 6.`
	`      f292:  Louder, press 4. Softer, press 7. Faster,`
	`      press 9. Slower, press 8.`
	`      f377:  To delete message, press star 3.`
	`ELSE`
	`      # DEFINITY AUDIX 3.0, 3.1`
	`      f378:  You are checking the status of your`
	`      outgoing messages.`
	`      f381:  To listen to the message, press 0. To re-`
	`      record message before delivery, press 1.`
	`      f376:  To skip to the next header, press the pound`
	`      sign. To listen to the header, rewind by pressing`
	`      2, then play by pressing 3. To skip to the next`
	`      category, press star pound.`
	`      f339:  To replay the last few seconds, press 5. To`
	`      advance a few seconds, press 6.`
	`      f292:  Louder, press 4. Softer, press 7. Faster,`
	`      press 9. Slower, press 8.`
	`      f377:  To delete message, press star 3.`
	`ENDIF`

a87	f223: Please enter extension f224: and pound sign. f330: Or enter just the pound sign if it's your phone.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a88	f818: You have just recorded f754: Greeting NUMBER, f766: To use this greeting for all calls, press 1. f913: If finished, press pound.
a90	f384: Please enter number of month, then two digits for day, and pound sign.
a92	f910: You are playing an announcement which need additional input before it can be played. f384: Please enter number of month, then two digits for day, and pound sign.
a93	f307: You are playing announcements. f254: To play the active version, press 1. f338: To play the administrative version, press 2. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a94	f308: You are playing announcement fragments. f254: To play the active version, press 1. f338: To play the administrative version, press 2. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a96	f503: You are administering your attendant menu. f502: To record attendant menu, press 1. To listen to attendant menu, press 0. f550: To rewind your attendant menu, press 2. To delete it, press star 3. To stop playback of your attendant menu, press 3. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f105: To restart at the activity menu, press star 7. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a97	f529: You are changing your outcalling options. f105: To restart at the activity menu, press star 7. f527: To change number, press 1. To change times, press 2. For instructions on entering your outcalling number, press 3. f528: To turn on, press 9. To turn off, press 6. f105: To restart at the activity menu, press star 7.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a98	f11: You are recording machine names. f6: Enter machine voice ID. f224: and pound sign. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a99	f549: You are administering your attendant menu. To create attendant menu, press 1. f105: To restart at the activity menu, press star 7. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a100	f138: You are listening to machine names. f6: Enter machine voice ID. f224: and pound sign. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

Announcement	Fragments

a101	# VERSION > 2 is INTUITY FAX feature. FAX enabled == 1, FAX not enabled == 0
	IF (VERSION > 2)
	THEN
	    f518: You are creating a voice message which will be delivered to the person specified in your message as soon as possible. Please be aware that in order to forward this message to the recipient, someone will listen to the name and number portion.
	    IF (NUMBER > 0)
	    THEN
	        f1004: To bypass voice recording and create a fax only message, press pound.
	    ENDIF,
	    f13: To record, press 1. After recording, press 1 again.
	    f304: To playback message, press 2-3. To delete your message, press star 3. To approve your message, press pound.
	    f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
	    f555: To access your mailbox, press star 7.
	    f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
	ELSE
	    f518: You are creating a voice message which will be delivered to the person specified in your message as soon as possible. Please be aware that in order to forward this message to the recipient, someone will listen to the name and number portion.
	    f13: To record, press 1. After recording, press 1 again.
	    f304: To playback message, press 2-3. To delete your message, press star 3. To approve your message, press pound.
	    f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
	    f555: To access your mailbox, press star 7.
	    f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
	ENDIF

a102	f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign.

Announcement	Fragments
	f555: To access your mailbox, press star 7. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9. f516: To leave a message that will be delivered as soon as possible, f380: Please wait.
a103	f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign. f555: To access your mailbox, press star 7. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9. f274: Please make entry soon, or be disconnected.
a104	f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign. f555: To access your mailbox, press star 7. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9. f515: To be transferred to an operator, f380: Please wait.
a105	f536: You are specifying your outcalling time period. The time you specify will be restricted by the times allowed by the system administrator. f545: To delete own time, press star 3. f105: To restart at the activity menu, press star 7. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a106	f536: You are specifying your outcalling time period. The time you specify will be restricted by the times allowed by the system administrator. f535: For outcalling any time, press 1. For outcalling during prime time, press 2. To specify your times, press 3. For system outcalling schedule, press 4. f105: To restart at the activity menu, press star 7. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a108	f529: You are changing your outcalling options. f527: To change number, press 1. To change times, press 2. For instructions on entering your outcalling number, press 3. f528: To turn on, press 9. To turn off, press 6. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a109	f669: With the current settings, this login announcement will be interruptible and the login announcement has an expiration date of. DATE
a110	f663: Message waiting notification is not active and this message has an expiration date of. DATE
a111	f668: With the current settings, this login announcement will be non-interruptible and the login announcement has an expiration date of. DATE
a112	f664: Message waiting notification is active and this message has an expiration date of. DATE

a113	# VERSION > 2 INTUITY 3.0.
	# NUMBER = 1 if fax enabled,
	# NUMBER = 0 if fax is not enabled.
	# CAD = Call Answer Disable and ABR = Address Before Record. XEROX Features
	# Introduced in INTUITY 3.0
	# NUMBER(2) is CAD and 0 is inactive and 1 is active.
	# NUMBER(3) is ABR and 0 is inactive and 1 is active.
	# a1174 is called by this announcement to determine the appropriate
	# fragment to be played depending on what features were active.
	IF (VERSION > 2)
	THEN
	    f305: You are at the activity menu.
	    IF (NUMBER==0)
	    THEN
	        f990: To record and send voice mail messages, press 1.
	    ELSE
	        f991: To record and send voice mail or fax

Announcement	Fragments

	messages, press 1.
	ENDIF,
	f992: To get messages, press 2.
	f1016: To administer your greeting, press 3.
	f996: To check your outgoing messages, press 4.
	a1174(NUMBER,NUMBER(2),NUMBER(3)),
	IF(NUMBER == 0)
	  THEN
	    f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7.
	  ELSE
	    f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logon, press Star Star 7.
	  ENDIF,
	f291: To transfer to another extension, press star 8.
	f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
	ELSE
	f305: You are at the activity menu.
	f23: To record messages, press 1. To get messages, press 2. To administer your greeting, press 3.
	f48: To check your outgoing messages, press 4. To administer mailing list, personal directory, password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7.
	f291: To transfer to another extension, press star 8.
	f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
	ENDIF

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a114	# VERSION > 2 INTUITY 3.0.
	# NUMBER = 1 if fax enabled,
	# NUMBER = 0 if fax is not enabled.
	# CAD = Call Answer Disable and ABR = Address Before
	Record. XEROX Features
	# Introduced in INTUITY 3.0
	# NUMBER(2) is CAD and 0 is inactive and 1 is active.
	# NUMBER(3) is ABR and 0 is inactive and 1 is active.
	# a1174 is called by this announcement to determine the
	appropriate
	# fragment to be played depending on what features were
	active.
	IF (VERSION > 2)
	THEN
	     f305: You are at the activity menu.
	     IF (NUMBER==0)
	     THEN
	          f990: To record and send voice mail
	          messages, press 1.
	     ELSE
	          f991: To record and send voice mail or fax
	          messages, press 1.
	     ENDIF,
	     f992: To get messages, press 2.
	     f1013: To administer attendant menu, press 3.
	     f996: To check your outgoing messages, press 4.
	     a1174(NUMBER,NUMBER(2),NUMBER(3)),
	     IF(NUMBER == 0)
	       THEN
	          f1001: To change outcalling information,
	          press 6. To scan incoming messages
	          automatically, press 7. To re-logon, press
	          star star 7.
	       ELSE
	          f1165: To change outcalling information,
	          press 6. To scan incoming messages
	          automatically or print all new faxes, press
	          7. To re-logon, press Star Star 7.
	       ENDIF,
	     f291: To transfer to another extension, press
	     star 8.
	     f117: To reach the covering extension, press star
	     zero.
	     f282: To have system wait, press star 9. To
	     access the names or numbers directory, press star
	     star 6. If finished, please hang up or to
	     disconnect AUDIX, press star star 9.
	ELSE
	     f305: You are at the activity menu.
	     f984: To record and send voice mail messages,
	     press 1. To get messages, press 2. To administer
	     attendant menu, press 3.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	f48: To check your outgoing messages, press 4. To administer mailing list, personal directory, password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7. f291: To transfer to another extension, press star 8. f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9. ENDIF

Announcement	Fragments

a115	# VERSION > 2 INTUITY 3.0.
	# NUMBER = 1 if fax enabled,
	# NUMBER = 0 if fax is not enabled.
	# CAD = Call Answer Disable and ABR = Address Before Record. XEROX Features
	# Introduced in INTUITY 3.0
	# NUMBER(2) is CAD and 0 is inactive and 1 is active.
	# NUMBER(3) is ABR and 0 is inactive and 1 is active.
	# a1174 is called by this announcement to determine the appropriate
	# fragment to be played depending on what features were active.
	IF (VERSION > 2)
	THEN
	     f305: You are at the activity menu.
	     IF (NUMBER==0)
	     THEN
	         f990: To record and send voice mail messages, press 1.
	     ELSE
	         f991: To record and send voice mail or fax messages, press 1.
	     ENDIF,
	     f992: To get messages, press 2.
	     f1006: To record or change the greeting heard by callers, press 3.
	     f996: To check your outgoing messages, press 4.
	     a1174(NUMBER,NUMBER(2),NUMBER(3)),
	     IF(NUMBER == 0)
	      THEN
	         f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7.
	      ELSE
	         f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logon, press Star Star 7.
	      ENDIF,
	     f291: To transfer to another extension, press star 8.
	     f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
	ELSE
	     f305: You are at the activity menu.
	     f986: To record and send voice mail messages, press 1. To get messages, press 2. To record or change the greetings heard by callers, press 3.
	     f48: To check your outgoing messages, press 4. To

Announcement	Fragments
	administer mailing list, personal directory, password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7. f291: To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9. ENDIF
a116	f493: You are requesting a transfer. f562: Enter the NUMBER, f563: digit extension f119: you wish to call f224: and pound sign. f115: To transfer using names instead, press star 2. f105: To restart at the activity menu, press star 7. f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a117	f493: You are requesting a transfer. f562: Enter the NUMBER, f563: digit extension f119: you wish to call f224: and pound sign. f115: To transfer using names instead, press star 2. f105: To restart at the activity menu, press star 7. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

Announcement	Fragments
a118	f847: You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to or forward the message, press 1. f849: To skip to the next message, press the pound sign. To listen to the header, rewind by pressing 2, then play by pressing 3. To skip to the next category, press star pound. f577: To hold the message in its current category, press star star 4 f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star 3.

a119	# VERSION > 2 INTUITY 3.0.
	# NUMBER = 1 if fax enabled,
	# NUMBER = 0 if fax is not enabled.
	# CAD = Call Answer Disable and ABR = Address Before Record. XEROX Features
	# Introduced in INTUITY 3.0
	# NUMBER(2) is CAD and 0 is inactive and 1 is active.
	# NUMBER(3) is ABR and 0 is inactive and 1 is active.
	# a1174 is called by this announcement to determine the appropriate
	# fragment to be played depending on what features were active.
	IF (VERSION > 2)
	THEN
	     f305: You are at the activity menu.
	     IF (NUMBER==0)
	     THEN
	         f990: To record and send voice mail messages, press 1.
	     ELSE
	         f991: To record and send voice mail or fax messages, press 1.
	     ENDIF,
	     f992: To get messages, press 2.
	     f996: To check your outgoing messages, press 4.
	     a1174(NUMBER,NUMBER(2),NUMBER(3)),
	     IF(NUMBER == 0)
	      THEN
	         f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7.
	      ELSE
	         f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logon, press Star Star 7.
	      ENDIF,

Announcement	Fragments

	f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
	ELSE
	f305: You are at the activity menu.
	f985: To record and send voice mail messages, press 1. To get messages, press 2.
	f48: To check your outgoing messages, press 4. To administer mailing list, personal directory, password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7.
	f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
	ENDIF

Announcement	Fragments

a120	```# VERSION > 2 INTUITY 3.0.```
	 ```# NUMBER = 1 if fax enabled,```
	 ```# NUMBER = 0 if fax is not enabled.```
	 ```# CAD = Call Answer Disable and ABR = Address Before```
	 ```Record. XEROX Features```
	 ```# Introduced in INTUITY 3.0```
	 ```# NUMBER(2) is CAD and 0 is inactive and 1 is active.```
	 ```# NUMBER(3) is ABR and 0 is inactive and 1 is active.```
	 ```# a1174 is called by this announcement to determine the```
	 ```appropriate```
	 ```# fragment to be played depending on what features were```
	 ```active.```
	 ```IF (VERSION > 2)```
	 ```THEN```
	 ``` f305: You are at the activity menu.```
	 ``` IF (NUMBER==0)```
	 ``` THEN```
	 ``` f990: To record and send voice mail```
	 ``` messages, press 1.```
	 ``` ELSE```
	 ``` f991: To record and send voice mail or fax```
	 ``` messages, press 1.```
	 ``` ENDIF,```
	 ``` f992: To get messages, press 2.```
	 ``` f1013: To administer attendant menu, press 3.```
	 ``` f996: To check your outgoing messages, press 4.```
	 ``` a1174(NUMBER,NUMBER(2),NUMBER(3)),```
	 ``` IF(NUMBER == 0)```
	 ``` THEN```
	 ``` f1001: To change outcalling information,```
	 ``` press 6. To scan incoming messages```
	 ``` automatically, press 7. To re-logon, press```
	 ``` star star 7.```
	 ``` ELSE```
	 ``` f1165: To change outcalling information,```
	 ``` press 6. To scan incoming messages```
	 ``` automatically or print all new faxes, press```
	 ``` 7. To re-logon, press Star Star 7.```
	 ``` ENDIF,```
	 ``` f282: To have system wait, press star 9. To```
	 ``` access the names or numbers directory, press star```
	 ``` star 6. If finished, please hang up or to```
	 ``` disconnect AUDIX, press star star 9.```
	 ```ELSE```
	 ``` f305: You are at the activity menu.```
	 ``` f984: To record and send voice mail messages,```
	 ``` press 1. To get messages, press 2. To administer```
	 ``` attendant menu, press 3.```
	 ``` f48: To check your outgoing messages, press 4. To```
	 ``` administer mailing list, personal directory,```
	 ``` password, or account name, press 5. To change```
	 ``` outcalling information, press 6. To scan incoming```

Announcement	Fragments
	messages automatically, press 7. To re-logon, press star star 7. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9. ENDIF

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a121	# VERSION > 2 INTUITY 3.0.
	# NUMBER = 1 if fax enabled,
	# NUMBER = 0 if fax is not enabled.
	# CAD = Call Answer Disable and ABR = Address Before
	Record. XEROX Features
	# Introduced in INTUITY 3.0
	# NUMBER(2) is CAD and 0 is inactive and 1 is active.
	# NUMBER(3) is ABR and 0 is inactive and 1 is active.
	# a1174 is called by this announcement to determine the
	appropriate
	# fragment to be played depending on what features were
	active.
	IF (VERSION > 2)
	THEN
	     f305: You are at the activity menu.
	     IF (NUMBER==0)
	     THEN
	        f990: To record and send voice mail
	        messages, press 1.
	     ELSE
	        f991: To record and send voice mail or fax
	        messages, press 1.
	     ENDIF,
	     f992: To get messages, press 2.
	     f1006: To record or change the greeting heard by
	     callers, press 3.
	     f996: To check your outgoing messages, press 4.
	     a1174(NUMBER,NUMBER(2),NUMBER(3)),
	     IF(NUMBER == 0)
	      THEN
	        f1001: To change outcalling information,
	        press 6. To scan incoming messages
	        automatically, press 7. To re-logon, press
	        star star 7.
	      ELSE
	        f1165: To change outcalling information,
	        press 6. To scan incoming messages
	        automatically or print all new faxes, press
	        7. To re-logon, press Star Star 7.
	      ENDIF,
	     f291: To transfer to another extension, press
	     star 8.
	     f117: To reach the covering extension, press star
	     zero.
	     f282: To have system wait, press star 9. To
	     access the names or numbers directory, press star
	     star 6. If finished, please hang up or to
	     disconnect AUDIX, press star star 9.
	ELSE
	     f305: You are at the activity menu.
	     f986: To record and send voice mail messages,
	     press 1. To get messages, press 2. To record or

Announcement	Fragments
	change the greetings heard by callers, press 3. f48: To check your outgoing messages, press 4. To administer mailing list, personal directory, password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7. f291: To transfer to another extension, press star 8. f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9. ENDIF
a122	f848: You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to the message, press 1. f849: To skip to the next message, press the pound sign. To listen to the header, rewind by pressing 2, then play by pressing 3. To skip to the next category, press star pound. f577: To hold the message in its current category, press star star 4 f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star 3.
a123	f323: You are responding to a piece of incoming mail. f41: To forward message with comment at beginning, press 2. f126: To forward message with comment at end, press 3. f8: To record a new message, press 4. f1434: To return to getting messages, press pound. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a124	f375: You are getting your incoming messages. To listen to the message, press 0. To respond to the message, press 1. f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing 2, then play by pressing 3. To skip to the next category, press star pound. f577: To hold the message in its current category, press star star 4 f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star 3.

a125	# VERSION > 2 INTUITY 3.0.
	# NUMBER = 1 if fax enabled,
	# NUMBER = 0 if fax is not enabled.
	# CAD = Call Answer Disable and ABR = Address Before Record. XEROX Features
	# Introduced in INTUITY 3.0
	# NUMBER(2) is CAD and 0 is inactive and 1 is active.
	# NUMBER(3) is ABR and 0 is inactive and 1 is active.
	# a1174 is called by this announcement to determine the appropriate
	# fragment to be played depending on what features were active.
	IF (VERSION > 2)
	THEN
	      f305: You are at the activity menu.
	      IF (NUMBER==0)
	      THEN
	            f990: To record and send voice mail messages, press 1.
	      ELSE
	            f991: To record and send voice mail or fax messages, press 1.
	      ENDIF,
	      f992: To get messages, press 2.
	      f996: To check your outgoing messages, press 4.
	      a1174(NUMBER,NUMBER(2),NUMBER(3)),
	      IF(NUMBER == 0)
	        THEN
	            f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7.
	        ELSE
	            f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logon, press Star Star 7.
	        ENDIF,

Announcement	Fragments

	f291: To transfer to another extension, press star 8.
	f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
	
	ELSE
	f305: You are at the activity menu.
	f985: To record and send voice mail messages, press 1. To get messages, press 2.
	f48: To check your outgoing messages, press 4. To administer mailing list, personal directory, password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7.
	f291: To transfer to another extension, press star 8.
	f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
	ENDIF

a126	f323: You are responding to a piece of incoming mail. f486: To reply to sender by voice mail, press 1. f8: To record a new message, press 4. f1434: To return to getting messages, press pound. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a127	# VERSION > 2 INTUITY 3.0.
	# NUMBER = 1 if fax enabled,
	# NUMBER = 0 if fax is not enabled.
	# CAD = Call Answer Disable and ABR = Address Before
	Record. XEROX Features
	# Introduced in INTUITY 3.0
	# NUMBER(2) is CAD and 0 is inactive and 1 is active.
	# NUMBER(3) is ABR and 0 is inactive and 1 is active.
	# a1174 is called by this announcement to determine the
	appropriate
	# fragment to be played depending on what features were
	active.
	IF (VERSION > 2)
	THEN
	     f305: You are at the activity menu.
	     IF (NUMBER==0)
	     THEN
	         f990: To record and send voice mail
	         messages, press 1.
	     ELSE
	         f991: To record and send voice mail or fax
	         messages, press 1.
	     ENDIF,
	     f992: To get messages, press 2.
	     f1006: To record or change the greeting heard by
	callers, press 3.
	     f996: To check your outgoing messages, press 4.
	     a1174(NUMBER,NUMBER(2),NUMBER(3)),
	     IF(NUMBER == 0)
	       THEN
	          f1001: To change outcalling information,
	          press 6. To scan incoming messages
	          automatically, press 7. To re-logon, press
	          star star 7.
	       ELSE
	          f1165: To change outcalling information,
	          press 6. To scan incoming messages
	          automatically or print all new faxes, press
	          7. To re-logon, press Star Star 7.
	       ENDIF,
	     f291: To transfer to another extension, press
	star 8.
	     f117: To reach the covering extension, press star
	zero.
	     f282: To have system wait, press star 9. To
	access the names or numbers directory, press star
	star 6. If finished, please hang up or to
	disconnect AUDIX, press star star 9.
	ELSE
	     f305: You are at the activity menu.
	     f983: To record and send voice mail messages,
	press 1. To get messages, press 2. To record or

Announcement	Fragments
	change the greeting heard by callers, press 3. f48: To check your outgoing messages, press 4. To administer mailing list, personal directory, password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7. f291: To transfer to another extension, press star 8. f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9. ENDIF
a128	f323: You are responding to a piece of incoming mail. f8: To record a new message, press 4. f1434: To return to getting messages, press pound. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| a129 | ```
# VERSION > 2 INTUITY 3.0.
# NUMBER = 1 if fax enabled,
# NUMBER = 0 if fax is not enabled.
# CAD = Call Answer Disable and ABR = Address Before
Record.  XEROX Features
# Introduced in INTUITY 3.0
# NUMBER(2) is CAD and 0 is inactive and 1 is active.
# NUMBER(3) is ABR and 0 is inactive and 1 is active.
# a1174 is called by this announcement to determine the
appropriate
# fragment to be played depending on what features were
active.
IF (VERSION > 2)
THEN
        f305:  You are at the activity menu.
        IF (NUMBER==0 )
        THEN
                f990:  To record and send voice mail
                messages, press 1.
        ELSE
                f991:  To record and send voice mail or fax
                messages, press 1.
        ENDIF,
        f992:  To get messages, press 2.
        f996:  To check your outgoing messages, press 4.
        a1174(NUMBER,NUMBER(2),NUMBER(3)),
        IF( NUMBER == 0 )
          THEN
                f1001:  To change outcalling information,
                press 6. To scan incoming messages
                automatically, press 7. To re-logon, press
                star star 7.
          ELSE
                f1165:  To change outcalling information,
                press 6.  To scan incoming messages
                automatically or print all new faxes, press
                7.  To re-logon, press Star Star 7.
          ENDIF,
        f291:  To transfer to another extension, press
        star 8.
        f117:  To reach the covering extension, press star
        zero.
        f282:  To have system wait, press star 9. To
        access the names or numbers directory, press star
        star 6. If finished, please hang up or to
        disconnect AUDIX, press star star 9.
ELSE
        f305:  You are at the activity menu.
        f985:  To record and send voice mail messages,
        press 1. To get messages, press 2.
        f48:  To check your outgoing messages, press 4. To
        administer mailing list, personal directory,
``` |

Announcement	Fragments
	password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7. f291: To transfer to another extension, press star 8. f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9. ENDIF
a130	f659: Message waiting notification will alert all local subscribers of this message. This option should be used sparingly, for it can impact system performance.
a131	f725: You are adding entries to your personal directory. f832: Please enter extension and pound sign. f833: To delete current entry, press star 3. f58: For name addressing, press star 2. f913: If finished, press pound.
a132	f725: You are adding entries to your personal directory. f118: Enter last name f224: and pound sign. f833: To delete current entry, press star 3. f148: For extension addressing, press star 2. f913: If finished, press pound.
a133	f657: You are choosing options for this broadcast message.
a134	f654: the message will be broadcast and private.
a135	f649: the message will be broadcast.
a136	f723: You are administering your personal directory. f706: To add entries, press 1. To review all entries, press 2. To review a specific entry, press 3. f913: If finished, press pound.
a137	f325: You are administering your lists. To create a mailing list, press 1. To play a summary of all your lists, press 2. To review a particular list, press 3.
a138	f665: You are choosing options for this login announcement.
a139	f650: the message will be a login announcement.
a140	f652: A broadcast message is delivered to every subscriber on this machine. You may also address a broadcast message to subscribers on other machines.
a141	f655: A login announcement will be played each time any subscriber logs onto this machine. You may also address a login message to subscribers on other machines.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a142	f670: Non-interruptible status forces each subscriber to listen to the entire login announcement every time they log onto this machine.
a143	f670: Non-interruptible status forces each subscriber to listen to the entire login announcement every time they log onto this machine. f626: To specify expiration date, press 2. f671: Expiration date specifies the last day this login announcement will be available to subscribers. The default expiration date is the second day after the scheduled delivery date. f661: To approve these options, press pound. f774: If you have addressed this message and wish to deliver it immediately, press star star pound.
a144	f646: A priority message will be delivered before other messages and will be flagged for special attention in the recipient's mailbox.
a145	f645: Private messages cannot be forwarded by the recipients.
a146	f662: Message waiting notification is active. f628: To deactivate message waiting notification, press 1. f659: Message waiting notification will alert all local subscribers of this message. This option should be used sparingly, for it can impact system performance. f626: To specify expiration date, press 2.
a147	f288: You are in the names directory. To find a subscriber's extension, enter the last name followed by the pound sign. To enter the letter Q, press 7; for Z press 9. To look up by extension instead press star 2. f277: To exit directory, press pound. f105: To restart at the activity menu, press star 7. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.
a148	f666: With the current settings, this login announcement will be non-interruptible.
a149	f643: You are choosing options for this message. There are no options currently set. f612: To make private, press 1. f645: Private messages cannot be forwarded by the recipients.
a150	f610: You are recording your name. After you record your name, you can access other AUDIX features. As you use AUDIX your name will be included in system announcements that you and other people will hear. Press 1 and at the tone, please speak your first and last name as you would like others to hear it. After speaking your name, press 1 again.
a151	f611: You are recording your name. To record your name, press 1. After recording, press 1 again. To playback

Announcement	Fragments
	name, press 2-3. To approve, press pound.
a152	f322: You are in the numbers directory. To find a subscriber's name enter the extension followed by the pound sign. To look up by name instead, press star 2. f277: To exit directory, press pound. f105: To restart at the activity menu, press star 7. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.
a153	f838: You are selecting which messages will receive outcalls.

a154	`# VERSION > 2 is INTUITY FAX feature.  FAX enabled == 1,`
	 `FAX not enabled == 0`
	 `IF (VERSION > 2)`
	 `THEN`
	     `IF (NUMBER > 0)`
	     `THEN`
	        `f1005:  Load your document into the FAX`
	        `machine.  To send, press pound or enter an`
	        `option.`
	        `f1002:  To hear a list of options, press 0.`
	     `ELSE`
	        `f916:  To send message, press pound or enter`
	        `an option, to hear a list of options,  press`
	        `zero.`
	     `ENDIF`
	 `ELSE`
	     `f916:  To send message, press pound or enter an`
	     `option, to hear a list of options,  press zero.`
	 `ENDIF`

a155	f644: You are choosing options for this message. With the current settings,
a156	f648: the message will be priority.
a157	f726: You are reviewing all entries in your personal directory. f372: To skip to next entry, press pound. To delete current entry, press star 3. f852: To rewind to the current entry, press 2. To rewind to previous entries, press 2 as many times as necessary.
a158	f729: You are reviewing a specific entry in your personal directory. To delete the current entry, press star 3. To review another entry, enter the alias followed by the pound sign.

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a159	# VERSION > 2 INTUITY 3.0.
	# NUMBER = 1 if fax enabled,
	# NUMBER = 0 if fax is not enabled.
	# CAD = Call Answer Disable and ABR = Address Before
	Record. XEROX Features
	# Introduced in INTUITY 3.0
	# NUMBER(2) is CAD and 0 is inactive and 1 is active.
	# NUMBER(3) is ABR and 0 is inactive and 1 is active.
	# a1174 is called by this announcement to determine the
	appropriate
	# fragment to be played depending on what features were
	active.
	IF (VERSION > 2)
	THEN
	     f305: You are at the activity menu.
	     IF (NUMBER==0)
	     THEN
	         f990: To record and send voice mail
	         messages, press 1.
	     ELSE
	         f991: To record and send voice mail or fax
	         messages, press 1.
	     ENDIF,
	     f992: To get messages, press 2.
	     f1006: To record or change the greeting heard by
	     callers, press 3.
	     f996: To check your outgoing messages, press 4.
	     a1174(NUMBER,NUMBER(2),NUMBER(3)),
	     IF(NUMBER == 0)
	      THEN
	         f1001: To change outcalling information,
	         press 6. To scan incoming messages
	         automatically, press 7. To re-logon, press
	         star star 7.
	      ELSE
	         f1165: To change outcalling information,
	         press 6. To scan incoming messages
	         automatically or print all new faxes, press
	         7. To re-logon, press Star Star 7.
	      ENDIF,
	     f282: To have system wait, press star 9. To
	     access the names or numbers directory, press star
	     star 6. If finished, please hang up or to
	     disconnect AUDIX, press star star 9.
	ELSE
	     f305: You are at the activity menu.
	     f986: To record and send voice mail messages,
	     press 1. To get messages, press 2. To record or
	     change the greetings heard by callers, press 3.
	     f48: To check your outgoing messages, press 4. To
	     administer mailing list, personal directory,
	     password, or account name, press 5. To change

Announcement	Fragments
	outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9. ENDIF
a160	f660: Expiration date specifies the last day this broadcast message will be available to subscribers. The expiration date does not apply to a broadcast message already received by a subscriber and saved in their mailbox. The default expiration date is the second day after the scheduled delivery date. f661: To approve these options, press pound. f774: If you have addressed this message and wish to deliver it immediately, press star star pound.
a161	f800: You are specifying the expiration date. f660: Expiration date specifies the last day this broadcast message will be available to subscribers. The expiration date does not apply to a broadcast message already received by a subscriber and saved in their mailbox. The default expiration date is the second day after the scheduled delivery date. f384: Please enter number of month, then two digits for day, and pound sign. f831: To exit the expiration date options, press star pound. f774: If you have addressed this message and wish to deliver it immediately, press star star pound.
a163	f671: Expiration date specifies the last day this login announcement will be available to subscribers. The default expiration date is the second day after the scheduled delivery date. f661: To approve these options, press pound. f774: If you have addressed this message and wish to deliver it immediately, press star star pound.
a164	f651: the message will be private and priority.

Announcement	Fragments

a165	```
	# VERSION > 2 is for INTUITY 3.0 Fax Feature.
	# NUMBER == 0 if fax not allowed, and 1 if fax allowed.
	# NUMBER(2) used for Address Before Record feature
	(ABR) -(XEROX feature)
	# introduced in INTUITY 3.0
	# NUMBER(2) == 0 for addressing options not allowed, 1
	for addressing options
	# allowed.
	# NUMBER(3) used for Call Answer Disable feature (CAD)
	(XEROX feature)
	# introduced in INTUITY 3.0
	# NUMBER(3) == is 0 for call answer options not allowed,
	1 for call answer
	# options allowed.
	# This is the help at subscriber admin w/o "record name"
	fragment.
	IF (VERSION > 2)
	THEN
	        f703: You are at subscriber administration.
	        f700: To administer mailing lists, press 1. To
	        administer personal directory, press 2.
	        IF (NUMBER == 1)
	        THEN
	                f1052: To specify your fax preferences,
	                press 3.
	        ENDIF,
	        f701: To change your password, press 4.
	        IF (NUMBER(2) == 1)
	        THEN
	                f1144: To specify whether a message can be
	                addressed before it's recorded, press 6.
	        ENDIF,
	        IF (NUMBER(3) == 1)
	        THEN
	                f1145: To administer call answer options,
	                press 7.
	        ENDIF
	ELSE
	        f703: You are at subscriber administration.
	        f700: To administer mailing lists, press 1. To
	        administer personal directory, press 2.
	        f701: To change your password, press 4.
	ENDIF
	``

a166	``` # VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == 0 if fax not allowed, and 1 if fax allowed. # NUMBER(2) used for Address Before Record(ABR)-(XEROX feature) # introduced in INTUITY 3.0 # NUMBER(2) == 0 for addressing options not allowed, 1 for addressing options # allowed. ```

Announcement	Fragments

	# NUMBER(3) used for Call Answer Disable feature (CAD) (XEROX feature)
	# introduced in INTUITY 3.0
	# NUMBER(3) == is 0 for call answer options not allowed, 1 for call answer
	# options allowed.
	IF (VERSION > 2)
	THEN
	    f703: You are at subscriber administration.
	    f700: To administer mailing lists, press 1. To administer personal directory, press 2.
	    IF (NUMBER == 1)
	    THEN
	        f1052: To specify your fax preferences, press 3.
	    ENDIF,
	    f701: To change your password, press 4.
	    f702: To record your name, press 5.
	    IF (NUMBER(2) == 1)
	    THEN
	        f1144: To specify whether a message can be addressed before it's recorded, press 6.
	    ENDIF,
	    IF (NUMBER(3) == 1)
	    THEN
	        f1145: To administer call answer options, press 7.
	    ENDIF
	ELSE
	    f703: You are at subscriber administration.
	    f700: To administer mailing lists, press 1. To administer personal directory, press 2.
	    f701: To change your password, press 4.
	    f702: To record your name, press 5.
	ENDIF

a167	f736: You are recording your name. As you use AUDIX your name will be included in system announcements that you and other people will hear. f608: At the tone, please speak your name. After speaking your name, press 1.

Announcement	Fragments
a168	f323: You are responding to a piece of incoming mail. f486: To reply to sender by voice mail, press 1. f8: To record a new message, press 4. f163: To call sender, press zero. f1434: To return to getting messages, press pound. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a169	f323: You are responding to a piece of incoming mail. f8: To record a new message, press 4. f163: To call sender, press zero. f1434: To return to getting messages, press pound. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a170	f323: You are responding to a piece of incoming mail. f41: To forward message with comment at beginning, press 2. f126: To forward message with comment at end, press 3. f8: To record a new message, press 4. f163: To call sender, press zero. f1434: To return to getting messages, press pound. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a171	f493: You are requesting a transfer. f987: Enter last name of the person f119: you wish to call f224: and pound sign. f290: If you wish to specify a non-AUDIX subscriber, first change to extension addressing by pressing star 2. f105: To restart at the activity menu, press star 7. f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a172	f493: You are requesting a transfer. f987: Enter last name of the person f119: you wish to call f224: and pound sign. f290: If you wish to specify a non-AUDIX subscriber,

Announcement	Fragments
	first change to extension addressing by pressing star 2. f105: To restart at the activity menu, press star 7. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a173	NAME
a174	NAME, f822: As you use AUDIX your name will be included in system announcements that you and other people will hear. At the tone, please speak your name. After speaking your name, press 1.
a175	NAME, f146: To continue, press pound. f143: To step back again, press 2.
a176	NAME, f146: To continue, press pound.
a177	NAME, f680: is busy. Sorry, you cannot leave a message now because this user's mailbox is full.
a178	NAME, f197: Cannot step back.
a179	NAME, f75: To skip, press pound. To delete, press star 3. f294: To add entries, press 1.
a180	NAME, f388: To skip, press the pound key.
a181	NAME, f74: deleted.
a182	NAME, f679: is not available. Sorry, you cannot leave a message now because this user's mailbox is full.

Announcement	Fragments
| a183 | ```
# VERSION > 2 is INTUITY 3.0 FAX.  Calling a new
announcement was cleaner
# then trying to change this one.  NUMBER(4) == number
of fax messages.
NAME,
IF (VERSION > 2)
THEN
        a1169(NUMBER,NUMBER(2),NUMBER(3),NUMBER(4))
ELSE
        IF (VERSION>1)
        THEN
                IF (NUMBER(2)>0)
                THEN
                        #password is about to expire
                        a1153(NUMBER(3))
                ENDIF
        ENDIF,
        NUMBER,
        f63:  new
        f601:  Priority
        IF (NUMBER==1)
        THEN
                f160:  message
        ELSE
                f168:  messages.
        ENDIF
ENDIF
``` |
| a184 | ```
# VERSION > 2 is INTUITY 3.0 FAX.  Calling a new
announcement was cleaner
# then trying to change this one.  NUMBER(5) == number
of fax messages.
NAME,
IF (VERSION>2)
THEN
        a1167(NUMBER,NUMBER(2),NUMBER(3),NUMBER(4),NUMBER(
5))
ELSE
        IF (VERSION>1)
        THEN
                IF (NUMBER(3)>0)
                THEN
                        #password is about to expire
                        a1153(NUMBER(4))
                ENDIF
        ENDIF,
        NUMBER + NUMBER(2),
        f63:  new
        f345:  Voice mail
        IF (NUMBER + NUMBER(2) == 1 )
        THEN
                f160:  message
``` |

Announcement	Fragments
| | ```
        ELSE
                f168:  messages.
        ENDIF,
        f17:  including
        NUMBER,
        f601:  Priority
        IF (NUMBER == 1)
        THEN
                f160:  message
        ELSE
                f168:  messages.
        ENDIF
ENDIF
``` |
| a185 | ```
NAME,
IF (VERSION>1)
THEN
        IF (NUMBER(2)>0)
        THEN
                #password is about to expire
                a1153(NUMBER(3))
        ENDIF
ENDIF,
IF (VERSION > 2)
THEN
        NUMBER,
        f63:  new
        IF (NUMBER==1)
        THEN
                f160:  message
        ELSE
                f168:  messages.
        ENDIF,
        IF (NUMBER(4) > 0)
        THEN
                NUMBER(4),
                f1011:  with fax.
        ENDIF
ELSE
        NUMBER,
        f63:  new
        f345:  Voice mail
        IF (NUMBER==1)
        THEN
                f160:  message
        ELSE
                f168:  messages.
        ENDIF
ENDIF
``` |

Announcement	Fragments
a186	NAMEEXT
a187	NAMEEXT, f74: deleted.
a188	NAMEEXT, f722: was not added to your personal directory.

a190	`# VERSION > 2 is INTUITY 3.0 FAX.  Calling a new`
	`announcement was cleaner`
	`# then trying to change this one.  NUMBER(3) == number`
	`of fax messages.`
	`IF (VERSION > 2)`
	`THEN`
	`        a1168(NUMBER, NUMBER(2), NUMBER(3))`
	`ELSE`
	`        NUMBER + NUMBER(2),`
	`        f63:  new`
	`        f345:  Voice mail`
	`        IF (NUMBER + NUMBER(2) == 1 )`
	`        THEN`
	`                f160:  message`
	`        ELSE`
	`                f168:  messages.`
	`        ENDIF,`
	`        f17:  including`
	`        NUMBER,`
	`        f601:  Priority`
	`        IF (NUMBER == 1)`
	`        THEN`
	`                f160:  message`
	`        ELSE`
	`                f168:  messages.`
	`        ENDIF`
	`ENDIF`

a191	f158: Transfer cannot be completed. f236: Try again f109: later. f95: Please disconnect.

a192	`#NUMBER: 0 is stacked response off, 1 is stacked`
	`response on`
	`#NUMBER(2): 0 is forwarding not allowed, 1 is forwarding`
	`allowed`
	`#NUMBER(3): 0 if sender doesn't exist, 1 if sender exits`
	`#NUMBER(4): 1 if FAX enabled, 0 if FAX is not enabled.`
	`#NUMBER(5): 1 is voice only, 2 is fax only, 3 is voice`
	`and fax`
	`# VERSION > 2 INTUITY MACH 3.0 Fax Feature`
	`#`
	`IF (VERSION<2)`
	`THEN`
	`        #Definity Audix 3.0`

Announcement	Fragments
| | ```
        f234:  To respond or forward, press 1.
ELSE
        #Definity Audix 3.1
        IF (NUMBER==0)
        THEN
                #stacked response feature off
                IF (NUMBER(2)==0)
                THEN
                        #no forwarding
                        f252:  To respond to this message,
                        press 1.
                ELSE
                        #forwarding
                        f234:  To respond or forward, press 1.
                ENDIF
        ELSE
                #stacked response feature on
                IF (NUMBER(3)==1)
                THEN
                        #sender of message exists, may reply
                        f1463:  To reply to sender by voice
                        mail, press 1, 7.
                ENDIF,
                IF (NUMBER(2)==1)
                THEN
                        #forwarding allowed
                        f1464:  To forward with comment, press
                        1, 2.
                ENDIF,
                f1465:  To record a new message, press 1, 4.
        ENDIF
ENDIF,
IF (VERSION > 2)
THEN
        # INTUITY 3.0
        IF (NUMBER(5) != 1)
        THEN
                # Not voice only
                IF (NUMBER(4) == 1)
                THEN
                        # fax enabled, prompt for printing
                        f1073:  To print, press star 1.
                ENDIF
        ENDIF
ENDIF,
f24:  To delete,  press star 3.
f388:  To skip, press the pound key.
``` |

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a193	f562: Enter the NUMBER, f563: digit extension f224: and pound sign. f117: To reach the covering extension, press star zero. f115: To transfer using names instead, press star 2.
a194	f562: Enter the NUMBER, f563: digit extension f224: and pound sign. f117: To reach the covering extension, press star zero. f115: To transfer using names instead, press star 2. f335: When finished, press pound.
a195	f562: Enter the NUMBER, f563: digit extension f224: and pound sign. f115: To transfer using names instead, press star 2.
a196	f562: Enter the NUMBER, f563: digit extension f224: and pound sign. f115: To transfer using names instead, press star 2. f335: When finished, press pound.
a197	f94: Good-bye.
a199	f592: AUDIX passwords must now be NUMBER, f81: digits. f593: Please choose a new password of NUMBER(2), f81: digits. f173: Please enter new password f224: and pound sign.
a200	f105: To restart at the activity menu, press star 7. f238: To review another list,
a201	f213: Re-enter password f224: and pound sign.
a202	f18: To forward with comment, press 2. f8: To record a new message, press 4.
a204	f486: To reply to sender by voice mail, press 1. f8: To record a new message, press 4.
a205	f8: To record a new message, press 4.
a206	f252: To respond to this message, press 1. f24: To delete, press star 3. f388: To skip, press the pound key.
a207	f930: Accessed Messages
a208	f625: To activate message waiting notification, press 1.
a210	f246: Message addressed to NAME, IF (NUMBER>0)

Announcement	Fragments

	THEN
	     f2: and
	NUMBER,
	IF (NUMBER==1)
	THEN
	       f602: other
	ELSE
	      f217: others
	ENDIF
	ENDIF

a211	f336: To review addressees, press star 1. f247: To add to list,
a212	f334: When finished addressing, press pound.
a213	f464: Enter extensions f224: and pound sign.
a214	f118: Enter last name f224: and pound sign.
a215	f832: Please enter extension and pound sign. f708: If finished adding entries, press pound.
a216	f118: Enter last name f224: and pound sign. f708: If finished adding entries, press pound.
a218	f464: Enter extensions f224: and pound sign. f335: When finished, press pound.
a219	f464: Enter extensions f224: and pound sign. f121: When finished, approve list by pressing pound.
a220	f131: To send to others not on your list,
a222	f118: Enter last name f224: and pound sign. f335: When finished, press pound.
a223	f118: Enter last name f224: and pound sign. f121: When finished, approve list by pressing pound.
a224	f711: Alias BUTTONS, f712: defined for NAME
a225	f711: Alias BUTTONS, f712: defined for NAMEEXT, f74: deleted.
a226	f711: Alias BUTTONS, f712: defined for NAMEEXT, f197: Cannot step back.

Announcement	Fragments
a227	f631: Message waiting notification activated. f632: Expiration date will be DATE
a228	f711: Alias BUTTONS, f712: defined for NAMEEXT, f372: To skip to next entry, press pound. To delete current entry, press star 3.
a229	f711: Alias BUTTONS, f185: not found.

a230	f744: For all calls,...
	IF (NUMBER==0)
	THEN
	    f776: the system greeting
	ELSE
	    f754: Greeting
	NUMBER
	ENDIF,
	f745: active.

a231	f716: Alias must be ten or fewer numerals.
a232	f716: Alias must be ten or fewer numerals. f727: Enter alias and pound sign.
a233	f717: Alias already defined.
a234	f709: Enter alias for NAME, f224: and pound sign.

a235	# The VERSION > 2 was introduced in INTUITY 3.0 FAX feature.
	# NUMBER(2) == number of fax messages.
	f2: and
	NUMBER,
	f63: new
	f601: Priority
	IF (NUMBER==1)
	THEN
	    f160: message
	ELSE
	    f168: messages.
	ENDIF,
	IF (VERSION > 2)
	THEN
	    IF (NUMBER(2) > 0)
	    THEN
	        NUMBER(2),
	        f1011: with fax.
	    ENDIF
	ENDIF

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a236	IF (VERSION > 2)
	THEN
	      f2: and
	     NUMBER,
	     f602: other
	     f63: new
	     IF (NUMBER==1)
	     THEN
	           f160: message
	     ELSE
	           f168: messages.
	     ENDIF,
	     IF (NUMBER(2) > 0)
	     THEN
	           NUMBER(2),
	           f1011: with fax.
	     ENDIF
	ELSE
	     f2: and
	     NUMBER,
	     f602: other
	     f63: new
	     f345: Voice mail
	     IF (NUMBER==1)
	     THEN
	           f160: message
	     ELSE
	           f168: messages.
	     ENDIF
	ENDIF

a237	f540: and from TIME, f524: to TIME(2)
a238	f16: Enter announcement id f224: and pound sign.
a239	f627: To approve broadcast options, press pound.
a240	f634: To approve login announcement options, press pound.
a241	f606: To re-record your name, press 1. To approve, press pound.
a242	f791: Calls identified as busy and no answer. f792: Calls identified as out-of-hours.
a243	f791: Calls identified as busy and no answer. f793: Calls not identified as out-of-hours.
a244	f790: Calls identified as internal and external. f792: Calls identified as out-of-hours.
a245	f790: Calls identified as internal and external. f793: Calls not identified as out-of-hours.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a246	f502: To record attendant menu, press 1. To listen to attendant menu, press 0. f105: To restart at the activity menu, press star 7.
a247	f506: Menu approved and activated.
a248	f505: You have selected an invalid option.
a249	f27: To attach original, press 9 for yes or 6 for no.
a250	f580: Cannot attach a private message
a251	f580: Cannot attach a private message f581: Press 6 now
a252	f504: Transferring to an operator,
a253	f508: Attendant Service not available, try again later. f95: Please disconnect.

a254	# VERSION > 2 is for INTUITY 3.0 Fax Feature.
	# NUMBER == 1-Fax , 0-no Fax.
	IF (VERSION > 2)
	THEN
	     f843: To scan headers and messages, press 1. To scan headers only, press 2. To scan messages only, press 3.
	     IF (NUMBER==1)
	     THEN
	          f1040: To print all new faxes, press 4.
	     ENDIF
	ELSE
	     f843: To scan headers and messages, press 1. To scan headers only, press 2. To scan messages only, press 3.
	ENDIF

a255	f29: Returned to checking status of outgoing messages.
a256	f640: Message cannot be both a login announcement and priority.
a257	f641: Message cannot be both a login announcement and private.
a258	f272: Contact administrator for help. f95: Please disconnect.
a259	f642: Message cannot be both broadcast and a login announcement
a260	f639: Message cannot be both broadcast and priority.
a261	f31: Date not understood. f384: Please enter number of month, then two digits for day, and pound sign.
a262	f32: You must enter your extension to logon.
a263	f100: Invalid Entry.
a264	f35: Login incorrect.
a265	f35: Login incorrect. f236: Try again
a266	f40: Time not understood. f383: Please enter hour, then two digits for minutes, then press 2 for A.M. or 7 for P.M., and pound sign.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a267	f13: To record, press 1. After recording, press 1 again.
a268	f683: Broadcaster has deleted this broadcast message.
| a269 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
                f1065:  Broadcast fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                        f1066:  Broadcast voice and fax
                        message from
                ELSE
                        f682:  Broadcast message from
                ENDIF
        ENDIF,
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
a1010(NUMBER,NUMBER(2),NUMBER(3))
ELSE
        f682:  Broadcast message from
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
a873(NUMBER)
ENDIF
``` |

Announcement	Fragments
| a270 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
                f1065:  Broadcast fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                        f1066:  Broadcast voice and fax
                        message from
                ELSE
                        f682:  Broadcast message from
                ENDIF
        ENDIF,
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
        a1010(NUMBER,NUMBER(2),NUMBER(3)),
        f689:  Expiration time is
TIME(2),DATE(2)
ELSE
        f682:  Broadcast message from
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
        a873(NUMBER),
        f689:  Expiration time is
TIME(2),DATE(2)
ENDIF
``` |
| a271 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
                f1065:  Broadcast fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                        f1066:  Broadcast voice and fax
                        message from
``` |

Announcement	Fragments
|  | ```
          ELSE
                 f682:  Broadcast message from
          ENDIF
      ENDIF,
      NAME,
      f262:  received
      TIME,DATE,
      f905:  <.5 second pause>
a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION
ELSE
      f682:  Broadcast message from
      NAME,
      f262:  received
      TIME,DATE,
      f905:  <.5 second pause>
a873(NUMBER),EXTENSION
ENDIF
``` |

Announcement	Fragments
| a272 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
                f1065:  Broadcast fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                        f1066:  Broadcast voice and fax
                        message from
                ELSE
                        f682:  Broadcast message from
                ENDIF
        ENDIF,
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
        a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION,
        f689:  Expiration time is
TIME(2),DATE(2)
ELSE
        f682:  Broadcast message from
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
        a873(NUMBER),EXTENSION,
        f689:  Expiration time is
TIME(2),DATE(2)
ENDIF
``` |
| a273 | ```
# VERSION > 2 is for INTUITY 3.0 Fax Feature.
# NUMBER == length of voice portion.
# NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice
and fax.
IF (VERSION > 2)
THEN
        IF (NUMBER(2) == 2)
        THEN
                f1128:  Broadcast fax message to
        ELSE
                IF (NUMBER(2) == 3)
                THEN
                        f1129:  Broadcast voice and fax
                        message to
                ELSE
``` |

Announcement	Fragments
| | ```
                    f1127:  Broadcast message to
                ENDIF
        ENDIF,
        f1117:  all local subscribers.
ELSE
        f693:  Broadcast message to all local subscribers
ENDIF,
IF (NUMBER>0)
THEN
        f2:  and
NUMBER,
IF (NUMBER==1)
THEN
                f602:  other
ELSE
                f217:  others
ENDIF
ENDIF
``` |
| a274 | f653: For broadcast options, press star 6. |
| a275 | f623: Broadcast. |

Announcement	Fragments
| a276 | ```
# VERSION > 2 is for INTUITY 3.0 Fax Feature.
# NUMBER == 1 if voice only, 2 if fax only, 3 if voice
and fax.
# NUMBER(2) == 1 if fax enabled, 0 if fax is disabled.
IF (VERSION > 2)
THEN
        IF ( NUMBER == 1)
        THEN
                f21:  To listen, press 0.
                f24:  To delete,  press star 3.
                f388:  To skip, press the pound key.
        ELSE
                IF (NUMBER == 2)
                THEN
                        IF (NUMBER(2) == 1)
                        THEN
                                f1073:  To print, press star 1.
                        ENDIF,
                        f24:  To delete,  press star 3.
                        f388:  To skip, press the pound key.
                ELSE
                        f21:  To listen, press 0.
                        IF (NUMBER(2) == 1)
                        THEN
                                f1073:  To print, press star 1.
                        ENDIF,
                        f24:  To delete,  press star 3.
                        f388:  To skip, press the pound key.
                ENDIF
        ENDIF
ELSE
        f21:  To listen, press 0.
        f24:  To delete,  press star 3.
        f388:  To skip, press the pound key.
ENDIF
``` |
| a277 | `f917:  To schedule delivery, press 3.` |
| a278 | ```
f749:  For busy calls,...
IF (NUMBER==0)
THEN
        f776:  the system greeting
ELSE
        f754:  Greeting
NUMBER
ENDIF,
f745:  active.
``` |
| a279 | ```
# VERSION > 2 is INTUITY FAX feature.  FAX enabled
NUMBER == 1,
# FAX not enable  NUMBER == 0
# NUMBER(2) is used for Call Answer Disable/Enable Xerox
Feature
# NUMBER(2) == 1 if call answer disabled turned on, 0 if
``` |

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| | ```
off.
IF (VERSION > 2)
THEN
        # INTUITY 3.0
        IF (NUMBER(2) == 1)
        THEN
                f1162:  Sorry, the mailbox you have reached
                is not accepting messages at this time.
                f95:  Please disconnect.
        ELSE
                f513:  Begin your message by saying the name
                and telephone number of the person you are
                calling.  Someone will listen to the start
                of your message, and then forward the
                complete message to the person you called.
                IF (NUMBER == 1)
                THEN
                        #Fax enabled
                        f1140:  When finished you may attach a
                        fax by pressing pound.
                ENDIF
        ENDIF
ELSE
        # DEFINITY AUDIX 3.0 and 3.1
        f513:  Begin your message by saying the name and
        telephone number of the person you are calling.
        Someone will listen to the start of your message,
        and then forward the complete message to the
        person you called.
ENDIF
``` |
a280	f51: Entries deleted, please re-enter delivery time.
a281	f74: deleted.
a282	f43: Your call is being answered by AUDIX. f507: The person you called is not available. To leave a message, use touch tones to re-enter the number you called. f239: followed by the pound sign.
a283	f5: To record personal greeting, press 1. To listen to personal greeting, press 0. To select which greeting to use, press star pound.
a284	f42: The return address for this message is not a mailbox on this system.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| a285 | ```
# announcement changed for Intuity MACH3 FAX Feature
# VERSION is 2 for 3.1 DEFINITY AUDIX and 3 for INTUITY
3.0 fax feature
# NUMBER 0 is no message, 1 is message was left
IF (VERSION > 2)
THEN
        # Intuity 3.0 VERSION is 3
        IF (NUMBER==1)
        THEN
              f56:  Thank you for leaving your message.
        ENDIF,
        f46:  To access your mailbox, press star 7.
        f973:  If you are finished, please hang up, or
        press star, star 9.
ELSE
        # Definity Audix 3.1 VERSION = 2
        f56:  Thank you for leaving your message.
        f46:  To access your mailbox, press star 7.
        f973:  If you are finished, please hang up, or
        press star, star 9.
ENDIF
``` |
| a286 | ```
f47:  Call from
NAME,
f262:  received
TIME,DATE,a873(NUMBER)
``` |
| a287 | ```
f47:  Call from
NAME,
f262:  received
TIME,DATE,
f86:  extension
BUTTONS,a873(NUMBER)
``` |
| a288 | ```
f43:  Your call is being answered by AUDIX.
NAME,
f680:  is busy. Sorry, you cannot leave a message now
because this user's mailbox is full.
``` |
| a289 | ```
# VERSION > 2 introduced with INTUITY 3.0.  NUMBER(2) is
used for the
# FAX feature.  NUMBER(2) == 1 if fax is enabled.
# NUMBER(2) is used for Call Answer Disable/Enable Xerox
Feature
# NUMBER(3) == 1 if call answer disabled turned on, 0 if
off.
IF (VERSION > 2)
THEN
        #INTUITY 3.0
        a1178(NUMBER,NUMBER(2),NUMBER(3),NAME)
ELSE
        IF (NUMBER == 0)
``` |

Announcement	Fragments
| | ```
         THEN
                f43:  Your call is being answered by AUDIX.
                NAME,
                f44:  is not available. To leave a message,
                wait for the tone.
         ENDIF,
         IF (NUMBER == 1)
         THEN
                f71:  To leave a message, wait for the tone.
         ENDIF,
         IF (NUMBER == 2)
         THEN
                NAME,
                f44:  is not available. To leave a message,
                wait for the tone.
         ENDIF
ENDIF
``` |
| a290 | ```
# VERSION > 2 introduced with INTUITY 3.0.  NUMBER(2) is
used for the
# FAX feature.  NUMBER(2) == 1 if fax is enabled.
# NUMBER(2) is used for Call Answer Disable/Enable Xerox
Feature
# NUMBER(3) == 1 if call answer disabled turned on, 0 if
off.
IF (VERSION > 2)
THEN
       #INTUITY 3.0
       a1177(NUMBER,NUMBER(2),NUMBER(3),NAME)
ELSE
       IF (NUMBER == 0)
       THEN
              f43:  Your call is being answered by AUDIX.
              NAME,
              f45:  is busy. To leave a message, wait for
              the tone.
       ENDIF,
       IF (NUMBER == 1)
       THEN
              f71:  To leave a message, wait for the tone.
       ENDIF,
       IF (NUMBER == 2)
       THEN
              NAME,
              f45:  is busy. To leave a message, wait for
              the tone.
       ENDIF
ENDIF
``` |

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a291	`# VERSION > 2 introduced with INTUITY 3.0. NUMBER(2) is`
	`used for the`
	`# FAX feature. NUMBER(2) == 1 if fax is enabled.`
	`# NUMBER(2) is used for Call Answer Disable/Enable Xerox`
	`Feature`
	`# NUMBER(3) == 1 if call answer disabled turned on, 0 if`
	`off.`
	`IF (VERSION > 2)`
	`THEN`
	`        #INTUITY 3.0`
	`        a1175(NUMBER,NUMBER(2),NUMBER(3),NAME)`
	`ELSE`
	`        IF (NUMBER == 0)`
	`        THEN`
	`                f43:  Your call is being answered by AUDIX.`
	`                NAME,`
	`                f45:  is busy. To leave a message, wait for`
	`                the tone.`
	`        ENDIF,`
	`        IF (NUMBER == 1)`
	`        THEN`
	`                f71:  To leave a message, wait for the tone.`
	`        ENDIF,`
	`        IF (NUMBER == 2)`
	`        THEN`
	`                NAME,`
	`                f45:  is busy. To leave a message, wait for`
	`                the tone.`
	`        ENDIF,`
	`        f112:  Otherwise, for assistance, press zero now.`
	`ENDIF`

a292	`# VERSION > 2 introduced with INTUITY 3.0. NUMBER(2) is`
	`used for the`
	`# FAX feature. NUMBER(2) == 1 if fax is enabled.`
	`# NUMBER(2) is used for Call Answer Disable/Enable Xerox`
	`Feature`
	`# NUMBER(3) == 1 if call answer disabled turned on, 0 if`
	`off.`
	`IF (VERSION > 2)`
	`THEN`
	`        #INTUITY 3.0`
	`        a1176(NUMBER,NUMBER(2),NUMBER(3),NAME)`
	`ELSE`
	`        IF (NUMBER == 0)`
	`        THEN`
	`                f43:  Your call is being answered by AUDIX.`
	`                NAME,`
	`                f44:  is not available. To leave a message,`
	`                wait for the tone.`
	`        ENDIF,`
	`        IF (NUMBER == 1)`

Announcement	Fragments
|  | ```
        THEN
                f71:  To leave a message, wait for the tone.
        ENDIF,
        IF (NUMBER == 2)
        THEN
                NAME,
                f44:  is not available. To leave a message,
                wait for the tone.
        ENDIF,
        f112:  Otherwise, for assistance, press zero now.
ENDIF
``` |
a293	f43: Your call is being answered by AUDIX. NAME, f679: is not available. Sorry, you cannot leave a message now because this user's mailbox is full.
a294	f156: Maximum length recorded.
a295	f50: Call NAME, f262: received TIME,DATE, f86: extension BUTTONS,a873(NUMBER)
a296	f50: Call f262: received TIME,DATE,a873(NUMBER)
| a297 | ```
# VERSION > 2 is INTUITY FAX feature.  FAX enabled
NUMBER == 1,
# FAX not enable  NUMBER == 0
IF (VERSION > 2)
THEN
        # INTUITY 3.0
        f507:  The person you called is not available. To
        leave a message, use touch tones to re-enter the
        number you called.
        IF (NUMBER == 1)
        THEN
                #Fax enabled
                f1140:  When finished you may attach a fax
                by pressing pound.
        ENDIF
ELSE
        # 3.0 and 3.1 DEFINITY AUDIX
        f507:  The person you called is not available. To
        leave a message, use touch tones to re-enter the
        number you called.
ENDIF
``` |

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a298	f507: The person you called is not available. To leave a message, use touch tones to re-enter the number you called. f274: Please make entry soon, or be disconnected.
a299	f511: If you do not have a touch tone phone, f380: Please wait.
a300	f794: To change identification to busy and no answer, press 2.
a301	f911: Enter buttons followed by pound.
a302	f912: Enter number followed by pound.
a303	f630: To change expiration date from DATE, f762: press 2.
a304	f795: To change to identification internal and external, press 1.
a305	f910: You are playing an announcement which need additional input before it can be played. f911: Enter buttons followed by pound.
a306	f910: You are playing an announcement which need additional input before it can be played. f912: Enter number followed by pound.
a307	f527: To change number, press 1. To change times, press 2. For instructions on entering your outcalling number, press 3. f528: To turn on, press 9. To turn off, press 6.
a308	f60: Changed.
a309	f565: Outcall canceled for new messages currently in mailbox.

a310	`# VERSION > 2 is INTUITY 3.0 FAX feature.`
	`# NUMBER = 1 is voice only msg, 2 Fax only msg, 3 Voice/Fax msg.`
	`# NUMBER(2) = 1 - fax is enabled, 0 - fax is disabled`
	`IF (VERSION > 2)`
	`THEN`
	`        IF (NUMBER == 1)`
	`        THEN`
	`                f12: To re-record, press 1. After recording, press 1 again. To delete, press star 3. To playback, press 2-3. To approve as is, press pound.`
	`        ELSE`
	`                IF (NUMBER == 2)`
	`                THEN`
	`                        IF (NUMBER(2) == 1)`
	`                        THEN`
	`                                f1073: To print, press star 1.`
	`                        ENDIF,`
	`                        f24: To delete, press star 3.`
	`                        f1007: To playback, press 2-3.`
	`                        f157: To approve as is, press the pound key.`

Announcement	Fragments
| | ```
            ELSE
                IF (NUMBER == 3)
                THEN
                    f13:  To record, press 1. After
                    recording, press 1 again.
                    IF(NUMBER(2) == 1)
                    THEN
                        f1073:  To print, press
                        star 1.
                    ENDIF,
                    f24:  To delete,  press star 3.
                    f1007:  To playback, press 2-3.
                    f157:  To approve as is, press
                    the pound key.

                ENDIF
            ENDIF
        ENDIF
ELSE
    f12:  To re-record, press 1. After recording,
    press 1 again. To delete, press star 3. To
    playback, press 2-3. To approve as is, press
    pound.
ENDIF
``` |
a311	f628: To deactivate message waiting notification, press 1.
a313	f931: Delivered Messages
a314	f801: To respond to this notification, press 1. To delete, press star 3. To skip, press pound.
a315	f24: To delete, press star 3. f388: To skip, press the pound key.
a316	f77: Deleted.
a317	f77: Deleted. f173: Please enter new password f224: and pound sign.
a318	f77: Deleted. f22: To deliver now, press pound. To schedule delivery time enter hour and minutes, press 2 for A.M. or 7 for P.M., and pound sign.
a319	f706: To add entries, press 1. To review all entries, press 2. To review a specific entry, press 3. f913: If finished, press pound.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a320	f705: Directory contains
	NUMBER,
	IF (NUMBER==1)
	THEN
	        f84: entry.
	ELSE
	        f83: entries.
	ENDIF

a321	f724: Personal directory review completed.
a322	f140: Entry already deleted. To delete more entries, press star 1.
a324	f145: List has no entries.
a325	f538: Enter the ending hour and minutes, press 2 for A.M. or 7 for P.M., and pound sign.
a326	f472: To approve, press pound. To record from here, press 1. f24: To delete, press star 3.
a327	f727: Enter alias and pound sign. f833: To delete current entry, press star 3. f148: For extension addressing, press star 2. f913: If finished, press pound.
a328	f727: Enter alias and pound sign. f833: To delete current entry, press star 3. f58: For name addressing, press star 2. f913: If finished, press pound.
a329	f727: Enter alias and pound sign. f913: If finished, press pound.
a330	f713: Enter next extension and pound sign. f708: If finished adding entries, press pound.
a331	f710: Enter next name and pound sign. f708: If finished adding entries, press pound.
a332	f85: Erased. f13: To record, press 1. After recording, press 1 again.
a333	f632: Expiration date will be DATE
a334	f86: extension BUTTONS, f552: is not authorized to receive messages.
a335	f86: extension BUTTONS, f552: is not authorized to receive messages. f553: You may enter another number
a336	f86: extension BUTTONS, f552: is not authorized to receive messages. f95: Please disconnect.
a337	f86: extension BUTTONS,

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	f841: not defined
a338	f86: extension f202: not valid.

a339	f748: For external calls,...
	IF (NUMBER==0)
	THEN
	    f776: the system greeting
	ELSE
	    f754: Greeting
	NUMBER
	ENDIF,
	f745: active.

a340	f971: To send, press #.
a341	f971: To send, press #. f774: If you have addressed this message and wish to deliver it immediately, press star star pound.

a342	# VERSION > 2 is for INTUITY 3.0 Fax Feature.
	# NUMBER == length of voice portion.
	# NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice and fax.
	IF (VERSION > 2)
	THEN
	    IF (NUMBER(2) == 2)
	    THEN
	        f1125: Fax message to
	    ELSE
	        IF (NUMBER(2) == 3)
	        THEN
	            f1126: Voice and fax message to
	        ELSE
	            f258: Message to
	        ENDIF
	    ENDIF,
	    f1117: all local subscribers.
	ELSE
	    f739: Message sent to all local subscribers.
	ENDIF,
	IF (NUMBER>0)
	THEN
	    f2: and
	NUMBER,
	IF (NUMBER==1)
	THEN
	      f602: other
	ELSE
	      f217: others
	ENDIF
	ENDIF

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| a343 | ```
# VERSION > 2 is for INTUITY 3.0 Fax Feature.
# NUMBER == length of voice portion.
# NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice
and fax.
IF (VERSION > 2)
THEN
        IF (NUMBER(2) == 2)
        THEN
                f1119:  Private fax message to
        ELSE
                IF (NUMBER(2) == 3)
                THEN
                        f1120:  Private voice and fax message
                        to
                ELSE
                        f696:  Private message to
                ENDIF
        ENDIF,
        f1117:  all local subscribers.
ELSE
        f740:  Private message sent to all local
        subscribers.
ENDIF,
IF (NUMBER>0)
THEN
        f2:  and
NUMBER,
        IF (NUMBER==1)
        THEN
                f602:  other
        ELSE
                f217:  others
        ENDIF
ENDIF
``` |
| a344 | ```
# NUMBER = length of voice portion
# NUMBER(2) = 1 for voice, 2 for fax and 3 for voice and
fax.
# NUMBER(3) is length of fax portion in pages.
# VERSION introduced in INTUITY 3.0 Fax featrue. VERSION
= 3.
IF (VERSION > 2)
THEN
        IF (NUMBER(2) == 2)
        THEN
                #Private, priority fax message to
                f1109:  Private, priority fax message to
        ELSE
                IF (NUMBER(2) == 3)
                THEN
                        # Private priority voice and fax
message to
``` |

Announcement	Fragments

	f1110: Private, priority voice and
	                fax message to
	        ELSE
	                #Private priority message to
	                f695: Private, priority message to
	        ENDIF
	    ENDIF
	ELSE
	    f741: Private, priority message sent to
	ENDIF,
	NAME,
	IF (NUMBER>0)
	THEN
	    f2: and
	NUMBER,
	    IF (NUMBER==1)
	    THEN
	        f602: other
	    ELSE
	        f217: others
	    ENDIF
	ENDIF

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a345	```
	# VERSION > 2 is for INTUITY 3.0 Fax Feature.
	# NUMBER == length of voice portion.
	# NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice
	and fax.
	IF (VERSION > 2)
	THEN
	        IF (NUMBER(2) == 2)
	        THEN
	                f1115: Priority fax message to
	        ELSE
	                IF (NUMBER(2) == 3)
	                THEN
	                        f1116: Priority voice and fax message
	                        to
	                ELSE
	                        f698: Priority message to
	                ENDIF
	        ENDIF
	ELSE
	        f743: Priority message sent to
	ENDIF,
	NAME,
	IF (NUMBER>0)
	THEN
	        f2: and
	NUMBER,
	IF (NUMBER==1)
	THEN
	                f602: other
	ELSE
	                f217: others
	ENDIF
	ENDIF
	``

a346	```
	# VERSION > 2 is for INTUITY 3.0 Fax Feature.
	# NUMBER == 1 if voice only, 2 if fax only, 3 if voice
	and fax.
	# NUMBER(2) = 1 - fax enabled, 0 - fax disabled
	IF (VERSION > 2)
	THEN
	        # INTUITY 3.0
	        IF (NUMBER == 1)
	        THEN
	                #Voice only
	                f21: To listen, press 0.
	        ELSE
	                IF (NUMBER == 2)
	                THEN
	                        #FAX only
	                        IF (NUMBER(2) == 1)
	                        THEN
	                                f1073: To print, press star 1.
	``

Announcement	Fragments

	``
	                        ENDIF
	                 ELSE
	                        IF (NUMBER == 3)
	                        THEN
	                                #Voice and FAX
	                                f21: To listen, press 0.
	                                IF (NUMBER(2) == 1)
	                                THEN
	                                        f1073: To print, press
	                                        star 1.
	                                ENDIF
	                        ENDIF
	                 ENDIF
	           ENDIF,
	           f1039: To change or send again, press one.
	           f388: To skip, press the pound key.
	    ELSE
	           # DEFINITY AUDIX 3.0, 3.1
	           f474: To listen, press 0. To change or send
	           again, press 1.
	           f388: To skip, press the pound key.
	    ENDIF
	``

a347	f932: Filed Messages
a348	f89: First message. f197: Cannot step back. f142: To listen to the header, press 3.
a349	f118: Enter last name f224: and pound sign. f175: Please note only AUDIX subscribers can be specified by name.

a350	f807: For busy...
	f2: and
	f812: no answer
	f814: calls.
	IF (NUMBER==0)
	THEN
	      f776: the system greeting
	ELSE
	      f754: Greeting
	NUMBER
	ENDIF,
	f745: active.

Announcement	Fragments

a351	f807: For busy...
	f812: no answer
	f813: and out-of-hours
	f814: calls.
	IF (NUMBER==0)
	THEN
	    f776: the system greeting
	ELSE
	    f754: Greeting
	NUMBER
	ENDIF,
	f745: active.

a352	f805: For internal...
	f2: and
	f810: external
	f814: calls.
	IF (NUMBER==0)
	THEN
	    f776: the system greeting
	ELSE
	    f754: Greeting
	NUMBER
	ENDIF,
	f745: active.

a353	f805: For internal...
	f810: external
	f813: and out-of-hours
	f814: calls.
	IF (NUMBER==0)
	THEN
	    f776: the system greeting
	ELSE
	    f754: Greeting
	NUMBER
	ENDIF,
	f745: active.

a354	f90: Enter fragment id f224: and pound sign.

a355	# VERSION > 2 is INTUITY FAX feature. NUMBER is length of voice portion
	# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax.
	# NUMBER(3) is length of fax portion in pages.
	IF (VERSION > 2)
	THEN
	    IF (NUMBER(2)==2)
	    THEN
	        f1062: Private broadcast fax message from
	    ELSE
	        IF (NUMBER(2)==3)
	        THEN

Announcement	Fragments
|  | ```
                        f1063:  Private broadcast voice and
                        fax message from
                ELSE
                        f684:  Private, broadcast message from
                ENDIF
        ENDIF,
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
a1010(NUMBER,NUMBER(2),NUMBER(3))
ELSE
        f684:  Private, broadcast message from
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
a873(NUMBER)
ENDIF
``` |

Announcement	Fragments
| a356 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
                f1062:  Private broadcast fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                        f1063:  Private broadcast voice and
                        fax message from
                ELSE
                        f684:  Private, broadcast message from
                ENDIF
        ENDIF,
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
        a1010(NUMBER,NUMBER(2),NUMBER(3)),
        f689:  Expiration time is
TIME(2),DATE(2)
ELSE
        f684:  Private, broadcast message from
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
        a873(NUMBER),
        f689:  Expiration time is
TIME(2),DATE(2)
ENDIF
``` |
| a357 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
                f1062:  Private broadcast fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                        f1063:  Private broadcast voice and
                        fax message from
``` |

Announcement	Fragments
| | ```
              ELSE
                    f684:  Private, broadcast message from
              ENDIF
       ENDIF,
       NAME,
       f262:  received
       TIME,DATE,
       f905:  <.5 second pause>
a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION
ELSE
       f684:  Private, broadcast message from
       NAME,
       f262:  received
       TIME,DATE,
       f905:  <.5 second pause>
a873(NUMBER),EXTENSION
ENDIF
``` |

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a358	`# VERSION > 2 is INTUITY FAX feature.  NUMBER is length`
	`of voice portion`
	`# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice`
	`fax.`
	`# NUMBER(3) is length of fax portion in pages.`
	`IF (VERSION > 2)`
	`THEN`
	`        IF (NUMBER(2)==2)`
	`        THEN`
	`                f1062:  Private broadcast fax message from`
	`        ELSE`
	`                IF (NUMBER(2)==3)`
	`                THEN`
	`                        f1063:  Private broadcast voice and`
	`                        fax message from`
	`                ELSE`
	`                        f684:  Private, broadcast message from`
	`                ENDIF`
	`        ENDIF,`
	`        NAME,`
	`        f262:  received`
	`        TIME,DATE,`
	`        f905:  <.5 second pause>`
	`        a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION,`
	`        f689:  Expiration time is`
	`TIME(2),DATE(2)`
	`ELSE`
	`        f684:  Private, broadcast message from`
	`        NAME,`
	`        f262:  received`
	`        TIME,DATE,`
	`        f905:  <.5 second pause>`
	`        a873(NUMBER),EXTENSION,`
	`        f689:  Expiration time is`
	`TIME(2),DATE(2)`
	`ENDIF`

a360	f715: Cannot add new entries because your directory is full.
a361	f715: Cannot add new entries because your directory is full. NAMEEXT, f722: was not added to your personal directory.
a362	f93: You have no personal greeting, system greeting used.
a364	f243: Rewound.
a365	f754: Greeting NUMBER, f771: approved and active f823: ...for all calls
a366	f754: Greeting

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	NUMBER, f771: approved and active f827: ...for busy f2: and f812: no answer f814: calls.
a367	f754: Greeting NUMBER, f771: approved and active f827: ...for busy f813: and out-of-hours f814: calls.
a368	f754: Greeting NUMBER, f771: approved and active f827: ...for busy f814: calls.
a369	f754: Greeting NUMBER, f771: approved and active f827: ...for busy f812: no answer f813: and out-of-hours f814: calls.
a370	f754: Greeting NUMBER, f771: approved and active f826: ...for external f813: and out-of-hours f814: calls.
a371	f754: Greeting NUMBER, f771: approved and active f826: ...for external f814: calls.
a372	f754: Greeting NUMBER, f771: approved and active f825: ...for internal f2: and f810: external f814: calls.
a373	f754: Greeting NUMBER, f771: approved and active f825: ...for internal f813: and out-of-hours f814: calls.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a374	f754: Greeting NUMBER, f771: approved and active f825: ...for internal f814: calls.
a375	f754: Greeting NUMBER, f771: approved and active f825: ...for internal f810: external f813: and out-of-hours f814: calls.
a376	f754: Greeting NUMBER, f771: approved and active f828: ...for no answer f813: and out-of-hours f814: calls.
a377	f754: Greeting NUMBER, f771: approved and active f828: ...for no answer f814: calls.
a378	f754: Greeting NUMBER, f771: approved and active f829: ...for out-of-hours f814: calls.
a379	f754: Greeting NUMBER, f74: deleted.
a380	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f823: ...for all calls
a381	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f827: ...for busy f2: and f812: no answer f814: calls.
a382	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f827: ...for busy f813: and out-of-hours f814: calls.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a383	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f827: ...for busy f814: calls.
a384	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f827: ...for busy f812: no answer f813: and out-of-hours f814: calls.
a385	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f826: ...for external f813: and out-of-hours f814: calls.
a386	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f826: ...for external f814: calls.
a387	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f825: ...for internal f2: and f810: external f814: calls.
a388	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f825: ...for internal f813: and out-of-hours f814: calls.
a389	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f825: ...for internal f814: calls.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a390	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f825: ...for internal f810: external f813: and out-of-hours f814: calls.
a391	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f828: ...for no answer f813: and out-of-hours f814: calls.
a392	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f828: ...for no answer f814: calls.
a393	f754: Greeting NUMBER, f74: deleted. f332: System greeting used. f829: ...for out-of-hours f814: calls.
a394	f754: Greeting NUMBER, f214: Approved.
a395	f754: Greeting NUMBER, f755: not recorded.
a396	f754: Greeting NUMBER, f765: recorded, but not active
a397	f754: Greeting NUMBER, f770: recorded and active f823: ...for all calls
a398	f754: Greeting NUMBER, f770: recorded and active f827: ...for busy f2: and f812: no answer f814: calls.
a399	f754: Greeting NUMBER, f770: recorded and active f827: ...for busy

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	f813: and out-of-hours f814: calls.
a400	f754: Greeting NUMBER, f770: recorded and active f827: ...for busy f814: calls.
a401	f754: Greeting NUMBER, f770: recorded and active f827: ...for busy f812: no answer f813: and out-of-hours f814: calls.
a402	f754: Greeting NUMBER, f770: recorded and active f826: ...for external f813: and out-of-hours f814: calls.
a403	f754: Greeting NUMBER, f770: recorded and active f826: ...for external f814: calls.
a404	f754: Greeting NUMBER, f770: recorded and active f825: ...for internal f2: and f810: external f814: calls.
a405	f754: Greeting NUMBER, f770: recorded and active f825: ...for internal f813: and out-of-hours f814: calls.
a406	f754: Greeting NUMBER, f770: recorded and active f825: ...for internal f814: calls.
a407	f754: Greeting NUMBER, f770: recorded and active f825: ...for internal f810: external f813: and out-of-hours f814: calls.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a408	f754: Greeting NUMBER, f770: recorded and active f828: ...for no answer f813: and out-of-hours f814: calls.
a409	f754: Greeting NUMBER, f770: recorded and active f828: ...for no answer f814: calls.
a410	f754: Greeting NUMBER, f770: recorded and active f829: ...for out-of-hours f814: calls.
a411	f754: Greeting NUMBER, f745: active. f823: ...for all calls
a412	f754: Greeting NUMBER, f745: active. f827: ...for busy f2: and f812: no answer f814: calls.
a413	f754: Greeting NUMBER, f745: active. f827: ...for busy f813: and out-of-hours f814: calls.
a414	f754: Greeting NUMBER, f745: active. f827: ...for busy f814: calls.
a415	f754: Greeting NUMBER, f745: active. f827: ...for busy f812: no answer f813: and out-of-hours f814: calls.
a416	f754: Greeting NUMBER, f745: active. f826: ...for external f813: and out-of-hours f814: calls.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a417	f754: Greeting NUMBER, f745: active. f826: ...for external f814: calls.
a418	f754: Greeting NUMBER, f745: active. f825: ...for internal f2: and f810: external f814: calls.
a419	f754: Greeting NUMBER, f745: active. f825: ...for internal f813: and out-of-hours f814: calls.
a420	f754: Greeting NUMBER, f745: active. f825: ...for internal f814: calls.
a421	f754: Greeting NUMBER, f745: active. f825: ...for internal f810: external f813: and out-of-hours f814: calls.
a422	f754: Greeting NUMBER, f745: active. f828: ...for no answer f813: and out-of-hours f814: calls.
a423	f754: Greeting NUMBER, f745: active. f828: ...for no answer f814: calls.
a424	f754: Greeting NUMBER, f745: active. f829: ...for out-of-hours f814: calls.
a425	f752: To listen to a greeting, press 0. To create, change, or delete a greeting, press 1. To scan all your greetings, press 2. To activate a greeting, press 3. To administer call types, press 4. If finished, press pound.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a426	f756: To listen to greeting NUMBER, f772: again f760: press 0.
a427	f756: To listen to greeting NUMBER, f760: press 0.
a428	f753: Enter greeting number.
a429	f757: To re-record, press 1. f24: To delete, press star 3. f913: If finished, press pound.
a430	f757: To re-record, press 1. f759: To review status, press 2. f24: To delete, press star 3. f913: If finished, press pound.
a431	f88: Cannot use the guest password f173: Please enter new password f224: and pound sign.
a432	f788: To identify calls as out-of-hours, press 3.

a433	f747: For internal calls,...
	IF (NUMBER==0)
	THEN
	      f776: the system greeting
	ELSE
	      f754: Greeting
	NUMBER
	ENDIF,
	f745: active.

a434	f737: Login announcement will be interruptible.
a435	f136: Line busy.
a436	f149: All circuits busy.
a437	f99: Invalid announcement.
a438	f637: Invalid date.
a439	f637: Invalid date. DATE, f678: is past the expiration date, please reschedule.
a440	f637: Invalid date. DATE, f638: is prior to delivery date, please re-schedule.
a441	f101: Invalid fragment.
a442	f10: That is not a valid machine voice ID.
a443	f579: Password must be NUMBER, f81: digits. f173: Please enter new password f224: and pound sign.
a444	f579: Password must be NUMBER, f211: to fifteen digits f173: Please enter new password f224: and pound sign.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a445	f102: That is not a valid extension.
a446	f128: To request another transfer, press star 8. f129: or leave a message for NAME
a447	f104: Message delivered, cannot listen to a delivered message.
a448	f492: Owner erased.
a449	f110: list BUTTONS
a450	f110: list BUTTONS, f142: To listen to the header, press 3.

a451	f110: list
	BUTTONS,
	f65: contains
	NUMBER,
	IF (NUMBER<=1)
	THEN
	    f84: entry.
	ELSE
	    f83: entries.
	ENDIF

a452	f110: list
	BUTTONS,
	f65: contains
	NUMBER,
	IF (NUMBER<=1)
	THEN
	    f159: member.
	ELSE
	    f150: members.
	ENDIF

a453	f110: list BUTTONS, f74: deleted.
a454	f110: list BUTTONS, f197: Cannot step back. f142: To listen to the header, press 3.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a455	f110: list BUTTONS, f485: has NUMBER, IF (NUMBER<=1) THEN f159: member. ELSE f150: members. ENDIF, f15: and is f226: private
a456	f110: list BUTTONS, f485: has NUMBER, IF (NUMBER<=1) THEN f159: member. ELSE f150: members. ENDIF, f15: and is f227: public
a457	f110: list BUTTONS, f226: private f61: To modify status, press 9 for yes or 6 for no.
a458	f110: list BUTTONS, f227: public f61: To modify status, press 9 for yes or 6 for no.
a459	f110: list BUTTONS, f74: deleted. f130: because there were no entries.
a460	f110: list BUTTONS, f120: too large to include. f132: You can store your list as is by pressing star pound or add up to NUMBER, f139: additional members,
a462	f110: list BUTTONS, f120: too large to include. f134: You can store your list or delete members, but you cannot add members.
a463	f110: list BUTTONS, f120: too large to include.

Announcement	Fragments
	f124: No more list space. f349: To approve list as is, press pound. f241: To review list, press star 1.
a465	f110: list BUTTONS, f208: is not a public list.
a466	f110: list BUTTONS, f202: not valid. f498: Please enter a new list id f224: and pound sign.
a467	f110: list f185: not found.
a468	f110: list f185: not found. f295: To re-enter list, press star 5.
a469	f110: list BUTTONS, f219: owned by NAME, f65: contains NUMBER, f150: members.
a470	f110: list BUTTONS, f219: owned by NAME, f120: too large to include. f132: You can store your list as is by pressing star pound or add up to NUMBER, f139: additional members,
a471	f110: list BUTTONS, f219: owned by NAME, f120: too large to include. f134: You can store your list or delete members, but you cannot add members.
a472	f110: list BUTTONS, f219: owned by NAME, f120: too large to include. f124: No more list space. f349: To approve list as is, press pound. f241: To review list, press star 1.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a473	f110: list BUTTONS, f219: owned by NAME, f74: deleted.
a474	f110: list BUTTONS, f219: owned by NAME, f208: is not a public list.
a476	f124: No more list space. f970: To continue reviewing, press 3. To delete an entry, press star 3. If finished reviewing, press pound.
a477	f110: list BUTTONS, f219: owned by NAME, f208: is not a public list. f295: To re-enter list, press star 5.
a478	f111: Please enter list id f224: and pound sign.
a479	f141: No more lists.
a480	f124: No more list space. f133: To continue reviewing, press 3. To delete an entry, press star 3. If finished reviewing, press star pound.
a481	f116: List is full. f133: To continue reviewing, press 3. To delete an entry, press star 3. If finished reviewing, press star pound.
a482	f116: List is full. f349: To approve list as is, press pound. f241: To review list, press star 1.
a483	f124: No more list space. f349: To approve list as is, press pound. f241: To review list, press star 1.
a484	f113: You already have a list BUTTONS, f114: To replace list, re-enter id and pound sign. To create a new list, enter new list id f224: and pound sign.
a485	f154: Cannot create new list, you have maximum lists allowed. To select lists to be deleted, press 5-1-2 and follow instructions.
a486	f155: Cannot create new list, total number of members in all your lists equals maximum allowed.
a487	f122: List space nearly full. You may enter NUMBER, f123: new members.
a488	f468: To continue playing, press 3.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a489	f691: Login announcement from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER)
a490	f691: Login announcement from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER), f689: Expiration time is TIME(2),DATE(2)
a491	f691: Login announcement from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER),EXTENSION
a492	f691: Login announcement from NAME, f262: received TIME,DATE, f905: <.5 second pause> a873(NUMBER),EXTENSION, f689: Expiration time is TIME(2),DATE(2)

a493	f697: Login announcement to all local subscribers
	IF (NUMBER>0)
	THEN
	    f2: and
	NUMBER,
	IF (NUMBER==1)
	THEN
	      f602: other
	ELSE
	      f217: others
	ENDIF
	ENDIF

a494	f656: For login announcement options, press star 6.
a495	f624: Login announcement.
a496	f100: Invalid Entry. f96: For help, press star 4.

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a497	f364: enter owner's extension f224: and pound sign. f471: If it's your list, press pound.
a498	f470: Enter owner's last name f224: and pound sign. f471: If it's your list, press pound.
a501	f240: To skip, press pound. To listen, press 0. f24: To delete, press star 3.
a502	f14: To make private, press 1. To make public, press 2.
a503	f704: To create lists, press 1. To scan lists, press 2. To review and modify lists, press 3.

a504	# VERSION > 2 introduced in INTUITY 3.0
	# Call anser disabled/enabled feature - XEROX
	IF (VERSION > 2)
	THEN
	      # INTUITY 3.0
	      IF (NUMBER == 1)
	      THEN
	            NAME,
	            f1163: is not available.
	            f1162: Sorry, the mailbox you have reached
	            is not accepting messages at this time.
	            f95: Please disconnect.
	      ELSE
	            f82: Please leave a message for
	NAME
	      ENDIF
	ELSE
	      #DEFINITY AUDIX 3.1 and INTUITY 2.0
	      f82: Please leave a message for
	NAME
	ENDIF

a505	f152: Leave Word Calling from NAME, f262: received TIME,DATE
a506	f152: Leave Word Calling from NAME, f262: received TIME,DATE, f86: extension BUTTONS

a507	# VERSION > 2 is for INTUITY 3.0 Fax Feature.
	# NUMBER == 1-voice only, 2-fax only, 3-voice and fax.
	# NUMBER(2) - 1 - fax enabled, 0 - fax disabled
	IF (VERSION > 2)
	THEN
	      IF (NUMBER == 1)

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| | ```
                THEN
                        f474:  To listen, press 0. To change or send
                        again, press 1.
                        f24:  To delete,  press star 3.
                        f388:  To skip, press the pound key.
                ELSE
                        IF (NUMBER == 2)
                        THEN
                                IF (NUMBER(2) == 1)
                                THEN
                                        f1073:  To print, press star 1.
                                ENDIF,
                                f1039:  To change or send again, press
                                one.
                                f24:  To delete,  press star 3.
                                f388:  To skip, press the pound key.
                        ELSE
                                IF (NUMBER == 3)
                                THEN
                                        f21:  To listen, press 0.
                                        IF (NUMBER(2) == 1)
                                        THEN
                                                f1073:  To print, press
                                                star 1.
                                        ENDIF,
                                        f1039:  To change or send again,
                                        press one.
                                        f24:  To delete,  press star 3.
                                        f388:  To skip, press the pound
                                        key.
                                ENDIF
                        ENDIF
                ENDIF
        ELSE
                f474:  To listen, press 0. To change or send
                again, press 1.
                f24:  To delete,  press star 3.
                f388:  To skip, press the pound key.
        ENDIF
``` |

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a508	```
	# VERSION > 2 is for INTUITY 3.0 Fax Feature.
	# NUMBER is 1 if prompting to change, 0 if not.
	# NUMBER(2) is 1 is fax enabled 0 if fax disabled.
	IF (VERSION > 2)
	THEN
	        #INTUITY 3.0
	        IF (NUMBER == 1)
	        THEN
	                # Prompt to change.
	                f30: To change, press 1.
	        ENDIF,
	        IF (NUMBER(2) == 1)
	        THEN
	                # FAX enabled.
	                f1073: To print, press star 1.
	        ENDIF,
	        f24: To delete, press star 3.
	        f388: To skip, press the pound key.
	ELSE
	        #Definity Audix 3.0 and 3.1
	        f30: To change, press 1.
	        f24: To delete, press star 3.
	        f388: To skip, press the pound key.
	ENDIF
	``

a509	f6: Enter machine voice ID. f224: and pound sign.
a510	f153: Maximum length recorded. To re-record, press 2-1. To approve as is, press pound.
a511	f125: Must be six or fewer numerals. f111: Please enter list id f224: and pound sign.
a512	f570: Recorded name too long
a513	f156: Maximum length recorded. f157: To approve as is, press the pound key.
a514	f582: AUDIX passwords must now be at least NUMBER, f81: digits. f593: Please choose a new password of NUMBER(2), f588: or more digits. f173: Please enter new password f224: and pound sign.
a515	f614: To make broadcast, press 8.
a516	f615: To make a login announcement, press 9.
a517	f633: To make non-interruptible, press 1.
a518	f613: To make priority, press 2.
a519	f612: To make private, press 1.
a520	f386: Cannot change a delivered message.
a521	f484: Enter more characters followed by the pound sign; if you just completed entering the last name, enter the

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	first name.
	f224: and pound sign.
a522	f777: Cannot listen to system greeting.
a523	f778: Cannot modify system greeting.
a524	f780: Personal greetings review completed.
a525	f781: To skip to the next greeting, press the pound sign. f756: To listen to greeting NUMBER, f760: press 0. f24: To delete, press star 3. f707: If finished, press star pound.

a527	# VERSION > 2 is for INTUITY 3.0 Fax Feature.
	# NUMBER == 1 if voice only, 2 if fax only, 3 if voice and fax.
	# NUMBER(2) = 1 - fax enabled, 0 - fax disabled
	IF (VERSION > 2)
	THEN
	    f165: Returned to getting messages.
	    IF (NUMBER == 1)
	    THEN
	        f21: To listen, press 0.
	        f24: To delete, press star 3.
	        f388: To skip, press the pound key.
	    ELSE
	        IF (NUMBER == 2)
	        THEN
	            IF (NUMBER(2) == 1)
	            THEN
	                f1073: To print, press star 1.
	            ENDIF,
	            f24: To delete, press star 3.
	            f388: To skip, press the pound key.
	        ELSE
	            f21: To listen, press 0.
	            IF (NUMBER(2) == 1)
	            THEN
	                f1073: To print, press star 1.
	            ENDIF,
	            f24: To delete, press star 3.
	            f388: To skip, press the pound key.
	        ENDIF
	    ENDIF
	ELSE
	    f165: Returned to getting messages.
	    f21: To listen, press 0.
	    f24: To delete, press star 3.
	    f388: To skip, press the pound key.
	ENDIF

a528	f91: At end.

Announcement	Fragments
a529	f844: End of message.
| a530 | ```
# VERSION > 2 is for INTUITY 3.0 Fax Feature.
# NUMBER == 1 if voice only, 2 if fax only, 3 if voice
and fax.
# NUMBER(2) = 1 - fax enabled, 0 fax disabled
IF (VERSION > 2)
THEN
        f165:  Returned to getting messages.
        # INTUITY 3.0
        IF (NUMBER == 1)
        THEN
                #Voice only
                f21:  To listen, press 0.
                f255:  To delete this message, press star 3.
        ELSE
                IF (NUMBER == 2)
                THEN
                        #FAX only
                        IF (NUMBER(2) == 1)
                        THEN
                                f1073:  To print, press star 1.
                        ENDIF,
                        f255:  To delete this message, press
                        star 3.
                ELSE
                        IF (NUMBER == 3)
                        THEN
                                #Voice and FAX
                                f21:  To listen, press 0.
                                IF (NUMBER(2) == 1)
                                THEN
                                        f1073:  To print, press
                                        star 1.
                                ENDIF,
                                f255:  To delete this message,
                                press star 3.
                        ENDIF
                ENDIF
        ENDIF,
        f388:  To skip, press the pound key.
ELSE
        # DEFINITY AUDIX 3.0, 3.1
        f165:  Returned to getting messages.
        f21:  To listen, press 0.
        f255:  To delete this message, press star 3.
        f388:  To skip, press the pound key.
ENDIF
``` |
a531	f166: At end. To playback, press 2-3.
a532	f473: filed
a533	f167: To approve, press pound. To record from here,

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	press 1. To playback, press 2-3.
a534	f170: Delivery scheduled
a535	f170: Delivery scheduled TIME,DATE, f66: If correct, press pound. If not, press star 3 and re-enter time.
a536	f631: Message waiting notification activated.
a537	f198: Partial name deleted.
a538	f603: You also have f34: Electronic Text f168: messages.
a539	f172: You have new f343: Leave word calling f168: messages.
a540	f603: You also have f343: Leave word calling f2: and f34: Electronic Text f168: messages.
a541	f603: You also have f343: Leave word calling f2: and f342: Electronic document communication f168: messages.
a542	f172: You have new f343: Leave word calling f2: and f342: Electronic document communication f168: messages.
a543	f603: You also have f343: Leave word calling f2: and f344: Message Center Service f168: messages.
a544	f172: You have new f343: Leave word calling f2: and f344: Message Center Service f168: messages.
a545	f603: You also have f343: Leave word calling f344: Message Center Service f2: and f342: Electronic document communication f168: messages.
a546	f172: You have new f343: Leave word calling f344: Message Center Service f2: and f342: Electronic document communication f168: messages.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a548	f172: You have new f34: Electronic Text f168: messages.
a549	f603: You also have f342: Electronic document communication f168: messages.
a550	f172: You have new f342: Electronic document communication f168: messages.
a551	f603: You also have f344: Message Center Service f168: messages.
a552	f172: You have new f344: Message Center Service f168: messages.
a553	f603: You also have f344: Message Center Service f2: and f342: Electronic document communication f168: messages.
a554	f172: You have new f344: Message Center Service f2: and f342: Electronic document communication f168: messages.
a555	f603: You also have f343: Leave word calling f168: messages.
a556	f928: New Messages
a557	f600: new Broadcast messages.
a558	f845: Next message.
a559	f105: To restart at the activity menu, press star 7. f67: To create another list, f111: Please enter list id f224: and pound sign.
a560	f830: You must approve your recording. f167: To approve, press pound. To record from here, press 1. To playback, press 2-3.
a561	f53: Message deleted, no delivery will occur.
a562	f180: Nothing to approve.
a563	f850: Broadcast and Login Message services are not available.
a564	f636: Login announcement will be non-interruptible.
a565	f842: Announcement not recorded. Try again later. f95: Please disconnect.
a566	f203: No room in your mailbox for a recording. f62: Please delete unneeded messages.
a569	f215: No room to retain a copy. f62: Please delete unneeded messages.
a570	f1443: Voice filesystem is out of space.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	f1444: Please contact the administrator.
a571	f207: Message too long to add comment. To record a new message, press star 7-1.
a572	f209: Cannot modify another subscriber's list.
a573	f92: Nothing to advance.
a574	f177: Cannot listen to a delivered message.
a575	f178: No addressees identified.
a576	f178: No addressees identified. f74: deleted.
a577	f169: Administrative version not specified, please do so using administrator's terminal.

a579	f750: For no answer calls,...
	IF (NUMBER==0)
	THEN
	        f776: the system greeting
	ELSE
	        f754: Greeting
	NUMBER
	ENDIF,
	f745: active.

a581	f180: Nothing to approve. f13: To record, press 1. After recording, press 1 again.
a582	f548: You have no attendant menu.
a583	f609: No room to save Broadcast message so it will be retained in the new message category.
a584	f186: To record messages, press 1. To get messages, press 2. To check your outgoing messages, press 4.
a585	f182: Nothing to delete.
a586	f182: Nothing to delete. f173: Please enter new password f224: and pound sign.
a587	f714: Directory has no entries.
a589	f184: Nothing to erase. f13: To record, press 1. After recording, press 1 again.
a590	f575: Cannot forward a private message
a592	f188: Passwords do not match. Please re-enter new password f224: and pound sign.
a593	f189: You have no mailbox. f272: Contact administrator for help.
a594	f190: Message delivered, you cannot change it now.
a595	f191: No more messages.
a596	f779: No greetings recorded.
a597	f192: No messages.
a598	f193: No name recorded.
a599	f193: No name recorded. f608: At the tone, please speak your name. After speaking your name, press 1.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a600	f194: No new messages.
a601	f509: System not administered for outcalling.
a603	f49: No operator defined.
a604	f196: You have no personal greeting.
a605	f199: Nothing to rewind.
a606	f199: Nothing to rewind. f256: At beginning. To re-record, press 1. To playback, press 2-3.
a607	f199: Nothing to rewind. f142: To listen to the header, press 3. f143: To step back again, press 2.
a608	f3: No new remote subscribers can be addressed.
a609	f200: No time entered, nothing to delete. f22: To deliver now, press pound. To schedule delivery time enter hour and minutes, press 2 for A.M. or 7 for P.M., and pound sign.
a610	f571: Non-existent subscriber
a611	f232: Recording stopped. f180: Nothing to approve.
a612	f173: Please enter new password f224: and pound sign.
a613	f223: Please enter extension f224: and pound sign. f237: Or press star 7.
a614	f510: Number f202: not valid.
a615	f510: Number f202: not valid. f95: Please disconnect.
a616	f535: For outcalling any time, press 1. For outcalling during prime time, press 2. To specify your times, press 3. For system outcalling schedule, press 4.
a617	f530: Outcalling f522: turned off to restart at the activity menu, press star 7.
a618	f530: Outcalling f521: turned on f835: for all new messages
a619	f530: Outcalling f521: turned on f836: only for new priority messages
a620	f532: To change your outcalling phone number, press 1 and enter the number to be called followed by the pound sign. Anything you enter will be interpreted as a part of the called number. No global commands such as star 4 will be accepted at this time. IF (VERSION<2) THEN #Definity AUDIX 3.0 doesn't allow # signs in the middle of the

Announcement	Fragments

	`#outcall number`
	f557: In most cases, entering a star or pound as the first digit will result in the star or pound being outpulsed. A star entered as part of the digit string will be interpreted as a pause of one and a half seconds. If a longer pause is required, use multiple stars in a row.
	f560: If you are programming a number to call a pager that requires a pound sign termination, press 9 to hear further help. Otherwise, press 6 to return to outcalling administration.
	`ELSE`
	`#Definity AUDIX 3.1 allows # signs in the middle`
	`of the`
	`#outcall number`
	f1284: In all cases, entering a star or pound as the first digit will result in the star or pound being outpulsed. A star entered as part of the digit string will be interpreted as a pause of one and a half seconds. If a longer pause is required, use multiple stars in a row.
	f1285: If you are programming a number to call a pager that requires a pound sign in or at the end of the digit string, press 9 to hear further help. Otherwise, press 6 to return to outcalling administration.
	`ENDIF`

a621	f531: Enter outcalling number f224: and pound sign. f556: To exit, press star pound now.

Announcement	Fragments

a622	IF (VERSION<2)
	THEN
	      #Definity AUDIX 3.0 doesn't allow # signs in the middle of the
	      #outcall number
	      f589: For pagers requiring a pound sign termination, start your number with a double pound sign. This will result in a single pound being outpulsed at the end of the digit string. Then, a star or pound in the next position will be interpreted as part of the outcalling number.
	      f590: A star entered as part of the digit string will be interpreted as a pause of one and a half seconds. If a longer pause is required, use multiple stars in a row.
	ELSE
	      #Definity AUDIX 3.1 allows # signs in the middle of the
	      #outcall number
	      f1286: Wherever a pound sign is required in the digit string, enter star pound. For pagers requiring a pound sign termination, end your digit string with star pound pound.
	      f1452: A star entered as part of the digit string will be interpreted as a pause of one and a half seconds.
	      f1287: If a pause is required before a pound sign, enter star star pound.
	      f1471: Up to 60 characters may be entered.
	ENDIF

a623	f534: Your outcalling number is DIALSTR
a624	f544: Outcalling specified for f525: any time f526: subject to administrator restrictions
a625	f544: Outcalling specified for TIME, f524: to TIME(2), f526: subject to administrator restrictions
a626	f544: Outcalling specified for TIME, f524: to TIME(2), f526: subject to administrator restrictions f66: If correct, press pound. If not, press star 3 and re-enter time.
a627	f500: This is AUDIX. NAME,

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	f172: You have new f168: messages. f551: To access your messages, f223: Please enter extension f224: and pound sign. f543: To avoid further notification of these messages, press star pound.
a628	f519: You are not authorized for outcalling.
a629	f520: Your outcalling number, DIALSTR, f522: turned off to restart at the activity menu, press star 7. f527: To change number, press 1. To change times, press 2. For instructions on entering your outcalling number, press 3. f528: To turn on, press 9. To turn off, press 6.
a630	f520: Your outcalling number, DIALSTR, f521: turned on f835: for all new messages f523: for f525: any time f526: subject to administrator restrictions f105: To restart at the activity menu, press star 7. f527: To change number, press 1. To change times, press 2. For instructions on entering your outcalling number, press 3. f528: To turn on, press 9. To turn off, press 6.
a631	f520: Your outcalling number, DIALSTR, f521: turned on f835: for all new messages f523: for TIME, f524: to TIME(2), f526: subject to administrator restrictions f105: To restart at the activity menu, press star 7. f527: To change number, press 1. To change times, press 2. For instructions on entering your outcalling number, press 3. f528: To turn on, press 9. To turn off, press 6.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a632	f520: Your outcalling number, DIALSTR, f521: turned on f836: only for new priority messages f523: for f525: any time f526: subject to administrator restrictions f105: To restart at the activity menu, press star 7. f527: To change number, press 1. To change times, press 2. For instructions on entering your outcalling number, press 3. f528: To turn on, press 9. To turn off, press 6.
a633	f520: Your outcalling number, DIALSTR, f521: turned on f836: only for new priority messages f523: for TIME, f524: to TIME(2), f526: subject to administrator restrictions f105: To restart at the activity menu, press star 7. f527: To change number, press 1. To change times, press 2. For instructions on entering your outcalling number, press 3. f528: To turn on, press 9. To turn off, press 6.
a634	f837: To turn on Outcalling for all new messages, press 1. To turn on outcalling only for new priority messages, press 2.
a635	f929: Old Messages
a636	f840: Option f841: not defined

a637	f216: originally
	f259: scheduled for
	TIME,DATE,
	f261: rescheduled for
	TIME(2),DATE(2),
	IF (NUMBER==1)
	THEN
	    f264: Message not delivered because mailbox was full.
	ELSE
	    f265: Message not delivered because their mailboxes were full.
	ENDIF

a638	f216: originally f259: scheduled for TIME,DATE, f261: rescheduled for TIME(2),DATE(2),

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	f265: Message not delivered because their mailboxes were full. f689: Expiration time is TIME(3),DATE(3)
a639	f216: originally f259: scheduled for TIME,DATE, f261: rescheduled for TIME(2),DATE(2), f98: Message not delivered due to transmission problems.
a640	f216: originally f259: scheduled for TIME,DATE, f261: rescheduled for TIME(2),DATE(2), f98: Message not delivered due to transmission problems. f689: Expiration time is TIME(3),DATE(3)
a641	f216: originally f259: scheduled for TIME,DATE, f261: rescheduled for TIME(2),DATE(2), f387: Message not delivered because recipient not found.
a642	f216: originally f259: scheduled for TIME,DATE, f261: rescheduled for TIME(2),DATE(2), f387: Message not delivered because recipient not found. f689: Expiration time is TIME(3),DATE(3)
a643	f216: originally f259: scheduled for TIME,DATE, f261: rescheduled for TIME(2),DATE(2), f584: Message not delivered because special feature denied on recipients machine.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a644	f216: originally f259: scheduled for TIME,DATE, f261: rescheduled for TIME(2),DATE(2), f584: Message not delivered because special feature denied on recipients machine. f689: Expiration time is TIME(3),DATE(3)

a645	f751: For out-of-hours calls,...
	IF (NUMBER==0)
	THEN
	    f776: the system greeting
	ELSE
	    f754: Greeting
	NUMBER
	ENDIF,
	f745: active.

a647	f681: Sorry, cannot leave a message now because this user's mailbox is full.
a648	f214: Approved.
a649	f1: Someone is changing your greeting, please try again later.
a650	f607: Name cannot be saved at this time, please continue
a651	f720: Alias entered not followed by pound and not added to the directory.
a652	f719: Extension entered not followed by pound and not added to the directory.
a653	f718: Name entered not followed by pound and not added to the directory.
a654	f37: Extension entered not followed by pound f187: and not added to the list. f464: Enter extensions f224: and pound sign. f349: To approve list as is, press pound.
a655	f38: Name entered not followed by pound f187: and not added to the list. f118: Enter last name f224: and pound sign. f349: To approve list as is, press pound.
a656	f798: Prime time is TIME, f524: to TIME(2)
a657	f798: Prime time is TIME, f524: to TIME(2),

Announcement	Fragments
	f788: To identify calls as out-of-hours, press 3. f789: Otherwise, press 4.
a658	f226: private f47: Call from NAME, f262: received TIME,DATE,a873(NUMBER)
a659	f226: private f47: Call from NAME, f262: received TIME,DATE, f86: extension BUTTONS,a873(NUMBER)
a660	f226: private f50: Call NAME, f262: received TIME,DATE, f86: extension BUTTONS,a873(NUMBER)
a661	f226: private f50: Call f262: received TIME,DATE,a873(NUMBER)
a662	f226: private f110: list

Announcement	Fragments
| a663 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
                f1068:  Private fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                        f1069:  Private voice and fax message
                        from
                ELSE
                        f686:  Private message from
                ENDIF
        ENDIF,
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
a1010(NUMBER,NUMBER(2),NUMBER(3))
ELSE
        f686:  Private message from
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
a873(NUMBER)
ENDIF
``` |
| a664 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
                f1068:  Private fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                        f1069:  Private voice and fax message
                        from
                ELSE
                        f686:  Private message from
                ENDIF
        ENDIF,
``` |

Announcement	Fragments
| | ```
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
        a1010(NUMBER,NUMBER(2),NUMBER(3)),
        f689:  Expiration time is
TIME(2),DATE(2)
ELSE
        f686:  Private message from
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
        a873(NUMBER),
        f689:  Expiration time is
TIME(2),DATE(2)
ENDIF
``` |
| a665 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
                f1068:  Private fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                        f1069:  Private voice and fax message
                        from
                ELSE
                        f686:  Private message from
                ENDIF
        ENDIF,
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION
ELSE
        f686:  Private message from
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
a873(NUMBER),EXTENSION
ENDIF
``` |

Announcement	Fragments
| a666 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
            f1068:  Private fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                  f1069:  Private voice and fax message
                  from
                ELSE
                  f686:  Private message from
                ENDIF
         ENDIF,
      NAME,
      f262:  received
      TIME,DATE,
      f905:  <.5 second pause>
      a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION,
      f689:  Expiration time is
TIME(2),DATE(2)
ELSE
      f686:  Private message from
      NAME,
      f262:  received
      TIME,DATE,
      f905:  <.5 second pause>
      a873(NUMBER),EXTENSION,
      f689:  Expiration time is
TIME(2),DATE(2)
ENDIF
``` |
| a667 | f918: To re-schedule delivery, press 3. |
| a668 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
      IF (NUMBER(2)==2)
      THEN
            f1057:  Priority fax message from
      ELSE
            IF (NUMBER(2)==3)
            THEN
                f1058:  Priority voice and fax message
``` |

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| | ```
                      from
              ELSE
                      f690:  Priority message from
              ENDIF
        ENDIF,
        NAME,
        f262:  received
TIME,DATE,a1010(NUMBER,NUMBER(2),NUMBER(3))
ELSE
        f690:  Priority message from
        NAME,
        f262:  received
TIME,DATE,a873(NUMBER)
ENDIF
``` |
| a669 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
                f1057:  Priority fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                        f1058:  Priority voice and fax message
                        from
                ELSE
                        f690:  Priority message from
                ENDIF
        ENDIF,
        NAME,
        f262:  received
TIME,DATE,a1010(NUMBER,NUMBER(2),NUMBER(3)),
        f689:  Expiration time is
TIME(2),DATE(2)

ELSE
        f690:  Priority message from
        NAME,
        f262:  received
        TIME,DATE,a873(NUMBER),
        f689:  Expiration time is
TIME(2),DATE(2)
ENDIF
``` |

Announcement	Fragments
| a670 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
                f1057:  Priority fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                        f1058:  Priority voice and fax message
                        from
                ELSE
                        f690:  Priority message from
                ENDIF
        ENDIF,
        NAME,
        f262:  received
TIME,DATE,a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION
ELSE
        f690:  Priority message from
        NAME,
        f262:  received
TIME,DATE,a873(NUMBER),EXTENSION
ENDIF
``` |
| a671 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
                f1057:  Priority fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                        f1058:  Priority voice and fax message
                        from
                ELSE
                        f690:  Priority message from
                ENDIF
        ENDIF,
        NAME,
        f262:  received
TIME,DATE,
        a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION,
``` |

Announcement	Fragments

	f689: Expiration time is
	TIME(2),DATE(2)
	ELSE
	    f690: Priority message from
	    NAME,
	    f262: received
	    TIME,DATE,a873(NUMBER),EXTENSION,
	    f689: Expiration time is
	TIME(2),DATE(2)
	ENDIF

a672	f919: To file a copy, press 4.

a673	```# VERSION > 2 is for INTUITY 3.0 Fax Feature.```
	```# NUMBER == length of voice portion.```
	```# NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice```
	and fax.
	IF (VERSION > 2)
	THEN
	    IF (NUMBER(2) == 2)
	    THEN
	        f1115: Priority fax message to
	    ELSE
	        IF (NUMBER(2) == 3)
	        THEN
	            f1116: Priority voice and fax message
	            to
	        ELSE
	            f698: Priority message to
	        ENDIF
	    ENDIF
	ELSE
	    f698: Priority message to
	ENDIF,
	NAME,
	IF (NUMBER>0)
	THEN
	    f2: and
	NUMBER,
	IF (NUMBER==1)
	THEN
	       f602: other
	ELSE
	       f217: others
	ENDIF
	ENDIF

a674	f227: public f110: list

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| a675 | ```
# VERSION > 2 is for INTUITY 3.0 Fax Feature.
# NUMBER == length of voice portion.
# NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice
and fax.
IF (VERSION > 2)
THEN
        IF (NUMBER(2) == 2)
        THEN
                f1122:  Private broadcast fax message to
        ELSE
                IF (NUMBER(2) == 3)
                THEN
                        f1123:  Private broadcast voice and
                        fax message to
                ELSE
                        f1121:  Private broadcast message to
                ENDIF
        ENDIF,
        f1117:  all local subscribers.
ELSE
        f694:  Private, broadcast message to all local
        subscribers
ENDIF,
IF (NUMBER>0)
THEN
        f2:  and
NUMBER,
IF (NUMBER==1)
THEN
                f602:  other
ELSE
                f217:  others
ENDIF
ENDIF
``` |
| a676 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
                f1059:  Private, priority fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                        f1060:  Private, priority voice and
                        fax message from
                ELSE
                        f685:  Private, priority message from
``` |

Announcement	Fragments
| | ```
              ENDIF
        ENDIF,
        NAME,
        f262:  received
TIME,DATE,a1010(NUMBER,NUMBER(2),NUMBER(3))
ELSE
        f685:  Private, priority message from
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
a873(NUMBER)
ENDIF
``` |
| a677 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
                f1059:  Private, priority fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                        f1060:  Private, priority voice and
                        fax message from
                ELSE
                        f685:  Private, priority message from
                ENDIF
        ENDIF,
        NAME,
        f262:  received
        TIME,DATE,
        a1010(NUMBER,NUMBER(2),NUMBER(3)),
        f689:  Expiration time is
        TIME(2),DATE(2)
ELSE
        f685:  Private, priority message from
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
        a873(NUMBER),
        f689:  Expiration time is
TIME(2),DATE(2)
ENDIF
``` |

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| a678 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
                f1059:  Private, priority fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                        f1060:  Private, priority voice and
                        fax message from
                ELSE
                        f685:  Private, priority message from
                ENDIF
        ENDIF,
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
        a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION
ELSE
        f685:  Private, priority message from
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
a873(NUMBER),EXTENSION
ENDIF
``` |
| a679 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
                f1059:  Private, priority fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                        f1060:  Private, priority voice and
                        fax message from
                ELSE
                        f685:  Private, priority message from
                ENDIF
        ENDIF,
``` |

Announcement	Fragments

	NAME,
	f262: received
	TIME,DATE,
	f905: <.5 second pause>
	a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION,
	f689: Expiration time is
	TIME(2),DATE(2)
	ELSE
	     f685: Private, priority message from
	     NAME,
	     f262: received
	     TIME,DATE,
	     f905: <.5 second pause>
	     a873(NUMBER),EXTENSION,
	     f689: Expiration time is
	TIME(2),DATE(2)
	ENDIF

a680	f242: Returned to the f57: accessed f164: category. f142: To listen to the header, press 3.
a681	f242: Returned to the f59: delivered f164: category. f142: To listen to the header, press 3.
a682	f242: Returned to the f473: filed f164: category. f142: To listen to the header, press 3.
a683	f242: Returned to the f63: new f164: category. f142: To listen to the header, press 3.
a684	f242: Returned to the f64: old f164: category. f142: To listen to the header, press 3.
a685	f242: Returned to the f68: undeliverable f164: category. f142: To listen to the header, press 3.
a686	f242: Returned to the f69: undelivered f164: category. f142: To listen to the header, press 3.
a687	f242: Returned to the f70: unopened f164: category. f142: To listen to the header, press 3.
a688	f228: Record at the tone.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a689	f229: You will have up to NUMBER, f230: seconds to record.
a690	f604: As you use AUDIX your name will be included in system announcements that you and other people will hear. Press 1, and at the tone, please speak your name. After speaking your name, press 1 again.
a691	f232: Recording stopped.
a692	f232: Recording stopped. f193: No name recorded. f608: At the tone, please speak your name. After speaking your name, press 1.
a693	f486: To reply to sender by voice mail, press 1. f18: To forward with comment, press 2. f8: To record a new message, press 4.
a694	f127: Returned to previous activity. f96: For help, press star 4.
a695	f19: To review from beginning, press star 1. If finished, press star pound.
a696	f147: Review completed.
a697	f147: Review completed. f569: To modify, press 1. If finished, press star pound.
a698	f147: Review completed. f19: To review from beginning, press star 1. If finished, press star pound.
a699	f256: At beginning. To re-record, press 1. To playback, press 2-3.
a700	f619: To remove broadcast status, press 8.
a701	f620: To remove login announcement status, press 9.
a702	f635: To remove non-interruptible status, press 1.
a703	f796: To remove out-of-hours identification, press 4.
a704	f618: To remove priority status, press 2.
a705	f617: To remove private status, press 1.
a706	f244: Rewound to previous message. f142: To listen to the header, press 3.
a707	f802: Cannot send a message to the broadcast mailbox.
a708	f245: Please return call.
a709	f245: Please return call. f86: extension BUTTONS
a710	f785: Same greeting used for all calls.
a711	f785: Same greeting used for all calls. f786: To identify calls as internal and external, press 1. f787: To identify calls as busy and no answer, press 2.
a712	f511: If you do not have a touch tone phone, f236: Try again f109: later.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	f514: otherwise
	f274: Please make entry soon, or be disconnected.
a713	f248: scheduled TIME,DATE, f249: To change delivery time, press star 3; To approve, press pound.
a714	f250: To change delivery time, press star 3.
a715	f22: To deliver now, press pound. To schedule delivery time enter hour and minutes, press 2 for A.M. or 7 for P.M., and pound sign.
a716	f629: Please enter month, day, and pound sign.
a717	f477: Press 1 to select NAME
a718	f905: <.5 second pause> f478: 2 to select NAME
a719	f905: <.5 second pause> f479: 3 to select NAME
a722	f23: To record messages, press 1. To get messages, press 2. To administer your greeting, press 3.
a723	f501: To record messages, press 1. To get messages, press 2. To administer attendant menu, press 3.
a724	f482: Press pound to select NAME, f483: or enter more characters f224: and pound sign. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a725	f482: Press pound to select NAME, f483: or enter more characters f224: and pound sign.
a726	f482: Press pound to select NAMEEXT, f483: or enter more characters f224: and pound sign. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a727	f257: To use personal greeting, press 9. To use system greeting, press 6.
a728	f775: To record messages, press 1. To get messages, press 2. To administer personal greetings, press 3.
a729	f674: Due to sending restrictions, you cannot send messages to NAME
a730	f388: To skip, press the pound key.
a731	f626: To specify expiration date, press 2.
a732	f626: To specify expiration date, press 2. f634: To approve login announcement options, press pound.
a733	f243: Rewound. f142: To listen to the header, press 3. f143: To step back again, press 2.
a734	f537: Enter the starting hour and minutes, press 2 for A.M. or 7 for P.M., and pound sign.
a735	f466: created TIME,DATE
a736	f259: scheduled for TIME,DATE
a737	f259: scheduled for TIME,DATE, f689: Expiration time is TIME(2),DATE(2)
a738	f259: scheduled for TIME,DATE, f730: Message not delivered because the broadcast mailbox was not defined.
a739	f259: scheduled for TIME,DATE, f699: Message not delivered because another login announcement is active.
a740	f259: scheduled for TIME,DATE, f738: Message not delivered due to sending restrictions.
a741	f259: scheduled for TIME,DATE, f98: Message not delivered due to transmission problems.
a742	f259: scheduled for TIME,DATE, f387: Message not delivered because recipient not found.
a743	f259: scheduled for TIME,DATE,

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	f584: Message not delivered because special feature denied on recipients machine.
a744	f259: scheduled for TIME,DATE, f264: Message not delivered because mailbox was full.
a745	f262: received TIME,DATE
a746	f262: received TIME,DATE, f689: Expiration time is TIME(2),DATE(2)
a748	f920: To not file a copy, press 4.
a749	f472: To approve, press pound. To record from here, press 1. f468: To continue playing, press 3.
a750	f499: When finished recording, press # to approve, or 1 to edit your message.
a751	f475: To file a copy, press 9 for yes or 6 for no.
a752	f977: Name not found.
a754	f270: subscriber id f202: not valid.

Announcement	Fragments
| a755 | ```
# VERSION > 2 is for INTUITY 3.0 Fax Feature.
# NUMBER == 0 if fax not allowed, and 1 if fax allowed.
# NUMBER(2) is 0 for addressing options not allowed, 1
for addressing options
# allowed.
# NUMBER(3) is 0 for call answer options not allowed, 1
for call answer options
# allowed.
IF (VERSION > 2)
THEN
        f700:  To administer mailing lists, press 1. To
        administer personal directory, press 2.
        IF (NUMBER == 1)
        THEN
                f1052:  To specify your  fax preferences,
                press 3.
        ENDIF,
        f701:  To change your password, press 4.
        IF (NUMBER(2) == 1)
        THEN
                f1144:  To specify whether a message can be
                addressed  before it's recorded, press 6.
        ENDIF,
        IF (NUMBER(3) == 1)
        THEN
                f1145:  To administer call answer options,
                press 7.
        ENDIF
ELSE
        f700:  To administer mailing lists, press 1. To
        administer personal directory, press 2.
        f701:  To change your password, press 4.
ENDIF
``` |
| a756 | ```
# VERSION > 2 is for INTUITY 3.0 Fax Feature.
# NUMBER == 0 if fax not allowed, and 1 if fax allowed.
# NUMBER(2) is 0 for addressing options not allowed, 1
for addressing options
# allowed.
# NUMBER(3) is 0 for call answer options not allowed, 1
for call answer options
# allowed.
IF (VERSION > 2)
THEN
        f700:  To administer mailing lists, press 1. To
        administer personal directory, press 2.
        IF (NUMBER == 1)
        THEN
                f1052:  To specify your  fax preferences,
                press 3.
        ENDIF,
        f701:  To change your password, press 4.
``` |

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

	f702: To record your name, press 5.
	IF (NUMBER(2) == 1)
	THEN
	    f1144: To specify whether a message can be
	    addressed before it's recorded, press 6.
	ENDIF,
	IF (NUMBER(3) == 1)
	THEN
	    f1145: To administer call answer options,
	    press 7.
	ENDIF
	ELSE
	    f700: To administer mailing lists, press 1. To
	    administer personal directory, press 2.
	    f701: To change your password, press 4.
	    f702: To record your name, press 5.
	ENDIF

a757	f26: To record names, press 4. To play names, press 5. To record machine names, press 6. To play machine names, press 7.
a758	f539: The system allows outcalls from TIME, f524: to TIME(2)
a759	f18: To forward with comment, press 2. f8: To record a new message, press 4. f163: To call sender, press zero.
a760	f486: To reply to sender by voice mail, press 1. f8: To record a new message, press 4. f163: To call sender, press zero.
a761	f8: To record a new message, press 4. f163: To call sender, press zero.
a762	f274: Please make entry soon, or be disconnected.
a763	f96: For help, press star 4. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9. f274: Please make entry soon, or be disconnected.
a764	f533: Too many digits.
a765	f276: Time requested has passed, please re-schedule delivery. f22: To deliver now, press pound. To schedule delivery time enter hour and minutes, press 2 for A.M. or 7 for P.M., and pound sign.
a766	f275: Cannot get your messages now, due to multiple logins to your mailbox. f95: Please disconnect.

Announcement	Fragments
| a767 | ```
# VERSION > 2 is for INTUITY 3.0 Fax Feature.
# NUMBER == length of voice portion.
# NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice
and fax.
IF (VERSION > 2)
THEN
        IF (NUMBER(2) == 2)
        THEN
                f1109:  Private, priority fax message to
        ELSE
                IF (NUMBER(2) == 3)
                THEN
                        f1110:  Private, priority voice and
                        fax message to
                ELSE
                        f695:  Private, priority message to
                ENDIF
        ENDIF
ELSE
        f695:  Private, priority message to
ENDIF,
NAME,
IF (NUMBER>0)
THEN
        f2:  and
NUMBER,
IF (NUMBER==1)
THEN
                f602:  other
ELSE
                f217:  others
ENDIF
ENDIF
``` |
a768	f486: To reply to sender by voice mail, press 1. f18: To forward with comment, press 2. f8: To record a new message, press 4. f163: To call sender, press zero.
a769	f128: To request another transfer, press star 8.
a770	f118: Enter last name f224: and pound sign. f175: Please note only AUDIX subscribers can be specified by name. f117: To reach the covering extension, press star zero. f251: To transfer using extension instead, press star 2.
a771	f118: Enter last name f224: and pound sign. f175: Please note only AUDIX subscribers can be specified by name. f117: To reach the covering extension, press star zero.

Announcement	Fragments
	f251: To transfer using extension instead, press star 2.
	f335: When finished, press pound.
a772	f512: Your call is being transferred to an operator.
a773	f118: Enter last name
	f224: and pound sign.
	f251: To transfer using extension instead, press star 2.
a774	f118: Enter last name
	f224: and pound sign.
	f251: To transfer using extension instead, press star 2.
	f335: When finished, press pound.
a775	f515: To be transferred to an operator,
	f380: Please wait.
a776	f933: Undeliverable Messages
a777	f934: Undelivered Messages
a778	f688: An undeliverable message was returned to your outgoing mailbox. To access your outgoing mailbox, press star 7-4.
a779	f687: Undeliverable message notification received TIME,DATE
a780	f935: Unopened Messages
a781	f541: Up to NUMBER,
	f542: digits may be used.
a783	f766: To use this greeting for all calls, press 1.
	f913: If finished, press pound.
a784	f783: To activate another greeting, enter greeting number. To deactivate a greeting, activate a different greeting in its place.
	f784: To activate system greeting, enter zero.
	f913: If finished, press pound.
a785	f767: To use this greeting for all calls, press 0. For busy calls, press 1. For no answer calls, press 2.
a786	f767: To use this greeting for all calls, press 0. For busy calls, press 1. For no answer calls, press 2.
	f913: If finished, press pound.
a787	f764: To use this greeting for all calls, press 0. For internal calls, press 1. For external calls, press 2.
a788	f764: To use this greeting for all calls, press 0. For internal calls, press 1. For external calls, press 2.
	f913: If finished, press pound.
a789	f782: To activate a greeting, enter greeting number. To deactivate a greeting, activate a different greeting in its place.
	f784: To activate system greeting, enter zero.
	f913: If finished, press pound.
a790	f331: Personal greeting used.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a791	f797: To use same greeting for all calls, press 5. f913: If finished, press pound.
a792	f332: System greeting used.
a793	f332: System greeting used. f823: ...for all calls
a794	f332: System greeting used. f827: ...for busy f2: and f812: no answer f814: calls.
a795	f332: System greeting used. f827: ...for busy f813: and out-of-hours f814: calls.
a796	f332: System greeting used. f827: ...for busy f814: calls.
a797	f332: System greeting used. f827: ...for busy f812: no answer f813: and out-of-hours f814: calls.
a798	f332: System greeting used. f826: ...for external f813: and out-of-hours f814: calls.
a799	f332: System greeting used. f826: ...for external f814: calls.
a800	f332: System greeting used. f825: ...for internal f2: and f810: external f814: calls.
a801	f332: System greeting used. f825: ...for internal f813: and out-of-hours f814: calls.
a802	f332: System greeting used. f825: ...for internal f814: calls.
a803	f332: System greeting used. f825: ...for internal f810: external f813: and out-of-hours f814: calls.
a804	f332: System greeting used. f828: ...for no answer f813: and out-of-hours f814: calls.
a805	f332: System greeting used.

Announcement	Fragments
	f828: ...for no answer
	f814: calls.
a806	f332: System greeting used.
	f829: ...for out-of-hours
	f814: calls.
| a808 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
                f1071:  Fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                        f1072:  Voice and fax message from
                ELSE
                        f281:  Message from
                ENDIF
        ENDIF,
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
a1010(NUMBER,NUMBER(2),NUMBER(3))
ELSE
        f281:  Message from
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
a873(NUMBER)
ENDIF
``` |

Announcement	Fragments
| a809 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
                f1071:  Fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                        f1072:  Voice and fax message from
                ELSE
                        f281:  Message from
                ENDIF
        ENDIF,
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
        a1010(NUMBER,NUMBER(2),NUMBER(3)),
        f689:  Expiration time is
TIME(2),DATE(2)
ELSE
        f281:  Message from
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
        a873(NUMBER),
        f689:  Expiration time is
TIME(2),DATE(2)
ENDIF
``` |
| a810 | ```
# VERSION > 2 is INTUITY FAX feature.  NUMBER is length
of voice portion
# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice
fax.
# NUMBER(3) is length of fax portion in pages.
IF (VERSION > 2)
THEN
        IF (NUMBER(2)==2)
        THEN
                f1071:  Fax message from
        ELSE
                IF (NUMBER(2)==3)
                THEN
                        f1072:  Voice and fax message from
                ELSE
                        f281:  Message from
``` |

Announcement	Fragments
|  | ```
              ENDIF
        ENDIF,
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION
ELSE
        f281:  Message from
        NAME,
        f262:  received
        TIME,DATE,
        f905:  <.5 second pause>
a873(NUMBER),EXTENSION
ENDIF
``` |

Announcement	Fragments

a811	`# VERSION > 2 is INTUITY FAX feature.  NUMBER is length of voice portion`
	`# NUMBER(2) == 1 for voice, 2 for fax, and 3 for voice fax.`
	`# NUMBER(3) is length of fax portion in pages.`
	`IF (VERSION > 2)`
	`THEN`
	`        IF (NUMBER(2)==2)`
	`        THEN`
	`                f1071:  Fax message from`
	`        ELSE`
	`                IF (NUMBER(2)==3)`
	`                THEN`
	`                        f1072:  Voice and fax message from`
	`                ELSE`
	`                        f281:  Message from`
	`                ENDIF`
	`        ENDIF,`
	`        NAME,`
	`        f262:  received`
	`        TIME,DATE,`
	`        f905:  <.5 second pause>`
	`        a1010(NUMBER,NUMBER(2),NUMBER(3)),EXTENSION,`
	`        f689:  Expiration time is`
	`TIME(2),DATE(2)`
	`ELSE`
	`        f281:  Message from`
	`        NAME,`
	`        f262:  received`
	`        TIME,DATE,`
	`        f905:  <.5 second pause>`
	`        a873(NUMBER),EXTENSION,`
	`        f689:  Expiration time is`
	`TIME(2),DATE(2)`
	`ENDIF`

a812	`f87:  This call is experiencing difficulties.` `f1007:  To playback, press 2-3.`
a813	`f380:  Please wait.`

a814	`f283:  Your mailbox is more than`
	`NUMBER,`
	`f284:  percent full. Please delete unneeded messages or greetings.`

a815	`f287:  Welcome to AUDIX.` `f97:  For help at any time, press star 4.`
a816	`f179:  Warning, if you do not supply an addressee list, message will be deleted immediately.`
a817	`f293:  Nothing to playback.`
a818	`a902(NUMBER(1)),a903(NUMBER(2)),a904(NUMBER(1),NUMBER(2))`

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a819	TIME, f253: Please enter month, day f224: and pound sign.

a820	IF (NUMBER<=60)
	THEN
	    (f390+NUMBER)
	ELSE
	    IF (NUMBER<=100)
	    THEN
	        (f450+((NUMBER-60)/10)),
	        IF (NUMBER%10>0)
	        THEN
	            (f390+(NUMBER%10))
	        ENDIF
	    ELSE
	        a901(NUMBER)
	    ENDIF
	ENDIF

a821	f86: extension BUTTONS
a822	f20: Remote extension BUTTONS
a823	f463: star
a824	f462: pound
a825	f546: pause
a826	f277: To exit directory, press pound.
a827	f482: Press pound to select NAMEEXT, f483: or enter more characters
a828	f764: To use this greeting for all calls, press 0. For internal calls, press 1. For external calls, press 2. f773: To activate for out-of-hours calls, press 3. f913: If finished, press pound.
a829	f767: To use this greeting for all calls, press 0. For busy calls, press 1. For no answer calls, press 2. f773: To activate for out-of-hours calls, press 3. f913: If finished, press pound.
a830	f818: You have just recorded f754: Greeting NUMBER

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a831	f658: Message waiting notification is currently not active. f625: To activate message waiting notification, press 1. f659: Message waiting notification will alert all local subscribers of this message. This option should be used sparingly, for it can impact system performance. f626: To specify expiration date, press 2.
a832	f628: To deactivate message waiting notification, press 1. f626: To specify expiration date, press 2. f627: To approve broadcast options, press pound.
a833	f625: To activate message waiting notification, press 1. f626: To specify expiration date, press 2. f627: To approve broadcast options, press pound.
a834	f87: This call is experiencing difficulties. f236: Try again f109: later. f95: Please disconnect.
a836	f110: list BUTTONS, f142: To listen to the header, press 3. f143: To step back again, press 2.

a837	# VERSION > 2 is for INTUITY 3.0 Fax Feature.
	# NUMBER == is 0 if no new fax, 1 if new fax is present in the mailbox.
	IF (VERSION > 2)
	THEN
	        f846: You are selecting an option for Automatic Message Scan.
	        f843: To scan headers and messages, press 1. To scan headers only, press 2. To scan messages only, press 3.
	        IF (NUMBER == 1)
	        THEN
	                f1040: To print all new faxes, press 4.
	        ENDIF
	ELSE
	        f846: You are selecting an option for Automatic Message Scan.
	        f843: To scan headers and messages, press 1. To scan headers only, press 2. To scan messages only, press 3.
	ENDIF

a838	# VERSION > 2 is for INTUITY 3.0 Fax Feature. # NUMBER == length of voice portion. # NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice and fax. IF (VERSION > 2)

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
|  | ```
THEN
        IF (NUMBER(2) == 2)
        THEN
                f1125:  Fax message to
        ELSE
                IF (NUMBER(2) == 3)
                THEN
                        f1126:  Voice and fax message to
                ELSE
                        f258:  Message to
                ENDIF
        ENDIF
ELSE
        f258:  Message to
ENDIF,
NAME,
IF (NUMBER>0)
THEN
        f2:  and
NUMBER,
IF (NUMBER==1)
THEN
                f602:  other
ELSE
                f217:  others
ENDIF
ENDIF
``` |

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| a840 | ```
# VERSION > 2 is for INTUITY 3.0 Fax Feature.
# NUMBER == length of voice portion.
# NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice
and fax.
IF (VERSION > 2)
THEN
        IF (NUMBER(2) == 2)
        THEN
                f1119:  Private fax message to
        ELSE
                IF (NUMBER(2) == 3)
                THEN
                        f1120:  Private voice and fax message
                        to
                ELSE
                        f696:  Private message to
                ENDIF
        ENDIF
ELSE
        f742:  Private message sent to
ENDIF,
NAME,
IF (NUMBER>0)
THEN
        f2:  and
NUMBER,
IF (NUMBER==1)
THEN
                f602:  other
ELSE
                f217:  others
ENDIF
ENDIF
``` |
| a841 | ```
# VERSION > 2 is for INTUITY 3.0 Fax Feature.
# NUMBER == length of voice portion.
# NUMBER(2) == 1, voice only, 2 - fax only, 3 - voice
and fax.
IF (VERSION > 2)
THEN
        IF (NUMBER(2) == 2)
        THEN
                f1119:  Private fax message to
        ELSE
                IF (NUMBER(2) == 3)
                THEN
                        f1132:  Private voice and fax message
                        to
                ELSE
                        f696:  Private message to
                ENDIF
        ENDIF
``` |

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

	ELSE
	     f696: Private message to
	ENDIF,
	NAME,
	IF (NUMBER>0)
	THEN
	     f2: and
	NUMBER,
	IF (NUMBER==1)
	THEN
	       f602: other
	ELSE
	       f217: others
	ENDIF
	ENDIF

a842	f647: the message will be private.
a843	f390: oh
a844	f391: one
a845	f392: two
a846	f393: three
a847	f394: four
a848	f395: five
a849	f396: six
a850	f397: seven
a851	f398: eight
a852	f399: nine
a853	f308: You are playing announcement fragments. f279: Enter announcement set and pound sign.
a854	f307: You are playing announcements. f279: Enter announcement set and pound sign.
a855	f900: 123 Standard US English
a856	f901: Announcement set does not exist
a857	f902: Announcement set
a858	f909: Announcement BUTTONS, f906: <1.0 second pause>
a859	f910: You are playing an announcement which need additional input before it can be played. f832: Please enter extension and pound sign. f58: For name addressing, press star 2.
a860	f910: You are playing an announcement which need additional input before it can be played. f710: Enter next name and pound sign. f148: For extension addressing, press star 2.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a861	f910: You are playing an announcement which need additional input before it can be played. f329: You have not yet entered enough characters to identify a specific subscriber. To enter the letter Q, press 7; for Z press 9. f484: Enter more characters followed by the pound sign; if you just completed entering the last name, enter the first name. f224: and pound sign.
a862	f383: Please enter hour, then two digits for minutes, then press 2 for A.M. or 7 for P.M., and pound sign.
a863	f910: You are playing an announcement which need additional input before it can be played. f383: Please enter hour, then two digits for minutes, then press 2 for A.M. or 7 for P.M., and pound sign.
a864	f914: not filed.
a865	f915: No options menu available.
a866	f226: private
a867	f969: You are choosing between announcement sets whose names match your entry. To indicate no announcement sets match, delete entry by pressing star 3.
a868	f921: To make private, press 1. To send, press #.
a869	f922: To access the Delivery Options Menu, press # after recording your message.
a870	f923: Press # to approve your message and access the Delivery Options Menu
a871	f926: <error sound>
a872	f937: Sorry you are having difficulty. Please get help and try again later. f94: Good-bye.

a873	IF (NUMBER<100)
	THEN
	     IF (NUMBER%10==0)
	     THEN
	          IF (NUMBER==0)
	          THEN
	               f585: Zero
	               f924: seconds
	          ELSE
	               a820(NUMBER),
	               f924: seconds
	          ENDIF
	     ELSE
	          a972(NUMBER)
	     ENDIF
	ELSE
	     a820((NUMBER+30)/60),
	     f925: minutes
	ENDIF

a874	f4: not private.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a875	f601: Priority
a876	f622: not Priority.
a877	f158: Transfer cannot be completed. f236: Try again f109: later.
a878	f263: You are recording a subscriber name. f980: To record from here, press 1 f979: After recording, press 1 again
a879	f346: You are recording a machine name. f13: To record, press 1. After recording, press 1 again.
a880	f263: You are recording a subscriber name. f980: To record from here, press 1 f979: After recording, press 1 again f304: To playback message, press 2-3. To delete your message, press star 3. To approve your message, press pound. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
a881	f346: You are recording a machine name. f13: To record, press 1. After recording, press 1 again. f304: To playback message, press 2-3. To delete your message, press star 3. To approve your message, press pound. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
a882	f73: You have NUMBER, f854: seconds to finish recording.
a883	f232: Recording stopped. f570: Recorded name too long f608: At the tone, please speak your name. After speaking your name, press 1.
a886	f978: unknown f861: AMIS f510: Number
a889	f25: List id not followed by pound. f498: Please enter a new list id f224: and pound sign.
a890	f37: Extension entered not followed by pound f364: enter owner's extension f224: and pound sign. f471: If it's your list, press pound.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a891	f38: Name entered not followed by pound f470: Enter owner's last name f224: and pound sign. f471: If it's your list, press pound.

a892	```
	# VERSION > 2 is for INTUITY 3.0 Fax Feature.
	# NUMBER == 1-voice only, 2-fax only, 3-voice and fax.
	# NUMBER(2) - 1 - fax enabled, 0 - fax disabled
	IF (VERSION > 2)
	THEN
	        IF (NUMBER == 1)
	        THEN
	                f856: This is a recorded message from
	                NAME,
	                f21: To listen, press 0.
	                f24: To delete, press star 3.
	        ELSE
	                IF (NUMBER == 2)
	                THEN
	                        f1044: This is a fax message from
	NAME,
	                        IF (NUMBER(2) == 1)
	                        THEN
	                                f1073: To print, press star 1.
	                        ENDIF,
	                        f24: To delete, press star 3.
	                ELSE
	                        IF (NUMBER == 3)
	                        THEN
	                                f1045: This is a voice and fax
	                                message from
	                                NAME,
	                                f21: To listen, press 0.
	                                IF (NUMBER(2) == 1)
	                                THEN
	                                        f1073: To print, press
	                                        star 1.
	                                ENDIF,
	                                f24: To delete, press star 3.
	                        ENDIF
	                ENDIF
	        ENDIF
	ELSE
	        f856: This is a recorded message from
	        NAME,
	        f21: To listen, press 0.
	        f24: To delete, press star 3.
	ENDIF
	``

a893	f856: This is a recorded message from NAME, f21: To listen, press 0. f24: To delete, press star 3.

Announcement	Fragments
	f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.
a894	f562: Enter the f855: remote AMIS mailbox id f224: and pound sign.
a895	f867: You are entering the f855: remote AMIS mailbox id f868: Mailbox id must be less than or equal to 16 digits. f833: To delete current entry, press star 3.
a896	f259: scheduled for TIME,DATE, f862: It could not be delivered because the recipient appears to be a wrong number.
a897	f259: scheduled for TIME,DATE, f863: It could not be delivered after multiple attempts to deliver the message.
a898	f864: Automated call, please press 1 to disconnect.
a899	f865: Your number was dialed by mistake. We are sorry for this inconvenience. To prevent this from recurring, this call has been reported as a misdialed call.

a901	`IF (NUMBER>1000)`
	`THEN`
	`        a906(NUMBER)`
	`ELSE`
	`        a820(NUMBER/100),`
	`        f454:  hundred`
	`        IF (NUMBER%100>0)`
	`        THEN`
	`                a820(NUMBER%100)`
	`        ENDIF`
	`ENDIF`

a902	`IF (NUMBER==0)`
	`THEN`
	`        a820(12)`
	`ELSE`
	`        IF (NUMBER>12)`
	`        THEN`
	`                a820(NUMBER-12)`
	`        ELSE`
	`                a820(NUMBER)`
	`        ENDIF`
	`ENDIF`

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a903	<pre>IF (NUMBER>0)
	THEN
	        IF (NUMBER<10)
	        THEN
	                f390: oh
	        ENDIF,
	        a820(NUMBER)
	ENDIF</pre>

a904	<pre>IF (NUMBER>12)
	THEN
	        f301: P. M.
	ELSE
	        IF (NUMBER==12)
	        THEN
	                IF (NUMBER(2)==0)
	                THEN
	                        f201: noon.
	                ELSE
	                        f301: P. M.
	                ENDIF
	        ELSE
	                IF (NUMBER==0&&NUMBER(2)==0)
	                THEN
	                        f161: midnight.
	                ELSE
	                        f300: A. M.
	                ENDIF
	        ENDIF
	ENDIF</pre>

a905	<pre>(f938 + (NUMBER - 1))</pre>

a906	<pre>IF (NUMBER(1)>1000000)
	THEN
	        f456: million
	ELSE
	        a820(NUMBER/1000),
	        f455: thousand
	        IF ((NUMBER%1000)>0)
	        THEN
	                a820(NUMBER%1000)
	        ENDIF
	ENDIF</pre>

a907	<pre># VERSION > 2 is for INTUITY 3.0 Fax Feature.
	# NUMBER == 1-voice only, 2-fax only, 3-voice and fax.
	IF (VERSION > 2)
	THEN
	        IF (NUMBER == 1)
	        THEN</pre>

Announcement	Fragments

	f858: To replay, press 0.
	f24: To delete, press star 3.
	    ELSE
	
	       IF (NUMBER == 2)
	       THEN
	          f1046: This is a fax message.
	          f1047: To print
	          f1012: Press START on your fax
	          machine now.
	          f24: To delete, press star 3.
	       ELSE
	
	          IF (NUMBER == 3)
	          THEN
	             f858: To replay, press 0.
	             f1047: To print
	             f1012: Press START on your fax
	             machine now.
	             f24: To delete, press star 3.
	          ENDIF
	       ENDIF
	    ENDIF
	ELSE
	    f858: To replay, press 0.
	    f24: To delete, press star 3.
	ENDIF

a908	f74: deleted. f95: Please disconnect.
a909	f859: Mailbox id not followed by pound.
a910	f860: Mailbox id not valid.
a911	f866: AMIS casual subscribers cannot be added to your list.
a912	f561: You are addressing your message. f285: To add a member, enter extension f224: and pound sign. f869: If the extension entered belongs to a casual AMIS subscriber, you will be prompted for a mailbox id. f868: Mailbox id must be less than or equal to 16 digits. f328: To delete the previous entry, press star 3. To add a mailing list you have already created, or a public list owned by others, press star 5. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound. f58: For name addressing, press star 2.
a913	NAME, f75: To skip, press pound. To delete, press star 3. f333: To add entries to the list or to change status of list, press 1.
a914	f9: star 7 not available.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a915	f861: AMIS BUTTONS, f86: extension BUTTONS(2)
a916	TIME
a917	f711: Alias BUTTONS, f712: defined for NAMEEXT
a918	DATE
a919	f617: To remove private status, press 1. f971: To send, press #.

a920	# announcement changed for Intuity MACH3 FAX Feature
	# VERSION is 2 for 3.1 DEFINITY AUDIX and 3 for INTUITY 3.0 fax feature
	# NUMBER 0 is no message, 1 is message was left
	IF (VERSION > 2)
	THEN
	    # Intuity 3.0 VERSION = 3
	    IF (NUMBER == 1)
	    THEN
	        f56: Thank you for leaving your message.
	    ENDIF,
	    f46: To access your mailbox, press star 7.
	    f291: To transfer to another extension, press star 8.
	    f973: If you are finished, please hang up, or press star, star 9.
	ELSE
	    # Definity Audix 3.1 VERSION = 2
	    f56: Thank you for leaving your message.
	    f46: To access your mailbox, press star 7.
	    f291: To transfer to another extension, press star 8.
	    f973: If you are finished, please hang up, or press star, star 9.
	ENDIF

a921	# announcement changed for Intuity MACH3 FAX Feature
	# VERSION is 2 for 3.1 DEFINITY AUDIX and 3 for INTUITY 3.0 fax feature
	# NUMBER 0 is no message, 1 is message was left
	IF (VERSION > 2)
	THEN
	    # Intuity 3.0 VERSION = 3
	    IF (NUMBER == 1)
	    THEN

Announcement	Fragments

	f56: Thank you for leaving your message.
	ENDIF,
	f46: To access your mailbox, press star 7.
	f291: To transfer to another extension, press star 8.
	f972: To reach the covering extension, press zero.
	f973: If you are finished, please hang up, or press star, star 9.
	ELSE
	      # Definity Audix 3.1 VERSION = 2
	      f56: Thank you for leaving your message.
	      f46: To access your mailbox, press star 7.
	      f291: To transfer to another extension, press star 8.
	      f972: To reach the covering extension, press zero.
	      f973: If you are finished, please hang up, or press star, star 9.
	ENDIF

a922	f974: Not broadcast.
a923	f975: Not login announcement.
a924	f375: You are getting your incoming messages. To listen to the message, press 0. To respond to the message, press 1. f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. f577: To hold the message in its current category, press star star 4 f377: To delete message, press star 3. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6.
a925	f848: You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to the message, press 1. f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. f577: To hold the message in its current category, press star star 4 f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star 3.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a926	f375: You are getting your incoming messages. To listen to the message, press 0. To respond to the message, press 1. f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. f577: To hold the message in its current category, press star star 4 f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star 3.
a927	f847: You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to or forward the message, press 1. f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. f577: To hold the message in its current category, press star star 4 f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star 3.

a928	# VERSION > 2 is for INTUITY 3.0 Fax Feature.
	# NUMBER(3) - 1 if voice only, 2 if fax only, 3 if voice and fax.
	# NUMBER(4) - 1 - fax enabled, 0 - fax disabled
	IF (VERSION > 2)
	THEN
	    f378: You are checking the status of your outgoing messages.
	    # INTUITY 3.0
	    IF (NUMBER(3) == 1)
	    THEN
	        #Voice only
	        f1462: To listen to the message, press 0.
	    ELSE
	        IF (NUMBER(3) == 2)
	        THEN
	            #FAX only
	            IF (NUMBER(4) == 1)
	            THEN
	                f1073: To print, press star 1.
	            ENDIF
	        ELSE
	            #Voice and FAX
	            f1462: To listen to the message,

Announcement	Fragments
	<pre> press 0.
IF (NUMBER(4) == 1)
THEN
f1073: To print, press star 1.
ENDIF
ENDIF
ENDIF,
f1038: To re-record message before delivery,
press one.
f388: To skip, press the pound key.
f142: To listen to the header, press 3.
f143: To step back again, press 2.
f578: To skip to the next category, press star
pound.
f339: To replay the last few seconds, press 5. To
advance a few seconds, press 6.
f292: Louder, press 4. Softer, press 7. Faster,
press 9. Slower, press 8.
f377: To delete message, press star 3.
ELSE
# DEFINITY AUDIX 3.0, 3.1
f378: You are checking the status of your
outgoing messages.
f381: To listen to the message, press 0. To re-
record message before delivery, press 1.
f388: To skip, press the pound key.
f142: To listen to the header, press 3.
f143: To step back again, press 2.
f578: To skip to the next category, press star
pound.
f339: To replay the last few seconds, press 5. To
advance a few seconds, press 6.
f292: Louder, press 4. Softer, press 7. Faster,
press 9. Slower, press 8.
f377: To delete message, press star 3.
ENDIF</pre>

Announcement	Fragments
| a929 | ```
# VERSION > 2 is for INTUITY 3.0 Fax Feature.
# NUMBER(3) == 1 if voice only, 2 if fax only, 3 if
voice and fax.
# NUMBER(4) - 1 - fax enabled, 0 - fax disabled
IF (VERSION > 2)
THEN
        f378:  You are checking the status of your
        outgoing messages.
        # INTUITY 3.0
        IF (NUMBER(3) == 1)
        THEN
                #Voice only
                f1462:  To listen to the message, press 0.
        ELSE
                IF (NUMBER(3) == 2)
                THEN
                        #FAX only
                        IF (NUMBER(4) == 1)
                        THEN
                                f1073:  To print, press star 1.
                        ENDIF
                ELSE
                        #Voice and FAX
                        f1462:  To listen to the message,
                        press 0.
                        IF (NUMBER(4) == 1)
                        THEN
                                f1073:  To print, press star 1.
                        ENDIF
                ENDIF
        ENDIF,
        f1039:  To change or send again, press one.
        f388:  To skip, press the pound key.
        f142:  To listen to the header, press 3.
        f143:  To step back again, press 2.
        f578:  To skip to the next category, press star
        pound.
        IF (NUMBER(3) != 2)
        THEN
                f339:  To replay the last few seconds, press
                5. To advance a few seconds, press 6.
        ENDIF,
        f292:  Louder, press 4. Softer, press 7. Faster,
        press 9. Slower, press 8.
        f377:  To delete message, press star 3.
ELSE
        # DEFINITY AUDIX 3.0, 3.1
        f378:  You are checking the status of your
        outgoing messages.
        f474:  To listen, press 0. To change or send
        again, press 1.
        f388:  To skip, press the pound key.
``` |

Announcement	Fragments
	f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star 3. ENDIF
a930	f378: You are checking the status of your outgoing messages. f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f379: To delete status information, press star 3.
a931	f674: Due to sending restrictions, you cannot send messages to f861: AMIS BUTTONS
a932	f493: You are requesting a transfer. f562: Enter the NUMBER, f563: digit extension f119: you wish to call f224: and pound sign. f115: To transfer using names instead, press star 2. f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a933	f493: You are requesting a transfer. f562: Enter the NUMBER, f563: digit extension f119: you wish to call f224: and pound sign. f115: To transfer using names instead, press star 2. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

Announcement	Fragments
a934	f288: You are in the names directory. To find a subscriber's extension, enter the last name followed by the pound sign. To enter the letter Q, press 7; for Z press 9. To look up by extension instead press star 2. f277: To exit directory, press pound. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.
a935	f322: You are in the numbers directory. To find a subscriber's name enter the extension followed by the pound sign. To look up by name instead, press star 2. f277: To exit directory, press pound. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.
a936	f493: You are requesting a transfer. f987: Enter last name of the person f119: you wish to call f224: and pound sign. f290: If you wish to specify a non-AUDIX subscriber, first change to extension addressing by pressing star 2. f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a937	f493: You are requesting a transfer. f987: Enter last name of the person f119: you wish to call f224: and pound sign. f290: If you wish to specify a non-AUDIX subscriber, first change to extension addressing by pressing star 2. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a938	f291: To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a939	f357: You are choosing between subscribers whose names match your entry. To indicate no subscribers match, delete entry by pressing star 3. To change to extension addressing and delete your entry, press star 2. f291: To transfer to another extension, press star 8. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.
a940	f482: Press pound to select NAME,

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	f483: or enter more characters f224: and pound sign. f291: To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a941	f482: Press pound to select NAMEEXT, f483: or enter more characters f224: and pound sign. f291: To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a942	f291: To transfer to another extension, press star 8. f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

Announcement	Fragments

a943	# VERSION > 2 is INTUITY FAX feature. FAX enabled == 1, FAX not enabled == 0
	IF (VERSION > 2)
	THEN
	    f518: You are creating a voice message which will be delivered to the person specified in your message as soon as possible. Please be aware that in order to forward this message to the recipient, someone will listen to the name and number portion.
	    IF (NUMBER > 0)
	    THEN
	        f1004: To bypass voice recording and create a fax only message, press pound.
	    ENDIF,
	    f13: To record, press 1. After recording, press 1 again.
	    f304: To playback message, press 2-3. To delete your message, press star 3. To approve your message, press pound.
	    f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
	    f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
	ELSE
	    f518: You are creating a voice message which will be delivered to the person specified in your message as soon as possible. Please be aware that in order to forward this message to the recipient, someone will listen to the name and number portion.
	    f13: To record, press 1. After recording, press 1 again.
	    f304: To playback message, press 2-3. To delete your message, press star 3. To approve your message, press pound.
	    f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
	    f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
	ENDIF

a944	f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star

Announcement	Fragments
	9. f516: To leave a message that will be delivered as soon as possible, f380: Please wait.
a945	f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9. f274: Please make entry soon, or be disconnected.
a946	f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9. f515: To be transferred to an operator, f380: Please wait.
a947	f117: To reach the covering extension, press star zero. f291: To transfer to another extension, press star 8. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.
a948	f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.
a949	f291: To transfer to another extension, press star 8. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.
a951	f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign. f117: To reach the covering extension, press star zero. f291: To transfer to another extension, press star 8. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9. f515: To be transferred to an operator, f380: Please wait.

Announcement	Fragments
a952	f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign. f117: To reach the covering extension, press star zero. f291: To transfer to another extension, press star 8. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9. f516: To leave a message that will be delivered as soon as possible, f380: Please wait.
a953	f517: You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign. f117: To reach the covering extension, press star zero. f291: To transfer to another extension, press star 8. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9. f274: Please make entry soon, or be disconnected.
a954	f56: Thank you for leaving your message. f95: Please disconnect.
a955	f56: Thank you for leaving your message. f291: To transfer to another extension, press star 8. f973: If you are finished, please hang up, or press star, star 9.
a956	f56: Thank you for leaving your message. f291: To transfer to another extension, press star 8. f972: To reach the covering extension, press zero. f973: If you are finished, please hang up, or press star, star 9.
a957	f291: To transfer to another extension, press star 8.
a958	f117: To reach the covering extension, press star zero. f291: To transfer to another extension, press star 8.
a959	f95: Please disconnect.
a960	f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

a961	# VERSION > 2 is INTUITY FAX feature. FAX enabled == 1, FAX not enabled == 0
	IF (VERSION > 2)
	THEN
	      f518: You are creating a voice message which will
	      be delivered to the person specified in your
	      message as soon as possible. Please be aware that
	      in order to forward this message to the recipient,
	      someone will listen to the name and number
	      portion.

Announcement	Fragments

	IF (NUMBER > 0)
	THEN
	    f1004: To bypass voice recording and create a fax only message, press pound.
	ENDIF,
	f13: To record, press 1. After recording, press 1 again.
	f304: To playback message, press 2-3. To delete your message, press star 3. To approve your message, press pound.
	f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
	f117: To reach the covering extension, press star zero.
	f291: To transfer to another extension, press star 8.
	f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.
	
	ELSE
	    f518: You are creating a voice message which will be delivered to the person specified in your message as soon as possible. Please be aware that in order to forward this message to the recipient, someone will listen to the name and number portion.
	    f13: To record, press 1. After recording, press 1 again.
	    f304: To playback message, press 2-3. To delete your message, press star 3. To approve your message, press pound.
	    f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
	    f117: To reach the covering extension, press star zero.
	    f291: To transfer to another extension, press star 8.
	    f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.
	ENDIF

a962	f853: Messages skipped, retained as new.
a963	f477: Press 1 to select
a964	f905: <.5 second pause> f478: 2 to select
a965	f905: <.5 second pause> f479: 3 to select
a968	f96: For help, press star 4.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| a969 | ```
IF ( NUMBER / 1000 > 12 )
THEN
      f99:  Invalid announcement.
ELSE
      IF ( NUMBER < 1000 )
      THEN
            f99:  Invalid announcement.
      ELSE
            a973( NUMBER )
      ENDIF
ENDIF,
a971( NUMBER )
``` |
| a970 | ```
f(NUMBER / 100),
f(NUMBER % 100)
``` |
| a971 | ```
f((NUMBER/10)%100)
``` |
| a972 | ```
IF (NUMBER<10)
THEN
      f400:  ten
      f924:  seconds
ELSE
        IF (NUMBER%10>=5)
        THEN
              a820((NUMBER+10)-(NUMBER%10)),
           f924:  seconds
        ELSE
              a820((NUMBER)-(NUMBER%10)),
           f924:  seconds
        ENDIF
ENDIF
``` |
| a973 | ```
IF ( NUMBER % 10 == 2 )
THEN
      f((NUMBER / 1000) % 12)
ELSE
      IF ( NUMBER % 10 == 7 )
      THEN
            IF ( NUMBER / 1000 != 12 )
            THEN
                  f12:  To re-record, press 1. After
                  recording, press 1 again. To delete,
                  press star 3. To playback, press 2-3.
                  To approve as is, press pound.
+ (NUMBER / 1000)
            ELSE
                  f(NUMBER / 1000)
            ENDIF
      ELSE
            f99:  Invalid announcement.
``` |

Announcement	Fragments
	`        ENDIF` `ENDIF`

a974	`f259:  scheduled for`
	`TIME,DATE,`
	`f981:  Message not delivered because it was longer than`
	`the 8 minute AMIS message limit.`

a978	`# New announcement introduced in INTUITY 3.0 Fax feature`
	`# NUMBER == the size of the fax message in number of`
	`pages`
	`f1104:  Print request to...`
	`NAMEEXT`

a979	`# New announcement introduced in INTUITY 3.0 Fax feature` `f1032:  Subscriber cannot receive fax.`
a980	`f774:  If you have addressed this message and wish to` `deliver it  immediately, press star star pound.`
a981	`f1020:  No message to send.`
a982	`f1019:  Cannot replace or modify an existing fax.`
a983	`f1015:  Fax will not be included.`
a984	`f1014:  Fax will be included.`
a985	`f971:  To send, press #.`
a986	`f1018:  Load your document into the FAX machine,  To` `send, press pound.`
a987	`f1017:  A login announcement must be voice only.`
a988	`f1008:  To include a fax, press 5.`
a989	`f1009:  To no longer include a fax, press 5.`

a990	`IF (NUMBER==0)`
	`THEN`
	`      f499:  When finished recording, press # to`
	`      approve, or 1 to edit your message.`
	`ELSE`
	`      f988:  To send only a fax, press pound.`
	`      f514:  otherwise`
	`      f499:  When finished recording, press # to`
	`      approve, or 1 to edit your message.`
	`ENDIF`

a991	`f1012:  Press START on your fax machine now.`

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a992	# New announcement for FAX feature, introduced in INTUITY MACH 3.0 f108: You are recording a message. f1004: To bypass voice recording and create a fax only message, press pound. f13: To record, press 1. After recording, press 1 again. f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
a993	f1031: A fax must be addressed before it can be created.

a994	# New announcement introduced in 3.0 of Intuity. Fax Feature
	# NUMBER == default print destination existS
	IF (NUMBER > 0)
	THEN
	    f1087: To print to destination...
	    BUTTONS,
	    f1088: press pound
	ENDIF,
	f1089: To specify destination, enter digits followed by the pound key.
	f1472: <.1 second pause, this fragment may be replaced with a customized recording which can be used to explain/state fax prefixes for printing.>
	f1090: To print on the fax machine from which you are calling, press star 6.

a995	# New announcement introduced in 3.0 of Intuity. Fax Feature
	# NUMBER == default print destination exisTS
	f1091: You are specifying where your documents will be printed
	IF (NUMBER > 0)
	THEN
	    f1087: To print to destination...
	    BUTTONS,
	    f1088: press pound
	ELSE
	    f1092: A default print destination has not been
	    assigned.
	    f1093: To assign a default print destination
	    press star 7, then 5-3.
	ENDIF,
	f1094: To specify a default destination, enter digits then press the pound key.
	f1472: <.1 second pause, this fragment may be replaced with a customized recording which can be used to explain/state fax prefixes for printing.>
	f1095: This destination will be used for the remainder of this call. When you hang up, your default

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	destination will be restored. f1090: To print on the fax machine from which you are calling, press star 6. f1096: If you choose this option, the document will begin to print. You will not be able to access your mailbox while the document is printing. You will be able to call into your mailbox again after printing is complete.
a996	# New announcement introduced in 3.0 of Intuity. Fax Feature f1097: Print scheduled.
a997	# New announcement introduced in 3.0 of Intuity. Fax Feature f1092: A default print destination has not been assigned. f1094: To specify a default destination, enter digits then press the pound key. f1472: <.1 second pause, this fragment may be replaced with a customized recording which can be used to explain/state fax prefixes for printing.> f1090: To print on the fax machine from which you are calling, press star 6.
a998	# New announcement introduced in 3.0 of Intuity. Fax Feature BUTTONS, f1098: To approve, press pound. f1099: Or re-enter print destination number and pound sign.
a999	# New announcement introduced in 3.0 of Intuity. Fax Feature f1100: Invalid. BUTTONS, f1101: Re-enter print destination number and pound sign. f1472: <.1 second pause, this fragment may be replaced with a customized recording which can be used to explain/state fax prefixes for printing.>
a1000	# New announcement introduced in 3.0 of Intuity. Fax Feature f1102: Too many print requests, try again later.
a1001	# New announcement introduced in 3.0 of Intuity. Fax Feature f1103: Fax extension for NAME
a1002	# New announcement introduced in INTUITY 3.0 Fax feature f1035: Message delivered, cannot print a delivered message.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a1003	# New announcement introduced in INTUITY 3.0 Fax feature f1033: Cannot print a delivered message.
a1004	# New announcement introduced in INTUITY 3.0 Fax feature f1034: Cannot get your messages now, due to an active print request.

a1005	# New announcement introduced in INTUITY 3.0 Fax feature
	# NUMBER: 0 - no new faxes, 1 - new faxes
	# NUMBER(2): 0 - only public faxes, 1 - only private faxes, 2 - both private
	# and public
	IF (NUMBER == 0)
	THEN
	    f1041: There are no new faxes.
	ELSE
	    IF (NUMBER(2) == 1)
	    THEN
	        f1042: Private fax messages will not be printed, no other faxes to print.
	    ELSE
	        IF (NUMBER(2) == 2)
	        THEN
	            f1043: Private fax messages will not be printed, print scheduled for all other faxes.
	        ELSE
	            f1097: Print scheduled.
	        ENDIF
	    ENDIF
	ENDIF

a1006	# New announcement introduced in INTUITY 3.0 Fax feature f1053: Fax not enabled for your mailbox, for help press star 4.
a1007	# New announcement introduced in INTUITY 3.0 Fax feature f1056: System not administered for fax.

a1008	# New announcement introduced in INTUITY 3.0 Fax feature
	# NUMBER is 0 for no default destination, 1 for default destination
	# NUMBER(2) 0 for autoprt inactive, 1 for autoprt active
	# NUMBER(3) 0 for autodelete inactive, 1 for autodelete active
	IF (NUMBER==0)
	THEN
	    f1092: A default print destination has not been assigned.
	ELSE
	    f1061: Your default print destination is...

Announcement	Fragments

	BUTTONS,
	　　　IF (NUMBER(2) == 1)
	　　　THEN
	　　　　　　IF (NUMBER(3) == 1)
	　　　　　　THEN
	　　　　　　　　　f1136:　Autoprinting is turned on.
	　　　　　　　　　f1139:　Autodeletion is turned on.
	　　　　　　ELSE
	　　　　　　　　　f1136:　Autoprinting is turned on.
	　　　　　　　　　f1138:　Autodeletion is turned off.
	　　　　　　ENDIF
	　　　ELSE
	　　　　　　f1137:　Autoprinting is turned off.
	　　　ENDIF
	ENDIF,
	f105:　To restart at the activity menu, press star 7.
	f1075:　To change the default print destination, press 1.
	IF (NUMBER(2) == 0)
	THEN
	　　　f1076:　To have your faxes printed automatically, press 9 for Yes.
	ELSE
	　　　f1077:　To cancel automatic printing of your faxes, press 6 for no.
	　　　f1078:　To change autodeletion option, press 9.
	ENDIF

a1009	# New announcement for INTUITY 3.0 FAX feature.
	# NUMBER is number of fax pages.
	IF (NUMBER==0)
	THEN
	　　　f585:　Zero
	　　　f1029:　pages.
	ELSE
	　　　a820(NUMBER),
	　　　IF (NUMBER==1)
	　　　THEN
	　　　　　　f1028:　page.
	　　　ELSE
	　　　　　　f1029:　pages.
	　　　ENDIF
	ENDIF

Announcement	Fragments

a1010	```# New announcement for INTUITY 3.0 FAX feature.```
	```# NUMBER is number of seconds of voice in message.```
	```# NUMBER(2) == media type, 1-voice only, 2-fax only, 3-```
	```voice fax.```
	```# NUMBER(3) is length of pages of fax in message.```
	```IF (NUMBER(2)==1)```
	```THEN```
	``` a873(NUMBER)```
	```ENDIF,```
	```IF (NUMBER(2)==2)```
	```THEN```
	``` f905: <.5 second pause>```
	```a1009(NUMBER(3))```
	```ENDIF,```
	```IF (NUMBER(2)==3)```
	```THEN```
	``` a873(NUMBER),```
	``` f905: <.5 second pause>```
	```a1009(NUMBER(3))```
	```ENDIF```

a1011	```# New announcement introduced in INTUITY 3.0 Fax feature```
	```# NUMBER = fax page length```
	```# NUMBER(2) = 1 - fax enabled, 0 - fax disabled```
	```f1049: Fax of```
	```IF (NUMBER == 0)```
	```THEN```
	``` f585: Zero```
	``` f1029: pages.```
	```ELSE```
	``` NUMBER,```
	``` IF (NUMBER == 1)```
	``` THEN```
	``` f1028: page.```
	``` ELSE```
	``` f1029: pages.```
	``` ENDIF```
	```ENDIF,```
	```IF (NUMBER(2) == 1)```
	```THEN```
	``` f1073: To print, press star 1.```
	```ENDIF,```
	```f24: To delete, press star 3.```
	```f388: To skip, press the pound key.```

a1012	```# New announcement introduced in INTUITY 3.0 Fax feature```
	```# Number of pages for fax.```
	```# NUMBER(2), 0 fax is disabled, 1 fax is enabled```
	```f1050: Message does not contain voice.```
	```f1049: Fax of```
	```NUMBER,```

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0–1

Announcement	Fragments

	IF (NUMBER == 1)
	THEN
	     f1028: page.
	ELSE
	     f1029: pages.
	ENDIF,
	IF (NUMBER(3) == 0)
	THEN
	     f252: To respond to this message, press 1.
	ELSE
	     f234: To respond or forward, press 1.
	ENDIF,
	IF (NUMBER(2) == 1)
	THEN
	     f1073: To print, press star 1.
	ENDIF,
	f24: To delete, press star 3.
	f388: To skip, press the pound key.

a1013	# New announcement introduced in INTUITY 3.0 Fax feature f1048: Nothing to print.
a1014	# New announcement introduced in INTUITY 3.0 Fax feature f1051: Voice and fax message.
a1015	# New announcement introduced in INTUITY 3.0 Fax feature f1079: Enter your default print destination followed by the pound key. f1472: <.1 second pause, this fragment may be replaced with a customized recording which can be used to explain/state fax prefixes for printing.> f556: To exit, press star pound now.
a1016	# New announcement introduced in INTUITY 3.0 Fax feature f1061: Your default print destination is... BUTTONS
a1017	# New announcement introduced in INTUITY 3.0 Fax feature f1080: Invalid destination.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a1018	# New announcement introduced in INTUITY 3.0 Fax feature
	# NUMBER is 0 for autoprt inactive, 1 for autoprt active
	f1075: To change the default print destination, press 1.
	IF (NUMBER == 0)
	THEN
	     f1076: To have your faxes printed automatically, press 9 for Yes.
	ELSE
	     f1077: To cancel automatic printing of your faxes, press 6 for no.
	     f1078: To change autodeletion option, press 9.
	ENDIF,
	f105: To restart at the activity menu, press star 7.

a1019	# New announcement introduced in INTUITY 3.0 Fax feature
	# NUMBER: 0 for autoprt inactive, 1 for autoprt active
	IF (NUMBER == 1)
	THEN
	     f1136: Autoprinting is turned on.
	ELSE
	     f1137: Autoprinting is turned off.
	     f1138: Autodeletion is turned off.
	ENDIF

a1020	# New announcement introduced in INTUITY 3.0 Fax feature f1081: After a fax only message is printed automatically, should it also be deleted from your mailbox? Press 9 for yes or 6 for No. f105: To restart at the activity menu, press star 7.
a1021	# New announcement introduced in INTUITY 3.0 Fax feature f1136: Autoprinting is turned on. f1139: Autodeletion is turned on.
a1022	# New announcement introduced in INTUITY 3.0 Fax feature f1136: Autoprinting is turned on. f1138: Autodeletion is turned off.
a1023	# New announcement introduced in INTUITY 3.0 Fax feature f1083: You must enter a default print destination before autoprinting can be used.
a1024	# New announcement introduced in INTUITY 3.0 Fax feature # NUMBER: 0 no default number assigned, 1- default print number assigned. # NUMBER(2): 0 autoprint off, 1-autoprint on. f1084: You are changing your fax print options. f1086: The default print destination is where documents are normally printed. f1085: To change or add default print destination, press 1.

Announcement	Fragments

	IF (NUMBER == 0)
	THEN
	    f1135: A default print destination must be
	    assigned before autoprinting can be used.
	ENDIF,
	IF (NUMBER(2) == 0)
	THEN
	    f1076: To have your faxes printed automatically,
	    press 9 for Yes.
	ELSE
	    f1077: To cancel automatic printing of your
	    faxes, press 6 for no.
	ENDIF,
	f1124: When autoprinting is turned on, all non-private
	faxes that are received will automatically attempt to
	print at the default destination.
	IF (NUMBER(2) == 1)
	THEN
	    f1078: To change autodeletion option, press 9.
	ENDIF

a1025	# New announcement introduced in INTUITY 3.0 Fax feature f1111: You are in the autodeletion menu. f1114: If autodeletion is turned on, fax only messages will be deleted after they are automatically printed. f1082: To turn on autodeletion, press 9. To turn off, press 6.
a1026	# New announcement introduced in INTUITY 3.0 Fax feature f1118: You are specifying the default print destination for fax items. f1143: The default print destination should be set to the destination where you normally send your documents for printing. f1124: When autoprinting is turned on, all non-private faxes that are received will automatically attempt to print at the default destination. f1130: This is also used as the default print destination when scanning fax messages. f1133: It must be a valid call delivery number. f1134: To enter destination, enter digits followed by the pound key. f1472: <.1 second pause, this fragment may be replaced with a customized recording which can be used to explain/state fax prefixes for printing.>

Announcement	Fragments

a1027	# New announcement introduced in INTUITY 3.0
	# NUMBER(4) is 1 if fax enabled, 0 is fax disebled.
	# NUMBER(5) - 1 is voice only, 2 fax only, 3 voice and
	fax
	f252: To respond to this message, press 1.
	f24: To delete, press star 3.
	IF (NUMBER(5) != 1)
	THEN
	      IF (NUMBER(4) == 1)
	      THEN
	            #Fax Enabled
	            f1073: To print, press star 1.
	      ENDIF
	ENDIF,
	f388: To skip, press the pound key.

a1028	# New announcement introduced in INTUITY 3.0 f1019: Cannot replace or modify an existing fax.

a1029	# New announcement for INTUITY 3.0 - XEROX ABR Feature.
	#
	# NUMBER == 0 Address Before Record is off.
	# NUMBER == 1 Address Before Record is on.
	IF (NUMBER == 1)
	THEN
	      f1152: Address Before Record turned on.
	      f1153: To turn off, press 1.
	ELSE
	      f1154: Address Before Record turned off.
	      f1155: To turn on, press 1.
	ENDIF

a1030	# New announcement for INTUITY 3.0 - XEROX ABR Feature.
	#
	# NUMBER == 0 Address Before Record is off.
	# NUMBER == 1 Address Before Record is on.
	IF (NUMBER == 1)
	THEN
	      f1152: Address Before Record turned on.
	ELSE
	      f1154: Address Before Record turned off.
	ENDIF

a1031	# New announcement for INTUITY 3.0 - XEROX ABR Feature. # If the subscriber tries to create a fax before addressing it. # The announcement states A fax must be addressed before it can be created. f1031: A fax must be addressed before it can be created.
a1032	# New announcement for INTUITY 3.0 - XEROX ABR Feature. #

Announcement	Fragments

	# NUMBER == 0 Address Before Record is off.
	# NUMBER == 1 Address Before Record is on.
	f1157: You are administering Addressing options.
	IF (NUMBER == 1)
	THEN
	    f1152: Address Before Record turned on.
	    f1153: To turn off, press 1.
	ELSE
	    f1154: Address Before Record turned off.
	    f1155: To turn on, press 1.
	ENDIF,
	f105: To restart at the activity menu, press star 7.

a1033	# New announcement for INTUITY 3.0 - XEROX CAD Feature.
	#
	# NUMBER == 0 Call Answer Disabled is off.
	# NUMBER == 1 Call Answer Disabled is on.
	IF (NUMBER == 0)
	THEN
	    f1164: Call answer messages will be accepted.
	    f1158: To prevent callers from leaving messages,
	    press 1.
	ELSE
	    f1159: Call answer messages will not be accepted.
	    f1160: To allow callers to leave messages, press
	    1.
	ENDIF

a1034	# New announcement for INTUITY 3.0 - XEROX CAD Feature.
	#
	# NUMBER == 0 Call Answer Disabled is off.
	# NUMBER == 1 Call Answer Disabled is on.
	IF (NUMBER == 0)
	THEN
	    f1164: Call answer messages will be accepted.
	ELSE
	    f1159: Call answer messages will not be accepted.
	ENDIF

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a1035	# New announcement for INTUITY 3.0 - XEROX CAD Feature.
	#
	# NUMBER == 0 Call Answer Disabled is off.
	# NUMBER == 1 Call Answer Disabled is on.
	f1161: You are administering Call Answer options.
	IF (NUMBER == 1)
	THEN
	     f1164: Call answer messages will be accepted.
	     f1158: To prevent callers from leaving messages,
	     press 1.
	ELSE
	     f1159: Call answer messages will not be accepted.
	     f1160: To allow callers to leave messages, press
	     1.
	ENDIF,
	f105: To restart at the activity menu, press star 7.

a1036	# New announcement introduced in 3.0 of Intuity. Fax Feature f1167: Only 25 faxes printed.

a1037	# New announcement introduced in INTUITY 3.0
	f1049: Fax of
	IF (NUMBER==0)
	THEN
	     f585: Zero
	     f1029: pages.
	ELSE
	     a820(NUMBER),
	     IF (NUMBER == 1)
	     THEN
	          #Page
	          f1028: page.
	     ELSE
	          #Pages
	          f1029: pages.
	     ENDIF
	ENDIF

a1038	# New announcement introduced in INTUITY 3.0 # Call Answer Enable/Disable feature - XEROX f1162: Sorry, the mailbox you have reached is not accepting messages at this time. f95: Please disconnect.
a1039	# New announcement introduced in INTUITY 3.0 # Address Before Record feature - XEROX f1031: A fax must be addressed before it can be created.
a1105	f43: Your call is being answered by AUDIX.
a1109	f1263: Please enter more digits, or pound sign.
a1112	IF (NUMBER > 0) THEN f1305: PLease enter an outcalling option. To hear

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	a list of options, press 0. ENDIF, IF (NUMBER(2) > 0) THEN f0: <NULL fragment, 0.0 second pause> ENDIF, f105: To restart at the activity menu, press star 7.
a1121	f1404: To administer this greeting, press 1.
a1122	f1408: To administer this greeting, press 2. f105: To restart at the activity menu, press star 7.

a1123	IF (NUMBER > 0)
	THEN
	      f1405: To listen to your secondary greeting,
	      press 0.
	      f1409: To record your secondary greeting, press
	      1.
	      f1402: To administer your primary greeting, press
	      pound.
	ELSE
	      f1406: To listen to your primary greeting, press
	      0.
	      f1407: To record your primary greeting, press 1.
	      f1410: To administer your secondary greeting,
	      press pound.
	ENDIF,
	f105: To restart at the activity menu, press star 7.

a1124	IF (NUMBER > 0)
	THEN
	      f1405: To listen to your secondary greeting,
	      press 0.
	ELSE
	      f1406: To listen to your primary greeting, press
	      0.
	ENDIF,
	f757: To re-record, press 1.
	IF (NUMBER > 0)
	THEN
	      f1412: To delete your secondary greeting, and use
	      the system greeting, press star 3. .
	      f1402: To administer your primary greeting, press
	      pound.
	ELSE
	      f1411: To delete your primary greeting, and use
	      the system greeting press star 3.
	      f1410: To administer your secondary greeting,
	      press pound.
	ENDIF,
	f105: To restart at the activity menu, press star 7.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a1125	IF (NUMBER > 0)
	THEN
	    f1414: Your new secondary greeting is now active.
	ELSE
	    f1413: Your new primary greeting is now active.
	ENDIF

a1126	f1415: Recording deleted.
	IF (NUMBER > 0)
	THEN
	    f1417: Your secondary greeting has not changed.
	ELSE
	    f1416: Your primary greeting has not changed.
	ENDIF

a1127	f1400: For English press star 1.
a1128	f1401: Your primary greeting is in
a1129	f0: <NULL fragment, 0.0 second pause>
a1130	f1403: Your secondary greeting is in
a1131	f0: <NULL fragment, 0.0 second pause>
a1132	f1420: Callers will hear the greeting and receive instructions in the primary language unless they press star-1, in which case they will hear the greeting and receive instructions in the secondary language.

a1133	IF (NUMBER > 0)
	THEN
	    f1419: You are administering your secondary
	    greeting.
	ELSE
	    f1418: You are administering your primary
	    greeting.
	ENDIF

a1134	f1430: The following message was restored.
a1135	f1431: No message to restore.
a1136	f1432: To undelete last deleted message, press star star 8.
a1137	f913: If finished, press pound.
a1138	f1433: The return address for this message is not a valid extension.
a1139	f1434: To return to getting messages, press pound. f8: To record a new message, press 4.
a1140	f1434: To return to getting messages, press pound. f291: To transfer to another extension, press star 8. f96: For help, press star 4.
a1141	f1434: To return to getting messages, press pound. f18: To forward with comment, press 2. f8: To record a new message, press 4.
a1142	f0: <NULL fragment, 0.0 second pause>
a1143	f1436: English

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a1144	f1437: <CHIMES - LIKE DOOR BELL>
	f1438: Call for
	NAME,
	f0: <NULL fragment, 0.0 second pause>
	IF (NUMBER>0)
	THEN
	    f908: <5.0 second pause>
	ENDIF

a1145	f1439: <BEEP - LIKE CONF BRIDGE TONE>
a1146	f1440: <BEEP - LIKE RECORD AT TONE TONE>
a1147	f1441: <BEEP BEEP BEEP TONE - FOR OUT OF SPACE TONE>
a1148	f1442: <BEEP - LIKE EOM TONE BUT SOFTER>
a1149	#This announcement is a duplicate of 518 which is used for voice #mail, however this is used for call answer only. #A unique annc id was intentionally used to allow customers #to not advertise this feature easily. f613: To make priority, press 2.

Announcement	Fragments

a1150	#This announcement is played when scanning any call answer
	#message that was left when the calling party is known.
	#
	#NUMBER: 0 if message not private, 1 if message is private
	#NUMBER(2): 0 if message not priority, 1 if message is priority
	#NUMBER(3): length in seconds of message
	#NUMBER(4): 0 if message extension unavailable, 1 if available
	#NUMBER(5): 1 -voice only, 2 fax only, 3 voice and fax
	#NUMBER(6): number of fax pages
	#NAME: name of the calling party, if available
	#TIME: time message was left
	#DATE: date message was left
	#BUTTONS: extension of the calling party, if available
	# VERSION > 2 introduced in INTUITY 3.0 FAX VERSION == 3.
	IF (VERSION > 2)
	THEN
	    a1170(NUMBER,NUMBER(2),NUMBER(3),NUMBER(4),NUMBER(5),NUMBER(6),NAME,TIME,DATE,BUTTONS)
	ELSE
	    # VERSION == 2, THIS IS 3.1 DEFINITY AUDIX and 2.0 INTUITY AUDIX
	    IF (NUMBER>0)
	    THEN
	        #Message is private
	        IF (NUMBER(2)>0)
	        THEN
	            #Message is priority
	            f1445: Private, priority call from
	        ELSE
	            #Message is not priority
	            f1446: Private call from
	        ENDIF
	    ELSE
	        #Message is not private
	        IF (NUMBER(2)>0)
	        THEN
	            #Message is priority
	            f1447: Priority call from
	        ELSE
	            #Message is not priority
	            f47: Call from
	        ENDIF
	    ENDIF,
	NAME,
	    f262: received
	#Time and date message was left
	TIME,

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

	DATE,
	     f905: <.5 second pause>
	a873(NUMBER(3)),
	IF (NUMBER(4)>0)
	THEN
	     #Calling party is known, play extension out also
	        f86: extension
	     BUTTONS
	ENDIF
	ENDIF

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a1151	#This announcement is played when scanning any call answer
	#message that was left when the calling party is unknown.
	#
	#NUMBER: 0 if message not private, 1 if message is private
	#NUMBER(2): 0 if message not priority, 1 if message is priority
	#NUMBER(3): length in seconds of message
	#NUMBER(4): 0 if message extension unavailable, 1 if available
	#NUMBER(5): 1 -voice only, 2 -fax only, 3 -voice and fax
	#NUMBER(6): length of fax pages
	#TIME: time message was left
	#DATE: date message was left
	#BUTTONS: extension of the calling party, if available
	# VERSION > 2 introduced in INTUITY 3.0 FAX VERSION == 3.
	IF (VERSION > 2)
	THEN
	      a1171(NUMBER,NUMBER(2),NUMBER(3),NUMBER(4),NUMBER(5),NUMBER(6),TIME,DATE,BUTTONS)
	ELSE
	      # VERSION == 2, THIS IS 3.1 DEFINITY AUDIX and 2.0 INTUITY AUDIX
	      IF (NUMBER>0)
	      THEN
	            #Message is private
	            IF (NUMBER(2)>0)
	            THEN
	                  #Message is priority
	                  f1448: Private, priority call received
	            ELSE
	                  #Message is not priority
	                  f1449: Private call received
	            ENDIF
	      ELSE
	            #Message is not private
	            IF (NUMBER(2)>0)
	            THEN
	                  #Message is priority
	                  f1450: Priority call received
	            ELSE
	                  #Message is not priority
	                  f1451: Call received
	            ENDIF
	      ENDIF,
	#Time and date message was left
	TIME,
	DATE,

Announcement	Fragments
|  | ```
        f905:  <.5 second pause>
a873(NUMBER(3)),
IF (NUMBER(4)>0)
THEN
        #Calling party is known, play extension out also
            f86:  extension
        BUTTONS
ENDIF
ENDIF
``` |
| a1152 | ```
f329:  You have not yet entered enough characters to
identify a specific subscriber.  To enter the letter Q,
press 7; for Z press 9.
f484:  Enter more characters followed by the pound sign;
if you just completed entering the last name, enter the
first name.
f224:  and pound sign.
f24:  To delete,  press star 3.
``` |
| a1153 | ```
#NUMBER: number of days till password expires
#        assumed greater than 0
IF (NUMBER==1)
THEN
        f1455:  Your password will expire within one day.
ELSE
        f1453:  Your password will expire in
        NUMBER,
        f1454:  days.
ENDIF
``` |
| a1154 | f1456: Your password has expired. |
| a1155 | f1457: Old and new passwords cannot be the same. |
| a1156 | ```
#NUMBER: minimum age before change
f1458:  Password cannot be changed within
NUMBER,
IF (NUMBER==1)
THEN
        f1460:  day of last change.
ELSE
        f1459:  days of last change.
ENDIF
``` |

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a1157	#This announcement is used for the help when manually scanning
	#message headers.
	#
	#NUMBER: 0 is forwarding not allowed, 1 is forwarding allowed
	#NUMBER(2): 0 is message not scanned, 1 is message scanned
	#NUMBER(3): 1 - voice only, 2 - fax only, 3 - voice and fax.
	#NUMBER(4): 1 - fax enabled, 0 - fax disabled.
	#This variable was introduced in INTUITY 3.0 fax fax feature.
	#VERSION > 2 is for INTUITY 3.0 fax feature.
	#VERSION is 2 for 3.1 DEFINITY AUDIX and 3 for INTUITY 3.0 fax feature.
	IF (VERSION > 2)
	THEN
	    # INTUITY 3.0 - VERSION = 3
	    a1172(NUMBER,NUMBER(2),NUMBER(3),NUMBER(4))
	ELSE
	    # DEFINITY AUDIX 3.1 - VERSION = 2
	    f1461: You are getting your incoming messages.
	    f1462: To listen to the message, press 0.
	    IF (NUMBER==0)
	    THEN
	        #forwarding not allowed
	        f252: To respond to this message, press 1.
	    ELSE
	        #forwarding allowed
	        f1466: To respond to or forward the
	        message, press one.
	    ENDIF,
	    IF (NUMBER(2)==0)
	    THEN
	        #message not scanned
	        f388: To skip, press the pound key.
	        f142: To listen to the header, press 3.
	        f143: To step back again, press 2.
	        f578: To skip to the next category, press
	        star pound.
	    ELSE
	        #message scanned
	        f376: To skip to the next header, press the
	        pound sign. To listen to the header, rewind
	        by pressing 2, then play by pressing 3. To
	        skip to the next category, press star pound.
	    ENDIF,
	    f577: To hold the message in its current category, press star star 4
	    f339: To replay the last few seconds, press 5. To advance a few seconds, press 6.

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star 3. ENDIF

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a1158	#This announcement is used for the help when manually scanning
	#message headers.
	#when the stacked response feature is active.
	#NUMBER: 0 is forwarding not allowed, 1 is forwarding allowed
	#NUMBER(2): 0 is message not scanned, 1 is message scanned
	#NUMBER(3): 0 if sender doesn't exist, 1 is sender exists
	#NUMBER(4): 1 is voice only, 2 fax only, 3 voice and fax
	#NUMBER(5): 0 fax disabled, 1 fax enabled
	#VERSION > 2 means Intuity MACH3 Fax feautre
	#
	f1461: You are getting your incoming messages.
	IF (VERSION > 2)
	THEN
	      # Mach 3
	      IF (NUMBER(4) == 1)
	      THEN
	            # Voice only
	            f1462: To listen to the message, press 0.
	      ELSE
	            IF (NUMBER(4) == 2)
	            THEN
	                  IF (NUMBER(5) == 1)
	                THEN
	                      f1073: To print, press star 1.
	                ENDIF
	            ELSE
	                f1462: To listen to the message, press 0.
	                IF(NUMBER(5) == 1)
	                THEN
	                      f1073: To print, press star 1.
	                ENDIF
	            ENDIF
	      ENDIF
	ELSE
	      # Definity 3.0 or 3.1
	      f1462: To listen to the message, press 0.
	ENDIF,
	IF (NUMBER(3)==1)
	THEN
	      #sender of message exists, may reply
	      f1463: To reply to sender by voice mail, press 1, 7.
	ENDIF,
	IF (NUMBER==1)
	THEN
	      #forwarding allowed
	      f1464: To forward with comment, press 1, 2.

Announcement	Fragments

	ENDIF,
	f1465: To record a new message, press 1, 4.
	IF (NUMBER(2)==0)
	THEN
	    #message not scanned
	    f388: To skip, press the pound key.
	    f142: To listen to the header, press 3.
	    f143: To step back again, press 2.
	    f578: To skip to the next category, press star pound.
	ELSE
	    #message scanned
	    f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing 2, then play by pressing 3. To skip to the next category, press star pound.
	ENDIF,
	f577: To hold the message in its current category, press star star 4
	f339: To replay the last few seconds, press 5. To advance a few seconds, press 6.
	f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
	f377: To delete message, press star 3.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a1159	#This announcement is used for the help when manually scanning
	#message headers.
	#
	#NUMBER: 0 is forwarding not allowed, 1 is forwarding allowed
	#NUMBER(2): 0 is message not scanned, 1 is message scanned
	#NUMBER(3): 1 - voice only, 2 - fax only, 3 - voice and fax.
	#NUMBER(4): 1 - fax enabled, 0 - fax disabled.
	#This variable was introduced in INTUITY 3.0 fax fax feature.
	#VERSION > 2 is for INTUITY 3.0 fax feature.
	#VERSION is 2 for 3.1 DEFINITY AUDIX and 3 for INTUITY 3.0 fax feature.
	IF (VERSION > 2)
	THEN
	    # INTUITY 3.0 - VERSION = 3
	    a1173(NUMBER,NUMBER(2),NUMBER(3),NUMBER(4))
	ELSE
	    # 3.1 DEFINITY AUDIX - VERSION = 2
	    IF (NUMBER==0)
	    THEN
	        #forwarding not allowed
	        f848: You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to the message, press 1.
	    ELSE
	        #forwarding allowed
	        f847: You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to or forward the message, press 1.
	    ENDIF,
	    IF (NUMBER(2)==0)
	    THEN
	        #message not scanned
	        f388: To skip, press the pound key.
	        f142: To listen to the header, press 3.
	        f143: To step back again, press 2.
	        f578: To skip to the next category, press star pound.
	    ELSE
	        #message scanned
	        f849: To skip to the next message, press the pound sign. To listen to the header, rewind by pressing 2, then play by pressing 3. To skip to the next category, press star pound.
	    ENDIF,

Announcement	Fragments
	f577: To hold the message in its current category, press star star 4 f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star 3. ENDIF

a1160	#This announcement is used for responding to a message.
	#
	#NUMBER: 0 if sender doesn't exist, 1 if sender exists
	#NUMBER(2): 0 if stacked response off, 1 if stacked respone on
	#NUMBER(3): 0 is forwarding not allowed, 1 is forwarding allowed
	#NUMBER(4): 0 is can't call sender, 1 is can call sender
	#
	IF (NUMBER(2)==1)
	THEN
	    f1434: To return to getting messages, press
	    pound.
	ENDIF,
	IF (NUMBER==1)
	THEN
	    #may reply to sender
	    IF (NUMBER(2)==0)
	    THEN
	        #stacked response off
	        f486: To reply to sender by voice mail, press 1.
	    ELSE
	        #stacked response on
	        f1469: To reply to sender by voice mail, press 7.
	    ENDIF
	ENDIF,
	IF (NUMBER(3)==1)
	THEN
	    f18: To forward with comment, press 2.
	ENDIF,
	f8: To record a new message, press 4.
	IF (NUMBER(4)==1)
	THEN
	    f163: To call sender, press zero.
	ENDIF

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a1161	#This announcement is used for help in responding to a message.
	#
	#NUMBER: 0 if sender doesn't exist, 1 if sender exists
	#NUMBER(2): 0 if stacked response off, 1 if stacked respone on
	#NUMBER(3): 0 is forwarding not allowed, 1 is forwarding allowed
	#NUMBER(4): 0 is can't call sender, 1 is can call sender
	#
	f323: You are responding to a piece of incoming mail.
	IF (NUMBER==1)
	THEN
	      #may reply to sender
	      IF (NUMBER(2)==0)
	      THEN
	            #stacked response off
	            f486: To reply to sender by voice mail, press 1.
	      ELSE
	            #stacked response on
	            f1469: To reply to sender by voice mail, press 7.
	      ENDIF
	ENDIF,
	IF (NUMBER(3)==1)
	THEN
	      f41: To forward message with comment at beginning, press 2.
	      f126: To forward message with comment at end, press 3.
	ENDIF,
	f8: To record a new message, press 4.
	IF (NUMBER(4)==1)
	THEN
	      f163: To call sender, press zero.
	ENDIF,
	f1434: To return to getting messages, press pound.

a1162	f1467: The return address for this message is not a mailbox on this system.
a1163	f1468: The return address for this message is not a valid extension.
a1164	f1470: No voice portion of message to playback.
a1165	f618: To remove priority status, press 2.
a1166	f646: A priority message will be delivered before other messages and will be flagged for special attention in the recipient's mailbox.
a1167	# This announcement was introduced in INTUITY 3.0 FAX. # NUMBER(5) == number of fax messages. IF (NUMBER(3)>0) THEN

Announcement	Fragments

	`#password is about to expire`
	`    a1153(NUMBER(4))`
	`ENDIF,`
	`NUMBER + NUMBER(2),`
	`f63:  new`
	`IF (NUMBER + NUMBER(2) == 1 )`
	`THEN`
	`    f160:   message`
	`ELSE`
	`    f168:   messages.`
	`ENDIF,`
	`NUMBER,`
	`f1010:  with priority.`
	`IF (NUMBER(5)>0)`
	`THEN`
	`    NUMBER(5),`
	`    f1011:  with fax.`
	`ENDIF`

a1168	`# This announcement was introduced in INTUITY 3.0 FAX.`
	`# NUMBER(3) == number of fax messages.`
	`NUMBER + NUMBER(2),`
	`f63:  new`
	`IF (NUMBER + NUMBER(2) == 1 )`
	`THEN`
	`    f160:   message`
	`ELSE`
	`    f168:   messages.`
	`ENDIF,`
	`NUMBER,`
	`f1010:  with priority.`
	`IF (NUMBER(3) > 0)`
	`THEN`
	`    NUMBER(3),`
	`    f1011:  with fax.`
	`ENDIF`

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| a1169 | ```
# This announcement was introduced in INTUITY 3.0 FAX.
# NUMBER(4) == number of fax messages.
IF (NUMBER(2)>0)
THEN
        #password is about to expire
        a1153(NUMBER(3))
ENDIF,
NUMBER,
f63:  new
f601:  Priority
IF (NUMBER==1)
THEN
        f160:  message
ELSE
        f168:  messages.
ENDIF,
IF (NUMBER(4) > 0)
THEN
        NUMBER(4),
        f1011:  with fax.
ENDIF
``` |
| a1170 | ```
#This announcement is played when scanning any call
answer
#message that was left when the calling party is known.
#
# This announcement was introduced in INTUITY 3.0 FAX
feature.
#NUMBER: 0 if message not private, 1 if message is
private
#NUMBER(2): 0 if message not priority, 1 if message is
priority
#NUMBER(3): length in seconds of message
#NUMBER(4): 0 if message extension unavailable, 1 if
available
# NUMBER(5) == 1 voice only, 2- fax only, 3- voice and
fax
# NUMBER(6) == number of fax pages
#NAME: name of the calling party, if available
#TIME: time message was left
#DATE: date message was left
#BUTTONS: extension of the calling party, if available
IF (NUMBER>0)
THEN
        #Message is private
        IF (NUMBER(2)>0)
        THEN
                #Message is priority
                IF (NUMBER(5) == 2)
                THEN
                        #Message is private, priority fax
                        f993:  Private, priority fax call from
``` |

Announcement	Fragments
| | ```
                        ELSE
                                IF (NUMBER(5)==3)
                                THEN
                                        #Message is private, priority
voice and fax
                                        f994:  Private, priority voice
                                        and fax call from
                                ELSE

                                        #Message is private, priority
voice
                                        f1445:  Private, priority call
                                        from
                                ENDIF
                        ENDIF
                ELSE
                        #Message is not priority
                        IF (NUMBER(5) == 2)
                        THEN
                                #Message is private fax
                                f995:  Private fax call from
                        ELSE
                                IF (NUMBER(5) == 3)
                                THEN
                                        #Message is private voice and
fax
                                        f998:  Private voice and fax
                                        call from
                                ELSE
                                        f1446:  Private call from
                                ENDIF
                        ENDIF
                ENDIF
        ELSE
                #Message is not private
                IF (NUMBER(2)>0)
                THEN
                        #Message is priority
                        IF (NUMBER(5) == 2)
                        THEN
                                #Message is priority fax
                                f1000:  Priority fax call from
                        ELSE
                                IF (NUMBER(5) == 3)
                                THEN
                                        #Message is priority voice and
fax
                                        f1003:  Priority voice and fax
                                        call from
                                ELSE
                                        #Message is priority
``` |

Announcement	Fragments
|  | ```
                              f1447:  Priority call from
                      ENDIF
                ENDIF
        ELSE
                #Message is not priority
                IF (NUMBER(5) == 2)
                THEN
                        #Message is fax
                        f1054:  Fax call from
                ELSE
                        IF (NUMBER(5) == 3)
                        THEN
                                #Message is voice and fax
                                f1055:  Voice and fax call from
                        ELSE
                                f47:  Call from
                        ENDIF
                ENDIF
        ENDIF
ENDIF,
NAME,
f262:  received
#Time and date message was left
TIME,
DATE,
f905:  <.5 second pause>
#Play out length of message
a1010(NUMBER(3),NUMBER(5), NUMBER(6)),
IF (NUMBER(4)>0)
THEN
        #Calling party is known, play extension out also
        f86:  extension
        BUTTONS
ENDIF
``` |
| a1171 | ```
#This announcement is played when scanning any call
answer
#message that was left when the calling party is
unknown.
#
# This announcement was introduced in INTUITY 3.0 FAX
feature.
# NUMBER: 0 if message not private, 1 if message is
private
# NUMBER(2): 0 if message not priority, 1 if message is
priority
# NUMBER(3): length in seconds of message
# NUMBER(4): 0 if message extension unavailable, 1 if
available
# NUMBER(5) == 1 voice only, 2- fax only, 3- voice and
fax
# NUMBER(6) == length of fax pages
``` |

Announcement	Fragments
| | ```
#TIME: time message was left
#DATE: date message was left
#BUTTONS: extension of the calling party, if available
#
IF (NUMBER>0)
THEN
        #Message is private
        IF (NUMBER(2)>0)
        THEN
                IF (NUMBER(5) == 2)
                THEN
                        #Message is private priority fax
                        f1021:  Private, priority fax call
                        received
                ELSE
                        IF (NUMBER(5) == 3)
                        THEN
                                #Message is private priority
voice and fax
                                f1022:  Private, priority voice
                                and fax call received
                        ELSE
                                f1448:  Private, priority call
                                received
                        ENDIF
                ENDIF
        ELSE
                #Message is not priority
                IF (NUMBER(5) == 2)
                THEN
                        #Private fax
                        f1023:  Private fax call received
                ELSE
                        IF (NUMBER(5) == 3)
                        THEN
                                #Private voice and fax
                                f1024:  Private voice and fax
                                call received
                        ELSE
                                #Private voice
                                f1449:  Private call received
                        ENDIF
                ENDIF
        ENDIF
ELSE
        #Message is not private
        IF (NUMBER(2)>0)
        THEN
                #Message is priority
                IF (NUMBER(5) == 2)
                THEN
``` |

Announcement	Fragments
| | ```
                        #Priority fax
                        f1025:  Priority fax call received
                ELSE
                        IF (NUMBER(5) == 3)
                        THEN
                                #Priority voice and fax
                                f1026:  Priority voice and fax
                                call received
                        ELSE
                                #Priority voice
                                f1450:  Priority call received
                        ENDIF
                ENDIF
        ELSE
                #Message is not priority
                IF (NUMBER(5) == 2)
                THEN
                        #Fax received
                        f1027:  Fax call received
                ELSE
                        IF (NUMBER(5) == 3)
                        THEN
                                #Voice and Fax received
                                f1030:  Voice and fax call
                                received
                        ELSE
                                #Voice received
                                f1451:  Call received
                        ENDIF
                ENDIF
        ENDIF
ENDIF,
#Time and date message was left
TIME,
DATE,
f905:  <.5 second pause>
#Play out length of message
a1010(NUMBER(3),NUMBER(5), NUMBER(6)),
IF (NUMBER(4)>0)
THEN
        #Calling party is known, play extension out also
        f86:  extension
        BUTTONS
ENDIF
``` |
| a1172 | ```
#This announcement is used for the help when manually
scanning
#message headers.
#
#NUMBER: 0 is forwarding not allowed, 1 is forwarding
allowed
#NUMBER(2): 0 is message not scanned, 1 is message
``` |

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	scanned
	#NUMBER(3): 1 - voice only, 2 - fax only, 3 - voice and fax.
	#NUMBER(4): 0 fax is disabled, 1 fax is enabled
	#This variable was introduced in INTUITY 3.0 fax fax feature.
	#VERSION > 2 is for INTUITY 3.0 fax feature.
	#VERSION is 2 for 3.1 DEFINITY AUDIX and 3 for INTUITY 3.0 fax feature.
	f1461: You are getting your incoming messages.
	IF (NUMBER(3) == 1)
	THEN
	f1462: To listen to the message, press 0.
	ELSE
	IF (NUMBER(3) == 2)
	THEN
	IF (NUMBER(4) == 1)
	THEN
	f1073: To print, press star 1.
	ENDIF
	ELSE
	f1462: To listen to the message, press 0.
	IF (NUMBER(4) == 1)
	THEN
	f1073: To print, press star 1.
	ENDIF
	ENDIF
	ENDIF,
	IF (NUMBER==0)
	THEN
	#forwarding not allowed
	f252: To respond to this message, press 1.
	ELSE
	#forwarding allowed
	f1466: To respond to or forward the message, press one.
	ENDIF,
	IF (NUMBER(2)==0)
	THEN
	#message not scanned
	f388: To skip, press the pound key.
	f142: To listen to the header, press 3.
	f143: To step back again, press 2.
	f578: To skip to the next category, press star pound.
	ELSE
	#message scanned
	f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing 2, then play by pressing 3. To skip to the next category, press star pound.

Announcement	Fragments
	ENDIF, f577: To hold the message in its current category, press star star 4 f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star 3.

a1173	#This announcement is used for the help when manually scanning
	#message headers.
	#
	#NUMBER: 0 is forwarding not allowed, 1 is forwarding allowed
	#NUMBER(2): 0 is message not scanned, 1 is message scanned
	#NUMBER(3): 1 - voice only, 2 - fax only, 3 - voice and fax.
	#NUMBER(4): 0 fax disabled, 1 - fax enabled
	#This variable was introduced in INTUITY 3.0 fax fax feature.
	#VERSION > 2 is for INTUITY 3.0 fax feature.
	#VERSION is 2 for 3.1 DEFINITY AUDIX and 3 for INTUITY 3.0 fax feature.
	IF (NUMBER==0)
	THEN
	    #forwarding not allowed
	    IF (NUMBER(3) == 1)
	    THEN
	        #voice only
	        f848: You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to the message, press 1.
	    ELSE
	        f1036: You are automatically scanning your incoming messages.
	        IF (NUMBER(3) == 2)
	        THEN
	            #FAX only
	            IF (NUMBER(4) == 1)
	            THEN
	                f1073: To print, press star 1.
	            ENDIF
	        ELSE
	            #voice and FAX
	            f1462: To listen to the message, press 0.
	            IF (NUMBER(4) == 1)
	            THEN
	                f1073: To print, press star 1.
	            ENDIF

Announcement	Fragments

	``
	            ENDIF,
	            f1037: To respond to the message, press
	            one.
	     ENDIF
	ELSE
	     #forwarding allowed
	     IF (NUMBER(3) == 1)
	     THEN
	            #Voice only
	            f847: You are automatically scanning your
	            incoming messages. To listen to the
	            message, press zero. To respond to or
	            forward the message, press 1.
	     ELSE
	            f1036: You are automatically scanning your
	            incoming messages.
	            IF (NUMBER(3) == 2)
	            THEN
	                   #FAX only
	                   IF (NUMBER(4) == 1)
	                   THEN
	                          f1073: To print, press star 1.
	                   ENDIF
	            ELSE
	                   #voice and FAX
	                   f1462: To listen to the message,
	                   press 0.
	                   IF (NUMBER(4) == 1)
	                   THEN
	                          f1073: To print, press star 1.
	                   ENDIF
	            ENDIF,
	            f1466: To respond to or forward the
	            message, press one.
	     ENDIF
	
	ENDIF,
	IF (NUMBER(2)==0)
	THEN
	     #message not scanned
	     f388: To skip, press the pound key.
	     f142: To listen to the header, press 3.
	     f143: To step back again, press 2.
	     f578: To skip to the next category, press star
	     pound.
	ELSE
	     #message scanned
	     f849: To skip to the next message, press the
	     pound sign. To listen to the header, rewind by
	     pressing 2, then play by pressing 3. To skip to
	     the next category, press star pound.
	``

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0–1

Announcement	Fragments
	ENDIF, f577: To hold the message in its current category, press star star 4 f339: To replay the last few seconds, press 5. To advance a few seconds, press 6. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star 3.

a1174	# New announcement for INTUITY 3.0 – XEROX CAD and ABR Feature and FAX.
	# This announcement determines what plays out for the help announcements
	# which call this announcement- a76,a77,a113,a114,a115,a119,a120,a121,a125,
	# a127,a129,a159.
	# Which combination plays out depends on how the system is configured and
	# which features are active at the time.
	#
	# NUMBER == 0 if fax not allowed, and 1 if fax allowed.
	# NUMBER(2) used for Address Before Record feature (ABR) –(XEROX feature)
	# introduced in INTUITY 3.0
	# NUMBER(2) == 0 for addressing options not allowed, 1 for addressing options
	# allowed.
	# NUMBER(3) used for Call Answer Disable feature (CAD) (XEROX feature)
	# introduced in INTUITY 3.0
	# NUMBER(3) == is 0 for call answer options not allowed, 1 for call answer
	# options allowed.
	IF (NUMBER == 0)
	THEN
	     IF (NUMBER(2) == 0)
	     THEN
	         IF (NUMBER(3) == 0)
	         THEN
	            # To administer mailing lists,
	            # personal directory, password, or
	            # account name, press 5.
	            f997: To administer mailing list, personal directory, password, or account name, press 5.
	         ELSE
	            # To administer mailing list, personal directory,
	            # password,
	            # account name, or call answer options, press 5.
	            f1149: To administer mailing list, personal directory, password, account

Announcement	Fragments
| | ```
                              name, or call answer options, press 5.
                    ENDIF
            ELSE
                    IF (NUMBER(3) ==0)
                    THEN
                            # To administer mailing list, personal
directory,
                            # password, account name, or
addressing options,
                            # press 5.
                            f1147:  To administer mailing list,
                            personal directory, password, account
                            name, or addressing options, press 5.
                    ELSE
                            # To administer mailing list, personal
directory,
                            # password,
                            # account name, addressing options,
                            # or call answer options, press 5.
                            f1151:  To administer mailing list,
                            personal directory, password, account
                            name, addressing options, or call
                            answer options, press 5.
                    ENDIF
            ENDIF
    ELSE
            IF (NUMBER(2) == 0)
            THEN
                    IF (NUMBER(3) == 0)
                    THEN
                            # To administer mailing list, personal
directory,
                            # password,
                            # fax options, or account name, press
5.
                            f999:  To administer mailing list,
                            personal directory, password, fax
                            options, or account name, press 5.
                            ELSE
                                    # To administer mailing list,
personal
                                    # directory,
                                    # password, fax options, account
name, or
                                    # call answer options, press 5.
                            f1150:  To administer mailing list,
                            personal directory, password, fax
                            options, account name, or call answer
                            options, press 5.
                    ENDIF
            ELSE
``` |

Announcement	Fragments
| | ```
                        IF (NUMBER(3) == 0)
                        THEN
                                # To administer mailing list, personal
directory,
                                # password, fax options, account name,
or
                                # addressing options, press 5.
                                f1148:  To administer mailing list,
                                personal directory, password, fax
                                options, account name, or addressing
                                options, press 5.
                        ELSE
                                # To administer mailing list, personal
directory,
                                # password, fax options, account name,
addressing
                                # options, or call answer options,
press 5.
                                f1146:  To administer mailing list,
                                personal directory, password, fax
                                options, account name, addressing
                                options, or call answer options, press
                                5.
                        ENDIF
                ENDIF
        ENDIF
``` |
| a1175 | ```
# New announcement introduced in INTUITY 3.0.
# VERSION > 2 introduced with INTUITY 3.0.  NUMBER(2) is
used for the
# FAX feature.  NUMBER(2) == 1 if fax is enabled.
# NUMBER(3) is used for Call Answer Disable/Enable (CAD)
Xerox Feature
# NUMBER(3) == 1 if call answer disabled turned on, 0 if
off.
IF (NUMBER == 0)
THEN
        IF (NUMBER(3) == 1)
        THEN
                #CAD enabled
                f43:  Your call is being answered by AUDIX.
                NAME,
                f1163:  is not available.
                f1162:  Sorry, the mailbox you have reached
                is not accepting messages at this time.
                f95:  Please disconnect.
        ELSE
                #CAD disabled.
                f43:  Your call is being answered by AUDIX.
                NAME,
                f45:  is busy. To leave a message, wait for
                the tone.
``` |

Announcement	Fragments
| | ```
        ENDIF
ENDIF,
IF (NUMBER == 1)
THEN
        IF (NUMBER(3) == 1)
        THEN
                f1162:  Sorry, the mailbox you have reached
                is not accepting messages at this time.
                f95:  Please disconnect.
        ELSE
                f71:  To leave a message, wait for the tone.
        ENDIF
ENDIF,
IF (NUMBER == 2)
THEN
        IF (NUMBER(3) == 1)
        THEN
                NAME,
                f1163:  is not available.
                f1162:  Sorry, the mailbox you have reached
                is not accepting messages at this time.
                f95:  Please disconnect.
        ELSE
                NAME,
                f45:  is busy. To leave a message, wait for
                the tone.
        ENDIF
ENDIF,
IF(NUMBER(2) == 1 && NUMBER(3) != 1)
THEN
        # FAX enabled.
        f1141:  When finished recording, press pound for
        more options.
ENDIF,
f112:  Otherwise, for assistance, press zero now.
``` |

Announcement	Fragments
| a1176 | ```
# New announcement introduced in INTUITY 3.0.
# VERSION > 2 introduced with INTUITY 3.0.  NUMBER(2) is
used for the
# FAX feature.  NUMBER(2) == 1 if fax is enabled.
# NUMBER(3) is used for Call Answer Disable/Enable (CAD)
Xerox Feature
# NUMBER(3) == 1 if call answer disabled turned on, 0 if
off.
IF (NUMBER == 0)
THEN
        IF (NUMBER(3) == 1)
        THEN
                #CAD enabled
                f43:  Your call is being answered by AUDIX.
                NAME,
                f1163:  is not available.
                f1162:  Sorry, the mailbox you have reached
                is not accepting messages at this time.
                f95:  Please disconnect.
        ELSE
                #CAD disabled.
                f43:  Your call is being answered by AUDIX.
                NAME,
                f44:  is not available. To leave a message,
                wait for the tone.
        ENDIF
ENDIF,
IF (NUMBER == 1)
THEN
        IF (NUMBER(3) == 1)
        THEN
                f1162:  Sorry, the mailbox you have reached
                is not accepting messages at this time.
                f95:  Please disconnect.
        ELSE
                f71:  To leave a message, wait for the tone.
        ENDIF
ENDIF,
IF (NUMBER == 2)
THEN
        IF (NUMBER(3) == 1)
        THEN
                NAME,
                f1163:  is not available.
                f1162:  Sorry, the mailbox you have reached
                is not accepting messages at this time.
                f95:  Please disconnect.
        ELSE
                NAME,
                f44:  is not available. To leave a message,
                wait for the tone.
        ENDIF
``` |

Announcement	Fragments

	ENDIF,
	IF(NUMBER(2) == 1 && NUMBER(3) != 1)
	THEN
	    # FAX enabled.
	    f1141: When finished recording, press pound for
	    more options.
	ENDIF,
	f112: Otherwise, for assistance, press zero now.

Announcement	Fragments

a1177	```
	# New announcement introduced in INTUITY 3.0.
	# VERSION > 2 introduced with INTUITY 3.0. NUMBER(2) is
	used for the
	# FAX feature. NUMBER(2) == 1 if fax is enabled.
	# NUMBER(3) is used for Call Answer Disable/Enable (CAD)
	Xerox Feature
	# NUMBER(3) == 1 if call answer disabled turned on, 0 if
	off.
	IF (NUMBER == 0)
	THEN
	        IF (NUMBER(3) == 1)
	        THEN
	                #CAD enabled
	                f43: Your call is being answered by AUDIX.
	                NAME,
	                f1163: is not available.
	                f1162: Sorry, the mailbox you have reached
	                is not accepting messages at this time.
	                f95: Please disconnect.
	        ELSE
	                #CAD disabled.
	                f43: Your call is being answered by AUDIX.
	                NAME,
	                f45: is busy. To leave a message, wait for
	                the tone.
	        ENDIF
	ENDIF,
	IF (NUMBER == 1)
	THEN
	        IF (NUMBER(3) == 1)
	        THEN
	                f1162: Sorry, the mailbox you have reached
	                is not accepting messages at this time.
	                f95: Please disconnect.
	        ELSE
	                f71: To leave a message, wait for the tone.
	        ENDIF
	ENDIF,
	IF (NUMBER == 2)
	THEN
	        IF (NUMBER(3) == 1)
	        THEN
	                NAME,
	                f1163: is not available.
	                f1162: Sorry, the mailbox you have reached
	                is not accepting messages at this time.
	                f95: Please disconnect.
	        ELSE
	                NAME,
	                f45: is busy. To leave a message, wait for
	                the tone.
	        ENDIF
	``

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

	ENDIF,
	IF(NUMBER(2) == 1 && NUMBER(3) != 1)
	THEN
	    # FAX enabled.
	    f1141: When finished recording, press pound for
	    more options.
	ENDIF

Announcement	Fragments

a1178	`# New announcement introduced in INTUITY 3.0.`
	`# VERSION > 2 introduced with INTUITY 3.0.  NUMBER(2) is`
	`used for the`
	`# FAX feature.  NUMBER(2) == 1 if fax is enabled.`
	`# NUMBER(3) is used for Call Answer Disable/Enable (CAD)`
	`Xerox Feature`
	`# NUMBER(3) == 1 if call answer disabled turned on, 0 if`
	`off.`
	`IF (NUMBER == 0)`
	`THEN`
	`        IF (NUMBER(3) == 1)`
	`        THEN`
	`                #CAD enabled`
	`                f43:  Your call is being answered by AUDIX.`
	`                NAME,`
	`                f1163:  is not available.`
	`                f1162:  Sorry, the mailbox you have reached`
	`                is not accepting messages at this time.`
	`                f95:  Please disconnect.`
	`        ELSE`
	`                #CAD disabled.`
	`                f43:  Your call is being answered by AUDIX.`
	`                NAME,`
	`                f44:  is not available. To leave a message,`
	`                wait for the tone.`
	`        ENDIF`
	`ENDIF,`
	`IF (NUMBER == 1)`
	`THEN`
	`        IF (NUMBER(3) == 1)`
	`        THEN`
	`                f1162:  Sorry, the mailbox you have reached`
	`                is not accepting messages at this time.`
	`                f95:  Please disconnect.`
	`        ELSE`
	`                f71:  To leave a message, wait for the tone.`
	`        ENDIF`
	`ENDIF,`
	`IF (NUMBER == 2)`
	`THEN`
	`        IF (NUMBER(3) == 1)`
	`        THEN`
	`                NAME,`
	`                f1163:  is not available.`
	`                f1162:  Sorry, the mailbox you have reached`
	`                is not accepting messages at this time.`
	`                f95:  Please disconnect.`
	`        ELSE`
	`                NAME,`
	`                f44:  is not available. To leave a message,`
	`                wait for the tone.`
	`        ENDIF`

Announcement	Fragments

	ENDIF,
	IF(NUMBER(2) == 1 && NUMBER(3) != 1)
	THEN
	     # FAX enabled.
	     f1141: When finished recording, press pound for
	     more options.
	ENDIF

a1179	f1166: Temporarily cannot access your messages. Processing your request to print all new faxes. Please try again"
a1180	f1168: Fax print all request to NAMEEXT
a1181	f378: You are checking the status of your outgoing messages. f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing 2, then play by pressing 3. To skip to the next category, press star pound. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star 3.
a1182	f378: You are checking the status of your outgoing messages. f388: To skip, press the pound key. f142: To listen to the header, press 3. f143: To step back again, press 2. f578: To skip to the next category, press star pound. f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8. f377: To delete message, press star 3.
a1183	f59: delivered TIME,DATE
a1184	f1169: Printing has completed. TIME,DATE
a1185	f1162: Sorry, the mailbox you have reached is not accepting messages at this time. f46: To access your mailbox, press star 7. f973: If you are finished, please hang up, or press star, star 9.
a1186	f165: Returned to getting messages.
a1187	f29: Returned to checking status of outgoing messages.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a1188	# New announcement introduced in INTUITY 3.0 Fax feature
	# Number of pages for fax.
	# NUMBER(2), 0 fax is disabled, 1 fax is enabled
	#
	f1050: Message does not contain voice.
	f1049: Fax of
	NUMBER,
	IF (NUMBER == 1)
	THEN
	     f1028: page.
	ELSE
	     f1029: pages.
	ENDIF

a1189	#New announcement 1189 for INTUITY MACH 3 DIALSTR
a1190	# annc 1190 Intuity Mach 3 # Pause of .1 second f903: <.1 second pause>
a1191	# annc 1191 Intuity Mach 3 # Pause of .2 second f904: <.2 second pause>
a1192	# annc 1192 Intuity Mach 3 # Pause of .5 second f905: <.5 second pause>
a1193	# annc 1193 Intuity Mach 3 # Pause of 1 second f906: <1.0 second pause>
a1194	# annc 1194 Intuity Mach 3 # Pause of 2 second f907: <2.0 second pause>
a1195	# annc 1195 Intuity Mach 3 # Pause of 5 second f908: <5.0 second pause>
a1900	# announcment for Ford Motor Company # custom development for Tandem Mailboxes # P_TND_CA1 (a1900) # Call Answer name and ext of caller known # # NUMBER(1) 1 = private, 2 = priority, # 3 = private, priority, 0 = neither # NUMBER(2) message length, number of seconds # NUMBER(3) 1 = play EXTENSION, 0 = don't # NUMBER(4) 1 = voice, 2 = fax, 3 = both # NUMBER(5) number of fax pages # NAME = primary recipient # NAME(2) = sender # TIME, DATE, BUTTONS (extension of caller) # IF (NUMBER == 0)

Announcement	Fragments
| | ```
THEN
        # not private, not priority
        a1903(NUMBER(4))
ELSE
        IF ( NUMBER == 1 )
        THEN
                # private
                a1904(NUMBER(4))
        ELSE
                IF ( NUMBER == 2 )
                THEN
                        # priority
                        a1905(NUMBER(4))
                ELSE
                        # private and priority
                        a1906(NUMBER(4))
                ENDIF
        ENDIF
ENDIF,
NAME,
f1924:  ...from...
NAME(2),
f262:  received
TIME,DATE,
a1010(NUMBER(2),NUMBER(4),NUMBER(5)),
IF ( NUMBER(3) == 1 )
THEN
        f86:  extension
BUTTONS
ENDIF
``` |

Announcement	Fragments

a1901	```
	# announcment for Ford Motor Company
	# custom development for Tandem Mailboxes
	# P_TND_CA2 (a1901)
	# Call Answer name and ext of caller NOT known
	#
	# NUMBER(1) 1 = private, 2 = priority,
	# 3 = private, priority, 0 = neither
	# NUMBER(2) message length, number of seconds
	# NUMBER(3) 1 = voice, 2 = fax, 3 = both
	# NUMBER(4) number of fax pages
	# NAME = primary recipient
	# TIME, DATE
	#
	IF (NUMBER == 0)
	THEN
	        # not private, not priority
	        a1903(NUMBER(3))
	ELSE
	        IF (NUMBER == 1)
	        THEN
	                # private
	                a1904(NUMBER(3))
	        ELSE
	                IF (NUMBER == 2)
	                THEN
	                        # priority
	                        a1905(NUMBER(3))
	                ELSE
	                        # private and priority
	                        a1906(NUMBER(3))
	                ENDIF
	        ENDIF
	ENDIF,
	NAME,
	f262: received
	TIME,DATE,
	a1010(NUMBER(2),NUMBER(3),NUMBER(4))
	``

a1902	``` # announcment for Ford Motor Company # custom development for Tandem Mailboxes # P_TND_VM (a1902) # Voice Mail Header # # NUMBER(1) 1 = private, 2 = priority, # 3 = private, priority, 0 = neither # NUMBER(2) message length, number of seconds # NUMBER(3) 1 = play EXTENSION, 0 = don't # NUMBER(4) 1 = voice, 2 = fax, 3 = both # NUMBER(5) number of fax pages # NAME = primary recipient # NAME(2) = sender ```

Announcement	Fragments
| | ```
# TIME, DATE, BUTTONS (extension of caller)
#
IF ( NUMBER == 0 )
THEN
        # not private, not priority
        a1907(NUMBER(4))
ELSE
        IF ( NUMBER == 1 )
        THEN
                # private
                a1908(NUMBER(4))
        ELSE
                IF ( NUMBER == 2 )
                THEN
                        # priority
                        a1909(NUMBER(4))
                ELSE
                        # private and priority
                        a1910(NUMBER(4))
                ENDIF
        ENDIF
ENDIF,
NAME,
f1924:  ...from...
NAME(2),
f59:  delivered
TIME,DATE,
a1010(NUMBER(2),NUMBER(4),NUMBER(5)),
IF ( NUMBER(3) == 1 )
THEN
        f86:  extension
BUTTONS
ENDIF
``` |

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a1903	```
	# announcment for Ford Motor Company
	# custom development for Tandem Mailboxes
	# (a1903) called by a1900 and a1901
	# message not private or priority
	#
	# NUMBER 1 = voice, 2 = fax, 3 = both
	#
	IF (NUMBER == 1)
	THEN
	        # voice
	        f1900: Call to...
	ELSE
	        IF (NUMBER == 2)
	        THEN
	                # fax
	                f1901: Fax call to...
	        ELSE
	                # voice and fax
	                f1902: Voice and fax call to...
	        ENDIF
	ENDIF
	``

a1904	```
	# announcment for Ford Motor Company
	# custom development for Tandem Mailboxes
	# (a1904) called by a1900 and a1901
	# Private message
	#
	# NUMBER 1 = voice, 2 = fax, 3 = both
	#
	IF (NUMBER == 1)
	THEN
	        # voice
	        f1903: Private call to...
	ELSE
	        IF (NUMBER == 2)
	        THEN
	                # fax
	                f1904: Private fax call to...
	        ELSE
	                # voice and fax
	                f1905: Private voice and fax call to...
	        ENDIF
	ENDIF
	``

a1905	```
	# announcment for Ford Motor Company
	# custom development for Tandem Mailboxes
	# (a1905) called by a1900 and a1901
	# Priority message
	#
	# NUMBER 1 = voice, 2 = fax, 3 = both
	#
	IF (NUMBER == 1)
	``

Announcement	Fragments
| | ```
THEN
        # voice
        f1906:  Priority call to...
ELSE

        IF ( NUMBER == 2 )
        THEN
                # fax
                f1907:  Priority fax call to...
        ELSE
                # voice and fax
                f1908:  Priority voice and fax call to...
        ENDIF
ENDIF
``` |
| a1906 | ```
# announcment for Ford Motor Company
# custom development for Tandem Mailboxes
# (a1906) called by a1900 and a1901
# Private/Priority message
#
# NUMBER 1 = voice, 2 = fax, 3 = both
#
IF ( NUMBER == 1 )
THEN
        # voice
        f1909:  Private, priority call to...
ELSE
        IF ( NUMBER == 2 )
        THEN
                # fax
                f1910:  Private, priority fax call to...
        ELSE
                # voice and fax
                f1911:  Private, priority voice and fax call
                to...
        ENDIF
ENDIF
``` |

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| a1907 | ```
# announcment for Ford Motor Company
# custom development for Tandem Mailboxes
# (a1907) called by a1902
# message not private or priority
#
# NUMBER 1 = voice, 2 = fax, 3 = both
#
IF ( NUMBER == 1 )
THEN
        # voice
        f1912:  Message to...
ELSE
        IF ( NUMBER == 2 )
        THEN
                # fax
                f1913:  Fax message to...
        ELSE
                # voice and fax
                f1914:  Voice and fax message to...
        ENDIF
ENDIF
``` |
| a1908 | ```
# announcment for Ford Motor Company
# custom development for Tandem Mailboxes
# (a1908) called by a1902
# Private message
#
# NUMBER 1 = voice, 2 = fax, 3 = both
#
IF ( NUMBER == 1 )
THEN
        # voice
        f1915:  Private message to...
ELSE
        IF ( NUMBER == 2 )
        THEN
                # fax
                f1916:  Private fax message to...
        ELSE
                # voice and fax
                f1917:  Private voice and fax message to...
        ENDIF
ENDIF
``` |
| a1909 | ```
# announcment for Ford Motor Company
# custom development for Tandem Mailboxes
# (a1909) called by a1902
# Priority message
#
# NUMBER 1 = voice, 2 = fax, 3 = both
#
IF ( NUMBER == 1 )
``` |

Announcement	Fragments
| | ```
THEN
        # voice
        f1918:  Priority message to...
ELSE

        IF ( NUMBER == 2 )
        THEN
                # fax
                f1919:  Priority fax message to...
        ELSE
                # voice and fax
                f1920:  Priority voice and fax message to...
        ENDIF
ENDIF
``` |
| a1910 | ```
# announcment for Ford Motor Company
# custom development for Tandem Mailboxes
# (a1910) called by a1902
# Private/Priority message
#
# NUMBER 1 = voice, 2 = fax, 3 = both
#
IF ( NUMBER == 1 )
THEN
        # voice
        f1921:  Private, priority message to...
ELSE

        IF ( NUMBER == 2 )
        THEN
                # fax
                f1922:  Private, priority fax message to...
        ELSE
                # voice and fax
                f1923:  Private, priority voice and fax
                message to...
        ENDIF
ENDIF
``` |

Announcement	Fragments
| a1911 | ```
# Mach 4 announcment for Ford Motor Company
# custom development for Tandem Mailboxes
# PM4_TND_CA1  (a1911)
# Call Answer name and ext of caller known
#
# NUMBER(1) 1 = private, 2 = priority,
#           3 = private, priority, 0 = neither
# NUMBER(2) message length, number of seconds
# NUMBER(3) 1 = play EXTENSION, 0 = don't
# NUMBER(4) 1=voice,2=fax,3=text,4=file attachment
# NUMBER(5) 1=voice,2=fax,3=text,4=file attachment
# NUMBER(6) 1=voice,2=fax,3=text,4=file attachment
# NUMBER(7) 1=voice,2=fax,3=text,4=file attachment
# NUMBER(8) number of fax pages
# NUMBER(9) number of bytes
# NAME = primary recipient
# NAME(2) = sender
# TIME, DATE, BUTTONS (extension of caller)
#
IF ( NUMBER == 1 )
THEN
        # private
        f2021:  Private...
ELSE
        IF ( NUMBER == 2 )
        THEN
                # priority
                f2023:  Priority...
        ELSE
                IF ( NUMBER == 3 )
                THEN
                        # private and priority
                        f2022:  Private, priority...
                ENDIF
        ENDIF
ENDIF,
a2101(NUMBER(4),NUMBER(5),NUMBER(6),NUMBER(7)),
f1900:  Call to...
NAME,
f1924:  ...from...
NAME(2),
f262:  received
TIME,DATE,
a2102(NUMBER(8),NUMBER(9),NUMBER(2)),
IF ( NUMBER(3) == 1 )
THEN
        f86:  extension
BUTTONS
ENDIF
``` |
| a1912 | # Mach 4 announcment for Ford Motor Company |

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0–1

Announcement	Fragments
| | ```
# custom development for Tandem Mailboxes
# PM4_TND_CA2  (a1912)
# Call Answer name and ext of caller NOT known
#
# NUMBER(1) 1 = private, 2 = priority,
#           3 = private, priority, 0 = neither
# NUMBER(2) message length, number of seconds
# NUMBER(3) 1=voice,2=fax,3=text,4=file attachment
# NUMBER(4) 1=voice,2=fax,3=text,4=file attachment
# NUMBER(5) 1=voice,2=fax,3=text,4=file attachment
# NUMBER(6) 1=voice,2=fax,3=text,4=file attachment
# NUMBER(7) number of fax pages
# NUMBER(8) number of bytes
# NAME = primary recipient
# TIME, DATE
#
IF ( NUMBER == 1 )
THEN
      # private
      f2021:  Private...
ELSE
      IF ( NUMBER == 2 )
      THEN
            # priority
            f2023:  Priority...
      ELSE
            IF ( NUMBER == 3 )
            THEN
                  # private and priority
                  f2022:  Private, priority...
            ENDIF
      ENDIF
ENDIF,
a2101(NUMBER(3),NUMBER(4),NUMBER(5),NUMBER(6)),
f1900:  Call to...
NAME,
f262:  received
TIME,DATE,
a2102(NUMBER(7),NUMBER(8),NUMBER(2))
``` |

Announcement	Fragments
| a1913 | ```
# Mach 4 announcment for Ford Motor Company
# custom development for Tandem Mailboxes
# PM4_TND_VM (a1913)
# Voice Mail Header
#
# NUMBER(1) 1 = private, 2 = priority,
#           3 = private, priority, 0 = neither
# NUMBER(2) message length, number of seconds
# NUMBER(3) 1 = play EXTENSION, 0 = don't
# NUMBER(4) 1=voice,2=fax,3=text,4=file attachment
# NUMBER(5) 1=voice,2=fax,3=text,4=file attachment
# NUMBER(6) 1=voice,2=fax,3=text,4=file attachment
# NUMBER(7) 1=voice,2=fax,3=text,4=file attachment
# NUMBER(8) number of fax pages
# NUMBER(9) number of bytes
# NAME = primary recipient
# NAME(2) = sender
# TIME, DATE, BUTTONS (extension of caller)
#
IF ( NUMBER == 1 )
THEN
        # private
        f2021:  Private...
ELSE
        IF ( NUMBER == 2 )
        THEN
                # priority
                f2023:  Priority...
        ELSE
                IF ( NUMBER == 3 )
                THEN
                        # private and priority
                        f2022:  Private, priority...
                ENDIF
        ENDIF
ENDIF,
a2101(NUMBER(4),NUMBER(5),NUMBER(6),NUMBER(7)),
f1912:  Message to...
NAME,
f1924:  ...from...
NAME(2),
f59: delivered
TIME,DATE,
a2102(NUMBER(8),NUMBER(9),NUMBER(2)),
IF ( NUMBER(3) == 1 )
THEN
        f86:  extension
BUTTONS
ENDIF
``` |
| a1914 | `# DISCLAIMER announcement added in 4.3` |

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	# contains blank fragment that can be # recorded by customer f1925: # this is a blank fragment which can be recorded by # the customer, for use as a disclaimer announcement
a2000	# announcement 2000 # new for Mach 4 #f2000, f926: <error sound> f2001: One or more components of this multimedia message could not be delivered. Please contact the sender.
a2001	# announcement 2001 # new for Mach 4 f259: scheduled for TIME,DATE, f2002: Message not delivered because it contained 1 or more media types that the recipient's machine is unable to process.
a2002	# announcement 2002 # new for Mach 4 f259: scheduled for TIME,DATE, f2003: Message not delivered because it is too long for the recipient's machine.
a2005	# announcement 2005 # new for Mach 4 f259: scheduled for TIME,DATE, f2006: Message not delivered because private messages cannot be sent to the recipient's machine.

Announcement	Fragments
| a2006 | ```
# announcement 2006
# This is a new for Mach 4 (replaces annc 1169)
# NUMBER = total number of messages
# NUMBER(2) Yes/No Play password annc
# NUMBER(3) number of days till password expires
# NUMBER(4) = number of fax messages.
# NUMBER(5) = number of text messages
# NUMBER(6) = number of other media messages
NAME,
IF (NUMBER(2)>0)
THEN
      #password is about to expire
      a1153(NUMBER(3))
ENDIF,
NUMBER,
f63:  new
f601:  Priority
IF (NUMBER==1)
THEN
      f160:  message
ELSE
      f168:  messages.
ENDIF,
IF (NUMBER(4) > 0)
THEN
      NUMBER(4),
      f1011:  with fax.
ENDIF,
IF ( NUMBER(5) > 0 )
THEN
      NUMBER(5),
      f2007:  with text.
ENDIF,
IF ( NUMBER(6) > 0 )
THEN
      NUMBER(6),
      f2008:  with other media
ENDIF
``` |
| a2007 | ```
#  Announcement 2007 new in MACH4
# NUMBER = number of priority messages
# NUMBER(2) = number of non-priority messages
# NUMBER(3) = 1/0 play password annc
# NUMBER(4) = number days till passwd expires
# NUMBER(5) = number of fax messages.
# NUMBER(6) = number of text messages
# NUMBER(7) = number of binary/other mesages
#
NAME,
IF (NUMBER(3)>0)
THEN
      #password is about to expire
``` |

Announcement	Fragments
	`` a1153(NUMBER(4))
ENDIF,
NUMBER + NUMBER(2),
f63: new
IF (NUMBER + NUMBER(2) == 1)
THEN
f160:   message
ELSE
f168:   messages.
ENDIF,
NUMBER,
f1010: with priority.
IF (NUMBER(5)>0)
THEN
NUMBER(5),
f1011: with fax.
ENDIF,
IF (NUMBER(6) > 0)
THEN
NUMBER(6),
f2007: with text.
ENDIF,
IF (NUMBER(7) > 0)
THEN
NUMBER(7),
f2008: with other media
ENDIF
``

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| a2008 | ```
# announcement 2008 new in MACH4
# replaces a185
# NUMBER = number of messages
# NUMBER(2) = 1/0 play passwd annc
# NUMBER(3) = days till passwd expires
# NUMBER(4) = number of fax messages
# NUMBER(5) = number of text messages
# NUMBER(6) = nuber of binary/other messages
#
NAME,
IF (NUMBER(2)>0)
THEN
        #password is about to expire
        a1153(NUMBER(3))
ENDIF,
NUMBER,
f63:  new
IF (NUMBER==1)
THEN
        f160:   message
ELSE
        f168:   messages.
ENDIF,
IF (NUMBER(4) > 0)
THEN
        NUMBER(4),
        f1011:  with fax.
ENDIF,
IF (NUMBER(5) > 0)
THEN
        NUMBER(5),
        f2007:  with text.
ENDIF,
IF (NUMBER(6) > 0)
THEN
        NUMBER(6),
        f2008:  with other media
ENDIF
``` |
| a2009 | ```
#   announcement 2009 new in MACH4
# NUMBER = number of priority messages
# NUMBER(2) = number of non-priority messages
# NUMBER(3) = number of fax messages
# NUMBER(4) = number of text messages
# NUMBER(5) = number of binary/other messages
#
NUMBER + NUMBER(2),
f63:  new
IF (NUMBER + NUMBER(2) == 1 )
THEN
        f160:   message
ELSE
``` |

Announcement	Fragments

	`        f168:   messages.`
	`ENDIF,`
	`NUMBER,`
	`f1010:  with priority.`
	`IF (NUMBER(3) > 0)`
	`THEN`
	`      NUMBER(3),`
	`      f1011:  with fax.`
	`ENDIF,`
	`IF ( NUMBER(4) > 0 )`
	`THEN`
	`      NUMBER(4),`
	`      f2007:  with text.`
	`ENDIF,`
	`IF ( NUMBER(5) > 0 )`
	`THEN`
	`      NUMBER(5),`
	`      f2008:  with other media`
	`ENDIF`

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| a2010 | ```
# announcement 2010 new in MACH4
# replaces a235
# NUMBER = number of priority messages
# NUMBER(2) = number of fax messages
# NUMBER(3) = number of text messages
# NUMBER(4) = number of binary/other messages
#
f2:  and
NUMBER,
f63:  new
f601:  Priority
IF (NUMBER==1)
THEN
      f160:  message
ELSE
      f168:  messages.
ENDIF,
IF (NUMBER(2) > 0)
THEN
      NUMBER(2),
      f1011:  with fax.
ENDIF,
IF (NUMBER(3) > 0)
THEN
      NUMBER(3),
      f2007:  with text.
ENDIF,
IF (NUMBER(4) > 0)
THEN
      NUMBER(4),
      f2008:  with other media
ENDIF
``` |
| a2011 | ```
# announcement 2011 new in MACH4
# NUMBER = number of priority messages
# NUMBER(2) = number of fax messages
# NUMBER(3) = number of text messages
# NUMBER(4) = number of binary/other messages
#
f2:  and
NUMBER,
f602:  other
f63:  new
IF (NUMBER==1)
THEN
      f160:  message
ELSE
      f168:  messages.
ENDIF,
IF (NUMBER(2) > 0)
THEN
      NUMBER(2),
``` |

Announcement	Fragments

	f1011: with fax.
	ENDIF,
	IF (NUMBER(3) > 0)
	THEN
	     NUMBER(3),
	     f2007: with text.
	ENDIF,
	IF (NUMBER(4) > 0)
	THEN
	     NUMBER(4),
	     f2008: with other media
	ENDIF

a2012	# announcement 2012 new in MACH4 # deletion tone f2000: \<ERROR TONE - Missing Component>
a2013	# announcement 2013 new in MACH4 f2009: Incomplete...

a2014	# announcement 2014 new in MACH4
	# MSG HEADER
	# NUMBER(1),(2),(3),(4) = type of component
	# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary
	# NUMBER(5) = number of pages
	# NUMBER(6) = number of bytes
	# NUMBER(7) = number of seconds
	#
	f2017: Broadcast...
	a2101(NUMBER,NUMBER(2),NUMBER(3)),
	f2019: ...message from...
	NAME,
	f262: received
	TIME,DATE,
	f905: \<.5 second pause>
	# do pages, bytes, seconds
	a2102(NUMBER(5),NUMBER(6),NUMBER(7))

Announcement	Fragments
a2015	# announcement 2015 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2017: Broadcast... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), f689: Expiration time is TIME(2),DATE(2)
a2016	# announcement 2016 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2017: Broadcast... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), EXTENSION
a2017	# announcement 2017 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2017: Broadcast... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause>

Announcement	Fragments
|  | ```
a2102(NUMBER(5),NUMBER(6),NUMBER(7)),
EXTENSION,
f689:  Expiration time is
TIME(2),DATE(2)
``` |
| a2018 | ```
# announcement 2018 new in MACH4
# MSG HEADER
# NUMBER(1),(2),(3),(4) = type of component
# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary
# NUMBER(5) = number of other subscribers
#
f2017:  Broadcast...
a2101(NUMBER,NUMBER(2),NUMBER(3)),
f2020:  ...message to...
f1117:  all local subscribers.
IF ( NUMBER(5) > 0 )
THEN
     f2:  and
NUMBER(5),
     IF ( NUMBER(5) == 1 )
     THEN
          f602:  other
     ELSE
          f217:  others
     ENDIF
ENDIF
``` |
| a2019 | ```
# announcement 2019 new in MACH4
# MSG HEADER
# NUMBER(1),(2),(3),(4) = type of component
# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary
# NUMBER(5) = number of other subscribers
#
a2101(NUMBER,NUMBER(2),NUMBER(3)),
f2020:  ...message to...
f1117:  all local subscribers.
IF ( NUMBER(5) > 0 )
THEN
     f2:  and
NUMBER(5),
     IF ( NUMBER(5) == 1 )
     THEN
          f602:  other
     ELSE
          f217:  others
     ENDIF
ENDIF
``` |

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| a2020 | ```
# announcement 2020 new in MACH4
# MSG HEADER
# NUMBER(1),(2),(3),(4) = type of component
# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary
# NUMBER(5) = number of other subscribers
#
f2021:  Private...
a2101(NUMBER,NUMBER(2),NUMBER(3)),
f2020:  ...message to...
f1117:  all local subscribers.
IF ( NUMBER(5) > 0 )
THEN
      f2:  and
NUMBER(5),
      IF ( NUMBER(5) == 1 )
      THEN
            f602:  other
      ELSE
            f217:  others
      ENDIF
ENDIF
``` |
| a2021 | ```
# announcement 2021 new in MACH4
# MSG HEADER
# NUMBER(1),(2),(3),(4) = type of component
# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary
# NUMBER(5) = number of other subscribers
#
f2022:  Private, priority...
a2101(NUMBER,NUMBER(2),NUMBER(3)),
f2020:  ...message to...
NAME,
IF ( NUMBER(5) > 0 )
THEN
      f2:  and
NUMBER(5),
      IF ( NUMBER(5) == 1 )
      THEN
            f602:  other
      ELSE
            f217:  others
      ENDIF
ENDIF
``` |
| a2022 | ```
# announcement 2022 new in MACH4
# MSG HEADER
# NUMBER(1),(2),(3),(4) = type of component
# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary
# NUMBER(5) = number of other subscribers
#
f2023:  Priority...
a2101(NUMBER,NUMBER(2),NUMBER(3)),
``` |

Announcement	Fragments
| | ```
f2020:  ...message to...
NAME,
IF ( NUMBER(5) > 0 )
THEN
      f2:  and
NUMBER(5),
      IF ( NUMBER(5) == 1 )
      THEN
            f602:  other
      ELSE
            f217:  others
      ENDIF
ENDIF
``` |
| a2023 | ```
# announcement 2023 new in MACH4
# MSG HEADER
# NUMBER(1),(2),(3),(4) = type of component
# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary
# NUMBER(5) = number of pages
# NUMBER(6) = number of bytes
# NUMBER(7) = number of seconds
#
f2024:  Private, broadcast...
a2101(NUMBER,NUMBER(2),NUMBER(3)),
f2019:  ...message from...
NAME,
f262:  received
TIME,DATE,
f905:  <.5 second pause>
a2102(NUMBER(5),NUMBER(6),NUMBER(7))
``` |
| a2024 | ```
# announcement 2024 new in MACH4
# MSG HEADER
# NUMBER(1),(2),(3),(4) = type of component
# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary
# NUMBER(5) = number of pages
# NUMBER(6) = number of bytes
# NUMBER(7) = number of seconds
#
f2024:  Private, broadcast...
a2101(NUMBER,NUMBER(2),NUMBER(3)),
f2019:  ...message from...
NAME,
f262:  received
TIME,DATE,
f905:  <.5 second pause>
a2102(NUMBER(5),NUMBER(6),NUMBER(7)),
f689:  Expiration time is
TIME(2),DATE(2)
``` |

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a2025	`# announcement 2025 new in MACH4`
	`# MSG HEADER`
	`# NUMBER(1),(2),(3),(4) = type of component`
	`# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary`
	`# NUMBER(5) = number of pages`
	`# NUMBER(6) = number of bytes`
	`# NUMBER(7) = number of seconds`
	`#`
	`f2024:  Private, broadcast...`
	`a2101(NUMBER,NUMBER(2),NUMBER(3)),`
	`f2019:  ...message from...`
	`NAME,`
	`f262:  received`
	`TIME,DATE,`
	`f905:  <.5 second pause>`
	`a2102(NUMBER(5),NUMBER(6),NUMBER(7)),`
	`EXTENSION`

a2026	`# announcement 2026 new in MACH4`
	`# MSG HEADER`
	`# NUMBER(1),(2),(3),(4) = type of component`
	`# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary`
	`# NUMBER(5) = number of pages`
	`# NUMBER(6) = number of bytes`
	`# NUMBER(7) = number of seconds`
	`#`
	`f2024:  Private, broadcast...`
	`a2101(NUMBER,NUMBER(2),NUMBER(3)),`
	`f2019:  ...message from...`
	`NAME,`
	`f262:  received`
	`TIME,DATE,`
	`f905:  <.5 second pause>`
	`a2102(NUMBER(5),NUMBER(6),NUMBER(7)),`
	`EXTENSION,`
	`f689:  Expiration time is`
	`TIME(2),DATE(2)`

a2027	`# announcement 2027 new in MACH4`
	`# MSG HEADER`
	`# NUMBER(1),(2),(3),(4) = type of component`
	`# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary`
	`# NUMBER(5) = number of pages`
	`# NUMBER(6) = number of bytes`
	`# NUMBER(7) = number of seconds`
	`#`
	`f2021:  Private...`
	`a2101(NUMBER,NUMBER(2),NUMBER(3)),`
	`f2019:  ...message from...`
	`NAME,`
	`f262:  received`
	`TIME,DATE,`

Announcement	Fragments
	f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7))
a2028	# announcement 2028 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2021: Private... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), f689: Expiration time is TIME(2),DATE(2)
a2029	# announcement 2029 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2021: Private... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)),EXTENSION

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a2030	`# announcement 2030 new in MACH4`
	`# MSG HEADER`
	`# NUMBER(1),(2),(3),(4) = type of component`
	`# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary`
	`# NUMBER(5) = number of pages`
	`# NUMBER(6) = number of bytes`
	`# NUMBER(7) = number of seconds`
	`#`
	`f2021:  Private...`
	`a2101(NUMBER,NUMBER(2),NUMBER(3)),`
	`f2019:  ...message from...`
	`NAME,`
	`f262:  received`
	`TIME,DATE,`
	`f905:  <.5 second pause>`
	`a2102(NUMBER(5),NUMBER(6),NUMBER(7)),`
	`EXTENSION,`
	`f689:  Expiration time is`
	`TIME(2),DATE(2)`

a2031	`# announcement 2031 new in MACH4`
	`# MSG HEADER`
	`# NUMBER(1),(2),(3),(4) = type of component`
	`# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary`
	`# NUMBER(5) = number of pages`
	`# NUMBER(6) = number of bytes`
	`# NUMBER(7) = number of seconds`
	`#`
	`f2023:  Priority...`
	`a2101(NUMBER,NUMBER(2),NUMBER(3)),`
	`f2019:  ...message from...`
	`NAME,`
	`f262:  received`
	`TIME,DATE,`
	`f905:  <.5 second pause>`
	`a2102(NUMBER(5),NUMBER(6),NUMBER(7))`

a2032	`# announcement 2032 new in MACH4`
	`# MSG HEADER`
	`# NUMBER(1),(2),(3),(4) = type of component`
	`# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary`
	`# NUMBER(5) = number of pages`
	`# NUMBER(6) = number of bytes`
	`# NUMBER(7) = number of seconds`
	`#`
	`f2023:  Priority...`
	`a2101(NUMBER,NUMBER(2),NUMBER(3)),`
	`f2019:  ...message from...`
	`NAME,`
	`f262:  received`
	`TIME,DATE,`
	`f905:  <.5 second pause>`

Announcement	Fragments
	a2102(NUMBER(5),NUMBER(6),NUMBER(7)), f689: Expiration time is TIME(2),DATE(2)
a2033	# announcement 2033 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2023: Priority... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)),EXTENSION
a2034	# announcement 2034 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2023: Priority... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), EXTENSION, f689: Expiration time is TIME(2),DATE(2)

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a2035	```# announcement 2035 new in MACH4```
	```# MSG HEADER```
	```# NUMBER(1),(2),(3),(4) = type of component```
	```# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary```
	```# NUMBER(5) = number of other subscribers```
	```#```
	```f2023: Priority...```
	```a2101(NUMBER,NUMBER(2),NUMBER(3)),```
	```f2020: ...message to...```
	```NAME,```
	```IF (NUMBER(5) > 0)```
	```THEN```
	``` f2: and```
	```NUMBER(5),```
	``` IF (NUMBER(5) == 1)```
	``` THEN```
	``` f602: other```
	``` ELSE```
	``` f217: others```
	``` ENDIF```
	```ENDIF```

a2036	```# announcement 2036 new in MACH4```
	```# MSG HEADER```
	```# NUMBER(1),(2),(3),(4) = type of component```
	```# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary```
	```# NUMBER(5) = number of other subscribers```
	```#```
	```f2024: Private, broadcast...```
	```a2101(NUMBER,NUMBER(2),NUMBER(3)),```
	```f2020: ...message to...```
	```f1117: all local subscribers.```
	```IF (NUMBER(5) > 0)```
	```THEN```
	``` f2: and```
	```NUMBER(5),```
	``` IF (NUMBER(5) == 1)```
	``` THEN```
	``` f602: other```
	``` ELSE```
	``` f217: others```
	``` ENDIF```
	```ENDIF```

a2037	```# announcement 2037 new in MACH4```
	```# MSG HEADER```
	```# NUMBER(1),(2),(3),(4) = type of component```
	```# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary```
	```# NUMBER(5) = number of pages```
	```# NUMBER(6) = number of bytes```
	```# NUMBER(7) = number of seconds```
	```#```

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	f2022: Private, priority... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7))
a2038	# announcement 2038 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2022: Private, priority... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), f689: Expiration time is TIME(2),DATE(2)
a2039	# announcement 2039 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # f2022: Private, priority... a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)),EXTENSION

Announcement	Fragments
| a2040 | ```
# announcement 2040 new in MACH4
# MSG HEADER
# NUMBER(1),(2),(3),(4) = type of component
# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary
# NUMBER(5) = number of pages
# NUMBER(6) = number of bytes
# NUMBER(7) = number of seconds
#
f2022:  Private, priority...
a2101(NUMBER,NUMBER(2),NUMBER(3)),
f2019:  ...message from...
NAME,
f262:  received
TIME,DATE,
f905:  <.5 second pause>
a2102(NUMBER(5),NUMBER(6),NUMBER(7)),
EXTENSION,
f689:  Expiration time is
TIME(2),DATE(2)
``` |
| a2041 | ```
# announcement 2041 new in MACH4
# MSG HEADER
# NUMBER(1),(2),(3),(4) = type of component
# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary
# NUMBER(5) = number of other subscribers
#
f2022:  Private, priority...
a2101(NUMBER,NUMBER(2),NUMBER(3)),
f2020:  ...message to...
NAME,
IF ( NUMBER(5) > 0 )
THEN
      f2:  and
NUMBER(5),
      IF ( NUMBER(5) == 1 )
      THEN
            f602:  other
      ELSE
            f217:  others
      ENDIF
ENDIF
``` |
| a2042 | ```
# announcement 2042 new in MACH4
# MSG HEADER
# NUMBER(1),(2),(3),(4) = type of component
# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary
# NUMBER(5) = number of pages
# NUMBER(6) = number of bytes
# NUMBER(7) = number of seconds
#
a2101(NUMBER,NUMBER(2),NUMBER(3)),
f2019:  ...message from...
``` |

Announcement	Fragments
	NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7))
a2043	# announcement 2043 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)), f689: Expiration time is TIME(2),DATE(2)
a2044	# announcement 2044 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = number of pages # NUMBER(6) = number of bytes # NUMBER(7) = number of seconds # a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f262: received TIME,DATE, f905: <.5 second pause> a2102(NUMBER(5),NUMBER(6),NUMBER(7)),EXTENSION

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a2045	```# announcement 2045 new in MACH4```
	 ```# MSG HEADER```
	 ```# NUMBER(1),(2),(3),(4) = type of component```
	 ```# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary```
	 ```# NUMBER(5) = number of pages```
	 ```# NUMBER(6) = number of bytes```
	 ```# NUMBER(7) = number of seconds```
	 ```#```
	 ```a2101(NUMBER,NUMBER(2),NUMBER(3)),```
	 ```f2019: ...message from...```
	 ```NAME,```
	 ```f262: received```
	 ```TIME,DATE,```
	 ```f905: <.5 second pause>```
	 ```a2102(NUMBER(5),NUMBER(6),NUMBER(7)),```
	 ```EXTENSION,```
	 ```f689: Expiration time is```
	 ```TIME(2),DATE(2)```

a2046	```# announcement 2046 new in MACH4```
	 ```# MSG HEADER```
	 ```# NUMBER(1),(2),(3),(4) = type of component```
	 ```# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary```
	 ```# NUMBER(5) = number of other subscribers```
	 ```#```
	 ```a2101(NUMBER,NUMBER(2),NUMBER(3)),```
	 ```f2020: ...message to...```
	 ```NAME,```
	 ```IF (NUMBER(5) > 0)```
	 ```THEN```
	 ``` f2: and```
	 ```NUMBER(5),```
	 ``` IF (NUMBER(5) == 1)```
	 ``` THEN```
	 ``` f602: other```
	 ``` ELSE```
	 ``` f217: others```
	 ``` ENDIF```
	 ```ENDIF```

a2047	```# announcement 2047 new in MACH4```
	 ```# MSG HEADER```
	 ```# NUMBER(1),(2),(3),(4) = type of component```
	 ```# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary```
	 ```# NUMBER(5) = number of other subscribers```
	 ```#```
	 ```f2021: Private...```
	 ```a2101(NUMBER,NUMBER(2),NUMBER(3)),```
	 ```f2020: ...message to...```
	 ```NAME,```
	 ```IF (NUMBER(5) > 0)```
	 ```THEN```

Announcement	Fragments
| | ```
        f2:  and
NUMBER(5),
        IF ( NUMBER(5) == 1 )
        THEN
             f602:  other
        ELSE
             f217:  others
        ENDIF
ENDIF
``` |
| a2048 | ```
# announcement 2048 new in MACH4
# MSG HEADER
# NUMBER(1),(2),(3),(4) = type of component
# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary
# NUMBER(5) = number of other subscribers
#
f2021:  Private...
a2101(NUMBER,NUMBER(2),NUMBER(3)),
f2020:  ...message to...
NAME,
IF ( NUMBER(5) > 0 )
THEN
        f2:  and
NUMBER(5),
        IF ( NUMBER(5) == 1 )
        THEN
             f602:  other
        ELSE
             f217:  others
        ENDIF
ENDIF
``` |

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| a2049 | ```
# announcement 2049 new in MACH4
# MSG HEADER
# NUMBER(1),(2),(3),(4) = type of component
# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary
# NUMBER(5) = number of pages
# NUMBER(6) = number of bytes
# NUMBER(7) = number of seconds
# NUMBER(8) = private/non-private
# NUMBER(9) = prioity/non-priority
# NUMBER(10) = ext available or not
#
IF ( NUMBER(8) == 1 )
THEN
        f2021:  Private...
ENDIF,
IF ( NUMBER(9) == 1 )
THEN
        f2023:  Priority...
ENDIF,
a2101(NUMBER,NUMBER(2),NUMBER(3)),
f2025:  ...call from...
NAME,
f262:  received
TIME,DATE,
f905:  <.5 second pause>
a2102(NUMBER(5),NUMBER(6),NUMBER(7)),
IF ( NUMBER(10) > 0 )
THEN
        f86:  extension
BUTTONS
ENDIF
``` |
| a2050 | ```
# announcement 2050 new in MACH4
# Controlling announcement to play length of
# message in bytes
#
IF ( NUMBER < 1000 )
THEN
        # less than 1K
        a2051(NUMBER)
ELSE
        IF ( NUMBER < 999500 )
        THEN
                # less than 1M
            # allow for rounding
                a2052(NUMBER)
        ELSE
                # 1M or greater
                a2053(NUMBER)
        ENDIF
ENDIF
``` |

Announcement	Fragments
| a2051 | ```
# announcement 2051 new in MACH4
# announcement for playing length of
# message in bytes (less than 1K)
#
IF ( NUMBER == 0 )
THEN
        f2010:  zero
        f2011:  bytes
ELSE
        IF ( NUMBER == 1 )
        THEN
                f391:  one
                f2012:  byte
        ELSE
                a820(NUMBER),
                f2011:  bytes
        ENDIF
ENDIF
``` |
| a2052 | ```
# announcement 2052 new in MACH4
# announcement for playing length of
# message in bytes (1K to 1M)
#
IF ( NUMBER < 1025 )
THEN
        f391:  one
        f2013:  kilobyte
ELSE
        f2053:  ...approximately...
        IF ( NUMBER/1000 == 1 && NUMBER%1000 < 500 )
        THEN
                f391:  one
                f2013:  kilobyte
        ELSE
                IF ( (NUMBER%1000) < 500 )
                THEN
                        a820(NUMBER/1000)
                ELSE
                        a820((NUMBER/1000) + 1)
                ENDIF,
                f2014:  kilobytes
        ENDIF
ENDIF
``` |

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| a2053 | ```
# announcement 2053 new in MACH4
# announcement for playing length of
# message in bytes ( > 1M )
# allow for rounding 999500 = 1M
# NUMBER = number of bytes
#
IF ( NUMBER < 1000000)
THEN
        # rounding for 999500 or greater
        f2053:  ...approximately...
        f391:  one
        f2015:  megabyte
ELSE
        IF ( NUMBER == 1000000 )
        THEN
                f391:  one
                f2015:  megabyte
        ELSE
                f2053:  ...approximately...
                IF ( NUMBER/1000000==1 && NUMBER%1000000 <
500000 )
                THEN
                        f391:  one
                        f2015:  megabyte
                ELSE
                        IF ( (NUMBER%1000000) < 500000 )
                        THEN
                                a820(NUMBER/1000000)
                        ELSE
                                a820((NUMBER/1000000) + 1)
                        ENDIF,
                        f2016:  megabytes
                ENDIF
        ENDIF
ENDIF
``` |
| a2054 | ```
# announcement 2054 new in MACH4
# MSG HEADER
# NUMBER(1),(2),(3),(4) = type of component
# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary
# NUMBER(5) = number of pages
# NUMBER(6) = number of bytes
# NUMBER(7) = number of seconds
# NUMBER(8) = private/non-private
# NUMBER(9) = prioity/non-priority
# NUMBER(10) = ext available of not
#
IF ( NUMBER(8) == 1 )
THEN
        f2021:  Private...
ENDIF,
``` |

Announcement	Fragments
| | ```
IF ( NUMBER(9) == 1 )
THEN
        f2023:  Priority...
ENDIF,
a2101(NUMBER,NUMBER(2),NUMBER(3)),
f2026:  ...call received...
TIME,DATE,
f905:  <.5 second pause>
a2102(NUMBER(5),NUMBER(6),NUMBER(7)),
IF ( NUMBER(10) > 0 )
THEN
        f86:  extension
BUTTONS
ENDIF
``` |
| a2055 | ```
# announcement 2055 new in MACH4
# NUMBER = number of pages
#
f2027:  Text of...
f2053:  ...approximately...
a820(NUMBER),
IF ( NUMBER == 1 )
THEN
        f1028:  page.
ELSE
        f1029:  pages.
ENDIF
``` |
| a2056 | ```
# announcement 2056 new in MACH4
# NUMBER = number of bytes
#
f2028:  Binary file of...
a2050(NUMBER)
``` |

Announcement	Fragments
| a2057 | ```
# announcement 2057 new in MACH4
# NUMBER: 0 is stacked response off, 1 is stacked
response on
# NUMBER(2): 0 is forwarding not allowed, 1 is
forwarding allowed
# NUMBER(3): 0 if sender doesn't exist, 1 if sender
exits
# NUMBER(4): 1/0 is printable
IF (NUMBER==0)
THEN
        #stacked response feature off
        IF (NUMBER(2)==0)
        THEN
                #no forwarding
                f252:  To respond to this message, press 1.
        ELSE
                #forwarding
                f234:  To respond or forward, press 1.
        ENDIF
ELSE
        #stacked response feature on
        IF (NUMBER(3)==1)
        THEN
                #sender of message exists, may reply
                f1463:  To reply to sender by voice mail,
                press 1, 7.
        ENDIF,
        IF (NUMBER(2)==1)
        THEN
                #forwarding allowed
                f1464:  To forward with comment, press 1, 2.
        ENDIF,
        f1465:  To record a new message, press 1, 4.
ENDIF,
IF (NUMBER(4) == 1)
THEN
        # printable
        f1073:  To print, press star 1.
ENDIF,
f24:  To delete,  press star 3.
f388:  To skip, press the pound key.
``` |
| a2058 | ```
# announcement 2058 new in MACH4
# NUMBER == 1/0 is prinable
f21:  To listen, press 0.
IF (NUMBER == 1)
THEN
        f1073:  To print, press star 1.
ENDIF,
f24:  To delete,  press star 3.
f388:  To skip, press the pound key.
``` |
| a2059 | ```
# announcement 2059 new in MACH4
# NUMBER = 1/0 contains voice
``` |

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| | ```
# NUMBER(2) = 1/0 is printable
IF (NUMBER == 1)
THEN
     f2054:  To re-record, press 1. After recording,
     press 1 again.
ENDIF,
IF (NUMBER(2) == 1)
THEN
     f1073:  To print, press star 1.
ENDIF,
f24:  To delete,  press star 3.
f1007:  To playback, press 2-3.
f157:  To approve as is, press the pound key.
``` |
| a2060 | ```
# announcement 2060 new in MACH4
# NUMBER == 1/0 is prinable
f21:  To listen, press 0.
IF (NUMBER == 1)
THEN
     f1073:  To print, press star 1.
ENDIF,
f1039:  To change or send again, press one.
f388:  To skip, press the pound key.
``` |
| a2061 | ```
# announcement 2061 new in MACH4
# NUMBER == 1/0 is prinable
f21:  To listen, press 0.
IF (NUMBER == 1)
THEN
     f1073:  To print, press star 1.
ENDIF,
f1039:  To change or send again, press one.
f24:  To delete,  press star 3.
f388:  To skip, press the pound key.
``` |
| a2062 | ```
# announcement 2062 new in MACH4
# NUMBER = 1/0 contains voice
# NUMBER(2) = 1/0 is printable
IF (NUMBER == 1)
THEN
     f30:  To change, press 1.
ENDIF,
IF (NUMBER(2) == 1)
THEN
     f1073:  To print, press star 1.
ENDIF,
f24:  To delete,  press star 3.
f388:  To skip, press the pound key.
``` |

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a2063	# announcement 2063 new in MACH4 # NUMBER == 1/0 is prinable f165: Returned to getting messages. f21: To listen, press 0. IF (NUMBER == 1) THEN f1073: To print, press star 1. ENDIF, f24: To delete, press star 3. f388: To skip, press the pound key.
a2064	# announcement 2064 new in MACH4 # NUMBER == 1/0 is prinable f165: Returned to getting messages. f21: To listen, press 0. IF (NUMBER == 1) THEN f1073: To print, press star 1. ENDIF, f255: To delete this message, press star 3. f388: To skip, press the pound key.
a2065	# announcement 2065 new in MACH4 # MSG HEADER # NUMBER(1),(2),(3),(4) = type of component # 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary # NUMBER(5) = 1/0 is printable # a2101(NUMBER,NUMBER(2),NUMBER(3)), f2019: ...message from... NAME, f21: To listen, press 0. IF (NUMBER(5) == 1) THEN f1073: To print, press star 1. ENDIF, f24: To delete, press star 3.
a2066	# announcement 2066 new in MACH4 # NUMBER == 1/0 is prinable f252: To respond to this message, press 1. f24: To delete, press star 3. IF (NUMBER == 1) THEN f1073: To print, press star 1. ENDIF, f388: To skip, press the pound key.
a2067	# announcement 2067 new in MACH4 # f926: <error sound> f1048: Nothing to print.

Announcement	Fragments

a2068	`# announcement 2068 new in MACH4`
	`#This announcement is used for the help when manually scanning`
	`#message headers.`
	`#`
	`#NUMBER: 0 is forwarding not allowed, 1 is forwarding allowed`
	`#NUMBER(2): 0 is message not scanned, 1 is message scanned`
	`#NUMBER(3): 1/0 is printable`
	`#NUMBER(4): number of components in message`
	`#`
	`f1461:  You are getting your incoming messages.`
	`f1462:  To listen to the message, press 0.`
	`IF (NUMBER(3) == 1)`
	`THEN`
	`     f1073:  To print, press star 1.`
	`ENDIF,`
	`IF (NUMBER==0)`
	`THEN`
	`     #forwarding not allowed`
	`     f252:  To respond to this message, press 1.`
	`ELSE`
	`     #forwarding allowed`
	`     f1466:  To respond to or forward the message,`
	`     press one.`
	`ENDIF,`
	`IF (NUMBER(2)==0)`
	`THEN`
	`     #message not scanned`
	`     f388:  To skip, press the pound key.`
	`     f142:  To listen to the header, press 3.`
	`     f143:  To step back again, press 2.`
	`     f578:  To skip to the next category, press star`
	`     pound.`
	`ELSE`
	`     #message scanned`
	`     f376:  To skip to the next header, press the pound`
	`     sign. To listen to the header, rewind by pressing`
	`     2, then play by pressing 3. To skip to the next`
	`     category, press star pound.`
	`ENDIF,`
	`f577:  To hold the message in its current category,`
	`press star star 4`
	`f339:  To replay the last few seconds, press 5. To`
	`advance a few seconds, press 6.`
	`IF ( NUMBER(4) == 1 )`
	`THEN`
	`     f2035:  To advance to the end of the message,`
	`     press star 6.`
	`ELSE`
	`     IF (NUMBER(4) > 1 )`
	`     THEN`
	`          f2036:  To rewind to the beginning of this`
	`          component, press star 5.  To advance to the`
	`          end of this component,  press star 6.`
	`     ENDIF`
	`ENDIF,`
	`f292:  Louder, press 4. Softer, press 7. Faster, press`

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a2069	`# announcement 2069 new in MACH4`
	`#  replaces a1158`
	`#This announcement is used for the help when manually scanning`
	`#message headers.`
	`#`
	`#NUMBER: 0 is forwarding not allowed, 1 is forwarding allowed`
	`#NUMBER(2): 0 is message not scanned, 1 is message scanned`
	`#NUMBER(3): stacked response on/off`
	`#NUMBER(4): 1/0 is printable`
	`#NUMBER(5): number of components in message`
	`#`
	`f1461:  You are getting your incoming messages.`
	`f1462:  To listen to the message, press 0.`
	`IF (NUMBER(4) == 1)`
	`THEN`
	`     #is printable`
	`     f1073:  To print, press star 1.`
	`ENDIF,`
	`IF (NUMBER(3) == 1)`
	`THEN`
	`     f1463:  To reply to sender by voice mail, press 1,`
	`     7.`
	`ENDIF,`
	`IF (NUMBER == 1)`
	`THEN`
	`     #forwarding allowed`
	`     f1464:  To forward with comment, press 1, 2.`
	`ENDIF,`
	`f1465:  To record a new message, press 1, 4.`
	`IF (NUMBER(2)==0)`
	`THEN`
	`     #message not scanned`
	`     f388:  To skip, press the pound key.`
	`     f142:  To listen to the header, press 3.`
	`     f143:  To step back again, press 2.`
	`     f578:  To skip to the next category, press star`
	`     pound.`
	`ELSE`
	`     #message scanned`
	`     f376:  To skip to the next header, press the pound`
	`     sign. To listen to the header, rewind by pressing`
	`     2, then play by pressing 3. To skip to the next`
	`     category, press star pound.`
	`ENDIF,`
	`f577:  To hold the message in its current category,`
	`press star star 4`
	`f339:  To replay the last few seconds, press 5. To`
	`advance a few seconds, press 6.`
	`IF ( NUMBER(5) == 1 )`

Announcement	Fragments
	``THEN
f2035: To advance to the end of the message,
press star 6.
ELSE
IF (NUMBER(5) > 1)
THEN
f2036: To rewind to the beginning of this
component, press star 5. To advance to the
end of this component, press star 6.
ENDIF
ENDIF,
f292: Louder, press 4. Softer, press 7. Faster, press
9. Slower, press 8.
IF (NUMBER(5) < 2)
THEN
f377: To delete message, press star 3.
ELSE
f2037: To delete entire message, press star 3.
ENDIF```

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a2070	# announcement 2070 new in MACH4
	# similar to a1173
	#This announcement is used for the help when manually scanning
	#message headers.
	#
	#NUMBER: 0 is forwarding not allowed, 1 is forwarding allowed
	#NUMBER(2): 0 is message not scanned, 1 is message scanned
	#NUMBER(3): 1/0 is printable
	#NUMBER(4): number of components in this message
	#
	IF (NUMBER == 0)
	THEN
	    f848: You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to the message, press 1.
	    IF (NUMBER(3) == 1)
	    THEN
	        f1073: To print, press star 1.
	    ENDIF
	ELSE
	    f847: You are automatically scanning your incoming messages. To listen to the message, press zero. To respond to or forward the message, press 1.
	    IF (NUMBER(3) == 1)
	    THEN
	        f1073: To print, press star 1.
	    ENDIF
	ENDIF,
	IF (NUMBER(2)==0)
	THEN
	    #message not scanned
	    f388: To skip, press the pound key.
	    f142: To listen to the header, press 3.
	    f143: To step back again, press 2.
	    f578: To skip to the next category, press star pound.
	ELSE
	    #message scanned
	    f849: To skip to the next message, press the pound sign. To listen to the header, rewind by pressing 2, then play by pressing 3. To skip to the next category, press star pound.
	ENDIF,
	f577: To hold the message in its current category, press star star 4
	f339: To replay the last few seconds, press 5. To advance a few seconds, press 6.
	IF (NUMBER(4) == 1)

Announcement	Fragments

	``
	THEN
	        f2035: To advance to the end of the message,
	        press star 6.
	ELSE
	
	        IF (NUMBER(4) > 1)
	        THEN
	                f2036: To rewind to the beginning of this
	                component, press star 5. To advance to the
	                end of this component, press star 6.
	        ENDIF
	ENDIF,
	f292: Louder, press 4. Softer, press 7. Faster, press
	9. Slower, press 8.
	IF (NUMBER(4) < 2)
	THEN
	        f377: To delete message, press star 3.
	ELSE
	        f2037: To delete entire message, press star 3.
	ENDIF
	``

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a2071	# announcement 2071 new in MACH4
	#This announcement is used for the help when manually scanning
	#message headers.
	#
	#NUMBER: 1/0 is printable
	#NUMBER(2): number of components in message
	#
	f378: You are checking the status of your outgoing messages.
	f1462: To listen to the message, press 0.
	IF (NUMBER == 1)
	THEN
	    f1073: To print, press star 1.
	ENDIF,
	f1039: To change or send again, press one.
	f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing 2, then play by pressing 3. To skip to the next category, press star pound.
	f339: To replay the last few seconds, press 5. To advance a few seconds, press 6.
	IF (NUMBER(2) == 1)
	THEN
	    f2035: To advance to the end of the message, press star 6.
	ELSE
	    IF (NUMBER(4) > 1)
	    THEN
	        f2036: To rewind to the beginning of this component, press star 5. To advance to the end of this component, press star 6.
	    ENDIF
	ENDIF,
	f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
	IF (NUMBER(4) < 2)
	THEN
	    f377: To delete message, press star 3.
	ELSE
	    f2037: To delete entire message, press star 3.
	ENDIF

a2072	# announcement 2072 new in MACH4 #This announcement is used for the help when manually scanning #message headers. # #NUMBER: 1/0 is printable #NUMBER(2): number of components in message # f378: You are checking the status of your outgoing

Announcement	Fragments

	messages.
	f1462: To listen to the message, press 0.
	IF (NUMBER == 1)
	THEN
	     f1073: To print, press star 1.
	ENDIF,
	f1038: To re-record message before delivery, press one.
	f388: To skip, press the pound key.
	f142: To listen to the header, press 3.
	f143: To step back again, press 2.
	f578: To skip to the next category, press star pound.
	f339: To replay the last few seconds, press 5. To
	advance a few seconds, press 6.
	IF (NUMBER(2) == 1)
	THEN
	     f2035: To advance to the end of the message,
	     press star 6.
	ELSE
	     IF (NUMBER(4) > 1)
	     THEN
	          f2036: To rewind to the beginning of this
	          component, press star 5. To advance to the
	          end of this component, press star 6.
	     ENDIF
	ENDIF,
	f292: Louder, press 4. Softer, press 7. Faster, press
	9. Slower, press 8.
	IF (NUMBER(4) < 2)
	THEN
	     f377: To delete message, press star 3.
	ELSE
	     f2037: To delete entire message, press star 3.
	ENDIF

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a2073	# announcement 2073 new in MACH4
	# replaces a929
	#This announcement is used for the help when manually scanning
	#message headers.
	#
	#NUMBER: 1/0 is printable
	#NUMBER(2): number of components in message
	#
	f378: You are checking the status of your outgoing messages.
	f1462: To listen to the message, press 0.
	IF (NUMBER == 1)
	THEN
	    f1073: To print, press star 1.
	ENDIF,
	f1039: To change or send again, press one.
	f388: To skip, press the pound key.
	f142: To listen to the header, press 3.
	f143: To step back again, press 2.
	f578: To skip to the next category, press star pound.
	f339: To replay the last few seconds, press 5. To advance a few seconds, press 6.
	IF (NUMBER(2) == 1)
	THEN
	    f2035: To advance to the end of the message, press star 6.
	ELSE
	    IF (NUMBER(2) > 1)
	    THEN
	        f2036: To rewind to the beginning of this component, press star 5. To advance to the end of this component, press star 6.
	    ENDIF
	ENDIF,
	f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
	IF (NUMBER(2) < 2)
	THEN
	    f377: To delete message, press star 3.
	ELSE
	    f2037: To delete entire message, press star 3.
	ENDIF

a2074	# announcement 2074 new in MACH4 #This announcement is used for the help when manually scanning #message headers. # #NUMBER: 1/0 is printable #NUMBER(2): number of components in message #

Announcement	Fragments

	f378: You are checking the status of your outgoing messages.
	f1462: To listen to the message, press 0.
	IF (NUMBER == 1)
	THEN
	    f1073: To print, press star 1.
	ENDIF,
	f1038: To re-record message before delivery, press one.
	f376: To skip to the next header, press the pound sign. To listen to the header, rewind by pressing 2, then play by pressing 3. To skip to the next category, press star pound.
	f339: To replay the last few seconds, press 5. To advance a few seconds, press 6.
	IF (NUMBER(2) == 1)
	THEN
	    f2035: To advance to the end of the message, press star 6.
	ELSE
	    IF (NUMBER(2) > 1)
	    THEN
	        f2036: To rewind to the beginning of this component, press star 5. To advance to the end of this component, press star 6.
	    ENDIF
	ENDIF,
	f292: Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.
	IF (NUMBER(2) < 2)
	THEN
	    f377: To delete message, press star 3.
	ELSE
	    f2037: To delete entire message, press star 3.
	ENDIF

Announcement	Fragments
| a2075 | ```
# announcement 2075 new in MACH4
# NUMBER: 1 = voice, 2 = fax, 3 = text, 4 = binary/other
#
f2038:  Rewound...
IF ( NUMBER != 0 )
THEN
      f2030:  ...voice...
(NUMBER-1)
ENDIF,
f2039:  ...component.
IF ( NUMBER(2) == 1 )
THEN
      f2057:  At beginning of message.
      f2040:  To listen, press 3.
ELSE
      f2040:  To listen, press 3.
      f2058:  To step back to previous component, press
      star 5.
ENDIF
``` |
| a2076 | ```
# announcement 2076 new in MACH4
#
f2052:  At beginning of message.  To step back to
previous message, press star 2.  To listen, press 0.
``` |
| a2077 | ```
# announcement 2077 new in MACH4
# NUMBER = 1 if fax enabled,
# NUMBER = 0 if fax is not enabled.
f305:  You are at the activity menu.
IF (NUMBER==0 )
THEN
      f990:  To record and send voice mail messages,
      press 1.
ELSE
      f991:  To record and send voice mail or fax
      messages, press 1.
ENDIF,
f992:  To get messages, press 2.
f1006:  To record or change the greeting heard by
callers, press 3.
f996:  To check your outgoing messages, press 4.
f2041:  To customize your mailbox -- for example,  to
create or edit  your  mailing lists, to specify your
printer preferences, or to change your password, press
5.
IF( NUMBER == 0 )
THEN
      f1001:  To change outcalling information, press 6.
      To scan incoming messages automatically, press 7.
      To re-logon, press star star 7.
ELSE
      f1165:  To change outcalling information, press 6.
      To scan  incoming messages  automatically or print
``` |

Announcement	Fragments
	all new faxes, press 7. To re-logon, press Star Star 7. ENDIF, f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

a2078	# announcement 2078 new in MACH4
	# NUMBER = 1 if fax enabled,
	# NUMBER = 0 if fax is not enabled.
	f305: You are at the activity menu.
	IF (NUMBER==0)
	THEN
	　　　f990: To record and send voice mail messages, press 1.
	ELSE
	　　　f991: To record and send voice mail or fax messages, press 1.
	ENDIF,
	f992: To get messages, press 2.
	f1013: To administer attendant menu, press 3.
	f996: To check your outgoing messages, press 4.
	f2041: To customize your mailbox -- for example, to create or edit your mailing lists, to specify your printer preferences, or to change your password, press 5.
	IF(NUMBER == 0)
	THEN
	　　　f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7.
	ELSE
	　　　f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logon, press Star Star 7.
	ENDIF,
	f291: To transfer to another extension, press star 8.
	f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a2079	`# announcement 2079 new in MACH4`
	`# replaces a113`
	`# NUMBER = 1 if fax enabled,`
	`# NUMBER = 0 if fax is not enabled.`
	`f305:  You are at the activity menu.`
	`IF (NUMBER==0)`
	`THEN`
	`     f990:  To record and send voice mail messages,`
	`     press 1.`
	`ELSE`
	`     f991:  To record and send voice mail or fax`
	`     messages, press 1.`
	`ENDIF,`
	`f992:  To get messages, press 2.`
	`f1016:  To administer your greeting, press 3.`
	`f996:  To check your outgoing messages, press 4.`
	`f2041:  To customize your mailbox -- for example,  to`
	`create or edit  your mailing lists, to specify your`
	`printer preferences, or to change your password, press`
	`5.`
	`IF(NUMBER == 0)`
	`THEN`
	`     f1001:  To change outcalling information, press 6.`
	`     To scan incoming messages automatically, press 7.`
	`     To re-logon, press star star 7.`
	`ELSE`
	`     f1165:  To change outcalling information, press 6.`
	`     To scan incoming messages  automatically or print`
	`     all new faxes, press 7.  To re-logon, press Star`
	`     Star 7.`
	`ENDIF,`
	`f291:  To transfer to another extension, press star 8.`
	`f282:  To have system wait, press star 9. To access the`
	`names or numbers directory, press star star 6. If`
	`finished, please hang up or to disconnect AUDIX, press`
	`star star 9.`

a2080	`# announcement 2080 new in MACH4`
	`# NUMBER = 1 if fax enabled,`
	`# NUMBER = 0 if fax is not enabled.`
	`f305:  You are at the activity menu.`
	`IF (NUMBER==0 )`
	`THEN`
	`     f990:  To record and send voice mail messages,`
	`     press 1.`
	`ELSE`
	`     f991:  To record and send voice mail or fax`
	`     messages, press 1.`
	`ENDIF,`
	`f992:  To get messages, press 2.`
	`f1013:  To administer attendant menu, press 3.`
	`f996:  To check your outgoing messages, press 4.`
	`f2041:  To customize your mailbox -- for example,  to`

Announcement	Fragments

	create or edit your mailing lists, to specify your printer preferences, or to change your password, press 5.
	IF(NUMBER == 0)
	THEN
	     f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7.
	ELSE
	     f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logon, press Star Star 7.
	ENDIF,
	f291: To transfer to another extension, press star 8.
	f117: To reach the covering extension, press star zero.
	f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| a2081 | ```
# announcement 2081 new in MACH4
# NUMBER = 1 if fax enabled,
# NUMBER = 0 if fax is not enabled.
f305:  You are at the activity menu.
IF (NUMBER==0 )
THEN
      f990:  To record and send voice mail messages,
      press 1.
ELSE
      f991:  To record and send voice mail or fax
      messages, press 1.
ENDIF,
f992:  To get messages, press 2.
f1006:  To record or change the greeting heard by
callers, press 3.
f996:  To check your outgoing messages, press 4.
f2041:  To customize your mailbox -- for example,  to
create or edit  your mailing lists, to specify your
printer preferences, or to change your password, press
5.
IF( NUMBER == 0 )
THEN
      f1001:  To change outcalling information, press 6.
      To scan incoming messages automatically, press 7.
      To re-logon, press star star 7.
ELSE
      f1165:  To change outcalling information, press 6.
      To scan incoming messages  automatically or print
      all new faxes, press 7.  To re-logon, press Star
      Star 7.
ENDIF,
f291:  To transfer to another extension, press star 8.
f282:  To have system wait, press star 9. To access the
names or numbers directory, press star star 6. If
finished, please hang up or to disconnect AUDIX, press
star star 9.
``` |
| a2082 | ```
# announcement 2082 new in MACH4
# NUMBER = 1 if fax enabled,
# NUMBER = 0 if fax is not enabled.
f305:  You are at the activity menu.
IF (NUMBER==0 )
THEN
      f990:  To record and send voice mail messages,
      press 1.
ELSE
      f991:  To record and send voice mail or fax
      messages, press 1.
ENDIF,
f992:  To get messages, press 2.
f996:  To check your outgoing messages, press 4.
f2041:  To customize your mailbox -- for example,  to
create or edit  your mailing lists, to specify your
``` |

Announcement	Fragments

	printer preferences, or to change your password, press 5.
	IF(NUMBER == 0)
	THEN
	    f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7.
	ELSE
	    f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logon, press Star Star 7.
	ENDIF,
	f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

a2083	# announcement 2083 new in MACH4
	# NUMBER = 1 if fax enabled,
	# NUMBER = 0 if fax is not enabled.
	f305: You are at the activity menu.
	IF (NUMBER==0)
	THEN
	    f990: To record and send voice mail messages, press 1.
	ELSE
	    f991: To record and send voice mail or fax messages, press 1.
	ENDIF,
	f992: To get messages, press 2.
	f1013: To administer attendant menu, press 3.
	f996: To check your outgoing messages, press 4.
	f2041: To customize your mailbox -- for example, to create or edit your mailing lists, to specify your printer preferences, or to change your password, press 5.
	IF(NUMBER == 0)
	THEN
	    f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7.
	ELSE
	    f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logon, press Star Star 7.
	ENDIF,
	f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

Announcement	Fragments

a2084	# announcement 2084 new in MACH4
	# replaces a121
	# NUMBER = 1 if fax enabled,
	# NUMBER = 0 if fax is not enabled.
	f305: You are at the activity menu.
	IF (NUMBER==0)
	THEN
	      f990: To record and send voice mail messages,
	      press 1.
	ELSE
	      f991: To record and send voice mail or fax
	      messages, press 1.
	ENDIF,
	f992: To get messages, press 2.
	f1006: To record or change the greeting heard by
	callers, press 3.
	f996: To check your outgoing messages, press 4.
	f2041: To customize your mailbox -- for example, to
	create or edit your mailing lists, to specify your
	printer preferences, or to change your password, press
	5.
	IF(NUMBER == 0)
	THEN
	      f1001: To change outcalling information, press 6.
	      To scan incoming messages automatically, press 7.
	      To re-logon, press star star 7.
	ELSE
	      f1165: To change outcalling information, press 6.
	      To scan incoming messages automatically or print
	      all new faxes, press 7. To re-logon, press Star
	      Star 7.
	ENDIF,
	f291: To transfer to another extension, press star 8.
	f117: To reach the covering extension, press star zero.
	f282: To have system wait, press star 9. To access the
	names or numbers directory, press star star 6. If
	finished, please hang up or to disconnect AUDIX, press
	star star 9.

a2085	# announcement 2085 new in MACH4
	# NUMBER = 1 if fax enabled,
	# NUMBER = 0 if fax is not enabled.
	f305: You are at the activity menu.
	IF (NUMBER==0)
	THEN
	      f990: To record and send voice mail messages,
	      press 1.
	ELSE
	      f991: To record and send voice mail or fax
	      messages, press 1.
	ENDIF,
	f992: To get messages, press 2.
	f996: To check your outgoing messages, press 4.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

	f2041: To customize your mailbox -- for example, to create or edit your mailing lists, to specify your printer preferences, or to change your password, press 5.
	IF(NUMBER == 0)
	THEN
	     f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7.
	ELSE
	     f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logon, press Star Star 7.
	ENDIF,
	f291: To transfer to another extension, press star 8.
	f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

a2086	# announcement 2086 new in MACH4
	# NUMBER = 1 if fax enabled,
	# NUMBER = 0 if fax is not enabled.
	f305: You are at the activity menu.
	IF (NUMBER==0)
	THEN
	     f990: To record and send voice mail messages,
	     press 1.
	ELSE
	     f991: To record and send voice mail or fax
	     messages, press 1.
	ENDIF,
	f992: To get messages, press 2.
	f1006: To record or change the greeting heard by
	callers, press 3.
	f996: To check your outgoing messages, press 4.
	f2041: To customize your mailbox -- for example, to
	create or edit your mailing lists, to specify your
	printer preferences, or to change your password, press
	5.
	IF(NUMBER == 0)
	THEN
	     f1001: To change outcalling information, press 6.
	     To scan incoming messages automatically, press 7.
	     To re-logon, press star star 7.
	ELSE
	     f1165: To change outcalling information, press 6.
	     To scan incoming messages automatically or print
	     all new faxes, press 7. To re-logon, press Star
	     Star 7.
	ENDIF,
	f291: To transfer to another extension, press star 8.
	f117: To reach the covering extension, press star zero.
	f282: To have system wait, press star 9. To access the
	names or numbers directory, press star star 6. If
	finished, please hang up or to disconnect AUDIX, press
	star star 9.

a2087	# announcement 2087 new in MACH4
	# NUMBER = 1 if fax enabled,
	# NUMBER = 0 if fax is not enabled.
	f305: You are at the activity menu.
	IF (NUMBER==0)
	THEN
	     f990: To record and send voice mail messages,
	     press 1.
	ELSE
	     f991: To record and send voice mail or fax
	     messages, press 1.
	ENDIF,
	f992: To get messages, press 2.
	f996: To check your outgoing messages, press 4.
	f2041: To customize your mailbox -- for example, to

Announcement	Fragments

	create or edit your mailing lists, to specify your printer preferences, or to change your password, press 5.
	IF(NUMBER == 0)
	THEN
	      f1001: To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7.
	ELSE
	      f1165: To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logon, press Star Star 7.
	ENDIF,
	f291: To transfer to another extension, press star 8.
	f117: To reach the covering extension, press star zero.
	f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| a2088 | ```
# announcement 2088 new in MACH4
# NUMBER = 1 if fax enabled,
# NUMBER = 0 if fax is not enabled.
f305:  You are at the activity menu.
IF (NUMBER==0 )
THEN
        f990:  To record and send voice mail messages,
        press 1.
ELSE
        f991:  To record and send voice mail or fax
        messages, press 1.
ENDIF,
f992:  To get messages, press 2.
f1006:  To record or change the greeting heard by
callers, press 3.
f996:  To check your outgoing messages, press 4.
f2041:  To customize your mailbox -- for example,  to
create or edit  your mailing lists, to specify your
printer preferences, or to change your password, press
5.
IF( NUMBER == 0 )
THEN
        f1001:  To change outcalling information, press 6.
        To scan incoming messages automatically, press 7.
        To re-logon, press star star 7.
ELSE
        f1165:  To change outcalling information, press 6.
        To scan incoming messages  automatically or print
        all new faxes, press 7.  To re-logon, press Star
        Star 7.
ENDIF,
f282:  To have system wait, press star 9. To access the
names or numbers directory, press star star 6. If
finished, please hang up or to disconnect AUDIX, press
star star 9.
``` |
| a2089 | ```
# announcement 2089 new in MACH4
# NUMBER == 0 if fax not allowed, and 1 if fax allowed.
# NUMBER(2) used for Address Before Record feature
(ABR) -(XEROX feature)
# introduced in INTUITY 3.0 (MACH3)
# NUMBER(2) == 0 for addressing options not allowed, 1
for addressing options
# allowed.
# NUMBER(3) used for Call Answer Disable feature (CAD)
(XEROX feature)
# introduced in INTUITY 3.0
# NUMBER(3) == is 0 for call answer options not allowed,
1 for call answer
# options allowed.
# This is the help at subscriber admin w/o "record name"
fragment.
f703:  You are at subscriber administration.
``` |

Announcement	Fragments

	f700: To administer mailing lists, press 1. To administer personal directory, press 2.
	IF (NUMBER == 1)
	THEN
	    f1052: To specify your fax preferences, press 3.
	ENDIF,
	f701: To change your password, press 4.
	IF (NUMBER(2) == 1)
	THEN
	    f1144: To specify whether a message can be addressed before it's recorded, press 6.
	ENDIF,
	IF (NUMBER(3) == 1)
	THEN
	    f1145: To administer call answer options, press 7.
	ENDIF,
	f2042: To administer your media preference for sorting incoming messages, press 8.

Announcement	Fragments

a2090	# announcement 2090 new in MACH4
	# NUMBER == 0 if fax not allowed, and 1 if fax allowed.
	# NUMBER(2) used for Address Before Record feature (ABR) -(XEROX feature)
	# introduced in INTUITY 3.0 (MACH3)
	# NUMBER(2) == 0 for addressing options not allowed, 1 for addressing options
	# allowed.
	# NUMBER(3) used for Call Answer Disable feature (CAD) (XEROX feature)
	# introduced in INTUITY 3.0
	# NUMBER(3) == is 0 for call answer options not allowed, 1 for call answer
	# options allowed.
	# This is the help at subscriber admin with "record name" fragment.
	f703: You are at subscriber administration.
	f700: To administer mailing lists, press 1. To administer personal directory, press 2.
	IF (NUMBER == 1)
	THEN
	    f1052: To specify your fax preferences, press 3.
	ENDIF,
	f701: To change your password, press 4.
	f702: To record your name, press 5.
	IF (NUMBER(2) == 1)
	THEN
	    f1144: To specify whether a message can be
	    addressed before it's recorded, press 6.
	ENDIF,
	IF (NUMBER(3) == 1)
	THEN
	    f1145: To administer call answer options, press
	    7.
	ENDIF,
	f2042: To administer your media preference for sorting incoming messages, press 8.

a2091	# announcement 2091 new in MACH4 # NUMBER == 0 if fax not allowed, and 1 if fax allowed. # NUMBER(2) used for Address Before Record feature (ABR) -(XEROX feature) # introduced in INTUITY 3.0 (MACH3) # NUMBER(2) == 0 for addressing options not allowed, 1 for addressing options # allowed. # NUMBER(3) used for Call Answer Disable feature (CAD) (XEROX feature) # introduced in INTUITY 3.0 # NUMBER(3) == is 0 for call answer options not allowed, 1 for call answer # options allowed.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments

	# This is the help at subscriber admin w/0 "record name" fragment.
	f700: To administer mailing lists, press 1. To administer personal directory, press 2.
	IF (NUMBER == 1)
	THEN
	    f1052: To specify your fax preferences, press 3.
	ENDIF,
	f701: To change your password, press 4.
	IF (NUMBER(2) == 1)
	THEN
	    f1144: To specify whether a message can be addressed before it's recorded, press 6.
	ENDIF,
	IF (NUMBER(3) == 1)
	THEN
	    f1145: To administer call answer options, press 7.
	ENDIF,
	f2042: To administer your media preference for sorting incoming messages, press 8.

Announcement	Fragments

a2092	# announcement 2092 new in MACH4
	# NUMBER == 0 if fax not allowed, and 1 if fax allowed.
	# NUMBER(2) used for Address Before Record feature (ABR) -(XEROX feature)
	# introduced in INTUITY 3.0 (MACH3)
	# NUMBER(2) == 0 for addressing options not allowed, 1 for addressing options
	# allowed.
	# NUMBER(3) used for Call Answer Disable feature (CAD) (XEROX feature)
	# introduced in INTUITY 3.0
	# NUMBER(3) == is 0 for call answer options not allowed, 1 for call answer
	# options allowed.
	# This is the help at subscriber admin with "record name" fragment.
	f700: To administer mailing lists, press 1. To administer personal directory, press 2.
	IF (NUMBER == 1)
	THEN
	        f1052: To specify your fax preferences, press 3.
	ENDIF,
	f701: To change your password, press 4.
	f702: To record your name, press 5.
	IF (NUMBER(2) == 1)
	THEN
	        f1144: To specify whether a message can be
	        addressed before it's recorded, press 6.
	ENDIF,
	IF (NUMBER(3) == 1)
	THEN
	        f1145: To administer call answer options, press
	        7.
	ENDIF,
	f2042: To administer your media preference for sorting incoming messages, press 8.

a2093	# announcement 2093 f2043: You are administering your preferred media type for sorting incoming messages. Messages with a primary media type matching your preference will be presented before other messages, regardless of the order in which they have been received. f2044: No media preference for sorting incoming messages has been specified. f2045: For voice, press 1. For fax, press 2. For text, press 3. For binary files, press 4. f2046: To retain your current preference, press the pound key.
a2094	# announcement 2094 new in MACH4 f2044: No media preference for sorting incoming messages has been specified.

Announcement	Fragments
	f2045: For voice, press 1. For fax, press 2. For text, press 3. For binary files, press 4.
	f2046: To retain your current preference, press the pound key.
a2095	# announcement 2095 new in MACH4
	f2043: You are administering your preferred media type for sorting incoming messages. Messages with a primary media type matching your preference will be presented before other messages, regardless of the order in which they have been received.
	f2047: Your media preference for sorting incoming messages is...
	f2030: ...voice...
	(NUMBER-1),
	f2048: For no preference, press 0.
	f2045: For voice, press 1. For fax, press 2. For text, press 3. For binary files, press 4.
	f2046: To retain your current preference, press the pound key.
a2096	# announcement 2096 new in MACH4
	f2047: Your media preference for sorting incoming messages is...
	f2030: ...voice...
	(NUMBER-1),
	f2048: For no preference, press 0.
	f2045: For voice, press 1. For fax, press 2. For text, press 3. For binary files, press 4.
	f2046: To retain your current preference, press the pound key.
a2097	# announcement 2097 new in MACH4
	# NUMBER = 0 = none,1 = voice,2 = fax,3 = text,4 = binary/other
	IF (NUMBER == 0)
	THEN
	f2044: No media preference for sorting incoming messages has been specified.
	ELSE
	f2030: ...voice...
	(NUMBER-1),
	f2049: ...will be your preferred media type.
	ENDIF
a2098	# announcement 2098 new in MACH4
	f2050: Remote user.
a2099	# announcement 2099 new in MACH4
	f926: <error sound>
a2100	# announcement 2100 new in MACH4
	f2051: Your password cannot be, the same as your extension number, consecutive digits, or a single repeated digit. Please enter new password and the pound key.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
| a2101 | ```
# announcement 2101 new in MACH4
# called by MSG HEADER anncs
# to speak type(s) of components
# NUMBER(1),(2),(3),(4) = type of component
# 0 = none, 1 = voice, 2 = fax, 3 = text, 4 = binary
IF ( NUMBER(3) != 0 )
THEN
        # multimedia
        f2034:  ...multi-media...
ELSE
        IF ( NUMBER(2) == 0 )
        THEN
                IF ( NUMBER != 0 )
                THEN
                        # only 1 component
                        f2030:  ...voice...
(NUMBER-1)
                ENDIF
        ELSE
                # two components
                f2030:  ...voice...
(NUMBER-1),
                f2018:  ...and...
                f2030:  ...voice...
(NUMBER(2)-1)
        ENDIF
ENDIF
``` |
| a2102 | ```
# announcement 2102 new in MACH4
# called by MSG HEADER annc
# to speak pages, bytes, seconds
# NUMBER = number of pages
# NUMBER = number of bytes
# NUMBER = number of seconds
#
IF ( NUMBER > 0 )
THEN
        a820(NUMBER),
        IF (NUMBER == 1 )
        THEN
                f1028:  page.
        ELSE
                f1029:  pages.
        ENDIF
ENDIF,
IF ( NUMBER(2) == 0 OR NUMBER(2) > 0 )
THEN
        a2050(NUMBER(2))
ENDIF,
IF (NUMBER(3) > 0 )
THEN
        a873(NUMBER(3))
``` |

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	ENDIF
a2103	# NEW ANNOUNCEMENT FOR MACH4 f2004: Message receipt notification: the complete message was delivered to you on an associated system. To play the message header, press 2-3.
a2104	# NEW ANNOUNCEMENT FOR MACH4 f2005: Header only message. No part of the original message is missing. To play the message header, press 2-3.
a2105	# NEW ANNOUNCEMENT FOR MACH4 f2059: This machine is unable to send mail to... NAME
a2150	# announcement 2150 # new announcement for SABER f2150: Speak a name.
a2151	# announcement 2151 # used with announcement 912 when # SABER is not active f561: You are addressing your message. f2151: You may add a person by speaking his or her name. To do so, press star-six-zero, wait for the tone, then speak. f175: Please note only AUDIX subscribers can be specified by name. f2152: To use touchtones to add a person, enter extension and pound sign. f869: If the extension entered belongs to a casual AMIS subscriber, you will be prompted for a mailbox id. f868: Mailbox id must be less than or equal to 16 digits. f328: To delete the previous entry, press star 3. To add a mailing list you have already created, or a public list owned by others, press star 5. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound. f2153: For name addressing, using touchtones, press star-2.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a2152	# announcement 2152 # used with announcement 912 when # SABER is active f561: You are addressing your message. f2154: You may add a person by speaking his or her name. To do so, wait for the tone at the end of this menu, then speak. f175: Please note only AUDIX subscribers can be specified by name. f328: To delete the previous entry, press star 3. To add a mailing list you have already created, or a public list owned by others, press star 5. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound. f2152: To use touchtones to add a person, enter extension and pound sign. f869: If the extension entered belongs to a casual AMIS subscriber, you will be prompted for a mailbox id. f868: Mailbox id must be less than or equal to 16 digits. f2153: For name addressing, using touchtones, press star-2. f2157: To turn-off speech recognition, and rely on touchtone addressing, press star-six-zero.
a2153	# announcement 2153 # used instead of announcement 214 f2155: Use touchtones to enter the last name, followed by the pound sign.
a2154	# announcement 2154 # used with announcement 7 when # SABER is not active f561: You are addressing your message. f2151: You may add a person by speaking his or her name. To do so, press star-six-zero, wait for the tone, then speak. f2156: To use touchtones to add a person, enter last name, followed by the pound sign. f175: Please note only AUDIX subscribers can be specified by name. f328: To delete the previous entry, press star 3. To add a mailing list you have already created, or a public list owned by others, press star 5. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound. f148: For extension addressing, press star 2.
a2155	# announcement 2155 # used with announcement 7 when # SABER is active f561: You are addressing your message. f2154: You may add a person by speaking his or her

Announcement	Fragments
	name. To do so, wait for the tone at the end of this menu, then speak. f2156: To use touchtones to add a person, enter last name, followed by the pound sign. f175: Please note only AUDIX subscribers can be specified by name. f328: To delete the previous entry, press star 3. To add a mailing list you have already created, or a public list owned by others, press star 5. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound. f148: For extension addressing, press star 2. f2157: To turn-off speech recognition, and rely on touchtone addressing, press star-six-zero.
a2156	# announcement 2156 # used with announcement 19 when # SABER is not active f327: You are creating a mailing list. f2151: You may add a person by speaking his or her name. To do so, press star-six-zero, wait for the tone, then speak. f175: Please note only AUDIX subscribers can be specified by name. f2152: To use touchtones to add a person, enter extension and pound sign. f328: To delete the previous entry, press star 3. To add a mailing list you have already created, or a public list owned by others, press star 5. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound. f2153: For name addressing, using touchtones, press star-2. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a2157	# announcement 2157 # used with announcement 19 when # SABER is active f327: You are creating a mailing list. f2154: You may add a person by speaking his or her name. To do so, wait for the tone at the end of this menu, then speak. f175: Please note only AUDIX subscribers can be specified by name. f328: To delete the previous entry, press star 3. To add a mailing list you have already created, or a public list owned by others, press star 5. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound. f2152: To use touchtones to add a person, enter extension and pound sign. f2153: For name addressing, using touchtones, press star-2. f2157: To turn-off speech recognition, and rely on touchtone addressing, press star-six-zero. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a2158	# announcement 2158 # used instead of announcement 218 f2155: Use touchtones to enter the last name, followed by the pound sign. f335: When finished, press pound.
a2159	# announcement 2159 # used with announcement 20 when # SABER is not active f327: You are creating a mailing list. f2151: You may add a person by speaking his or her name. To do so, press star-six-zero, wait for the tone, then speak. f2156: To use touchtones to add a person, enter last name, followed by the pound sign. f175: Please note only AUDIX subscribers can be specified by name. f328: To delete the previous entry, press star 3. To add a mailing list you have already created, or a public list owned by others, press star 5. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound. f148: For extension addressing, press star 2. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8.

Announcement	Fragments
	f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a2160	# announcement 2160 # used with announcement 20 when # SABER is active f327: You are creating a mailing list. f2154: You may add a person by speaking his or her name. To do so, wait for the tone at the end of this menu, then speak. f2156: To use touchtones to add a person, enter last name, followed by the pound sign. f175: Please note only AUDIX subscribers can be specified by name. f328: To delete the previous entry, press star 3. To add a mailing list you have already created, or a public list owned by others, press star 5. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound. f148: For extension addressing, press star 2. f2157: To turn-off speech recognition, and rely on touchtone addressing, press star-six-zero. f235: To restart at the activity menu, press star 7. To transfer to another extension, press star 8. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a2161	# announcement 2161 # used with announcement 195 when # SABER is not active f562: Enter the NUMBER, f563: digit extension f224: and pound sign. f2158: To transfer by speaking the person's name, press star-six-zero, wait for the tone, then speak.

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a2162	# announcement 2162 # used with announcement 117 when # SABER is not active f493: You are requesting a transfer. f562: Enter the NUMBER, f563: digit extension f119: you wish to call f224: and pound sign. f2158: To transfer by speaking the person's name, press star-six-zero, wait for the tone, then speak. f2159: To use touchtones to spell the person's name press star-2. f175: Please note only AUDIX subscribers can be specified by name. f105: To restart at the activity menu, press star 7. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a2163	# announcement 2163 # used with announcement 117 when # SABER is active f493: You are requesting a transfer. f2160: To transfer by speaking the person's name, wait for the tone at the end of this menu, then speak. f175: Please note only AUDIX subscribers can be specified by name. f2161: To transfer using touchtones... f562: Enter the NUMBER, f563: digit extension f119: you wish to call f224: and pound sign. f2159: To use touchtones to spell the person's name press star-2. f2157: To turn-off speech recognition, and rely on touchtone addressing, press star-six-zero. f105: To restart at the activity menu, press star 7. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a2164	# announcement 2164 # used with announcement 349 when # SABER is not active f2155: Use touchtones to enter the last name, followed by the pound sign. f2158: To transfer by speaking the person's name, press star-six-zero, wait for the tone, then speak. f175: Please note only AUDIX subscribers can be specified by name.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a2165	# announcement 2165 # used with announcement 172 when # SABER is not active f493: You are requesting a transfer. f2155: Use touchtones to enter the last name, followed by the pound sign. f2158: To transfer by speaking the person's name, press star-six-zero, wait for the tone, then speak. f175: Please note only AUDIX subscribers can be specified by name. f290: If you wish to specify a non-AUDIX subscriber, first change to extension addressing by pressing star 2. f105: To restart at the activity menu, press star 7. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a2166	# announcement 2166 # used with announcement 172 when # SABER is active f493: You are requesting a transfer. f2160: To transfer by speaking the person's name, wait for the tone at the end of this menu, then speak. f175: Please note only AUDIX subscribers can be specified by name. f2161: To transfer using touchtones... f987: Enter last name of the person f119: you wish to call f224: and pound sign. f290: If you wish to specify a non-AUDIX subscriber, first change to extension addressing by pressing star 2. f2157: To turn-off speech recognition, and rely on touchtone addressing, press star-six-zero. f105: To restart at the activity menu, press star 7. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a2167	# announcement 2167 # new announcement for SABER f2165: Transferring to ... NAME, f2166: Press any key to cancel.

Announcement	Fragments
a2168	# announcement 2168 # used instead of announcement 939 f2167: You are choosing between subscribers whose names match your entry. To indicate no subscribers match, delete your entry by pressing star-3. If you need additional help after deleting the entry, press star-4. f291: To transfer to another extension, press star 8. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.
a2169	# announcement 2169 # new announcement for SABER f926: <error sound> f2168: More than three subscribers pronounce their names in this manner. f2169: You must use touchtones to enter the destination. f96: For help, press star 4.
a2170	# announcement 2170 # new announcement for SABER f926: <error sound> f2170: Speech recognition is not available. f2169: You must use touchtones to enter the destination. f96: For help, press star 4.
a2171	# announcement 2171 # used with announcement 6 when # SABER is not active f561: You are addressing your message. f2151: You may add a person by speaking his or her name. To do so, press star-six-zero, wait for the tone, then speak. f175: Please note only AUDIX subscribers can be specified by name. f2152: To use touchtones to add a person, enter extension and pound sign. f328: To delete the previous entry, press star 3. To add a mailing list you have already created, or a public list owned by others, press star 5. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound. f2153: For name addressing, using touchtones, press star-2.
a2172	# announcement 2172 # used with announcement 6 when # SABER is active f561: You are addressing your message. f2154: You may add a person by speaking his or her name. To do so, wait for the tone at the end of this menu, then speak.

Announcement	Fragments
	f175: Please note only AUDIX subscribers can be specified by name. f328: To delete the previous entry, press star 3. To add a mailing list you have already created, or a public list owned by others, press star 5. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound. f2152: To use touchtones to add a person, enter extension and pound sign. f2153: For name addressing, using touchtones, press star-2. f2157: To turn-off speech recognition, and rely on touchtone addressing, press star-six-zero.
a2173	# announcement 2173 # used with announcement 116 when # SABER is not active f493: You are requesting a transfer. f562: Enter the NUMBER, f563: digit extension f119: you wish to call f224: and pound sign. f2158: To transfer by speaking the person's name, press star-six-zero, wait for the tone, then speak. f2159: To use touchtones to spell the person's name press star-2. f175: Please note only AUDIX subscribers can be specified by name. f105: To restart at the activity menu, press star 7. f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a2174	# announcement 2174 # used with announcement 116 when # SABER is active f493: You are requesting a transfer. f2160: To transfer by speaking the person's name, wait for the tone at the end of this menu, then speak. f175: Please note only AUDIX subscribers can be specified by name. f2161: To transfer using touchtones... f562: Enter the NUMBER, f563: digit extension f119: you wish to call f224: and pound sign. f2159: To use touchtones to spell the person's name press star-2. f2157: To turn-off speech recognition, and rely on touchtone addressing, press star-six-zero. f117: To reach the covering extension, press star zero. f105: To restart at the activity menu, press star 7. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a2175	# announcement 2175 # used with announcement 171 when # SABER is not active f493: You are requesting a transfer. f2155: Use touchtones to enter the last name, followed by the pound sign. f2158: To transfer by speaking the person's name, press star-six-zero, wait for the tone, then speak. f175: Please note only AUDIX subscribers can be specified by name. f290: If you wish to specify a non-AUDIX subscriber, first change to extension addressing by pressing star 2. f105: To restart at the activity menu, press star 7. f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a2176	# announcement 2176 # used with announcement 171 when # SABER is active f493: You are requesting a transfer. f2160: To transfer by speaking the person's name, wait for the tone at the end of this menu, then speak. f175: Please note only AUDIX subscribers can be specified by name. f2161: To transfer using touchtones... f987: Enter last name of the person

Announcement	Fragments
	f119: you wish to call f224: and pound sign. f290: If you wish to specify a non-AUDIX subscriber, first change to extension addressing by pressing star 2. f2157: To turn-off speech recognition, and rely on touchtone addressing, press star-six-zero. f105: To restart at the activity menu, press star 7. f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a2177	# announcement 2177 # used with announcement 936 when # SABER is not active f493: You are requesting a transfer. f2155: Use touchtones to enter the last name, followed by the pound sign. f2158: To transfer by speaking the person's name, press star-six-zero, wait for the tone, then speak. f175: Please note only AUDIX subscribers can be specified by name. f290: If you wish to specify a non-AUDIX subscriber, first change to extension addressing by pressing star 2. f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a2178	# announcement 2178 # used with announcement 936 when # SABER is active f493: You are requesting a transfer. f2160: To transfer by speaking the person's name, wait for the tone at the end of this menu, then speak. f175: Please note only AUDIX subscribers can be specified by name. f2161: To transfer using touchtones... f987: Enter last name of the person f119: you wish to call f224: and pound sign. f290: If you wish to specify a non-AUDIX subscriber, first change to extension addressing by pressing star 2. f2157: To turn-off speech recognition, and rely on touchtone addressing, press star-six-zero. f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a2179	# announcement 2179 # used with announcement 937 when # SABER is not active f493: You are requesting a transfer. f2155: Use touchtones to enter the last name, followed by the pound sign. f2158: To transfer by speaking the person's name, press star-six-zero, wait for the tone, then speak. f175: Please note only AUDIX subscribers can be specified by name. f290: If you wish to specify a non-AUDIX subscriber, first change to extension addressing by pressing star 2. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a2180	# announcement 2180 # used with announcement 937 when # SABER is active f493: You are requesting a transfer. f2160: To transfer by speaking the person's name, wait for the tone at the end of this menu, then speak. f175: Please note only AUDIX subscribers can be specified by name. f2161: To transfer using touchtones... f987: Enter last name of the person f119: you wish to call f224: and pound sign. f290: If you wish to specify a non-AUDIX subscriber, first change to extension addressing by pressing star 2. f2157: To turn-off speech recognition, and rely on touchtone addressing, press star-six-zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a2181	# announcement 2181 # used with announcement 193 when # SABER is not active f562: Enter the NUMBER, f563: digit extension f224: and pound sign. f117: To reach the covering extension, press star zero. f2158: To transfer by speaking the person's name, press star-six-zero, wait for the tone, then speak.
a2182	# announcement 2182 # used with announcement 194 when # SABER is not active f562: Enter the NUMBER, f563: digit extension

US-ENGLISH 123 Announcements

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
	f224: and pound sign. f117: To reach the covering extension, press star zero. f2158: To transfer by speaking the person's name, press star-six-zero, wait for the tone, then speak. f335: When finished, press pound.
a2183	# announcement 2183 # used with announcement 196 when # SABER is not active f562: Enter the NUMBER, f563: digit extension f224: and pound sign. f2158: To transfer by speaking the person's name, press star-six-zero, wait for the tone, then speak. f335: When finished, press pound.
a2184	# announcement 2184 # used instead of announcement 131 f725: You are adding entries to your personal directory. f832: Please enter extension and pound sign. f833: To delete current entry, press star 3. f2153: For name addressing, using touchtones, press star-2. f913: If finished, press pound.
a2185	# announcement 2185 # used instead of announcement 216 f2155: Use touchtones to enter the last name, followed by the pound sign. f708: If finished adding entries, press pound.
a2186	# announcement 2186 # used instead of announcement 222 f2155: Use touchtones to enter the last name, followed by the pound sign. f335: When finished, press pound.
a2187	# announcement 2187 # used instead of announcement 223 f2155: Use touchtones to enter the last name, followed by the pound sign. f121: When finished, approve list by pressing pound.
a2188	# announcement 2188 # used instead of announcement 328 f727: Enter alias and pound sign. f833: To delete current entry, press star 3. f2153: For name addressing, using touchtones, press star-2. f913: If finished, press pound.

US-ENGLISH 123 Announcements
DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

Announcement	Fragments
a2189	# announcement 2189 # used instead of announcement 859 f910: You are playing an announcement which need additional input before it can be played. f832: Please enter extension and pound sign. f2153: For name addressing, using touchtones, press star-2.
a2190	# announcement 2190 # used instead of announcement 655 f38: Name entered not followed by pound f187: and not added to the list. f2155: Use touchtones to enter the last name, followed by the pound sign. f349: To approve list as is, press pound.
a2191	# announcement 2191 # used with announcement 932 when # SABER is not active f493: You are requesting a transfer. f562: Enter the NUMBER, f563: digit extension f119: you wish to call f224: and pound sign. f2158: To transfer by speaking the person's name, press star-six-zero, wait for the tone, then speak. f2159: To use touchtones to spell the person's name press star-2. f175: Please note only AUDIX subscribers can be specified by name. f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a2192	# announcement 2192 # used with announcement 932 when # SABER is active f493: You are requesting a transfer. f2160: To transfer by speaking the person's name, wait for the tone at the end of this menu, then speak. f175: Please note only AUDIX subscribers can be specified by name. f2161: To transfer using touchtones... f562: Enter the NUMBER, f563: digit extension f119: you wish to call f224: and pound sign. f2159: To use touchtones to spell the person's name press star-2. f2157: To turn-off speech recognition, and rely on touchtone addressing, press star-six-zero.

Announcement	Fragments
	f117: To reach the covering extension, press star zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a2193	# announcement 2193 # used with announcement 933 when # SABER is not active f493: You are requesting a transfer. f562: Enter the NUMBER, f563: digit extension f119: you wish to call f224: and pound sign. f2158: To transfer by speaking the person's name, press star-six-zero, wait for the tone, then speak. f2159: To use touchtones to spell the person's name press star-2. f175: Please note only AUDIX subscribers can be specified by name. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.
a2194	# announcement 2194 # used with announcement 933 when # SABER is active f493: You are requesting a transfer. f2160: To transfer by speaking the person's name, wait for the tone at the end of this menu, then speak. f175: Please note only AUDIX subscribers can be specified by name. f2161: To transfer using touchtones... f562: Enter the NUMBER, f563: digit extension f119: you wish to call f224: and pound sign. f2159: To use touchtones to spell the person's name press star-2. f2157: To turn-off speech recognition, and rely on touchtone addressing, press star-six-zero. f282: To have system wait, press star 9. To access the names or numbers directory, press star star 6. If finished, please hang up or to disconnect AUDIX, press star star 9.

Announcement	Fragments
a2195	# announcement 2195 # used with announcement 770 when # SABER is not active f2155: Use touchtones to enter the last name, followed by the pound sign. f2158: To transfer by speaking the person's name, press star-six-zero, wait for the tone, then speak. f175: Please note only AUDIX subscribers can be specified by name. f117: To reach the covering extension, press star zero. f251: To transfer using extension instead, press star 2.
a2196	# announcement 2196 # used with announcement 771 when # SABER is not active f2155: Use touchtones to enter the last name, followed by the pound sign. f2158: To transfer by speaking the person's name, press star-six-zero, wait for the tone, then speak. f175: Please note only AUDIX subscribers can be specified by name. f117: To reach the covering extension, press star zero. f251: To transfer using extension instead, press star 2. f335: When finished, press pound.
a2197	# announcement 2197 # used with announcement 773 when # SABER is not active f2155: Use touchtones to enter the last name, followed by the pound sign. f2158: To transfer by speaking the person's name, press star-six-zero, wait for the tone, then speak. f251: To transfer using extension instead, press star 2.
a2198	# announcement 2198 # used with announcement 774 when # SABER is not active f2155: Use touchtones to enter the last name, followed by the pound sign. f2158: To transfer by speaking the person's name, press star-six-zero, wait for the tone, then speak. f251: To transfer using extension instead, press star 2. f335: When finished, press pound.
a2199	# announcement 2199 # used instead of announcement 61 f2167: You are choosing between subscribers whose names match your entry. To indicate no subscribers match, delete your entry by pressing star-3. If you need additional help after deleting the entry, press star-4. f235: To restart at the activity menu, press star 7. To

Announcement	Fragments
	transfer to another extension, press star 8. f80: To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f0 *a1112,a1129,a1131,a1142,a1144*

<NULL fragment, 0.0 second pause>

f1 *a649*

 Someone is changing your greeting, please try again later.

f2 *a210,a235,a236,a273,a342,a343,a344,a345,a350,a352,*
a366,a372,a381,a387,a398,a404,a412,a418,a493,a540,
a541,a542,a543,a544,a545,a546,a553,a554,a673,a675,
a767,a794,a800,a838,a840,a841,a2010,a2011,a2018,
a2019,a2020,a2021,a2022,a2035,a2036,a2041,a2046,
a2047,a2048

 and

f3 *a608*

 No new remote subscribers can be addressed.

f4 *a874*

 not private.

f5 *a26,a283*

 To record personal greeting, press 1. To listen to personal greeting, press 0. To select which greeting to use, press star pound.

f6 *a98,a100,a509*

 Enter machine voice ID.

f8 *a62,a85,a123,a126,a128,a168,a169,a170,a202,a204,*
a205,a693,a759,a760,a761,a768,a1139,a1141,a1160,
a1161

 To record a new message, press 4.

f9 *a914*

 star 7 not available.

f10 *a442*
 That is not a valid machine voice ID.

f11 *a98*
 You are recording machine names.

f12 *a310,a973*
 To re-record, press 1. After recording, press 1 again. To delete, press star 3. To playback, press 2-3. To approve as is, press pound.

f13 *a49,a68,a101,a267,a310,a332,a581,a589,a879,a881, a943,a961,a992*
 To record, press 1. After recording, press 1 again.

f14 *a39,a502*
 To make private, press 1. To make public, press 2.

f15 *a455,a456*
 and is

f16 *a238*
 Enter announcement id

f17 *a184,a190*
 including

f18 *a202,a693,a759,a768,a1141,a1160*
 To forward with comment, press 2.

f19 *a695,a698*
 To review from beginning, press star 1. If finished, press star pound.

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f20 *a822*

 Remote extension

f21 *a276,a346,a507,a527,a530,a892,a893,a2058,a2060,*
a2061,a2063,a2064,a2065

 To listen, press 0.

f22 *a318,a609,a715,a765*

 To deliver now, press pound. To schedule delivery time enter hour and minutes, press 2 for A.M. or 7 for P.M., and pound sign.

f23 *a113,a722*

 To record messages, press 1. To get messages, press 2. To administer your greeting, press 3.

f24 *a34,a74,a192,a206,a276,a310,a315,a326,a429,a430,*
a501,a507,a508,a525,a527,a892,a893,a907,a1011,
a1012,a1027,a1152,a2057,a2058,a2059,a2061,a2062,
a2063,a2065,a2066

 To delete, press star 3.

f25 *a889*

 List id not followed by pound.

f26 *a757*

 To record names, press 4. To play names, press 5. To record machine names, press 6. To play machine names, press 7.

f27 *a249*

 To attach original, press 9 for yes or 6 for no.

f29 *a255,a1187*

 Returned to checking status of outgoing messages.

f30 *a508,a2062*
 To change, press 1.

f31 *a261*
 Date not understood.

f32 *a262*
 You must enter your extension to logon.

f34 *a538,a540,a548*
 Electronic Text

f35 *a264,a265*
 Login incorrect.

f36 *a50*
 To record a personal greeting, press 1.

f37 *a654,a890*
 Extension entered not followed by pound

f38 *a655,a891,a2190*
 Name entered not followed by pound

f39 *a26*
 To delete, press star 3. To stop playback,
press 3.

f40 *a266*
 Time not understood.

f41 *a62,a85,a123,a170,a1161*
 To forward message with comment at beginning,
press 2.

f42 *a284*
The return address for this message is not a mailbox on this system.

f43 *a282,a288,a289,a290,a291,a292,a293,a1105,a1175, a1176,a1177,a1178*
Your call is being answered by AUDIX.

f44 *a289,a292,a1176,a1178*
is not available. To leave a message, wait for the tone.

f45 *a290,a291,a1175,a1177*
is busy. To leave a message, wait for the tone.

f46 *a4,a8,a27,a68,a69,a70,a71,a285,a920,a921,a1185*
To access your mailbox, press star 7.

f47 *a286,a287,a658,a659,a1150,a1170*
Call from

f48 *a76,a77,a113,a114,a115,a119,a120,a121,a125,a127, a129,a159*
To check your outgoing messages, press 4. To administer mailing list, personal directory, password, or account name, press 5. To change outcalling information, press 6. To scan incoming messages automatically, press 7. To re-logon, press star star 7.

f49 *a603*
No operator defined.

f50 *a295,a296,a660,a661*
 Call

f51 *a280*
 Entries deleted, please re-enter delivery time.

f53 *a561*
 Message deleted, no delivery will occur.

f56 *a285,a920,a921,a954,a955,a956*
 Thank you for leaving your message.

f57 *a680*
 accessed

f58 *a6,a19,a131,a328,a859,a912*
 For name addressing, press star 2.

f59 *a681,a1183,a1902,a1913*
 delivered

f60 *a308*
 Changed.

f61 *a457,a458*
 To modify status, press 9 for yes or 6 for no.

f62 *a566,a569*
 Please delete unneeded messages.

f63 *a183,a184,a185,a190,a235,a236,a683,a1167,a1168,*
a1169,a2006,a2007,a2008,a2009,a2010,a2011
 new

f64 *a684*
 old

f65 *a451,a452,a469*
 contains

f66 *a535,a626*
 **If correct, press pound. If not, press star 3
and re-enter time.**

f67 *a559*
 To create another list,

f68 *a685*
 undeliverable

f69 *a686*
 undelivered

f70 *a687*
 unopened

f71 *a289,a290,a291,a292,a1175,a1176,a1177,a1178*
 To leave a message, wait for the tone.

f73 *a882*
 You have

f74 *a181,a187,a225,a281,a379,a380,a381,a382,a383,a384,
a385,a386,a387,a388,a389,a390,a391,a392,a393,a453,
a459,a473,a576,a908*
 deleted.

f75 *a179,a913*
 To skip, press pound. To delete, press star 3.

f77 *a316,a317,a318*
 Deleted.

f80 *a14,a15,a16,a17,a18,a61,a68,a69,a70,a71,a102,a103,*
a104,a147,a152,a763,a893,a934,a935,a939,a944,a945,
a946,a947,a948,a949,a951,a952,a953,a961,a2168,
a2199
 To have system wait, press star 9. If finished, please hang up or to disconnect AUDIX, press star star 9.

f81 *a199,a443,a514*
 digits.

f82 *a504*
 Please leave a message for

f83 *a320,a451*
 entries.

f84 *a320,a451*
 entry.

f85 *a332*
 Erased.

f86 *a287,a295,a334,a335,a336,a337,a338,a506,a659,a660,*
a709,a821,a915,a1150,a1151,a1170,a1171,a1900,a1902,
a1911,a1913,a2049,a2054
 extension

f87 *a812,a834*
 This call is experiencing difficulties.

f88 *a431*
 Cannot use the guest password

f89 *a348*
 First message.

f90 *a354*
 Enter fragment id

f91 *a528*
 At end.

f92 *a573*
 Nothing to advance.

f93 *a362*
 You have no personal greeting, system greeting used.

f94 *a197,a872*
 Good-bye.

f95 *a191,a253,a258,a279,a336,a504,a565,a615,a766,a834,*
a908,a954,a959,a1038,a1175,a1176,a1177,a1178
 Please disconnect.

f96 *a496,a694,a763,a968,a1140,a2169,a2170*
 For help, press star 4.

f97 *a815*
 For help at any time, press star 4.

f98 *a639,a640,a741*
 Message not delivered due to transmission problems.

f99 *a437,a969,a973*
 Invalid announcement.

f100 *a263,a496,a970,a971*
 Invalid Entry.

f101 *a441*
 Invalid fragment.

f102 *a445*
 That is not a valid extension.

f104 *a447*
 **Message delivered, cannot listen to a
delivered message.**

f105 *a13,a96,a97,a99,a105,a106,a116,a117,a147,a152,a171,
a172,a200,a246,a559,a630,a631,a632,a633,a1008,
a1018,a1020,a1032,a1035,a1112,a1122,a1123,a1124,
a2162,a2163,a2165,a2166,a2173,a2174,a2175,a2176*
 To restart at the activity menu, press star 7.

f108 *a34,a49,a992*
 You are recording a message.

f109 *a191,a712,a834,a877*
 later.

f110 *a449,a450,a451,a452,a453,a454,a455,a456,a457,a458,
a459,a460,a462,a463,a465,a466,a467,a468,a469,a470,
a471,a472,a473,a474,a477,a662,a674,a836*
 list

f111 *a29,a31,a63,a64,a478,a511,a559*
 Please enter list id

f112 *a291,a292,a1175,a1176*
 Otherwise, for assistance, press zero now.

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f113 *a484*
  You already have a list

f114 *a484*
  To replace list, re-enter id and pound sign.
To create a new list, enter new list id

f115 *a116,a117,a193,a194,a195,a196,a932,a933*
  To transfer using names instead, press star 2.

f116 *a481,a482*
  List is full.

f117 *a4,a9,a15,a68,a69,a70,a71,a79,a80,a108,a114,a116,*
a121,a127,a129,a171,a193,a194,a770,a771,a932,a936,
a942,a947,a951,a952,a953,a958,a961,a2080,a2084,
a2086,a2087,a2173,a2174,a2175,a2176,a2177,a2178,
a2181,a2182,a2191,a2192,a2195,a2196
  To reach the covering extension, press star
zero.

f118 *a132,a214,a216,a222,a223,a349,a655,a770,a771,a773,*
a774
  Enter last name

f119 *a116,a117,a171,a172,a932,a933,a936,a937,a2162,*
a2163,a2166,a2173,a2174,a2176,a2178,a2180,a2191,
a2192,a2193,a2194
  you wish to call

f120 *a460,a462,a463,a470,a471,a472*
  too large to include.

f121 *a219,a223,a2187*
  When finished, approve list by pressing pound.

f122 *a487*
  List space nearly full. You may enter

f123 *a487*
 new members.

f124 *a463,a472,a476,a480,a483*
 No more list space.

f125 *a511*
 Must be six or fewer numerals.

f126 *a62,a85,a123,a170,a1161*
 To forward message with comment at end, press 3.

f127 *a694*
 Returned to previous activity.

f128 *a446,a769*
 To request another transfer, press star 8.

f129 *a446*
 or leave a message for

f130 *a459*
 because there were no entries.

f131 *a220*
 To send to others not on your list,

f132 *a460,a470*
 You can store your list as is by pressing star pound or add up to

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f133 *a480,a481*
 To continue reviewing, press 3. To delete an entry, press star 3. If finished reviewing, press star pound.

f134 *a462,a471*
 You can store your list or delete members, but you cannot add members.

f136 *a435*
 Line busy.

f138 *a100*
 You are listening to machine names.

f139 *a460,a470*
 additional members,

f140 *a322*
 Entry already deleted. To delete more entries, press star 1.

f141 *a479*
 No more lists.

f142 *a348,a450,a454,a607,a680,a681,a682,a683,a684,a685, a686,a687,a706,a733,a836,a924,a925,a926,a927,a928, a929,a930,a1157,a1158,a1159,a1172,a1173,a1182, a2068,a2069,a2070,a2072,a2073*
 To listen to the header, press 3.

f143 *a175,a607,a733,a836,a924,a925,a926,a927,a928,a929, a930,a1157,a1158,a1159,a1172,a1173,a1182,a2068, a2069,a2070,a2072,a2073*
 To step back again, press 2.

f145 *a324*
 List has no entries.

f146 *a175,a176*
 To continue, press pound.

f147 *a696,a697,a698*
 Review completed.

f148 *a7,a20,a67,a132,a327,a860,a2154,a2155,a2159,a2160*
 For extension addressing, press star 2.

f149 *a436*
 All circuits busy.

f150 *a452,a455,a456,a469*
 members.

f152 *a505,a506*
 Leave Word Calling from

f153 *a510*
 Maximum length recorded. To re-record, press
2-1. To approve as is, press pound.

f154 *a485*
 Cannot create new list, you have maximum
lists allowed. To select lists to be deleted,
press 5-1-2 and follow instructions.

f155 *a486*
 Cannot create new list, total number of
members in all your lists equals maximum
allowed.

f156 *a294,a513*
 Maximum length recorded.

f157 *a310,a513,a2059*
To approve as is, press the pound key.

f158 *a191,a877*
 Transfer cannot be completed.

f159 *a452,a455,a456*
 member.

f160 *a183,a184,a185,a190,a235,a236,a1167,a1168,a1169,*
a2006,a2007,a2008,a2009,a2010,a2011
 message

f161 *a904*
 midnight.

f163 *a85,a168,a169,a170,a759,a760,a761,a768,a1160,a1161*
 To call sender, press zero.

f164 *a680,a681,a682,a683,a684,a685,a686,a687*
 category.

f165 *a527,a530,a1186,a2063,a2064*
 Returned to getting messages.

f166 *a531*
 At end. To playback, press 2-3.

f167 *a34,a533,a560*
 **To approve, press pound. To record from here,
press 1. To playback, press 2-3.**

f168 *a183,a184,a185,a190,a235,a236,a538,a539,a540,a541,*
a542,a543,a544,a545,a546,a548,a549,a550,a551,a552,
a553,a554,a555,a627,a1167,a1168,a1169,a2006,a2007,
a2008,a2009,a2010,a2011
 messages.

f169 *a577*
 **Administrative version not specified, please
do so using administrator's terminal.**

f170 *a534,a535*
 Delivery scheduled

f172 *a539,a542,a544,a546,a548,a550,a552,a554,a627*
 You have new

f173 *a199,a317,a431,a443,a444,a514,a586,a612*
 Please enter new password

f175 *a349,a770,a771,a2151,a2152,a2154,a2155,a2156,a2157,*
a2159,a2160,a2162,a2163,a2164,a2165,a2166,a2171,
a2172,a2173,a2174,a2175,a2176,a2177,a2178,a2179,
a2180,a2191,a2192,a2193,a2194,a2195,a2196
 **Please note only AUDIX subscribers can be
specified by name.**

f177 *a574*
 Cannot listen to a delivered message.

f178 *a575,a576*
 No addressees identified.

f179 *a816*
 **Warning, if you do not supply an addressee
list, message will be deleted immediately.**

f180 *a562,a581,a611*
 Nothing to approve.

f182 *a585,a586*
 Nothing to delete.

f184 *a589*
 Nothing to erase.

f185 *a229,a467,a468*
 not found.

f186 *a584*
 To record messages, press 1. To get messages, press 2. To check your outgoing messages, press 4.

f187 *a654,a655,a2190*
 and not added to the list.

f188 *a592*
 Passwords do not match. Please re-enter new password

f189 *a593*
 You have no mailbox.

f190 *a594*
 Message delivered, you cannot change it now.

f191 *a595*
 No more messages.

f192 *a597*
 No messages.

f193 *a598,a599,a692*
 No name recorded.

f194 *a600*
 No new messages.

f196 *a604*
 You have no personal greeting.

f197 *a178,a226,a348,a454*
 Cannot step back.

f198 *a537*
 Partial name deleted.

f199 *a605,a606,a607*
 Nothing to rewind.

f200 *a609*
 No time entered, nothing to delete.

f201 *a904*
 noon.

f202 *a338,a466,a614,a615,a754*
 not valid.

f203 *a566*
 No room in your mailbox for a recording.

f207 *a571*
 Message too long to add comment. To record a
new message, press star 7-1.

f208 *a465,a474,a477*
 is not a public list.

f209 *a572*
  Cannot modify another subscriber's list.

f210 *a14,a51*
  Please enter a new password

f211 *a444*
  to fifteen digits

f212 *a10,a16*
  Please enter password again for confirmation. To delete the password you just entered, press star 3

f213 *a201*
  Re-enter password

f214 *a394,a648*
  Approved.

f215 *a569*
  No room to retain a copy.

f216 *a637,a638,a639,a640,a641,a642,a643,a644*
  originally

f217 *a210,a273,a342,a343,a344,a345,a493,a673,a675,a767, a838,a840,a841,a2018,a2019,a2020,a2021,a2022,a2035, a2036,a2041,a2046,a2047,a2048*
  others

f219 *a469,a470,a471,a472,a473,a474,a477*
  owned by

f220 *a56*
  Enter password

f221 *a57*
 **Enter announcement id and pound sign. Refer
to administration manual for correct id.**

f222 *a58*
 **Enter fragment id and pound sign. Refer to
administration manual for correct id.**

f223 *a53,a59,a60,a87,a613,a627*
 Please enter extension

f224 *a6,a7,a11,a12,a14,a19,a20,a29,a31,a32,a38,a45,a51,
a53,a54,a55,a56,a59,a60,a63,a64,a65,a66,a67,a87,
a98,a100,a116,a117,a132,a171,a172,a193,a194,a195,
a196,a199,a201,a213,a214,a216,a218,a219,a222,a223,
a234,a238,a317,a349,a354,a431,a443,a444,a466,a478,
a484,a497,a498,a509,a511,a514,a521,a559,a586,a592,
a612,a613,a621,a627,a654,a655,a724,a725,a726,a770,
a771,a773,a774,a819,a861,a889,a890,a891,a894,a912,
a932,a933,a936,a937,a940,a941,a1152,a2161,a2162,
a2163,a2166,a2173,a2174,a2176,a2178,a2180,a2181,
a2182,a2183,a2191,a2192,a2193,a2194*
 and pound sign.

f226 *a455,a457,a658,a659,a660,a661,a662,a866*
 private

f227 *a456,a458,a674*
 public

f228 *a688*
 Record at the tone.

f229 *a689*
 You will have up to

f230 *a689*
  seconds to record.

f232 *a611,a691,a692,a883*
  Recording stopped.

f233 *a11,a12*
  Previous login incorrect. Please re-enter extension

f234 *a192,a1012,a2057*
  To respond or forward, press 1.

f235 *a5,a9,a10,a19,a20,a24,a25,a26,a28,a30,a32,a38,a39,
a40,a41,a42,a43,a44,a45,a48,a50,a51,a57,a58,a59,
a61,a62,a63,a64,a65,a66,a67,a78,a79,a80,a83,a85,
a93,a94,a98,a100,a108,a123,a126,a128,a168,a169,
a170,a724,a726,a2156,a2157,a2159,a2160,a2199*
  **To restart at the activity menu, press star 7.
To transfer to another extension, press star 8.**

f236 *a191,a265,a712,a834,a877*
  Try again

f237 *a613*
  Or press star 7.

f238 *a200*
  To review another list,

f239 *a282*
  followed by the pound sign.

f240 *a501*
  To skip, press pound. To listen, press 0.

f241 *a463,a472,a482,a483*
 To review list, press star 1.

f242 *a680,a681,a682,a683,a684,a685,a686,a687*
 Returned to the

f243 *a364,a733*
 Rewound.

f244 *a706*
 Rewound to previous message.

f245 *a708,a709*
 Please return call.

f246 *a210*
 Message addressed to

f247 *a211*
 To add to list,

f248 *a713*
 scheduled

f249 *a713*
 To change delivery time, press star 3; To approve, press pound.

f250 *a714*
 To change delivery time, press star 3.

f251 *a770,a771,a773,a774,a2195,a2196,a2197,a2198*
 To transfer using extension instead, press star 2.

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f252 *a192,a206,a1012,a1027,a1157,a1172,a2057,a2066,*
a2068
 To respond to this message, press 1.

f253 *a819*
 Please enter month, day

f254 *a93,a94*
 To play the active version, press 1.

f255 *a530,a2064*
 To delete this message, press star 3.

f256 *a606,a699*
 At beginning. To re-record, press 1. To
playback, press 2-3.

f257 *a727*
 To use personal greeting, press 9. To use
system greeting, press 6.

f258 *a342,a838*
 Message to

f259 *a637,a638,a639,a640,a641,a642,a643,a644,a736,a737,*
a738,a739,a740,a741,a742,a743,a744,a896,a897,a974,
a2001,a2002,a2005
 scheduled for

f261 *a637,a638,a639,a640,a641,a642,a643,a644*
 rescheduled for

f262 *a269,a270,a271,a272,a286,a287,a295,a296,a355,a356,*
a357,a358,a489,a490,a491,a492,a505,a506,a658,a659,
a660,a661,a663,a664,a665,a666,a668,a669,a670,a671,
a676,a677,a678,a679,a745,a746,a808,a809,a810,a811,
a1150,a1170,a1900,a1901,a1911,a1912,a2014,a2015,
a2016,a2017,a2023,a2024,a2025,a2026,a2027,a2028,
a2029,a2030,a2031,a2032,a2033,a2034,a2037,a2038,
a2039,a2040,a2042,a2043,a2044,a2045,a2049
 received

f263 *a878,a880*
 You are recording a subscriber name.

f264 *a637,a744*
 **Message not delivered because mailbox was
full.**

f265 *a637,a638*
 **Message not delivered because their mailboxes
were full.**

f270 *a754*
 subscriber id

f272 *a258,a593*
 Contact administrator for help.

f274 *a70,a103,a298,a712,a762,a763,a945,a953*
 Please make entry soon, or be disconnected.

f275 *a766*
 **Cannot get your messages now, due to multiple
logins to your mailbox.**

f276 *a765*
 **Time requested has passed, please re-schedule
delivery.**

f277 *a147,a152,a826,a934,a935*
  To exit directory, press pound.

f279 *a853,a854*
  Enter announcement set and pound sign.

f281 *a808,a809,a810,a811*
  Message from

f282 *a5,a9,a10,a13,a19,a20,a24,a25,a26,a28,a30,a32,a38,*
a39,a40,a41,a42,a43,a44,a45,a48,a50,a51,a57,a58,
a59,a62,a63,a64,a65,a66,a67,a76,a77,a78,a79,a80,
a83,a85,a93,a94,a96,a97,a98,a99,a100,a101,a105,
a106,a108,a113,a114,a115,a116,a117,a119,a120,a121,
a123,a125,a126,a127,a128,a129,a159,a168,a169,a170,
a171,a172,a724,a726,a932,a933,a936,a937,a938,a940,
a941,a942,a943,a960,a2077,a2078,a2079,a2080,a2081,
a2082,a2083,a2084,a2085,a2086,a2087,a2088,a2156,
a2157,a2159,a2160,a2162,a2163,a2165,a2166,a2173,
a2174,a2175,a2176,a2177,a2178,a2179,a2180,a2191,
a2192,a2193,a2194
  **To have system wait, press star 9. To access
the names or numbers directory, press star star
6. If finished, please hang up or to disconnect
AUDIX, press star star 9.**

f283 *a814*
  Your mailbox is more than

f284 *a814*
  **percent full. Please delete unneeded messages
or greetings.**

f285 *a6,a19,a912*
  To add a member, enter extension

f286 *a7,a20*
  To add a member, enter last name

f287 *a815*
 Welcome to AUDIX.

f288 *a147,a934*
 You are in the names directory. To find a subscriber's extension, enter the last name followed by the pound sign. To enter the letter Q, press 7; for Z press 9. To look up by extension instead press star 2.

f290 *a171,a172,a936,a937,a2165,a2166,a2175,a2176,a2177, a2178,a2179,a2180*
 If you wish to specify a non-AUDIX subscriber, first change to extension addressing by pressing star 2.

f291 *a4,a8,a15,a18,a68,a69,a70,a71,a77,a113,a114,a115, a121,a125,a127,a129,a920,a921,a938,a939,a940,a941, a942,a947,a949,a951,a952,a953,a955,a956,a957,a958, a961,a1140,a2078,a2079,a2080,a2081,a2084,a2085, a2086,a2087,a2168*
 To transfer to another extension, press star 8.

f292 *a24,a26,a34,a40,a41,a42,a44,a47,a49,a68,a73,a74, a81,a86,a96,a101,a118,a122,a124,a880,a881,a925, a926,a927,a928,a929,a930,a943,a961,a992,a1157, a1158,a1159,a1172,a1173,a1181,a1182,a2068,a2069, a2070,a2071,a2072,a2073,a2074*
Louder, press 4. Softer, press 7. Faster, press 9. Slower, press 8.

f293 *a817*
 Nothing to playback.

f294 *a40,a179*
 To add entries, press 1.

f295 *a468,a477*
 To re-enter list, press star 5.

f297 *a55,a66*
 To specify owner by extension, press star 2.

f298 *a54,a65*
 To specify owner by name, press star 2.

f299 *a26,a50*
 You are administering your greeting.

f300 *a904*
 A. M.

f301 *a904*
 P. M.

f302 *a30*
 You are recording announcement fragments.
Enter fragment id followed by pound sign. Refer
to administration manual for correct id.

f303 *a32*
 You are recording names. Enter extension

f304 *a68,a101,a880,a881,a943,a961*
 To playback message, press 2-3. To delete your
message, press star 3. To approve your message,
press pound.

f305 *a76,a77,a113,a114,a115,a119,a120,a121,a125,a127,*
a129,a159,a2077,a2078,a2079,a2080,a2081,a2082,
a2083,a2084,a2085,a2086,a2087,a2088
 You are at the activity menu.

f306 *a10,a14,a16,a51*
 You are changing your password.

f307 *a57,a93,a854*
 You are playing announcements.

f308 *a58,a94,a853*
 You are playing announcement fragments.

f309 *a59*
 You are playing names.

f310 *a3*
 January

f311 *NONE*
 February

f312 *NONE*
 March

f313 *NONE*
 April

f314 *NONE*
 May

f315 *NONE*
 June

f316 *NONE*
 July

f317 *NONE*
 August

f318 *NONE*
  September

f319 *NONE*
  October

f320 *NONE*
  November

f321 *NONE*
  December

f322 *a152,a935*
  You are in the numbers directory. To find a subscriber's name enter the extension followed by the pound sign. To look up by name instead, press star 2.

f323 *a62,a85,a123,a126,a128,a168,a169,a170,a1161*
  You are responding to a piece of incoming mail.

f324 *a78*
  You are selecting which greeting will be played to callers. If you want your personal greeting to be played, press 9 for yes. If you press 6 for no, the system greeting will be used.

f325 *a137*
  You are administering your lists. To create a mailing list, press 1. To play a summary of all your lists, press 2. To review a particular list, press 3.

f326 *a83*
 You are doing system administration. To record names, press 4. To play names, press 5. To record a machine name, press 6. To play a machine name, press 7. To record fragments, press 1. To play fragments, press 2. To play announcements, press 3.

f327 *a19,a20,a45,a2156,a2157,a2159,a2160*
 You are creating a mailing list.

f328 *a6,a7,a19,a20,a912,a2151,a2152,a2154,a2155,a2156, a2157,a2159,a2160,a2171,a2172*
 To delete the previous entry, press star 3. To add a mailing list you have already created, or a public list owned by others, press star 5. To review or modify the list you are creating, press star 1. To approve the list you are creating and move on to the next step, press pound.

f329 *a45,a67,a861,a1152*
 You have not yet entered enough characters to identify a specific subscriber. To enter the letter Q, press 7; for Z press 9.

f330 *a12,a87*
 Or enter just the pound sign if it's your phone.

f331 *a790*
 Personal greeting used.

f332 *a380,a381,a382,a383,a384,a385,a386,a387,a388,a389,*
a390,a391,a392,a393,a792,a793,a794,a795,a796,a797,
a798,a799,a800,a801,a802,a803,a804,a805,a806

System greeting used.

f333 *a44,a913*

To add entries to the list or to change status of list, press 1.

f334 *a212*

When finished addressing, press pound.

f335 *a194,a196,a218,a222,a771,a774,a2158,a2182,a2183,*
a2186,a2196,a2198

When finished, press pound.

f336 *a211*

To review addressees, press star 1.

f338 *a93,a94*

To play the administrative version, press 2.

f339 *a24,a26,a34,a47,a73,a74,a86,a96,a118,a122,a124,*
a880,a881,a924,a925,a926,a927,a928,a929,a992,a1157,
a1158,a1159,a1172,a1173,a2068,a2069,a2070,a2071,
a2072,a2073,a2074

To replay the last few seconds, press 5. To advance a few seconds, press 6.

f340 *a84*

Enter the hour, one through twelve, then two digits for the minutes, then press 2 for A.M .or 7 for P.M., and the pound sign.

f341 *a33*

Enter the number of the month, one through twelve, then two digits for the day of the month, then the pound sign.

f342 *a541,a542,a545,a546,a549,a550,a553,a554*
 Electronic document communication

f343 *a539,a540,a541,a542,a543,a544,a545,a546,a555*
 Leave word calling

f344 *a543,a544,a545,a546,a551,a552,a553,a554*
 Message Center Service

f345 *a184,a185,a190,a236*
 Voice mail

f346 *a879,a881*
 You are recording a machine name.

f347 *a29,a31,a54,a55*
 You are adding a list.

f348 *a63,a64,a65,a66,a67*
 You are specifying a mailing list to review.

f349 *a463,a472,a482,a483,a654,a655,a2190*
 To approve list as is, press pound.

f350 *a3*
 Sunday

f351 *NONE*
 Monday

f352 *NONE*
 Tuesday

f353 *NONE*
 Wednesday

f354 *NONE*
 Thursday

f355 *NONE*
 Friday

f356 *NONE*
 Saturday

f357 *a61,a939*
 You are choosing between subscribers whose names match your entry. To indicate no subscribers match, delete entry by pressing star 3. To change to extension addressing and delete your entry, press star 2.

f358 *a39*
 You are identifying a list as private or public.

f359 *a43*
 You are changing the status of your list. To modify status, press 9 for yes or 6 for no.

f360 *a41*
 You are scanning mailing lists. To review list members, press 0. To rewind to previous list, press 2. To continue scanning lists, press 3.

f361 *a41*
 To skip to next list, press pound. To delete list, press star 3.

f362 *a54,a55,a65,a66*
 If you own the list, press pound. If someone else owns the list

f363 *a29,a31,a63,a64*
 To approve the list you are creating, press pound.

f364 *a54,a65,a497,a890*
 enter owner's extension

f365 *a55,a66*
 enter owner's name

f366 *a29,a63*
 To specify a different owner by extension, press star 3.

f367 *a31,a64*
 To specify a different owner by name, press star 3.

f368 *a38*
 You are entering the number for a new list. Please enter a number up to six digits long

f369 *a38*
 To replace an existing list, enter that list's number,

f370 *a40,a44*
 These are entries in your list.

f371 *a40,a42,a44*

 To rewind to current entry, press 2. To rewind
to previous entries, press 2 as many times as
necessary. To continue playback of list, press
3.

f372 *a40,a44,a157,a228*

 To skip to next entry, press pound. To delete
current entry, press star 3.

f373 *a25*

 You are choosing whether to attach a copy of
original message to your reply. To include the
original, press 9 for yes. To send only your
reply, press 6 for no.

f375 *a124,a924,a926*

 You are getting your incoming messages. To
listen to the message, press 0. To respond to
the message, press 1.

f376 *a73,a81,a86,a124,a1157,a1158,a1172,a1181,a2068,
a2069,a2071,a2074*

 To skip to the next header, press the pound
sign. To listen to the header, rewind by
pressing 2, then play by pressing 3. To skip to
the next category, press star pound.

f377 *a73,a86,a118,a122,a124,a924,a925,a926,a927,a928,
a929,a1157,a1158,a1159,a1172,a1173,a1181,a1182,
a2068,a2069,a2070,a2071,a2072,a2073,a2074*

 To delete message, press star 3.

f378 *a73,a81,a86,a928,a929,a930,a1181,a1182,a2071,a2072, a2073,a2074*

 You are checking the status of your outgoing messages.

f379 *a81,a930*

 To delete status information, press star 3.

f380 *a69,a71,a102,a104,a299,a775,a813,a944,a946,a951, a952*

 Please wait.

f381 *a86,a928*

 To listen to the message, press 0. To re-record message before delivery, press 1.

f382 *a33,a84*

 You are scheduling your message for delivery.

f383 *a266,a862,a863*

 Please enter hour, then two digits for minutes, then press 2 for A.M. or 7 for P.M., and pound sign.

f384 *a90,a92,a161,a261*

 Please enter number of month, then two digits for day, and pound sign.

f385 *a75*

 To approve delivery time, press pound. To modify delivery time, press star 3 and listen for further instructions.

f386 *a520*

 Cannot change a delivered message.

f387 *a641,a642,a742*

 Message not delivered because recipient not found.

f388 *a42,a180,a192,a206,a276,a315,a346,a507,a508,a527,*
a530,a730,a924,a925,a926,a927,a928,a929,a930,a1011,
a1012,a1027,a1157,a1158,a1159,a1172,a1173,a1182,
a2057,a2058,a2060,a2061,a2062,a2063,a2064,a2066,
a2068,a2069,a2070,a2072,a2073

To skip, press the pound key.

f390 *a820,a843,a903*

 oh

f391 *a844,a2051,a2052,a2053*

 one

f392 *a845*

 two

f393 *a846*

 three

f394 *a847*

 four

f395 *a848*

 five

f396 *a849*

 six

f397 *a850*

 seven

f398 *a851*

 eight

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f399 *a852*
 nine

f400 *a972*
 ten

f401 *NONE*
 eleven

f402 *NONE*
 twelve

f403 *NONE*
 thirteen

f404 *NONE*
 fourteen

f405 *NONE*
 fifteen

f406 *NONE*
 sixteen

f407 *NONE*
 seventeen

f408 *NONE*
 eighteen

f409 *NONE*
 nineteen

f410 *NONE*
 twenty

f411 *NONE*
 twenty-one

f412 *NONE*
 twenty-two

f413 *NONE*
 twenty-three

f414 *NONE*
 twenty-four

f415 *NONE*
 twenty-five

f416 *NONE*
 twenty-six

f417 *NONE*
 twenty-seven

f418 *NONE*
 twenty-eight

f419 *NONE*
 twenty-nine

f420 *NONE*
 thirty

f421 *NONE*
 thirty-one

f422 *NONE*
 thirty-two

f423 *NONE*
 thirty-three

f424 *NONE*
 thirty-four

f425 *NONE*
 thirty-five

f426 *NONE*
 thirty-six

f427 *NONE*
 thirty-seven

f428 *NONE*
 thirty-eight

f429 *NONE*
 thirty-nine

f430 *NONE*
 forty

f431 *NONE*
 forty-one

f432 *NONE*
 forty-two

f433 *NONE*
 forty-three

f434 *NONE*
 forty-four

f435 *NONE*
 forty-five

f436 *NONE*
 forty-six

f437 *NONE*
 forty-seven

f438 *NONE*
 forty-eight

f439 *NONE*
 forty-nine

f440 *NONE*
 fifty

f441 *NONE*
 fifty-one

f442 *NONE*
 fifty-two

f443 *NONE*
 fifty-three

f444 *NONE*
 fifty-four

f445 *NONE*
 fifty-five

f446 *NONE*
 fifty-six

f447 *NONE*
  fifty-seven

f448 *NONE*
  fifty-eight

f449 *NONE*
  fifty-nine

f450 *a820*
  sixty

f451 *NONE*
  seventy

f452 *NONE*
  eighty

f453 *NONE*
  ninety

f454 *a901*
  hundred

f455 *a906*
  thousand

f456 *a906*
  million

f462 *a824*
  pound

f463 *a823*
  star

f464 *a213,a218,a219,a654*
 Enter extensions

f466 *a735*
 created

f468 *a488,a749*
 To continue playing, press 3.

f470 *a498,a891*
 Enter owner's last name

f471 *a497,a498,a890,a891*
 If it's your list, press pound.

f472 *a326,a749*
 To approve, press pound. To record from here, press 1.

f473 *a532,a682*
 filed

f474 *a73,a346,a507,a929*
 To listen, press 0. To change or send again, press 1.

f475 *a751*
 To file a copy, press 9 for yes or 6 for no.

f477 *a717,a963*
 Press 1 to select

f478 *a718,a964*
 2 to select

f479 *a719,a965*
 3 to select

f482 *a724,a725,a726,a827,a940,a941*
 Press pound to select

f483 *a724,a725,a726,a827,a940,a941*
 or enter more characters

f484 *a45,a67,a521,a861,a1152*
 Enter more characters followed by the pound sign; if you just completed entering the last name, enter the first name.

f485 *a455,a456*
 has

f486 *a62,a85,a126,a168,a204,a693,a760,a768,a1160,a1161*
 To reply to sender by voice mail, press 1.

f487 *a33*
 To delete time, press star 3. To default rest of the delivery time, press pound.

f488 *a84*
 To specify immediate delivery, press pound. Otherwise

f492 *a448*
 Owner erased.

f493 *a116,a117,a171,a172,a932,a933,a936,a937,a2162, a2163,a2165,a2166,a2173,a2174,a2175,a2176,a2177, a2178,a2179,a2180,a2191,a2192,a2193,a2194*
 You are requesting a transfer.

f498 *a466,a889*

 Please enter a new list id

f499 *a750,a990*

 When finished recording, press # to approve, or 1 to edit your message.

f500 *a627*

 This is AUDIX.

f501 *a723*

 To record messages, press 1. To get messages, press 2. To administer attendant menu, press 3.

f502 *a24,a96,a246*

 To record attendant menu, press 1. To listen to attendant menu, press 0.

f503 *a24,a96*

 You are administering your attendant menu.

f504 *a252*

 Transferring to an operator,

f505 *a248*

 You have selected an invalid option.

f506 *a247*

 Menu approved and activated.

f507 *a282,a297,a298*

 The person you called is not available. To leave a message, use touch tones to re-enter the number you called.

f508 *a253*
 Attendant Service not available, try again
later.

f509 *a601*
 System not administered for outcalling.

f510 *a614,a615,a886*
 Number

f511 *a299,a712*
 If you do not have a touch tone phone,

f512 *a772*
 Your call is being transferred to an operator.

f513 *a279*
 Begin your message by saying the name and
telephone number of the person you are calling.
Someone will listen to the start of your
message, and then forward the complete message
to the person you called.

f514 *a712,a990*
 otherwise

f515 *a71,a104,a775,a946,a951*
 To be transferred to an operator,

f516 *a69,a102,a944,a952*
 To leave a message that will be delivered as
soon as possible,

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f517 *a69,a70,a71,a102,a103,a104,a944,a945,a946,a951, a952,a953*

You are entering the number of the person for whom you are leaving a message. This may be the complete number you dialed or simply the extension. For a faster response, terminate your entry with a pound sign.

f518 *a68,a101,a943,a961*

You are creating a voice message which will be delivered to the person specified in your message as soon as possible. Please be aware that in order to forward this message to the recipient, someone will listen to the name and number portion.

f519 *a628*

You are not authorized for outcalling.

f520 *a629,a630,a631,a632,a633*

Your outcalling number,

f521 *a618,a619,a630,a631,a632,a633*

turned on

f522 *a617,a629*

turned off to restart at the activity menu, press star 7.

f523 *a630,a631,a632,a633*

for

f524 *a22,a237,a625,a626,a631,a633,a656,a657,a758*

to

f525 *a624,a630,a632*
 any time

f526 *a624,a625,a626,a630,a631,a632,a633*
 subject to administrator restrictions

f527 *a28,a97,a108,a307,a629,a630,a631,a632,a633*
 To change number, press 1. To change times, press 2. For instructions on entering your outcalling number, press 3.

f528 *a28,a97,a108,a307,a629,a630,a631,a632,a633*
 To turn on, press 9. To turn off, press 6.

f529 *a28,a97,a108*
 You are changing your outcalling options.

f530 *a617,a618,a619*
 Outcalling

f531 *a621*
 Enter outcalling number

f532 *a620*
 To change your outcalling phone number, press 1 and enter the number to be called followed by the pound sign. Anything you enter will be interpreted as a part of the called number. No global commands such as star 4 will be accepted at this time.

f533 *a764*
 Too many digits.

f534 *a623*

 Your outcalling number is

f535 *a80,a106,a616*

 For outcalling any time, press 1. For outcalling during prime time, press 2. To specify your times, press 3. For system outcalling schedule, press 4.

f536 *a79,a80,a105,a106*

 You are specifying your outcalling time period. The time you specify will be restricted by the times allowed by the system administrator.

f537 *a734*

 Enter the starting hour and minutes, press 2 for A.M. or 7 for P.M., and pound sign.

f538 *a325*

 Enter the ending hour and minutes, press 2 for A.M. or 7 for P.M., and pound sign.

f539 *a758*

 The system allows outcalls from

f540 *a237*

 and from

f541 *a781*

 Up to

f542 *a781*

 digits may be used.

f543 *a53,a627*
 To avoid further notification of these messages, press star pound.

f544 *a624,a625,a626*
 Outcalling specified for

f545 *a79,a105*
 To delete own time, press star 3.

f546 *a825*
 pause

f548 *a582*
 You have no attendant menu.

f549 *a48,a99*
 You are administering your attendant menu. To create attendant menu, press 1.

f550 *a24,a96*
 To rewind your attendant menu, press 2. To delete it, press star 3. To stop playback of your attendant menu, press 3.

f551 *a53,a627*
 To access your messages,

f552 *a334,a335,a336*
 is not authorized to receive messages.

f553 *a335*
 You may enter another number

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f555 *a15,a17,a18,a101,a102,a103,a104*

To access your mailbox, press star 7.

f556 *a621,a1015*

To exit, press star pound now.

f557 *a620*

In most cases, entering a star or pound as the first digit will result in the star or pound being outpulsed. A star entered as part of the digit string will be interpreted as a pause of one and a half seconds. If a longer pause is required, use multiple stars in a row.

f560 *a620*

If you are programming a number to call a pager that requires a pound sign termination, press 9 to hear further help. Otherwise, press 6 to return to outcalling administration.

f561 *a6,a7,a912,a2151,a2152,a2154,a2155,a2171,a2172*

You are addressing your message.

f562 *a116,a117,a193,a194,a195,a196,a894,a932,a933,a2161, a2162,a2163,a2173,a2174,a2181,a2182,a2183,a2191, a2192,a2193,a2194*

Enter the

f563 *a116,a117,a193,a194,a195,a196,a932,a933,a2161, a2162,a2163,a2173,a2174,a2181,a2182,a2183,a2191, a2192,a2193,a2194*

digit extension

f565 *a309*

Outcall canceled for new messages currently in mailbox.

f566 *a53*

 You are responding to an outcall notifying you of new messages.

f567 *a53*

 Either logging in or pressing star pound will result in the outcall being canceled for the new messages currently in your mailbox. If additional new messages arrive, another outcall will be scheduled."

f569 *a697*

 To modify, press 1. If finished, press star pound.

f570 *a512,a883*

 Recorded name too long

f571 *a610*

 Non-existent subscriber

f575 *a590*

 Cannot forward a private message

f577 *a118,a122,a124,a924,a925,a926,a927,a1157,a1158, a1159,a1172,a1173,a2068,a2069,a2070*

 To hold the message in its current category, press star star 4

f578 *a924,a925,a926,a927,a928,a929,a930,a1157,a1158, a1159,a1172,a1173,a1182,a2068,a2069,a2070,a2072, a2073*

 To skip to the next category, press star pound.

f579 *a443,a444*

 Password must be

f580 *a250,a251*

 Cannot attach a private message

f581 *a251*

 Press 6 now

f582 *a514*

 AUDIX passwords must now be at least

f584 *a643,a644,a743*

 Message not delivered because special feature denied on recipients machine.

f585 *a873,a1009,a1011,a1037*

 Zero

f587 *a42*

 You are reviewing a list.

f588 *a514*

 or more digits.

f589 *a622*

 For pagers requiring a pound sign termination, start your number with a double pound sign. This will result in a single pound being outpulsed at the end of the digit string. Then, a star or pound in the next position will be interpreted as part of the outcalling number.

f590 *a622*

 A star entered as part of the digit string will be interpreted as a pause of one and a half seconds. If a longer pause is required, use multiple stars in a row.

f591 *a52*

 To change your outcalling phone number, press 1. To hear further instructions on programming a pager, press 9. To return to outcalling administration, press 6.

f592 *a199*

 AUDIX passwords must now be

f593 *a199,a514*

 Please choose a new password of

f600 *a557*

 new Broadcast messages.

f601 *a183,a184,a190,a235,a875,a1169,a2006,a2010*

 Priority

f602 *a210,a236,a273,a342,a343,a344,a345,a493,a673,a675, a767,a838,a840,a841,a2011,a2018,a2019,a2020,a2021, a2022,a2035,a2036,a2041,a2046,a2047,a2048*

 other

f603 *a538,a540,a541,a543,a545,a549,a551,a553,a555*

 You also have

f604 *a690*

As you use AUDIX your name will be included in system announcements that you and other people will hear. Press 1, and at the tone, please speak your name. After speaking your name, press 1 again.

f606 *a241*

To re-record your name, press 1. To approve, press pound.

f607 *a650*

Name cannot be saved at this time, please continue

f608 *a167,a599,a692,a883*

At the tone, please speak your name. After speaking your name, press 1.

f609 *a583*

No room to save Broadcast message so it will be retained in the new message category.

f610 *a150*

You are recording your name. After you record your name, you can access other AUDIX features. As you use AUDIX your name will be included in system announcements that you and other people will hear. Press 1 and at the tone, please speak your first and last name as you would like others to hear it. After speaking your name, press 1 again.

f611 *a151*
 You are recording your name. To record your name, press 1. After recording, press 1 again. To playback name, press 2-3. To approve, press pound.

f612 *a149,a519*
 To make private, press 1.

f613 *a518,a1149*
 To make priority, press 2.

f614 *a515*
 To make broadcast, press 8.

f615 *a516*
 To make a login announcement, press 9.

f617 *a705,a919*
 To remove private status, press 1.

f618 *a704,a1165*
 To remove priority status, press 2.

f619 *a700*
 To remove broadcast status, press 8.

f620 *a701*
 To remove login announcement status, press 9.

f622 *a876*
 not Priority.

f623 *a275*
 Broadcast.

f624 *a495*
 Login announcement.

f625 *a208,a831,a833*
 To activate message waiting notification, press 1.

f626 *a143,a146,a731,a732,a831,a832,a833*
 To specify expiration date, press 2.

f627 *a239,a832,a833*
 To approve broadcast options, press pound.

f628 *a146,a311,a832*
 To deactivate message waiting notification, press 1.

f629 *a716*
 Please enter month, day, and pound sign.

f630 *a303*
 To change expiration date from

f631 *a227,a536*
 Message waiting notification activated.

f632 *a227,a333*
 Expiration date will be

f633 *a517*
 To make non-interruptible, press 1.

f634 *a240,a732*
 To approve login announcement options, press pound.

f635 *a702*
 To remove non-interruptible status, press 1.

f636 *a564*
 Login announcement will be non-interruptible.

f637 *a438,a439,a440*
 Invalid date.

f638 *a440*
 is prior to delivery date, please re-schedule.

f639 *a260*
 Message cannot be both broadcast and priority.

f640 *a256*
 **Message cannot be both a login announcement
and priority.**

f641 *a257*
 **Message cannot be both a login announcement
and private.**

f642 *a259*
 **Message cannot be both broadcast and a login
announcement**

f643 *a149*
 **You are choosing options for this message.
There are no options currently set.**

f644 *a155*
 **You are choosing options for this message.
With the current settings,**

f645 *a145,a149*
 Private messages cannot be forwarded by the recipients.

f646 *a144,a1166*
 A priority message will be delivered before other messages and will be flagged for special attention in the recipient's mailbox.

f647 *a842*
 the message will be private.

f648 *a156*
 the message will be priority.

f649 *a135*
 the message will be broadcast.

f650 *a139*
 the message will be a login announcement.

f651 *a164*
 the message will be private and priority.

f652 *a140*
 A broadcast message is delivered to every subscriber on this machine. You may also address a broadcast message to subscribers on other machines.

f653 *a274*
 For broadcast options, press star 6.

f654 *a134*
 the message will be broadcast and private.

f655 *a141*

 A login announcement will be played each time any subscriber logs onto this machine. You may also address a login message to subscribers on other machines.

f656 *a494*

 For login announcement options, press star 6.

f657 *a133*

 You are choosing options for this broadcast message.

f658 *a831*

 Message waiting notification is currently not active.

f659 *a130,a146,a831*

 Message waiting notification will alert all local subscribers of this message. This option should be used sparingly, for it can impact system performance.

f660 *a160,a161*

 Expiration date specifies the last day this broadcast message will be available to subscribers. The expiration date does not apply to a broadcast message already received by a subscriber and saved in their mailbox. The default expiration date is the second day after the scheduled delivery date.

f661 *a143,a160,a163*

 To approve these options, press pound.

f662 *a146*
 Message waiting notification is active.

f663 *a110*
 Message waiting notification is not active and
this message has an expiration date of.

f664 *a112*
 Message waiting notification is active and
this message has an expiration date of.

f665 *a138*
 You are choosing options for this login
announcement.

f666 *a148*
 With the current settings, this login
announcement will be non-interruptible.

f668 *a111*
 With the current settings, this login
announcement will be non-interruptible and the
login announcement has an expiration date of.

f669 *a109*
 With the current settings, this login
announcement will be interruptible and the
login announcement has an expiration date of.

f670 *a142,a143*
 Non-interruptible status forces each
subscriber to listen to the entire login
announcement every time they log onto this
machine.

f671 *a143,a163*
 Expiration date specifies the last day this login announcement will be available to subscribers. The default expiration date is the second day after the scheduled delivery date.

f674 *a729,a931*
 Due to sending restrictions, you cannot send messages to

f678 *a439*
 is past the expiration date, please reschedule.

f679 *a182,a293*
 is not available. Sorry, you cannot leave a message now because this user's mailbox is full.

f680 *a177,a288*
 is busy. Sorry, you cannot leave a message now because this user's mailbox is full.

f681 *a647*
 Sorry, cannot leave a message now because this user's mailbox is full.

f682 *a269,a270,a271,a272*
 Broadcast message from

f683 *a268*
 Broadcaster has deleted this broadcast message.

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f684 *a355,a356,a357,a358*
 Private, broadcast message from

f685 *a676,a677,a678,a679*
 Private, priority message from

f686 *a663,a664,a665,a666*
 Private message from

f687 *a779*
 Undeliverable message notification received

f688 *a778*
 An undeliverable message was returned to your outgoing mailbox. To access your outgoing mailbox, press star 7-4.

f689 *a270,a272,a356,a358,a490,a492,a638,a640,a642,a644,*
a664,a666,a669,a671,a677,a679,a737,a746,a809,a811,
a2015,a2017,a2024,a2026,a2028,a2030,a2032,a2034,
a2038,a2040,a2043,a2045
 Expiration time is

f690 *a668,a669,a670,a671*
 Priority message from

f691 *a489,a490,a491,a492*
 Login announcement from

f693 *a273*
 Broadcast message to all local subscribers

f694 *a675*
 Private, broadcast message to all local subscribers

f695 *a344,a767*
 Private, priority message to

f696 *a343,a840,a841*
 Private message to

f697 *a493*
 Login announcement to all local subscribers

f698 *a345,a673*
 Priority message to

f699 *a739*
 Message not delivered because another login announcement is active.

f700 *a165,a166,a755,a756,a2089,a2090,a2091,a2092*
 To administer mailing lists, press 1. To administer personal directory, press 2.

f701 *a165,a166,a755,a756,a2089,a2090,a2091,a2092*
 To change your password, press 4.

f702 *a166,a756,a2090,a2092*
 To record your name, press 5.

f703 *a165,a166,a2089,a2090*
 You are at subscriber administration.

f704 *a503*
 To create lists, press 1. To scan lists, press 2. To review and modify lists, press 3.

f705 *a320*
 Directory contains

f706 *a136,a319*
 To add entries, press 1. To review all
entries, press 2. To review a specific entry,
press 3.

f707 *a74,a525*
 If finished, press star pound.

f708 *a215,a216,a330,a331,a2185*
 If finished adding entries, press pound.

f709 *a234*
 Enter alias for

f710 *a331,a860*
 Enter next name and pound sign.

f711 *a224,a225,a226,a228,a229,a917*
 Alias

f712 *a224,a225,a226,a228,a917*
 defined for

f713 *a330*
 Enter next extension and pound sign.

f714 *a587*
 Directory has no entries.

f715 *a360,a361*
 Cannot add new entries because your directory
is full.

f716 *a231,a232*
 Alias must be ten or fewer numerals.

f717 *a233*
 Alias already defined.

f718 *a653*
 Name entered not followed by pound and not added to the directory.

f719 *a652*
 Extension entered not followed by pound and not added to the directory.

f720 *a651*
 Alias entered not followed by pound and not added to the directory.

f722 *a188,a361*
 was not added to your personal directory.

f723 *a136*
 You are administering your personal directory.

f724 *a321*
 Personal directory review completed.

f725 *a131,a132,a2184*
 You are adding entries to your personal directory.

f726 *a157*
 You are reviewing all entries in your personal directory.

f727 *a232,a327,a328,a329,a2188*
 Enter alias and pound sign.

f729 *a158*
 You are reviewing a specific entry in your personal directory. To delete the current entry, press star 3. To review another entry, enter the alias followed by the pound sign.

f730 *a738*
 Message not delivered because the broadcast mailbox was not defined.

f736 *a167*
 You are recording your name. As you use AUDIX your name will be included in system announcements that you and other people will hear.

f737 *a434*
 Login announcement will be interruptible.

f738 *a740*
 Message not delivered due to sending restrictions.

f739 *a342*
 Message sent to all local subscribers.

f740 *a343*
 Private message sent to all local subscribers.

f741 *a344*
 Private, priority message sent to

f742 *a840*
 Private message sent to

f743 *a345*
 Priority message sent to

f744 *a230*
 For all calls,...

f745 *a1,a230,a278,a339,a350,a351,a352,a353,a411,a412,*
a413,a414,a415,a416,a417,a418,a419,a420,a421,a422,
a423,a424,a433,a579,a645
 active.

f747 *a433*
 For internal calls,...

f748 *a339*
 For external calls,...

f749 *a278*
 For busy calls,...

f750 *a579*
 For no answer calls,...

f751 *a645*
 For out-of-hours calls,...

f752 *a425*
 To listen to a greeting, press 0. To create, change, or delete a greeting, press 1. To scan all your greetings, press 2. To activate a greeting, press 3. To administer call types, press 4. If finished, press pound.

f753 *a35,a36,a428*
 Enter greeting number.

f754 *a88,a230,a278,a339,a350,a351,a352,a353,a365,a366,*
a367,a368,a369,a370,a371,a372,a373,a374,a375,a376,
a377,a378,a379,a380,a381,a382,a383,a384,a385,a386,
a387,a388,a389,a390,a391,a392,a393,a394,a395,a396,
a397,a398,a399,a400,a401,a402,a403,a404,a405,a406,
a407,a408,a409,a410,a411,a412,a413,a414,a415,a416,
a417,a418,a419,a420,a421,a422,a423,a424,a433,a579,
a645,a830

 Greeting

f755 *a395*

 not recorded.

f756 *a74,a426,a427,a525*

 To listen to greeting

f757 *a429,a430,a1124*

 To re-record, press 1.

f759 *a430*

 To review status, press 2.

f760 *a74,a426,a427,a525*

 press 0.

f762 *a303*

 press 2.

f764 *a787,a788,a828*

 **To use this greeting for all calls, press 0.
For internal calls, press 1. For external
calls, press 2.**

f765 *a396*

 recorded, but not active

f766 *a88,a783*

 To use this greeting for all calls, press 1.

f767 *a785,a786,a829*
 To use this greeting for all calls, press 0. For busy calls, press 1. For no answer calls, press 2.

f770 *a397,a398,a399,a400,a401,a402,a403,a404,a405,a406, a407,a408,a409,a410*
 recorded and active

f771 *a365,a366,a367,a368,a369,a370,a371,a372,a373,a374, a375,a376,a377,a378*
 approved and active

f772 *a426*
 again

f773 *a828,a829*
 To activate for out-of-hours calls, press 3.

f774 *a143,a160,a161,a163,a341,a980*
 If you have addressed this message and wish to deliver it immediately, press star star pound.

f775 *a728*
 To record messages, press 1. To get messages, press 2. To administer personal greetings, press 3.

f776 *a1,a230,a278,a339,a350,a351,a352,a353,a433,a579, a645*
 the system greeting

f777 *a522*
 Cannot listen to system greeting.

f778 *a523*

 Cannot modify system greeting.

f779 *a596*

 No greetings recorded.

f780 *a524*

 Personal greetings review completed.

f781 *a74,a525*

 To skip to the next greeting, press the pound sign.

f782 *a789*

 To activate a greeting, enter greeting number. To deactivate a greeting, activate a different greeting in its place.

f783 *a784*

 To activate another greeting, enter greeting number. To deactivate a greeting, activate a different greeting in its place.

f784 *a784,a789*

 To activate system greeting, enter zero.

f785 *a23,a710,a711*

 Same greeting used for all calls.

f786 *a23,a711*

 To identify calls as internal and external, press 1.

f787 *a23,a711*

 To identify calls as busy and no answer, press 2.

f788 *a22,a432,a657*
  To identify calls as out-of-hours, press 3.

f789 *a22,a657*
  Otherwise, press 4.

f790 *a244,a245*
  Calls identified as internal and external.

f791 *a242,a243*
  Calls identified as busy and no answer.

f792 *a242,a244*
  Calls identified as out-of-hours.

f793 *a243,a245*
  Calls not identified as out-of-hours.

f794 *a300*
  To change identification to busy and no
answer, press 2.

f795 *a304*
  To change to identification internal and
external, press 1.

f796 *a703*
  To remove out-of-hours identification, press
4.

f797 *a791*
  To use same greeting for all calls, press 5.

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f798 *a22,a656,a657*

 Prime time is

f800 *a161*

 You are specifying the expiration date.

f801 *a314*

 To respond to this notification, press 1. To delete, press star 3. To skip, press pound.

f802 *a707*

 Cannot send a message to the broadcast mailbox.

f805 *a352,a353*

 For internal...

f807 *a350,a351*

 For busy...

f810 *a352,a353,a372,a375,a387,a390,a404,a407,a418,a421, a800,a803*

 external

f812 *a350,a351,a366,a369,a381,a384,a398,a401,a412,a415, a794,a797*

 no answer

f813 *a351,a353,a367,a369,a370,a373,a375,a376,a382,a384, a385,a388,a390,a391,a399,a401,a402,a405,a407,a408, a413,a415,a416,a419,a421,a422,a795,a797,a798,a801, a803,a804*

 and out-of-hours

f814 *a350,a351,a352,a353,a366,a367,a368,a369,a370,a371,*
a372,a373,a374,a375,a376,a377,a378,a381,a382,a383,
a384,a385,a386,a387,a388,a389,a390,a391,a392,a393,
a398,a399,a400,a401,a402,a403,a404,a405,a406,a407,
a408,a409,a410,a412,a413,a414,a415,a416,a417,a418,
a419,a420,a421,a422,a423,a424,a794,a795,a796,a797,
a798,a799,a800,a801,a802,a803,a804,a805,a806
 calls.

f815 *a46*
 You are administering your personal greetings.

f816 *a35*
 You are listening to a personal greeting.

f817 *a36*
 You are recording a personal greeting.

f818 *a88,a830*
 You have just recorded

f819 *a74*
 You are scanning your personal greetings.

f820 *a37*
 You are selecting which greeting to activate.

f821 *a21,a22,a23*
 You are administering call types.

f822 *a174*
 As you use AUDIX your name will be included in system announcements that you and other people will hear. At the tone, please speak your name. After speaking your name, press 1.

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f823 *a1,a365,a380,a397,a411,a793*

 ...for all calls

f825 *a372,a373,a374,a375,a387,a388,a389,a390,a404,a405,*
a406,a407,a418,a419,a420,a421,a800,a801,a802,a803

 ...for internal

f826 *a370,a371,a385,a386,a402,a403,a416,a417,a798,a799*

 ...for external

f827 *a366,a367,a368,a369,a381,a382,a383,a384,a398,a399,*
a400,a401,a412,a413,a414,a415,a794,a795,a796,a797

 ...for busy

f828 *a376,a377,a391,a392,a408,a409,a422,a423,a804,a805*

 ...for no answer

f829 *a378,a393,a410,a424,a806*

 ...for out-of-hours

f830 *a560*

 You must approve your recording.

f831 *a161*

 To exit the expiration date options, press star pound.

f832 *a131,a215,a859,a2184,a2189*

 Please enter extension and pound sign.

f833 *a131,a132,a327,a328,a895,a2184,a2188*

 To delete current entry, press star 3.

f835 *a618,a630,a631*

 for all new messages

f836 *a619,a632,a633*
  only for new priority messages

f837 *a634*
  To turn on Outcalling for all new messages,
press 1. To turn on outcalling only for new
priority messages, press 2.

f838 *a153*
  You are selecting which messages will receive
outcalls.

f839 *a74*
  To rewind to the previous greeting, press 2.

f840 *a636*
  Option

f841 *a337,a636*
  not defined

f842 *a565*
  Announcement not recorded. Try again later.

f843 *a254,a837*
  To scan headers and messages, press 1. To scan
headers only, press 2. To scan messages only,
press 3.

f844 *a529*
  End of message.

f845 *a558*
  Next message.

f846 *a837*

  You are selecting an option for Automatic
Message Scan.

f847 *a118,a927,a1159,a1173,a2070*

  You are automatically scanning your incoming
messages. To listen to the message, press
zero. To respond to or forward the message,
press 1.

f848 *a122,a925,a1159,a1173,a2070*

  You are automatically scanning your incoming
messages. To listen to the message, press
zero. To respond to the message, press 1.

f849 *a118,a122,a1159,a1173,a2070*

  To skip to the next message, press the pound
sign. To listen to the header, rewind by
pressing 2, then play by pressing 3. To skip to
the next category, press star pound.

f850 *a563*

  Broadcast and Login Message services are not
available.

f852 *a157*

  To rewind to the current entry, press 2. To
rewind to previous entries, press 2 as many
times as necessary.

f853 *a962*

  Messages skipped, retained as new.

f854 *a882*

  seconds to finish recording.

f855 *a894,a895*
 remote AMIS mailbox id

f856 *a892,a893*
This is a recorded message from

f858 *a907*
 To replay, press 0.

f859 *a909*
 Mailbox id not followed by pound.

f860 *a910*
 Mailbox id not valid.

f861 *a886,a915,a931*
  AMIS

f862 *a896*
 It could not be delivered because the
recipient appears to be a wrong number.

f863 *a897*
 It could not be delivered after multiple
attempts to deliver the message.

f864 *a898*
 Automated call, please press 1 to disconnect.

f865 *a899*
 Your number was dialed by mistake. We are
sorry for this inconvenience. To prevent this
from recurring, this call has been reported as
a misdialed call.

f866 *a911*
 AMIS casual subscribers cannot be added to
your list.

f867 *a895*
 You are entering the

f868 *a895,a912,a2151,a2152*
 Mailbox id must be less than or equal to 16
digits.

f869 *a912,a2151,a2152*
 If the extension entered belongs to a casual
AMIS subscriber, you will be prompted for a
mailbox id.

f900 *a855*
123 Standard US English

f901 *a856*
 Announcement set does not exist

f902 *a857*
 Announcement set

f903 *a1190*
 <.1 second pause>

f904 *a1191*
 <.2 second pause>

f905 *a269,a270,a271,a272,a355,a356,a357,a358,a489,a490,*
a491,a492,a663,a664,a665,a666,a676,a677,a678,a679,
a718,a719,a808,a809,a810,a811,a964,a965,a1010,
a1150,a1151,a1170,a1171,a1192,a2014,a2015,a2016,
a2017,a2023,a2024,a2025,a2026,a2027,a2028,a2029,
a2030,a2031,a2032,a2033,a2034,a2037,a2038,a2039,
a2040,a2042,a2043,a2044,a2045,a2049,a2054

 <.5 second pause>

f906 *a858,a1193*

 <1.0 second pause>

f907 *a1194*

 <2.0 second pause>

f908 *a1144,a1195*

 <5.0 second pause>

f909 *a858*

 Announcement

f910 *a92,a305,a306,a859,a860,a861,a863,a2189*

 You are playing an announcement which need additional input before it can be played.

f911 *a301,a305*

 Enter buttons followed by pound.

f912 *a302,a306*

 Enter number followed by pound.

f913 *a35,a36,a88,a131,a132,a136,a319,a327,a328,a329,*
a429,a430,a783,a784,a786,a788,a789,a791,a828,a829,
a1137,a2184,a2188

 If finished, press pound.

f914 *a864*

 not filed.

f915 *a865*
 No options menu available.

f916 *a154*
To send message, press pound or enter an
option, to hear a list of options, press zero.

f917 *a277*
 To schedule delivery, press 3.

f918 *a667*
 To re-schedule delivery, press 3.

f919 *a672*
 To file a copy, press 4.

f920 *a748*
 To not file a copy, press 4.

f921 *a868*
 To make private, press 1. To send, press #.

f922 *a869*
 To access the Delivery Options Menu, press #
after recording your message.

f923 *a870*
 Press # to approve your message and access the
Delivery Options Menu

f924 *a873,a972*
 seconds

f925 *a873*
 minutes

f926 *a871,a2000,a2067,a2099,a2169,a2170*
 <error sound>

f928 *a556*
 New Messages

f929 *a635*
 Old Messages

f930 *a207*
 Accessed Messages

f931 *a313*
 Delivered Messages

f932 *a347*
 Filed Messages

f933 *a776*
 Undeliverable Messages

f934 *a777*
 Undelivered Messages

f935 *a780*
 Unopened Messages

f936 *a2*
 Partial entry deleted.

f937 *a872*
 **Sorry you are having difficulty. Please get
help and try again later.**

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f938 *a905*

 first

f939 *NONE*

 second

f940 *NONE*

 third

f941 *NONE*

 fourth

f942 *NONE*

 fifth

f943 *NONE*

 sixth

f944 *NONE*

 seventh

f945 *NONE*

 eighth

f946 *NONE*

 ninth

f947 *NONE*

 tenth

f948 *NONE*

 eleventh

f949 *NONE*

 twelfth

f950 *NONE*
  thirteenth

f951 *NONE*
  fourteenth

f952 *NONE*
  fifteenth

f953 *NONE*
  sixteenth

f954 *NONE*
  seventeenth

f955 *NONE*
  eighteenth

f956 *NONE*
  nineteenth

f957 *NONE*
  twentieth

f958 *NONE*
  twenty-first

f959 *NONE*
  twenty-second

f960 *NONE*
  twenty-third

f961 *NONE*
  twenty-fourth

f962 *NONE*
  twenty-fifth

f963 *NONE*
  twenty-sixth

f964 *NONE*
  twenty-seventh

f965 *NONE*
  twenty-eighth

f966 *NONE*
  twenty-ninth

f967 *NONE*
  thirtieth

f968 *NONE*
  thirty-first

f969 *a867*
  You are choosing between announcement sets whose names match your entry. To indicate no announcement sets match, delete entry by pressing star 3.

f970 *a476*
  To continue reviewing, press 3. To delete an entry, press star 3. If finished reviewing, press pound.

f971 *a340,a341,a919,a985*
  To send, press #.

f972 *a921,a956*
 To reach the covering extension, press zero.

f973 *a285,a920,a921,a955,a956,a1185*
If you are finished, please hang up, or press
star, star 9.

f974 *a922*
 Not broadcast.

f975 *a923*
 Not login announcement.

f977 *a752*
Name not found.

f978 *a886*
unknown

f979 *a878,a880*
After recording, press 1 again

f980 *a878,a880*
To record from here, press 1

f981 *a974*
Message not delivered because it was longer
than the 8 minute AMIS message limit.

f983 *a76,a127*
 To record and send voice mail messages, press
1. To get messages, press 2. To record or
change the greeting heard by callers, press 3.

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f984 *a77,a114,a120*

To record and send voice mail messages, press 1. To get messages, press 2. To administer attendant menu, press 3.

f985 *a119,a125,a129*

To record and send voice mail messages, press 1. To get messages, press 2.

f986 *a115,a121,a159*

To record and send voice mail messages, press 1. To get messages, press 2. To record or change the greetings heard by callers, press 3.

f987 *a171,a172,a936,a937,a2166,a2176,a2178,a2180*

Enter last name of the person

f988 *a990*

To send only a fax, press pound.

f989 *NONE*

Otherwise, when finished recording, press pound to approve, or 1 to edit your message.

f990 *a76,a77,a113,a114,a115,a119,a120,a121,a125,a127, a129,a159,a2077,a2078,a2079,a2080,a2081,a2082, a2083,a2084,a2085,a2086,a2087,a2088*

To record and send voice mail messages, press 1.

f991 *a76,a77,a113,a114,a115,a119,a120,a121,a125,a127, a129,a159,a2077,a2078,a2079,a2080,a2081,a2082, a2083,a2084,a2085,a2086,a2087,a2088*

To record and send voice mail or fax messages, press 1.

f992 *a76,a77,a113,a114,a115,a119,a120,a121,a125,a127,
a129,a159,a2077,a2078,a2079,a2080,a2081,a2082,
a2083,a2084,a2085,a2086,a2087,a2088*
To get messages, press 2.

f993 *a1170*
Private, priority fax call from

f994 *a1170*
Private, priority voice and fax call from

f995 *a1170*
Private fax call from

f996 *a76,a77,a113,a114,a115,a119,a120,a121,a125,a127,
a129,a159,a2077,a2078,a2079,a2080,a2081,a2082,
a2083,a2084,a2085,a2086,a2087,a2088*
To check your outgoing messages, press 4.

f997 *a1174*
**To administer mailing list, personal directory,
password, or account name, press 5.**

f998 *a1170*
Private voice and fax call from

f999 *a1174*
**To administer mailing list, personal directory,
password, fax options, or account name, press
5.**

f1000 *a973,a1170*
Priority fax call from

f1001 *a76,a77,a113,a114,a115,a119,a120,a121,a125,a127,
a129,a159,a2077,a2078,a2079,a2080,a2081,a2082,
a2083,a2084,a2085,a2086,a2087,a2088*

**To change outcalling information, press 6. To
scan incoming messages automatically, press 7.
To re-logon, press star star 7.**

f1002 *a154*

To hear a list of options, press 0.

f1003 *a1170*

Priority voice and fax call from

f1004 *a49,a68,a101,a943,a961,a992*

**To bypass voice recording and create a fax only
message, press pound.**

f1005 *a154*

**Load your document into the FAX machine. To
send, press pound or enter an option.**

f1006 *a76,a115,a121,a127,a159,a2077,a2081,a2084,a2086,
a2088*

**To record or change the greeting heard by
callers, press 3.**

f1007 *a310,a812,a2059*

To playback, press 2-3.

f1008 *a988*

To include a fax, press 5.

f1009 *a989*

To no longer include a fax, press 5.

f1010 *a1167,a1168,a2007,a2009*

with priority.

f1011 *a185,a235,a236,a1167,a1168,a1169,a2006,a2007,a2008,*
a2009,a2010,a2011
with fax.

f1012 *a907,a991*
Press START on your fax machine now.

f1013 *a77,a114,a120,a2078,a2080,a2083*
To administer attendant menu, press 3.

f1014 *a984*
Fax will be included.

f1015 *a983*
Fax will not be included.

f1016 *a113,a2079*
To administer your greeting, press 3.

f1017 *a987*
A login announcement must be voice only.

f1018 *a986*
**Load your document into the FAX machine, To
send, press pound.**

f1019 *a982,a1028*
Cannot replace or modify an existing fax.

f1020 *a981*
No message to send.

f1021 *a1171*
Private, priority fax call received

f1022 *a1171*
Private, priority voice and fax call received

f1023 *a1171*
Private fax call received

f1024 *a1171*
Private voice and fax call received

f1025 *a1171*
Priority fax call received

f1026 *a1171*
Priority voice and fax call received

f1027 *a1171*
Fax call received

f1028 *a1009,a1011,a1012,a1037,a1188,a2055,a2102*
page.

f1029 *a1009,a1011,a1012,a1037,a1188,a2055,a2102*
pages.

f1030 *a1171*
Voice and fax call received

f1031 *a993,a1031,a1039*
A fax must be addressed before it can be created.

f1032 *a979*
Subscriber cannot receive fax.

f1033 *a1003*
Cannot print a delivered message.

f1034 *a1004*
Cannot get your messages now, due to an active print request.

f1035 *a1002*
Message delivered, cannot print a delivered message.

f1036 *a1173*
You are automatically scanning your incoming messages.

f1037 *a1173*
To respond to the message, press one.

f1038 *a86,a928,a2072,a2074*
To re-record message before delivery, press one.

f1039 *a73,a346,a507,a929,a2060,a2061,a2071,a2073*
To change or send again, press one.

f1040 *a254,a837*
To print all new faxes, press 4.

f1041 *a1005*
There are no new faxes.

f1042 *a1005*
Private fax messages will not be printed, no other faxes to print.

f1043 *a1005*
Private fax messages will not be printed, print scheduled for all other faxes.

f1044 *a892*
This is a fax message from

f1045 *a892*
This is a voice and fax message from

f1046 *a907*
This is a fax message.

f1047 *a907*
To print

f1048 *a1013,a2067*
Nothing to print.

f1049 *a1011,a1012,a1037,a1188*
Fax of

f1050 *a1012,a1188*
Message does not contain voice.

f1051 *a1014*
Voice and fax message.

f1052 *a165,a166,a755,a756,a2089,a2090,a2091,a2092*
To specify your fax preferences, press 3.

f1053 *a1006*
Fax not enabled for your mailbox, for help press star 4.

f1054 *a1170*
Fax call from

f1055 *a1170*
Voice and fax call from

f1056 *a1007*
System not administered for fax.

f1057 *a668,a669,a670,a671*
Priority fax message from

f1058 *a668,a669,a670,a671*
Priority voice and fax message from

f1059 *a676,a677,a678,a679*
Private, priority fax message from

f1060 *a676,a677,a678,a679*
Private, priority voice and fax message from

f1061 *a1008,a1016*
Your default print destination is...

f1062 *a355,a356,a357,a358*
Private broadcast fax message from

f1063 *a355,a356,a357,a358*
Private broadcast voice and fax message from

f1065 *a269,a270,a271,a272*
Broadcast fax message from

f1066 *a269,a270,a271,a272*
Broadcast voice and fax message from

f1068 *a663,a664,a665,a666*

Private fax message from

f1069 *a663,a664,a665,a666*

Private voice and fax message from

f1071 *a808,a809,a810,a811*

Fax message from

f1072 *a808,a809,a810,a811*

Voice and fax message from

f1073 *a73,a86,a192,a276,a310,a346,a507,a508,a527,a530,*
a892,a928,a929,a1011,a1012,a1027,a1158,a1172,a1173,
a2057,a2058,a2059,a2060,a2061,a2062,a2063,a2064,
a2065,a2066,a2068,a2069,a2070,a2071,a2072,a2073,
a2074

To print, press star 1.

f1075 *a1008,a1018*

**To change the default print destination, press
1.**

f1076 *a1008,a1018,a1024*

**To have your faxes printed automatically, press
9 for Yes.**

f1077 *a1008,a1018,a1024*

**To cancel automatic printing of your faxes,
press 6 for no.**

f1078 *a1008,a1018,a1024*

To change autodeletion option, press 9.

f1079 *a1015*

**Enter your default print destination followed
by the pound key.**

f1080 *a1017*
Invalid destination.

f1081 *a1020*
After a fax only message is printed automatically, should it also be deleted from your mailbox? Press 9 for yes or 6 for No.

f1082 *a1025*
To turn on autodeletion, press 9. To turn off, press 6.

f1083 *a1023*
You must enter a default print destination before autoprinting can be used.

f1084 *a1024*
You are changing your fax print options.

f1085 *a1024*
To change or add default print destination, press 1.

f1086 *a1024*
The default print destination is where documents are normally printed.

f1087 *a994,a995*
To print to destination...

f1088 *a994,a995*
press pound

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f1089 *a994*
To specify destination, enter digits followed by the pound key.

f1090 *a994,a995,a997*
To print on the fax machine from which you are calling, press star 6.

f1091 *a995*
You are specifying where your documents will be printed

f1092 *a995,a997,a1008*
A default print destination has not been assigned.

f1093 *a995*
To assign a default print destination press star 7, then 5-3.

f1094 *a995,a997*
To specify a default destination, enter digits then press the pound key.

f1095 *a995*
This destination will be used for the remainder of this call. When you hang up, your default destination will be restored.

f1096 *a995*
If you choose this option, the document will begin to print. You will not be able to access your mailbox while the document is printing. You will be able to call into your mailbox again after printing is complete.

f1097 *a996,a1005*
Print scheduled.

f1098 *a998*
To approve, press pound.

f1099 *a998*
**Or re-enter print destination number and pound
sign.**

f1100 *a999*
Invalid.

f1101 *a999*
**Re-enter print destination number and pound
sign.**

f1102 *a1000*
Too many print requests, try again later.

f1103 *a1001*
Fax extension for

f1104 *a978*
Print request to...

f1105 *NONE*
To print, press star 1.

f1106 *NONE*
To send fax, press pound.

f1108 *NONE*
When autoprinting is turned on, your non-private faxes are sent automatically to the default fax print number.

f1109 *a344,a767*
Private, priority fax message to

f1110 *a344,a767*
Private, priority voice and fax message to

f1111 *a1025*
You are in the autodeletion menu.

f1114 *a1025*
If autodeletion is turned on, fax only messages will be deleted after they are automatically printed.

f1115 *a345,a673*
Priority fax message to

f1116 *a345,a673*
Priority voice and fax message to

f1117 *a273,a342,a343,a675,a2018,a2019,a2020,a2036*
all local subscribers.

f1118 *a1026*
You are specifying the default print destination for fax items.

f1119 *a343,a840,a841*
Private fax message to

f1120 *a343,a840*
Private voice and fax message to

f1121 *a675*
Private broadcast message to

f1122 *a675*
Private broadcast fax message to

f1123 *a675*
Private broadcast voice and fax message to

f1124 *a1024,a1026*
When autoprinting is turned on, all non-private faxes that are received will automatically attempt to print at the default destination.

f1125 *a342,a838*
Fax message to

f1126 *a342,a838*
Voice and fax message to

f1127 *a273*
Broadcast message to

f1128 *a273*
Broadcast fax message to

f1129 *a273*
Broadcast voice and fax message to

f1130 *a1026*
This is also used as the default print destination when scanning fax messages.

f1132 *a841*
Private voice and fax message to

f1133 *a1026*
It must be a valid call delivery number.

f1134 *a1026*
**To enter destination, enter digits followed by
the pound key.**

f1135 *a1024*
**A default print destination must be assigned
before autoprinting can be used.**

f1136 *a1008,a1019,a1021,a1022*
Autoprinting is turned on.

f1137 *a1008,a1019*
Autoprinting is turned off.

f1138 *a1008,a1019,a1022*
Autodeletion is turned off.

f1139 *a1008,a1021*
Autodeletion is turned on.

f1140 *a279,a297*
**When finished you may attach a fax by pressing
pound.**

f1141 *a1175,a1176,a1177,a1178*
**When finished recording, press pound for more
options.**

f1143 *a1026*
The default print destination should be set to the destination where you normally send your documents for printing.

f1144 *a165,a166,a755,a756,a2089,a2090,a2091,a2092*
To specify whether a message can be addressed before it's recorded, press 6.

f1145 *a165,a166,a755,a756,a2089,a2090,a2091,a2092*
To administer call answer options, press 7.

f1146 *a1174*
To administer mailing list, personal directory, password, fax options, account name, addressing options, or call answer options, press 5.

f1147 *a1174*
To administer mailing list, personal directory, password, account name, or addressing options, press 5.

f1148 *a1174*
To administer mailing list, personal directory, password, fax options, account name, or addressing options, press 5.

f1149 *a1174*
To administer mailing list, personal directory, password, account name, or call answer options, press 5.

f1150 *a1174*

To administer mailing list, personal directory, password, fax options, account name, or call answer options, press 5.

f1151 *a1174*

To administer mailing list, personal directory, password, account name, addressing options, or call answer options, press 5.

f1152 *a1029,a1030,a1032*

Address Before Record turned on.

f1153 *a1029,a1032*

To turn off, press 1.

f1154 *a1029,a1030,a1032*

Address Before Record turned off.

f1155 *a1029,a1032*

To turn on, press 1.

f1157 *a1032*

You are administering Addressing options.

f1158 *a1033,a1035*

To prevent callers from leaving messages, press 1.

f1159 *a1033,a1034,a1035*

Call answer messages will not be accepted.

f1160 *a1033,a1035*

To allow callers to leave messages, press 1.

f1161 *a1035*
You are administering Call Answer options.

f1162 *a279,a504,a1038,a1175,a1176,a1177,a1178,a1185*
Sorry, the mailbox you have reached is not accepting messages at this time.

f1163 *a504,a1175,a1176,a1177,a1178*
is not available.

f1164 *a1033,a1034,a1035*
Call answer messages will be accepted.

f1165 *a76,a77,a113,a114,a115,a119,a120,a121,a125,a127,*
a129,a159,a2077,a2078,a2079,a2080,a2081,a2082,
a2083,a2084,a2085,a2086,a2087,a2088
To change outcalling information, press 6. To scan incoming messages automatically or print all new faxes, press 7. To re-logon, press Star Star 7.

f1166 *a1179*
Temporarily cannot access your messages. Processing your request to print all new faxes. Please try again"

f1167 *a1036*
Only 25 faxes printed.

f1168 *a1180*
Fax print all request to

f1169 *a1184*
Printing has completed.

f1263 *a1109*

Please enter more digits, or pound sign.

f1284 *a620*

In all cases, entering a star or pound as the first digit will result in the star or pound being outpulsed. A star entered as part of the digit string will be interpreted as a pause of one and a half seconds. If a longer pause is required, use multiple stars in a row.

f1285 *a620*

If you are programming a number to call a pager that requires a pound sign in or at the end of the digit string, press 9 to hear further help. Otherwise, press 6 to return to outcalling administration.

f1286 *a622*

Wherever a pound sign is required in the digit string, enter star pound. For pagers requiring a pound sign termination, end your digit string with star pound pound.

f1287 *a622*

If a pause is required before a pound sign, enter star star pound.

f1305 *a1112*

PLease enter an outcalling option. To hear a list of options, press 0.

f1400 *a1127*

For English press star 1.

f1401 *a1128*
Your primary greeting is in

f1402 *a1123,a1124*
To administer your primary greeting, press
pound.

f1403 *a1130*
Your secondary greeting is in

f1404 *a1121*
To administer this greeting, press 1.

f1405 *a1123,a1124*
To listen to your secondary greeting, press 0.

f1406 *a1123,a1124*
To listen to your primary greeting, press 0.

f1407 *a1123*
To record your primary greeting, press 1.

f1408 *a1122*
To administer this greeting, press 2.

f1409 *a1123*
To record your secondary greeting, press 1.

f1410 *a1123,a1124*
To administer your secondary greeting, press
pound.

f1411 *a1124*
To delete your primary greeting, and use the
system greeting press star 3.

f1412 *a1124*
To delete your secondary greeting, and use the system greeting, press star 3. .

f1413 *a1125*
Your new primary greeting is now active.

f1414 *a1125*
Your new secondary greeting is now active.

f1415 *a1126*
Recording deleted.

f1416 *a1126*
Your primary greeting has not changed.

f1417 *a1126*
Your secondary greeting has not changed.

f1418 *a1133*
You are administering your primary greeting.

f1419 *a1133*
You are administering your secondary greeting.

f1420 *a1132*
Callers will hear the greeting and receive instructions in the primary language unless they press star-1, in which case they will hear the greeting and receive instructions in the secondary language.

f1430 *a1134*
The following message was restored.

f1431 *a1135*
No message to restore.

f1432 *a1136*
To undelete last deleted message, press star
star 8.

f1433 *a1138*
The return address for this message is not a
valid extension.

f1434 *a62,a85,a123,a126,a128,a168,a169,a170,a1139,a1140,*
a1141,a1160,a1161
To return to getting messages, press pound.

f1436 *a1143*
English

f1437 *a1144*
<CHIMES - LIKE DOOR BELL>

f1438 *a1144*
Call for

f1439 *a1145*
<BEEP - LIKE CONF BRIDGE TONE>

f1440 *a1146*
<BEEP - LIKE RECORD AT TONE TONE>

f1441 *a1147*
<BEEP BEEP BEEP TONE - FOR OUT OF SPACE TONE>

f1442 *a1148*
<BEEP - LIKE EOM TONE BUT SOFTER>

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f1443 *a570*
Voice filesystem is out of space.

f1444 *a570*
Please contact the administrator.

f1445 *a1150,a1170*
Private, priority call from

f1446 *a1150,a1170*
Private call from

f1447 *a1150,a1170*
Priority call from

f1448 *a1151,a1171*
Private, priority call received

f1449 *a1151,a1171*
Private call received

f1450 *a1151,a1171*
Priority call received

f1451 *a1151,a1171*
Call received

f1452 *a622*
A star entered as part of the digit string will be interpreted as a pause of one and a half seconds.

f1453 *a1153*
Your password will expire in

f1454 *a1153*
days.

f1455 *a1153*
Your password will expire within one day.

f1456 *a1154*
Your password has expired.

f1457 *a1155*
Old and new passwords cannot be the same.

f1458 *a1156*
Password cannot be changed within

f1459 *a1156*
days of last change.

f1460 *a1156*
day of last change.

f1461 *a1157,a1158,a1172,a2068,a2069*
You are getting your incoming messages.

f1462 *a73,a86,a928,a929,a1157,a1158,a1172,a1173,a2068,*
a2069,a2071,a2072,a2073,a2074
To listen to the message, press 0.

f1463 *a192,a1158,a2057,a2069*
To reply to sender by voice mail, press 1, 7.

f1464 *a192,a1158,a2057,a2069*
To forward with comment, press 1, 2.

f1465 *a192,a1158,a2057,a2069*
To record a new message, press 1, 4.

f1466 *a1157,a1172,a1173,a2068*
To respond to or forward the message, press one.

f1467 *a1162*
The return address for this message is not a mailbox on this system.

f1468 *a1163*
The return address for this message is not a valid extension.

f1469 *a1160,a1161*
To reply to sender by voice mail, press 7.

f1470 *a1164*
No voice portion of message to playback.

f1471 *a622*
Up to 60 characters may be entered.

f1472 *a994,a995,a997,a999,a1015,a1026*
<.1 second pause, this fragment may be replaced with a customized recording which can be used to explain/state fax prefixes for printing.>

f1900 *a1903,a1911,a1912*
Call to...

f1901 *a1903*
Fax call to...

f1902 *a1903*
Voice and fax call to...

f1903 *a1904*
Private call to...

f1904 *a1904*
Private fax call to...

f1905 *a1904*
Private voice and fax call to...

f1906 *a1905*
Priority call to...

f1907 *a1905*
Priority fax call to...

f1908 *a1905*
Priority voice and fax call to...

f1909 *a1906*
Private, priority call to...

f1910 *a1906*
Private, priority fax call to...

f1911 *a1906*
Private, priority voice and fax call to...

f1912 *a1907,a1913*
Message to...

f1913 *a1907*
Fax message to...

f1914 *a1907*
Voice and fax message to...

f1915 *a1908*
Private message to...

f1916 *a1908*
Private fax message to...

f1917 *a1908*
Private voice and fax message to...

f1918 *a1909*
Priority message to...

f1919 *a1909*
Priority fax message to...

f1920 *a1909*
Priority voice and fax message to...

f1921 *a1910*
Private, priority message to...

f1922 *a1910*
Private, priority fax message to...

f1923 *a1910*
Private, priority voice and fax message to...

f1924 *a1900,a1902,a1911,a1913*
...from...

f1925 *a1914*
 # this is a blank fragment which can be recorded by # the customer, for use as a disclaimer announcement

f1999 *NONE*
Message does not contain voice.

f2000 *a2012*
<ERROR TONE - Missing Component>

f2001 *a2000*
**One or more components of this multimedia
message could not be delivered. Please contact
the sender.**

f2002 *a2001*
**Message not delivered because it contained 1 or
more media types that the recipient's machine
is unable to process.**

f2003 *a2002*
**Message not delivered because it is too long
for the recipient's machine.**

f2004 *a2103*
**Message receipt notification: the complete
message was delivered to you on an associated
system. To play the message header, press 2-3.**

f2005 *a2104*
**Header only message. No part of the original
message is missing.   To play the message
header, press 2-3.**

f2006 *a2005*
**Message not delivered because private messages
cannot be sent to the recipient's machine.**

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f2007 *a2006,a2007,a2008,a2009,a2010,a2011*
with text.

f2008 *a2006,a2007,a2008,a2009,a2010,a2011*
with other media

f2009 *a2013*
Incomplete...

f2010 *a2051*
zero

f2011 *a2051*
bytes

f2012 *a2051*
byte

f2013 *a2052*
kilobyte

f2014 *a2052*
kilobytes

f2015 *a2053*
megabyte

f2016 *a2053*
megabytes

f2017 *a2014,a2015,a2016,a2017,a2018*
Broadcast...

f2018 *a2101*
...and...

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f2019 *a2014,a2015,a2016,a2017,a2023,a2024,a2025,a2026,*
a2027,a2028,a2029,a2030,a2031,a2032,a2033,a2034,
a2037,a2038,a2039,a2040,a2042,a2043,a2044,a2045,
a2065

...message from...

f2020 *a2018,a2019,a2020,a2021,a2022,a2035,a2036,a2041,*
a2046,a2047,a2048

...message to...

f2021 *a1911,a1912,a1913,a2020,a2027,a2028,a2029,a2030,*
a2047,a2048,a2049,a2054

Private...

f2022 *a1911,a1912,a1913,a2021,a2037,a2038,a2039,a2040,*
a2041

Private, priority...

f2023 *a1911,a1912,a1913,a2022,a2031,a2032,a2033,a2034,*
a2035,a2049,a2054

Priority...

f2024 *a2023,a2024,a2025,a2026,a2036*
Private, broadcast...

f2025 *a2049*
...call from...

f2026 *a2054*
...call received...

f2027 *a2055*
Text of...

f2028 *a2056*
Binary file of...

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f2029 *NONE*

This is a...

f2030 *a2075,a2095,a2096,a2097,a2101*

...voice...

f2031 *NONE*

...fax...

f2032 *NONE*

...text...

f2033 *NONE*

...attached file...

f2034 *a2101*

...multi-media...

f2035 *a2068,a2069,a2070,a2071,a2072,a2073,a2074*

To advance to the end of the message, press star 6.

f2036 *a2068,a2069,a2070,a2071,a2072,a2073,a2074*

To rewind to the beginning of this component, press star 5. To advance to the end of this component, press star 6.

f2037 *a2068,a2069,a2070,a2071,a2072,a2073,a2074*

To delete entire message, press star 3.

f2038 *a2075*

Rewound...

f2039 *a2075*

...component.

f2040 *a2075*
To listen, press 3.

f2041 *a2077,a2078,a2079,a2080,a2081,a2082,a2083,a2084,*
a2085,a2086,a2087,a2088
**To customize your mailbox -- for example, to
create or edit your mailing lists, to specify
your printer preferences, or to change your
password, press 5.**

f2042 *a2089,a2090,a2091,a2092*
**To administer your media preference for sorting
incoming messages, press 8.**

f2043 *a2093,a2095*
**You are administering your preferred media type
for sorting incoming messages. Messages with a
primary media type matching your preference
will be presented before other messages,
regardless of the order in which they have been
received.**

f2044 *a2093,a2094,a2097*
**No media preference for sorting incoming
messages has been specified.**

f2045 *a2093,a2094,a2095,a2096*
**For voice, press 1. For fax, press 2. For
text, press 3. For binary files, press 4.**

f2046 *a2093,a2094,a2095,a2096*
**To retain your current preference, press the
pound key.**

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f2047 *a2095,a2096*
Your media preference for sorting incoming messages is...

f2048 *a2095,a2096*
For no preference, press 0.

f2049 *a2097*
...will be your preferred media type.

f2050 *a2098*
Remote user.

f2051 *a2100*
Your password cannot be, the same as your extension number, consecutive digits, or a single repeated digit. Please enter new password and the pound key.

f2052 *a2076*
At beginning of message. To step back to previous message, press star 2. To listen, press 0.

f2053 *a2052,a2053,a2055*
...approximately...

f2054 *a2059*
To re-record, press 1. After recording, press 1 again.

f2055 *NONE*
This selection will take effect next time you login. To re-logon now, press, star, star 7.

f2056 *NONE*
None...

f2057 *a2075*
At beginning of message.

f2058 *a2075*
To step back to previous component, press star 5.

f2059 *a2105*
This machine is unable to send mail to...

f2150 *a2150*
Speak a name.

f2151 *a2151,a2154,a2156,a2159,a2171*
You may add a person by speaking his or her name. To do so, press star-six-zero, wait for the tone, then speak.

f2152 *a2151,a2152,a2156,a2157,a2171,a2172*
To use touchtones to add a person, enter extension and pound sign.

f2153 *a2151,a2152,a2156,a2157,a2171,a2172,a2184,a2188,*
a2189
For name addressing, using touchtones, press star-2.

f2154 *a2152,a2155,a2157,a2160,a2172*
You may add a person by speaking his or her name. To do so, wait for the tone at the end of this menu, then speak.

DEFINITY® R3.2 / INTUITY™ AUDIX® R5.0-1

f2155 *a2153,a2158,a2164,a2165,a2175,a2177,a2179,a2185,*
a2186,a2187,a2190,a2195,a2196,a2197,a2198

Use touchtones to enter the last name, followed by the pound sign.

f2156 *a2154,a2155,a2159,a2160*

To use touchtones to add a person, enter last name, followed by the pound sign.

f2157 *a2152,a2155,a2157,a2160,a2163,a2166,a2172,a2174,*
a2176,a2178,a2180,a2192,a2194

To turn-off speech recognition, and rely on touchtone addressing, press star-six-zero.

f2158 *a2161,a2162,a2164,a2165,a2173,a2175,a2177,a2179,*
a2181,a2182,a2183,a2191,a2193,a2195,a2196,a2197,
a2198

To transfer by speaking the person's name, press star-six-zero, wait for the tone, then speak.

f2159 *a2162,a2163,a2173,a2174,a2191,a2192,a2193,a2194*

To use touchtones to spell the person's name press star-2.

f2160 *a2163,a2166,a2174,a2176,a2178,a2180,a2192,a2194*

To transfer by speaking the person's name, wait for the tone at the end of this menu, then speak.

f2161 *a2163,a2166,a2174,a2176,a2178,a2180,a2192,a2194*

To transfer using touchtones...

f2165 *a2167*

Transferring to ...

f2166 *a2167*
Press any key to cancel.

f2167 *a2168,a2199*
You are choosing between subscribers whose names match your entry. To indicate no subscribers match, delete your entry by pressing star-3. If you need additional help after deleting the entry, press star-4.

f2168 *a2169*
More than three subscribers pronounce their names in this manner.

f2169 *a2169,a2170*
You must use touchtones to enter the destination.

f2170 *a2170*
Speech recognition is not available.