


CODED TOOLS

NOS. 543A TO 554A

TOOL, 543A Manufacture Discontinued.
 Replaced by the No. 569A tool.


TOOL, 544A



1/4" Hex. offset socket wrench.

For use on 245 and 254 type relays, 216 type switches, and 300 to 308 type switches, inclusive.


TOOL, 545A



Adjuster.

For use on 245, 254, 263 and 264 type relays.


TOOL, 546A



Adjuster.

For use on 245 and 254 type relays.

TOOL, 547A




Magnet winding connector.

Used in conjunction with the 360 type tool.

For use on 245 and 254 type relays, 300 and similar type switches and 1 and 2 type timers.

TOOL, 548A




Magnet winding connector.

Used in conjunction with the 360 type tool.

For use on 300 and similar type switches.

TOOL, 549A




Spring adjuster.

For use on 300 and similar type switches.

TOOL, 550A Manufacture Discontinued.
 Replaced by the No. 550B Tool.

SECTION A706.039

TOOL, 550B




Cutover tool.

Replaces the No. 550A tool.

For use on 300 and similar type switches.

TOOL, 551A



Combination wrench.


For use on 1 type timers.

→ TOOL, 552A

P-233336 Knob

P-233340 Washer

P-298647 Nozzle




Oil gun.

For use on 1 type timers and reciprocating bar interrupters.

Bell Telephone Laboratories, Inc.

TOOL, 553A




Lamp extractor.

Replaces the No. 116 tool.

For use in removing switchboard lamps.

TOOL, 554A



Screwdriver dial.

For use in adjusting gain of type K carrier line amplifier J68741A.