




# AKASO KingPad A90 Volume Rocker/Power Button Unit Replacement

This guide will show you how to replace the Volume Rocker/Power Button Unit on the left side of the AKASO KingPad A90 tablet.

Written By: Miles



---

## INTRODUCTION

The Volume Rocker/Power Button Unit can sometimes break, and must then be replaced to continue to be able to adjust the volume.

---

### TOOLS:

- [Tweezers](#) (1)
  - [iFixit Opening Tools](#) (1)
  - [Phillips #000 Screwdriver](#) (1)
  - [Soldering Workstation](#) (1)
  - [Spudger](#) (1)
-

## Step 1 — Volume Rocker/Power Button Unit





- Remove screws
- Insert spudger tool on the middle of the left side, between the white and black plastic
- Slide in a plastic opening tool and use it to further pull the back off.
- Work your way around the edge of the tablet with the plastic opening tool and insert more as needed
- Pull off the back cover

## Step 2



- Remove the broken volume rocker/power button unit.
- Place the new part into the empty slot.

### Step 3



- Replace the back cover with the new part in place.
- Gently press the speaker into place.
- ⚠ Be careful to not let the volume rocker unit fall out of place.
- Replace the screws.