



# Acer Aspire S3 MS2346 Speakers Replacement

Replacement guide for the speakers of an Acer Aspire S3 laptop.

Written By: Nikolas I Steckley



---

## INTRODUCTION

This guide will walk you through removing the speakers. The speakers may need to be removed if they are damaged, or just to access the components beneath them.

---

### TOOLS:


- [Phillips #00 Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
-

## Step 1 — Back Cover




- Remove the 12 5mm Phillips #00 screws.
- Use a plastic opening tool to gently pry open the back panel.
- Gently lift up the back panel, exposing the internals of the laptop.

## Step 2 — Speakers



- Unscrew the 4 1mm PH00 screws attaching the speakers to the frame.

### Step 3



- Gently remove the speakers. Note that the wire connecting them may be lightly glued down. If so, gently pry up.

To reassemble your device, follow these instructions in reverse order.