




Asus G501JW-BHI7N12 Device Page Battery Replacement

Replacing a dying or faulty battery in this model of Asus laptop.

Written By: Bruce Baker





INTRODUCTION

This guide requires a basic toolkit and deals with the battery of a laptop. Replacing your battery could be a good solution if you are running into problems with a shortened battery life or you have a higher quality replacement battery ready.

TOOLS:

- [Anti-Static Wrist Strap](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
-


Step 1 — Battery



⚠ Attach the clip of your anti-static wrist strap to the case of the laptop. This prevents any accidents that could fry the motherboard.

- Remove the four 7.0mm Philips #0 screws around the battery.

Step 2



- Unplug the connector highlighted in this picture by pulling it up and out of its seating, then pull the battery away from the motherboard and remove the battery.

To reassemble your device, follow these instructions in reverse order.