



Asus GL551JW-AH71 Battery Replacement

This guide outline how to replace a battery for a Asus GL551JW-AH71

Written By: William Kelley



INTRODUCTION

This guide outlines how to remove the battery in the Asus GL551JW-AH71. This guide also serves as a prerequisite for guides that require the removal of the back cover.

Step 1 — Battery



- Close the device and lay it upside down.
- ⚠ Unplug the device and make sure the device is powered off before removing the battery.

Step 2



- Move the battery eject button to the right. The battery will be ejected.

Step 3



- Grab the battery and remove it from the device.

To reassemble your device, follow these instructions in reverse order.