




Brentwood TS-292B Bread Grabber Replacement

A replacement guide for the bread grabber on the Brentwood TS-292B.

Written By: Elly Ayala



INTRODUCTION

This guide will show how to remove and replace the bread grabber of the Brentwood TS-292B.

TOOLS:


- [Metal Spudger Set](#) (1)
 - [Phillips #2 Screwdriver](#) (1)
-

Step 1 — Bread Grabber



- Remove all 6mm screws with the Phillips #2 screwdriver from the bottom of the toaster


Step 2



- Pull lever tab away from the toaster with force (after pushing in the small tab located to the left)



i Remove toaster cover carefully

Step 3



- Detach the bundled cable connector by carefully pulling it away from the circuit board

Step 4



- Make sure to keep toasting lever down
- Undo tabs with metal spudger on both sides
- Pinch and carefully remove from toaster

To reassemble your device, follow these instructions in reverse order.