



# Canon PowerShot G1 X Mark II Battery Replacement

This guide shows you how to replace the battery in your Canon Powershot G1 X Mark II.

Written By: John Kulick



---

## INTRODUCTION

This guide shows how to remove the battery from your camera, which is necessary if the battery is faulty or needs to be charged. This replacement is very easy, involves no tools, and requires no disassembly.



### PARTS:

- [Replacement Battery for Canon PowerShot G1 X Mark II](#) (1)
-

## Step 1 — Battery



- Locate the battery housing cover on the bottom of your camera.
- Place a finger on the textured portion of the battery housing cover.
- Slide the cover in the direction that the arrow is pointing.

## Step 2



- Use your finger to pivot the orange tab away from the battery.

## Step 3



- Pull the battery out of the housing with your fingers.

To secure the battery back into its housing, follow these instructions in reverse order.