



Dell Inspiron n5110 - Keyboard Replacement

Dell Inspiron n5110 - Keyboard Replacement

Written By: ZFix



INTRODUCTION

How to remove not working keyboard and install a new one.


[Please SUBSCRIBE to my channel ツ](#)

[video: <http://youtu.be/Tjo2cGmfRpg>]

TOOLS:

- [iFixit Opening Tools](#) (1)
 - [iFixit Tech Knife](#) (1)
-

Step 1 — Keyboard



- Switch off the laptop and remove the battery.
- The Keyboard is held by 4x locking clips.

Step 2



- By using cutter, carefully lift up the one side of the keyboard and start opening the locking clips.

Step 3



- Disconnect the keyboard flex cable and you are ready to install the new one keyboard.



[Please SUBSCRIBE to my channel ツ](#)

To reassemble your device, follow these instructions in reverse order.