




Dell Vostro 3360 Battery Replacement

Written By: Johnathan Hammond



INTRODUCTION

In this guide, we will be showing you how to remove and replace the Battery.

TOOLS:


- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Remove the Screw



- Remove the screw that secures the access panel to the computer.

Step 2 — Remove the Access Panel




- Remove the access panel from the computer.

Step 3 — Remove the Screw



- Remove the screw that secures the keyboard to the chassis.

Step 4 — Prying the Keyboard




- Starting on the right side of the system, use a plastic scribe to pry up the keyboard from the computer.

Step 5 — Flipping the Keyboard




- Flip the keyboard over and lay it on the palmrest.

Step 6 — Lifting the Clip




- Lift the clip to release the keyboard cable and disconnect it from the computer.

Step 7 — Disconnecting the Battery Cable




- Disconnect the battery cable from the system board.

Step 8 — Remove the Screws



- Remove the screws that secure the battery to the system board.

Step 9 — Remove the Battery



- Remove the battery from the computer.