




Dell Vostro 3560 Optical Drive Replacement

Replace the optical drive of your Vostro 3560 laptop

Written By: Max Bareilles




INTRODUCTION

This guide will show you how to replace the optical drive of your Dell Vostro 3560 laptop. Some of this guide was made with information from [this](#) video.

TOOLS:



- [Phillips #00 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Identify your laptop



- Make sure you have the right laptop by checking the sticker.

Step 2 — Remove Battery



- Start with your PC shut off and upside down.
- Pull out tabs.
- Pull up on rail to remove battery.

Step 3 — Remove Back Panel




- Remove the two screws:
 - One M2 Phillips screw (Fixed)
 - One 5-mm M2 Phillips screw

Step 4




- Use a iFixit opening tool to remove the back panel.

Step 5




- From here you can access:
 - The hard drive
 - The RAM.
 - The CD Drive.

Step 6 — Optical Drive






- We will focus on the Optical Drive.

Step 7 — Remove Optical Drive



- Remove the 3-mm M2 Phillips screws.

Step 8



- Pull the optical drive out of the frame.

i If it doesn't come out immediately, you might have to shake it.

To reassemble your device, follow these instructions in reverse order.