



# Dell XPS 12 9Q23 Battery Replacement

This guide will show you how to replace the battery inside the device.


Written By: Kyle Yatsula



 **TOOLS:**

- [T5 Torx Screwdriver](#) (1)
  - [Phillips #00 Screwdriver](#) (1)
-

## Step 1 — Battery




- Pop the center cover open on the bottom cover.
- Remove the center screw with a #00 Phillips screwdriver.
- Use a T5 Torx screwdriver for the remaining screws around the edge of the bottom cover.

## Step 2




- Carefully remove back panel after all screws have been removed.

### Step 3




- After the back panel has been removed, disconnect the battery to prevent electrical shock

### Step 4



- Use a Phillips #00 screwdriver to remove the 8 screws that secure the battery.

## Step 5 — Remove the battery



- Once all the screws have been removed the battery is now safe to extract

To reassemble your device, follow these instructions in reverse order.