



HP Pavilion 15-p046nr Disk Drive Replacement

How to replace the Disk Drive of an HP Pavilion 15-p046nr.

Written By: Betsabe Hernandez



INTRODUCTION

If your disk drive no longer works on your HP Pavilion 15-p046nr, you've come to the right place. This guide will walk you through how to replace your notebook's disk drive. You may need to replace your disk drive if your computer fails to read disks entered into the drive or the drive refuses to open. You will need a Phillips size 00 screwdriver for this guide. Before you get started, be sure to [completely disconnect power from your device.](#)

TOOLS:

- [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Battery



- Flip the laptop over so the bottom is facing up.
- Place your finger on the top left-hand slide button with the lock symbol.
- ⓘ Moving the slide does require some force.
- Slide the button to the right so that an unlocked symbol is visible.

Step 2



- Place your finger or thumb on the top right-hand slide with the battery symbol visible.
- Slide the button to the left.
- ⓘ Moving the slide will require some force.
- Lift the battery off the computer with your thumb.
- ⓘ You will not need to slide the right button with the battery to reinstall the battery.

Step 3 — Disk Drive



- Remove one 7 mm, Phillips #00 screw from the back panel.
- Open the disk drive by gently pulling on the drive.
- Pull the disk drive out and away from the device.

To reassemble your device, follow these instructions in reverse order.