



How to switch to Iview etc on Kogan smart tv

Only YouTube and Netflix on menu. No Iview or SBS on demand or other channels catch up options visible on menu?

Written By: Rick

INTRODUCTION

While viewing ABC tv press the red button on remote to switch to Iview which is not on menu This red button works for all digital tv channels switching through to relative on demand channel. Probably works on other brand smart tv's too.

To reassemble your device, follow these instructions in reverse order.