



# LG A275 Keyboard Replacement

Sometimes the keys on the keyboard can be broken or jammed. This guide will teach you how to replace the keyboard.

Written By: Alec Pierce



---

## INTRODUCTION

If the keys on your phone are stuck or jammed, there could be something blocking the sensors such as pocket lint or paper.

---

### **TOOLS:**

- [iFixit Opening Tools](#) (1)
-

## Step 1 — Keyboard



- First start by removing the front cover of the phone.
- ⓘ On the back you will see a rubber keypad with notches in it.

## Step 2



- Remove the old keypad, and line up the new keypad with the plastic bars on the front of the case.
- ⓘ You should see plastic alignment bars where the keypad should slip into the front of the case.

To reassemble your device, follow these instructions in reverse order.