



Lenovo Tab 4 TB-8504F Battery Replacement

How to replace the battery in a Lenovo Tab 4 8.

Written By: Ivan Chavez



 **TOOLS:**

- [iFixit Opening Picks set of 6](#) (1)
 - [Phillips #000 Screwdriver](#) (1)
 - [Spudger](#) (1)
-

Step 1 — Battery



- Start at the microSD slot.
- Use the opening pick to slide underneath the back cover of the tablet.
- Slide the opening pick around the tablet until the back cover is off.

Step 2



- Remove the 8 screws with a Phillips #000 screwdriver [bit].
 - There is a screw under the blue "s" sticker.
- Remove tape holding plate down.
- Use precision tweezers or your fingers to remove plate.

Step 3



- Remove yellow tape.
- Use a spudger or plastic opening tool to remove the battery's ribbon cable from the motherboard.

Step 4



- Gently pull on the two stretch release adhesive strips. Do not pull up, pull away from battery.
 - Once the tabs are off, lift the battery up from the frame.
- ⚠ Do not bend or puncture the battery.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-04-14 02:52:54 PM (MST).

