# Lenovo ThinkPad Yoga 14 20FY Back Cover Replacement

This guide will show you how to remove the back cover on the Lenovo ThinkPad Yoga 14 20FY.

Written By: Patrick Kramer

This document was generated on 2019-10-16 05:38:58 PM (MST).

© iFixit — CC BY-NC-SA

www.iFixit.com

Page 1 of 4

INTRODUCTION

This guide explains how to safely remove the back panel of the Lenovo ThinkPad Yoga 20FY. It provides the tools needed as well as the quickest and easiest way to complete the task.

🔧 TOOLS:

- Mako Driver Kit - 64 Precision Bits (1)

This document was generated on 2019-10-16 05:38:58 PM (MST).

www.iFixit.com

Step 1 — Back Cover

- Remove the indicated nine M2 x 6 mm nylon-coated screws using a Phillips head screwdriver.

- (i) The screws do not come all the way out. Do not force them out.

Step 2

- After removing all of the screws, gently lift up on all covers to remove the back plate and reveal the interior of the device.

This document was generated on 2019-10-16 05:38:58 PM (MST).

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-10-16 05:38:58 PM (MST).

www.iFixit.com