




Linksys WRT54GL Antenna Assembly Replacement

Written By: Josh Bacon



Step 1 — Antenna Assembly Replacement



- Simply twist the antenna assembly and remove! Very simple!
- Follow steps in reverse order to reassemble.

To reassemble your device, follow these instructions in reverse order.