



Minolta Dimage Xt Battery Replacement

This guide explains how to replace the lithium battery.


Written By: Megan Milam



INTRODUCTION


In the event that the battery needs to be replaced it is necessary to follow the steps of this guide to achieve this goal.

Step 1 — Battery



- Locate the latch labeled BATT SD CARD on the right side of the camera.
- Push the latch in the direction of the arrow, and it will spring open.

Step 2



- Insert the battery into the larger slot until the gray tab (circled in red) clicks and secures the battery.
- To remove the battery, pull the gray tab back until the battery springs free.

When the battery has been removed/inserted, push the latch down, and it will lock into place.