



Nutri Ninja Ninja Blender Duo BL641 Suction Cups Replacement

The suction cups at the bottom of the base can deteriorate over time. This guide will show how to replace them.

Written By: Brian Pham



This document was generated on 2019-10-05 06:05:59 PM (MST).

INTRODUCTION

Suctions cups at the bottom of the base can deteriorate over time. This guide will demonstrate how to replace them.

TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [Star Bit Screwdriver](#) (1)

PARTS:

- [Suction cup](#) (1)

Step 1 — Suction Cups



- Turn the blender upside down.
- Remove all screws that connect the bottom panel to the base of the blender (0.5 inch 5 gauge phillip's head).
 - Note: 2 of the screws will be star shaped (in blue).
- Lift the bottom off of the base.

Step 2



- Pull the damaged suction cup off of its pit.

To reassemble your device, follow these instructions in reverse order.