




Samsung ATIV Book 7 NP740U3E-K01UB Battery Replacement

In this guide you will learn how to replace the battery in your Samsung ATIV Book 7 NP740U3E-K01UB.

Written By: Matthew Kibaru




INTRODUCTION

This is a guide to created to explain how to replace this Samsung laptop's battery. In this guide is important because it is a prerequisite guide to replacement more parts within the laptop.

TOOLS:


- [Phillips #000 Screwdriver](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Backplate




- Remove the ten 5 mm screws that hold the backplate using the Phillips #000 screwdriver.

Step 2




- Remove the backplate.

Step 3 — Battery



- Remove the six 5mm screws that hold the battery by using the Phillips #0 screwdriver.

Step 4



- Disconnect the battery from the motherboard and remove the battery.

To reassemble your device, follow these instructions in reverse order.