




Samsung HMX-F90 Strap Side Outer Casing Replacement

Use this guide to remove the strap side of the outer casing.

Written By: Amir Harb



INTRODUCTION

Use this guide to remove the outer casing of your device.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Battery



- Pull the release tab away from the battery.
- Slide the battery towards the release tab and then pull the battery away from the camcorder.

Step 2 — Strap Side Outer Casing



- Rotate the camcorder so that the strap side is facing you.
- Locate and remove the three 4.5mm Phillips #00 screws around the hand strap.

Step 3




- Rotate the camcorder so that the battery slot is facing you.
- Located in the top left corner of the battery slot, remove the 4.5mm Phillips #00 screw.

Step 4



- Rotate the camcorder so you are looking at the bottom of the camcorder.
- Locate and remove the last three 4.5mm Phillips #00 screws.

Step 5



- With both hands, pull the side strap apart from the rest of the camcorder.

To reassemble your device, follow these instructions in reverse order.