



# Samsung NP-N210-JA02US Wireless Card Replacement

Replace the Wireless Card in your Samsung NP-N210-JA02US.

Written By: Afif Chehabaldeen



---

## INTRODUCTION


If you encounter issues while connecting to wireless internet connections, replacing your wireless card may enable you to access the internet.

---

### TOOLS:

- [Phillips 001 Screwdriver](#) (1)
  - [Phillips #1 Screwdriver](#) (1)
  - [Tweezers](#) (1)
  - [Heavy-Duty Spudger](#) (1)
-

## Step 1 — Battery




- Carefully slide both locking pins to the unlocked position.

## Step 2



- Slide the battery out of its housing.

### Step 3 — Battery Removal



- Remove the following 14 screws:
- Thirteen 5 mm Phillips #1 screws
- One 3.5 mm Phillips #001 screw

### Step 4




- Carefully insert the plastic opening tool in the seam between the lower casing and the chrome bezel.

## Step 5




- Slide the opening tool across all sides of the lower case, and lift it up to remove the case and reveal the internal components.

## Step 6




- Locate the wireless card.

## Step 7




- Remove the 3.5 mm Philips #1 screw.

## Step 8



- Carefully with tweezers, lift both connectors to disconnect them from the wireless card.

## Step 9



- Gently remove the wireless card from its socket.

To reassemble your device, follow these instructions in reverse order.