



Samsung Series 5 3G Chromebook Back Cover Removal

A lot of repairs for the Samsung Series 5 3G Chromebook will require you to remove the back cover. This guide will show you how to do it.

Written By: Helder Avelino




INTRODUCTION

Follow this guide if you want to replace the back cover of your Samsung Series 5 3G Chromebook. Removing the back cover exposes all the internal components of the laptop. This will void your warranty, so use caution and be sure not to damage any of the components inside.

TOOLS:

- [Phillips #1 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
 - [Spudger](#) (1)
-

Step 1 — Back Cover




- Make sure your Chromebook is powered off before you begin.
- Place the laptop on a flat surface with the bottom side facing up.
- Remove the rubber feet from the bottom of the panel. The easiest way to do this is to use your fingernails to pick them out.
- Remove all the seven screws in the bottom panel.

Step 2



- Loosen the back cover panel by using the flathead screwdriver or the spudger.

Step 3



- Once you work your way around, you can remove the panel.

To reassemble your device, follow these instructions in reverse order.