



Sony Betamovie BMC-220 Elecret Condenser Microphone Replacement

This guide describes how to remove the electret condenser microphone located on the right side of the Sony Betamovie BMC-220.

Written By: Jordan Bates



This document was generated on 2020-02-07 04:02:48 AM (MST).

INTRODUCTION

Is your camcorder failing to record audio? Consider using this guide to replace the electret condenser microphone of the device.

Step 1 — Elecret Condenser Microphone



- Hold the black tubing located on the right side of the camera below the eye piece.
- Using your hands, grab the microphone from inside of the tube.
- Pull the microphone out of the plastic tubing.

To reassemble your device, follow these instructions in reverse order.