




Toshiba Satellite C655-S5142 Hard Disk Drive Replacement

This guide will help accomplish with removing the hard drive from a Toshiba Satellite C655-S5142.

Written By: Alex Kozlowski



 **TOOLS:**

- [Phillips Head Screwdriver: Size PH1 \(1\)](#)
-

Step 1 — Hard Disk Drive



 Unplug your computer, and make sure that it is shut off before starting.

- Flip over your laptop, making sure the hard drive is facing you.

Step 2



- Using a Phillips head screwdriver, remove the one screw holding the backplate on.

Step 3



- With a Phillips head screwdriver remove the final screw holding the hard drive in place.

Step 4



- To remove the hard drive, lift up the plastic tap attached to it and slowly pull up using your other hand as support.

To reassemble your device, follow these instructions in reverse order.