



Toshiba Satellite C655D-S5084 Battery Replacement

Installing battery on Toshiba Satellite C655D-S5084.

Written By: Shelby Kunz



INTRODUCTION

If your device has a short battery life, or does not hold a charge at all, you may need to replace your battery. This guide will help you remove your old, worn battery, and replace it with a new, fresh battery in your Toshiba Satellite C655D-S5084.

Step 1 — Battery



- Turn over device to view the underside of the laptop, with the battery closest to you. Unlock the switch on the right side of the battery.

Step 2



- With one hand, unlock and hold the switch on the left of the battery while sliding the battery toward yourself with your other hand to remove it.

To reassemble your device, follow these instructions in reverse order.